

**Instruction Manual
for AC Generators**

QAS18 YdS USA (3 Phase)

Instruction manual.....	3
Circuit diagrams	23

Registration code

Collection: APC Q

Tab : 38

Printed Matter N°

2954 0840 00

01/2004

Atlas Copco

ATLAS COPCO - PORTABLE AIR DIVISION

www.atlascopco.com

Warranty and Liability Limitation

Use only authorized parts.

Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

The manufacturer does not accept any liability for any damage arising for modifications, additions or conversions made without the manufacturer's approval in writing.

Copyright 2003, Atlas Copco Airpower n.v., Antwerp, Belgium.

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

Congratulations on the purchase of your QAS18 AC generator. It is a solid, safe and reliable machine, built according to the latest technology. Follow the instructions in this booklet and we guarantee you years of troublefree operation. Please read the following instructions carefully before starting to use your machine.

While every effort has been made to ensure that the information in this manual is correct, Atlas Copco does not assume responsibility for possible errors. Atlas Copco reserves the right to make changes without prior notice.

CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

CONTENTS

1. Safety precautions for portable generators	4	6. Checks and trouble shooting.....	16
2. Leading particulars	8	6.1. Checking voltmeter P4.....	16
2.1. General description	8	6.2. Checking frequency meter P5.....	16
2.2. Bodywork	9	6.3. Checking ammeters P1.....	16
2.3. Markings.....	9	6.4. Alternator trouble shooting	17
2.4. Drain plugs and filler caps	9	6.5. Engine trouble shooting.....	17
2.5. Control and indicator panel	9	7. Technical specifications	19
2.6. Remote start (RS).....	11	7.1. Readings on gauges	19
2.7. Dip-switches.....	11	7.2. Settings of switches.....	19
2.8. Output connections	11	7.3. Specifications of the engine/alternator/unit	19
2.9. External fuel tank connection	12	7.4. Conversion list of SI units into British units	20
2.10. Triple voltage with switch (TV).....	12	7.5. Dataplate	21
3. Operating instructions.....	12		
3.1. Installation.....	12		
3.2. Connecting the generator	13		
3.3. Before starting	13		
3.4. Starting	14		
3.5. During operation.....	14		
3.6. Stopping	14		
4. Maintenance	15		
4.1. Maintenance schedule	15		
4.2. Engine maintenance.....	15		
4.3. (*) Measuring the alternator insulation resistance	15		
5. Storage of the generator	16		
5.1. Storage	16		
5.2. Preparing for operation after storage	16		

1. SAFETY PRECAUTIONS FOR PORTABLE GENERATORS

To be read attentively and acted accordingly before towing, lifting, operating, performing maintenance or repairing the generator.

1.1 INTRODUCTION

The policy of Atlas Copco is to provide the users of their equipment with safe, reliable and efficient products. Factors taken into account are among others:

- the intended and predictable future use of the products, and the environments in which they are expected to operate,
- applicable rules, codes and regulations,
- the expected useful product life, assuming proper service and maintenance,
- providing the manual with up-to-date information.

Before handling any product, take time to read the relevant instruction manual. Besides giving detailed operating instructions, it also gives specific information about safety, preventive maintenance, etc.

Keep the manual always at the unit location, easy accessible to the operating personnel.

See also the safety precautions of the engine and possible other equipment, which are separately sent along or are mentioned on the equipment or parts of the unit.

These safety precautions are general and some statements will therefore not always apply to a particular unit.

Only people that have the right skills should be allowed to operate, adjust, perform maintenance or repair on Atlas Copco equipment. It is the responsibility of management to appoint operators with the appropriate training and skill for each category of job.

Skill level 1: Operator

An operator is trained in all aspects of operating the unit with the push-buttons, and is trained to know the safety aspects.

Skill level 2: Mechanical technician

A mechanical technician is trained to operate the unit the same as the operator. In addition, the mechanical technician is also trained to perform maintenance and repair, as described in the instruction manual, and is allowed to change settings of the control and safety system. A mechanical technician does not work on live electrical components.

Skill level 3: Electrical technician

An electrical technician is trained and has the same qualifications as both the operator and the mechanical technician. In addition, the electrical technician may carry out electrical repairs within the various enclosures of the unit. This includes work on live electrical components.

Skill level 4: Specialist from the manufacturer

This is a skilled specialist sent by the manufacturer or its agent to perform complex repairs or modifications to the equipment.

In general it is recommended that not more than two people operate the unit, more operators could lead to unsafe operating conditions. Take necessary steps to keep unauthorized persons away from the unit and eliminate all possible sources of danger at the unit.

When handling, operating, overhauling and/or performing maintenance or repair on Atlas Copco equipment, the mechanics are expected to use safe engineering practices and to observe all relevant local safety requirements and ordinances. The following list is a reminder of special safety directives and precautions mainly applicable to Atlas Copco equipment.

Neglecting the safety precautions may endanger people as well as environment and machinery:

- endanger people due to electrical, mechanical or chemical influences,
- endanger the environment due to leakage of oil, solvents or other substances,
- endanger the machinery due to function failures.

All responsibility for any damage or injury resulting from neglecting these precautions or by non-observance of ordinary caution and due care required in handling, operating, maintenance or repair, also if not expressly mentioned in this instruction manual, is disclaimed by Atlas Copco.

The manufacturer does not accept any liability for any damage arising from the use of non-original parts and for modifications, additions or conversions made without the manufacturer's approval in writing.

If any statement in this manual does not comply with local legislation, the stricter of the two shall be applied.

Statements in these safety precautions should not be interpreted as suggestions, recommendations or inducements that it should be used in violation of any applicable laws or regulations.

1.2 GENERAL SAFETY PRECAUTIONS

- 1 The owner is responsible for maintaining the unit in a safe operating condition. Unit parts and accessories must be replaced if missing or unsuitable for safe operation.
- 2 The supervisor, or the responsible person, shall at all times make sure that all instructions regarding machinery and equipment operation and maintenance are strictly followed and that the machines with all accessories and safety devices, as well as the consuming devices, are in good repair, free of abnormal wear or abuse, and are not tampered with.
- 3 Whenever there is an indication or any suspicion that an internal part of a machine is overheated, the machine shall be stopped but no inspection covers shall be opened before sufficient cooling time has elapsed; this to avoid the risk of spontaneous ignition of oil vapor when air is admitted.
- 4 Normal ratings (pressures, temperatures, speeds, etc.) shall be durably marked.
- 5 Operate the unit only for the intended purpose and within its rated limits (pressure, temperature, speeds, etc.).
- 6 The machinery and equipment shall be kept clean, i.e. as free as possible from oil, dust or other deposits.
- 7 To prevent an increase in working temperature, inspect and clean heat transfer surfaces (cooler fins, intercoolers, water jackets, etc.) regularly. See the maintenance schedule.
- 8 All regulating and safety devices shall be maintained with due care to ensure that they function properly. They may not be put out of action.
- 9 Pressure and temperature gauges shall be checked regularly with regard to their accuracy. They shall be replaced whenever outside acceptable tolerances.
- 10 Safety devices shall be tested as described in the maintenance schedule of the instruction manual to determine that they are in good operating condition.
- 11 Mind the markings and information labels on the unit.
- 12 In the event the safety labels are damaged or destroyed, they must be replaced to ensure operator safety.
- 13 Keep the work area neat. Lack of order will increase the risk of accidents.
- 14 When working on the unit, wear safety clothing. Depending on the kind of activities these are: safety glasses, ear protection, safety helmet (including visor), safety gloves, protective clothing, safety shoes. Do not wear the hair long and loose (protect long hair with a hairnet), or wear loose clothing or jewelry.
- 15 Take precautions against fire. Handle fuel, oil and anti-freeze with care because they are inflammable substances. Do not smoke or approach with naked flame when handling such substances. Keep a fire-extinguisher in the vicinity.
- 16a **Portable generators (with earthing pin):**
Earth the generator as well as the load properly.
- 16b **Portable generators IT:**
Note: This generator is built to supply a sheer alternating current IT network.
Earth the load properly.

1.3 SAFETY DURING TRANSPORT AND INSTALLATION

To lift a unit, all loose or pivoting parts, e.g. doors and towbar, shall first be securely fastened.

Do not attach cables, chains or ropes directly to the lifting eye; apply a crane hook or lifting shackle meeting local safety regulations. Never allow sharp bends in lifting cables, chains or ropes.

Helicopter lifting is not allowed.

It is strictly forbidden to dwell or stay in the risk zone under a lifted load. Never lift the unit over people or residential areas. Lifting acceleration and retardation shall be kept within safe limits.

- 1 Before towing the unit:
 - check the towbar, the brake system and the towing eye. Also check the coupling of the towing vehicle,
 - check the towing and brake capability of the towing vehicle,
 - check that the towbar, jockey wheel or stand leg is safely locked in the raised position,
 - ascertain that the towing eye can swivel freely on the hook,
 - check that the wheels are secure and that the tires are in good condition and inflated correctly,
 - connect the signalisation cable, check all lights and connect the pneumatic brake couplers,
 - attach the safety break-away cable or safety chain to the towing vehicle,
 - remove wheel chocks, if applied, and disengage the parking brake.
- 2 To tow a unit use a towing vehicle of ample capacity. Refer to the documentation of the towing vehicle.
- 3 If the unit is to be backed up by the towing vehicle, disengage the overrun brake mechanism (if it is not an automatic mechanism).
- 4 Never exceed the maximum towing speed of the unit (mind the local regulations).
- 5 Place the unit on level ground and apply the parking brake before disconnecting the unit from the towing vehicle. Unclip the safety break-away cable or safety chain. If the unit has no parking brake or jockey wheel, immobilize the unit by placing chocks in front of and/or behind the wheels. When the towbar can be positioned vertically, the locking device must be applied and kept in good order.
- 6 To lift heavy parts, a hoist of ample capacity, tested and approved according to local safety regulations, shall be used.
- 7 Lifting hooks, eyes, shackles, etc., shall never be bent and shall only have stress in line with their design load axis. The capacity of a lifting device diminishes when the lifting force is applied at an angle to its load axis.
- 8 For maximum safety and efficiency of the lifting apparatus all lifting members shall be applied as near to perpendicular as possible. If required, a lifting beam shall be applied between hoist and load.
- 9 Never leave a load hanging on a hoist.
- 10 A hoist has to be installed in such a way that the object will be lifted perpendicular. If that is not possible, the necessary precautions must be taken to prevent load-swinging, e.g. by using two hoists, each at approximately the same angle not exceeding 30° from the vertical.
- 11 Locate the unit away from walls. Take all precautions to ensure that hot air exhausted from the engine and driven machine cooling systems cannot be recirculated. If such hot air is taken in by the engine or driven machine cooling fan, this may cause overheating of the unit; if taken in for combustion, the engine power will be reduced.
- 12 Generators shall be stalled on an even, solid floor, in a clean location with sufficient ventilation. If the floor is not level or can vary in inclination, consult Atlas Copco.
- 13 The electrical connections shall correspond to local codes. The machines shall be earthed and protected against short circuits by fuses or circuit breakers.
- 14 Never connect the generator outlets to an installation which is also connected to a public mains.
- 15 Before connecting a load, switch off the corresponding circuit breaker, and check whether frequency, voltage, current and power factor comply with the ratings of the generator.

1.4 SAFETY DURING USE AND OPERATION

- 1 When the unit has to operate in a fire-hazardous environment, each engine exhaust has to be provided with a spark arrestor to trap incendiary sparks.
- 2 The exhaust contains carbon monoxide which is a lethal gas. When the unit is used in a confined space, conduct the engine exhaust to the outside atmosphere by a pipe of sufficient diameter; do this in such a way that no extra back pressure is created for the engine. If necessary, install an extractor. Observe any existing local regulations. Make sure that the unit has sufficient air intake for operation. If necessary, install extra air intake ducts.
- 3 When operating in a dust-laden atmosphere, place the unit so that dust is not carried towards it by the wind. Operation in clean surroundings considerably extends the intervals for cleaning the air intake filters and the cores of the coolers.
- 4 Never remove a filler cap of the cooling water system of a hot engine. Wait until the engine has sufficiently cooled down.
- 5 Never refill fuel while the unit is running, unless otherwise stated in the Atlas Copco Instruction Book (AIB). Keep fuel away from hot parts such as air outlet pipes or the engine exhaust. Do not smoke when fuelling. When fuelling from an automatic pump, an earthing cable should be connected to the unit to discharge static electricity. Never spill nor leave oil, fuel, coolant or cleansing agent in or around the unit.
- 6 All doors shall be shut during operation so as not to disturb the cooling air flow inside the bodywork and/or render the silencing less effective. A door should be kept open for a short period only e.g. for inspection or adjustment.
- 7 Periodically carry out maintenance works according to the maintenance schedule.
- 8 Stationary housing guards are provided on all rotating or reciprocating parts not otherwise protected and which may be hazardous to personnel. Machinery shall never be put into operation, when such guards have been removed, before the guards are securely reinstalled.
- 9 Noise, even at reasonable levels, can cause irritation and disturbance which, over a long period of time, may cause severe injuries to the nervous system of human beings.
When the sound pressure level, at any point where personnel normally has to attend, is:
below 70 dB(A): no action needs to be taken,
above 70 dB(A): noise-protective devices should be provided for people continuously being present in the room,
below 85 dB(A): no action needs to be taken for occasional visitors staying a limited time only,
above 85 dB(A): room to be classified as a noise-hazardous area and an obvious warning shall be placed permanently at each entrance to alert people entering the room, for even relatively short times, about the need to wear ear protectors,
above 95 dB(A): the warning(s) at the entrance(s) shall be completed with the recommendation that also occasional visitors shall wear ear protectors,
above 105 dB(A): special ear protectors that are adequate for this noise level and the spectral composition of the noise shall be provided and a special warning to that effect shall be placed at each entrance.
- 10 Insulation or safety guards of parts the temperature of which can be in excess of 80 °C (175 °F) and which may be accidentally touched by personnel shall not be removed before the parts have cooled to room temperature.
- 11 Never operate the unit in surroundings where there is a possibility of taking in flammable or toxic fumes.
- 12 If the working process produces fumes, dust or vibration hazards, etc., take the necessary steps to eliminate the risk of personnel injury.

- 13 When using compressed air or inert gas to clean down equipment, do so with caution and use the appropriate protection, at least safety glasses, for the operator as well as for any bystander. Do not apply compressed air or inert gas to your skin or direct an air or gas stream at people. Never use it to clean dirt from your clothes.
- 14 When washing parts in or with a cleaning solvent, provide the required ventilation and use appropriate protection such as a breathing filter, safety glasses, rubber apron and gloves, etc.
- 15 Safety shoes should be compulsory in any workshop and if there is a risk, however small, of falling objects, wearing of a safety helmet should be included.
- 16 If there is a risk of inhaling hazardous gases, fumes or dust, the respiratory organs must be protected and depending on the nature of the hazard, so must the eyes and skin.
- 17 Remember that where there is visible dust, the finer, invisible particles will almost certainly be present too; but the fact that no dust can be seen is not a reliable indication that dangerous, invisible dust is not present in the air.
- 18 Never operate the generator in excess of its limits as indicated in the technical specifications and avoid long no-load sequences.
- 19 Never operate the generator in a humid atmosphere. Excessive moisture causes worsening of the generator insulation.
- 20 Do not open electrical cabinets, cubicles or other equipment while voltage is supplied. If such cannot be avoided, e.g. for measurements, tests or adjustments, have the action carried out by a qualified electrician only, with appropriate tools, and ascertain that the required bodily protection against electrical hazards is applied.
- 21 Never touch the power terminals during operation of the machine.
- 22 Whenever an abnormal condition arises, e.g. excessive vibration, noise, Adour, etc., switch the circuit breakers to OFF and stop the engine. Correct the faulty condition before restarting.
- 23 Check the electric cables regularly. Damaged cables and insufficient lightening of connections may cause electric shocks. Whenever damaged wires or dangerous conditions are observed, switch the circuit breakers to OFF and stop the engine. Replace the damaged wires or correct the dangerous condition before restarting. Make sure that all electric connections are securely tightened.
- 24 Avoid overloading the generator. The generator is provided with circuit breakers for overload protection. When a breaker has tripped, reduce the concerned load before restarting.
- 25 If the generator is used as stand-by for the mains supply, it must not be operated without control system which automatically disconnects the generator from the mains when the mains supply is restored.
- 26 Never remove the cover of the output terminals during operation. Before connecting or disconnecting wires, switch off the load and the circuit breakers, stop the machine and make sure that the machine cannot be started inadvertently or there is any residual voltage on the power circuit.
- 27 Running the generator at low load for long periods will reduce the lifetime of the engine.

1.5 SAFETY DURING MAINTENANCE AND REPAIR

Maintenance, overhaul and repair work shall only be carried out by adequately trained personnel; if required, under supervision of someone qualified for the job.

- 1 Use only the correct tools for maintenance and repair work, and only tools which are in good condition.
- 2 Parts shall only be replaced by genuine Atlas Copco replacement parts.
- 3 All maintenance work, other than routine attention, shall only be undertaken when the unit is stopped. Steps shall be taken to prevent inadvertent starting. In addition, a warning sign bearing a legend such as "work in progress; do not start" shall be attached to the starting equipment. On engine-driven units the battery shall be disconnected and removed or the terminals covered by insulating caps. On electrically driven units the main switch shall be locked in open position and the fuses shall be taken out. A warning sign bearing a legend such as "work in progress; do not supply voltage" shall be attached to the fuse box or main switch.
- 4 Prior to stripping an engine or other machine or undertaking major overhaul on it, prevent all movable parts from rolling over or moving.
- 5 Make sure that no tools, loose parts or rags are left in or on the machine. Never leave rags or loose clothing near the engine air intake.
- 6 Never use flammable solvents for cleaning (fire-risk).
- 7 Take safety precautions against toxic vapors of cleaning liquids.
- 8 Never use machine parts as a climbing aid.
- 9 Observe scrupulous cleanliness during maintenance and repair. Keep away dirt, cover the parts and exposed openings with a clean cloth, paper or tape.
- 10 Never weld on or perform any operation involving heat near the fuel or oil systems. Fuel and oil tanks must be completely purged, e.g. by steam-cleaning, before carrying out such operations. Never weld on, or in any way modify, pressure vessels. Disconnect the alternator cables during arc welding on the unit.
- 11 Support the towbar and the axle(s) securely if working underneath the unit or when removing a wheel. Do not rely on jacks.
- 12 Do not remove any of, or tamper with, the sound-damping material. Keep the material free of dirt and liquids such as fuel, oil and cleansing agents. If any sound-damping material is damaged, replace it to prevent the sound pressure level from increasing.
- 13 Use only lubricating oils and greases recommended or approved by Atlas Copco or the machine manufacturer. Ascertain that the selected lubricants comply with all applicable safety regulations, especially with regard to explosion or fire-risk and the possibility of decomposition or generation of hazardous gases. Never mix synthetic with mineral oil.
- 14 Protect the engine, alternator, air intake filter, electrical and regulating components, etc., to prevent moisture ingress, e.g. when steam-cleaning.
- 15 When performing any operation involving heat, flames or sparks on a machine, the surrounding components shall first be screened with non-flammable material.

- 16 Never use a light source with open flame for inspecting the interior of a machine.
- 17 When repair has been completed, the machine shall be barred over at least one revolution for reciprocating machines, several revolutions for rotary ones to ensure that there is no mechanical interference within the machine or driver. Check the direction of rotation of electric motors when starting up the machine initially and after any alteration to the electrical connection(s) or switch gear, to check that the oil pump and the fan function properly.
- 18 Maintenance and repair work should be recorded in an operator's logbook for all machinery. Frequency and nature of repairs can reveal unsafe conditions.
- 19 When hot parts have to be handled, e.g. shrink fitting, special heat-resistant gloves shall be used and, if required, other body protection shall be applied.
- 20 When using cartridge type breathing filter equipment, ascertain that the correct type of cartridge is used and that its useful service life is not surpassed.
- 21 Make sure that oil, solvents and other substances likely to pollute the environment are properly disposed of.
- 22 Before clearing the generator for use after maintenance or overhaul, submit it to a testrun, check that the AC power performance is correct and that the control and shut down devices function correctly.

1.6 TOOL APPLICATIONS SAFETY

Apply the proper tool for each job. With the knowledge of correct tool use and knowing the limitations of tools, along with some common sense, many accidents can be prevented.

Special service tools are available for specific jobs and should be used when recommended. The use of these tools will save time and prevent damage to parts.

1.7 BATTERY SAFETY PRECAUTIONS

Batteries

When servicing batteries, always wear protecting clothing and glasses.

- 1 The electrolyte in batteries is a sulfuric acid solution which is fatal if it hits your eyes, and which can cause burns if it contacts your skin. Therefore, be careful when handling batteries, e.g. when checking the charge condition.
- 2 Install a sign prohibiting fire, open flame and smoking at the post where batteries are being charged.
- 3 When batteries are being charged, an explosive gas mixture forms in the cells and might escape through the vent holes in the plugs. Thus an explosive atmosphere may form around the battery if ventilation is poor, and can remain in and around the battery for several hours after it has been charged. Therefore:
 - never smoke near batteries being, or having recently been, charged,
 - never break live circuits at battery terminals, because a spark usually occurs.
- 4 When connecting an auxiliary battery (AB) in parallel to the unit battery (CB) with booster cables: connect the + pole of AB to the + pole of CB, then connect the - pole of CB to the mass of the unit. Disconnect in the reverse order.

2.5.2 Generator gauges

P1..... Ammeter line L1

Indicates the outgoing current in the first line (L1).

P2..... Ammeter line L2

Indicates the outgoing current in the second line (L2).

P3..... Ammeter line L3

Indicates the outgoing current in the third line (L3).

P4..... Voltmeter

Indicates the voltage selected by means of voltage selector switch S4.


P5..... Frequency / RPM meter

Indicates the frequency of the supply voltage and the speed of the engine.

S4..... Voltmeter selector switch




Allows to measure the voltage between each of the phases and between each phase and the neutral. It also allows to switch off the voltmeter.

2.5.3 Engine controls and lamps





ST..... Starter switch

The starter switch is a three-position switch.

-  : used to select normal start and to disable remote start
-  : used to switch off the power supply from the battery or to reset after a shut down due to a failure. The unit will not be able to start up.
-  : used to select remote start.



After approximately 20 seconds in position  without starting, the control system will automatically shut down (battery saving purpose) indicating a low oil pressure failure. In this case, a reset of the control system by putting the switch in position  is necessary.

F4 Fuse

The fuse activates when the current from the battery to the engine control circuit exceeds its setting. The fuse can be switched on and off by pushing the button.

L1 Electrical system indicator

Lights up when the electrical system of the engine is energized.

L2 Engine preheating system indicator

Lights up when the glow plugs in the engine, used to facilitate starting, are warming up. Extinguishes after approximately 10 seconds. Bypassing of the preheattime is allowed e.g. when starting a hot engine, but the preheat system remains active.

L3 Alternator charging indicator

Goes out after starting, indicating that the alternator is charging. A failing alternator however will not shut the engine down.

L4 AC shut down indicator

Lights up when no AC input (< 75 V line-to-neutral) is present.

L5 Overspeed shut down indicator

Lights up when the engine's speed has exceeded 115 % of the nominal speed.

L6 Engine coolant temperature fault indicator

Lights up when the high engine coolant temperature was the cause of shut down.

L7 Engine oil pressure fault indicator

Lights up when the low engine oil pressure was the cause of shut down.

L8 Spare shut down indicator

Can be used to wire an extra shut down, e.g. for low fuel level in case a switch is incorporated in the fuel tank.

R11.... Output voltage adjust potentiometer

Allows to adjust the output voltage. R11 is located on the control and indicator panel.

2.6 REMOTE START (RS)

"Remote start" allows to switch the unit on or off without using the control panel located on the unit. The start module of the control panel provides extra connections for the remote start/stop switch and the plant contactor (voltage free contact), both to be installed by the customer.



The plant contactor should be sized according to the load. The maximum current through the voltage free contact is 3 A.


The remote start/stop switch Sx has to meet the following specifications: 12 V DC, 4 A.

Refer to the circuit diagram for the correct connection of the plant contactor and the remote start/stop switch.

A shunt trip coil will switch off Q1.1 or Q1.2 (depending on the mode the unit is running in) in case of an emergency stop or an earth fault.


2.7 DIP-SWITCHES

For correct functioning of the module, the DIP switches at the back of the control module should be positioned as follows:



2.8 OUTPUT CONNECTIONS

The output connections are situated below the control and indicator panel.



S2.....Emergency stop button

Push the button to stop the generator in case of an emergency. When the button is pressed, it must be unlocked, by turning it anti-clockwise, before the generator can be restarted.

Q1.1...Circuit breaker for low voltage

Interrupts the low voltage power supply towards X1, X2, X3 and X4 when a short-circuit occurs at the load side, or when the overcurrent protection (50 A) is activated. It must be reset manually after eliminating the problem.

Q1.2...Circuit breaker for high voltage

Interrupts the high voltage power supply towards X1, X2, X3 and X4 when a short-circuit occurs at the load side, or when the overcurrent protection (25 A) is activated. It must be reset manually after eliminating the problem.

Q4.....Circuit breaker for X4

Interrupts line L1 and L2 towards the power supply X4 when a short-circuit occurs at the load side, or when the overcurrent protection (20 A) is activated. It must be reset manually after eliminating the problem.

X1.....Main power supply - Terminal board

Terminals L1, L2, L3, N (=neutral) and PE (=grounding), hidden behind the control panel door and behind a small transparent door.

X2.....Single phase outlet socket

Provides lines L1, L2, and N (=neutral).

X3.....Single phase outlet socket

Provides lines L1, L2, and N (=neutral).

X4.....Single phase outlet socket

Provides lines L2, N (=neutral) and PE (=grounding).

X25....Connection block

Allows easy connection for a remote start switch.




Refer to the circuit diagrams for the correct connection.


2.9 EXTERNAL FUELTANK CONNECTION

The "External fueltank connection" allows to bypass the internal fueltank and to connect an external fueltank to the unit.

When using an external fueltank, make sure to connect the fuel supply line as well as the fuel return line. Always put both valves in the same position (either internal or external tank) and make sure that they are in the extreme (horizontal) position. Connections to fuel-lines ought to be air-tight to prevent air from entering the fuel system.



Indicates the fuel supply line from the tank to the engine.



Indicates the fuel return line from the engine to the tank.



Indicates the internal fueltank.



Indicates the external fueltank.

2.10 TRIPLE VOLTAGE WITH SWITCH (TV)

The generator can run in three different modes:

- 1 phase
- 3 phase, lower voltage
- 3 phase, higher voltage

Depending on which mode the generator is running in, circuit breaker Q1.1 or Q1.2 will be operational.

Circuit breakers Q1.1 and Q1.2 cannot be switched on at the same time. This is prevented by means of the auxiliary voltage selection relays K11 and K12 (refer to the circuit diagram).

The selection between the three modes is done by means of S10.

S10.... Output voltage selector switch

Allows to select a 3 phase high output voltage, a 3 phase low output voltage or a 1 phase low output voltage. Selector switch S10 is located on the alternator.



Changing the output voltage is only allowed after shutdown.

After changing the output voltage by means of the selection switch S10, adjust the output voltage by means of potentiometer R11 to the required value.

1 phase

When using this selection, the generator provides a 240 V output voltage.

3 phase lower voltage

When using this selection, the generator provides a 208 V output voltage.

3 phase higher voltage

When using this selection, the generator provides a 480 V output voltage.

3. OPERATING INSTRUCTIONS



In your own interest, always strictly observe all relevant safety instructions.

Do not operate the generator in excess of the limitations mentioned in the Technical Specifications.

Local rules concerning the setting up of low voltage power installations (below 1,000 V) must be respected when connecting site distribution panels, switch gear or loads to the generator.

At each start-up and at any time a new load is connected, the earthing of the generator must be verified. Earthing must be done either by the earthing rod or, if available, by an existing, suitable earthing installation. The protective system against excessive contact voltage is not effective unless a suitable earthing is made.

The generator is wired for a TN-system to IEC 364-3, i.e. one point in the power source directly earthed - in this case the neutral. The exposed conductive parts of the electric installation must be directly connected to the functional earth.

If operating the generator in another power system, e.g. an IT-system, other protective devices required for these types must be installed. In any case only a qualified electrician is authorized to remove the connection between the neutral (N) and earth terminals in the terminal box of the alternator.

3.1 INSTALLATION

- Place the generator on a horizontal, even and solid floor.
- Protect the generator against dust and rain if it is operated outside.
- Check that the engine exhaust is not directed towards people. If the generator is operated indoors, install an exhaust pipe of sufficient diameter to duct the engine exhaust towards the outside. Check for sufficient ventilation so that the cooling air is not recirculated. If necessary, consult Atlas Copco.
- Leave enough space for operation, inspection and maintenance (at least 1 meter at each side).
- Check that the inner earthing system is in compliance with the local legislation.
- Use coolant for the engine cooling system. Refer to the Engine instruction book for the proper coolant mixture.
- Check the tightness of the bolts and nuts.

3.2 CONNECTING THE GENERATOR

3.2.1 Precautions for non-linear and sensitive loads



Non-linear loads draw currents with high contents in harmonics, causing distortion in the wave form of the voltage generated by the alternator.

The most common non-linear, 3-phase loads are thyristor/rectifier-controlled loads, such as convertors supplying voltage to variable speed motors, uninterruptable power supplies and Telecom supplies. Gas-discharge lighting arranged in single-phase circuits generate high 3rd harmonics and risk for excessive neutral current.

Loads most sensitive to voltage distortion include incandescent lamps, discharge lamps, computers, X-ray equipment, audio amplifiers and elevators.

Consult Atlas Copco for measures against the adverse influence of non-linear loads.

3.2.2 Quality, minimum section and maximum length of cables

The cable connected to the terminal board of the generator must be selected in accordance with local legislation. The type of cable, its rated voltage and current carrying capacity are determined by installation conditions, stress and ambient temperature. For flexible wiring, rubber-sheathed, flexible core conductors must be used.

3.2.3 Connecting the load

Site distribution panel

If outlet sockets are required, they must be mounted on a site distribution panel supplied from the terminal board of the generator and in compliance with local regulations for power installations on building sites.

Protection



For safety reasons, it is necessary to provide an isolating switch or circuit breaker in each load circuit. Local legislation may impose the use of isolating devices which can be locked.


- Check whether frequency, voltage and current comply with the ratings of the generator.
- Provide for the load cable, without excessive length, and lay it out in a safe way without forming coils.
- Open the door of the control and indicator panel and the transparent door in front of the terminal board X1.
- Provide the wire ends with cable lugs suited for the cable terminals.
- Loosen the cable clamp and push the wire ends of the load cable through the orifice and clamp.
- Connect the wires to the proper terminals (L1, L2, L3, N and PE) of X1 and tighten the bolts securely.
- Tighten the cable clamp.
- Close the transparent door in front of X1.

3.3 BEFORE STARTING


- With the generator standing level, check the engine oil level and top up if necessary. The oil level must be near to, but not exceed the high mark on the engine oil level dipstick.
- Check the coolant level in the expansion tank of the engine cooling system. The water level must be near to the FULL mark. Add coolant if necessary.
- Drain any water and sediment from the fuel pre-filter. Check the fuel level and top up if necessary. It is recommended to fill the tank after the day's operation to prevent watervapor in a nearly empty tank from condensing.
- Check the vacuum indicator of the air filter. If the red part shows completely, replace the filter element.
- Press the vacuator valve of the air filter to remove dust.
- Check the generator for leakage, tightness of wire terminals, etc. Correct if necessary.
- Check that fuse F4 is not activated and that the emergency stop is in the "OUT" position.
- Check that the load is switched off.
- Check that circuit breakers Q1.1 and Q1.2 are switched off.
- Check the correct position of the voltage selector switch (S10) on the alternator.

3.4 STARTING

To start up the unit locally, without using the remote start/stop switch, proceed as follows:


- Put the starter switch in position . The unit starts a preheating cycle which takes 12 seconds.
- After the preheating period, the unit will start. The starting attempt will take maximum 12 seconds. If the unit does not start immediately, it will perform another two starting attempts.
- Approximately 15 seconds after starting (stabilization time for the generator), the timer relay closes the voltage free contact and the plant contactor is energized (if installed).
- Check that the warning lamps on the control and indicator panel are out. Refer to “Control and indicator panel” for component locations.
- Run the engine for approximately 5 minutes to warm up.
- Check the engine oil pressure (P9) and the cooling water temperature (P8).
- Check the voltmeter P4 (with voltmeter selector switch S4 in different positions) and the frequency meter P5.
- Switch on circuit breaker Q1.1 or Q1.2, depending on the mode the generator is running in.
- Switch on the load and check the ammeters P1, P2 and P3, voltmeter P4 (voltmeter selector switch S4 in different positions) and the frequency meter P5.

To start up the unit from a remote location using the remote start/stop switch, proceed as follows:

- Put the starter switch in position .
- Switch on circuit breakers Q1.1 or Q1.2, depending on the mode the unit is running in.
- Put the remote start/stop switch in position start. The unit starts a preheating cycle which takes 12 seconds.
- After the preheating period, the unit will start. The starting attempt will take maximum 12 seconds.
- Approximately 15 seconds after starting (stabilization time for the generator), the timer relay closes the voltage free contact and the plant contactor is energized (if installed).
- Check that the warning lamps on the control and indicator panel are out. Refer to “Control and indicator panel” for component locations.
- Run the engine for approximately 5 minutes to warm up.
- Check the engine oil pressure (P9) and the cooling water temperature (P8).
- Check the voltmeter P4 (with voltmeter selector switch S4 in different positions) and the frequency meter P5.
- Switch on the load and check the ammeters P1, P2 and P3, voltmeter P4 (voltmeter selector switch S4 in different positions) and the frequency meter P5.

3.5 DURING OPERATION

Following points should be carried out regularly:

- Check the engine gauges and the lamps for normal readings.
-  **Avoid to let the engine run out of fuel. If it happened, priming will speed up the starting.**
- Check for leakage of oil, fuel or cooling water.
 - Avoid long low-load periods (< 30 %). In this case, an output drop and higher oil consumption of the engine could occur.
 - Check, by means of the generator gauges, that the voltage between the phases is identical and that the rated current per phase is not exceeded.
 - When single-phase loads are connected to the generator output terminals, keep all loads well-balanced (in 3 phase output voltage mode).
 - If circuit breakers are activated during operation, switch off the load and stop the generator. Check and, if necessary, decrease the load.



The generator's side doors may only remain opened for short periods during operation, to carry out checks for example.

3.6 STOPPING

To stop the unit when the starter switch is in position , proceed as follows:

- Switch off the load.
- Switch off circuit breakers Q1.1 or Q1.2, depending on the mode the unit is running in.
- Let the engine run for about 5 minutes.
- Stop the engine by putting the starter switch in position O.

To stop the unit when the starter switch is in position , proceed as follows:

- Switch off the load.
- Let the engine run for about 5 minutes.
- Stop the engine by putting the remote start/stop switch in position stop or by putting the starter switch in position O.



Lock the side doors and the door of the indicators and control panel to avoid unauthorized access.

4. MAINTENANCE



Before carrying out any maintenance activity, check that the start switch is in position **O** and that no electrical power is present on the terminals.

4.1 MAINTENANCE SCHEDULE	Daily	Initial	Small	Normal	Yearly
		<i>50 hours</i>	<i>250 hours</i>	<i>500 hours</i>	<i>2000 hours</i>
SERVICE PAK	-	With unit	2912 4249 05	2912 4250 06	2912 4251 07
For the most important subassemblies, Atlas Copco has developed service kits that combine all wear parts. These service kits offer you the benefits of genuine parts, save on administration costs and are offered at reduced price, compared to the loose components. Refer to the parts list for more information on the contents of the service kits.					
Coolant level	Check	Check	Check	Check	Check
Tension and condition of drive belt(s)		Check	Check	Check	Replace
Radiator and intercooler fins		Check/Clean	Check/Clean	Check/Clean	Check/Clean
Fuel pre-filter/Water separator	Check/Drain	Check/Drain	Check/Drain	Check/Drain	Check/Drain
Fuel filter element		Replace	Replace	Replace	Replace
Fuel injectors					Check
Oil level in sump	Check	Check	Check	Check	Check
Oil pressure on gauge	Check	Check	Check	Check	Check
Lubrication oil		Change	Change	Change	Change
Oil filter(s)		Replace	Replace	Replace	Replace
Air cleaner and dust bowl		Clean	Clean	Clean	Clean
Air filter element (1)			Clean	Replace	Replace
Safety cartridge					Replace
Valve clearance		Check/adjust	Check/adjust	Check/adjust	Check/adjust
Oil, fuel and water leaks		Check	Check	Check	Check
Mechanical links (e.g. fuel solenoid link)			Grease	Grease	Grease
Level battery electrolyte (2)		Check	Check	Check	Check
Condition of vibration dampers		Check	Check	Check	Check
Alternator insulation resistance (*)		Measure	Measure	Measure	Measure
Tightness of nuts and bolts		Check			Check
Door hinges and locks		Grease			Grease
Fixation of hoses, cables and pipes				Check	Check
Inspection by Atlas Copco Service technician					

(1) More frequently when operating in a dusty environment. Evacuate dust from the airfilter valve daily.

(2) A Service Bulletin (ASB) dealing elaborately with batteries and due care is available on request.

4.2 ENGINE MAINTENANCE

Refer to the engine's operator manual for full maintenance, including instructions for changing the oil and cooling water and replacing the fuel, oil and air filters.

4.3 (*)MEASURING THE ALTERNATOR INSULATION RESISTANCE

A 500 V megger is required to measure the alternator insulation resistance.

If the N-terminal is connected to the earthing system, it must be disconnected from the earth terminal. Disconnect the AVR. Disconnect the radio interference suppressor.

Connect the megger between the earth terminal and terminal L1 and generate a voltage of 500 V. The scale must indicate a resistance of at least 5 MΩ.

Refer to the alternator operating and maintenance instructions for more details.

5. STORAGE OF THE GENERATOR

5.1 STORAGE

- Store the generator in a dry, frost-free room which is well ventilated.
- Run the engine regularly, e.g. once a week, until it is warmed up. If this is impossible, extra precautions must be taken:
 - Consult the engine's operator manual.
 - Remove the battery. Store it in a dry, frost-free room. Keep the battery clean and its terminals lightly covered with petroleum jelly. Recharge the battery regularly.
 - Clean the generator and protect all electrical components against moisture.
 - Place silicagel bags, VCI paper (Volatile Corrosion Inhibitor) or another drying agent inside the generator and close the doors.
 - Stick sheets of VCI paper with adhesive tape on the bodywork to close off all openings.
 - Wrap the generator, except the bottom, with a plastic bag.

5.2 PREPARING FOR OPERATION AFTER STORAGE

Before operating the generator again, remove the wrapping, VCI paper and silicagel bags and check the generator thoroughly (go through the checklist "Before starting").

- Consult the engine's operator manual.
- Check that the insulation resistance of the generator exceeds 5 MΩ.
- Replace the fuel filter and fill the fuel tank. Vent the fuel system.
- Reinstall and connect the battery, if necessary after being recharged.
- Submit the generator to a test run.

6. CHECKS AND TROUBLE SHOOTING



Never perform a test run with connected power cables. Never touch an electrical connector without a voltage check.

When a failure occurs, always report what you experienced before, during and after the failure. Information with regard to the load (type, size, power factor, etc.), vibrations, exhaust gas colour, insulation check, odours, output voltage, leaks and damaged parts, ambient temperature, daily and normal maintenance and altitude might be helpful to quickly locate the problem. Also report any information regarding the humidity and location of the generator (e.g. close to sea).

6.1 CHECKING VOLTMETER P4

- Put a voltmeter in parallel with voltmeter P4 on the control panel.
- Check that the read-out of both voltmeters is the same.
- Stop the generator and disconnect one terminal.
- Check that the internal resistance of the voltmeter is high.

6.2 CHECKING FREQUENCY METER P5

- Run the unit at normal speed.
- Put a voltmeter in parallel with frequency meter P5.
- If the measured voltage is higher than 200 V, the frequency meter has to work properly.

If not, remove the frequency meter, connect it with the mains (230 V) and check that it indicates 50 Hz.

6.3 CHECKING AMMETERS P1

- Measure during the load, by means of a clamp-on probe, the outgoing current in the three phases.
- Compare the measured current with the current indicated on ammeters on the corresponding ammeters P1, P2 and P3. Both readings should be the same.

6.4 ALTERNATOR TROUBLE SHOOTING

Symptom	Possible cause	Corrective action
<i>Alternator does not excite.</i>	Blown fuse. Insufficient residual voltage. No residual voltage.	Replace fuse. Increase the speed by 15 %. For an instant apply on the + and – terminals of the electronic regulator a 12 V battery voltage with a 30 Ω resistor in series respecting the polarities.
<i>After being excited alternator does not excite.</i>	Connections are interrupted.	Check connection cables as per attached drawings.
<i>Low voltage at no load.</i>	Voltage potentiometer out of setting. Intervention of protection. Winding failure.	Reset voltage. Check rpm. Check windings.
<i>High voltage at no load.</i>	Voltage potentiometer out of setting. Failed regulator.	Reset voltage. Substitute regulator.
<i>Lower than rated voltage at load.</i>	Voltage potentiometer out of setting. Intervention by protection. Failed regulator. Rotating bridge failure.	Reset voltage potentiometer. Current too high, power factor lower than 0.8; speed lower than 10 % of rated speed. Substitute regulator. Check diodes, disconnect cables.
<i>Higher than rated voltage at load.</i>	Voltage potentiometer out of setting. Loose sensing wires on AVR. Failed regulator.	Reset voltage potentiometer. Check sensing wires on AVR. Substitute regulator.
<i>Unstable voltage.</i>	Speed variation in engine. Regulator out of setting.	Check regularity of rotation. Regulate stability of regulator by acting on “STABILITY” potentiometer.

6.5 ENGINE TROUBLE SHOOTING

The table below gives an overview of the possible engine problems and their possible causes.

6.5.1 The starter motor turns the engine too slowly

- Battery capacity too low.
- Bad electrical connection.
- Fault in starter motor.
- Wrong grade of lubricating oil.

6.5.2 The engine does not start or is difficult to start

- Starter motor turns engine too slowly.
- Fuel tank empty.
- Fault in fuel control solenoid.
- Restriction in a fuel pipe.
- Fault in fuel lift pump.
- Dirty fuel filter element.
- Air in fuel system.
- Fault in atomizers.

- Cold start system used incorrectly.
- Fault in cold start system.
- Restriction in fuel tank vent.
- Wrong type or grade of fuel used.
- Restriction in exhaust pipe.

6.5.3 Not enough power

- Restriction in a fuel pipe.
- Fault in fuel lift pump.
- Dirty fuel filter element.
- Restriction in air filter/cleaner or induction system.
- Air in fuel system.
- Fault in atomizers or atomizers of an incorrect type.
- Restriction in fuel tank vent.
- Wrong type or grade of fuel used.
- Restricted movement of engine speed control.
- Restriction in exhaust pipe.
- Engine temperature is too high.
- Engine temperature is too low.

6.5.4 Misfire

- Restriction in a fuel pipe.
- Fault in fuel lift pump.
- Dirty fuel filter element.
- Air in fuel system.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Engine temperature is too high.
- Incorrect valve tip clearances.

6.5.5 The pressure of the lubricating oil is too low

- Wrong grade of lubricating oil.
- Not enough lubricating oil in sump.
- Defective gauge.
- Dirty lubricating oil filter element.

6.5.6 High fuel consumption

- Restriction in air filter/cleaner or induction system.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Wrong type or grade of fuel used.
- Restricted movement of engine speed control.
- Restriction in exhaust pipe.
- Engine temperature is too low.
- Incorrect valve tip clearances.

6.5.7 Black exhaust smoke

- Restriction in air filter/cleaner or induction system.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Wrong type or grade of fuel used.
- Restriction in exhaust pipe.
- Engine temperature is too low.
- Incorrect valve tip clearances.
- Engine overload.

6.5.8 Blue or white exhaust smoke

- Wrong grade of lubricating oil.
- Fault in cold start system.
- Engine temperature is too low.

6.5.9 The engine knocks

- Fault in fuel lift pump.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Wrong type or grade of fuel used.
- Engine temperature is too high.
- Incorrect valve tip clearances.

6.5.10 The engine runs erratically

- Fault in fuel control.
- Restriction in a fuel pipe.
- Fault in fuel lift pump.
- Dirty fuel filter element.
- Restriction in air filter/cleaner or induction system.
- Air in fuel system.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Restriction in fuel tank vent.
- Restricted movement of engine speed control.
- Engine temperature is too high.
- Incorrect valve tip clearances.

6.5.11 Vibration

- Fault in atomizers or atomizers of an incorrect type.
- Restricted movement of engine speed control.
- Engine temperature is too high.
- Fan damaged.
- Fault in engine mounting or flywheel housing.

6.5.12 The pressure of the lubricating oil is too high

- Wrong grade of lubricating oil.
- Defective gauge.

6.5.13 The engine temperature is too high

- Restriction in air filter/cleaner or induction system.
- Fault in atomizers or atomizers of an incorrect type.
- Fault in cold start system.
- Restriction in exhaust pipe.
- Fan damaged.
- Too much lubricating oil in sump.
- Restriction in air or water passages of radiator.
- Insufficient coolant in system.

6.5.14 Crankcase pressure

- Restriction in breather pipe.
- Vacuum pipe leaks or fault in exhauster.

6.5.15 Bad compression

- Restriction in air filter/cleaner or induction system.
- Incorrect valve tip clearances.

6.5.16 The engine starts and stops

- Dirty fuel filter element.
- Restriction in air filter/cleaner or induction system.
- Air in fuel system.

6.5.17 The engine shuts down after approximately 15 seconds

- Bad connection towards oil pressure switch/coolant temperature switch.
- DIP switch on back of module wrong positioned.

7. TECHNICAL SPECIFICATIONS

7.1 READINGS ON GAUGES

<i>Gauge</i>	<i>Reading</i>	<i>US</i>	<i>Metric</i>
Ammeter L1 (P1)	Below max. rating	A	A
Ammeter L2 (P2)	Below max. rating	A	A
Ammeter L3 (P3)	Below max. rating	A	A
Voltmeter (P4)	Depends upon selector switch	V	V
Frequency meter (P5)	Between 60 and 62.5	Hz	Hz
Hourmeter (P6)	Adding up	h	h
Fuel level (P7)	Above 0	Fuel tank full	Fuel tank full
Engine temperature (P8)	Below 221 °F or 105 °C	°F	°C
Engine oil pressure (P9)	Below maximum rating	psi	bar

7.2 SETTINGS OF SWITCHES

<i>Switch</i>	<i>Function</i>	<i>Activates at</i>	<i>Activates at</i>
Engine oil pressure	shut down	7.25 psi	0.5 bar
Engine coolant temperature	shut down	221 °F	105 °C

7.3 SPECIFICATIONS OF THE ENGINE/ALTERNATOR/UNIT

		<i>US</i>	<i>Metric</i>
<i>Reference values</i>	Absolute air inlet pressure	14.5 psi	1 bar
	Air inlet temperature	77 °F	25 °C
	Relative air humidity	30 %	30 %
	Generator service duty	Continuous	Continuous
	Rated speed	1800 rpm	1800 rpm
	Rated frequency	60 Hz	60 Hz
<i>Limitations without derating</i>	Maximum ambient temperature	104 °F	40 °C
	Maximum altitude	3281 ft	1000 m
	Maximum relative air humidity	85 %	85 %
	Minimum starting temperature	-0.4 °F	-18 °C
<i>Performance</i>	Rated continuous active power (COP) 3 ph	21.5 hp	16 kW
	Rated continuous active power (COP) 1 ph	18.6 hp	13.9 kW
	Rated Power factor (3 phase/1 phase)	0.80/1.0	0.80/1.0
	Rated continuous apparent power 3ph	20 kVa	20 kVa
	Rated continuous apparent power 1 ph	13.9 kVa	13.9 kVa
	Rated voltage 3 ph. line-to-line, higher voltage	480 V	480 V
	Rated voltage 3 ph. line-to-line, lower voltage	208 V	208 V
	Rated voltage 1ph. line-to-line	240 V	240 V
	Rated current 3 ph. line-to-line, higher voltage	24 A	24 A
	Rated current 3 ph. line-to-line, lower voltage	55 A	55 A
	Rated current 1ph. line-to-line	58 A	58 A
	Performance class (acc.ISO 8528-5:1993)	G1	G1
	Frequency droop	<5	<5
		isochronous	isochronous
	Fuel consumption at full load/no load	9.04/2.43 lb/h	4.1/1.1 kg/h
	Specific fuel consumption	0.55 lb/kWh	0.25 Kg/kWh
	Fuel autonomy at full load	16 h	16 h
	Max. oil consumption at full load	0.49 oz/h	14 g/h
	Maximum sound power level (LWA) measured according to 2000/14/EC OND	95 dB(A)	95 dB(A)
	Capacity of fuel tank	21.38 USgal	81 l
	Single step load acceptance	100 %	100 %
	Setting of Q1.1	50 A	50 A
	Setting of Q1.2	25 A	25 A
	Setting of Q4	20 A	20 A
	Fuses F1, F2, F3	4 A	4 A
	Fuse F4	10 A	10 A

Application data	Mode of operation	continuous	continuous
	Site	land use	land use
	Operation	single	single
	Start-up and control mode	manual/auto.	manual/auto.
	Start-up time	unspecified	unspecified
	Mobility/ Config. acc. to ISO 8528-1:1993	transportable/D	transportable/D
		mobile/E	mobile/E
	Mounting	fully resilient	fully resilient
	Climatic exposure	open air	open air
Alternator	Degree of protection (cubicle)	IP54	IP54
	Status of neutral	earthed	earthed
	Standard	IEC 34-1	IEC 34-1
	Make	MECC ALTE	MECC ALTE
	Model	ECO 28-1L	ECO 28-1L
	Rated output, class H temp. rise	24 kVA	24 kVA
	Degree of protection	23 IP	23 IP
	Insulation stator	H	H
	Insulation rotor	H	H
Engine	Number of wires	12	12
	Type YANMAR	4TNE88-ACG	4TNE88-ACG
	Rated net output	26.28 hp	19.6 kW
	Coolant	water	water
	Combustion system	direct injection	direct injection
	Aspiration	natural aspirated	natural aspirated
	Number of cylinders	4	4
	Swept volume	0.58 Usgal	2.189 l
	Speed governing (optional)	mechanical electronic	mechanical electronic
Power circuit	Capacity of oil sump	2.38 Usgal	9 l
	Capacity of cooling system	1.06 + 0.26 Usgal	4+1 l
	Electrical system	12 Vdc	12 Vdc
	Circuit-breaker, 3ph		
	Number of poles	3	3
	Thermal release It	25 A	25 A
	Magnetic release Im	3..5xIn	3..5xIn
	Circuit-breaker, 3ph, lower voltage		
	Number of poles	3	3
Unit	Thermal release It	50 A	50 A
	Magnetic release Im	3..5xIn	3..5xIn
	Dimensions (L x W x H)	81.12 x 45 x 37 in	2080 x 1156 x 951 mm
	Weight net mass	1753 lb	795 kg
	Weight wet mass	1958 lb	888 kg
Notes	1)	For engine performance to ISO 3046/1-1995	
	2)	For operating conditions beyond the stated limits, see derating diagram or consult the factory	
	3)	At reference conditions unless otherwise stated	

7.4 CONVERSION LIST OF SI UNITS INTO BRITISH UNITS

1 bar	=	14.504 psi	1 m	=	3.281 ft
1 g	=	0.035 oz	1 mm	=	0.039 in
1 kg	=	2.205 lb	1 m³/min	=	35.315 cfm
1 km/h	=	0.621 mile/h	1 mbar	=	0.401 in wc
1 kW	=	1.341 hp (UK and US)	1 N	=	0.225 lbf
1 l	=	0.264 US gal	1 Nm	=	0.738 lbf.ft
1 l	=	0.220 Imp gal (UK)	t°F	=	32 + (1.8 x t°C)
1 l	=	0.035 cu.ft	t°C	=	(t°F - 32)/1.8

– A temperature difference of 1°C = a temperature difference of 1.8 °F

7.5 DATAPLATE

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

ATLAS COPCO AIRPOWER n.v.

-YA3-*****-*****-

**** kg

**** kg

**** kg

A

B

C

Model/Modell/Modèle

f_N **** Hz **

P_N **** kVA ***

P_N * kW ***

U_N * V ***

I_N * A ***

cos phi **

Manuf. year/Baujahr/Année de fabrication ****

MADE BY ATLAS COPCO AIRPOWER n.v. WILRIJK, BELGIUM

15 6945 00

Atlas Copco

A

B

C

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

Maximum permitted loaden weight of the vehicle

Maximum permitted road weight of the front axle

Maximum permitted road weight of the rear axle

Company code

Product code

Unit serial number

Name of the manufacturer

EEC or national type approval number

Vehicle identification number

Model number

Frequency

Apparent power - COP

Active power - COP

Nominal rated voltage

Nominal rated current

Power factor


Manufacturing year

EEC mark in accordance with Machine Directive 89/392E

Mode of operation

Winding connections


Circuit diagrams



CIRCUIT DIAGRAM

QAS18 YdS USA (3 Phase)

9822 0888 05/02
Applicable for QAS18 YdS USA 3 Phase




LEGEND:

Wire size:

aa = 0.5 mm²
a = 1 mm²
b = 1.5 mm²
c = 2.5 mm²
d = 4 mm²
e = 6 mm²
f = 10 mm²
g = 16 mm²
h = 25 mm²
i = 35 mm²
j = 50 mm²
k = 70 mm²
l = 95 mm²
bx = 1.5 mm² NSGAF0eU

Colour code:

0 = black
1 = brown
2 = red
3 = orange
4 = yellow
5 = green
6 = blue
7 = purple
8 = grey
9 = white
54 = green/yellow




Sx : min. 12 Vdc 4A
Kx : to be wired between generator and load
coil : max. 240VAC
3A AC11

B11	Speed sensor	P5	Frequencymeter 45-65 Hz	X1	Terminal board
F1-5	Fuse 4 A	Q1.1	Circuit breaker	X2	Outlet sockets
G3	Alternator	Q1.2	Circuit breaker	X3	Outlet sockets
K11	Aux. relay (lower voltage)	Q4	Circuit breaker	X4	Outlet sockets

CIRCUIT DIAGRAM

QAS18 YdS USA (3 Phase)



Note 1

3ph higher voltage : connect 2-3 ; 6-7 ; 10-11 ; 4-8-12 (N)
 3ph lower voltage : connect 1-3 ; 5-7 ; 9-11 ; 2-4-6-8-10-12 (N)
 1ph lower voltage : connect 1-3 ; 5-7 ; 2-4-10-12(N) ; 6-8-9-11

Note 2

The actuator replaces the fuel stop solenoid valve (mentioned on the Engine Control Circuit diagram).


	Q1.1	Q1.2	P1	Wire size
QAS 18	50A	25A	0-60A	$\frac{X}{f} \frac{Y}{d}$

(O) : OPTIONAL EQUIPMENT

K12	Aux. relay (higher voltage)	R11	Supply voltage adjustment	X25	Terminal strip
K13	Contact	S2b	Emergency stop	Y11	Actuator
N11	Speed controller	S4	Voltage change-over switch	Kx	Contact generator ready
N12	Automatic voltage regulator	S10	Supply voltage switch	Sx	Remote start/stop
P1-3	Amperemeter	T1-3	Current transformer	I	Wire harness
P4	Voltmeter 0-500 V	P5	Frequencymeter 45-65 Hz		

CIRCUIT DIAGRAM QAS18 YdS USA (3 Phase)


9822 0888 28/05
Applicable for QAS18 YdS USA 3 Phase



B7	Fuel level sensor	K5	Starter relay	S7'	Low fuel level switch, warning
B8	Coolant temperature sensor	M1	Starter motor	S8	Coolant high temperature switch
B9	Oil pressure sensor	N4	Control module	S9	Engine oil low pressure switch
E1	Preheat resistor	N12	Speed controller	X10	15-pole connector

CIRCUIT DIAGRAM

QAS18 YdS USA (3 Phase)




Note:
 **: wire nr 110 for 115V
 **: wire nr 127 for 230V



F4	Fuse 10 A	P6	Hourmeter	S7	Low fuel level switch
G1	Battery 12 V	P7	Fuel level gauge	X16	Module connector
G2	Charging generator	P8	Coolant temperature gauge	X17	Fuel level unit connector
H1	Panel light	P9	Oil pressure gauge	Y1	Fuel stop solenoid
K0	Starter solenoid	S2a	Emergency stop button		
K1	Preheat relay		(S2b: see Power Circuit)		


CIRCUIT DIAGRAM

QAS18 YdS USA (3 Phase)

Applicable for QAS18 YdS USA 3 Phase

CIRCUIT DIAGRAM

QAS18 YdS USA (3 Phase)



Legend

Wire size :

aa = 0.5 mm²
a = 1 mm²
b = 1.5 mm²
c = 2.5 mm²
d = 4 mm²
e = 6 mm²
f = 10 mm²
g = 16 mm²
h = 25 mm²
i = 35 mm²
j = 50 mm²
k = 70 mm²
l = 95 mm²
bx = 1.5 mm² NSGAFOeU
lx = 95 mm² STK
px = 185 mm² STK


Colour code :

0 = black
1 = brown
2 = red
3 = orange
4 = yellow
5 = green
6 = blue
7 = purple
8 = grey
9 = white
54 = green/yellow

F4	Fuse 10A	P4	V-meter	P8	Coolant temperature gauge
H1	Panel light	P5	Hz-meter	P9	Oil pressure gauge
N4	Control module	P6	Hourmeter	X10	15-pole connector
P1-3	A-meter	P7	Fuel level gauge	X16	Module connector

CIRCUIT DIAGRAM
QAS18 YdS USA (3 Phase)

Automatic voltage regulator



**Instruction Manual
for AC Generators**

QAS18 YdS USA (3 Phase)

