

**Instruction Manual
for AC Generators**

QAS 325 Volvo

Instruction manual 3

Circuit diagrams 51

Warranty and Liability Limitation

Use only authorized parts.

Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

The manufacturer does not accept any liability for any damage arising for modifications, additions or conversions made without the manufacturer's approval in writing.

Copyright 2005, Atlas Copco Airpower n.v., Antwerp, Belgium.

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

Congratulations on the purchase of your AC generator. It is a solid, safe and reliable machine, built according to the latest technology. Follow the instructions in this booklet and we guarantee you years of troublefree operation. Please read the following instructions carefully before starting to use your machine.

While every effort has been made to ensure that the information in this manual is correct, Atlas Copco does not assume responsibility for possible errors. Atlas Copco reserves the right to make changes without prior notice.

Contents

1 Safety precautions for portable generators	4	5 Storage of the generator	41
2 Leading particulars	8	5.1. Storage	41
2.1. General description QAS 325 Volvo.....	8	5.2. Preparing for operation after storage	41
2.2. Bodywork	9	6 Checks and troubleshooting.....	41
2.3. Markings.....	9	6.1. Checking voltmeter P4.....	41
2.4. Drain plugs and filler caps	9	6.2. Checking ammeters P1, P2 and P3	41
2.5. Control and indicator panel Qc1001™	10	6.3. Alternator troubleshooting	42
2.6. Control and indicator panel Qc4001™	16	6.4. Engine troubleshooting.....	42
2.7. Output terminal board (TB).....	32	7 Options available for QAS 325 Volvo units	43
2.8. Battery switch	32	7.1. Circuit diagrams.....	43
2.9. Earth leakage relay	33	7.2. Overview of the electrical options.....	43
3 Operating instructions	33	7.3. Description of the electrical options.....	43
3.1. Installation.....	33	7.4. Overview of the mechanical options.....	46
3.2. Connecting the generator	34	7.5. Description of the mechanical options	46
3.3. Before starting	35	8 Technical specifications for QAS 325 Volvo.....	47
3.4. Operating Qc1001™	35	8.1. Readings on gauges	47
3.5. Operating Qc4001™	36	8.2. Settings of switches.....	47
4 Maintenance	37	8.3. Specifications of the engine/alternator/unit	47
4.1. Maintenance schedule	37	8.4. Conversion list of SI units into British units	49
4.2. Engine maintenance.....	38	8.5. Dataplate	49
4.3. Measuring the alternator insulation resistance	38		
4.4. Engine oil specifications	38		
4.5. Engine oil level check	39		
4.6. Engine oil and oil filter change.....	39		
4.7. Engine coolant specifications	39		
4.8. Coolant check.....	40		

1 Safety precautions for portable generators

To be read attentively and acted accordingly before towing, lifting, operating, performing maintenance or repairing the generator.

1.1 Introduction

The policy of Atlas Copco is to provide the users of their equipment with safe, reliable and efficient products. Factors taken into account are among others:

- the intended and predictable future use of the products, and the environments in which they are expected to operate,
- applicable rules, codes and regulations,
- the expected useful product life, assuming proper service and maintenance,
- providing the manual with up-to-date information.

Before handling any product, take time to read the relevant instruction manual. Besides giving detailed operating instructions, it also gives specific information about safety, preventive maintenance, etc.

Keep the manual always at the unit location, easy accessible to the operating personnel.

See also the safety precautions of the engine and possible other equipment, which are separately sent along or are mentioned on the equipment or parts of the unit.

These safety precautions are general and some statements will therefore not always apply to a particular unit.

Only people that have the right skills should be allowed to operate, adjust, perform maintenance or repair on Atlas Copco equipment. It is the responsibility of management to appoint operators with the appropriate training and skill for each category of job.

Skill level 1: Operator

An operator is trained in all aspects of operating the unit with the push-buttons, and is trained to know the safety aspects.

Skill level 2: Mechanical technician

A mechanical technician is trained to operate the unit the same as the operator. In addition, the mechanical technician is also trained to perform maintenance and repair, as described in the instruction manual, and is allowed to change settings of the control and safety system. A mechanical technician does not work on live electrical components.

Skill level 3: Electrical technician

An electrical technician is trained and has the same qualifications as both the operator and the mechanical technician. In addition, the electrical technician may carry out electrical repairs within the various enclosures of the unit. This includes work on live electrical components.

Skill level 4: Specialist from the manufacturer

This is a skilled specialist sent by the manufacturer or its agent to perform complex repairs or modifications to the equipment.

In general it is recommended that not more than two people operate the unit, more operators could lead to unsafe operating conditions. Take necessary steps to keep unauthorized persons away from the unit and eliminate all possible sources of danger at the unit.

When handling, operating, overhauling and/or performing maintenance or repair on Atlas Copco equipment, the mechanics are expected to use safe engineering practices and to observe all relevant local safety requirements and ordinances. The following list is a reminder of special safety directives and precautions mainly applicable to Atlas Copco equipment.

Neglecting the safety precautions may endanger people as well as environment and machinery:

- endanger people due to electrical, mechanical or chemical influences,
- endanger the environment due to leakage of oil, solvents or other substances,
- endanger the machinery due to function failures.

All responsibility for any damage or injury resulting from neglecting these precautions or by non-observance of ordinary caution and due care required in handling, operating, maintenance or repair, also if not expressly mentioned in this instruction manual, is disclaimed by Atlas Copco.

The manufacturer does not accept any liability for any damage arising from the use of non-original parts and for modifications, additions or conversions made without the manufacturer's approval in writing.

If any statement in this manual does not comply with local legislation, the stricter of the two shall be applied.

Statements in these safety precautions should not be interpreted as suggestions, recommendations or inducements that it should be used in violation of any applicable laws or regulations.

1.2 General safety precautions

- 1 The owner is responsible for maintaining the unit in a safe operating condition. Unit parts and accessories must be replaced if missing or unsuitable for safe operation.
 - 2 The supervisor, or the responsible person, shall at all times make sure that all instructions regarding machinery and equipment operation and maintenance are strictly followed and that the machines with all accessories and safety devices, as well as the consuming devices, are in good repair, free of abnormal wear or abuse, and are not tampered with.
 - 3 Whenever there is an indication or any suspicion that an internal part of a machine is overheated, the machine shall be stopped but no inspection covers shall be opened before sufficient cooling time has elapsed; this to avoid the risk of spontaneous ignition of oil vapour when air is admitted.
 - 4 Normal ratings (pressures, temperatures, speeds, etc.) shall be durably marked.
 - 5 Operate the unit only for the intended purpose and within its rated limits (pressure, temperature, speeds, etc.).
 - 6 The machinery and equipment shall be kept clean, i.e. as free as possible from oil, dust or other deposits.
 - 7 To prevent an increase in working temperature, inspect and clean heat transfer surfaces (cooler fins, intercoolers, water jackets, etc.) regularly. See the maintenance schedule.
 - 8 All regulating and safety devices shall be maintained with due care to ensure that they function properly. They may not be put out of action.
 - 9 Pressure and temperature gauges shall be checked regularly with regard to their accuracy. They shall be replaced whenever outside acceptable tolerances.
 - 10 Safety devices shall be tested as described in the maintenance schedule of the instruction manual to determine that they are in good operating condition.
 - 11 Mind the markings and information labels on the unit.
 - 12 In the event the safety labels are damaged or destroyed, they must be replaced to ensure operator safety.
 - 13 Keep the work area neat. Lack of order will increase the risk of accidents.
 - 14 When working on the unit, wear safety clothing. Depending on the kind of activities these are: safety glasses, ear protection, safety helmet (including visor), safety gloves, protective clothing, safety shoes. Do not wear the hair long and loose (protect long hair with a hairnet), or wear loose clothing or jewellery.
 - 15 Take precautions against fire. Handle fuel, oil and anti-freeze with care because they are inflammable substances. Do not smoke or approach with naked flame when handling such substances. Keep a fire-extinguisher in the vicinity.
- 16a Portable generators (with earthing pin):**
Earth the generator as well as the load properly.
- 16b Portable generators IT:**
Note: This generator is built to supply a sheer alternating current IT network.
Earth the load properly.

1.3 Safety during transport and installation

To lift a unit, all loose or pivoting parts, e.g. doors and towbar, shall first be securely fastened.

Do not attach cables, chains or ropes directly to the lifting eye; apply a crane hook or lifting shackle meeting local safety regulations. Never allow sharp bends in lifting cables, chains or ropes.

Helicopter lifting is not allowed. It is strictly forbidden to dwell or stay in the risk zone under a lifted load. Never lift the unit over people or residential areas. Lifting acceleration and retardation shall be kept within safe limits.

- 1 Before towing the unit:
 - check the towbar, the brake system and the towing eye. Also check the coupling of the towing vehicle,
 - check the towing and brake capability of the towing vehicle,
 - check that the towbar, jockey wheel or stand leg is safely locked in the raised position,
 - ascertain that the towing eye can swivel freely on the hook,
 - check that the wheels are secure and that the tyres are in good condition and inflated correctly,
 - connect the signalisation cable, check all lights and connect the pneumatic brake couplers,
 - attach the safety break-away cable or safety chain to the towing vehicle,
 - remove wheel chocks, if applied, and disengage the parking brake.
- 2 To tow a unit use a towing vehicle of ample capacity. Refer to the documentation of the towing vehicle.
- 3 If the unit is to be backed up by the towing vehicle, disengage the overrun brake mechanism (if it is not an automatic mechanism).
- 4 Never exceed the maximum towing speed of the unit (mind the local regulations).
- 5 Place the unit on level ground and apply the parking brake before disconnecting the unit from the towing vehicle. Unclip the safety break-away cable or safety chain. If the unit has no parking brake or jockey wheel, immobilize the unit by placing chocks in front of and/or behind the wheels. When the towbar can be positioned vertically, the locking device must be applied and kept in good order.
- 6 To lift heavy parts, a hoist of ample capacity, tested and approved according to local safety regulations, shall be used.
- 7 Lifting hooks, eyes, shackles, etc., shall never be bent and shall only have stress in line with their design load axis. The capacity of a lifting device diminishes when the lifting force is applied at an angle to its load axis.
- 8 For maximum safety and efficiency of the lifting apparatus all lifting members shall be applied as near to perpendicular as possible. If required, a lifting beam shall be applied between hoist and load.
- 9 Never leave a load hanging on a hoist.
- 10 A hoist has to be installed in such a way that the object will be lifted perpendicular. If that is not possible, the necessary precautions must be taken to prevent load-swinging, e.g. by using two hoists, each at approximately the same angle not exceeding 30° from the vertical.
- 11 Locate the unit away from walls. Take all precautions to ensure that hot air exhausted from the engine and driven machine cooling systems cannot be recirculated. If such hot air is taken in by the engine or driven machine cooling fan, this may cause overheating of the unit; if taken in for combustion, the engine power will be reduced.
- 12 Generators shall be stalled on an even, solid floor, in a clean location with sufficient ventilation. If the floor is not level or can vary in inclination, consult Atlas Copco.
- 13 The electrical connections shall correspond to local codes. The machines shall be earthed and protected against short circuits by fuses or circuit breakers.
- 14 Never connect the generator outlets to an installation which is also connected to a public mains.
- 15 Before connecting a load, switch off the corresponding circuit breaker, and check whether frequency, voltage, current and power factor comply with the ratings of the generator.

1.4 Safety during use and operation

- 1 When the unit has to operate in a fire-hazardous environment, each engine exhaust has to be provided with a spark arrestor to trap incendiary sparks.
- 2 The exhaust contains carbon monoxide which is a lethal gas. When the unit is used in a confined space, conduct the engine exhaust to the outside atmosphere by a pipe of sufficient diameter; do this in such a way that no extra back pressure is created for the engine. If necessary, install an extractor. Observe any existing local regulations. Make sure that the unit has sufficient air intake for operation. If necessary, install extra air intake ducts.
- 3 When operating in a dust-laden atmosphere, place the unit so that dust is not carried towards it by the wind. Operation in clean surroundings considerably extends the intervals for cleaning the air intake filters and the cores of the coolers.
- 4 Never remove a filler cap of the cooling water system of a hot engine. Wait until the engine has sufficiently cooled down.
- 5 Never refill fuel while the unit is running, unless otherwise stated in the Atlas Copco Instruction Book (AIB). Keep fuel away from hot parts such as air outlet pipes or the engine exhaust. Do not smoke when fuelling. When fuelling from an automatic pump, an earthing cable should be connected to the unit to discharge static electricity. Never spill nor leave oil, fuel, coolant or cleansing agent in or around the unit.
- 6 All doors shall be shut during operation so as not to disturb the cooling air flow inside the bodywork and/or render the silencing less effective. A door should be kept open for a short period only e.g. for inspection or adjustment.
- 7 Periodically carry out maintenance works according to the maintenance schedule.
- 8 Stationary housing guards are provided on all rotating or reciprocating parts not otherwise protected and which may be hazardous to personnel. Machinery shall never be put into operation, when such guards have been removed, before the guards are securely reinstalled.
- 9 Noise, even at reasonable levels, can cause irritation and disturbance which, over a long period of time, may cause severe injuries to the nervous system of human beings.
When the sound pressure level, at any point where personnel normally has to attend, is:
 - below 70 dB(A): no action needs to be taken,
 - above 70 dB(A): noise-protective devices should be provided for people continuously being present in the room,
 - below 85 dB(A): no action needs to be taken for occasional visitors staying a limited time only,
 - above 85 dB(A): room to be classified as a noise-hazardous area and an obvious warning shall be placed permanently at each entrance to alert people entering the room, for even relatively short times, about the need to wear ear protectors,
 - above 95 dB(A): the warning(s) at the entrance(s) shall be completed with the recommendation that also occasional visitors shall wear ear protectors,
 - above 105 dB(A): special ear protectors that are adequate for this noise level and the spectral composition of the noise shall be provided and a special warning to that effect shall be placed at each entrance.
- 10 Insulation or safety guards of parts the temperature of which can be in excess of 80°C and which may be accidentally touched by personnel shall not be removed before the parts have cooled to room temperature.
- 11 Never operate the unit in surroundings where there is a possibility of taking in flammable or toxic fumes.
- 12 If the working process produces fumes, dust or vibration hazards, etc., take the necessary steps to eliminate the risk of personnel injury.
- 13 When using compressed air or inert gas to clean down equipment, do so with caution and use the appropriate protection, at least safety glasses, for the operator as well as for any bystander. Do not apply compressed air or inert gas to your skin or direct an air or gas stream at people. Never use it to clean dirt from your clothes.
- 14 When washing parts in or with a cleaning solvent, provide the required ventilation and use appropriate protection such as a breathing filter, safety glasses, rubber apron and gloves, etc.
- 15 Safety shoes should be compulsory in any workshop and if there is a risk, however small, of falling objects, wearing of a safety helmet should be included.
- 16 If there is a risk of inhaling hazardous gases, fumes or dust, the respiratory organs must be protected and depending on the nature of the hazard, so must the eyes and skin.

- 17 Remember that where there is visible dust, the finer, invisible particles will almost certainly be present too; but the fact that no dust can be seen is not a reliable indication that dangerous, invisible dust is not present in the air.
- 18 Never operate the generator in excess of its limits as indicated in the technical specifications and avoid long no-load sequences.
- 19 Never operate the generator in a humid atmosphere. Excessive moisture causes worsening of the generator insulation.
- 20 Do not open electrical cabinets, cubicles or other equipment while voltage is supplied. If such cannot be avoided, e.g. for measurements, tests or adjustments, have the action carried out by a qualified electrician only, with appropriate tools, and ascertain that the required bodily protection against electrical hazards is applied.
- 21 Never touch the power terminals during operation of the machine.
- 22 Whenever an abnormal condition arises, e.g. excessive vibration, noise, odour, etc., switch the circuit breakers to OFF and stop the engine. Correct the faulty condition before restarting.
- 23 Check the electric cables regularly. Damaged cables and insufficient lightening of connections may cause electric shocks. Whenever damaged wires or dangerous conditions are observed, switch the circuit breakers to OFF and stop the engine. Replace the damaged wires or correct the dangerous condition before restarting. Make sure that all electric connections are securely tightened.
- 24 Avoid overloading the generator. The generator is provided with circuit breakers for overload protection. When a breaker has tripped, reduce the concerned load before restarting.
- 25 If the generator is used as stand-by for the mains supply, it must not be operated without control system which automatically disconnects the generator from the mains when the mains supply is restored.
- 26 Never remove the cover of the output terminals during operation. Before connecting or disconnecting wires, switch off the load and the circuit breakers, stop the machine and make sure that the machine cannot be started inadvertently or there is any residual voltage on the power circuit.
- 27 Running the generator at low load for long periods will reduce the lifetime of the engine.

1.5 Safety during maintenance and repair

Maintenance, overhaul and repair work shall only be carried out by adequately trained personnel; if required, under supervision of someone qualified for the job.

- 1 Use only the correct tools for maintenance and repair work, and only tools which are in good condition.
- 2 Parts shall only be replaced by genuine Atlas Copco replacement parts.
- 3 All maintenance work, other than routine attention, shall only be undertaken when the unit is stopped. Steps shall be taken to prevent inadvertent starting. In addition, a warning sign bearing a legend such as "work in progress; do not start" shall be attached to the starting equipment. On engine-driven units the battery shall be disconnected and removed or the terminals covered by insulating caps. On electrically driven units the main switch shall be locked in open position and the fuses shall be taken out. A warning sign bearing a legend such as "work in progress; do not supply voltage" shall be attached to the fuse box or main switch.
- 4 Prior to stripping an engine or other machine or undertaking major overhaul on it, prevent all movable parts from rolling over or moving.
- 5 Make sure that no tools, loose parts or rags are left in or on the machine. Never leave rags or loose clothing near the engine air intake.
- 6 Never use flammable solvents for cleaning (fire-risk).
- 7 Take safety precautions against toxic vapours of cleaning liquids.
- 8 Never use machine parts as a climbing aid.
- 9 Observe scrupulous cleanliness during maintenance and repair. Keep away dirt, cover the parts and exposed openings with a clean cloth, paper or tape.
- 10 Never weld on or perform any operation involving heat near the fuel or oil systems. Fuel and oil tanks must be completely purged, e.g. by steam-cleaning, before carrying out such operations. Never weld on, or in any way modify, pressure vessels. Disconnect the alternator cables during arc welding on the unit.
- 11 Support the towbar and the axle(s) securely if working underneath the unit or when removing a wheel. Do not rely on jacks.
- 12 Do not remove any of, or tamper with, the sound-damping material. Keep the material free of dirt and liquids such as fuel, oil and cleansing agents. If any sound-damping material is damaged, replace it to prevent the sound pressure level from increasing.
- 13 Use only lubricating oils and greases recommended or approved by Atlas Copco or the machine manufacturer. Ascertain that the selected lubricants comply with all applicable safety regulations, especially with regard to explosion or fire-risk and the possibility of decomposition or generation of hazardous gases. Never mix synthetic with mineral oil.
- 14 Protect the engine, alternator, air intake filter, electrical and regulating components, etc., to prevent moisture ingress, e.g. when steam-cleaning.
- 15 When performing any operation involving heat, flames or sparks on a machine, the surrounding components shall first be screened with non-flammable material.
- 16 Never use a light source with open flame for inspecting the interior of a machine.
- 17 When repair has been completed, the machine shall be barred over at least one revolution for reciprocating machines, several revolutions for rotary ones to ensure that there is no mechanical interference within the machine or driver. Check the direction of rotation of electric motors when starting up the machine initially and after any alteration to the electrical connection(s) or switch gear, to check that the oil pump and the fan function properly.
- 18 Maintenance and repair work should be recorded in an operator's logbook for all machinery. Frequency and nature of repairs can reveal unsafe conditions.
- 19 When hot parts have to be handled, e.g. shrink fitting, special heat-resistant gloves shall be used and, if required, other body protection shall be applied.
- 20 When using cartridge type breathing filter equipment, ascertain that the correct type of cartridge is used and that its useful service life is not surpassed.
- 21 Make sure that oil, solvents and other substances likely to pollute the environment are properly disposed of.
- 22 Before clearing the generator for use after maintenance or overhaul, submit it to a testrun, check that the AC power performance is correct and that the control and shutdown devices function correctly.

1.6 Tool applications safety

Apply the proper tool for each job. With the knowledge of correct tool use and knowing the limitations of tools, along with some common sense, many accidents can be prevented.

Special service tools are available for specific jobs and should be used when recommended. The use of these tools will save time and prevent damage to parts.

1.7 Battery safety precautions

Batteries

When servicing batteries, always wear protecting clothing and glasses.

- 1 The electrolyte in batteries is a sulphuric acid solution which is fatal if it hits your eyes, and which can cause burns if it contacts your skin. Therefore, be careful when handling batteries, e.g. when checking the charge condition.
- 2 Install a sign prohibiting fire, open flame and smoking at the post where batteries are being charged.
- 3 When batteries are being charged, an explosive gas mixture forms in the cells and might escape through the vent holes in the plugs. Thus an explosive atmosphere may form around the battery if ventilation is poor, and can remain in and around the battery for several hours after it has been charged. Therefore:
 - never smoke near batteries being, or having recently been, charged,
 - never break live circuits at battery terminals, because a spark usually occurs.
- 4 When connecting an auxiliary battery (AB) in parallel to the unit battery (CB) with booster cables: connect the + pole of AB to the + pole of CB, then connect the - pole of CB to the mass of the unit. Disconnect in the reverse order.


2 Leading particulars

2.1 General description QAS 325 Volvo

The QAS 325 Volvo is an AC generator, built for continuous running at sites where no electricity is available or as stand-by in cases of interruption of the mains. The generators operates at 50/60 Hz, 230/240 V in line-to-neutral mode and 400/480 V in line-to-line mode.

The QAS 325 Volvo generator is driven by a water-cooled diesel engine, manufactured by VOLVO PENTA.

An overview of the main parts is given in the diagram below.



1	Lifting rod	DFW	Drain flexible cooling water
2	Guiding rod	DH	Drain and access hole (in the frame)
3	Side doors	E	Engine
4	Engine exhaust	F	Fan
5	Data Plate	FCF	Filler cap fuel
6	Side door, access to control and indicator panel	FCO	Filler cap engine oil
7	Output terminal board	FCW	Filler cap cooling water
8	Hole for forklift	FF	Fuel filter
9	Earthing rod	G1	Battery
A	Alternator	ODP	Oil drain pump
AF	Air filter	OF	Oil filter
C	Coupling	OLD	Engine oil level dipstick
DFO	Drain flexible engine oil	S1	Battery switch

2.2 Bodywork

The alternator, the engine, the cooling system, etc. are enclosed in a sound-insulated bodywork that can be opened by means of side doors (and service plates).

The generator's lifting eye is located in the middle of the roof. The recesses in the roof have guiding rods at both sides.



Never use the guiding rods to lift the generator.

To be able to lift the generator by means of a forklift, rectangular holes are provided in the frame.

The earthing rod, connected to the generator's earth terminal is located at the side of the frame.

2.3 Markings

A brief description of all markings provided on your AC generator is given hereafter.



Indicates that an electric voltage, dangerous to life, is present. Never touch the electric terminals during operation.



Indicates that the engine exhaust is a hot and harmful gas, which is toxic in case of inhalation. Always make sure that the unit is operated outside or in a well-ventilated room.



Indicates that these parts can become very hot during operation (e.g. engine, cooler, etc.). Always make sure that these parts are cooled down before touching them.



Indicates that the guiding rods may not be used to lift the generator. Always use the lifting rod in the roof of the generator to lift it.



Indicates a lifting point of the generator.



Indicates that the alternator should not be cleaned with high pressurised water.



Use 15W40 oil only.



Indicates that the generator may be refuelled with diesel fuel only.



Indicates the drain for the engine oil.




Indicates the drain for the coolant.




Indicates the drain plug for the engine fuel.



Indicates the different earthing connections on the generator.





Indicates the battery switch.



Indicates the 3-way valve.



Indicates that the unit may start automatically and that the instruction book has to be consulted prior to use.

		QAS 325 Vd	
SERVICE PAK			
		Yearly (max. 3000)	2912 4414 0
Engine Oil		PAROIL 15W40	PAROIL 5W20
51 (1.3 US gal)		1615 5953 00	1615 6060 00
201 (5 US gal)		1615 5954 00	1615 6059 00
2101 (55 US gal)		1615 5955 00	
Engine Coolant		PARCOOL EG	
51 (1.3 US gal)		1615 5308 00	
201 (5 US gal)		1615 5307 00	
2101 (55 US gal)		1615 5306 00	

Indicates the partnumbers of the different service paks and of the engine oil. These parts can be ordered to the factory.

2.4 Drain plugs and filler caps

The drain holes for the engine oil, the coolant and the plug for the fuel, are located and labelled on the frame; the fuel drain plug at the front, the others at the service side.


The drain flexibles for the engine oil and the engine coolant can be brought to the outside of the generator through the drain hole.



The drain hole can also be used to guide external fuel tank connections. When connecting an external fueltank, use the 3-way valves. See "External fuel tank connection" on page 46

2.5 Control and indicator panel Qc1001™

2.5.1 General description Qc1001™ control panel



A1..... Qc1001™ display

F4..... Fuse

The fuse activates when the current from the battery to the engine control circuit exceeds its setting. The fuse can be reset by pushing the button.

H1..... Panel light


S2..... Emergency stop button

Push the button to stop the generator in case of an emergency. When the button is pressed, it must be unlocked, before the generator can be restarted. The emergency stop button can be secured in the locked position with the key, to avoid unauthorized use.

S20.... ON/OFF switch

To start up the unit (locally or remote).

2.5.2 Qc1001™ Module



The Qc1001™ module is located inside the control panel. This control module will carry out all necessary tasks to control and protect a generator, regardless of the use of the generator.

This means that the Qc1001™ module can be used for several applications.

2.5.3 Pushbutton and LED functions

Following pushbuttons are used on the Qc1001™:



ENTER: Is used to select and confirm changed settings in the Configuration.



UP: Is used to scroll through the display information. This button is also active in Configuration Mode.



DOWN: Is used to scroll through the display information. This button is also active in Configuration Mode.




When **UP & DOWN** are pressed at the same time for 3s, Configuration Mode will be entered (see page 15).



BACK: Is used to leave/enter the Warnings pop-up window, to leave the Configuration Mode and to leave menu's without change.



REMOTE MODE: Is used to activate the remote mode. The LED indicates if the gen-set is put in Remote Mode.



MANUAL MODE: Is used to activate the manual mode. The LED indicates if the gen-set is put in Manual Mode.




START: Manual start of the generator.



STOP: Manual stop of the generator.

Following LEDs are used on the Qc1001™



Power	Green LED indicates that the unit is powered up.
Manual	Green LED indicates that the Manual Mode is selected.
Remote	Green LED indicates that the Remote Mode is selected.
Alarm	Flashing red LED indicates that a shutdown is present. Continuous red LED indicates a warning. The exact warning/shutdown is shown at the display.

2.5.4 Qc1001™ Menu Overview


At Qc1001™, the LCD will show following information:

- in **Normal** condition (scroll through the information using **UP** and **DOWN**):
 - Status (eg: preheat, crank, run, cooldown, extended stop time, ...)
 - Running hours
 - Battery Voltage
 - Service Timer 1
 - Service Timer 2
 - **Generator Frequency**
- in **Warning** condition (scroll through the information using **UP** and **DOWN**):
 - a list of all active Warnings
- in **Shutdown** condition:
 - the cause of shutdown

It's possible to scroll through the views, using the **UP** and **DOWN** buttons. The scrolling is continuous.

If a Special status comes up, the Status Display is shown.
If a Warning comes up, the Warning Display is shown.
If a Shutdown comes up, the Shutdown Display is shown.


View 0



This view will show the ASW version number.

When there has been no button activity for three minutes, the display will return to the Default View.


View 1 (Qc1001™-Default Display)



The frequency value is centered in the top-right corner area.

The running hours value is at the bottom-left corner. The service timer indication(s) are shown in the bottom-right corner when the service timer(s) have run out. They will disappear when the service timer(s) have been resetted.

View 2 (Fuel Level Display)




This view shows the fuel level icon.

When the English text view is selected, this view will mention: "FUEL LEVEL ***%".

When there has been no button activity for three minutes, the display will return to the Default View.

View 3 (Engine Oil Pressure Display)




This view shows the oil pressure icons.

When the English text view is selected, this view will mention: "OIL PRESSURE **. *bar".

When there has been no button activity for three minutes, the display will return to the Default View.

See also "Configuration Mode View" on page 15 for selection between bar and psi.

View 4 (Engine Coolant Temperature Display)




This view shows the coolant temperature icons.

When the English text view is selected, this view will mention: "COOLANT TEMP. ***°C".

When there has been no button activity for three minutes, the display will return to the Default View.

See also “Configuration Mode View“ on page 15 for selection between °C and °F.

View 5 (Service Timers and Battery Voltage)




The service timer indications count upwards and give an alarm when the configured value is reached.

Resetting of the Service Timers is possible through a display Configuration Menu.

View 10 (reserved for normal English text)

In case that normal English text is selected i.s.o. icons, views 2 & 3 & 4 are changed into this three-row display format.

Status Display (pop-up window)



In case special statuses are entered, a pop-up window will automatically be entered for as long as the status is active.

The background screen is not updated when the status pop-up window is active.

These special statuses are:


PREHEAT	
START OFF	
COOLDOWN	
EXTENDED STOP TIME	
DIAGNOSTIC	

If a special status has elapsed, the default view will be entered again automatically.

If a Warning comes up, the Warning Display is shown.

If a Shutdown comes up, the Shutdown Display is shown.

Warning Display (pop-up window)



In case a Warning occurs, a pop-up window will automatically be entered for as long as the warning is active, no matter which view is active. The warning icons will be shown (together with a continuous lit alarm LED at the fascia), which is centered at the display. The Warning Display can always be left or entered again by pushing the BACK button.

If more than one warning comes up, it's possible to scroll through the warning messages with the UP and DOWN pushbuttons. The newest warning will be placed at the bottom of the list (meaning that the older warning stays at the display when a newer warning comes up).

If one or more than one warning is present, an arrow at the right of the display will be shown.

If a Shutdown comes up, the Shutdown Display is shown.

List of possible warnings:


LOW OIL PRESSURE




HIGH COOLANT TEMPERATURE



CHARGING ALTERNATOR



LOW FUEL LEVEL



LOW COOLANT LEVEL




GENERATOR OVERVOLTAGE




GENERATOR UNDERVOLTAGE



GENERATOR OVERFREQUENCY



GENERATOR UNDERFREQUENCY




SERVICE TIMER 1




SERVICE TIMER 2



ALARM



Shutdown Display (pop-up window)



In case a Shutdown occurs, a pop-up window will automatically be entered, no matter which view is active.

This pop-up window will stay present until the unit is put in OFF.


The shutdown icon will be shown (together with a flashing alarm LED at the fascia), which is centered at the display.

List of possible shutdowns:

LOW OIL PRESSURE	
HIGH COOLANT TEMPERATURE	
CHARGING ALTERNATOR	
LOW FUEL LEVEL	
LOW COOLANT LEVEL	
GENERATOR OVERVOLTAGE	
GENERATOR UNDERVOLTAGE	
GENERATOR OVERFREQUENCY	
GENERATOR UNDERFREQUENCY	

SERVICE TIMER 1	
SERVICE TIMER 2	
ALARM	
EMERGENCY STOP	
START FAILURE	
STOP FAILURE	

Configuration Mode View



The Configuration Menu's are pre-programmed!

The Configuration Mode is entered by detection of activation of pushbuttons UP and DOWN at the same time for 3s.

A password will be asked for when an attempt to change a setting is about to be done (user password = 2003).

By entering the configuration mode, pushbuttons MANUAL, REMOTE are disposed of their normal operations and will not perform any functionality.

Menu's shown on the LCD in Configuration Mode:

- Language selection
- Diagnostics Menu
- Running hours adjust

- Service Timer 2 reset
- Service Timer 1 reset
- Start Prepare Time
- Unit Menu
- Unit Type




Unit type 2 for QAS 325 Volvo!

- Generator Underfrequency: failclass, enable, delay, setpoint
- Generator Overfrequency: failclass, enable, delay, setpoint
- Generator Undervoltage: failclass, enable, delay, setpoint
- Generator Overvoltage: failclass, enable, delay, setpoint

It's possible to scroll between configuration menu's by using the pushbuttons UP and DOWN.

Pushing the ENTER button activates the configuration menu which is shown at the display.

This is the described menu flow:



2.5.5 Remote start operation

Installation wirings:

- X25.1 & X25.2 to be wired for the remote start switch.
- X25.3 & X25.4 to be wired for the remote contactor (open/close).

2.5.6 Fail classes

All the activated alarms of the Qc1001™ have their own pre-defined fail class.

All alarms are enabled according to one of these three statuses:

- disabled alarm, no supervision of alarm (OFF)
- enabled alarm, supervision of alarm all the time (ON)
- running alarm, only supervision when the machine is running (RUN)

2.5.7 Event Log

The unit will keep an event log of the latest 30 events.

Events are:


- shutdowns
- service timer 1 reset
- service timer 2 reset
- unit type changes

Together with each event, the running hours at the time of the event will be stored.

The events can only be read by means of the QcUSW.

2.6 Control and indicator panel Qc4001™

2.6.1 General description Qc4001™ control panel



A2..... Qc4001™ Display

H1..... Panel light

F10..... Fuse

The fuse (10 A) activates when the current from the battery to the engine control circuit exceeds its setting. The fuse can be reset by pushing the button.

S2..... Emergency stop button

Push the button to stop the generator in case of an emergency. When the button is pressed, it must be unlocked, before the generator can be restarted. The emergency stop button can be secured in the locked position with the key, to avoid unauthorized use.

S11 Frequency selector switch (50 Hz/OFF/60 Hz)

Allows to choose the frequency of the output voltage: 50 Hz or 60 Hz.



Changing the output frequency is only allowed after shutdown.

S20.... ON/OFF switch

Position O: No voltage is applied to the Qc4001™ module, the generator will not start.

Position I: Voltage is applied to the Qc4001™ module, it is possible to start up the generator.

X25.... Connection block

Allows easy connection for a remote start switch, for sensing of mains voltage and control of the mains contactor.



Refer to circuit diagram for the correct connection.

X30.... Connector X30

Connector for communication with other generators with Qc4001™ when paralleling.


X31.... Connector X31

Connector for communication with other generators with Qc4001™ when paralleling.

X32.... Connector X32

Connector for PMS communication with other generators with Qc4001™ when paralleling.

2.6.2 Qc4001™ Module



The Qc4001™ module is located inside the control panel, and communicates with a display unit, located in front of the control panel. This control module will carry out all necessary tasks to control and protect a generator, regardless of the use of the generator.

This means that the Qc4001™ module can be used for several applications.

2.6.3 Pushbutton and LED functions

Following pushbuttons are used on the Qc4001™



ALARM: Shows the active alarm list (up to 30 alarms can be listed).



JUMP: Each programmable parameter has a channel number in the menu. Instead of navigating through the entire menu, the user can jump directly to the required parameter, if he knows the channel number of that specific parameter. E.g. if the user wants to change 'language', he can jump directly to channel 4240.



LEFT: Moves the cursor left for scrolling in the menus.




UP: Increases the value of the selected set-point (in the setting menus). Allows the user to scroll upwards (in the daily use display).



SELECT: Is used to select the chosen function. A function can be chosen by the cursor.



DOWN: Decreases the value of the selected set-point (in the setting menus). Allows the user to scroll downwards (in the daily use display).



RIGHT: Moves the cursor right for scrolling in the menus.



BACK: Jumps one step backwards in the menu (until the daily use display is reached).




START: Manual Start of the generator (only enabled if the SEMI-AUTO mode is selected).




STOP: Manual Stop of the generator (only enabled if the SEMI-AUTO mode is selected).




GB (Generator Breaker GB) ON: Manual activation of close breaker and open breaker sequence (only enabled if the SEMI-AUTO mode is selected).




MB (Mains Breaker MB) ON: Manual activation of close breaker and open breaker sequence (only enabled if the SEMI-AUTO mode is selected).




AUTO: Allows the user to set the generator in AUTO mode.



SEMI-AUTO: Allows the user to set the generator in SEMI-AUTO mode.




TEST: Allows the user to set the generator in TEST mode. To enter the TEST mode, a password needs to be entered.




VIEW LOG: Shows the latest event. The user can scroll through the event & historical alarm list with the scroll buttons (up to 150 events & historical alarms can be listed).

Following LEDs are used on the Qc4001™



Alarm	Red LED flashing indicates that unacknowledged alarms are present. Red LED fixed indicates that ALL alarms are acknowledged.
Power	Green LED indicates that the voltage supply is switched on.
Run	Green LED indicates that the generator is running.
U/f OK	Green LED indicates that voltage/frequency is present and stable.
GB ON	Green LED indicates that the generator breaker is closed.
MB ON	Green LED indicates that the mains breaker is closed.
Mains OK	LED is green if the Mains is present and stable. LED is red when the Mains is not present. LED is flashing green when the Mains is present but not stable yet (during the "MAINS OK" delay time).
Auto	Green LED indicates that AUTO mode is selected.
Semi-Auto	Green LED indicates that SEMI-AUTO mode is selected.

The main Qc4001™ control unit includes 3 LEDs




Power	Green LED indicates that the voltage supply is switched on.
Self check OK	Green LED indicates that the unit is OK.
Alarm inhibit	Green LED indicates that the inhibit input is ON.

2.6.4 Qc4001™ Menu Overview


Main View

The display has 4 different lines. The information on these lines can change, depending on which view is used. There are 4 different main views possible: SETUP / S3 / S2 / S1.


Setup view:




S3 view:



S2 view:



S1 view:



The user can scroll through these views with the scroll buttons:


- The SETUP view shows the module name, the software version, the date and the time.
- The S3 view shows the application type and the mode, and some generator measurements. During synchronisation the S3 view will show a synchronoscope in the first line.
- The S2 view shows some generator measurements.
- In the S1 view the user can scroll up and down to 15 configurable screens showing different measurements of the generator, the bus and the Mains.

SETUP menu

The control and protection parameters can be programmed according the application. This can be done by scrolling through the setup menu to the appropriate parameter. Each parameter has a specific channel number and is listed in one of the 4 main SETUP menus:


- Protection Setup (PROT): Channels from 1010 to 1890 (steps of 10)
- Control Setup (CTRL): Channels from 2010 to 2210 (steps of 10)
- Power Setup (POWER): Channels from 3010 to 3250 (steps of 10)
- System Setup (SYST): Channels from 4010 to 4790 (steps of 10)

If you select SETUP then you get the following view:



The fourth line is the entry selection for the Menu system. If the SELECT button is pressed, the menu indicated with an underscore will be entered.

If PROT is selected, the following view will appear (example of parameter):



For a protective function the first entry shows the "Gen high-volt 1" setting.


Scrolling down will give all the protection parameters.

- The first line shows some generator data.
- The second line shows the channel number and the name of the parameter.
- The third line shows the value of a set point of this parameter.
- The fourth line shows the different possible set points. In this example:


LIM	LIMIT, setting of switch point
DEL	DELAY, setting of time delay
OA	OUTPUT A, selection of which relay the function must activate
OB	OUTPUT B, selection of which relay the function must activate
ACT	ACTION, activate/de-activate the function
FC	FAIL CLASS, fail class setting.

The user can scroll to these choices and select one choice with the SELECT button.

After selection of LIM the following view will be visible:



If the correct password is entered, the following view appears:



Now the user can change the LIM of parameter "Gen high-volt 1". This can be done with the scroll buttons. Then the user has to select SAVE to save the new settings.

To exit the user has to press the BACK button several times, until the main view appears.

The JUMP button

Instead of navigating through the entire menu, the user can jump directly to the required parameter, if he knows the channel number of that specific parameter.

If the JUMP button is pushed the password view will appear. Not all parameters can be changed by the end-user. The required password level for each parameter is given in the set point list.

The following menus can only be reached using the JUMP button:


- 4910 Service Timer 1
- 4920 Service Timer 2
- 4930 Diagnostics Menu
- 4940 Reset Eventlog
- 4950 Single/Split/Three phase
- 4971 User Password Change

Level 2 and Level 3 passwords can only be set through the Atlas Copco Utility Software' PC Software.

- 4980 Service Menu

Use the up and down buttons to change the settings and the SELECT button to store the new setting.

This is the described menu flow:



The menu flow is similar in the CONTROL SETUP, POWER SETUP and SYSTEM SETUP.



For more details on the Setup menu we refer to the Qc4001™ User manual.

Protection setup: overview of parameters (for correct values refer to controller)

1010 Bus High Voltage 1 CUSTOMER LEVEL

1011	Setpoint	103.0%
1012	Delay	10.00s
1013	Output Relay A	R0
1014	Output Relay B	R0
1015	Enable	OFF
1016	Fail Class	Warning

1020 Bus High Voltage 2 SERVICE LEVEL

1021	Setpoint	108.0%
1022	Delay	5.00s
1023	Output Relay A	R0
1024	Output Relay B	R0
1025	Enable	OFF
1026	Fail Class	Trip

1030 Bus Low Voltage 1 CUSTOMER LEVEL

1031	Setpoint	97.0%
1032	Delay	10.00s
1033	Output Relay A	R0
1034	Output Relay B	R0
1035	Enable	OFF
1036	Fail Class	Warning

1040 Bus Low Voltage 2 SERVICE LEVEL

1041	Setpoint	92.0%
1042	Delay	5.00s
1043	Output Relay A	R0
1044	Output Relay B	R0
1045	Enable	OFF
1046	Fail Class	Trip

1050 Bus High Frequency 1 CUSTOMER LEVEL

1051	Setpoint	103.0%
1052	Delay	10.00s
1053	Output Relay A	R0
1054	Output Relay B	R0
1055	Enable	OFF
1056	Fail Class	Warning

1060 Bus High Frequency 2 SERVICE LEVEL

1061	Setpoint	105.0%
1062	Delay	5.00s
1063	Output Relay A	R0
1064	Output Relay B	R0
1065	Enable	OFF
1066	Fail Class	Trip

1070 Bus Low Frequency 1 CUSTOMER LEVEL

1071	Setpoint	97.0%
1072	Delay	10.00s
1073	Output Relay A	R0
1074	Output Relay B	R0
1075	Enable	OFF
1076	Fail Class	Warning

1080 Bus Low Frequency 2 SERVICE LEVEL

1081	Setpoint	95.0%
1082	Delay	5.00s
1083	Output Relay A	R0
1084	Output Relay B	R0
1085	Enable	OFF
1086	Fail Class	Trip

1090 Reverse Power SERVICE LEVEL

1091	Setpoint	-20.0%
1092	Delay	5.00s
1093	Output Relay A	R0
1094	Output Relay B	R0
1095	Enable	ON
1096	Fail Class	Trip + Stop

1100 Over Current 1 CUSTOMER LEVEL

1101	Setpoint	110.0%
1102	Delay	60.00s
1103	Output Relay A	R0
1104	Output Relay B	R0
1105	Enable	ON
1106	Fail Class	Warning

1110 Over Current 2 SERVICE LEVEL

1111	Setpoint	120.0%
1112	Delay	30.00s
1113	Output Relay A	R0
1114	Output Relay B	R0
1115	Enable	ON
1116	Fail Class	Trip + Stop

1120 Over Load 1 CUSTOMER LEVEL

1121	Setpoint	110.0%
1122	Delay	60.00s
1123	Output Relay A	R0
1124	Output Relay B	R0
1125	Enable	ON
1126	Fail Class	Warning

1130 Over Load 2 SERVICE LEVEL

1131	Setpoint	120.0%
1132	Delay	30.00s
1133	Output Relay A	R0
1134	Output Relay B	R0
1135	Enable	ON
1136	Fail Class	Trip + Stop

1140 Current Unbalance SERVICE LEVEL

1141	Setpoint	30.0%
1142	Delay	10.00s
1143	Output Relay A	R0
1144	Output Relay B	R0
1145	Enable	OFF
1146	Fail Class	Trip + Stop

1150 Voltage Unbalance SERVICE LEVEL

1151	Setpoint	10.0%
1152	Delay	10.00s
1153	Output Relay A	R0
1154	Output Relay B	R0
1155	Enable	OFF
1156	Fail Class	Trip + Stop

1160 var Import SERVICE LEVEL

1161	Setpoint	50.0%
1162	Delay	10.00s
1163	Output Relay A	R0
1164	Output Relay B	R0
1165	Enable	ON
1166	Fail Class	Warning

1170 var Export SERVICE LEVEL

1171	Setpoint	50.0%
1172	Delay	10.00s
1173	Output Relay A	R0
1174	Output Relay B	R0
1175	Enable	ON
1176	Fail Class	Warning

1180 Df/Dt (ROCOF) SERVICE LEVEL

1181	Setpoint	5.0Hz/s
1182	Delay	6 periods
1183	Output Relay A	R0
1184	Output Relay B	R0
1185	Enable	OFF

1190 Vector Jump SERVICE LEVEL

1191	Setpoint	10.0 deg
1192	Output Relay A	R0
1193	Output Relay B	R0
1194	Enable	OFF

1210 Gen High Voltage 1 CUSTOMER LEVEL

1211	Setpoint	110.0%
1212	Delay	5.0s
1213	Output Relay A	R0
1214	Output Relay B	R0
1215	Enable	ON
1216	Fail Class	Warning

1220 Gen High Voltage 2 MASTER LEVEL

1221	Setpoint	120.0%
1222	Delay	1.0s
1223	Output Relay A	R0
1224	Output Relay B	R0
1225	Enable	ON
1226	Fail Class	Shutdown

1230 Gen Low Voltage 1 CUSTOMER LEVEL

1231	Setpoint	90.0%
1232	Delay	10.0s
1233	Output Relay A	R0
1234	Output Relay B	R0
1235	Enable	RUN
1236	Fail Class	Warning

1240 Gen Low Voltage 2 SERVICE LEVEL

1241	Setpoint	80.0%
1242	Delay	5.0s
1243	Output Relay A	R0
1244	Output Relay B	R0
1245	Enable	RUN
1246	Fail Class	Trip + Stop

1250 Gen High Frequency 1 CUSTOMER LEVEL

1251	Setpoint	110.0%
1252	Delay	5.0s
1253	Output Relay A	R0
1254	Output Relay B	R0
1255	Enable	ON
1256	Fail Class	Warning

1260	Gen High Frequency 2	MASTER LEVEL
1261	Setpoint	120.0%
1262	Delay	1.0s
1263	Output Relay A	R0
1264	Output Relay B	R0
1265	Enable	ON
1266	Fail Class	Shutdown

1270	Gen Low Frequency 1	CUSTOMER LEVEL
1271	Setpoint	90.0%
1272	Delay	10.0s
1273	Output Relay A	R0
1274	Output Relay B	R0
1275	Enable	RUN
1276	Fail Class	Warning

1280	Gen Low Frequency 2	SERVICE LEVEL
1281	Setpoint	80.0%
1282	Delay	5.0s
1283	Output Relay A	R0
1284	Output Relay B	R0
1285	Enable	RUN
1286	Fail Class	Trip + Stop

1310	4...20mA Input 1.1	CUSTOMER LEVEL
1311	Setpoint	10.0mA
1312	Delay	15.0s
1313	Output Relay A	R0
1314	Output Relay B	R0
1315	Enable	OFF
1316	Fail Class	Warning
USW	Alarm Type	High

1320	4...20mA Input 1.2	CUSTOMER LEVEL
1321	Setpoint	10.0mA
1322	Delay	15.0s
1323	Output Relay A	R0
1324	Output Relay B	R0
1325	Enable	OFF
1326	Fail Class	Warning
USW	Alarm Type	High

1330	4...20mA Input 2.1	CUSTOMER LEVEL
1331	Setpoint	10.0mA
1332	Delay	15.0s
1333	Output Relay A	R0
1334	Output Relay B	R0
1335	Enable	OFF
1336	Fail Class	Warning
USW	Alarm Type	High

1340	4...20mA Input 2.2	CUSTOMER LEVEL
1341	Setpoint	10.0mA
1342	Delay	15.0s
1343	Output Relay A	R0
1344	Output Relay B	R0
1345	Enable	OFF
1346	Fail Class	Warning
USW	Alarm Type	High

1350	Oil Pressure	SERVICE LEVEL
1351	Setpoint	4.0 bar
1352	Delay	5.0s
1353	Output Relay A	R0
1354	Output Relay B	R0
1355	Enable	OFF
1356	Fail Class	Warning
USW	Sensor Type	0

1360	VDO 1.2	SERVICE LEVEL
1361	Setpoint	5.0 bar
1362	Delay	5.0s
1363	Output Relay A	R0
1364	Output Relay B	R0
1365	Enable	OFF
1366	Fail Class	Warning

1370	High Coolant Temperature	SERVICE LEVEL
1371	Setpoint	110 deg 1)
	Setpoint	100 deg 2) 3) 4)
1372	Delay	3.0s
1373	Output Relay A	R0
1374	Output Relay B	R0
1375	Enable	ON
1376	Fail Class	Warning
USW	Sensor Type	0

1380	VDO 2.2	SERVICE LEVEL
1381	Setpoint	108 deg
1382	Delay	5.0s
1383	Output Relay A	R0
1384	Output Relay B	R0
1385	Enable	OFF
1386	Fail Class	Warning

1390	Fuel Level 1	CUSTOMER LEVEL
1391	Setpoint 1	10.0%
1392	Delay	10.0s
1393	Output Relay A	R0
1394	Output Relay B	R0
1395	Enable	ON
1396	Fail Class	Warning
USW	Sensor Type	1

1400	Fuel Pump Logic	CUSTOMER LEVEL
1401	Setpoint 2	20.0%
1402	Setpoint 3	80.0%
1403	Pump Relay	R4
1404	Enable	OFF
1405	Fill Check Delay	60.0s

1410	Fuel High Level	CUSTOMER LEVEL
1411	Setpoint 4	98.0%
1412	Delay	5.0s
1413	Output Relay A	R0
1414	Output Relay B	R0

1420	Overspeed	MASTER LEVEL
1421	Setpoint	1980rpm
1422	Delay	3.0s
1423	Output Relay A	R0
1424	Output Relay B	R0
1425	Enable	ON
1426	Fail Class	Shutdown

1430	Overspeed	MASTER LEVEL
1431	Overspeed S2	1980rpm
1432	Overspeed S3	1980rpm
1433	Overspeed S4	1980rpm

1440	Engine Failure	SERVICE LEVEL
1441	Delay	1.0s
1442	Output Relay A	R0
1443	Output Relay B	R0
1444	Enable	ON
1445	Fail Class	Shutdown
USW	Type	High

1450	Emergency Stop	MASTER LEVEL
1451	Delay	0.0s
1452	Output Relay A	R0
1453	Output Relay B	R0
1454	Enable	ON
1455	Fail Class	Shutdown
USW	Type	High

1460	Coolant Temperature 1	SERVICE LEVEL
1461	Setpoint	100 deg
1462	Delay	3.0s
1463	Output Relay A	R0
1464	Output Relay B	R0
1465	Enable	OFF
1466	Fail Class	Warning
USW	Alarm Type	High

1470	Coolant Temperature 2	SERVICE LEVEL
1471	Setpoint	108 deg
1472	Delay	3.0s
1473	Output Relay A	R0
1474	Output Relay B	R0
1475	Enable	OFF
1476	Fail Class	Shutdown
USW	Alarm Type	High

1480	Oil Pressure	SERVICE LEVEL
1481	Setpoint	3.0 bar
1482	Delay	5.0s
1483	Output Relay A	R0
1484	Output Relay B	R0
1485	Enable	OFF
1486	Fail Class	Warning
USW	Alarm Type	Low

1490	Fuel Level 2	CUSTOMER LEVEL
1491	Setpoint	5.0%
1492	Delay	20.0s
1493	Output Relay A	R0
1494	Output Relay B	R0
1495	Enable	ON
1496	Fail Class	Trip + Stop

1700	Digital Input 21	CUSTOMER LEVEL
1701	Delay	10.0s
1702	Output Relay A	R0
1703	Output Relay B	R0
1704	Enable	OFF
1705	Fail Class	Warning
1706	Type	High

1710	Digital Input 22	CUSTOMER LEVEL
1711	Delay	10.0s
1712	Output Relay A	R0
1713	Output Relay B	R0
1714	Enable	OFF
1715	Fail Class	Warning
1716	Type	High

1720	Digital Input 23	CUSTOMER LEVEL
1721	Delay	10.0s
1722	Output Relay A	R0
1723	Output Relay B	R0
1724	Enable	OFF
1725	Fail Class	Warning
1726	Type	High

1730	Digital Input 24	CUSTOMER LEVEL
1731	Delay	10.0s
1732	Output Relay A	R0
1733	Output Relay B	R0
1734	Enable	OFF
1735	Fail Class	Warning
1736	Type	High

1740	Digital Input 25	CUSTOMER LEVEL
1741	Delay	10.0s
1742	Output Relay A	R0
1743	Output Relay B	R0
1744	Enable	OFF
1745	Fail Class	Warning
1746	Type	High

1750	Digital Input 26	CUSTOMER LEVEL
1751	Delay	10.0s
1752	Output Relay A	R0
1753	Output Relay B	R0
1754	Enable	OFF
1755	Fail Class	Warning
1756	Type	High

1760	Low Fuel Warning	SERVICE LEVEL
1761	Delay	3.0s
1762	Output Relay A	R0
1763	Output Relay B	R0
1764	Enable	ON
1765	Fail Class	Warning
1766	Type	High

1770	Low Oil Pressure	SERVICE LEVEL
1771	Delay	3.0s
1772	Output Relay A	R0
1773	Output Relay B	R0
1774	Enable	RUN
1775	Fail Class	Shutdown
1776	Type	Low

1780	Coolant Temp. & Cool. Level	SERVICE LEVEL
1781	Delay	7.5s
1782	Enable Output Relay	R0
1783	Disable Output Relay	R0
1784	Enable	RUN
1785	Fail Class	Shutdown
1786	Type	Low

1790	Digital Input 30	CUSTOMER LEVEL
1791	Delay	10.0s
1792	Enable Output Relay	R0
1793	Disable Output Relay	R0
1794	Enable	OFF
1795	Fail Class	Warning
1796	Type	High

1860	Run Status	SERVICE LEVEL
1861	Delay	5.0s
1862	Output Relay A	R0
1863	Output Relay B	R0
1864	Enable	OFF

1870	W/L Input	SERVICE LEVEL
1871	Delay	3.0s
1872	Output Relay A	R0
1873	Enable	RUN
1874	Type	Low

1880	Static Charger	CUSTOMER LEVEL
1881	Delay	10.0s
1882	Output Relay A	R0
1883	Enable	OFF
1884	Type	High

1890	MDEC Run Signal	SERVICE LEVEL
1891	Delay	10.0s
1892	Output Relay A	R0
1893	Output Relay B	R0
1894	Enable	OFF

Control setup: overview of parameters

2010	Synchronisation Type	SERVICE LEVEL
	2011 Sync. Type	Dynamic Sync.
2020	Dynamic Sync.	SERVICE LEVEL
	2021 Df max.	0.3Hz
	2022 Df min.	0.0Hz
	2023 DU max.	5%
	2024 Breaker Delay	75ms
2030	Static Sync.	SERVICE LEVEL
	2031 GB Close Time	1.0s
	2032 Close Window	10.0 deg
	2033 Phase Gain	40
	2034 Frequency Gain	40
2050	f/U Limits	SERVICE LEVEL
	2051 Df max.	3.0Hz
	2052 DU max.	8%
2060	GB Synchr. Failure	SERVICE LEVEL
	2061 Delay	60.0s
	2062 Output Relay A	R0
	2063 Output Relay B	R0
2070	MB Synchr. Failure	SERVICE LEVEL
	2071 Delay	60.0s
	2072 Output Relay A	R0
	2073 Output Relay B	R0
2090	Frequency Control	CUSTOMER LEVEL
	2091 Deadband	0.2%
	2092 Frequency KP	15
	2093 Frequency KI	120
2100	Power Control	CUSTOMER LEVEL
	2101 Deadband	0.2%
	2102 Power KP	10
	2103 Power KI	45
2110	Power Ramp Up	CUSTOMER LEVEL
	2111 Speed	10%/s
	2112 Delay Point	10%
	2113 Delay Time	0.0s
2120	Power Ramp Down	CUSTOMER LEVEL
	2121 Speed	10%/s
	2122 Breaker Open	5%
2130	P/f Control Mix	CUSTOMER LEVEL
	2131 Mix Factor	50%
	2132 PF Control KP	250
	2133 PF Control KI	160
2140	Voltage Control	CUSTOMER LEVEL
	2141 Deadband	0.2%
	2142 KP	150
	2143 KI	320
2150	Var Control	CUSTOMER LEVEL
	2151 Deadband	0.2%
	2152 KP	25
	2153 KI	80
2160	Q/U Control Mix	SERVICE LEVEL
	2161 Mix Factor	50%
2170	PF Control	CUSTOMER LEVEL
	2171 Deadband	5
2180	Gov. Reg. Failure	SERVICE LEVEL
	2181 Deadband	30.0%
	2182 Delay	60.0s
	2183 Output Relay A	R0
	2184 Output Relay B	R0
2190	AVR Reg. Failure	SERVICE LEVEL
	2191 Deadband	30.0%
	2192 Delay	60.0s
	2193 Output Relay A	R0
	2194 Output Relay B	R0
2200	Breaker Type	CUSTOMER LEVEL
	2201 GB Type	Pulse
	2202 MB Type	Pulse
2210	Static Sync.	SERVICE LEVEL
	2211 Df max.	0.1Hz
	2212 DU max.	5%
	2213 Close Window	10.0 deg
	2214 KP	80
	2215 KI	80
	2216 Delay	1.0s

Power setup: overview of parameters

3010	Mains Power	CUSTOMER LEVEL
	3011 Day	5000kW
	3012 Night	5000kW
	3013 Transducer Scale	5000kW
3020	Daytime Period	CUSTOMER LEVEL
	3021 Start Hour	8
	3022 Start Minute	0
	3023 Stop Hour	16
	3024 Stop Minute	0
3030	Start Generator	CUSTOMER LEVEL
	3031 Setpoint	80%
	3032 Delay	10.0s
	3033 Minimum Load	10%
3040	Stop Generator	CUSTOMER LEVEL
	3041 Setpoint	60%
	3042 Delay	600.0s
3050	Load Dependent Start	CUSTOMER LEVEL
	3051 Setpoint	50kW
	3052 Delay	1.0s
	3053 Minimum Load	20kW
3060	Load Dependent Stop	CUSTOMER LEVEL
	3061 Setpoint	100kW
	3062 Delay	30.0s
3070	Test	CUSTOMER LEVEL
	3071 Setpoint	50%
	3072 Delay	300.0s
	3073 Test Synchron.	OFF
3080	Fixed Power Setpoint	CUSTOMER LEVEL
	3081 Power Set	80%
	3082 PF Set	0.95
3100	PMS Configuration	CUSTOMER LEVEL
	3101 # Gen-sets Available	1
	3102 Mains Available	OFF
	3103 PMS Active	OFF
	3104 Command Unit	ON
	3105 Enable Start/Stop	Local
3110	Internal Communication ID	CUSTOMER LEVEL
	3111 Intern. Comm. ID	1
3120	Priority Select	CUSTOMER LEVEL
	3121 Priority Select	Manual
3130	Number of ID's	CUSTOMER LEVEL
	3131 Enable Mains	OFF
	3132 Enable ID1	ON
	3133 Enable ID2	OFF
	3134 Enable ID3	OFF
	3135 Enable ID4	OFF
	3136 Enable ID5	OFF
3140	Number of ID's	CUSTOMER LEVEL
	3141 Enable ID6	OFF
	3142 Enable ID7	OFF
	3143 Enable ID8	OFF
	3144 Enable ID9	OFF
	3145 Enable ID10	OFF
	3146 Enable ID11	OFF
3160	Priority of ID's	CUSTOMER LEVEL
	3161 Priority ID1	1
	3162 Priority ID2	2
	3163 Priority ID3	3
	3164 Priority ID4	4
	3165 Priority ID5	5
	3166 Transmit	OFF
3170	Priority of ID's	CUSTOMER LEVEL
	3171 Priority ID6	6
	3172 Priority ID7	7
	3173 Priority ID8	8
	3174 Priority ID9	9
	3175 Priority ID10	10
	3176 Priority ID11	11
3230	Ground Relay	CUSTOMER LEVEL
	3231 Output Relay A	R0
	3232 Output Relay B	R0
	3233 Enable	OFF
3240	Stop Noncon. Gen-sets	CUSTOMER LEVEL
	3241 Delay	60.0s
3250	Power Capacity	CUSTOMER LEVEL
	3251 Power Capacity	50kW

System setup: overview of parameters

4010	Nominal Settings	CUSTOMER LEVEL
4011	Frequency	50Hz
4012	Generator Power	120kW 1)
	Generator Power	160kW 2)
	Generator Power	200kW 3)
	Generator Power	240kW 4)
4013	Generator Current	216A 1)
	Generator Current	289A 2)
	Generator Current	361A 3)
	Generator Current	433A 4)
4014	Generator Voltage	400V
4020	Nominal Settings 2	CUSTOMER LEVEL
4021	Frequency	50Hz 1)
	Frequency	60Hz 2) 3) 4)
4022	Generator Power	120kW 1)
	Generator Power	190kW 2)
	Generator Power	210kW 3)
	Generator Power	239kW 4)
4023	Generator Current	216A 1)
	Generator Current	286A 2)
	Generator Current	315A 3)
	Generator Current	360A 4)
4024	Generator Voltage	400V 1)
	Generator Voltage	480V 2) 3) 4)
4030	Nominal Settings 3	CUSTOMER LEVEL
4031	Frequency	50Hz
4032	Generator Power	120kW 1)
	Generator Power	160kW 2)
	Generator Power	200kW 3)
	Generator Power	240kW 4)
4033	Generator Current	216A 1)
	Generator Current	289A 2)
	Generator Current	361A 3)
	Generator Current	433A 4)
4034	Generator Voltage	400V
4040	Nominal Settings 4	CUSTOMER LEVEL
4041	Frequency	50Hz
4042	Generator Power	120kW 1)
	Generator Power	160kW 2)
	Generator Power	200kW 3)
	Generator Power	240kW 4)
4043	Generator Current	216A 1)
	Generator Current	289A 2)
	Generator Current	361A 3)
	Generator Current	433A 4)
4044	Generator Voltage	400V
4050	Transformer Gen-set	SERVICE LEVEL
4051	Volt. Prim.	440V
4052	Volt. Sec.	440V
4053	Current Prim.	300A 1) 2)
	Current Prim.	600A 3) 4)
4054	Current Sec.	5A
4060	Transformer Bus	SERVICE LEVEL
4061	Volt. Prim.	440V
4062	Volt. Sec.	440V
4100	Engine Comms.	SERVICE LEVEL
4101	Type	OFF
4110	Date & Time (internal clock)	CUSTOMER LEVEL
4110	Date	dd/mm/yyyy
4110	Time	hh:mm
4120	Counters	MASTER LEVEL
4121	Running Time	0
4122	GB Operations	0
4123	MB Operations	0
4124	Reset kWh	OFF
4220	Battery Low	SERVICE LEVEL
4221	Setpoint	18.0V
4222	Delay	3.0s
4223	Output Relay A	R0
4224	Output Relay B	R0
4225	Enable	ON
4230	Battery High	SERVICE LEVEL
4231	Setpoint	30.0V
4232	Delay	0.5s
4233	Output Relay A	R0
4234	Output Relay B	R0
4235	Enable	ON
4240	Language	CUSTOMER LEVEL
4241	Language	English
4250	Loadshare Out	CUSTOMER LEVEL
4251	Loadshare Out	4.0V
4260	Loadshare Type	CUSTOMER LEVEL
4261	Loadshare Type	Qc4001
4270	Battery Low 2	CUSTOMER LEVEL
4271	Setpoint	18.0V
4272	Delay	10.0s
4273	Output Relay A	R0
4274	Output Relay B	R0
4275	Enable	OFF
4280	Battery High 2	CUSTOMER LEVEL
4281	Setpoint	30.0V
4282	Delay	10.0s
4283	Output Relay A	R0
4284	Output Relay B	R0
4285	Enable	OFF
4290	Mode Relay	CUSTOMER LEVEL
4291	Test	R0
4292	Auto	R0
4293	Semi	R0
4300	Engine Type	MASTER LEVEL
4301	Engine Type	Diesel
4320	Gen-Set Mode	CUSTOMER LEVEL
4321	Gen-Set Mode	Island
4330	CAN Unit	CUSTOMER LEVEL
4331	CAN Unit	bar-celsius
4350	Tacho Configuration	SERVICE LEVEL
4351	Setpoint	400rpm
4352	Teeth	129 1)
	Teeth	140 2) 3)
	Teeth	156 4)
4360	Starter	CUSTOMER LEVEL
4361	Start Prepare	1.0s
4362	Start ON Time	12.0s
4363	Start OFF Time	12.0s
4364	Prepare	Normal
4370	Start Attempts	SERVICE LEVEL
4371	Attempts	3
4372	Output Relay A	R0
4373	Output Relay B	R0
4380	f/U OK	SERVICE LEVEL
4381	Delay	3.0s
4390	f/U failure	SERVICE LEVEL
4391	Delay	30.0s
4392	Output Relay A	R0
4393	Output Relay B	R0
4400	Stop	SERVICE LEVEL
4401	Cool Down Time	60.0s
4402	Extended Stop	15.0s
4403	Coil Type	RUN
4410	Stop Failure	SERVICE LEVEL
4411	Delay	20.0s
4412	Output Relay A	R0
4413	Output Relay B	R0
4420	Mains V Failure	CUSTOMER LEVEL
4421	Fail Delay	1.0s
4422	Mains OK Delay	60.0s
4423	Low Voltage	75%
4424	High Voltage	120%
4425	Mains Fail Control	Start+Open MB
4430	Mains Hz Failure	CUSTOMER LEVEL
4431	Fail Delay	1.0s
4432	Mains OK Delay	60.0s
4433	Low Frequency	95%
4434	High Frequency	105%
4440	MB Control	CUSTOMER LEVEL
4441	Function	Mode Shift OFF
4442	MB Close Delay	0.5s
4443	Back Sync.	OFF
4444	Synchr. Timer	75ms
4450	Alarm Horn	CUSTOMER LEVEL
4451	Delay	20.0s
4460	GB Control	CUSTOMER LEVEL
4461	GB Close Delay	1.0s
4610	Relay 1	SERVICE LEVEL
4611	Function	Alarm
4612	Off Delay	0.0s

4620	Relay 2	SERVICE LEVEL
4621	Function	Alarm
4622	Off Delay	0.0s

4630	Relay 3	SERVICE LEVEL
4631	Function	Alarm
4632	Off Delay	0.0s

4640	Relay 4	SERVICE LEVEL
4641	Function	Alarm
4642	Off Delay	0.0s

4710	Start/Stop Cmd. 1	CUSTOMER LEVEL
4711	Enable	OFF
4712	START/STOP	STOP
4713	Day(s)	10
4714	Hour	10
4715	Minute	0

4720	Start/Stop Cmd. 2	CUSTOMER LEVEL
4721	Enable	OFF
4722	START/STOP	STOP
4723	Day(s)	10
4724	Hour	10
4725	Minute	0

4730	Start/Stop Cmd. 3	CUSTOMER LEVEL
4731	Enable	OFF
4732	START/STOP	STOP
4733	Day(s)	10
4734	Hour	10
4735	Minute	0

4740	Start/Stop Cmd. 4	CUSTOMER LEVEL
4741	Enable	OFF
4742	START/STOP	STOP
4743	Day(s)	10
4744	Hour	10
4745	Minute	0

4750	Start/Stop Cmd. 5	CUSTOMER LEVEL
4751	Enable	OFF
4752	START/STOP	STOP
4753	Day(s)	10
4754	Hour	10
4755	Minute	0

4760	Start/Stop Cmd. 6	CUSTOMER LEVEL
4761	Enable	OFF
4762	START/STOP	STOP
4763	Day(s)	10
4764	Hour	10
4765	Minute	0

4770	Start/Stop Cmd. 7	CUSTOMER LEVEL
4771	Enable	OFF
4772	START/STOP	STOP
4773	Day(s)	10
4774	Hour	10
4775	Minute	0

4780	Start/Stop Cmd. 8	CUSTOMER LEVEL
4781	Enable	OFF
4782	START/STOP	STOP
4783	Day(s)	10
4784	Hour	10
4785	Minute	0

4790	GSM Pin Code	CUSTOMER LEVEL
4791	Pin code	0000

4910	Service Timer 1	SERVICE LEVEL
4911	Enable	ON
4912	Run Hours	500h
4913	Elapsed Days	365 days
4914	Fail Class	Warning
4915	Output Relay A	R0
4916	Reset	

4920	Service Timer 2	SERVICE LEVEL
4921	Enable	ON
4922	Run Hours	1000h
4923	Elapsed Days	365 days
4924	Fail Class	Warning
4925	Output Relay A	R0
4926	Reset	

4930	Diagnostics Mode	CUSTOMER LEVEL
4930	Diagnostics	Normal

4940	Reset Eventlog	MASTER LEVEL
4940	Reset	OFF

4971	Level 1 Password	CUSTOMER LEVEL
4971	Setting	2003

4972	Level 2 Password	SERVICE LEVEL
4972	Setting	****

4973	Level 3 Password	MASTER LEVEL
4973	Setting	****

0	Parameter ID	MASTER LEVEL
USW	ID	1) 9822 2002 63 00
USW	ID	2) 9822 2002 64 00
USW	ID	3) 9822 2002 65 00
USW	ID	4) 9822 2002 66 00

5010	VDO 1	SERVICE LEVEL
5011	VDO 1 @ 0.0bar	10
5012	VDO 1 @ 2.5bar	44.9
5013	VDO 1 @ 5.0bar	81
5014	VDO 1 @ 6.0bar	134.7

5020	VDO 1	SERVICE LEVEL
5021	VDO 1 @ 7.0bar	184
5022	VDO 1 @ 8.0bar	200
5023	VDO 1 @ 9.0bar	210
5024	VDO 1 @ 10.0bar	220

5030	VDO 2	SERVICE LEVEL
5031	VDO 2 @ 40°C	292
5032	VDO 2 @ 50°C	197
5033	VDO 2 @ 60°C	134
5034	VDO 2 @ 70°C	97

5040	VDO 2	SERVICE LEVEL
5041	VDO 2 @ 80°C	70
5042	VDO 2 @ 90°C	51
5043	VDO 2 @ 100°C	39
5044	VDO 2 @ 110°C	29

5050	VDO 3	CUSTOMER LEVEL
5051	VDO 3 @ 0%	78.8
5052	VDO 3 @ 40%	47.9
5053	VDO 3 @ 50%	40.2
5054	VDO 3 @ 60%	32.5

5060	VDO 3	CUSTOMER LEVEL
5061	VDO 3 @ 70%	24.8
5062	VDO 3 @ 80%	17
5063	VDO 3 @ 90%	9.3
5064	VDO 3 @ 100%	1.6

0	Password Language Page	SERVICE LEVEL
USW	Level	Service

0	Password Log Page	SERVICE LEVEL
USW	Level	Service

0	Password Control Page	SERVICE LEVEL
USW	Level	Service

2.6.5 Passwords

Changing different parameters requires different password levels. Some parameters cannot be changed by the end-customer because of safety reasons.

There are 4 different password levels:

- No password
- User password (default setting 2003)
- Service password
- Master password

Once the password has been entered, the user can change all the accessible set points.

The user can change the User password (go with JUMP button to channel 4971).

2.6.6 Fail Classes

All the activated alarms of the module are configured with a fail class. The fail class defines the category of the alarm and the subsequent action.

4 different fail classes can be used:

Fail Class	Action				
	Alarm horn relay	Alarm display	GB Trip	Gen-Set stop	Shutdown
1. Warning		X			
2. Trip of GB	X	X	X		
3. Trip & Stop	X	X	X	X	
4. Shutdown	X	X	X		X

All alarms can be disabled or enabled as following:

- OFF: disabled alarm, inactive supervision.
- ON: enabled alarm, supervision of alarm all the time.
- RUN: generator running alarm, only supervision when the generator is running.

2.6.7 Languages

English is the default language ex-factory, but all the 12 European languages can be selected in channel 4240. It is possible to edit and/or add text and to edit and/or add languages.

2.6.8 Standard modes

The following modes can be selected (push the dedicated button on the display unit).

Test mode

Enables the user to test the generator on a regular basis. The generator will follow a predefined sequence of actions.

Semi-Auto mode

Enables the user to have manual control and activation of the sequences with the buttons on the Qc4001™ control panel (A2). The generator can be started/stopped manually. The breakers can be closed/opened manually, but the module will check automatically synchronizing sequences.

Auto mode

The module controls the generator and the circuit breakers (generator breaker GB and mains breaker MB) automatically according to the operational state.

Diagnostics menu

This diagnostics menu can only be entered using the JUMP pushbutton, and going to channel 4930. This menu is used in engine diagnostics situations.

If diagnostics is selected in this menu, the fuel solenoid relay output will be de-energized for 30 seconds (to make sure that the unit is completely stopped), and then gets energized again. Then engine diagnostics can take place.

To leave this status, normal operation has to be selected again in this menu.



It's only possible to start the generator when Normal is selected

2.6.9 Standard applications

In the Qc4001™ module 5 application types can be selected (in channel 4320). A combination of each application type with the running mode results in a specific application.

Depending on the application the user has to connect extra wirings to terminal blocks X25. These terminal blocks can be found inside the control box on a DIN-rail. We refer to the circuit diagram 9822 0889 73a/00 for the correct connections.

Island operation

This operation type is selected for installations with one or more generators, but always without the Mains (= stand-alone). In practice up to 16 generators can be installed in parallel.

- Combined with Semi-auto mode = Local Start operation.

The sequences start/stop/close GB/open GB can be activated manually.

- Combined with Auto mode = Remote Start operation.

The remote start signal can be given with an external switch or with the internal real time clock. (8 start/stop commands can be defined in channels 4710-4780). After the generator has been started, the generator breaker will close automatically.



The generator cannot be started with an external signal, if the internal real time clock commands are enabled!

Installation wirings

- Terminals X25.10/X25.11 have to be linked. The module always needs a feedback signal from the Mains Breaker MB. In Island mode there is no MB in the system. In this case the MB opened signal is simulated with this link.

- The busbar sensing lines have to be wired to the corresponding control module inputs.

Place bridges between:

- X25.33 (L1) => X25.3
- X25.34 (L2) => X25.4
- X25.35 (L1) => X25.5

(The bus bar = power cables between GB and load)

- For Remote Start operation: wire the RS switch between X25.9 & X25.10.
- For Paralleling applications with other generators: see “Paralleling” section to set up generator for paralleling.

Automatic Mains Failure (AMF) operation

This application is only possible in combination with the Auto mode. If the Semi-auto mode is selected the AMF operation will NOT function!

When the Mains exceeds the defined voltage/frequency/current/speed limits for a defined delay time, the generator will take over the load automatically.

When the mains is restored within the defined limits for a defined time, the generator will synchronise to the mains and unload before disconnecting (only if back-synchronisation feature is enabled).

The generator will then go into cool down and stop.

It is possible to enable/disable the back synchronisation feature (in channel 4440).

Installation wirings

- The link between X25.10 & X25.11 has to be removed.
- Mains breaker feedback lines have to be wired to X25.10/X25.11/X25.12.
- Mains breaker control lines have to be wired to X25.13/X25.14/X25.15/X25.16. These terminals are voltage free contacts. The power for the MB has to be supplied by the customer (24 Vdc/230 Vac) (max. contact rating K11, K12 = 250 V/16 A).
- Make sure the connections between X25.33 & X25.3, X25.34 & X25.4, X25.35 & X25.5 are removed.
- The Mains sensing lines L1, L2, L3 have to be wired to terminals X25.3, X25.4, X25.5 (mains neutral is not sensed).
- If back synchronisation is enabled, all settings for paralleling set up (see “Paralleling”) must be verified also.

Peak Shaving (PS) operation

This application is normally used in combination with the Auto mode.

The generator will start up when the mains imported power (measured through an optional Power Transducer = PT) exceeds a defined level. The generator will synchronise with the bus, and will take load until the defined allowable mains imported power level is reached.

When the mains imported power decreases below the defined mains imported power level for a defined time, the generator will unload and disconnect from the bus. Then the generator will go into cool down.

Installation wirings

- The link between X25.10/X25.11 has to be removed.
- Mains breaker feedback lines have to be wired to X25.10/X25.11/X25.12.
- Mains breaker control lines have to be wired to X25.13/X25.14/X25.15/X25.16. These terminals are voltage free contacts. The power for the MB has to be supplied by the customer (24 Vdc/230 Vac) (max. contact rating K11, K12 = 250 V/16 A).
- The Mains sensing lines L1, L2, L3 have to be wired to terminals X25.3, X25.4, X25.5 (mains neutral is not sensed).
- Make sure the connections between X25.33 & X25.3, X25.34 & X25.4, X25.35 & X25.5 are removed.
- Power Transducer lines have to be wired to X25.21 (input) and X25.22 (GND).

Verify al settings for paralleling set up (see “Parallelling”).

Fixed Power (FP) operation

This application is normally used in combination with Semi-auto mode in installations with the Mains. The generator will deliver a defined fixed power to the load or to the Mains.

Installation wirings

- The link between X25.10/X25.11 has to be removed.
- Mains breaker feedback lines have to be wired to X25.10/X25.11/X25.12.
- Mains breaker control lines have to be wired to X25.13/X25.14/X25.15/X25.16. These terminals are voltage free contacts. The power for the MB has to be supplied by the customer (24 Vdc/ 230 Vac) (max. contact rating K11, K12 = 250 V/16 A)
- The Mains sensing lines L1, L2, L3 have to be wired to terminals X25.3, X25.4, X25.5 (Mains neutral is not sensed).
- Make sure the connections between X25.33 & X25.3, X25.34 & X25.4, X25.35 & X25.5 are removed.
- Verify al settings for paralleling set up (see “Parallelling”).

Load Take Over (LTO) operation

This application is normally used in combination with Semi-auto or Auto mode in installations with the Mains. The generator will start-up, synchronise and take over the load from the Mains gradually, before opening the Mains Breaker. To know if the load is completely taken over from the mains, an optional Power Transducer is necessary.

Installation wirings


- The link between X25.10 & X25.11 has to be removed.
- Mains breaker feedback lines have to be wired to X25.10/X25.11/X25.12.
- Mains breaker control lines have to be wired to X25.13/X25.14/X25.15 / X25.16. These terminals are voltage free contacts. The power for the MB has to be supplied by the customer (24 Vdc/ 230 Vac) (max. contact rating K11, K12 = 250 V/16 A).
- The Mains sensing lines L1, L2, L3 have to be wired to terminals X25.3, X25.4, X25.5 (mains neutral is not sensed).
- Make sure the connections between X25.33 & X25.3, X25.34 & X25.4, X25.35 & X25.5 are removed.
- Power Transducer lines have to be wired to X25.21 (input) and X25.22 (GND).
- Verify al settings for paralleling set up (see “Parallelling”).

2.6.10 Parallelling

Prior to starting parallel operation of two generators, following connections need to be made:

- Connect the communication cable between the generators (sockets X30 & X31).
- Each dedicated generator or SAPE has two of these connections, to enable paralleling more than two generators.
- Connect the load with the generator.

Go via the site distribution panel (to be installed by the customer) to connect the generator(s) and/or the SAPE unit(s) with the load. Always connect generator with the load, and never directly with second generator.



CORRECT

WRONG



When paralleling, make sure to disable the Earth leakage relay by putting switch S13 into off position.

2.6.11 Option Power Management System

PMS (= Power Management System) is a system that will automatically start & stop generators based on the actual load dependency. This will be done through a PMS communication between the different units connected.

PMS applications are always in combination with AUTO mode. The Qc4001™ controllers from the gensets need to be programmed as PMS in AUTO mode. When a Qc Mains controller is installed this needs to be programmed in the application that is required (AMF, LTO, Fixed power) and AUTO mode.



By programming the parameters in AUTO mode, the generator can start up immediately. It is recommended to place the generator in SEMI-AUTO mode while programming all the PMS parameters !

In an application with PMS it is important to program correctly the Start & Stop signals between the different generators because of the following reasons:

- The maximum load step needs to be programmed in the Qc4001™ controllers. This never may exceeds the power reserve of the running generators. Otherwise the gensets will go in overload with a sudden max. load increase before the next generator is started up and connected to the busbar.
- To prevent the gensets to run in a start - stop loop.

The start signal is the value of the maximum required load step.

The stop signal is the value when the generator should be stopped automatically.

Example: Installation with 3 gensets

G1 = 300 kW; G2 = 200 kW; G3 = 200 kW

- Start signal is set at 90 kW (maximum load step < 90 kW)

Start signal if:

Total Power needed > (total available power of running gensets - set point start signal)

- Only G1 is running; at 210 kW load (300 kW - 90 kW)
=> G2 will be started
- G1 & G2 are running; at 410 kW load (200 kW + 300 kW - 90 kW) => G3 will be started

- Stop signal is set at 100 kW and priority is set as (high) G1 > G2 > G3 (low)

Stop signal if :

Total Power needed < (Total available power of running gensets - Power of generator with lowest priority - set point stop signal)

- G1 & G2 & G3 are running; at 400 kW (700 kW - 200 kW - 100 kW) => G3 will be stopped
- G1 & G3 are running; at 200 kW (500 kW - 200 kW - 100 kW) => G2 will be stopped

The priority on starting & stopping the generators can be chosen on priority settings or on the amount of running hours. In manual mode the start & stop sequence is determent by the chosen priority between the generators. The generator with the lowest priority will start as the latest genset and will stop as first. If running hours are chosen as priority the start & stop sequence will be defined based on the actual running hours of the different generators. The lowest running hours will get the highest priority.



When paralleling generators with PMS, it is no longer necessary to use the analogue load sharing lines. This will be done through the PMS communication lines. Use a screened CAN communication cable with a maximum total distance of 200 meters. Do not connect the cable screen to the ground ! Use a 120 Ohm resistor at both end controllers of the PMS



For more information on this option, see User Manual Qc4001™.

2.6.12 Overview of applications

Installations with only 1 generator		
Application type	Mode	Comments
Island operation	SEMI-AUTO mode	= Local start
	AUTO mode	= Remote start
AMF operation	(SEMI-AUTO mode)	AMF Function will not work!
	AUTO mode	= Emergency start @ Mains Failure
Peak shaving	SEMI-AUTO mode	Only with Power Transducer (*)
	AUTO mode	Only with Power Transducer (*)
Fixed Power	SEMI-AUTO mode	
	AUTO mode	
Load Take Over	SEMI-AUTO mode	Only with Power Transducer (*)
	AUTO mode	Only with Power Transducer (*)

(*) A Power Transducer is a device that measures the actual power of the mains and which translates this into a 4...20 mA signal towards the Qc4001™ module. For details, please contact Atlas Copco.

Installations with more generators		
Application type	Mode	Comments
Island operation	SEMI-AUTO mode	= Manual paralleling between generators
	AUTO mode	= Remote paralleling between generators
AMF operation	(SEMI-AUTO mode)	AMF Function will not work!
	AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
Peak shaving	SEMI-AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
	AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
Fixed Power	SEMI-AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
	AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
Load Take Over	SEMI-AUTO mode	Only with PMS option + Qc4001™ Mains module (**)
	AUTO mode	Only with PMS option + Qc4001™ Mains module (**)

(**) It is possible to have an optional power management system (PMS) that allows communication between the Qc4001™ modules over CAN-bus. It has a fully intelligent system, which will start/load/stop the generator according to the actual load and to the status of each generator. The installation can contain up to 16 Qc4001™ modules (all equipped with this PMS option). If the Mains is included in the installation, then an extra Qc4001™ module is required. The installation can be monitored and controlled via the PMS Software Package. For details on this option, please contact Atlas Copco.




1. Each installation has to be prepared and reviewed very carefully before start-up. Wrong or incomplete wirings can damage the installation brutally!
2. Each application requires a specific combination of the following parameters:
 - Test / Semi-auto / Auto mode
 - Island / AMF / PS / FP / LTO application type
 - Back synchronising enabled/disabled

Wrong parameter settings can damage the installation brutally!

3. To be able to start up in cold conditions, parameter 4361 (Start prepare) can be changed to a higher value to have some preheating. Do not put this value above 60 seconds to avoid any possible damage.
4. For more information on the Qc4001™ module and its applications, we refer to the Qc4001™ User Manual. If you need more assistance, please contact Atlas Copco.

2.7 Output terminal board (TB)

The “Terminal board” provides a terminal board for more easy connection of cables. It is situated below the control and indicator panel.



N13 ... Earth leak detector

Detects and indicates an earth fault current and activates the main circuit breaker Q1. The detection level can be set at 30 mA fixed with instantaneous trip but can also be adjusted between 30 mA and 250 A with time delayed (0 – 1 sec) trip. N13 has to be reset manually after eliminating the problem (reset button marked R). It can be overridden by means of the earth leak switch (S13, labelled IΔN) but has to be tested monthly by pushing test button T13.

S2.....Emergency stop button

Push the button to stop the generator in case of an emergency. When the button is pressed, it must be unlocked, by turning it anti-clockwise, before the generator can be restarted. The emergency stop button can be secured in the locked position with the key, to avoid unauthorized use. When the emergency button is pressed the control module needs to be reset.

S13.... Lock-out switch for earth fault protection (N13)

This switch is located inside the cubicle and is labelled IΔN.

Position O: No de-energising of the main circuit breaker Q1 when an earth fault occurs.

Position 1: De-energising of the main circuit breaker Q1 when an earth fault occurs.

Q1 Circuit breaker for X1

Interrupts the power supply X1 when a short-circuit occurs at the load side, or when the overcurrent protection is activated. When activated, Q1 interrupts the three phases towards X1. It must be reset manually after eliminating the problem.

Q2 Circuit breaker for X2

Interrupts the power supply X2 when a short-circuit occurs at the load side, or when the overcurrent protection is activated. When activated, Q2 interrupts phase L3 and the neutral towards X2. It must be reset manually after eliminating the problem.

X1..... Main power supply

Terminals L1, L2, L3, N (= neutral) and PE (= earthing), behind a small transparent door.



Position O on switch S13 will only be used in conjunction with an external earth fault protection unit (e.g. integrated in a distribution board) or when the generator is used in parallel.

The earth fault protection on the single phase outlet socket is not affected by the switch S13.

If S13 is in position O, proper earthing is of the utmost importance for the safety of the user. Eliminating any earth fault protection can lead to serious injury or even death for anybody touching the unit or the load.

2.8 Battery switch


The battery switch is situated inside the sound-insulated bodywork. It allows to open or to close the electrical connection between the battery and the engine circuits.



Never turn the battery switch to OFF during operation.

2.9 Earth leakage relay

The “Earth relay” option provides a detector that will trip the main circuit breaker Q1 when an earth fault current is detected.



N13....Earth leak detector

Detects and indicates an earth fault current and activates the main circuit breaker Q1. The detection level can be set at 0.03 A fixed with instantaneous trip but can also be adjusted between 0.1 A and 1 A with time delayed (0 - 0.5 sec) trip. N13 has to be reset manually after eliminating the problem (reset button marked R). It can be overridden by means of the earth leak switch (S13, labelled IAN) but has to be tested monthly (by pushing test button T).

S13....Lock-out switch for earth fault protection (N13)

This switch is located inside the cubicle and is labelled IAN.

Position O: No de-energising of the main circuit breaker Q1 when an earth fault occurs.

Position 1: De-energising of the main circuit breaker Q1 when an earth fault occurs.

Q1.....Main circuit breaker



Position O will only be used in conjunction with an external earth fault protection unit (e.g. integrated in a distribution board).

If S13 is in position O, proper earthing is of the utmost importance for the safety of the user. Eliminating any earth fault protection can lead to serious injury or even death for anybody touching the unit or the load.

3 Operating instructions



In your own interest, always strictly observe all relevant safety instructions.

Do not operate the generator in excess of the limitations mentioned in the Technical Specifications.

Local rules concerning the setting up of low voltage power installations (below 1,000 V) must be respected when connecting site distribution panels, switch gear or loads to the generator.

At each start-up and at any time a new load is connected, the earthing of the generator must be verified. Earthing must be done either by the earthing rod or, if available, by an existing, suitable earthing installation. The protective system against excessive contact voltage is not effective unless a suitable earthing is made.

The generator is wired for a TN-system to IEC 364-3, i.e. one point in the power source directly earthed - in this case the neutral. The exposed conductive parts of the electric installation must be directly connected to the functional earth.

If operating the generator in another power system, e.g. an IT-system, other protective devices required for these types must be installed. In any case only a qualified electrician is authorized to remove the connection between the neutral (N) and earth terminals in the terminal box of the alternator.

3.1 Installation

- Place the generator on a horizontal, even and solid floor.
- Protect the generator against dust and rain if it is operated outside.
- Check that the engine exhaust is not directed towards people. If the generator is operated indoors, install an exhaust pipe of sufficient diameter to duct the engine exhaust towards the outside. Check for sufficient ventilation so that the cooling air is not recirculated. If necessary, consult Atlas Copco.
- Leave enough space for operation, inspection and maintenance (at least 1 meter at each side).
- Check that the inner earthing system is in compliance with the local legislation.
- Use coolant for the engine cooling system. Refer to the Engine instruction book for the proper coolant mixture.
- Check the tightness of the bolts and nuts.
- Install the earthing rod as near as possible to the generator and measure its diffusion resistance (max. 1 kΩ) in order not to have a contact voltage higher than 25 V at 30 mA leakage current.
- Check that the cable end of the earthing rod is connected to the earth terminal.

3.2 Connecting the generator

3.2.1 Precautions for non-linear and sensitive loads



Non-linear loads draw currents with high contents in harmonics, causing distortion in the wave form of the voltage generated by the alternator.

The most common non-linear, 3-phase loads are thyristor/rectifier-controlled loads, such as converters supplying voltage to variable speed motors, uninterruptable power supplies and Telecom supplies. Gas-discharge lighting arranged in single-phase circuits generate high 3rd harmonics and risk for excessive neutral current.

Loads most sensitive to voltage distortion include incandescent lamps, discharge lamps, computers, X-ray equipment, audio amplifiers and elevators.

Consult Atlas Copco for measures against the adverse influence of non-linear loads.

3.2.2 Quality, minimum section and maximum length of cables

The cable connected to the terminal board of the generator must be selected in accordance with local legislation. The type of cable, its rated voltage and current carrying capacity are determined by installation conditions, stress and ambient temperature. For flexible wiring, rubber-sheathed, flexible core conductors of the type H07 RN-F (Cenelec HD.22) or better must be used.

The following table indicates the maximum allowable 3-phase currents (in A), in an ambient temperature of 40°C, for cable types (multiple and single core PVC insulated conductors and H07 RN-F multiple core conductors) and wire sections as listed, in accordance with VDE 0298 installation method C3. Local regulations remain applicable if they are stricter than those proposed below.

Wire section (mm ²)	2,5	4	6	10	16	25	35	50	70	95
Max. current (A)										
Multiple core	22	30	38	53	71	94	114	138	176	212
Single core	25	33	42	57	76	101	123	155	191	228
H07 RN-F	21	28	36	50	67	88	110	138	170	205

The lowest acceptable wire section and the corresponding maximum cable or conductor length for multiple core cable or H07 RN-F, at rated current (20 A), for a voltage drop e lower than 5 % and at a power factor of 0.80, are respectively 2.5 mm² and 144 m. In case electric motors must be started, oversizing the cable is advisable.

The voltage drop across a cable can be determined as follows:

$$e = \frac{\sqrt{3} \cdot I \cdot L \cdot (R \cdot \cos \varphi + X \cdot \sin \varphi)}{1000}$$

e = Voltage drop (V)

I = Rated current (A)

L = Length of conductors (m)

R = Resistance (Ω/km to VDE 0102)

X = Reactance (Ω/km to VDE 0102)

3.2.3 Connecting the load

Site distribution panel

If outlet sockets are required, they must be mounted on a site distribution panel supplied from the terminal board of the generator and in compliance with local regulations for power installations on building sites.

Protection



For safety reasons, it is necessary to provide an isolating switch or circuit breaker in each load circuit. Local legislation may impose the use of isolating devices which can be locked.

- Check whether frequency, voltage and current comply with the ratings of the generator.
- Provide for the load cable, without excessive length, and lay it out in a safe way without forming coils.
- Open the door of the control and indicator panel and the transparent door in front of the terminal board X1.
- Provide the wire ends with cable lugs suited for the cable terminals.
- Loosen the cable clamp and push the wire ends of the load cable through the orifice and clamp.
- Connect the wires to the proper terminals (L1, L2, L3, N and PE) of X1 and tighten the bolts securely.
- Tighten the cable clamp.
- Close the transparent door in front of X1.



3.3 Before starting

- With the generator standing level, check the engine oil level and top up if necessary. The oil level must be near to, but not exceed the high mark on the engine oil level dipstick.
- Check the coolant level in the expansion tank of the engine cooling system. The coolant level must be near to the FULL mark. Add coolant if necessary.
- Drain any coolant and sediment from the fuel pre-filter. Check the fuel level and top up if necessary. It is recommended to fill the tank after the day's operation to prevent coolant damp in a nearly empty tank from condensing.
- Check the vacuum indicator of the air filter. If the red part shows completely, replace the filter element.
- Press the vacuator valve of the air filter to remove dust.
- Check the generator for leakage, tightness of wire terminals, etc. Correct if necessary.
- Check that fuse F4 is not activated and that the emergency stop is in the "OUT" position.
- Check that the load is switched off.
- Check that circuit breaker Q1 is switched off.
- Check that the earth fault protection (N13) has not tripped (reset if necessary).


3.4 Operating Qc1001™

3.4.1 Starting Qc1001™

To start up the unit locally, proceed as follows:


- Switch on the battery switch.
- Switch off circuit breaker Q1. This is not necessary when a plant contactor is installed between Q1 and the load.
- Turn the switch S20 in position I (ON). This will activate the Qc1001™ Controller.
- Push the manual mode . The corresponding LED lights up.
- Push the starter button . The unit starts a preheating cycle which takes 12 seconds.
- After the preheating period, the unit will start. The starting attempt will take maximum 12 seconds.
- Switch on circuit breaker Q1 in case no contactor is installed.

To start up the unit from a remote location, proceed as follows:

- Turn the switch S20 in position I (ON). This will activate the Qc1001™ Controller.
- Push the remote mode . The corresponding LED lights up.
- Switch on circuit breaker Q1.
- Put the remote start/stop switch in position start. The unit starts a preheating cycle which takes 12 seconds.
- After the preheating period, the unit will start. The starting attempt will take maximum 12 seconds.

3.4.2 During operation Qc1001™

Following points should be carried out regularly:

- Check the engine gauges and the lamps for normal readings.
-  **Avoid to let the engine run out of fuel. If it happened, priming will speed up the starting.**
- Check for leakage of oil, fuel or coolant.
 - Avoid long low-load periods (< 30 %). In this case, an output drop and higher oil consumption of the engine could occur.
 - Check, by means of the generator gauges, that the voltage between the phases is identical and that the rated current in the third phase (L3) is not exceeded.
 - When single-phase loads are connected to the generator output terminals, keep all loads well-balanced.


If circuit breakers are activated during operation, switch off the load and stop the generator. Check and, if necessary, decrease the load.



The generator's doors may only remain opened for short periods during operation, to carry out checks for example.

3.4.3 Stopping Qc1001™

To stop the unit locally, proceed as follows:

- Switch off the load.
- Switch off circuit breaker Q1.
- Let the engine run for about 5 minutes.
- Push the stop button .
- Turn the switch S20 in position O (OFF).
- Lock the side doors and the door of the indicators and control panel to avoid unauthorized access.

To stop the unit remotely, proceed as follows:

- Switch off the load.
- Stop the engine by putting the remote start/stop switch in position stop or by putting the switch S20 in position O (OFF).
- Cooldown period default 15 sec.
- Lock the side doors and the door of the indicators and control panel to avoid unauthorized access.

3.5 Operating Qc4001™

3.5.1 Starting Qc4001™

- Turn the optional battery switch to ON.
- Turn the S20 button to the ON position, this will activate the Qc4001™ Controller.
- Select the correct application type and the correct mode on the Qc4001™ module (see “Overview of applications” on page 31 for the possible selections).
- Make the correct wirings and program the applicable parameters (see “Standard applications” on page 28 for more details).
- When in SEMI-AUTO mode, use the START button to start-up the generator. The GB button cannot be used to close the generator breaker.
- When in AUTO mode, the generator will start-up automatically and close the contactors depending on the selected application.



The START button, the GB-close button and the MB-close button cannot be used in AUTO mode.

3.5.2 During operation Qc4001™

Following points should be carried out regularly:

- Check the display for normal readings.



Avoid letting the engine run out of fuel. If this happens, priming will speed up the starting.

- Check for leakage of oil, fuel or cooling water.
- Avoid long low-load periods (< 30 %). In this case, an output power drop and higher oil consumption of the engine could occur. It is recommended to operate the generator at full load capacity immediately after any low load operating period.
- When single-phase loads are connected to the generator output terminals, keep all loads well-balanced.



Never turn the optional battery switch to OFF during operation.

If circuit breaker Q1 trips off during operation, switch off the load and stop the generator. Check and, if necessary, decrease the load.

3.5.3 Stopping Qc4001™

- When in SEMI-AUTO mode, use the STOP button to stop the generator. The GB button will work to open the GB.
- When in AUTO mode, the STOP and GB button will not function. The generator shuts down automatically depending on the selected application



If you want to stop the generator manually, use the S20 button or the emergency stop button.

4 Maintenance

4.1 Maintenance schedule



Before carrying out any maintenance activity, check that the start switch is in position O and that no electrical power is present on the terminals.

Maintenance schedule	Daily	500 hours or yearly	2000 hours
Service pak	-	2912 4414 05	-
<i>For the most important subassemblies, Atlas Copco has developed service kits that combine all wear parts. These service kits offer you the benefits of genuine parts, save on administration costs and are offered at reduced price, compared to the loose components. Refer to the parts list for more information on the contents of the service kits.</i>			
Air/fuel/coolant & oil leakage	Check	Check	Check
Electrolyte level and terminals of battery		Check	Check
Fixation of hoses, cables and pipes		Check	Check
Oil and coolant level	Check	Check	Check
Coolers	Check and clean externally	Check and clean externally	Check and clean externally
Condition of cooling fan assembly	Check	Check	Check
Tension and condition of the drive belt		Check	Check
Conditions of the engine drive belts (2)		Check	Check
Door hinges and locks		Grease	Grease
Engine oil (1)		Replace	Replace
Engine oil filters		Replace	Replace
Engine oil filter (bypass)		Replace	Replace
Engine fuel filter element		Replace	Replace
Engine fuel prefilter element		Replace	Replace
Fuel prefilter element		Replace	Replace
Water in fuel filter	Drain	Drain	Drain
Turbocharger impeller casing and turbocharger compressor casing			Clean
Air cleaner and dust bowl	Clean	Clean	Clean
Air filter element		Change	Change
Safety cartridge		Replace	Replace
Engine inlet and outlet valves (4)			Check/Adjust if necessary
Alternator and starter motor		Check	Check
Electrical system: security of cables and wear		Check	Check
Mechanical links		Grease	Grease
Condition of vibration dampers		Check	Check
Alternator insulation resistance		Measure	Measure
Glycol level in coolant (3)		Check	Check
PH level of engine coolant (3)		Check	Check
Inspection by Atlas Copco Service technician		Generators in standby application have to be tested on a regular basis. At least once a month the engine should run for one hour. If possible a high load (>30%) should be applied so that the engine reaches its operating temperature.	

Notes:

- (1) It is recommended also to replace the engine oil after the first 150 running hours.
- (2) Drive belts need to be replaced every 8000 running hours or 36 months:
Alternator belt: AC partnumber 2914 9848 00
Fan belt: AC partnumber 2914 9851 00
- (3) Renew PARcoolant every 5 years.
- (4) New rocker cover gasket needs to be ordered separately with AC partnumber 2914 9852 00.

4.2 Engine maintenance

Refer to the engine's operator manual for full maintenance schedule.

4.3 Measuring the alternator insulation resistance

A 500 V megger is required to measure the alternator insulation resistance.

If the N-terminal is connected to the earthing system, it must be disconnected from the earth terminal. Disconnect the AVR.

Connect the megger between the earth terminal PE and terminal L1 and generate a voltage of 500 V. The scale must indicate a resistance of at least 5 MΩ.

Refer to the alternator operating and maintenance instructions for more details.

4.4 Engine oil specifications



It is strongly recommended to use Atlas Copco branded lubrication oils.

High-quality, mineral, hydraulic or synthesized hydrocarbon oil with rust and oxidation inhibitors, anti-foam and anti-wear properties is recommended.

The viscosity grade should correspond to the ambient temperature and ISO 3448, as follows:

Engine	Type of lubricant
between -15°C and 40°C	PAROIL 15W40
between -25°C and 30°C	PAROIL 5W30



Never mix synthetic with mineral oil.

Remark:

When changing from mineral to synthetic oil (or the other way around), you will need to do an extra rinse.

After doing the complete change procedure to synthetic oil, run the unit for a few minutes to allow good and complete circulation of the synthetic oil. Then drain the synthetic oil again and fill again with new synthetic oil. To set correct oil levels, proceed as in normal instruction.

4.4.1 Specifications PAROIL

PAROIL from Atlas Copco is the ONLY oil tested and approved for use in all engines built into Atlas Copco compressors and generators.

Extensive laboratory and field endurance tests on Atlas Copco equipment have proven PAROIL to match all lubrication demands in varied conditions. It meets stringent quality control specifications to ensure your equipment will run smoothly and reliably.

The quality lubricant additives in PAROIL allow for extended oil change intervals without any loss in performance or longevity.

PAROIL provides wear protection under extreme conditions. Powerful oxidation resistance, high chemical stability and rust-inhibiting additives help reduce corrosion, even within engines left idle for extended periods.

PAROIL contains high quality anti-oxidants to control deposits, sludge and contaminants that tend to build up under very high temperatures.

PAROIL's detergent additives keep sludge forming particles in a fine suspension instead of allowing them to clog your filter and accumulate in the valve/rocker cover area.

PAROIL releases excess heat efficiently, whilst maintaining excellent bore-polish protection to limit oil consumption.

PAROIL has an excellent Total Base Number (TBN) retention and more alkalinity to control acid formation.

PAROIL prevents Soot build-up.

PAROIL is optimized for the latest low emission EURO -3 & -2, EPA TIER II & III engines running on low sulphur diesel for lower oil and fuel consumption.

4.4.2 PAROIL 5W30 and PAROIL 15W40

Synthetic engine oil PAROIL 5W30

PAROIL 5W30 is a Synthetic ultra high performance diesel engine oil with a high viscosity- index. Atlas Copco PAROIL 5W30 is designed to provide excellent lubrication from start-up in temperatures as low as -25°C.

	Liter	US gal	Imp gal	cu.ft	Order number
can	5	1.3	1.1	0.175	1604 6060 00
barrel	210	55.2	46	7.35	1604 6059 00

Mineral engine oil PAROIL 15W40

PAROIL 15W40 is a mineral based high performance diesel engine oil with a high viscosity- index. Atlas Copco PAROIL 15W40 is designed to provide a high level of performance and protection in 'standard' ambient conditions as from -15°C.

	Liter	US gal	Imp gal	cu.ft	Order number
can	5	1.3	1.1	0.175	1615 5953 00
can	20	5.3	4.4	0.7	1615 5954 00
barrel	210	55.2	46	7.35	1615 5955 00

4.5 Engine oil level check

Consult the Engine Operation Manual for the oil specifications, viscosity recommendations and oil change intervals.

For intervals, see section "Maintenance schedule" on page 37.

Check engine oil level according to the instructions in the Engine Operation Manual and if necessary top up with oil.

4.6 Engine oil and oil filter change

See section "Maintenance schedule" on page 37.

4.7 Engine coolant specifications



Never remove the cooling system filler cap while coolant is hot.

The system may be under pressure. Remove the cap slowly and only when coolant is at ambient temperature. A sudden release of pressure from a heated cooling system can result in personal injury from the splash of hot coolant.

It is strongly recommended to use Atlas Copco branded coolant.

The use of the correct coolant is important for good heat transfer and protection of liquid-cooled engines. Coolants used in these engines must be mixtures of good quality water (distilled or de-ionised), special coolant additives and if necessary freeze protection. Coolant that is not to manufacturer's specification will result in mechanical damage of the engine.

The freezing point of the coolant must be lower than the freezing point that can occur in the area. The difference must be at least 5°C. If the coolant freezes, it may crack the cylinder block, radiator or coolant pump.

Consult the engine's operation manual and follow the manufacturer's directions.



Never mix different coolants and mix the coolant components outside the cooling system.

4.7.1 Specifications PARCOOL EG

PARCOOL EG is the only coolant that has been tested and approved by all engine manufacturers currently in use in Atlas Copco compressors and generators.

Atlas Copco's PARCOOL EG extended life coolant is the new range of organic coolants purpose designed to meet the needs of modern engines. PARCOOL EG can help prevent leaks caused by corrosion. PARCOOL EG is also fully compatible with all sealants and gasket types developed to join different materials used within an engine.

PARCOOL EG is a ready to use Ethylene Glycol based coolant, premixed in an optimum 50/50 dilution ratio, for antifreeze protection guaranteed to -40°C.

Because PARCOOL EG inhibits corrosion, deposit formation is minimized. This effectively eliminates the problem of restricted flow through the engine coolant ducts and the radiator, minimizing the risk for engine overheating and possible failure.

It reduces water pump seal wear and has excellent stability when subjected to sustained high operating temperatures.

PARCOOL EG is free of nitride and amines to protect your health and the environment. Longer service life reduces the amount of coolant produced and needing disposal to minimise environmental impact.

	Liter	US gal	Imp gal	cu.ft	Order number
can	5	1.3	1.1	0.175	1604 5308 00
can	20	5.3	4.4	0.7	1604 5307 01
barrel	210	55.2	46	7.35	1604 5306 00

To ensure protection against corrosion, cavitation and formation of deposits, the concentration of the additives in the coolant must be kept between certain limits, as stated by the manufacturer's guidelines. Topping up the coolant with water only, changes the concentration and is therefore not allowed.

Liquid-cooled engines are factory-filled with this type of coolant mixture.

4.8 Coolant check

4.8.1 Monitoring coolant condition

In order to guarantee the lifetime and quality of the product, thus to optimise engine protection, regular coolant-condition-analysis is advisable.

The quality of the product can be determined by three parameters.

Visual check

- Verify the outlook of the coolant regarding colour and make sure that no loose particles are floating around.

pH measurement

- Check the pH value of the coolant using a pH-measuring device.
- The pH-meter can be ordered from Atlas Copco with part number 2913 0029 00.
- Typical value for EG = 8.6.
- If the pH-level is below 7 or above 9.5, the coolant should be replaced.

Glycol concentration measurement

- To optimise the unique engine protection features of the PARCOOL EG the concentration of the Glycol in the water should be always above 33 vol.%.
- Mixtures with more than 68 vol.% mix ratio in water are not recommended, as this will lead to high engine operating temperatures.
- A refractometer can be ordered from Atlas Copco with part number 2913 0028 00.



In case of a mix of different coolant products this type of measurement might provide incorrect values.

4.8.2 Topping up of coolant

- Verify if the engine cooling system is in a good condition (no leaks, clean,...).
- Check the condition of the coolant.
- If the condition of the coolant is outside the limits, the complete coolant should be replaced (see section “Replacing the coolant”).
- Always top-up with PARCOOL EG.
- Topping up the coolant with water only, changes the concentration of additives and is therefore not allowed.

4.8.3 Replacing the coolant

Drain

- Completely drain the entire cooling system.
- Used coolant must be disposed or recycled in accordance with laws and local regulations.

Flush

- Flush twice with clean water. Used coolant must be disposed or recycled in accordance with laws and local regulations.
- From the Atlas Copco Instruction book, determine the amount of PARCOOL EG required and pour into the radiator top tank.
- It should be clearly understood that the risk for contamination is reduced in case of proper cleaning.
- In case a certain content of ‘other’ coolant remains in the system, the coolant with the lowest properties influences the quality of the ‘mixed’ coolant.

Fill

- To assure proper operation and the release of trapped air, run the engine until normal engine operation temperature is reached. Turn off the engine and allow to cool.
- Recheck coolant level and add if necessary.

5 Storage of the generator

5.1 Storage

- Store the generator in a dry, frost-free room which is well ventilated.
- Run the engine regularly, e.g. once a week, until it is warmed up. If this is impossible, extra precautions must be taken:
 - Consult the engine's operator manual.
 - Remove the battery. Store it in a dry, frost-free room. Keep the battery clean and its terminals lightly covered with petroleum jelly. Recharge the battery regularly.
 - Clean the generator and protect all electrical components against moisture.
 - Place silicagel bags, VCI paper (Volatile Corrosion Inhibitor) or another drying agent inside the generator and close the doors.
 - Stick sheets of VCI paper with adhesive tape on the bodywork to close off all openings.
 - Wrap the generator, except the bottom, in a plastic bag.

5.2 Preparing for operation after storage

Before operating the generator again, remove the wrapping, VCI paper and silicagel bags and check the generator thoroughly (go through the checklist "Before starting" on page 35).

- Consult the engine's operator manual.
- Check that the insulation resistance of the generator exceeds 5 MΩ.
- Replace the fuel filter and fill the fuel tank. Vent the fuel system.
- Reinstall and connect the battery, if necessary after being recharged.
- Submit the generator to a test run.

6 Checks and troubleshooting



Never perform a test run with connected power cables. Never touch an electrical connector without a voltage check.

When a failure occurs, always report what you experienced before, during and after the failure. Information with regard to the load (type, size, power factor, etc.), vibrations, exhaust gas colour, insulation check, odours, output voltage, leaks and damaged parts, ambient temperature, daily and normal maintenance and altitude might be helpful to quickly locate the problem. Also report any information regarding the humidity and location of the generator (e.g. close to sea).

6.1 Checking voltmeter P4

- Put a voltmeter in parallel with voltmeter P4 on the control panel.
- Check that the read-out of both voltmeters is the same.
- Stop the generator and disconnect one terminal.
- Check that the internal resistance of the voltmeter is high.

6.2 Checking ammeters P1, P2 and P3

- Measure by means of a clamp-on probe the current, during the load.
- Compare the measured current with the current indicated on the ammeter. Both readings should be the same.

6.3 Alternator troubleshooting

Symptom	Possible cause	Corrective action
<i>Alternator does not excite</i>	Blown fuse.	Replace fuse.
	Insufficient residual voltage.	Increase the speed by 15%.
	No residual voltage.	For an instant apply on the + and – terminals of the electronic regulator a 12 V battery voltage with a 30 Ω resistor in series respecting the polarities.
<i>After being excited alternator does not excite</i>	Connections are interrupted.	Check connection cables as per attached drawings.
<i>Low voltage at no load</i>	Voltage potentiometer out of setting.	Reset voltage.
	Intervention of protection.	Check frequency/voltage regulator.
	Winding failure.	Check windings.
<i>High voltage at no load</i>	Voltage potentiometer out of setting.	Reset voltage.
	Failed regulator.	Substitute regulator.
<i>Lower than rated voltage at load</i>	Voltage potentiometer out of setting.	Reset voltage potentiometer.
	Intervention by protection.	Current too high, power factor lower than 0.8; speed lower than 10% of rated speed.
	Failed regulator.	Substitute regulator.
	Rotating bridge failure.	Check diodes, disconnect cables.
<i>Higher than rated voltage at load</i>	Voltage potentiometer out of setting.	Reset voltage potentiometer.
	Failed regulator.	Substitute regulator.
<i>Unstable voltage</i>	Speed variation in engine.	Check regularity of rotation.
	Regulator out of setting.	Regulate stability of regulator by acting on “STABILITY” potentiometer.

6.4 Engine troubleshooting

Refer to the engine's operator manual for the engine troubleshooting. An extensive Engine troubleshooting manual is available at Volvo Penta. For more information contact Volvo Penta.

7 Options available for QAS 325 Volvo units

7.1 Circuit diagrams

The engine control circuit diagrams and the power circuit diagrams for the standard QAS 325 Volvo units, for the units with options and for the units with combined options are:

<i>Unit</i>	<i>Power circuit</i>	<i>Engine control circuit</i>
QAS 325 Qc1001™	9822 0889 54	9822 0889 79
QAS 325 Qc4001™	9822 0889 54	9822 0889 73
QAS 325 Low voltage	9822 0889 62	
QAS 325 Dual voltage	9822 0889 77	
QAS 325 N-EDF	9822 0889 55	
QAS 325 OUR	9822 0889 63	

7.2 Overview of the electrical options

The following “electrical” options are available:

- Automatic battery charger
- Engine coolant heater
- Outlet sockets (S)
- Low voltage (LV)
- Dual voltage (DV)
- “Electricité de France” (EDF)
- Over and under voltage relay (O.U.R)


7.3 Description of the electrical options

7.3.1 Automatic battery charger

The automatic battery charger charges the battery completely and is disconnected once the unit starts up.

Besides the output terminals (secondary side) the automatic battery charger has a trim potentiometer for setting of the output voltage. By means of an insulated slotted screwdriver or adjusting pin the output voltage can be set in the range.

The LED on the front indicates that the unit is operational.



Setting:

- Lower output voltage = counterclockwise rotation
- Higher output voltage = clockwise rotation

To use the battery charger:

- Provide the X25 connector, located at the side of the output terminal board, with external power to use the automatic battery charger.

7.3.2 Engine coolant heater

To make sure that the engine can start and accept load immediately, an external cooling water heater (2000 W, 240 V) is provided which keeps the engine temperature between 38°C and 49°C.

7.3.3 Outlet sockets (S)

The "Outlet sockets" option provides the following extra outlet sockets and circuit breakers:

Q1 Circuit breaker for X1

Interrupts the power supply X1 when a short-circuit occurs at the load side, or when the overcurrent protection is activated. When activated, Q1 interrupts the three phases towards X1. It must be reset manually after eliminating the problem.

Q2 Circuit breaker for X2

Interrupts the power supply to X2 when a short-circuit occurs at the load side, or when the overcurrent protection (16 A) is activated. When activated, Q2 interrupts the three phases towards X2. It can be activated again after eliminating the problem.

X1..... Main power supply (400 V AC)


Terminals L1, L2, L3, N (= neutral) and PE (= earthing), hidden behind the control panel door and behind a small transparent door.

X2..... Socket 16 A Rim earthing

Provides lines L3, N (= neutral) and PE (= grounding).

Socket 16 A Pin earthing

Provides lines L3, N (= neutral) and PE (= grounding).



When the sockets-option is installed, circuit breaker Q1 does not only interrupt the power supply towards X1 but also towards X2.


Make sure to switch on circuit breakers Q1 and Q2 after starting the generator when power supply is done by means of X2.

7.3.4 Low voltage (LV)

The "Low voltage" option allows to run the unit at low voltage (= high current).



All the cables that are used must be suitable for high current.



Q1 Circuit breaker for low voltage, high current

Interrupts the low voltage power supply towards X1 when a short-circuit occurs at the load side or when the overcurrent protection (QAS 325: 800 A) is activated. It must be reset manually after eliminating the problem.

X1..... Main power supply (400 V AC)

Terminals L1, L2, L3, N (= neutral) and PE (= earthing), hidden behind the control panel door and behind a small transparent door.

7.3.5 Dual voltage (DV)


The generator can run in two different modes:

3 phase, lower voltage

When using this selection, the generator provides a 230/240 V output voltage.

3 phase, higher voltage

When using this selection, the generator provides a 400/480 V output voltage.



Q1.1... Circuit breaker for low voltage, high current

Interrupts the low voltage power supply towards X1 when a short-circuit occurs at the load side or when the overcurrent protection (QAS 325: 800 A) is activated. It must be reset manually after eliminating the problem.

Q1.2... Circuit breaker for high voltage, low current

Interrupts the high voltage power supply towards X1 when a short-circuit occurs at the load side or when the overcurrent protection (QAS 325: 470 A) is activated. It must be reset manually after eliminating the problem.

R11.... Output voltage adjust potentiometer

Allows to adjust the output voltage.

Depending on which mode the generator is running in, circuit breaker Q1.1 or Q1.2 will be operational.

Circuit breakers Q1.1 and Q1.2 cannot be switched on at the same time. This is prevented by means of the auxiliary voltage selection relays S10b and S10c (refer to the circuit diagram).

The selection between the two modes is done by means of S10.

S10.... Output voltage selection switch

Allows to select a 3 phase high output voltage or a 3 phase low output voltage. Selector switch S10 is located on the alternator.




Changing the output voltage is only allowed after shutdown.


After changing the output voltage by means of the selection switch S10, adjust the output voltage by means of potentiometer R11 to the required value.

7.3.6 "Electricité de France" (EDF)

When the EDF-option is installed, the unit operates as a standard unit when the neutral and the PE terminals are connected to each other (see figure below). In this case, an earth leakage at the side of the generator or at the side of the load will switch off the circuit breaker.



When EDF-option is installed, the unit operates as EDF-unit when the earthing, the PE and the PE EDF terminals are connected to each other (see figure below). In this case, an earth leakage at the side of the generator will switch off the circuit breaker. An earth leakage at the side of the load will not switch off the circuit breaker.



Changing the operation mode from standard unit to EDF-unit or vice versa has to be carried out by a qualified person from "Electricité de France".

7.3.7 Over and under voltage relay (O.U.R)

The settings of this relay can be adjusted by the customer via the dedicated potentiometers. Factory settings are +8%/-8%/5 seconds. Outside these limits the generator will shut down (voltage LED of the module will light up).

7.4 Overview of the mechanical options

The following “mechanical” options are available:


- External fuel tank connection
- Spillage free skid

7.5 Description of the mechanical options

7.5.1 External fuel tank connection

The external fuel tank connection allows to bypass the internal fuel tank and to connect an external fuel tank to the unit.


When using this option, make sure to connect the fuel supply line as well as the fuel return line. Always put both valves in the same position (either internal or external tank) and make sure that they are in the extreme (horizontal) position. Connections to fuellines ought to be air-tight to prevent air from entering the fuel system.



Position 1: Indicates that the fuel supply line to the engine is connected to the internal fuel tank.



Position closed: Indicates that the fuel supply line to the engine is closed.



Position 2: Indicates that the fuel supply line to the engine is connected to the external fuel tank.

7.5.2 Spillage free skid

A spillage free skid with forklift slots allows the customer to transport the generator easily with a forklift.

It avoids accidental spilling of engine fluids.

8 Technical specifications for QAS 325 Volvo

8.1 Readings on gauges

<i>Gauge</i>	<i>Reading</i>	<i>Unit</i>
Ammeter L1-3 (P1-3)	Below max. rating	A
Voltmeter (P4)	Depends upon selector switch	V

8.2 Settings of switches

<i>Switch</i>	<i>Function</i>	<i>Activates at</i>
Engine oil pressure	Shut down	0.5 bar
Engine coolant temperature	Shut down	103°C

8.3 Specifications of the engine/alternator/unit

		50 Hz	60 Hz
<i>Reference values 1) 4)</i>	Rated frequency	50 Hz	60 Hz
	Rated speed	1500 rpm	1800 rpm
	Generator service duty	PRP	PRP
	Absolute air inlet pressure	100 kPa	100 kPa
	Relative air humidity	30 %	30 %
	Air inlet temperature	25°C	25°C
<i>Limitations 2)</i>	Maximum ambient temperature	40°C	40°C
	Altitude capability	1000 m	1000 m
	Relative air humidity maximum	< 85 %	< 85 %
	Minimum starting temperature unaided	0°C	0°C
	Minimum starting temperature with heater	-25°C	-25°C
<i>Performance data 2) 3) 4) 5)</i>	Rated active power (PRP) 3 phase	260 kW	276 kW
	Rated power factor (lagging) 3 phase	0.8	0.8
	Rated apparent power (PRP) 3 phase	325 kVA	345 kVA
	Rated apparent power (PRP) 3 phase, lower voltage	319 kVA	333 kVA
	Rated voltage 3 phase line to line voltage	400 V	480 V
	Rated voltage 3 phase line to line, lower voltage	230 V	240 V
	Rated current 3 phase	469 A	415 A
	Rated current 3 phase, lower voltage	800 A	800 A
	Performance class (acc. to ISO 8528-5:1993)	G2	G2
	Single step load acceptance (0-PRP)	63 %	89 %
	Frequency droop	< 5	< 5
	Single step load acceptance (0-PRP)	isochronous	isochronous
	Fuel consumption at full load/no load	56.8/6.3 kg/h	64.7/9.9 kg/h
	Specific fuel consumption	0.219 kg/kWh	0.232 kg/kWh
	Fuel autonomy at full load	7.2 h	6.3 h
	Max. oil consumption at full load	34 g/h	34 g/h
	Max. sound power level (LWA @ 75 % PRP load) measured according to REF 2000/14/EC OND	98 dB(A)	102 dB(A)
	Capacity of fuel tank	477 l	477 l
	Single step load capability (0-PRP)	100 %	100 %
<i>Application data</i>	Mode of operation	PRP	PRP
	Site	land use	land use
	Operation	single/parallel	single/parallel
	Start-up and control mode	manual/automatic	manual/automatic
	Start-up time	unspecified	unspecified
	Mobility/Config. acc. to ISO 8528-1:1993	transportable/D	transportable/D
	Mounting	fully resilient	fully resilient
	Climatic exposure	open air	open air
	Degree of protection (cubicle)	IP54	IP54
	Status of neutral	earthed	earthed

<i>Alternator</i>	Standard	IEC 34-1 ISO 8528-3	IEC 34-1 ISO 8528-3
	Make	MECC-ALTE	MECC-ALTE
	Model	ECO 38 3L/N	ECO 38 3L/N
	Rated output, class H temp. rise	350 kVA	420 kVA
	Rating type acc. ISO 8528-3	“BR” 125/40°C	“BR” 125/40°C
	Degree of protection	IP21	IP21
	Insulation class stator	H	H
	Insulation class rotor	H	H
<i>Engine</i>	Number of wires	12	12
	Standard	ISO 3046	ISO 3046
	Type VOLVO	ISO 8528-2	ISO 8528-2
	Rated net output	TAD941GE	TAD941GE
	Rating type acc. ISO 3046-7	280 kW	296 kW
	Production tolerance	ICXN	ICXN
	Coolant	0 to +2%	0 to +2%
	Combustion system	water	water
	Aspiration	direct injection	direct injection
		turbocharged	turbocharged
		intercooled	intercooled
	Number of cylinders	6	6
	Swept volume	9.36 l	9.36 l
	Speed governing	electronic	electronic
		EMS 2	EMS 2
<i>Power circuit</i>	Capacity of oil sump	30 l	30 l
	Capacity of cooling system	41 l	41 l
	Electrical system	24 Vdc	24 Vdc
	Circuit-breaker, 3 phase		
	Number of poles	4	4
	Thermal release It	470 A	470 A
	Magnetic release Im	3..10xIn	3..10xIn
	Circuit-breaker, 3 phase, lower voltage		
	Number of poles (optional)	4	4
	Thermal release It	800 A	800 A
	Magnetic release Im	3..10xIn	3..10xIn
	Fault current protection		
	Residual current release IDn	0.025-25 A	0.025-25 A
	Outlet sockets (optional)		
		domestic (1x)	
<i>Unit</i>		2p + E	
		16 A/230 V	
	Dimensions (L x W x H)	3955 x 1430 x 2130 mm	3955 x 1430 x 2130 mm
	Weight net mass	3984 kg	3984 kg
	Weight wet mass	4384 kg	4384 kg

Notes

- 1) Reference conditions for engine performance to ISO 3046-1.
 - 2) See derating diagram or consult the factory for other conditions.
 - 3) At reference conditions unless otherwise stated.
- Rating definition (ISO 8528-1):
- LTP: Limited Time Power is the maximum electrical power which a generating set is capable of delivering (at variable load), in the event of a utility power failure (for up to 500 hours per year of which a maximum of 300 hours is continuous running). No overload is permitted on these ratings. The alternator is peak continuous rated (as defined in ISO 8528-3) at 25°C.
 - PRP: Prime Power is the maximum power available during a variable power sequence, which may be run for an unlimited number of hours per year, between stated maintenance intervals and under the stated ambient conditions. A 10% overload is permitted for 1 hour in 12 hours. The permissible average power output during a 24h period shall not exceed the stated load factor of 80%.
- 5) Specific mass fuel used: 0.86 kg/l.

Derating table (in %, 100% is declared power at "Performance data")

Height (m)	Temperature (°C)									
	0	5	10	15	20	25	30	35	40	45
0	100	100	100	100	100	100	100	100	100	98
500	100	100	100	100	100	100	100	100	100	98
1000	100	100	100	100	100	100	100	100	100	98
1500	94	94	94	94	94	94	94	94	94	92
2000	88	88	88	88	88	88	88	88	88	86
2500	81	81	81	81	81	81	81	81	81	80
3000	75	75	75	75	75	75	75	75	75	74
3500	69	69	69	69	69	69	69	69	69	67
4000	63	63	63	63	63	63	63	63	63	61

For use of generator outside these conditions, please contact Atlas Copco.

8.4 Conversion list of SI units into British units

1 bar	=	14.504 psi	1 m	=	3.281 ft
1 g	=	0.035 oz	1 mm	=	0.039 in
1 kg	=	2.205 lb	1 m³/min	=	35.315 cfm
1 km/h	=	0.621 mile/h	1 mbar	=	0.401 in wc
1 kW	=	1.341 hp (UK and US)	1 N	=	0.225 lbf
1 l	=	0.264 US gal	1 Nm	=	0.738 lbf.ft
1 l	=	0.220 imp gal (UK)	t°F	=	32 + (1.8 x t°C)
1 l	=	0.035 cu.ft	t°C	=	(t°F - 32)/1.8

A temperature difference of 1°C = a temperature difference of 1.8°F.

8.5 Dataplate

The diagram shows a rectangular dataplate with the following fields and components:

- 1: Company code (YA3)
- 2: Product code (*****)
- 3: Unit serial number (*****)
- 4: Name of the manufacturer (ATLAS COPCO AIRPOWER n.v.)
- 5: EEC or national type approval number (***k***)
- 6: Vehicle identification number (-YA3-*****-*****-)
- 7: Model number (Model/Modell/Modèle *****)
- 8: Frequency (f_N LTP * Hz **)
- 9: Apparent power - PRP (P_N LTP * kVA ***)
- 10: Active power - PRP (P_N * kW ***)
- 11: Nominal rated voltage (U_N * V ***)
- 12: Nominal rated current (I_N * A ***)
- 13: Power factor (cos phi **)
- 14: Manufacturing year (Manuf. year/Baujahr/Année de fabrication ****)
- 15: EEC mark in accordance with Machine Directive 89/392E (CE)
- 16: Mode of operation (15 6945 00)
- 17: Winding connections (Atlas Copco logo)

A Maximum permitted loaded weight of the vehicle

B Maximum permitted road weight of the front axle

C Maximum permitted road weight of the rear axle

1 Company code

2 Product code

3 Unit serial number

4 Name of the manufacturer

5 EEC or national type approval number

6 Vehicle identification number

7 Model number

8 Frequency

9 Apparent power - PRP

10 Active power - PRP

11 Nominal rated voltage

12 Nominal rated current

13 Power factor


14 Manufacturing year

15 EEC mark in accordance with Machine Directive 89/392E

16 Mode of operation

17 Winding connections

Circuit diagrams



CIRCUIT DIAGRAM

9822 0889 54/01

Applicable for QAS 325 Volvo - Power circuit diagram - 400 V


Failure EMS 2 Alarm Red -

When unit shuts down this message is displayed -

This failure is a code coming from the engine controller. This cannot be decoded by our controller yet. There are tests going on to have the software updated so our controller will read these codes.

Check the coolant level first before calling Volvo


CALL REQUEST S81467 - 7/11/08 LAST UPDATED BY GUY ON 11/17/08



CIRCUIT DIAGRAM

	Q1	T1-3	P1-3	Wire size
QAS325	470A	600/5A	0-600A	$\frac{X}{2x lx}$ $\frac{Z}{I}$


Breaker Set.	Q1	Io	I1	I2=I3	T1	T2	I ² t
QAS325	470A	0.80xIn	0.95xIo	4	10	0.1	OFF



Legend

Wire size

Wire size	Colour code
aa = 0.5 mm ²	0 = black
a = 1 mm ²	1 = brown
b = 1.5 mm ²	2 = red
c = 2.5 mm ²	3 = orange
d = 4 mm ²	4 = yellow
e = 6 mm ²	5 = green
f = 10 mm ²	6 = blue
g = 16 mm ²	7 = purple
h = 25 mm ²	8 = grey
i = 35 mm ²	9 = white
j = 50 mm ²	54 = green/yellow
k = 70 mm ²	
l = 95 mm ²	
lx = 95 mm ² EPR-CSP to BS6195 4C	
bx = 1.5 mm ² NSGAFOeU	




F1-F3	Fuse 4 A	R5	Coolant heater	T1-T3	Current transformer
G3	Alternator	R11	Voltage adjustment potentiometer	T13	Toroid transformer for earth relay
Kx	Contactor generator ready (by voltage free contact, 15 sec. delayed)	S2b	Emergency stop (S2a see Engine circuit)	U1	Static battery conditioner
N12	Automatic voltage regulator	S11 a,b	Selector switch 50/60 Hz (S11c see Engine circuit)	X1	Terminal board
N13	Earth fault current relay	S13	Earth relay lock-out switch	X2	Outlet socket
Q1	Main circuit breaker	Sx	Remote Start/Stop	X10	15-pole connector
Q2	Circuit breaker			X25	Terminal strip
				(O)	Optional equipment

CIRCUIT DIAGRAM

9822 0889 55/01


Applicable for QAS 325 Volvo - Power circuit diagram - Electricité de France



CIRCUIT DIAGRAM

	Q1	T1-3	P1-3	Wire size
				<u>X</u> <u>Z</u>
QAS325	470A	600/5A	0-600A	2x lx l

Breaker Set.	Q1	lo	l1	l2=l3	T1	T2	l ² t
QAS325	470A	0.80xln	0.95xlo	4	10	0.1	OFF



Legend

Wire size	Colour code
aa = 0.5 mm ²	0 = black
a = 1 mm ²	1 = brown
b = 1.5 mm ²	2 = red
c = 2.5 mm ²	3 = orange
d = 4 mm ²	4 = yellow
e = 6 mm ²	5 = green
f = 10 mm ²	6 = blue
g = 16 mm ²	7 = purple
h = 25 mm ²	8 = grey
i = 35 mm ²	9 = white
j = 50 mm ²	54 = green/yellow
k = 70 mm ²	
l = 95 mm ²	
lx = 95 mm ² EPR-CSP to BS6195 4C	
bx = 1.5 mm ² NSGAFOeU	

F1-F3	Fuse 4 A	R5	Coolant heater	T1-T3	Current transformer
G3	Alternator	R11	Voltage adjustment potentiometer	T13	Toroid transformer for earth relay
Kx	Contact generator ready (by voltage free contact, 15 sec. delayed)	S2b	Emergency stop (S2a see Engine circuit)	U1	Static battery conditioner
N12	Automatic voltage regulator	S11 a,b	Selector switch 50/60 Hz (S11 c see Engine circuit)	X1	Terminal board
N13	Earth fault current relay	S13	Earth relay lock-out switch	X2	Outlet socket
Q1	Main circuit breaker	Sx	Remote Start/Stop	X10	15-pole connector
Q2	Circuit breaker			X25	Terminal strip
				(O)	Optional equipment

CIRCUIT DIAGRAM

9822 0889 62/01


Applicable for QAS 325 Volvo - Power circuit diagram - Low voltage

	Q1	T1-3	P1-3	Wire size
QAS325 LV	800A	1000/5A	0-1000A	$\frac{X}{2x \text{ px}}$


Breaker Set.	Q1	I _o	I ₁	I _{2=I3}	T1	T2	I _{2t}
QAS325 LV	800A	1,00xI _n	1.00xI _o	4	10	0,1	OFF

Legend

Wire size	Colour code
aa = 0.5 mm ²	0 = black
a = 1 mm ²	1 = brown
b = 1.5 mm ²	2 = red
c = 2.5 mm ²	3 = orange
d = 4 mm ²	4 = yellow
e = 6 mm ²	5 = green
f = 10 mm ²	6 = blue
g = 16 mm ²	7 = purple
h = 25 mm ²	8 = grey
i = 35 mm ²	9 = white
j = 50 mm ²	54 = green/yellow
k = 70 mm ²	
l = 95 mm ²	
bx = 1.5 mm ² NSGAFOeU	
lx = 95 mm ² EPR-CSP to BS6195 4C	
px = 185 mm ² EPR-CSP to BS6195 4C	



CIRCUIT DIAGRAM



F1-F3	Fuse 4 A	Q2	Circuit breaker	T13	Toroid transformer for earth relay
G3	Alternator	R5	Coolant heater	U1	Static battery conditioner
Kx	Contactor generator ready (by voltage free contact, 15 sec. delayed)	S2b	Emergency stop (S2a see Engine circuit)	X1	Terminal board
N12	Automatic voltage regulator	S13	Earth relay lock-out switch	X2	Outlet socket
N13	Earth fault current relay	Sx	Remote Start/Stop	X10	15-pole connector
Q1	Main circuit breaker	T1-T3	Current transformer	X25	Terminal strip
				(O)	Optional equipment


CIRCUIT DIAGRAM

9822 0889 63/01

Applicable for QAS 325 Volvo - Over and under voltage relay



CIRCUIT DIAGRAM



A1	Control module	Kv1	(K11 see Circuit diagram - Dual voltage) Under/overvoltage relay (low voltage) Umax = +8%, Umin = -8%, t1 = 5s To be sealed after adjustment!	Kv2	Under/overvoltage relay (high voltage) Umax = +8%, Umin = -8%, t1 = 5s To be sealed after adjustment!
K11	Auxiliary relay u/o voltage low voltage (K11 see Circuit diagram - Dual voltage)			Kt	Timer (delay = 10 sec)
K12	Auxiliary relay u/o voltage high voltage				

CIRCUIT DIAGRAM

9822 0889 73a/00

Applicable for QAS 325 Volvo - Qc4001™ + PMS

Legend



Wire size

aa = 0.5 mm²
a = 1 mm²
b = 1.5 mm²
c = 2.5 mm²
d = 4 mm²
e = 6 mm²
f = 10 mm²
g = 16 mm²
h = 25 mm²
i = 35 mm²
j = 50 mm²
k = 70 mm²
l = 95 mm²
lx = 95 mm² EPR-CSP to BS6195 4C
bx = 1.5 mm² NSGAFOeU

Colour code

0 = black
1 = brown
2 = red
3 = orange
4 = yellow
5 = green
6 = blue
7 = purple
8 = grey
9 = white
54 = green/yellow

Position of Relay Contacts




	Q1	T1-3	P1-3	Wire size
				X Z
QAS325	470A	600/5A	0-600A	2x lx l

Breaker Set.	Q1	Io	I1	I2=I3	T1	T2	I ² t
QAS325	470A	0.80xln	0.95xlo	4	10	0.1	OFF

A1	Generator control unit	K11	Auxiliary relay open mains CB	Q2	Circuit breaker 16 A (with U<)
A2	LCD display	K12	Auxiliary relay close mains CB	R5	Engine coolant heater
B7	Fuel level sensor	K21	Auxiliary relay open generator CB	R7	Resistor 220 Ohm
F1-F6	Fuses 250 mA	K22	Auxiliary relay close generator CB	R9,R10	Resistor 120 Ohm
F10	Fuse 10 A	M1	Starter motor	S1	Battery isolator
G1	Battery 24 Vdc	M3	Motor drive for Q1	S2a	Emergency stop
G3	Alternator	N12	Automatic voltage regulator	S7	Fuel level switch
H1	Panel light	N13	Earth leakage relay	S11a-d	50/60 Hz switch
K6	Fuel solenoid relay	Q1	Generator circuit breaker (3P+N)	S13	E.L.R. disable switch

CIRCUIT DIAGRAM




S20	ON/OFF-switch	Sx	(mounted inside Q1)	X2	Outlet socket
Sa	Auxiliary contact mains CB opened (mounted in MCB)	T1-T3	Remote start/stop switch	X10	Connector engine wire harness
Sb	Auxiliary contact mains CB closed (mounted in MCB)	T13	Current transformer	X25	Customer's terminal strip
SQ1	Auxiliary contact generator CB	U1	Torus earth leakage relay	X30-31	Connector load sharing
		X1	Battery charger	X32	PMS interface terminals
			Terminal board	(O)	Optional equipment

CIRCUIT DIAGRAM

9822 0889 73b/00

Applicable for QAS 325 Volvo - Qc4001™ + PMS - Air shut-off valve


OPTION AIR SHUT-OFF VALVE



CIRCUIT DIAGRAM

Legend

Wire size	Colour code
aa = 0.5 mm ²	0 = black
a = 1 mm ²	1 = brown
b = 1.5 mm ²	2 = red
c = 2.5 mm ²	3 = orange
d = 4 mm ²	4 = yellow
e = 6 mm ²	5 = green
f = 10 mm ²	6 = blue
g = 16 mm ²	7 = purple
h = 25 mm ²	8 = grey
i = 35 mm ²	9 = white
j = 50 mm ²	54 = green/yellow
k = 70 mm ²	
l = 95 mm ²	
bx = 1.5 mm ²	NSGAFOeU



Position of Relay Contacts

K12	KSV	KSV2
b9	b8	Sheet 1

G2	Charging alternator	KSV2	Auxiliary relay shut-off valve	S12	ON/OFF switch shut-off valve
K12	Timer relay shut-off valve	N12	Speed switch	YSV	Air shut-off valve
KSV	Auxiliary relay shut-off valve	S2b	Emergency stop		

CIRCUIT DIAGRAM

9822 0889 77/01

Applicable for QAS 325 Volvo - Power circuit diagram - Dual voltage

	Q1.1	Q1.2	T1-3	P1-3	Wire size		
					X	Y	Z
QAS325 2V	800A	470A	1000/5A	0-1000A	2x px	2x l	px


Breaker Set.	Q1	lo	l1	l2=l3	T1	T2	I_t
QAS325 Q1.1	800A	1,00xln	1.00xlo	4	10	0,1	OFF
QAS325 Q1.2	470A	0.80xln	0.95xlo				

NOTE 1


3ph higher voltage : connect 2-3 ; 6-7 ; 10-11 ; 4-8-12(N)
 3ph lower voltage : connect 12-1 ; 2-3 ; 4-5 ; 6-7 ; 8-9 ; 10-11

Legend

Wire size	Colour code
aa = 0.5 mm ²	0 = black
a = 1 mm ²	1 = brown
b = 1.5 mm ²	2 = red
c = 2.5 mm ²	3 = orange
d = 4 mm ²	4 = yellow
e = 6 mm ²	5 = green
f = 10 mm ²	6 = blue
g = 16 mm ²	7 = purple
h = 25 mm ²	8 = grey
i = 35 mm ²	9 = white
j = 50 mm ²	54 = green/yellow
k = 70 mm ²	
l = 95 mm ²	
bx = 1.5 mm ² NSGAFOeU	
px = 185 mm ² EPR-CSP to BS6195 4C	
lx = 95 mm ² EPR-CSP to BS6195 4C	



CIRCUIT DIAGRAM




F1-F3	Fuse 4 A	R5	Coolant heater	T13	Earth fault current detector
G3	Alternator	R11	Supply voltage adjust	U1	Static battery conditioner
Kx	Contactor generator ready (by voltage free contact, 15 sec. delayed)	S2b	Emergency stop (S2a see Engine Circuit)	X1	Terminal board
N12	Automatic voltage regulator	S10a,b,c	Supply voltage switch	X10	15-pole connector
N13	Earth fault current relay	S13	Earth relay lock-out switch	X25	Terminal strip
Q1.1	Circuit breaker (lower voltage)	Sx	Remote start/stop	(O)	Optional equipment
Q1.2	Circuit breaker (higher voltage)	T1-T3	Current transformer		

CIRCUIT DIAGRAM


9822 0889 79/01

Applicable for QAS 325 Volvo - Qc1001™

(*) Connect wire 15 direct to contact 34 of A1 or in case of option air shut-off valve connect to KSV2



CIRCUIT DIAGRAM



A1	Control module	N12	Speed switch	S11	(only used on 400 VY single voltage)
F4	Fuse	P1-P3	Amperemeter	S11c	Selector switch 50/60 Hz
G1	Battery 24 Vdc	P4	Voltmeter		(S11a,b see Power Circuit)
G2	Charging alternator	S1	Battery switch	S12	ON/OFF switch shut-off valve
H1	Panel light	S2a,c	Emergency stop	X10	15-pole connector
K12	Timer relay shut-off valve		(S2b see Power Circuit)	X17	Fuel level unit connector
KSV	Auxiliary relay shut-off valve	S4	Voltmeter change-over switch	X25	Fuel level unit connector
KSV2	Auxiliary relay shut-off valve	S7	Low fuel level switch	YSV	Air shut-off valve
M1	Starter motor	S7'	Low fuel level switch, warning	(O)	Optional equipment

**Instruction Manual
for AC Generators
QAS 325 Volvo**

