

# INSTRUCTION MANUAL

## FOR

### DGC-2020ES

## DIGITAL GENSET CONTROLLER



 **Basler Electric**

Publication: 9469200990  
Revision: B Feb-14



# Preface

This instruction manual provides information about the installation and operation of the DGC-2020ES Digital Genset Controller. To accomplish this, the following information is provided:

- Controls and indicators
- Inputs and outputs
- Protection and control functions
- Reporting and alarms information
- Mounting and connection diagrams
- BESTCOMS*Plus*<sup>®</sup> software
- Communication and security
- Maintenance and troubleshooting procedures
- Specifications
- CEM-2020
- MTU Fault Codes
- Exhaust Treatment
- Diagnostic Trouble Codes

## ***Conventions Used in this Manual***

---

Important safety and procedural information is emphasized and presented in this manual through Warning, Caution, and Note boxes. Each type is illustrated and defined as follows.

### **Warning!**

Warning boxes call attention to conditions or actions that may cause personal injury or death.

### **Caution**

Caution boxes call attention to operating conditions that may lead to equipment or property damage.

### **Note**

Note boxes emphasize important information pertaining to Digital Genset Controller installation or operation.



12570 State Route 143  
Highland IL 62249-1074 USA

[www.basler.com](http://www.basler.com)

[info@basler.com](mailto:info@basler.com)

Tel: +1 618.654.2341

Fax: +1 618.654.2351

© 2014 by Basler Electric

All rights reserved

First printing: March 2013

## Warning!

**READ THIS MANUAL.** Read this manual before installing, operating, or maintaining the DGC-2020ES. Note all warnings, cautions, and notes in this manual as well as on the product. Keep this manual with the product for reference. Only qualified personnel should install, operate, or service this system. Failure to follow warning and cautionary labels may result in personal injury or property damage. Exercise caution at all times.

Basler Electric does not assume any responsibility to compliance or noncompliance with national code, local code, or any other applicable code. This manual serves as reference material that must be well understood prior to installation, operation, or maintenance.

For terms of service relating to this product and software, see the *Commercial Terms of Products and Services* document available at [www.basler.com/terms](http://www.basler.com/terms).

This publication contains confidential information of Basler Electric Company, an Illinois corporation. It is loaned for confidential use, subject to return on request, and with the mutual understanding that it will not be used in any manner detrimental to the interests of Basler Electric Company and used strictly for the purpose intended.

It is not the intention of this manual to cover all details and variations in equipment, nor does this manual provide data for every possible contingency regarding installation or operation. The availability and design of all features and options are subject to modification without notice. Over time, improvements and revisions may be made to this publication. Before performing any of the following procedures, contact Basler Electric for the latest revision of this manual.

The English-language version of this manual serves as the only approved manual version.

# Contents

<b>Introduction</b> .....	<b>1</b>
Features and Functions .....	1
Style Number .....	2
Optional Features and Capabilities .....	3
<b>Controls and Indicators</b> .....	<b>5</b>
Display Operation and Navigation .....	6
Display Setup .....	21
Remote Display Panel (optional) .....	22
<b>Power Input</b> .....	<b>25</b>
Nominal Voltage Input and Acceptable Range of Input Voltage .....	25
Terminal Assignments .....	25
Power Consumption .....	25
Battery Ride-Through Capability .....	25
Fuse Protection .....	25
<b>Voltage and Current Sensing</b> .....	<b>27</b>
Generator Voltage .....	27
Bus Voltage .....	27
Generator Current .....	27
<b>Engine Sender Inputs</b> .....	<b>29</b>
Connections .....	29
Compatible Senders .....	29
Operation .....	29
Sender Programmability .....	29
Sender Characteristic Curves .....	29
Sender Failure Detection .....	33
<b>Speed Signal Inputs</b> .....	<b>35</b>
Magnetic Pickup .....	35
Generator Sensing Voltage .....	35
<b>Contact Inputs</b> .....	<b>37</b>
Programmable .....	37
<b>Contact Outputs</b> .....	<b>41</b>
Prestart .....	41
Start .....	41
Run .....	41
Relay Control .....	41
Programmable .....	42
<b>Operating Modes</b> .....	<b>45</b>
Off .....	45
Run .....	45
Auto .....	45
Operating Mode Control .....	45
<b>Breaker Management</b> .....	<b>47</b>
Breaker Status .....	47
Breaker Operation .....	47
Breaker Configuration .....	48
<b>Generator Protection</b> .....	<b>53</b>
Voltage .....	53
Frequency .....	56
Overcurrent .....	57

<b>Metering .....</b>	<b>59</b>
Metering Explorer .....	59
Engine.....	60
Generator .....	61
Power.....	61
Run Statistics.....	61
Status Indication .....	62
Inputs .....	63
Logic Control Relays .....	64
Outputs .....	64
Control .....	66
Auto Export Metering.....	67
<b>Reporting and Alarms.....</b>	<b>69</b>
Alarm Configuration.....	71
Retrieving Alarm Information.....	76
Resetting Alarms and Pre-Alarms .....	77
<b>Event Recording.....</b>	<b>79</b>
Event Log .....	79
<b>Mounting .....</b>	<b>85</b>
Hardware .....	85
Dimensions.....	85
<b>Terminals and Connectors.....</b>	<b>87</b>
Connections.....	88
Operating Power.....	88
Generator Current Sensing .....	89
Generator Voltage Sensing .....	89
Bus Voltage Sensing .....	89
Analog Engine Sender Inputs.....	90
Magnetic Pickup Input .....	90
Contact Sensing Inputs .....	90
Output Contacts.....	91
USB Interface .....	91
CAN Interface .....	91
Optional Remote Display Panel Connections .....	92
<b>Typical Connections .....</b>	<b>93</b>
Connections for Typical Applications .....	93
CAN Connections .....	97
CEM-2020 Connections .....	98
Installation for CE Systems .....	98
<b>BESTCOMSPlus® .....</b>	<b>99</b>
System Recommendations .....	100
Installation .....	100
Activation of the DGC-2020ES Plugin.....	100
Menu Bars .....	103
Settings Explorer .....	105
Metering Explorer .....	105
BESTspace™ .....	106
Settings File Management.....	106
Firmware Updates .....	109
BESTCOMSPlus® Updates.....	112
<b>BESTlogic™ Plus .....</b>	<b>113</b>
Overview of BESTlogic™ Plus .....	113
BESTlogic™ Plus Composition .....	114
Logic Schemes .....	134

Programming BESTlogic™Plus.....	135
BESTlogic™Plus File Management .....	137
BESTlogic™Plus Examples .....	138
<b>Communication .....</b>	<b>141</b>
USB .....	141
CAN .....	141
Remote Display Panel (optional).....	149
<b>Configuration.....</b>	<b>151</b>
System Settings.....	151
Rated Data .....	152
Remote Module Setup.....	155
Crank Settings .....	155
Automatic Restart.....	157
Exercise Timer.....	158
Sensing Transformers .....	158
Relay Control.....	159
System Configuration Detection.....	159
<b>Security .....</b>	<b>161</b>
Changing Passwords.....	161
Saving Passwords in a DGC-2020ES Settings File.....	161
Loading Passwords from a Settings File into the DGC-2020ES.....	163
<b>Timekeeping .....</b>	<b>165</b>
Clock Setup .....	165
Setting the Time and Date.....	166
Real-Time Clock Specifications.....	166
<b>Maintenance and Troubleshooting .....</b>	<b>167</b>
Maintenance .....	167
Storage .....	167
Troubleshooting.....	167
<b>Specifications .....</b>	<b>173</b>
Operating Power.....	173
Battery Ride Through .....	173
Current Sensing.....	173
Voltage Sensing .....	173
Contact Sensing .....	174
Engine System Inputs.....	174
Output Contacts.....	175
Metering.....	175
Generator Protection Functions .....	177
Logic Timers .....	178
Communication Interface.....	178
Real-Time Clock .....	179
Liquid Crystal Display (LCD) .....	179
Type Tests.....	179
Environment .....	180
UL Approval.....	180
CSA Certification .....	180
NFPA Compliance .....	180
CE Compliance.....	180
Physical .....	180
<b>CEM-2020 .....</b>	<b>181</b>
General Information.....	181
Features .....	181
Specifications .....	181

---

Functional Description .....	183
BESTCOMSPPlus® Software.....	183
Installation .....	183
Remote Contact Input Configuration.....	190
Remote Contact Output Configuration .....	190
Maintenance .....	191
<b>MTU Fault Codes.....</b>	<b>193</b>
<b>Exhaust Treatment.....</b>	<b>203</b>
Diesel Particulate Filter (DPF).....	203
Exhaust After-Treatment Systems (EATS).....	205
<b>Diagnostic Trouble Codes.....</b>	<b>207</b>
<b>Revision History .....</b>	<b>217</b>

# Introduction

The DGC-2020ES Digital Genset Controller provides integrated engine-genset control, protection, and metering in a rugged and economical package. Its features set make the DGC-2020ES ideal for standalone genset applications where paralleling or load sharing is not required. Microprocessor based technology allows for exact measurement, setpoint adjustment, and timing functions. Front panel controls and indicators enable quick and simple DGC-2020ES operation. Basler Electric communication software (BESTCOMSP<sup>Plus</sup>) allows units to be easily customized for each application. Because of the low sensing burden in the DGC-2020ES, dedicated potential transformers (PTs) are not required. A liquid crystal display (LCD) with backlighting can be viewed under a wide range of ambient light and temperature conditions.

## Features and Functions

---

The DGC-2020ES Digital Genset Controller has the following features:

- Generator Control
- Engine and Generator Protection
- Automatic Transfer Switch Control (Mains Failure)
- Automatic Generator Configuration Detection
- Programmable Analog Engine Senders
- Seven Programmable Contact Inputs
- Programmable Logic
- Exercise Timer
- ECU Communications via SAE J1939
- Additional contact input/output module available to expand the capabilities of the DGC-2020ES

DGC-2020ES Digital Genset Controllers perform the following functions:

### Generator Protection and Metering

Multifunction generator protection guards against generator overvoltage, undervoltage, reverse power, loss of excitation, underfrequency, overfrequency, and overcurrent. Each generator protection function has an adjustable pickup and time delay setting.

Metered generator parameters include voltage, current, real power (watts), apparent power (VA), and power factor (PF).

### Engine Protection and Metering

Engine protection features include oil pressure and coolant temperature monitoring, overcrank protection, ECU specific protection elements, and diagnostic reporting.

Metered engine parameters include oil pressure, coolant temperature, battery voltage, speed, fuel level, engine load, coolant level (from ECU), ECU specific parameters, and run-time statistics.

### Event Recording

An event log retains a history of system events in nonvolatile memory. Up to 30 event types are retained and each record contains a time stamp of the first and last occurrence, and the number of occurrences for each event. For more information, see the *Event Recording* chapter.

### Contact Inputs and Outputs

DGC-2020ES controllers have seven programmable contact inputs. All contact inputs recognize dry contacts. The programmable inputs can be configured to initiate a pre-alarm or alarm. An input can be programmed to receive an input from an automatic transfer switch. Inputs can also be programmed to override DGC-2020ES alarms and protection functions. Each input can be assigned a user-defined name for easy identification at the front panel display and in fault records.

Output contacts include three dedicated relays for energizing an engine's glow plugs, fuel solenoid, and starter solenoid. Four additional user-programmable output contacts are provided.

Additional contact inputs and output contact requirements can be accommodated with an optional CEM-2020 (Contact Expansion Module). Contact Basler Electric for ordering information.

### **Automatic Transfer Switch Control (Mains Failure)**

The DGC-2020ES can detect a mains failure via a single- or three-phase bus input. A mains failure is established when any one of the following conditions are met:

- Any phase of bus voltage falls below dead the bus threshold
- Any phase of bus voltage is unstable due to overvoltage or undervoltage
- Any phase of bus voltage is unstable due to overfrequency or underfrequency

At this time, the DGC-2020ES will start the genset and when ready, apply power to the load via the genset. The DGC-2020ES implements open transitions to and from the mains. When the mains returns and is considered stable, the DGC-2020ES will transfer the load back to the mains.

### **Communication**

DGC-2020ES communication features include a standard USB port for local (and temporary) communication, SAE J1939 interface for remote communication, and RS-485 interface for communication with an optional Remote Display Panel.

#### USB Port

The USB communication port can be used with BESTCOMS*Plus* software to quickly configure a DGC-2020ES with the desired settings or retrieve metering values and event log records.

#### CAN Interface

The CAN interface provides high-speed communication between the DGC-2020ES and the engine control unit (ECU) on an electronically controlled engine. This interface provides access to oil pressure, coolant temperature, and engine speed data by reading these parameters directly from the ECU. When available, engine diagnostic data can also be accessed. The CAN interface supports the following protocols:

- SAE J1939 Protocol - Oil pressure, coolant temperature, and engine speed data are received from the ECU. In addition, DTCs (Diagnostic Trouble Codes) help diagnose any engine or related failures. The engine DTCs are displayed on the front panel of the DGC-2020ES and may be obtained using BESTCOMS*Plus*® software.
- MTU Protocol - A DGC-2020ES connected to a genset equipped with an MTU ECU receives oil pressure, coolant temperature, and engine speed data from the engine controller, along with various alarms and pre-alarms that are MTU specific. In addition, the DGC-2020ES tracks and displays the active fault codes issued by the MTU engine ECU.

## ***Style Number***

---

Standard-order DGC-2020ES controllers are identified by a style number which consists of a combination of letters and numbers that define the controller's electrical characteristics and operational features. The model number, together with the style number, describes the options included in a specific controller. Figure 1 illustrates the DGC-2020ES style number identification chart.




Figure 1. DGC-2020ES Style Chart

For example, a DGC-2020ES with style number **5A2**, has the following characteristics and features.

- 5** 5 Aac Current Sensing Inputs
- A** Analog Senders
- 2** Mains Failure Detection


## Optional Features and Capabilities

### CEM-2020 (Contact Expansion Module)

The optional CEM-2020 provides 10 additional contact inputs and 18 or 24 additional output contacts (depending on module type) to the DGC-2020ES. The CEM-2020 communicates with the DGC-2020ES through a CAN interface. Refer to the *CEM-2020* chapter for more information.

### Remote Display Panel

The optional Remote Display Panel provides remote indication of many pre-alarm and alarm conditions. The DGC-2020ES communicates with the Remote Display Panel through an RS-485 interface. Refer to the *Controls and Indicators* chapter for more information.



# Controls and Indicators

DGC-2020ES controls and indicators are located on the front panel and are intended for local control and monitoring of DGC-2020ES operation. Front panel controls consist of pushbuttons. Front panel indicators consist of LED (light emitting diode) indicators and a backlit LCD (liquid crystal display).

DGC-2020ES controls and indicators are illustrated in Figure 2. Lettered locators in Figure 2 correspond to the control and indicator descriptions of Table 1.




Figure 2. Front Panel

**Table 1. Front Panel HMI Descriptions**

<b>Locator</b>	<b>Description</b>
A	<i>Liquid Crystal Display.</i> The backlit, 64 by 128 pixel LCD serves as the local information source for metering, alarms, pre-alarms, and protective functions. Display operation is maintained at $-40^{\circ}\text{C}$ .
B	<i>Supplying Load Indicator.</i> This green LED lights when the generator current is greater than Emergency Power Supply (EPS) threshold current.
C	<i>Alarm Indicator.</i> This red LED lights continuously during alarm conditions and flashes during pre-alarm conditions.
D	<i>Not in Auto Indicator.</i> This red LED lights when the DGC-2020ES is not operating in Auto mode. When the DGC-2020ES is operating in Run or Off mode, this LED is on.
E	<i>Run Pushbutton and Mode Indicator.</i> Pressing this button places the DGC-2020ES in Run mode. The green Run mode LED lights when Run mode is active.
F	<i>Off Pushbutton and Mode Indicator.</i> Pressing this button places the DGC-2020ES in Off mode. The red Off mode LED lights when the DGC-2020ES is in Off mode. This button also resets the Breaker Management Pre-Alarms and all MTU ECU Alarms.
G	<i>Auto Pushbutton and Mode Indicator.</i> Pressing the Auto button places the DGC-2020ES in Auto mode. The green Auto mode LED lights when Auto mode is active.
H	<i>Back Pushbutton.</i> This button is pressed to cancel a settings editing session and discard any settings changes. When navigating through menus, pressing this button moves upward a level. When pressed momentarily, this button also resets the Breaker Management Pre-Alarms and all MTU ECU Alarms. This button is also used to reset the Maintenance Interval when pressed for 10 seconds while viewing Hours Until Maintenance or Maintenance Due Pre-Alarm.
I	<i>Alarm Silence Pushbutton Combination.</i> Simultaneously pressing both the <i>Back</i> and <i>Edit</i> buttons opens the relay output programmed as the horn output.
J	<i>Edit Pushbutton.</i> Pressing this button starts an editing session and enables changes to DGC-2020ES settings. At the conclusion of an editing session, the Edit pushbutton is pressed again to save the setting changes. When navigating through menus, pressing this button moves downward one level. When entering a string, such as a password, this button locks the selected character and moves to the next position. When finished, press Edit twice to submit the string.
K	<i>Arrow Pushbuttons.</i> These two buttons are used to navigate through the front panel display menus and modify settings. Within a level, the up- and down-arrow buttons are used to move among items within the menu level. Pressing the down-arrow button moves to items lower in the list. Pressing the up-arrow button moves to items higher in the list. During a settings editing session, the up- and down-arrow buttons are used to raise and lower the value of the selected setting.
L	<i>Lamp Test Pushbutton Combination.</i> Simultaneously pressing both the Up- and Down-arrow buttons tests the DGC-2020ES indicators by exercising all LCD pixels and lighting all LEDs for as long as both buttons are held.

## ***Display Operation and Navigation***

The front panel display is used to make settings changes and display metering values. Refer to locators H, J, and K in Table 1 for information on changing settings through the front panel and navigating through the Metering screens.

## Login and Permissions

To login, navigate to the SETTINGS, ENTER PASSWORD screen and press the *Edit* key. Use the *Up/Down* arrow keys to scroll through the characters. Use the *Edit* key to accept a character and move to the next space. Once the password has been entered, press the *Edit* key again to login. A LOGOUT selection now appears in the list of SETTINGS. To logout, navigate to SETTINGS, LOGOUT and press the *Edit* key. The LOGOUT selection is removed from the SETTINGS list.

If communication access is active through the USB port, the front panel will display REMOTE COMMS, FRONT PANEL IS READ ONLY, and the summary screen. This informs the user that the front panel can only be used for viewing metering data and settings information. USB port access must be ended before modifying settings through the front panel.

## Summary Screen and Configurable Metering

The summary screen can be set to standard or scrolling. When set to standard, only the following parameters are displayed:

- VOLT\*
- AMP\*
- PH\*
- Hz
- OIL
- FUEL
- TEMP
- BATT

\* When set to standard, individual phase information can be automatically toggled at a rate set by the Phase Toggle Delay setting. Navigate to the SETTINGS, GENERAL SETTINGS, FRONT PANEL HMI screen and edit PH TOG DELAY. When the Phase Toggle Delay is set to zero, information for each phase is obtained by pressing the *Up* or *Down* arrow keys on the front panel HMI. When it is set to a number other than zero, the display will toggle through the phases automatically at the rate specified by the Phase Toggle Delay Setting.

When the summary screen is set to scrolling, you can select/configure the metering values that are displayed. Up to 20 values can be displayed and these values will scroll at a delay time specified by the user. To select a standard or scrolling summary, navigate to the SETTINGS, GENERAL SETTINGS, FRONT PANEL HMI screen and edit the SUMMARY VIEW. The SCROLL DELAY setting is also found on this screen.

To select the scrolling values, navigate to the SETTINGS, GENERAL SETTINGS, FRONT PANEL HMI screen and edit the CONFIGURABLE METERING. The following parameters may be placed in the scrolling summary:

- |                                      |                   |
|--------------------------------------|-------------------|
| • BATT V                             | • GEN VCA         |
| • BLANK (Shows nothing on this line) | • GEN VCN         |
| • BOOST PRESS                        | • INJ RAIL PRS    |
| • BUS Hz                             | • INTAK MNFLD TMP |
| • BUS VAB                            | • kVA A           |
| • BUS VBC                            | • kVA B           |
| • BUS VCA                            | • kVA C           |
| • CHRGR AIR TMP                      | • kVA TOT         |
| • COOLANT PRESS                      | • kvar A          |
| • ENGINE % LOAD                      | • kvar B          |
| • ENG INTCLR TEMP                    | • kvar C          |
| • ENG OIL TEMP                       | • kvar TOTAL      |
| • FUEL                               | • kW A            |
| • FUEL DELV P                        | • kW B            |
| • FUEL RATE                          | • kW C            |

- FUEL TEMP
- GEN Hz
- GEN IA
- GEN IB
- GEN IC
- GEN PF
- GEN VAB
- GEN VAN
- GEN VBC
- GEN VBN
- kWh
- kW TOT
- NONE (Removes a line from the scrolling list)
- OIL P
- RPM
- RPM SRC
- RUN HRS
- TEMP
- TOTAL FUEL USED

## Sleep Mode


Sleep mode de-energizes the LCD backlight and heater when no pushbutton activity is detected for 15 minutes and the DGC-2020ES is operating in OFF mode or Auto mode with the engine not running. Normal display operation resumes when any pushbutton is pressed or the genset is started remotely via the ATS input. Sleep mode will not be entered while an alarm is active. Sleep mode can be permanently disabled through BESTCOMSP<sup>Plus</sup>® or the front panel.

## Changing a Setting

To change a setting, navigate to the setting you want to change and press the *Edit* key. If you are not already logged in, you will be prompted for your password. Use the *Up/Down* arrow key to raise or lower the value. Press the *Edit* key again when finished.


## Front Panel Display Structure

The front panel display structure begins with the SUMMARY SCREEN. Pressing the *Edit* key opens the MAIN MENU screen. The MAIN MENU screen consists of METERING and SETTINGS. The METERING screen branches are shown in Figure 3. Details of the METERING screen branches follow Figure 3. The SETTINGS screen branches are shown in Figure 4. Details of the SETTINGS screen branches follow Figure 4.



P0067-82

**Figure 3. Metering Screen Branches**



## GENERATOR

- GEN VAB
- GEN VBC
- GEN VCA
- GEN VAN
- GEN VBN
- GEN VCN
- GEN FREQ
- GEN AMPS A
- GEN AMPS B
- GEN AMPS C
- BUS VAB
- BUS VBC
- BUS VCA
- BUS FREQ

## POWER

- kW A
- kW B
- kW C
- kW TOTAL
- kVA A
- kVA B
- kVA C
- kVA TOTAL
- kvar A
- kvar B
- kvar C
- kvar TOTAL
- PF

## RUN STATISTICS

- **CUMULATIVE**
  - CUMULATIVE
    - START
    - # STARTS
    - HRS TO MAINT
    - KW-HRS
  - TOTAL RUN TIME
    - HOURS
    - MINUTES
  - LOADED RUN TIME
    - HOURS
    - MINUTES
  - UNLOADED RUN TIME
    - HOURS
    - MINUTES
- **SESSION**
  - SESSION
    - START
    - KW-HRS
  - TOTAL RUN TIME
    - HOURS
    - MINUTES
  - LOADED RUN TIME
    - HOURS
    - MINUTES
  - UNLOADED RUN TIME
    - HOURS
    - MINUTES

## ALARMS-STATUS

- **ACTIVE ALARMS**
- **ACTIVE PRE-ALARMS**
- **MTU FAULT CODES** (Visible when ECU is configured for MTU MDEC, MTU ADEC, MTU ECU7/ECU8 or MTU Smart Connect.)
- **MTU STATUS** (Visible when ECU is configured for MTU MDEC, MTU ADEC, MTU ECU7/ECU8, or MTU Smart Connect.)
  - NMT-ALIVE STATUS (Visible when ECU is configured for MTU MDEC or MTU ECU7/ECU8.)
    - SPS\_NODE
    - SW\_TYP
    - SW\_VAR
    - SW\_ED1
    - SW\_ED2
    - REV
    - SW\_MOD
  - TRIP FUEL (Visible when ECU is configured for MTU ECU7/ECU8.)
    - TRIP HRS
    - TRIP IDLE HRS
    - FUEL RATE
    - TRIP FL RATE
    - TOTAL RUN TM
    - DAILY FUEL
    - TOTAL FUEL
  - FUEL (Visible when ECU is configured for MTU ADEC.)
    - DAY TANK LVL
    - STORE TANK LVL
  - ENGINE STATUS (Visible when ECU is configured for MTU ADEC, MTU ECU7/ECU8, or MTU Smart Connect.)
    - MTU FAULT CODES
    - ENG RUNNING
    - CYL CUTOUT
    - ENG OPTIMIZED (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
    - PREHT NT RCHD (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
    - SPEC TORQUE (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
    - SPD DMD FL MD (Visible when ECU is configured for MTU ADEC.)
    - CURR P DEGREE (Visible when ECU is configured for MTU ADEC.)
    - LOAD GEN ON (Visible when ECU is configured for MTU ADEC, MTU ECU7/ECU8, or MTU Smart Connect.)
    - PRIME PUMP ON (Visible when ECU is configured for MTU ADEC.)
    - RUNUP SPD LO (Visible when ECU is configured for MTU ADEC.)
    - IDLE SPD LO (Visible when ECU is configured for MTU ADEC.)
    - CYL CUTOUT CD (Visible when ECU is configured for MTU ECU7/ECU8.)
    - RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
    - DROOP % (Visible when ECU is configured for MTU ECU7/ECU8 or MTU Smart Connect.)
    - ENG COOL TEMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - CHRG AIR TMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - INTRCOOLR TEMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - ENG OIL TEMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - FUEL TEMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - ECU TEMP (Visible when ECU is configured for MTU ECU7/ECU8.)
    - OIL PRESSURE (Visible when ECU is configured for MTU ECU7/ECU8.)
    - CHG AIR P (Visible when ECU is configured for MTU ECU7/ECU8.)
    - FUEL DELV P (Visible when ECU is configured for MTU ECU7/ECU8.)
    - FL RAIL P (Visible when ECU is configured for MTU ECU7/ECU8.)
    - CAMSHAFT RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
    - IDLE RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
    - ECU SHUTDOWN (Visible when ECU is configured for MTU ECU7/ECU8.)
    - TOTAL RUN TM (Visible when ECU is configured for MTU ECU7/ECU8.)
    - ECU SUPP VOLTS (Visible when ECU is configured for MTU ECU7/ECU8.)
    - INJCT DBR % (Visible when ECU is configured for MTU ECU7/ECU8.)
    - RATED RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
    - INJCT QTY (Visible when ECU is configured for MTU ECU7/ECU8.)
    - RATED KW (Visible when ECU is configured for MTU ECU7/ECU8.)

- RESRV PWR % (Visible when ECU is configured for MTU ECU7/ECU8.)
  - START SEQ (Visible when ECU is configured for MTU ECU7/ECU8 or MTU Smart Connect.)
  - ECU OVRD FDBK (Visible when ECU is configured for MTU Smart Connect.)
  - COOLNT PRHT DONE (Visible when ECU is configured for MTU Smart Connect.)
  - REQ TORQUE (Visible when ECU is configured for MTU Smart Connect.)
  - EXT STOP (Visible when ECU is configured for MTU Smart Connect.)
  - OPERATING MODE (Visible when ECU is configured for MTU Smart Connect.)
- SPEED (Visible when ECU is configured for MTU ADEC, MTU ECU7/ECU8, or MTU Smart Connect.)
  - SPD DMD SRC
  - CAN SPD DMD
  - ANLG SPD DMD
  - SPEED DEMAND (Visible when ECU is configured for MTU Smart Connect.)
  - SEL SPD DMD (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
  - EFF SET SPEED (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
  - SPD DMD FL MD (Visible when ECU is configured for MTU ECU7/ECU8 or MTU Smart Connect.)
  - RATED RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
  - RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
  - CAMSHAFT RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
  - IDLE RPM (Visible when ECU is configured for MTU ECU7/ECU8.)
  - FREQ RPM DMD (Visible when ECU is configured for MTU ECU7/ECU8.)
- SIGNAL FEEDBK (Visible when ECU is configured for MTU ADEC, MTU ECU7/ECU8, or MTU Smart Connect.)
  - ECU\_OVRD\_FDBK
  - EXT STOP
  - SPD UP IN
  - SPD DN IN
  - CAN MODE FDBK (Visible when ECU is configured for MTU ADEC or MTU ECU7/ECU8.)
  - CYL CUTOUT (Visible when ECU is configured for MTU ECU7/ECU8.)
- DIAGNOSTICS (Visible when ECU is configured for MTU ECU7/ECU8.)
  - AL PWR AMP 1
  - AL PWR AMP 2
  - XSTR OUT AL
  - XSTR OUT STS
  - ECU SHUTDOWN
- CAN BUS (Visible when ECU is configured for MTU ECU7/ECU8.)
  - CAN MODE FDBK
  - CAN NODES
  - LOST NODES
- LIMITS (Visible when ECU is configured for MTU ECU7/ECU8.)
  - OIL PRESSURE
  - LO LIM OILP
  - LOLOLIM OILP
  - ENG COOL TEMP
  - CLNT LMT HI
  - CLNT LMT HIHI
  - CHRG AIR TMP
  - CHG AIR LMT HI
  - ECU SUPP VOLTS
  - L1L ECU VOLTS
  - L2L ECU VOLTS
  - U1L ECU VOLTS
  - U2I ECU VOLTS
  - INTRCOOLR TMP
  - INTCLR LMT HI
- **STATUS**
  - AUTO XFER SWITCH (Visible when the Auto Transfer Switch programmable function is configured to be driven by an input.)
  - EPS SUPP. LOAD
  - GEN BREAKER
  - MAINS BREAKER
  - BATTLE OVERRIDE (Visible when the Battle Override programmable function is configured to be driven by an input.)
  - LOW LINE OVERRIDE (Visible when the Low Line Override programmable function is configured to be driven by an input.)


- LOW COOL LEVEL (Visible when the Low Coolant Level programmable function is configured to be driven by an input.)
- LOW FUEL LEVEL (Visible when the Low Coolant Level programmable function is configured to be driven by an input.)
- BATT CHRГ FAIL (Visible when the Battery Charger Fail programmable function is configured to be driven by an input.)
- FUEL LEAK DETECT (Visible when the Fuel Leak Detect programmable function is configured to be driven by an input.)
- GRND DELTA O-RIDE (Visible when Generator Connection is configured for Delta and the Grounded Delta Override programmable function is configured to be driven by an input.)
- 1 PHASE O-RIDE (Visible when the 1-Phase Override programmable function is configured to be driven by an input.)
- BUS DEAD
- BUS STABLE
- BUS FAILED
- GEN DEAD
- GEN STABLE
- GEN FAILED
- ENG RUNNING
- CLDN TMR ACTIVE
- OFF MODE COOLDN
- COOLDN REQ
- COOL & STOP REQ
- EXT START DEL
- START DEL BYPASS
- ALT FRQ O-RIDE
- RESET
- ALARM SILENCE
- LAMP TEST
- IDLE REQUEST
- MAINS FAIL TEST
- CEM CONNECTED
- **INPUTS**
  - INPUT X (X = 1 to 7 (8 to 17 optional))
- **OUTPUTS**
  - START
  - RUN
  - PRESTART
  - OUTPUT X (X = 1 to 4 (5 to 28 optional))
- **LOGIC CTL RELAYS**
  - LCR X (X = 1 to 16)
- **CONF ELEMENTS**
  - CONFIG ELEMENT X (X = 1 to 8)
- **EVENT LOG**
  - [EVENT NAME]
    - ACTIVE
    - OCCURRENCE COUNT
    - FIRST DATE
    - FIRST TIME
    - LAST DATE
    - LAST TIME
    - FIRST ENG HRS
    - LAST ENG HRS
    - DETAILS
      - OCCURRENCE (Use the *Edit/Up/Down* keys to change the occurrence.)
      - DATE
      - TIME
      - ENG HRS
    - CLEAR EVENT (Visible when logged in through the front panel.)
- **J1939 DATA** (Visible when CAN bus is enabled and ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins or MTU Smart Connect.)
  - THROTTLE POSITN
  - LOAD @ CRNT RPM
  - ACTUAL ENG TORQ
  - ENGINE SPEED

- DESIRED SPEED
- INJ CNTRL PRESS
- INJ RAIL PRS
- ENGINE HOURS
- TRIP FUEL
- TRIP AVE FL RT
- TOTAL FUEL USED
- ENG COOLANT TEMP
- COOLNT PRHT DONE
- FUEL TEMP
- ENG OIL TEMP
- ENG INTCLR TEMP
- INTRCR CLNT LVL
- FUEL DELV P
- ENG OIL LEVEL
- ENG OIL PRESS
- COOLANT PRESS
- COOLANT LEVEL
- FUEL RATE
- BAROMETRIC PRESS
- AMB AIR TEMP
- AIR INLET TEMP
- BOOST PRESS
- INTAK MNFLD TEMP
- INTAK MNFLD1 ABS PRESS
- AIR FLTR DIF PRS
- EXHAUST GAS TEMP
- BATTERY VOLTAGE
- ECU INPUT VOLTS
- TRANS OIL PRESS
- TRANS OIL TEMP
- WINDG 1 TEMP
- WINDG 2 TEMP
- WINDG 3 TEMP
- ECU TEMP
- AUX PRESSURE1
- AUX PRESSURE2
- RATED KW
- RATED RPM
- EXHAUST TMP A
- EXHAUST TMP B
- CHRG AIR TMP
- FUEL 1 LEAK
- FUEL 2 LEAK
- ALARM RST FDBK
- ECU SHUTDOWN
- DEF TANK 1 LVL %
- DEF TANK 2 LVL %
- **J1939 ENGINE CONFIG** (Visible when CAN bus is enabled and ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins, or MTU Smart Connect.)
  - SPD @ IDLE PNT 1
  - TRQ @ IDLE PNT 1
  - SPD @ PNT 2
  - TRQ @ PNT 2
  - SPD @ PNT 3
  - TRQ @ PNT 3
  - SPD @ PNT 4
  - TRQ @ PNT 4
  - SPD @ PNT 5
  - TRQ @ PNT 5
  - SPD @ PNT 6
  - ENDSPEED GOV KP
  - REF ENG TORQUE
  - O-RIDE SPD PNT 7
  - O-RIDE TIME LMT

- SPEED LOWER LMT
- SPEED UPPER LMT
- TORQUE LOWER LMT
- TORQUE UPPER LMT

## DIAGNOSTICS

- **FLASH WR**



P0067-83

**Figure 4. Settings Screen Branches**

## GENERAL SETTINGS

- **FRONT PANEL HMI**
  - SUMMARY VIEW
  - SCROLL DELAY
  - PH TOG DELAY
  - LCD CONTRAST
  - SLEEP MODE
  - LANGUAGE
  - CONFIGURABLE METERING
    - ITEM X (X = 1 to 20)
- **CONFIGURE DATE/TIME**
  - YEAR
  - MONTH
  - DAY
  - HOURS
  - MINUTES
  - SECONDS
  - UTC OFFSET
  - DST ENABLED
  - CLK NOT SET WRN
- **VIEW DATE/TIME**
- **VERSION INFO**
  - DGC-2020ES
    - FIRMWARE VERSION
    - BOOT CODE VERSION
    - SERIAL NUMBER
    - PART NUMBER
    - MODEL NUMBER
    - LANGUAGE VERSION
    - LANGUAGE PART NUM
    - STYLE CODE
  - CEM-2020 (Visible when CEM-2020 is enabled.)
    - FIRMWARE VERSION
    - BOOT CODE VERSION
    - SERIAL NUMBER
    - PART NUMBER
    - MODEL NUMBER
    - BUILD DATE

## COMMUNICATIONS\*

\*(Visible when the optional J1939 CAN bus is enabled, style code xCx.)

- **CAN BUS SETUP**
  - CAN BUS SETUP
    - CAN BUS ENABLE
    - DTC ENABLE (Visible when CAN BUS is enabled.)
    - SPN CONV METHOD (Visible when CAN BUS is enabled.)
    - CAN BUS ADDR (Visible when CAN BUS is enabled.)
    - ECU OPT SLCT (Visible when CAN BUS is enabled.)
    - ECU PULSING (Visible when CAN BUS is enabled.)
    - ENG SHTDN TM (Visible when CAN BUS is enabled.)
    - PLS CYCL TM (Visible when CAN BUS is enabled.)
    - ECU SET TM (Visible when CAN BUS is enabled.)
    - RESP TIMEOUT (Visible when CAN BUS is enabled.)
  - ECU SETUP (Visible when CAN BUS is enabled.)
    - ECU CONF
    - GEN DATA TRANSMIT
    - ENGINE PARAM XMT
    - TRIP RESET (Visible when ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins, or MTU Smart Connect.)
    - DPF REGENERATE SETUP (Visible when ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins, or MTU Smart Connect.)
      - DPF MANUAL REGEN
      - DPF REGEN DISABLE
    - SPEED SELECT (Visible when ECU is configured for Volvo Penta.)
    - ACCEL POSITION (Visible when ECU is configured for Volvo Penta.)
    - MODULE TYPE (Visible when ECU is configured for MTU MDEC or MTU ECU7/ECU8.)
    - ALIVE MSG (Visible when ECU is configured for MTU MDEC or MTU ECU7/ECU8.)
    - SPEED SETUP
      - J1939 RPM ENABLE (Visible when ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins, or MTU Smart Connect.)
      - ENGINE RPM
      - RPM BAND WIDTH
      - IDLE RPM
      - SPEED UP (Visible when ECU is configured for MTU ADEC, MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - SPEED DN (Visible when ECU is configured for MTU ADEC, MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - TEST OVRSPPEED (Visible when ECU is configured for MTU ADEC, MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - SPD DMAND SRC (Visible when ECU is configured for MTU ADEC, MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - IDLE REQUEST (Visible when ECU is configured for MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - INCREASE IDLE (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
    - ECU SETUP (Visible when ECU is configured for MTU ADEC, MTU MDEC 304, MTU ECU7/ECU8, or MTU Smart Connect.)
      - TRIP RESET (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
      - INT OIL PRIME
      - GOV PRM SW (Visible when ECU is configured for MTU ADEC or MTU Smart Connect.)
      - ENG STRT PRIME (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
      - FAN OVERRIDE (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
      - MODE SWITCH (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
      - GOV PARAM SET (Visible when ECU is configured for MTU ECU7/ECU8.)
      - CAN RATING SW 1 (Visible when ECU is configured for MTU ECU7/ECU8.)
      - CAN RATING SW 2 (Visible when ECU is configured for MTU ECU7/ECU8.)

- DIS CYL CUT 1 (Visible when ECU is configured for MTU MDEC 304, or MTU ECU7/ECU8.)
- DIS CYL CUT 2 (Visible when ECU is configured for MTU MDEC 304, MTU ECU7/ECU8 or MTU Smart Connect.)
- OPERATING MODE (Visible when ECU is configured for MTU Smart Connect.)

## SYSTEM PARAMS

- **SYSTEM SETTINGS**
  - GEN CONNECT
  - BUS CONNECT
  - RATED kW
  - RATED VOLTS
  - RATED FREQ
  - ALTRNATE FRQ
  - RATED RPM
  - RATED PF
  - ROTATION
  - EPS
    - EPS THRESHLD
    - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - FUEL LVL TYP
  - SYSTEM UNITS
  - PRESSURE UNITS (Visible when Metric is selected for System Units.)
  - BATTERY VOLT
  - FLYWHL TEETH
  - SPEED SOURCE
  - MAINT RESET
  - NFPA LEVEL
  - POWER UP DELAY
- **REMOTE MODULE SETUP**
  - CEM SETUP
    - ENABLE
    - OUTPUTS (Visible when CEM-2020 is enabled.)
    - CAN BUS ADDR (Visible when CEM-2020 is enabled.)
    - VERSION INFO (Visible when CEM-2020 is enabled.)
      - FIRMWARE VERSION
      - BOOT CODE VERSION
      - SERIAL NUMBER
      - PART NUMBER
      - MODEL NUMBER
      - BUILD DATE
    - CEM DEBUG MENU (Visible when CEM-2020 is enabled.)
      - DGC TO CEM BP
      - CEM TO DGC BP
- **CRANK SETTINGS**
  - DISCNCT LMIT
  - PRECRNK DELY
  - PRESTRT CNTCT
  - STYLE
  - # CYCLES (Visible when Cycle is selected for Cranking Style.)
  - CONT TIME (Visible when Continuous is selected for Cranking Style.)
  - CYCLE TIME
  - COOLDWN TIME
  - OFF MODE COOLDN
  - PRESTART REST CONFIG
    - CONF
  - OIL PRS CRANK DISC
    - ENABLE
    - CRANK DISC PRS
- **AUTOMATIC RESTART**
  - ENABLE
  - ATTEMPTS
  - INTERVAL

- **EXERCISE TIMER**
  - MODE
  - RUN WITH LOAD
  - START HOUR
  - START MINUTE
  - RUN HOURS
  - RUN MINUTES
- **SENSING TRANS**
  - GEN PT PRI V
  - GEN PT SEC V
  - GEN CT PRI A
  - CT LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - BUS PT PRI V
  - BUS PT SEC V
- **RELAY CONTROL**
  - START
  - RUN
  - PRESTART
- **AUTO CONFIG DETECT**
  - ENABLE
  - LOW LINE THRESH
  - 1-PH THRESH
- **ENGINE STATISTICS**
  - START YEAR
  - START MONTH
  - START DAY
  - # STARTS
  - HRS TO MAINT
  - KW-HRS
  - TOTAL HRS
  - LOADED HRS
  - UNLOADED HRS

## PROGRAMMABLE INPUTS

- **CONFIGURABLE INPUTS**
  - INPUT X (X = 1 to 7)
    - ALARM CONFIG
    - ACTIVATN DLY
    - RECOGNITION
- **PROG FUNCTIONS**
  - EMERGENCY STOP
    - INPUT
  - AUTO XFER SWITCH
    - INPUT
    - RECOGNITION (Visible when an INPUT is selected.)
  - GRND DELTA O-RIDE
    - INPUT
    - RECOGNITION (Visible when an INPUT is selected.)
  - BATTLE OVERRIDE
    - INPUT
    - RECOGNITION (Visible when an INPUT is selected.)
  - LOW LINE OVERRIDE
    - INPUT
    - RECOGNITION (Visible when an INPUT is selected.)
  - 1 PHASE O-RIDE
    - INPUT
    - RECOGNITION (Visible when an INPUT is selected.)
  - BATT CHRГ FAIL
    - INPUT
    - ALARM CONFIG (Visible when an INPUT is selected.)
    - ACTIVATN DLY (Visible when an INPUT is selected.)
    - RECOGNITION (Visible when an INPUT is selected.)
  - LOW COOL LEVEL
    - INPUT

- ALARM CONFIG (Visible when an INPUT is selected.)
  - ACTIVATN DLY (Visible when an INPUT is selected.)
  - RECOGNITION (Visible when an INPUT is selected.)
- LOW FUEL LEVEL
  - INPUT
  - ALARM CONFIG (Visible when an INPUT is selected.)
  - ACTIVATN DLY (Visible when an INPUT is selected.)
  - RECOGNITION (Visible when an INPUT is selected.)
- FUEL LEAK DETECT
  - INPUT
  - ALARM CONFIG (Visible when an INPUT is selected.)
  - ACTIVATN DLY (Visible when an INPUT is selected.)
  - RECOGNITION (Visible when an INPUT is selected.)

## PROGRAMMABLE OUTPUTS

- **CONFIG ELEMENTS**
  - CONFIG ELEMENT X (X = 1 to 8)
    - ALARM CONFIG
    - ACTIVATN DLY
    - RECOGNITION

## ALARM CONFIGURATION

- **HORN CONFIGURATION**
  - HORN
  - NOT IN AUTO HORN
- **PRE-ALARMS**
  - HIGH COOLANT TEMP
    - ENABLE
    - THRESHOLD
  - LOW COOLANT TEMP
    - ENABLE
    - THRESHOLD
  - LOW OIL PRESSURE
    - ENABLE
    - THRESHOLD
  - LOW FUEL LEVEL
    - ENABLE
    - THRESHOLD
  - MAINTENANCE INTERVAL
    - ENABLE
    - THRESHOLD
  - BATTERY OVERVOLTAGE
    - ENABLE
    - THRESHOLD
  - LOW BATTERY VOLTAGE
    - ENABLE
    - THRESHOLD
    - ACTIVATN DLY
  - WEAK BATTERY VOLTAGE
    - ENABLE
    - THRESHOLD
    - ACTIVATN DLY
  - HIGH FUEL LEVEL
    - ENABLE
    - THRESHOLD
    - ACTIVATN DLY
  - ACTIVE DTC (Visible when DTC is enabled.)
    - ENABLE
  - ECU COMMS FAIL (Visible when CAN BUS is enabled.)
    - ENABLE
  - COOLANT LEVEL (Visible when CAN BUS is enabled.)
    - ENABLE
    - THRESHOLD

- CEM COMM FAIL (Visible when CEM-2020 is enabled.)
  - ENABLE
- CHECKSUM FAIL
  - ENABLE
- BRK CLOSE FAIL PALM
  - ENABLE
- BRK OPEN FAIL PALM
  - ENABLE
- **ALARMS**
  - HIGH COOLANT TEMP
    - ENABLE
    - THRESHOLD
    - ARMING DELAY
  - LOW OIL PRESSURE
    - ENABLE
    - THRESHOLD
    - ARMING DELAY
  - LOW FUEL LEVEL
    - ENABLE
    - THRESHOLD
    - ACTIVATN DLY
  - OVERSPEED
    - ENABLE
    - THRESHOLD
    - ACTIVATN DLY
  - COOLANT LEVEL (Visible when CAN bus is enabled.)
    - ENABLE
    - THRESHOLD

**NOTE**

The HIGH COOLANT TEMP and LOW OIL PRESSURE alarms have an ARMING DLY setting that disables the alarm for the specified time after engine startup.

- **SENDER FAIL**
  - COOL TEMP SENDR FAIL
    - CONFIG TYPE
    - ACTIVATN DLY
  - OIL PRESS SENDR FAIL
    - CONFIG TYPE
    - ACTIVATN DLY
  - FUEL LEVEL SENDR FAIL
    - CONFIG TYPE
    - ACTIVATN DLY
  - VOLTAGE SENSE FAIL
    - CONFIG TYPE
    - ACTIVATN DLY
  - SPEED SENDR FAIL
    - TIME DELAY

## GENERATOR PROTECTION

- **27 UNDERVOLTAGE**
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - 3 / 1 PHASE SETTINGS
    - PICKUP
    - HYSTERESIS
    - TIME DELAY
    - FREQ INHIBIT
    - ALARM CONFIG

- **59 OVERVOLTAGE**
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - 3 / 1 PHASE SETTINGS
    - PICKUP
    - HYSTERESIS
    - TIME DELAY
    - ALARM CONFIG
- **47 PHASE IMBALANCE**
  - PICKUP
  - HYSTERESIS
  - TIME DELAY
  - ALARM CONFIG
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
- **81 O/U FREQUENCY**
  - UNDERFREQUENCY
    - INHIBIT VOLTS
    - PICKUP
    - HYSTERESIS
    - TIME DELAY
    - ALARM CONFIG
  - OVERFREQUENCY
    - PICKUP
    - HYSTERESIS
    - TIME DELAY
    - ALARM CONFIG
  - ALTRNT FRQ SCALE FCTR
    - ALT FREQ SF
- **50 OVERCURRENT**
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - 3 / 1 PHASE SETTINGS
    - PICKUP
    - TIME DELAY
    - ALARM CONFIG

## BREAKER MANAGEMENT

- **BREAKER HARDWARE**
  - MAINS FAIL TRANSFER
    - ENABLE
    - RETURN DELAY
    - TRANSFER DELAY
    - MAX TRANSFER TIME
  - CLOSE WAIT TIME
    - TIME
  - GEN BREAKER
    - CONTINUOUS
    - CLOSING TIME
    - OPEN CMD
    - CLOSE CMD
  - MAINS BREAKER
    - CONFIGURED
    - CONTINUOUS (Visible when configured.)
    - CLOSING TIME (Visible when configured.)
    - OPEN CMD (Visible when configured.)
    - CLOSE CMD (Visible when configured.)
  - BRK CLOSE FAIL PALM
  - BRK OPEN FAIL PALM
- **BUS CONDITION DETECT**
  - GEN DEAD
    - THRESHOLD
    - TIME DELAY
  - GEN STABLE
    - OV PICKUP
    - OV DROPOUT
    - UV PICKUP

- UV DROPOUT
  - OF PICKUP
  - OF DROPOUT
  - UF PICKUP
  - UF DROPOUT
  - TIME DELAY
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - ALT FREQ SF
- GEN FAILED
  - TIME DELAY
- BUS DEAD
  - THRESHOLD
  - TIME DELAY
- BUS STABLE
  - OV PICKUP
  - OV DROPOUT
  - UV PICKUP
  - UV DROPOUT
  - OF PICKUP
  - OF DROPOUT
  - UF PICKUP
  - UF DROPOUT
  - TIME DELAY
  - LOW LINE SF (Visible when an input is selected for the Low Line Override programmable function.)
  - ALT FREQ SF
- BUS FAILED
  - TIME DELAY

## LOGIC TIMERS

- **TIMER X (X = 1 to 10)**
  - HOURS
  - MINUTES
  - SECONDS

## ENTER PASSWORD

**LOGOUT** (Visible when logged in through the front panel.)

## **Display Setup**

The DGC-2020ES LCD can be customized to fit the needs of your specific application. Most of the options can be adjusted using the front panel buttons while all options can be adjusted within BESTCOMSPPlus®. The display options are described below.

The *Front Panel HMI* screen is found in the BESTCOMSPPlus® *Settings Explorer* under the *General Settings* category. If using the front panel, navigate to Settings > General Settings > Front Panel HMI.

Figure 5 shows the BESTCOMSPPlus® Front Panel HMI settings screen.

LCD Contrast - Adjust this setting to reach the desired level of LCD contrast.

1. Front Panel Sleep Mode - Select enable to send the DGC-2020ES into sleep mode. In sleep mode, the LEDs and LCD backlight turn off after 15 minutes of inactivity on the front panel to minimize battery drain.
2. Language Selection - Select from English, French, German, or Spanish.
3. Scrolling Screens - These settings are not accessible via the front panel. If a different overview screen for the LCD is desired, specify the scrolling screens in which parameters are configured to appear on the front panel LCD display.

- a. Configure the *Configurable HMI Summary Settings*.
  - b. Set the *Scrolling Screen Enable* to *Enable*.
  - c. Set the *Scrolling Screen Scroll Delay* parameter to the desired value.
4. Phase Toggle Delay - Set the phase toggle delay to a nonzero value if automatic scrolling through the phase information in the standard overview screen on the front panel is desired. If it is left at zero, scrolling through phase information is accomplished using the up and down arrow buttons.
  5. Initializing Message 1 - This parameter defines the first line of text that appears on the front panel of the DGC-2020ES as it is going through its power up and initializing sequence.
  6. Initializing Message 2 - This parameter defines the second line of text that appears on the front panel of the DGC-2020ES as it is going through its power up and initializing sequence.

Figure 5. Settings Explorer, General Settings, Front Panel HMI Screen

## Remote Display Panel (optional)

Applications that require remote annunciation can use Basler Electric's Remote Display Panel. This device provides remote indication of many pre-alarm and alarm conditions.

The following pre-alarm conditions are indicated by LEDs on the Remote Display Panel:

- High coolant temperature
- Low coolant temperature
- Low oil pressure
- Low fuel level\*
- Weak battery
- Battery overvoltage†
- Battery charger failure\*†

The following alarm conditions are indicated by LEDs and an audible alarm on the Remote Display Panel:

- Low coolant level\*
- High coolant temperature
- Low oil pressure

- Overcrank
- Overspeed
- Emergency stop activated
- Fuel leak/Sender failure\*†
- Sender failure†

\* This can be configured in the DGC-2020ES as *None*, *Alarm*, or *Pre-alarm*. See the *Contact Inputs* chapter for more information. The LED on the Remote Display Panel illuminates when the input that is assigned to the programmable function is closed, whether the function is configured as *None*, *Alarm*, or *Pre-alarm*.

† This LED can be reprogrammed in the DGC-2020ES to suit the needs of a particular application. The condition listed above is annunciated by default.

Additionally, the Remote Display Panel indicates when the DGC-2020ES is not operating in Auto mode and when the generator is supplying load or when the DGC-2020ES is in an alarm state not listed above.

Refer to Basler Publication 9318100990 for more information on the Remote Display Panel.

See the *Terminals and Connectors* chapter for more information on connecting the Remote Display Panel to the DGC-2020ES.



# Power Input

Operating power for the DGC-2020ES is typically supplied by the genset starter battery. Power from the battery is supplied to an internal power supply that provides power for DGC-2020ES logic, protection, and control functions.

## ***Nominal Voltage Input and Acceptable Range of Input Voltage***

---

A nominal voltage of 12 or 24 Vdc within a range of 6 to 32 Vdc is accepted. Operating power must be of the correct polarity. Although reverse polarity will not cause damage, the DGC-2020ES will not operate.

## ***Terminal Assignments***

---

Input power is applied to terminals 18 (BATT+), 17 (BATT-), and 16 (CHASSIS).

## ***Power Consumption***

---

The amount of power consumed by the DGC-2020ES varies based on the selected mode. The power saving Sleep mode consumes 4.5 W with all relays de-energized. The Normal Operational Mode consumes 6.5 W in Run mode with the LCD heater off and 3 relays energized. The Maximum Operational Mode consumes 14 W in Run mode with the LCD heater on and 7 relays energized.

## ***Battery Ride-Through Capability***


---

Starting at 10 Vdc, withstands cranking ride-through down to 0 Vdc for 50 milliseconds.

## ***Fuse Protection***

---

To follow UL guidelines, a 5 A maximum, 32 Vdc supplementary fuse must be implemented in the battery input circuit to the DGC-2020ES.



# Voltage and Current Sensing

The DGC-2020ES senses generator voltage, generator current, and bus voltage through dedicated, isolated inputs.

## Generator Voltage

The DGC-2020ES accepts either line-to-line or line-to-neutral generator sensing voltage over the range of 12 to 576 volts, rms line-to-line. Single-phase generator voltage is sensed across phases A and B. Generator voltage sensing terminals are listed in Table 2.

**Table 2. Generator Voltage Sensing Terminals**

Terminal	Description
40 (GEN VN)	Neutral generator voltage sensing input
41 (GEN VC)	C-phase generator voltage sensing input
43 (GEN VB)	B-phase generator voltage sensing input
45 (GEN VA)	A-phase generator voltage sensing input

## Bus Voltage

Bus sensing over the range of 12 to 576 volts rms line-to-line is accepted by the DGC-2020ES. Sensing of bus voltage enables the DGC-2020ES to detect failures of the mains (utility). Controllers with style number xx2 measure bus voltage sensing to perform automatic mains failure transfers. Single-phase bus voltage is sensed across phases A and B. Bus voltage sensing terminals are listed in Table 3.

**Table 3. Bus Voltage Sensing Terminals**

Terminal	Description
46 (BUS VA)	A-phase bus voltage sensing input
48 (BUS VB)	B-phase bus voltage sensing input
50 (BUS VC)	C-phase bus voltage sensing input

## Generator Current

The DGC-2020ES has sensing inputs for A-phase, B-phase, and C-phase generator current. Depending on the style number, a DGC-2020ES has a nominal sensing current rating of 1 Aac or 5 Aac. A style number of 1xx indicates 1 Aac nominal current sensing and a style number of 5xx indicates 5 Aac nominal current sensing. Generator current sensing terminals are listed in Table 4.

**Table 4. Generator Current Sensing Terminals**

Terminal	Description
38 (IA+)	A-phase generator current sensing input
37 (IA-)	
36 (IB+)	B-phase generator current sensing input
35 (IB-)	
34 (IC+)	C-phase generator current sensing input
33 (IC-)	

**Note**

Unused current sensing inputs should be shorted to minimize noise pickup.

**Caution**

Generator current sensing terminals 37 (IA-), 35 (IB-), and 33 (IC-) must be terminated to ground for proper operation.

# Engine Sender Inputs

The DGC-2020ES has sender inputs dedicated to monitoring the engine fuel level, oil pressure, and coolant temperature. These inputs are programmable to give the user flexibility in selecting the sender to be used in an application. Information about programming sender inputs is provided later in this chapter.

## Connections

---

Oil pressure sender connections are made at terminals 8 and 11 (sender common). Fuel Level sender connections are made at terminals 9 and 11. Coolant Temperature sender connections are made at terminals 10 and 11.

## Compatible Senders

---

Oil pressure senders that are compatible with the DGC-2020ES include Datcon model 02505-00, Isspro model R8919, Stewart-Warner models 279BF, 279C, 411K and 411M, and VDO models 360025 and 360811. Compatible Fuel Level senders include the Isspro model R8925. Compatible Coolant Temperature senders include Datcon model 02019-00, Faria model TS4042, Isspro model, R8959, and Stewart-Warner model 334P. Other senders may also be used.

## Operation

---

A current is provided to each sender. The developed voltage is measured and scaled for use by the internal circuitry. An open circuit or short circuit across the sender terminals will cause the DGC-2020ES to indicate a failed sender.

## Sender Programmability

---

BESTCOMSP*lus*<sup>®</sup> software allows for the programming of sender characteristics. See *Sender Characteristic Curves*, below, for more information.

## Sender Characteristic Curves

---

The sender inputs of the DGC-2020ES can be customized to obtain maximum accuracy from the coolant temperature, oil pressure, and fuel level senders.

The characteristic curve of each sender input can be configured with up to 11 points. Each point can be assigned a resistance input value and a corresponding temperature (coolant temperature sender), pressure (oil pressure sender), or percentage (fuel level sender) value. A sender slope setting automatically orders the values in the resistance column according to whether the sender requires a negative or positive slope. Sender curve points are automatically plotted on a curve in BESTCOMSP*lus*, which can be printed.

Sender curve points configured in BESTCOMSP*lus* can be saved in the configuration file. The data for all three senders is automatically saved with the DGC-2020ES configuration file.

Any changes made in BESTCOMSP*lus* to the sender points, can be reverted to the factory-default values. A new settings file can also be created.


### Curve Configuration

If the DGC-2020ES receives engine information from an ECU, the programmable sender parameters for coolant temperature and oil pressure do not require configuration because they have no effect. Configuration of sender parameters is appropriate for resistive senders only.

### Fuel Level

Figure 6 illustrates the *Fuel Level* screen found in the *BESTCOMSPPlus Settings Explorer* under the *Programmable Senders* category. To program the fuel level sender, perform the following procedure:

1. The percent fuel level sender is configured by selecting one of the sender types that come as a part of the *BESTCOMSPPlus* sender library. Click on *Load Fuel Settings File* and select the appropriate sender.
2. If no sender file matches the sender being used, the individual points that map resistance points to fuel level may be modified by setting numeric values in the table, or dragging the points of the graph to the desired characteristic. Information on sender characteristics should be obtained from the sender manufacturer.
3. Select *Positive* or *Negative* sender slope as required for the desired sender graph.
4. Click *Save Fuel Data* to save the data in the current settings file.
5. If you want to save newly entered sender data as a sender library file, click *Create Fuel Settings File* and enter a file name and location to save the file.
6. Click the *Send Settings* button in *BESTCOMSPPlus* to send the sender settings to the DGC-2020ES.



**Figure 6. Settings Explorer, Programmable Senders, Fuel Level Screen**

### Oil Pressure

Figure 7 illustrates the *Oil Pressure* screen found in the *BESTCOMSPlus Settings Explorer* under the *Programmable Senders* category. To program the oil pressure sender, perform the following procedure:

1. The oil pressure sender can be configured by selecting one of the sender types that come as a part of the *BESTCOMSPlus* sender library. Click on *Load Oil Settings File* and select the appropriate sender.
2. If no sender file matches the sender being used, the individual points that map resistance points to oil pressure may be modified by setting numeric values in the table, or dragging the points of the graph to the desired characteristic. Information on sender characteristics should be obtained from the sender manufacturer.
3. Select *Positive* or *Negative* sender slope as required for the desired sender graph.
4. Click *Save Oil Data* to save the data in the current settings file.
5. If you want to save newly entered sender data as a sender library file, click *Create Oil Settings File* and enter a file name and location to save the file.
6. Click the *Send Settings* button in *BESTCOMSPlus* to send the sender settings to the DGC-2020ES.




Figure 7. Settings Explorer, Programmable Senders, Oil Pressure Screen

### Coolant Temperature

Figure 8 illustrates the *Coolant Temperature* screen found in the *BESTCOMSPPlus Settings Explorer* under the *Programmable Senders* category. To program the fuel level sender, perform the following procedure:

1. The coolant temperature sender can be configured by selecting one of the sender types that come as a part of the *BESTCOMSPPlus* sender library. Click on *Load Cool Settings File* and select the appropriate sender.
2. If no sender file matches the sender being used, the individual points that map resistance points to coolant temperature may be modified by setting numeric values in the table, or by dragging the points of the graph to the desired characteristic. Information on sender characteristics should be obtained from the sender manufacturer.
3. Select *Positive* or *Negative* sender slope as required for the desired sender graph.
4. Click *Save Cool Data* to save the data in the current settings file.
5. If you want to save newly entered sender data as a sender library file, click *Create Cool Settings File* and enter a file name and location to save the file.
6. Click the *Send Settings* button in *BESTCOMSPPlus* to send the sender settings to the DGC-2020ES.




Figure 8. Settings Explorer, Programmable Senders, Coolant Temperature Screen

## Sender Failure Detection

The DGC-2020ES can be configured to annunciate a pre-alarm or alarm when a loss of signal is detected at the coolant temperature, oil pressure, or fuel level sender input. The speed sender fail alarm is always enabled. A user-adjustable time delay is provided for each sender/sensing alarm/pre-alarm.

Alarm and pre-alarm annunciations for loss of engine speed signals are not user-programmable and operate as follows. If the MPU (magnetic pickup) or generator frequency is programmed as the sole engine speed source and that signal source fails, an alarm (and shutdown) is triggered. If the engine speed source is configured as MPU and generator frequency and a loss of one of the signal sources occurs, a pre-alarm is annunciated. An alarm (and shutdown) is triggered if both speed signals are lost.

The BESTCOMSPlus Sender Fail screen is illustrated in Figure 9 and is found in the *Settings Explorer* under *Alarm Configuration*. If using the front panel, navigate to Settings > Alarm Configuration > Sender Fail.

Sender Type	Alarm Configuration	Activation Delay
Coolant Temp Sender Fail	None	5 (min)
Oil Pressure Sender Fail	None	10 (s)
Fuel Level Sender Fail	None	10 (s)
Voltage Sensing Fail	None	10 (s)
Speed Sender Fail	(Not applicable)	10 (s)

Figure 9. Settings Explorer, Alarm Configuration, Sender Fail Screen



# Speed Signal Inputs

The DGC-2020ES uses signals from the generator voltage sensing inputs and magnetic pickup (MPU) input to detect machine speed.

## ***Magnetic Pickup***

---

Voltage supplied by a magnetic pickup is scaled and conditioned for use by the internal circuitry as a speed signal source. The MPU input accepts a signal over the range of 3 to 35 volts peak and 32 to 10,000 hertz.

### **Terminals**

Magnetic pickup connections are provided at terminals 31 (+) and 32 (-).

## ***Generator Sensing Voltage***

---

The generator voltage sensed by the DGC-2020ES is used to measure frequency and can be used to measure machine speed.

### **Terminals**

Sensing voltage is applied to terminals 45 (A-phase), 43 (B-phase).



# Contact Inputs

Contact inputs are available to initiate DGC-2020ES actions. The DGC-2020ES has seven programmable contact sensing inputs. Additional contact inputs can be accommodated with an optional CEM-2020 (Contact Expansion Module). Contact Basler Electric for availability and ordering information.

## Programmable

Each programmable input (Input 1 through Input 7) can be independently configured to perform the following functions. By default, each programmable input is disabled.

- Auto Transfer Switch
- Battery Charger Fail
- Battle Override
- Emergency Stop
- Fuel Leak Detect
- Grounded Delta Override
- Low Coolant Level
- Low Fuel Level
- Low Line Override
- Single-Phase Override

The programmable inputs accept dry contacts. A contact is connected between a programmable input and the negative side of the battery. Through *BESTCOMSPPlus*<sup>®</sup>, each programmable contact input can be assigned a name (16 alphanumeric characters, maximum) and configured as an alarm input, a pre-alarm input, or none. The default names for the inputs are INPUT\_x (where x = 1 to 7). When a programmable contact input is closed, the front panel display shows the name of the closed input if it was programmed as an alarm or pre-alarm input. Alarm inputs are annunciated through the Normal display mode screens of the front panel. Pre-alarm inputs are annunciated through the pre-alarm metering screen of the front panel. If neither alarm nor pre-alarm is programmed, no indication is given. Programming an input as *None* is useful when a programmable input is used as an input to programmable logic.

Connections for the programmable inputs are provided at terminals 3 (Input 1) through 9 (Input 7). The negative side of the battery voltage (terminal 17) serves as the return connection for the programmable inputs.

## Contact Input Configuration

Figure 10 illustrates the *Contact Inputs* screen found in the *BESTCOMSPPlus Settings Explorer* under the *Programmable Inputs* category. If using the front panel, navigate to Settings > Programmable Inputs > Configurable Inputs.

For each contact input, configure the following parameters:

1. Alarm Configuration - Select *None*, *Alarm*, or *Pre-Alarm*. When an alarm occurs, the horn output closes and the engine shuts down. When a pre-alarm occurs, the horn output toggles between open and closed while the engine remains running. If *None* is selected, the input is status only. The status is available to *BESTLogic™Plus* Programmable Logic regardless of *Alarm Configuration* setting.
2. Activation Delay - This parameter defines the duration that the input remains on before any annunciation occurs.
3. Label Text - Enter descriptive text that signifies the use of the input. This text appears next to the input in *BESTLogic™Plus* Programmable Logic and in the event log if the input is configured as an alarm or pre-alarm.
4. Contact Recognition - Select whether the contact input should be recognized always, or only while the engine is running. For example, a switch closes when oil pressure is low. Such a switch would be closed when the engine is not running but a low oil pressure alarm or pre-alarm should not be annunciated unless the switch is closed while the engine is running. A selection of *While Engine Running Only* prevents spurious annunciation when the engine is not running.

The screenshot shows a web-based configuration interface titled "Contact Inputs". It contains seven distinct panels, each representing a contact input from Input #1 to Input #7. Each panel is structured as follows:

- Input #1:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 1; Contact Recognition: Always.
- Input #2:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 2; Contact Recognition: Always.
- Input #3:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 3; Contact Recognition: Always.
- Input #4:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 4; Contact Recognition: Always.
- Input #5:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 5; Contact Recognition: Always.
- Input #6:** Alarm Configuration: None; Activation Delay (s): 0; Label Text: INPUT 6; Contact Recognition: Always.
- Input #7:** Alarm Configuration: (partially visible); Activation Delay (s): (partially visible); Label Text: (partially visible); Contact Recognition: (partially visible).

Figure 10. Settings Explorer, Programmable Inputs, Contact Inputs Screen

## Programmable Functions

Any of the seven contact inputs can be programmed to recognize any one of 10 function types:

- Automatic Transfer Switch (ATS) - Start and run the generator while the ATS input is true and the DGC-2020ES is in Auto mode.
- Grounded Delta Override - Uses Grounded Delta sensing if the generator connection is set for Delta.
- Battle Override - The alarms programmed to shut down the unit will be overridden and ignored.
- Low-Line Override - The 51, 27, and 59 settings are scaled by the low-line scale factor setting.
- Single-Phase Override - The unit switches to single-phase sensing configuration and uses the 1 Phase Override Sensing setting (A-B or A-C).
- Emergency Stop - Opens the Start, Run, and Fuel output relays and an ESTOP alarm is annunciated.
- Battery Charger Fail - When the selected input is invoked, a user selectable pre-alarm or alarm is annunciated after the activation delay.
- Low Coolant Level - When the selected input is invoked, a Low Coolant Level pre-alarm or alarm is annunciated after the activation delay.
- Low Fuel Level - When the selected input is invoked, a Low Fuel Level pre-alarm or alarm is annunciated after the activation delay.
- Fuel Leak Detect - When the selected input is invoked, a Fuel Leak pre-alarm or alarm is annunciated after the activation delay.

An Alarm Configuration setting of “None” prevents a function from being triggered by a contact input. Programmable function status is available in BESTlogic™ Plus Programmable Logic when the “None” alarm configuration setting is selected.

The *Programmable Functions* screen is found in the BESTCOMS Plus *Settings Explorer* under the *Programmable Inputs* category. If using the front panel, navigate to Settings > Programmable Inputs > Programmable Functions.

The BESTCOMS Plus Programmable Functions screen is illustrated in Figure 11.

The screenshot shows the 'Programmable Functions' configuration screen. It contains ten individual function settings, each with its own set of controls:

- Auto Transfer Switch:** Input: None, Contact Recognition: Always
- Grounded Delta Override:** Input: None, Contact Recognition: Always
- Battle Override:** Input: None, Contact Recognition: Always
- Low Line Override:** Input: None, Contact Recognition: Always
- Single Phase Override:** Input: None, Contact Recognition: Always
- Emergency Stop:** Input: None
- Battery Charger Fail:** Input: None, Alarm Configuration: None, Activation Delay (s): 0, Contact Recognition: Always
- Low Coolant Level:** Input: None, Alarm Configuration: None, Activation Delay (s): 0, Contact Recognition: Always
- Fuel Leak Detect:** Input: None, Alarm Configuration: None, Activation Delay (s): 0, Contact Recognition: Always
- Low Fuel Level:** Input: None, Alarm Configuration: None, Activation Delay (s): 0, Contact Recognition: Always

Figure 11. Settings Explorer, Programmable Inputs, Programmable Functions



# Contact Outputs

Output contact operation is controlled by the operating mode of the DGC-2020ES. The state of the Emergency Stop contact input also affects output contact operation. When the Emergency Stop contact input is open (emergency stop condition), the PRESTART, START, and RUN outputs open and an emergency stop alarm is annunciated. When the Emergency Stop input is closed, all output contacts operate normally.

DGC-2020ES output contacts include PRESTART, START, RUN, and four programmable outputs. Additional output contacts can be accommodated with an optional CEM-2020 (Contact Expansion Module).

## ***Prestart***

---

This output closes to energize the engine glow plugs or run pre-lubrication pumps. The PRESTART output can be programmed to close up to 30 seconds prior to engine cranking. The PRESTART output can also be programmed to open upon engine startup or remain closed as long as the engine is operating.

During the resting state, the PRESTART output can be set to Off, On, or Preheat Before Crank. If Preheat Before Crank is selected, the PRESTART output will be closed for a time equal to the Pre-crank delay time prior to re-entering the cranking state. If the Pre-crank delay setting is longer than the rest interval, the PRESTART output will be closed for the entire rest time.

PRESTART output connections are made through terminals located on the PRESTART relay.

## ***Start***

---

This output closes when engine cranking is initiated by the DGC-2020ES and opens when the magnetic pickup (MPU) or generator frequency indicates that the engine has started. Prior to engine starting, the duration of cranking is determined by the cranking style (cycle or continuous) selected. Cycle cranking permits up to seven crank cycles with crank cycle duration of 5 to 15 seconds. The continuous crank time is adjustable from 5 to 60 seconds.

START output connections are made through terminals located on the START relay.

## ***Run***

---

This output closes when engine cranking is initiated by the DGC-2020ES. The RUN output remains closed until it receives a command to stop the engine.

RUN output connections are made through terminals located on the RUN relay.

## ***Relay Control***

---

In some applications, it may be beneficial to modify the standard operation of the DGC-2020ES Run, Pre-Start, or Start relays. If desired, these relays can be configured to operate outside their predefined functionality. For example, if your genset does not require starting assistance from glow plugs, the Pre-Start relay may be assigned for another purpose. Configuring these relays as programmable makes them available in BESTlogic™ Plus programmable logic to be used in the same manner as the other programmable relay outputs. Predefined or programmable operation of the Run, Pre-Start, and Start relays is selected on the Relay Control screen (Figure 12). See the BESTlogic Plus chapter for more information about DGC-2020ES programmable logic.

The Relay Control screen is found in the BESTCOMS Plus® Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Relay Control.




Figure 12. Settings Explorer, System Parameters, Relay Control Screen

For each relay (Start, Run, and Pre-Start), select whether it should use its predefined functionality or be made programmable.

When *Programmable* is selected for a relay, it becomes available to BESTlogicPlus Programmable Logic as a logic element. The elements are titled *Start Output*, *Prestart Out*, and *Run Output*. The predefined functionality is available as an input to the logic. If *Programmable* is selected as the relay control mode, connecting the corresponding predefined input function to the relay causes it to function as if *Predefined* were selected as its relay control type. However, other logic can be combined with it to create operation that is more versatile. If *Programmable* is selected for a relay, but it is not used in the logic, that relay will never close.

An example logic scheme connecting the predefined inputs directly to the “programmable” relay outputs for all three relays is shown in Figure 13.




Figure 13. Example Logic Scheme of Programmable Relays

## Programmable

DGC-2020ES controllers have four programmable output contacts (OUT 1 through 4). An additional 24 contact outputs are provided with an optional CEM-2020 (Contact Expansion Module). An optional CEM-2020H (Contact Expansion Module - High Current) provides 18 contact outputs.

### Programmable Output Configuration

Figure 14 illustrates the *Contact Outputs* screen found in the BESTCOMSPlus *Settings Explorer* under the *Programmable Outputs* category. If using the front panel, navigate to Settings > Programmable Outputs > Contact Outputs.

Each output can be programmed with a text label describing its use. This label appears in BESTlogicPlus Programmable Logic where the output is used to aid in program clarity and ease of programming.

The screenshot shows a configuration window titled "Contact Outputs" with a light beige background. It contains four distinct configuration boxes. Each box is headed by a label "Output #1" through "Output #4" in blue text. Below each heading is the text "Label Text" in a smaller font, followed by a white text input field. The input fields contain the text "OUTPUT 1", "OUTPUT 2", "OUTPUT 3", and "OUTPUT 4" respectively. The boxes are arranged in two rows: the first row contains Output #1, #2, and #3; the second row contains Output #4.

Figure 14. Settings Explorer, Programmable Outputs, Contact Outputs

## Configurable Elements

Configurable elements are connected to the logic scheme as outputs. The configurable elements are incorporated into a *BESTlogicPlus* programmable logic scheme by selecting them from the *Elements* group in *BESTlogicPlus*. For more details, refer to the *BESTlogicPlus* chapter. Each of the eight elements can be independently configured to annunciate an alarm or pre-alarm. A user-adjustable time delay can be set to delay recognition of an element. By default, all elements are configured so that they do not trigger an alarm or pre-alarm. To make identifying an element easier, each of the elements can be given a user-assigned name. If used for an alarm or pre-alarm, the user-assigned name appears in the alarm or pre-alarm annunciation and in the DGC-2020ES event log. Elements can be recognized always or only while the engine is running. Configurable element status is available in *BESTlogicPlus* Programmable Logic when "None" is selected for Alarm Configuration. Configurable element status can be used as logic inputs to drive other logic in the program, similar to logic control relays.

The *BESTCOMSPlus Configurable Elements* screen is illustrated in Figure 15 and found in the *Settings Explorer* under the *Programmable Outputs* category. If using the front panel, navigate to *Settings > Programmable Outputs > Configurable Elements*.

### Configurable Elements

<p><b>Configurable Element #1</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 1</p> <p>Contact Recognition Always</p>	<p><b>Configurable Element #2</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 2</p> <p>Contact Recognition Always</p>	<p><b>Configurable Element #3</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 3</p> <p>Contact Recognition Always</p>
<p><b>Configurable Element #4</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 4</p> <p>Contact Recognition Always</p>	<p><b>Configurable Element #5</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 5</p> <p>Contact Recognition Always</p>	<p><b>Configurable Element #6</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 6</p> <p>Contact Recognition Always</p>
<p><b>Configurable Element #7</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 7</p> <p>Contact Recognition Always</p>	<p><b>Configurable Element #8</b></p> <p>Alarm Configuration None</p> <p>Activation Delay (s) 0</p> <p>Label Text CONFIG ELEMENT 8</p> <p>Contact Recognition Always</p>	

Figure 15. Settings Explorer, Programmable Outputs, Configurable Elements

# Operating Modes

Three operating modes provide the versatility to meet the application's needs. The DGC-2020ES operates in Off, Run, or Auto mode. These operating modes are described in the following paragraphs.

## **Off**

---

In OFF mode, the DGC-2020ES will not start under any circumstance. It cannot be started automatically. Programmable logic functions normally in this mode.

## **Run**

---

In RUN (manual) mode, the DGC-2020ES runs and cannot be shut off automatically. The breaker can be opened or closed through programmable logic inputs. Programmable logic functions normally in this mode.

## **Auto**

---

In AUTO mode, the DGC-2020ES may be started automatically or “self-start” from an automatic starting feature described in the following paragraphs. If the DGC-2020ES is not in AUTO mode, the self-starting modes will have no effect. The self-starting modes are independent, meaning that if any self-starting mode indicates that the unit should run, it will run. It will not shut down unless all self-starting modes indicate that the unit should not be running.

### **ATS Contact Input**

The ATS (automatic transfer switch) programmable function has an input mapped to it through BESTCOMSP<sup>Plus</sup>®. The unit will start and run when this contact is closed, and will stop when the contact is open.

### **Generator Exerciser**

The unit starts at the designated time and runs for the specified duration. The breaker will be closed if “Run with Load” is checked in the generator exerciser settings.

### **Mains Fail Transfer Functionality**

If mains fail transfer is enabled, the unit runs when any phase of the utility is dead or unstable, and will not stop until all phases of the utility are stable and the load has been transitioned to the utility.

### **Run-with-Load Logic Element**

When the run-with-load logic element start input is energized, the unit starts and closes its breaker. When the run-with-load logic element stop input is energized, the unit opens its breaker and stops.

### **Engine Run Logic Element**


When the engine run logic element start input is energized, the unit starts. When the engine run logic element stop input is energized, the unit opens its breaker if needed, cools down, and then stops.

## **Operating Mode Control**

---

Controls for selecting operating mode are located on the front panel and within BESTCOMSP<sup>Plus</sup>.

Refer to the *Controls and Indicators* chapter for more information.



# Breaker Management

The DGC-2020ES is capable of controlling the generator breaker and the mains breaker. Once it is determined that a valid breaker request is available, the DGC-2020ES will attempt to operate the breaker if possible. The user can choose to control only the generator breaker, the generator and mains breakers, or none. BESTCOMSP<sup>Plus</sup>® is used to configure breaker management. Refer to the BESTCOMSP<sup>Plus</sup> chapter for setting information.

## **Breaker Status**

---

The status of the breakers is determined by using BESTlogic™ *Plus* programmable logic and sent to the GENBRK and MAINSBRK logic blocks. These logic blocks have outputs that can be configured to energize an output contact and control a breaker as well as inputs for breaker control and status. See *Breaker Configuration*, below, for details on configuring the logic.

## **Breaker Operation**

---

The DGC-2020ES will attempt to close a breaker only after verifying that it can be closed. If the breaker cannot be closed, the close request will be ignored. Only one breaker can be closed at a time. Closure to a dead bus can be performed after meeting dead bus threshold and timing requirements set by the user.

### **Breaker Operation Requests**

Types of breaker operation requests include:

- Local Request - initiated by internal functions and based on operating modes.
- Com Request - initiated through a communication port using BESTCOMSP<sup>Plus</sup> or the front panel.
- Logic Request - initiated from BESTlogic<sup>Plus</sup>.

The type of response given for a local request depends on the operating mode of the DGC-2020ES.

#### *RUN Mode*

When in RUN mode, the generator and mains breakers can be closed manually using contact inputs or the breaker operation settings on the BESTCOMSP<sup>Plus</sup> *Control* screen.

#### *OFF or AUTO Mode (Not Running)*

If operating in the OFF mode or AUTO and not running, the generator breaker can be closed if the bus is determined to be dead.

#### *AUTO Mode (Running)*

When in AUTO mode and running, the mains fail transfer feature will automatically control the mains breaker and the generator breaker. Or, the external ATS (automatic transfer switch) will start the generator and control the breakers itself. In addition, the generator breaker can be automatically controlled by the exercise timer function or a RUNWLOAD (run with load) start through BESTlogic<sup>Plus</sup>. The generator breaker can be manually controlled using contact inputs and outputs or the breaker operation settings on the BESTCOMSP<sup>Plus</sup> *Control* screen.

### **Breaker Closure Conditions**

The conditions under which the DGC-2020ES will close a breaker are described in the following paragraphs.

#### *Breaker Status and Voltage Stability*

Before the generator breaker can be closed, it must be configured in BESTCOMSP<sup>Plus</sup>. If only the generator breaker is configured (mains breaker not configured) the DGC-2020ES reads user settings to determine if the generator side of the breaker is stable or dead and the bus side is dead. If both the

generator and the mains breakers are configured and open, the DGC-2020ES closes the generator breaker if the generator side of the breaker is stable or dead. If both breakers are configured and the mains breaker is closed, the DGC-2020ES will not close the generator breaker.

Before the mains breaker can be closed, it must be configured in *BESTCOMSPlus*. If both the mains and the generator breakers are configured and open, the DGC-2020ES will close the mains breaker if the mains side of the breaker is stable. If both breakers are configured and the generator breaker is closed, the DGC-2020ES will not close the mains breaker.

#### Command Agreement

A breaker will not change state if it receives conflicting commands. In other words, if an input is indicating an open command at the same time another input is indicating a close command, the breaker will not change state.

## **Breaker Configuration**

---

The following paragraphs describe how to properly configure a DGC-2020ES for generator breaker control.

### **Initial System Setup**

Connect the DGC-2020ES according to the appropriate figure in the *Typical Connections* chapter for the type of generator connection desired (wye, delta, etc.).

Set up the basic system parameters that will govern engine operation and alarm and pre-alarm annunciation. Details can be found in the *Configuration* chapter.

### **Breaker Hardware**

Configure the generator breaker parameters on the *BESTCOMSPlus Settings Explorer, Breaker Management, Breaker Hardware* screen. If using the front panel, navigate to Settings > Breaker Management > Breaker Hardware. Figure 16 illustrates the *BESTCOMSPlus* Breaker Hardware screen.

1. *Breaker Close Wait Time*: This is a time interval in which it is expected that the breaker will transition from open to closed or closed to open. If the generator breaker does not change state within that time, either a Gen Breaker Close Fail alarm or Gen Breaker Open Fail alarm is annunciated. If the mains breaker does not change state within that time, either a Mains Breaker Close Fail alarm or Mains Breaker Open Fail alarm is annunciated.
2. *Generator Breaker*
  - a. Set the *Contact Type* and *Open/Close Pulse Times* if pulsed contacts are used.
  - b. Set the *Breaker Closing Time*.
3. *Mains Breaker*
  - a. Set the Mains Breaker as Configured if it is used, otherwise do not configure these settings.
  - b. If the mains breaker is configured, set the contact type and pulse times if pulsed contacts are used.
  - c. If the mains breaker is configured, set the breaker close time.

### Breaker Hardware

**Mains Fail**

**Mains Fail Transfer**

Disable

Enable

Mains Fail Transfer Delay (s)

Mains Fail Return Delay (s)

Mains Fail Max Transfer Time (s)

**Gen and Mains Breaker**

Breaker Close Wait Time (s)

**Generator Breaker Hardware**

**Gen Breaker**

NOT Configured

Configured

Open Pulse Time (s)

Close Pulse Time (s)

**Contact Type**

Pulse

Continuous

Breaker Closing Time (ms)

**Mains Breaker Hardware**

**Mains Breaker**

NOT Configured

Configured

Open Pulse Time (s)

Close Pulse Time (s)

**Contact Type**

Pulse

Continuous

Breaker Closing Time (ms)

Figure 16. Settings Explorer, Breaker Management, Breaker Hardware Screen

## Breaker Setup in BESTlogic™ Plus

Set up the Gen Breaker in BESTlogicPlus Programmable Logic under the BESTCOMSPPlus Settings Explorer, BESTlogicPlus Programmable Logic screen. BESTlogicPlus is not available through the front panel interface. Figure 17 illustrates the Gen breaker logic scheme in BESTlogicPlus.




Figure 17. Settings Explorer, BESTlogicPlus Programmable Logic Screen

### 1. Generator Breaker

- a. Drag the Gen Breaker element into the logic diagram.
- b. Connect the breaker element open and close outputs to the contact outputs that will drive the breaker.
- c. Connect the physical input or remote input that has the breaker status (closed if breaker is closed, open when the breaker is open) to the *Status* input of the breaker element. This is the only way to indicate breaker status to the DGC-2020ES.
- d. If it is desired to have physical inputs that can request breaker open and close commands, connect the desired inputs to the open and close command inputs of the breaker element. These inputs should be pulsed. If both inputs close at the same time, the breaker will not change state. If it is not desired to have inputs for breaker commands, connect a “Logic 0” input object to the open and close command inputs of the breaker block.

### 2. Mains Breaker (if configured)

- a. Drag the Mains Breaker element into the logic diagram.
- b. Connect the breaker element open and close outputs to the contact outputs that will drive the breaker.
- c. Connect the physical input or remote input that has the breaker status (closed if breaker is closed, open if the breaker is open) to the *Status* input of the breaker element. This is the only way to indicate breaker status to the DGC-2020ES.
- d. If it is desired to have physical inputs that can request breaker open and close commands, connect the desired inputs to the open and close command inputs of the breaker element. These inputs should be pulsed. If both inputs close at the same time, the breaker will not

change state. If it is not desired to have inputs for breaker commands, connect a “Logic 0” input object to the open and close command inputs of the breaker block.

3. Click the **Save** button when the logic setup is complete.
4. From the Communication pull-down menu, select *Upload Logic to Device* to load the logic into the DGC-2020ES if connected, or save the settings file if working off line.

## Bus Condition Detection

(These thresholds determine when the generator and bus are considered to be stable or dead.)

Set the parameters for detecting stable and failed bus and generator under the *BESTCOMSPlus Settings Explorer, Breaker Management, Bus Condition Detection*. If using the front panel, navigate to *Settings > Breaker Management > Bus Condition Detection*.

Figure 18 illustrates the *BESTCOMSPlus Bus Condition Detection* screen.

1. Generator Sensing
  - a. Dead Bus Voltage Threshold and Activation Delay. When the generator voltage is below this threshold for the duration of the activation delay, the generator is deemed “Dead”.
  - b. Gen Stable Overvoltage and Undervoltage thresholds and Overfrequency and Underfrequency thresholds and the Bus Stable and Bus Failed Activation Delay times. When the generator voltage frequency is within the specified range for the duration of the Bus Stable Activation Delay, the generator is deemed “Stable”. Otherwise, it is deemed “Failed”.
2. Bus Sensing
  - a. Dead Bus Voltage Threshold and Activation Delay. When the voltage of the bus is below this threshold for the duration of the activation delay, the bus is deemed “Dead”.
  - b. Bus Stable Overvoltage and Undervoltage thresholds and Overfrequency and Underfrequency thresholds and the Bus Stable and Bus Failed Activation Delay times. When the bus voltage and frequencies are within the specified ranges for the duration of the Bus Stable Activation Delay, the bus is deemed “Stable”. Otherwise, it is deemed “Failed”.

### Caution

The bus condition parameters are critical because they determine when a breaker can be closed. The generator breaker can be closed when any one of the following is true:

- The generator is stable, the bus is dead, and both breakers are open.
- The generator is dead, the bus is dead, and both breakers are open.

The mains breaker can be closed only when the bus is stable and both breakers are open.

### Bus Condition Detection

#### Generator Sensing

##### Generator Condition Settings

Dead Gen Threshold	Dead Gen Activation Delay (s)	Gen Failed Activation Delay (s)
30 V	0.1	0.1
0.063 Per Unit		

#### Generator Stable

##### Overvoltage Settings

Pickup (V L-L)	Dropout
130 V	127 V
0.271 Per Unit	0.265 Per Unit

##### Undervoltage Settings

Pickup (V L-L)	Dropout
115 V	117 V
0.240 Per Unit	0.244 Per Unit

##### Overfrequency Settings

Pickup	Dropout
62.00 Hz	61.80 Hz
1.033 Per Unit	1.030 Per Unit

##### Underfrequency Settings

Pickup	Dropout
58.00 Hz	58.20 Hz
0.967 Per Unit	0.970 Per Unit

Gen Stable Activation Delay (s)	Low Line Scale Factor	Alternate Frequency Scale Factor
0.1	1.000	1.000

#### Bus Sensing

##### Bus Condition Settings

Dead Bus Threshold	Dead Bus Activation Delay (s)	Bus Failed Activation Delay (s)
30 V	0.1	0.1
0.063 Per Unit		

#### Bus Stable

##### Overvoltage Settings

Pickup (V L-L)	Dropout
130 V	127 V
0.271 Per Unit	0.265 Per Unit

##### Undervoltage Settings

Pickup (V L-L)	Dropout
115 V	117 V
0.240 Per Unit	0.244 Per Unit

##### Overfrequency Settings

Pickup	Dropout
62.00 Hz	61.80 Hz
1.033 Per Unit	1.030 Per Unit

##### Underfrequency Settings

Pickup	Dropout
58.00 Hz	58.20 Hz
0.967 Per Unit	0.970 Per Unit

Bus Stable Activation Delay (s)	Low Line Scale Factor	Alternate Frequency Scale Factor
0.1	1.000	1.000

**Figure 18. Settings Explorer, Breaker Management, Bus Condition Detection**

Place the unit in AUTO. The unit is now configured for generator breaker control. It can be tested by driving the RUN WITH LOAD logic element true, setting up the exercise timer for a loaded test, or by starting the unit in RUN or AUTO mode and giving it CLOSE and OPEN commands from the physical inputs if they are available for breaker control.

Refer to the *Maintenance and Troubleshooting* chapter if the breaker does not seem to operate properly.

# Generator Protection

DGC-2020ES controllers offer standard protection consisting of undervoltage (27), overvoltage (59), overcurrent (50), overfrequency (81O), underfrequency (81U), and phase-imbalance voltage (47) elements.

The description of generator protection is organized as follows:

- Voltage (27, 59, 47)
- Frequency (81)
- Overcurrent (50)

## Voltage

Voltage protection consists of an undervoltage element, an overvoltage element, and a phase-sequence voltage element.

### Undervoltage (27)

Two sets of undervoltage settings are provided for this element: one for three-phase generator connections and one for single-phase generator connections. The pickup setting entered is based on the PT secondary side. When a single-phase override contact input is received, the DGC-2020ES automatically switches from the three-phase undervoltage settings to the single-phase undervoltage settings.

An undervoltage condition is annunciated when the average of the three-phase (three-phase mode) or the line-to-line voltage (single-phase mode) decreases below the corresponding 27 pickup setting for the duration of the corresponding 27 activation delay. An undervoltage annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). An undervoltage annunciation can also be user-configured to close a programmable output.

The hysteresis setting functions as an undervoltage dropout by preventing rapid switching of the pickup output.

A frequency-based inhibit setting prevents a 27 trip from occurring during an undervoltage condition associated with system startup.

A low-line scale factor setting is used to automatically adjust the undervoltage pickup settings in applications that may utilize more than one type of genset connection. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate low-line override. This triggers scaling of the protection settings. The value of the scale factor setting serves as a multiplier for the pickup settings. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the pickup setting will be doubled ( $2.000 \times \text{PU}$ ).

The element is disabled when Alarm Configuration is set to "None". Element status is available in BESTlogic™ Plus Programmable Logic when "Status Only" is selected.

Settings which are related to machine ratings can be set in either actual units of voltage or in per unit values. When a native unit is edited, BESTCOMSPlus® automatically recalculates the per unit value based on the native unit setting and the rated data parameter (on the *System Parameters, Rated Data* screen) associated with it. When a per unit value is edited, BESTCOMSPlus automatically recalculates the native value based on the per unit setting and the rated data parameter associated with it.

Once all per unit values are assigned, if the rated data parameters are changed, BESTCOMSPlus automatically recalculates all native unit settings based on the modified rated data parameters.

The following settings have native units of *Secondary Volts*, and the rated data associated with them is *Rated Secondary Volts* (on the *System Parameters, Rated Data* screen).

- Undervoltage 27 Three-Phase Pickup
- Undervoltage 27 Single-Phase Pickup

The *Undervoltage* screen is found in the *BESTCOMSPPlus Settings Explorer* under the *Generator Protection, Voltage* category. If using the front panel, navigate to *Settings > Generator Protection > 27 Undervoltage*. The *BESTCOMSPPlus Undervoltage* screen is illustrated in Figure 19.

**Figure 19. Settings Explorer, Generator Protection, Voltage, Undervoltage (27) Screen**

## Overvoltage (59)

Two sets of overvoltage settings are provided for this element: one for three-phase generator connections and one for single-phase generator connections. The pickup setting entered is based on the PT secondary side (DGC-2020ES). When a single-phase override contact input is received, the DGC-2020ES automatically switches from the three-phase overvoltage settings to the single-phase overvoltage settings.

An overvoltage condition is annunciated when the average of the three-phase (three-phase mode) or the line-to-line voltage (single-phase mode) increases above the corresponding 59 pickup setting for the duration of the corresponding 59 activation delay. An overvoltage annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). An overvoltage annunciation can also be user-configured to close a programmable output.

The hysteresis setting functions as an undervoltage dropout by preventing rapid switching of the pickup output.

A low-line scale factor setting is used to automatically adjust the overvoltage pickup settings in applications that may utilize more than one type of genset connection. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate low-line override. This triggers scaling of the protection settings. The value of the scale factor setting serves as a multiplier for the pickup settings. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the pickup setting will be doubled ( $2.000 \times \text{PU}$ ).

The element is disabled when Alarm Configuration is set to "None". Element status is available in *BESTlogicPlus* Programmable Logic when "Status Only" is selected.

Settings which are related to machine ratings can be set in either actual units of voltage or in per unit values. When a native unit is edited, *BESTCOMSPPlus* automatically recalculates the per unit value based on the native unit setting and the rated data parameter (on the *System Parameters, Rated Data* screen) associated with it. When a per unit value is edited, *BESTCOMSPPlus* automatically recalculates the native value based on the per unit setting and the rated data parameter associated with it.

Once all per unit values are assigned, if the rated data parameters are changed, *BESTCOMSPPlus* automatically recalculates all native unit settings based on the modified rated data parameters.

The following settings have native units of *Secondary Volts*, and the rated data associated with them is *Rated Secondary Volts* (on the *System Parameters, Rated Data* screen).

- Overvoltage 59 Three-Phase Pickup
- Overvoltage 59 Single-Phase Pickup

The *Overvoltage* screen is found in the *BESTCOMSPPlus Settings Explorer* under the *Generator Protection, Voltage* category. If using the front panel, navigate to Settings > Generator Protection > 59 Overvoltage. The *BESTCOMSPPlus* Overvoltage screen is illustrated in Figure 20.

The screenshot shows the 'Overvoltage' configuration screen. It features a '59 Element' section with a 'Low Line Scale Factor' of 1.000. Below this are two columns of settings: '3 Phase' and 'Single Phase'. Each column includes fields for Pickup (V L-L), Per Unit, Hysteresis (V), and Activation Delay (s), and a dropdown for Alarm Configuration (set to None).

Figure 20. Settings Explorer, Generator Protection, Voltage, Overvoltage (59) Screen

## Phase Imbalance (47)

DGC-2020ES controllers are capable of protecting against voltage imbalances between any of the three phases. The pickup setting entered is based on the PT secondary side. A phase imbalance condition is annunciated when the difference between any of the three phases of generator voltage increases above the 47 pickup setting for the duration of the 47 activation delay setting. A phase imbalance annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). A phase imbalance annunciation can also be user-configured to close a programmable output.

The hysteresis setting functions as a phase imbalance dropout by preventing rapid switching of the pickup output.

A low-line scale factor setting is used to automatically adjust the phase imbalance pickup setting in applications that may utilize more than one type of genset connection. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate the low-line override. This triggers scaling of the protection settings. The value of the scale factor setting serves as a multiplier for the pickup setting. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the pickup setting will be doubled ( $2.000 \times \text{PU}$ ).

The element is disabled when Alarm Configuration is set to "None". Element status is available in *BESTlogicPlus* Programmable Logic when "Status Only" is selected.

Settings which are related to machine ratings can be set in either actual units of voltage or in per unit values. When a native unit is edited, *BESTCOMSPPlus* automatically recalculates the per unit value based on the native unit setting and the rated data parameter (on the *System Parameters, Rated Data* screen) associated with it. When a per unit value is edited, *BESTCOMSPPlus* automatically recalculates the native value based on the per unit setting and the rated data parameter associated with it.

Once all per unit values are assigned, if the rated data parameters are changed, *BESTCOMSPPlus* automatically recalculates all native unit settings based on the modified rated data parameters.

The following setting has native units of *Secondary Volts*, and the rated data associated with it is *Rated Secondary Volts* (on the *System Parameters, Rated Data* screen).

- Phase Imbalance 47 Pickup

The *Phase Imbalance* screen is found in the *BESTCOMSPPlus Settings Explorer* under the *Generator Protection, Voltage* category. If using the front panel, navigate to *Settings > Generator Protection > 47 Phase Imbalance*. The *BESTCOMSPPlus Phase Imbalance* screen is illustrated in Figure 21.

The screenshot shows the 'Phase Imbalance' configuration screen for element '47 Element'. The settings are as follows:

- Pickup:** 5 V
- Per Unit:** 0.010
- Hysteresis (V):** 1
- Activation Delay (s):** 1.0
- Alarm Configuration:** None
- Low Line Scale Factor:** 1.000

**Figure 21. Settings Explorer, Generator Protection, Voltage, Phase Imbalance (47) Screen**

## Frequency

Two sets of frequency protection settings are provided: one for underfrequency (81U) and one for overfrequency (81O).

### Underfrequency (81U)

An underfrequency condition is annunciated when the generator frequency decreases below the 81U pickup setting for the duration of the 81U activation delay setting. An underfrequency annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). An underfrequency annunciation can also be user-configured to close a programmable output.

A voltage-based inhibit setting prevents an 81U trip from occurring during an underfrequency condition associated with system startup.

The hysteresis setting functions as an underfrequency dropout by preventing rapid switching of the pickup output.

### Overfrequency(81O)

When the generator frequency increases above the 81O pickup setting for the duration of the 81O activation delay setting, an overfrequency condition is annunciated. An overfrequency annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). An overfrequency condition can also be user configured to close a programmable output.

The hysteresis setting functions as an overfrequency dropout by preventing rapid switching of the pickup output.

The element is disabled when Alarm Configuration is set to "None". Element status is available in *BESTlogicPlus* Programmable Logic when "Status Only" is selected.

### Alternate Frequency Scale Factor

An alternate frequency scale factor setting is used for automatic adjustment of the frequency pickup settings in applications that may utilize more than one operating frequency. For example, a machine that is configurable between 50 or 60 Hz operation. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input that is connected to the Alternate Frequency Override

logic element in BESTlogicPlus Programmable Logic. When the Alternate Frequency Override is true, the scale factor setting serves as a multiplier for the pickup settings. For example, if an alternate frequency scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the pickup setting is doubled (2.000 x PU).

## Per Unit

Settings which are related to machine ratings can be set in either actual units of hertz or in per unit values. Per unit settings are available for Pickup (81O/81U) and Inhibit Volts (81U). When a native unit is edited, BESTCOMSPPlus automatically recalculates the per unit value based on the native unit setting and the rated data parameter (on the *System Parameters, Rated Data* screen) associated with it. When a per unit value is edited, BESTCOMSPPlus automatically recalculates the native value based on the per unit setting and the rated data parameter associated with it.

Once all per unit values are assigned, if the rated data parameters are changed, BESTCOMSPPlus automatically recalculates all native unit settings based on the modified rated data parameters.

The following settings have native units of *Frequency in Hz*, and the rated data associated with them is *Rated Frequency* (on the *System Parameters, Rated Data* screen).

- 81 U Pickup
- 81 O Pickup

The following setting has native units of *Secondary Volts*, and the rated data associated with it is *Rated Secondary Volts* (on the *System Parameters, Rated Data* screen).

- 81 U Inhibit Voltage

The *Frequency* screen is found in the BESTCOMSPPlus *Settings Explorer* under the *Generator Protection, Frequency* category. If using the front panel, navigate to Settings > Generator Protection > 81 O/U Frequency. The BESTCOMSPPlus Frequency screen is illustrated in Figure 22.

The screenshot displays the 'Frequency' settings screen in the BESTCOMSPPlus Settings Explorer. It is organized into two main columns for elements 81U and 81O. Each column contains input fields for Pickup (Hz and Per Unit), Hysteresis (Hz), and Activation Delay (s). The 81U column also includes an Inhibit Volts field (V and Per Unit) and an Alarm Configuration dropdown menu. At the bottom of the screen, there is an 'Alternate Frequency Scale Factor' field.

Element	Pickup (Hz)	Pickup (Per Unit)	Hysteresis (Hz)	Activation Delay (s)	Inhibit Volts (V)	Inhibit Volts (Per Unit)	Alarm Configuration
81U	58.0	0.967	0.5	1.0	70	0.146	None
81O	62.0	1.033	0.5	1.0	-	-	None

Alternate Frequency Scale Factor: 1.000

Figure 22. Settings Explorer, Generator Protection, Frequency, Frequency (81) Screen

## Overcurrent

Two sets of overcurrent settings are provided for this element: one for three-phase generator connections and one for single-phase generator connections. The pickup setting entered is based on the CT secondary side. When a single-phase override contact input is received by the DGC-2020ES, the overcurrent protection settings automatically switch from the three-phase settings to the single-phase overcurrent protection settings.

When any of the phase currents increase above the pickup setting for the duration of the overcurrent time delay, an overcurrent condition is annunciated. An overcurrent annunciation can be user-selected to trigger a pre-alarm (warning) or alarm (shutdown). An overcurrent annunciation can also be user-configured to close a programmable output.

A low-line scale factor setting is used for automatic adjustment of the overcurrent pickup settings in applications that may utilize more than one type of genset connection. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate low-line override. This triggers scaling of the protection settings. The value of the scale factor setting serves as a multiplier for the pickup settings. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the pickup setting will be doubled ( $2.000 \times \text{PU}$ ).

The element is disabled when Alarm Configuration is set to "None". Element status is available in BESTlogicPlus Programmable Logic when "Status Only" is selected.

Settings which are related to machine ratings can be set in either actual units of current or in per unit values. When a native unit is edited, BESTCOMSPlus automatically recalculates the per unit value based on the native unit setting and the rated data parameter (on the *System Parameters, Rated Data* screen) associated with it. When a per unit value is edited, BESTCOMSPlus automatically recalculates the native value based on the per unit setting and the rated data parameter associated with it.

Once all per unit values are assigned, if the rated data parameters are changed, BESTCOMSPlus automatically recalculates all native unit settings based on the modified rated data parameters.

The following settings have native units of *Secondary Amps*, and the rated data associated with them is *Rated Secondary Phase Amps* (on the *System Parameters, Rated Data* screen).

- Overcurrent 50 Three-Phase Pickup
- Overcurrent 50 Single-Phase Pickup

The *Overcurrent* screen is found in the BESTCOMSPlus *Settings Explorer* under the *Generator Protection, Current* category. If using the front panel, navigate to Settings > Generator Protection > 50 Overcurrent. The BESTCOMSPlus Overcurrent screen is illustrated in Figure 23.

The screenshot shows the 'Overcurrent' settings page. At the top, it says 'Overcurrent'. Below that, there's a section for '50 - Overcurrent'. Under this section, there's a 'Low Line Scale Factor' input field with the value '1.000'. Below that, there are two sections: '3 Phase' and 'Single Phase'. Each section has a 'Pickup' input field (both set to '5.00'), a 'Per Unit' input field (both set to '1.1085'), an 'Activation Delay (s)' input field (both set to '1.0'), and an 'Alarm Configuration' dropdown menu (both set to 'None').

Figure 23. Settings Explorer, Generator Protection, Current, Overcurrent

# Metering

The DGC-2020ES provides comprehensive metering of internal and system conditions. These capabilities include extensive parameter metering, status indication and reporting.

## Metering Explorer

DGC-2020ES metering is accessed through the metering explorer menu on the front panel display or the BESTCOMSPPlus® metering explorer.

### Front Panel

On the front panel, the metering explorer is accessed through the Metering branch of the menu. Refer to the *Controls and Indicators* chapter for more information.

### BESTCOMSPPlus®

In BESTCOMSPPlus, the metering explorer is located in the upper left portion of the application window.

### Metering Screen Docking

A docking feature within the metering explorer allows arrangement and docking of multiple metering screens. Clicking and dragging a metering screen tab displays a blue, transparent square, several arrow boxes, and a tab box. These docking elements are illustrated in Figure 24 and described in Table 5.





Figure 24. Metering Screen Docking Options

Table 5. Descriptions of Call-outs in Figure 24.

Call-Out	Symbol	Description
A		Holding the left mouse button down on a metering tab and dragging it to one of the four arrow boxes will place the metering tab inside the selected window on the location selected. To place the metering tab as a tab inside the selected window, drop it on the tabs button in the center of the arrow buttons.
B		Holding the left mouse button down on a metering tab and dragging it to this arrow box will place it across the top of the screen. Click on the  (thumbtack) to dock it on the top bar. To display a screen that is docked, simply use the mouse to hover the pointer over the tab on the top bar.
C		Holding the left mouse button down on a metering tab and dragging it to this arrow box will place it across the side of the screen. Click on the  (thumbtack) to dock it on the side bar. To display a screen that is docked, simply use the mouse to hover the pointer over the tab on the side bar.
D		Holding the left mouse button down on a metering tab and dragging it to this arrow box will place it across the bottom of the screen. Click on the  (thumbtack) to dock it on the bottom bar. To display a screen that is docked, simply use the mouse to hover the pointer over the tab on the bottom bar.
E		Holding the left mouse button down on a metering tab and dragging it anywhere other than an arrow box will place it as a floating metering screen. This floating screen can later be closed by clicking on the  in the upper right corner. It can also be dragged to one of the arrow boxes used for docking.

### BESTspace™

BESTspace provides the ability to manage customized workspaces. Refer to the *BESTCOMSPPlus* chapter for more information on BESTspace.

## Engine

The *Engine* metering screen (Figure 25) provides information and metering of engine components. Parameters that do not apply to your engine are marked as either NS (not sent) or NA (not applicable).

The *Engine* screen is found in the *BESTCOMSPPlus Metering Explorer*. If using the front panel, navigate to Metering > Engine.



Figure 25. Metering Explorer, Engine Screen

## Generator

This screen provides metering of generator voltages and currents. See Figure 26.

The *Generator* screen is found in the *BESTCOMSPlus Metering Explorer*. If using the front panel, navigate to Metering > Generator.




Figure 26. Metering Explorer, Generator Screen

## Power

This screen provides metering of generator power and power factor. See Figure 27.

The *Power* screen is found in the *BESTCOMSPlus Metering Explorer*. If using the front panel, navigate to Metering > Power.




Figure 27. Metering Explorer, Power Screen

## Run Statistics

This screen provides Cumulative Run Statistics, Session Run Statistics, and Commission Date. See Figure 28.

The Cumulative Run Statistics are tracked from the first time the genset was started. The Session Run Statistics are tracked from the last time the genset was started until the following shutdown.

The Number of Starts, Hours Until Maintenance, Total kWh, Total Engine Run Time, Loaded Run Time, and Unloaded Run time can be changed by clicking the *Edit Cumulative Run Statistics* button. This is helpful when installing the DGC-2020ES into a pre-existing system. This allows the current statistics of the genset to be transferred into the DGC-2020ES for uninterrupted tracking.

The Hours Until Maintenance pre-alarm is configured on the Pre-Alarms screen in the Settings Explorer. The Hours Until Maintenance field displays “OFF” when the Maintenance Interval pre-alarm is disabled. Clicking *Reset Maintenance Interval* resets the Hours Until Maintenance to the value set for the Maintenance Interval pre-alarm on the Pre-Alarms screen in the Settings Explorer.

To change the commission date, click *Edit DGC Commission Date*. The DGC Commission Date dialog box appears. Enter the new commission date and click *Upload Data to Device*. Click *Close*. Note that the Commission Date field on the BESTCOMSPlus screen updates after the *Close* button is clicked.

The *Run Statistics* screen is found in the BESTCOMSPlus *Metering Explorer*. If using the front panel, navigate to Metering > Run Statistics.



Figure 28. Metering Explorer, Run Statistics Screen

## Status Indication

This screen indicates status of breakers, modes, switches, and I/O connection status. The status is TRUE when the corresponding indicator is red. See Figure 29.

The *Status* screen is found in the BESTCOMSPlus *Metering Explorer*. If using the front panel, navigate to Metering > Alarms-Status > Status.




Figure 29. Metering Explorer, Status Screen

## Inputs

### Contact Inputs

This screen indicates the status of contact inputs, contact input alarms, and contact input pre-alarms. The status is TRUE when the corresponding indicator is red. See Figure 30.

The *Contact Inputs* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Inputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Inputs*.




Figure 30. Metering Explorer, Inputs, Contact Inputs Screen

### Remote Contact Inputs

When an optional CEM-2020 (Contact Expansion Module) is connected, the status of the remote contact inputs, configurable remote contact input alarms, and remote contact input pre-alarms are shown on this screen. The status is TRUE when the corresponding indicator is red. See Figure 31.

The *Remote Contact Inputs* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Inputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Inputs*.




Figure 31. Metering Explorer, Inputs, Remote Contact Inputs Screen

## Logic Control Relays

This screen indicates the status of logic control relays. The status is TRUE when the corresponding indicator is green. See Figure 32.

The *Logic Control Relays* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Inputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Logic Control Relays*.




Figure 32. Metering Explorer, Inputs, Logic Control Relays Screen

## Outputs

### Contact Outputs

This screen indicates the status of contact outputs. The status is TRUE when the corresponding indicator is green. See Figure 33.

The *Contact Outputs* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Outputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Outputs*.



Figure 33. Metering Explorer, Outputs, Contact Outputs Screen

### Remote Contact Outputs

When an optional CEM-2020 (Contact Expansion Module) is connected, the status of the remote contact outputs is shown on this screen. The status is TRUE when the corresponding indicator is green. See Figure 34.

The *Remote Contact Outputs* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Outputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Outputs*.




Figure 34. Metering Explorer, Outputs, Remote Contact Outputs Screen

### Configurable Elements

This screen indicates the status of configurable elements. It also indicates alarms and pre-alarms of configurable elements. The status is TRUE when the corresponding indicator is green. See Figure 35.

The *Configurable Elements* screen is found in the *BESTCOMSPlus Metering Explorer* under the *Outputs* category. If using the front panel, navigate to *Metering > Alarms-Status > Configurable Elements*.




Figure 35. Metering Explorer, Outputs, Configurable Elements Screen

## Control

Controls for stopping/starting the engine, opening/closing breakers, and opening/closing switches are accessed using *BESTCOMSPlus* through the *Metering Explorer, Control* screen. This set of controls is especially useful when commissioning the DGC-2020ES. The PC or laptop running *BESTCOMSPlus* must be connected to the DGC-2020ES via the USB port (see the *Communication* chapter for details). When running *BESTCOMSPlus* in *Live* mode, these buttons interact with the DGC-2020ES in real time. Otherwise, you will be prompted before the settings are sent.

Using the Metering Explorer in *BESTCOMSPlus*, open the *Control* branch. Refer to Figure 36.

### Emergency Stop

The user has control to stop the generator in case of emergency by clicking on the *Emergency Stop* button.

### Engine Control

The engine can be started and stopped by clicking on the *Start* and *Stop* buttons. This function requires a connection to a properly configured ECU via J1939 (CANbus).

### Run, Auto, Off

The operating mode can be set to Run, Auto, or Off.

### Generator and Mains Breakers

There are controls for opening and closing the generator breaker and mains breaker. The breaker is open when the corresponding indicator is green and closed when red. This function requires that the Generator and Mains breakers be configured.

### Switches 1 through 4

Each of these switches can be opened or closed by clicking on the *Open* or *Close* buttons. The switch is closed when the corresponding indicator is red. These buttons control the virtual inputs found in *BESTLogicPlus* Programmable Logic. The number of the switch corresponds to the number of the virtual input it controls. See the *BESTlogicPlus* chapter for more information.





Figure 36. Metering Explorer, Control Screen

## ***Auto Export Metering***

---

This function automatically exports metering data over a user-defined period when a DGC-2020ES connection is active. To display the Auto Export Metering screen, click the *Tools* pull-down menu from the upper menu bar and click *Auto Export Metering*. Specify the *Number of Exports* and the *Interval* between each export. Enter a filename for the metering data and a folder in which to save. The file is saved in .CSV (comma separated values) format. The first export is performed immediately after clicking the *Start* button. Click the *Filter* button to select specific metering screens.



# Reporting and Alarms

The DGC-2020ES monitors ECU data, generator protection functions, and engine senders. An alarm or pre-alarm is annunciated when the monitored parameter exceeds its threshold settings.

When an alarm condition exists, the engine is stopped by opening the Fuel output contact. An existing pre-alarm condition is annunciated only.

When alarms are active, the front panel *Overview* screen is replaced by the *Active Alarms* screen. When only pre-alarms are active, the front panel *Overview* screen is alternated with the *Active Pre-Alarms* screen in one-second intervals. Active alarms and pre-alarms can be viewed through BESTCOMSP<sup>Plus</sup>®.

The front panel Alarm LED is illuminated when alarms are active. When pre-alarms are active, the Alarm LED flashes in one-second intervals.

If programmed and enabled, the horn output is closed when alarms are active. When pre-alarms are active, the horn output toggles in one-second intervals.

Active alarms are also indicated on the optional remote display panel in the form of LEDs and an audible horn. Red alarm LEDs light and the horn sounds when the corresponding alarm setting is exceeded. If an active alarm condition is not annunciated by the remote display panel, the *Switch Not In Auto* LED lights and the horn sounds.

Each alarm provides a logic output that can be connected to a physical output or other logic input using BESTlogic™*Plus* Programmable Logic.

A detailed list of alarms is provided in Table 6.

**Table 6. Available Alarms**

Name	Description
<b><i>Alarms</i></b>	
AUTO RESTART FAIL	Automatic Restart Failure
BATT CHRG FAIL	Battery Charger Fail
ECU SHUTDOWN	ECU Shutdown
EMERGENCY STOP	Emergency Shutdown
FUEL LEAK DETECT	Fuel Leak Detected
GEN TRANSFER FL	Transfer Fail
GLBL ALARM	Global Alarm
GLBL SNDR FAIL	Global Sender Fail
HI COOLANT TMP	High Coolant Temp
LOST ECU COMM	Loss of ECU Communication
LOW COOL LEVEL	Low Coolant Level
LOW FUEL LEVEL	Low Fuel Level
LOW OIL PRES	Low Oil Pressure
OVERCRANK	Overcrank
OVERSPEED	Overspeed
UNEXPECTED SHUTDN	Unexpected Shutdown
<b><i>Pre-alarms</i></b>	
BATT CHRG FAIL	Battery Charger Fail
BATT OVERVOLT	Battery Overvoltage
BUS REV ROT	Reverse Bus Rotation

<b>Name</b>	<b>Description</b>
CEM COMM FAIL	CEM Communication Failure
CEM HW MISMATCH	CEM Hardware Mismatch
CHECKSUM FAIL	Checksum Failure
DEF ENGINE DERATE	DEF Engine Derate
DEF FLUID EMPTY	DEF Fluid Empty
DEF FLUID LOW	DEF Fluid Low
DEF INDUCMT O-RIDE	DEF Inducement Override
DEF PRESVR INDUCMT	DEF Pre-Severe Inducement
DEF SEVERE INDUCMT	DEF Severe Inducement
DIAG TRBL CODE	Active DTC
DPF REGEN INHBTD	DPF Regenerate Disabled
DPF REGEN REQD	DPF Regenerate Required
DPF SOOT HIGH	DPF Soot Level High
DPF SOOT LVL EXT HI	DPF Soot Level Severely High
DPF SOOT LVL MOD HI	DPF Soot Level Moderately High
FUEL 1 LEAK	Fuel Filter 1 Leak
FUEL 2 LEAK	Fuel Filter 2 Leak
FUEL LEAK DETECT	Fuel Leak Detect
GEN REV ROT	Reverse Generator Rotation
GN BRK CL FL	Breaker Close Failure
GN BRK OP FL	Breaker Open Failure
HI COOLANT TMP	High Coolant Temp
HIGH EXHAUST TEMP	High Exhaust Temperature
HIGH FUEL LEVEL	High Fuel Level
LOST ECU COMM	Loss of ECU Communication
LOW BATT VOLT	Low Battery Voltage
LOW COOL LEVEL	Low Coolant Level
LOW COOL TMP	Low Coolant Temp
LOW FUEL LEVEL	Low Fuel Level
LOW OIL PRES	Low Oil Pressure
MAINT INTERVAL	Maintenance Interval
MPU FAIL	MPU Failure
MULTIPLE CEM	Duplicate CEM
SERFLASH RD FAIL	Serial Flash Read Failure
WEAK BATTERY	Weak Battery Voltage
<b>Sender Fail</b>	
COOL SNDR FAIL	Coolant Temp Sender Fail
FUEL LEVEL SNDR	Fuel Level Sender Fail
LOSS OF VOLT	Voltage Sensing Fail

Name	Description
OIL SNDR FAIL	Oil Pressure Sender Fail
SPD SNDR FAIL	Speed Sender Fail
<b>Generator Protection</b>	
27 UNDVOLT TRP	Undervoltage (27)
47 PHS IMBAL TRP	Phase Imbalance (47)
50 OVRCURR TRP	Overcurrent (50)
59 OVRVOLT TRP	Overvoltage (59)
81O OVRFREQ TRP	Frequency (81O)
81U UNDFREQ TRP	Frequency (81U)

## Alarm Configuration

Alarms, pre-alarms, sender failure alarms, and the audible horn can be configured through BESTCOMSP<sup>Plus</sup> or the front panel.

### Alarms

To configure alarms using BESTCOMSP<sup>Plus</sup>, open the *Alarm* screen (Figure 37). This screen is found in the *Settings Explorer* under the *Alarm Configuration* category. If using the front panel, navigate to Settings > Alarm Configuration > Alarms.

**Alarms**

**High Coolant Temp**

Enable    Threshold (F)    Arming Delay (s)  
 Disable    275    60

**Low Oil Pressure**

Enable    Threshold (psi)    Arming Delay (s)  
 Disable    15.0    10

**Overspeed**

Enable    Threshold (%)    Activation Delay (ms)  
 Disable    110    50

**Low Fuel Level**

Enable    Threshold (%)    Activation Delay (s)  
 Disable    2    30

**Low Coolant Level**

Enable    Threshold (%)  
 Disable    25

Figure 37. Settings Explorer, Alarm Configuration, Alarms Screen

The alarm settings are described below.

#### High Coolant Temp

High coolant temperature alarm settings consist of an enable/disable setting, a threshold setting, and an arming delay. If enabled, a high coolant temperature alarm is triggered instantaneously when the engine coolant temperature exceeds the threshold setting. The arming delay disables the high coolant

temperature alarm function for a user-adjustable period after engine startup. System units are configured on the System Settings screen.

#### Low Oil Pressure

Low oil pressure alarm settings consist of an enable/disable setting, a threshold setting, and an arming delay. If enabled, a low oil pressure alarm is triggered instantaneously when the engine oil pressure decreases below the threshold setting. The arming delay disables the low oil pressure alarm function for a user-adjustable period after engine startup. System units and metric pressure units are configured on the System Settings screen.

#### Overspeed

Overspeed alarm settings include an enable/disable setting, a threshold setting, and an activation delay. If enabled, an overspeed alarm occurs when the engine speed (in rpm) exceeds the threshold setting for the duration of the activation time delay.

#### Low Fuel Level

Low fuel level alarm settings consist of an enable/disable setting, a threshold setting, and an activation delay setting. If enabled, a low fuel level alarm is triggered when the metered fuel level drops below the threshold setting for the duration of the activation time delay.

#### Low Coolant Level

Low coolant level alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a low coolant level alarm is triggered when the metered coolant level drops below the threshold setting. ECU Support must be enabled on the *Communications, CAN Bus, CAN Bus Setup* screen before this alarm can be configured.

### **Pre-alarms**

To configure pre-alarms using BESTCOMSPPlus, open the *Pre-Alarms* screen (Figure 38). This screen is found in the *Settings Explorer* under the *Alarm Configuration* category. If using the front panel, navigate to Settings > Alarm Configuration > Pre-alarms.

The pre-alarm settings are described below.

#### High Fuel Level

High fuel level pre-alarm settings consist of an enable/disable setting, a threshold setting, and an activation delay. If enabled, a high fuel level pre-alarm is triggered when the metered fuel level increases above the threshold setting for the duration of the activation delay.

#### Low Fuel Level

Low fuel level pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a low fuel level pre-alarm is triggered when the metered fuel level decreases below the threshold setting.

#### Low Battery Voltage

Low battery voltage pre-alarm settings consist of an enable/disable setting, a threshold setting, and an activation delay. If enabled, a low battery voltage pre-alarm is triggered when the battery voltage decreases below the threshold setting for the duration of the activation time delay. The threshold can be entered in actual volts or a per-unit value. The per-unit threshold value is based on the nominal battery voltage setting found on the *System Parameters, Rated Data* screen.

#### High Coolant Temp

High coolant temperature pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a high coolant temperature pre-alarm is annunciated when the engine coolant temperature exceeds the threshold setting for a fixed duration of 60 seconds. System units are configured on the System Settings screen.

### Weak Battery Voltage

Weak battery voltage pre-alarm settings consist of an enable/disable setting, a threshold setting, and an activation time delay. If enabled, a weak battery voltage pre-alarm latches during engine cranking when the battery voltage decreases below the threshold setting for the duration of the activation delay. The threshold can be entered in actual volts or a per-unit value. The per-unit threshold value is based on the nominal battery voltage setting found on the *System Parameters, Rated Data* screen.

### Low Coolant Temp

Low coolant temperature pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a low coolant temperature pre-alarm occurs when the engine coolant temperature decreases below the threshold setting. System units are configured on the System Settings screen.

### Battery Overvoltage

Battery overvoltage pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a battery overvoltage pre-alarm occurs when the battery voltage increases above the threshold setting. The threshold can be entered in actual volts or a per-unit value. The per-unit threshold value is based on the nominal battery voltage setting found on the *System Parameters, Rated Data* screen.

### ECU Coms Fail

ECU communication failure pre-alarm settings consist of a single enable/disable setting. If enabled, this pre-alarm is triggered when the DGC-2020ES detects a problem in its J1939 CAN connection to the ECU.

### Coolant Level

Low coolant level pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a low coolant level pre-alarm is triggered when the metered coolant level decreases below the threshold setting.

### Maintenance Interval

Maintenance interval pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a maintenance interval pre-alarm is annunciated when the DGC-2020ES maintenance timer counts down to zero from the threshold time setting.

### Active DTC

Active DTC (diagnostic trouble code) pre-alarm settings consist of a single enable/disable setting. If J1939 CAN and DTC support are both enabled, an "active DTC" pre-alarm can be enabled. This pre-alarm is triggered when a DTC is sent from the ECU to the DGC-2020ES.

### Low Oil Pressure

Low oil pressure pre-alarm settings consist of an enable/disable setting and a threshold setting. If enabled, a low oil pressure pre-alarm is annunciated when the engine oil pressure decreases below the threshold setting for a fixed duration of 10 seconds. System units and metric pressure units are configured on the *System Settings* screen.

### CEM Comm Failure

CEM-2020 communication failure pre-alarm settings consist of a single enable/disable setting. If enabled, this pre-alarm is triggered when communication between the optional CEM-2020 and DGC-2020ES is lost.

### Checksum Failure

When one of the internal checksum calculations, used for data integrity purposes, has failed, the checksum failure pre-alarm is triggered. This indicates that some of the user settings or firmware code has been corrupted.

After upgrading firmware through *BESTCOMSPPlus*, the checksum failure pre-alarm may trigger. This pre-alarm is not indicative of an error in this case. It can be cleared by cycling power to the DGC-2020ES. If

the pre-alarm reoccurs, then it is indicative of an error and corrective action should be taken. See *Resetting Alarms, Checksum Failure*, below, for more information.

#### Breaker Close Failure

If enabled, this pre-alarm is triggered when the DGC-2020ES has issued a "breaker close" output and has not received "breaker closed" feedback from the breaker within the allowed closing time. The Monitor setting determines whether this condition is monitored only during transitions or always.

#### Breaker Open Failure

If enabled, this pre-alarm is triggered when the DGC-2020ES has issued a "breaker open" output and has not received "breaker opened" feedback from the breaker within the allowed closing time. The Monitor setting determines whether this condition is monitored only during transitions or always.

#### Reverse Rotation

If enabled, this pre-alarm is triggered when the Generator or Bus rotation is opposite of the Phase Rotation setting defined on the Rated Data screen.

### Pre-Alarms

<p><b>High Fuel Level</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold (%) <input type="text" value="90"/></p> <p>Activation Delay (s) <input type="text" value="0"/></p>	<p><b>High Coolant Temp</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p>Threshold (F) <input type="text" value="250"/></p>	<p><b>Battery Overvoltage</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold <input type="text" value="30.0"/> V</p> <p><input type="text" value="1.250"/> Per Unit</p>	
<p><b>Low Fuel Level</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold (%) <input type="text" value="25"/></p>	<p><b>Low Coolant Temp</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold (F) <input type="text" value="50"/></p>	<p><b>Low Battery Voltage</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold <input type="text" value="20.0"/> V</p> <p><input type="text" value="0.833"/> Per Unit</p> <p>Activation Delay (s) <input type="text" value="10"/></p>	
<p><b>Low Oil Pressure</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p>Threshold (psi) <input type="text" value="25.0"/></p>	<p><b>Coolant Level</b></p> <p><input type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold (%) <input type="text" value="50"/></p>	<p><b>Weak Battery Voltage</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold <input type="text" value="15.0"/> V</p> <p><input type="text" value="0.625"/> Per Unit</p> <p>Activation Delay (s) <input type="text" value="2.0"/></p>	
<p><b>CEM Comm Failure</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p>	<p><b>ECU Coms Fail</b></p> <p><input type="radio"/> Disable <input type="radio"/> Enable</p>	<p><b>Active DTC</b></p> <p><input type="radio"/> Disable <input type="radio"/> Enable</p>	<p><b>Maintenance Interval</b></p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Threshold (h) <input type="text" value="500"/></p>
<p><b>Checksum Failure</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p>	<p><b>Reverse Rotation</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p>	<p><b>Breaker Open Failure</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p><b>Monitor</b></p> <p><input checked="" type="radio"/> Transitions Only <input type="radio"/> Always</p>	<p><b>Breaker Close Failure</b></p> <p><input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p><b>Monitor</b></p> <p><input checked="" type="radio"/> Transitions Only <input type="radio"/> Always</p>

Figure 38. Settings Explorer, Alarm Configuration, Pre-Alarms Screen

### Horn Configuration

To configure the audible horn using BESTCOMSPlus, open the *Horn Configuration* screen (Figure 39). This screen is found in the *Settings Explorer* under the *Alarm Configuration* category. If using the front panel, navigate to Settings > Alarm Configuration > Horn Configuration.

An output contact is configured through programmable logic to energize an audible horn when an alarm or pre-alarm condition exists. The horn settings consist of an enable/disable setting and a Not in Auto enable/disable setting. If enabled, the contact output is closed when an alarm condition exists. The contact output is toggled between open and closed when a pre-alarm condition exists. If the Not in Auto setting is enabled, the horn is disabled when the DGC-2020ES is not operating in Auto mode.

**Horn Configuration**

**Horn**

Disable

Enable

**Not In Auto Horn Enable**

Disable

Enable

**Figure 39. Settings Explorer, Alarm Configuration, Horn Configuration Screen**

## Sender Failure

To configure sender failure alarms using BESTCOMSPlus, open the *Sender Fail* screen (Figure 40). This screen is found in the *Settings Explorer* under the *Alarm Configuration* category. If using the front panel, navigate to Settings > Alarm Configuration > Sender Fail.

Coolant temperature, oil pressure, fuel level, and voltage sensing sender failure settings consist of an alarm configuration setting and an activation delay. The alarm configuration setting allows selection of the type of alarm to be annunciated when a sender fail condition exists. None, Alarm, and Pre-alarm can be selected. The selected alarm type is triggered when a sender failure exists for the duration of the activation time delay.

Speed sender failure settings consist of a single activation delay. An alarm is triggered when a speed sender failure exists for the duration of the activation time delay.

**Sender Fail**

**Coolant Temp Sender Fail**

Alarm Configuration: Alarm      Activation Delay (min): 5

**Oil Pressure Sender Fail**

Alarm Configuration: Pre-Alarm      Activation Delay (s): 10

**Fuel Level Sender Fail**

Alarm Configuration: None      Activation Delay (s): 10

**Voltage Sensing Fail**

Alarm Configuration: None      Activation Delay (s): 10

**Speed Sender Fail**

Activation Delay (s): 10

**Figure 40. Settings Explorer, Alarm Configuration, Sender Fail Screen**

## Retrieving Alarm Information

Alarms can be viewed on the front panel display and through BESTCOMSPlus.

### Front Panel Display

The lists of active alarms and pre-alarms can be viewed by navigating to Metering > Alarms-Status > Active Alarms or Active Pre-alarms. These lists are scrollable by using the *Up* and *Down* pushbuttons.

## BESTCOMSPlus®

The status of each alarm and pre-alarm is displayed on the *Alarms* screen (Figure 41). This screen is found in the *Metering Explorer*. Alarms with a red indicator are active.



Figure 41. Metering Explorer, Alarms Screen

## Resetting Alarms and Pre-Alarms

Most pre-alarms automatically reset when the alarm condition no longer exists. Pre-alarms that do not automatically reset are listed below:

- Weak Battery
- Breaker Fail to Open
- Breaker Fail to Close

These pre-alarms are reset by navigating to the Overview screen on the front panel display and holding the *Back* pushbutton for two seconds.

Alarms do not automatically reset. Manually reset alarms by pressing the *Off* pushbutton.

### Horn

The audible horn can be silenced by simultaneously pressing the *Back* and *Edit* pushbuttons. This does not reset the alarm or pre-alarm causing the horn to annunciate.

### Maintenance Interval

To reset the maintenance interval pre-alarm through the front panel, navigate to the Settings > System Params > System Settings > Maint Reset screen. Operator, Settings, or OEM access level is required to reset the maintenance interval pre-alarm. If the maintenance interval pre-alarm is not enabled, the *Maint Reset* parameter is not visible on the front panel.

To reset the maintenance interval pre-alarm by using BESTCOMSPlus, use the *Metering Explorer* to open the *Run Statistics* screen and click on the *Reset Maintenance Interval* button.

To reset the maintenance interval pre-alarm from the front panel, navigate to the *Overview* screen and hold the *Back* pushbutton for 12 seconds.

## Checksum Failure

The checksum failure pre-alarm can be cleared by holding the *Back* pushbutton for two seconds while displaying the *Overview* screen. However, the pre-alarm will reoccur the next time the checksum is verified if the data is still corrupted. Some checksum calculations are done only on power-up, so this may not occur until the next time operating power is cycled.

If there are consistent checksum failure pre-alarms, attempt the following actions to correct the problem:

1. Load default settings by holding the *Up* and *Down* pushbuttons on the front panel while cycling power. After loading defaults, upload the settings file through *BESTCOMSPi.us* if necessary.

### Caution

Loading default settings will erase all custom settings. All reports and events will be cleared. It is recommended that all settings are downloaded and saved through *BESTCOMSPi.us* before attempting to load defaults. Once defaults are loaded, the saved settings can then be uploaded.

2. If the problem persists, reload the firmware file through *BESTCOMSPi.us*. See the *BESTCOMSPi.us* chapter for more information.
3. Contact Basler Electric Technical Support.
4. The checksum failure pre-alarm can be disabled. This disables only the annunciation of the pre-alarm and does not correct any error conditions.

# Event Recording

An event log retains history of system events in nonvolatile memory. Thirty event records are retained and each record contains a time stamp of the first and last event occurrence, and the number of occurrences for each event. In addition, each record contains details of the time, date, and engine hours for the most recent 30 occurrences of the event. The number of occurrences stops incrementing at 99. If an event occurs which is of a type that differs from those in the 30 records in memory, the record that has the oldest "last" event occurrence is removed from the log, and the new category takes its place. Since 30 event records with up to 99 occurrences each are retained in memory, a history of nearly 3,000 specific events are retained by the DGC-2020ES. Detailed occurrence information is retained for the most recent 30 occurrences of each event record, and there are 30 event records. Thus the time, date, and engine hours details for up to 900 specific event occurrences are retained in the event log.

## Event Log

An event log can be downloaded into BESTCOMSP<sup>Plus</sup>® for viewing and storage. The *Options* button is used to save the entire event log to a file, or to save the list to the computer clipboard making it available for insertion into other software applications. It is possible to copy a portion of the log to the computer clipboard by selecting the desired portion with the mouse then using the Options->Copy Selection feature. The *Download* button refreshes the event log list by performing a fresh download of the list from the DGC-2020ES. The *Clear* button gives the user the option of clearing selected or all event logs. Refer to Figure 42.

Description	Occurrence	Date	Eng Hrs (H:m)
4 GEN REV ROT P	77	2000-01-01 00:06:41	00:00
4 GEN REV ROT P	78	2000-01-01 00:06:48	00:00
4 GEN REV ROT P	79	2000-01-01 00:06:58	00:00
4 GEN REV ROT P	80	2000-01-01 00:06:58	00:00
4 GEN REV ROT P	81	2000-01-01 00:07:03	00:00
4 GEN REV ROT P	82	2000-01-01 00:07:07	00:00
4 GEN REV ROT P	83	2000-01-01 00:07:10	00:00
4 GEN REV ROT P	84	2000-01-01 00:07:11	00:00
4 GEN REV ROT P	85	2000-01-01 00:07:12	00:00
4 GEN REV ROT P	86	2000-01-01 00:07:15	00:00
4 GEN REV ROT P	87	2000-01-01 00:07:17	00:00
4 GEN REV ROT P	88	2000-01-01 00:07:18	00:00
4 GEN REV ROT P	89	2000-01-01 00:07:20	00:00
4 GEN REV ROT P	90	2000-01-01 00:07:24	00:00
4 GEN REV ROT P	91	2000-01-01 00:07:26	00:00
4 GEN REV ROT P	92	2000-01-01 00:07:29	00:00
4 GEN REV ROT P	93	2000-01-01 00:07:37	00:00
4 GEN REV ROT P	94	2000-01-01 00:07:39	00:00
4 GEN REV ROT P	95	2000-01-01 00:07:43	00:00
4 GEN REV ROT P	96	2000-01-01 00:07:46	00:00
4 GEN REV ROT P	97	2000-01-01 00:07:49	00:00
4 GEN REV ROT P	98	2000-01-01 00:07:53	00:00
4 GEN REV ROT P	99	2000-01-01 00:07:56	00:00
5 CAN ERR PASSIVE	1	2000-01-01 00:00:26	00:00
5 CAN ERR PASSIVE	2	2012-01-01 00:25:01	00:00
5 CAN ERR PASSIVE	3	2012-01-04 00:57:28	00:00
6 CEM COMM FAIL P	1	2000-01-01 00:00:46	00:00
6 CEM COMM FAIL P	2	2012-01-04 00:57:47	00:00
7 OVERCRANK A	1	2000-01-01 02:13:32	00:00
7 OVERCRANK A	2	2000-01-01 03:04:31	00:00

Figure 42. Metering Explorer, Event Log Screen (Sorted by Event ID)

The event log may also be viewed on the front panel display by navigating to *Metering, Alarms-Status, Event Log*. Use the Up/Down keys to highlight an event and press the *Right* key to view the summary of that event record. The summary contains the description of the event, date, time, and engine hours of the first occurrence of the event, along with date, time, and engine hours of the most recent occurrence of the event. To view details of specific event occurrences, press the *Down* key until DETAILS is highlighted and then press the *Right* key. The occurrence number can be changed by pressing the *Edit* key, *Up/Down* keys to select #, and pressing the *Edit* key again to exit. Table 7 lists all possible event strings (as shown in the event log).

**Table 7. Event List**

Event String	Event Description	Event Type
27 UNDVOLT TRP A	27 Undervoltage Trip	Alarm
27 UNDVOLT TRP P	27 Undervoltage Trip	Pre-Alarm
47 PHS IMBAL TRP A	47 Phase Imbalance Trip	Alarm
47 PHS IMBAL TRP P	47 Phase Imbalance Trip	Pre-Alarm
50 OVRCURR TRP A	50 Overcurrent Trip	Alarm
50 OVRCURR TRP P	50 Overcurrent Trip	Pre-Alarm
59 OVRVOLT TRP A	59 Overvoltage Trip	Alarm
59 OVRVOLT TRP P	59 Overvoltage Trip	Pre-Alarm
81O OVRFREQ TRP A	81 Overfrequency Trip	Alarm
81O OVRFREQ TRP P	81 Overfrequency Trip	Pre-Alarm
81U UNDFREQ TRP A	81 Underfrequency Trip	Alarm
81U UNDFREQ TRP P	81 Underfrequency Trip	Pre-Alarm
ATS INPUT CLOSED	ATS Input	Status
AUTO RESTART	Automatic Restart in Progress	Status
AUTO RESTART FAIL A	Automatic Restart Fail	Alarm
BATT CHRG FAIL A	Battery Charger Fail	Alarm
BATT CHRG FAIL P	Battery Charger Fail	Pre-Alarm
BATT OVERVOLT P	Battery Overvoltage	Pre-Alarm
BATTLE OVERRIDE	Battle Override	Status
CAN BUS OFF	CAN Bus entered Bus Off state	Status
CAN ERROR PASSIVE	CAN Bus entered Error Passive state	Status
CEM COMM FAIL P	CEM-2020 Communications Failure	Pre-Alarm
CEM HW MISMATCH P	Connected CEM-2020 is wrong type	Pre-Alarm
CHECKSUM FAIL P	Corrupt user settings or firmware code	Pre-Alarm
COMBINED RED A	Combined Red	Alarm
COMBINED YELLOW P	Combined Yellow	Pre-Alarm
CONFIG ELEMENT X A (X = 1 to 8)	Configurable Element X (X = 1 to 8)	Alarm
CONFIG ELEMENT X P (X = 1 to 8)	Configurable Element X (X = 1 to 8)	Pre-Alarm
COOL LVL SNDR FL A	Coolant Level Sender Fail	Alarm
COOL SNDR FAIL	Coolant Temperature Sender Fail	Status
COOL SNDR FAIL A	Coolant Temperature Sender Fail	Alarm
COOL SNDR FAIL P	Coolant Temperature Sender Fail	Pre-Alarm
DEF ENGINE DERATE P	Diesel Exhaust Fluid Engine Derate	Pre-Alarm
DEF FLUID EMPTY P	Diesel Exhaust Fluid Empty	Pre-Alarm
DEF FLUID LOW P	Diesel Exhaust Fluid Low	Pre-Alarm
DEF INDUCMT O-RIDE P	Diesel Exhaust Fluid Inducement Override	Pre-Alarm

Event String	Event Description	Event Type
DEF PRESVR INDUCMT P	Diesel Exhaust Fluid Pre-Severe Inducement	Pre-Alarm
DEF SEVERE INDUCMT P	Diesel Exhaust Fluid Severe inducement	Pre-Alarm
DGC HEARTBEAT FAIL P	DGC Heartbeat Fail	Pre-Alarm
DIAG TRBL CODE P	Diagnostic Trouble Code	Pre-Alarm
DPF REGNRATE DISABLD P	Diesel Particulate Filter Regeneration Disabled	Pre-Alarm
DPF REGEN REQD P	Diesel Particulate Filter Regeneration Required	Pre-Alarm
DPF SOOT LVL EXT HI P	Diesel Particulate Filter Soot Level Extremely High	Pre-Alarm
DPF SOOT LVL MOD HI P	Diesel Particulate Filter Soot Level Moderately High	Pre-Alarm
ECU SHUTDOWN A	ECU Shutdown	Alarm
EMERGENCY STOP A	Emergency Stop	Alarm
ENGINE RUNNING	Engine Running	Status
FUEL FLT PRS HI P	Fuel Filter Differential Pressure High	Pre-Alarm
FUEL LEAK 1 P	Fuel Filter 1 Leak	Pre-Alarm
FUEL LEAK 2 P	Fuel Filter 2 Leak	Pre-Alarm
FUEL LEAK DETECT A	Fuel Leak Detect	Alarm
FUEL LEAK DETECT P	Fuel Leak Detect	Pre-Alarm
FUEL LEVL SENDR A	Fuel Level Sender Fail	Alarm
FUEL LEVL SENDR FAIL	Fuel Level Sender Fail	Status
FUEL LEVL SENDR P	Fuel Level Sender Fail	Pre-Alarm
GEN TEST LOADED	Generator Exerciser Test with Load	Status
GEN TEST UNLOADED	Generator Exerciser Test without Load	Status
GLBL SNDR FAIL A	Global Sender Fail	Alarm
GN BKR CL FL P	Generator Breaker Fail to Close	Pre-Alarm
GN BKR OP FL P	Generator Breaker Fail to Open	Pre-Alarm
GN BKR SYN FL P	Generator Breaker Synchronization Fail	Pre-Alarm
HI COOLANT TMP A	High Coolant Temp	Alarm
HI COOLANT TMP P	High Coolant Temp	Pre-Alarm
HI DAY TANK LEVEL P	High Day Tank Level	Pre-Alarm
HI ECU VOLTS A	High ECU Supply Voltage	Alarm
HI EXHAUSE B T P	High Exhaust Temp B	Pre-Alarm
HI EXHAUST A T P	High Exhaust Temp A	Pre-Alarm
HI PRESSURE IN 1 P	High Pressure Input 1	Pre-Alarm
HI PRESSURE IN 2 P	High Pressure Input 2	Pre-Alarm
HI SUPPLY VOLTS P	High Voltage Supply	Pre-Alarm
HI T FUEL P	High Fuel Temp	Pre-Alarm
HIGH AMB TEMP P	High Ambient Temp	Pre-Alarm
HIGH CHARGE AIR TEMP A	High Charge Air Temp	Alarm
HIGH CHARGE AIR TEMP P	High Charge Air Temp	Pre-Alarm
HIGH COIL TEMP 1 P	High Temp Coil 1	Pre-Alarm
HIGH COIL TEMP 2 P	High Temp Coil 2	Pre-Alarm
HIGH COIL TEMP 3 P	High Temp Coil 3	Pre-Alarm
HIGH COOLANT TEMP A	High Coolant Temp	Alarm
HIGH COOLANT TEMP P	High Coolant Temp	Pre-Alarm

Event String	Event Description	Event Type
HIGH ECU TEMPERATURE P	High ECU Temp	Pre-Alarm
HIGH EXHAUST TEMP P	High Exhaust Temp	Pre-Alarm
HIGH FUEL LEVEL P	High Fuel Level	Pre-Alarm
HIGH FUEL RAIL PRESS P	High Fuel Rail Pressure	Pre-Alarm
HIGH INTRCOOLER TEMP P	High Intercooler Temp	Pre-Alarm
HIGH OIL TEMPERATURE P	High Oil Temp	Pre-Alarm
HIGH OIL TERMPERATURE A	High Oil Temp	Alarm
HIGH STRG TANK LEVEL P	High Storage Tank Level	Pre-Alarm
IDLE SPD LO P	Idle Speed Low	Pre-Alarm
INPUT X A (X = 1 to 17)	User Configurable Input X (X = 1 to 17)	Alarm
INPUT X P (X = 1 to 17)	User Configurable Input X (X = 1 to 17)	Pre-Alarm
LO AFTERCLR COOL LVL A	Low After Cooler Cool Level	Alarm
LO CHG AIR CLNT LVL P	Low Charge Air Coolant Level	Pre-Alarm
LO DAY TANK LEVEL P	Low Day Tank Level	Pre-Alarm
LO ECU VOLTS P	Low ECU Supply Voltage	Pre-Alarm
LO FUEL DLV PRESSURE A	Low Fuel Delivery Pressure	Alarm
LO SUPPLY VOLTS P	Low Voltage Supply	Pre-Alarm
LOAD TAKEOVER	Load Takeover	Status
LOGIC OUPUT A	Logic Output	Alarm
LOGIC OUPUT P	Logic Output	Pre-Alarm
LOSS OF VOLT	Voltage Sensing Fail	Status
LOSS OF VOLT A	Voltage Sensing Fail	Alarm
LOSS OF VOLT P	Voltage Sensing Fail	Pre-Alarm
LOSS REM COMS P	Loss of Remote Module Communication	Pre-Alarm
LOST ECU COMM A	Loss of ECU Communication	Alarm
LOST ECU COMM P	Loss of ECU Communication	Pre-Alarm
LOW BATT VOLT P	Low Battery Voltage	Pre-Alarm
LOW CHARGE AIR PRESS P	Low Charge Air Pressure	Pre-Alarm
LOW COOL LEVEL A	Low Coolant Level	Alarm
LOW COOL LEVEL P	Low Coolant Level	Pre-Alarm
LOW COOL TMP A	Low Coolant Temperature	Alarm
LOW COOL TMP P	Low Coolant Temperature	Pre-Alarm
LOW COOLANT LEVEL P	Low Coolant Level	Pre-Alarm
LOW FUEL DELIV PRESS P	Low Fuel Delivery Pressure	Pre-Alarm
LOW FUEL LEVEL A	Low Fuel Level	Alarm
LOW FUEL LEVEL P	Low Fuel Level	Pre-Alarm
LOW FUEL RAIL PRESS P	Low Fuel Rail Pressure	Pre-Alarm
LOW OIL PRES A	Low Oil Pressure	Alarm
LOW OIL PRES P	Low Oil Pressure	Pre-Alarm
LOW OIL PRESSURE A	Low Oil Pressure	Alarm
LOW OIL PRESSURE P	Low Oil Pressure	Pre-Alarm
LOW STRG TANK LEVEL P	Low Storage Tank Level	Pre-Alarm
MAINS FAIL TEST	Mains Fail Test	Status

<b>Event String</b>	<b>Event Description</b>	<b>Event Type</b>
MAINT INTERVAL P	Maintenance Interval	Pre-Alarm
MF TRANSFER	Mains Fail Transfer Complete	Status
MF TRANSFER FAIL	Mains Fail Transfer Fail	Status
MN BKR CL FL P	Mains Breaker Fail to Close	Pre-Alarm
MN BKR OP FL P	Mains Breaker Fail to Open	Pre-Alarm
MPU FAIL P	Magnetic Pickup Fail	Pre-Alarm
MULTIPLE CEM P	Multiple CEM-2020's	Pre-Alarm
NORM SHUTDOWN	Normal Shutdown	Status
OIL SNDR FAIL	Oil Pressure Sender Fail	Status
OIL SNDR FAIL A	Oil Pressure Sender Fail	Alarm
OIL SNDR FAIL P	Oil Pressure Sender Fail	Pre-Alarm
OVERCRANK A	Overcrank	Alarm
OVERSPD TEST ON P	Overspeed Test On	Pre-Alarm
OVERSPEED A	Overspeed	Alarm
PRIMING FAULT P	Priming Fault	Pre-Alarm
PROT SHUTDOWN	Protective Shutdown	Status
REV BUS ROT P	Reverse Bus Rotation	Pre-Alarm
REV GEN ROT P	Reverse Generator Rotation	Pre-Alarm
RUNUP SPD LO P	Run Up Speed Low	Pre-Alarm
SERFLASH RD FAIL	Serial Flash Read Fail	Pre-Alarm
SPD SNDR FAIL	Speed Sender Fail	Status
SPD SNDR FAIL A	Speed Sender Fail	Alarm
SPEED DMD FL P	Speed Demand Fail	Pre-Alarm
SPEED TOO LOW P	Engine Speed Too Low	Pre-Alarm
SS OVERRIDE ON P	Shutdown Override	Pre-Alarm
START SPEED LOW P	Start Speed Low	Pre-Alarm
VOLTAGE SENSE FAIL	Voltage Sensing Fail	Status
VOLTAGE SENSE FAIL A	Voltage Sensing Fail	Alarm
VOLTAGE SENSE FAIL P	Voltage Sensing Fail	Pre-Alarm
WEAK BATTERY P	Weak Battery	Pre-Alarm



# Mounting

DGC-2020ES controllers are delivered in sturdy cartons to prevent shipping damage. Upon receipt of a unit, check the part number against the requisition and packing list for agreement. Inspect for damage, and if there is evidence of such, immediately file a claim with the carrier and notify the Basler Electric regional sales office or your sales representative.


If the device is not installed immediately, store it in the original shipping package in a moisture- and dust-free environment.

## Hardware

The front panel is resistant to moisture, salt fog, humidity, dust, dirt, and chemical contaminants. DGC-2020ES controllers are mounted using the four permanently attached 10-24 studs. The torque applied to the mounting hardware should not exceed 20 inch-pounds (2.2 newton meters).

## Dimensions

Panel cutting and drilling dimensions are shown in Figure 43. Overall dimensions are shown in Figure 44. All dimensions are shown in inches with millimeters in parenthesis.






Figure 44. Overall Dimensions

# Terminals and Connectors

All DGC-2020ES terminals and connectors are located on the rear panel. DGC-2020ES terminals consist of a mini-B USB socket and plug-in connectors with spring clamp terminals.

Figure 45 illustrates the rear panel terminals. Locator letters in the illustration correspond to the terminal block and connector descriptions in Table 8.




Figure 45. Rear Panel

**Table 8. Rear Panel Terminal and Connector Descriptions**

Locator	Description
A	The majority of external, DGC-2020ES wiring is terminated at 8- or 15-position connectors with spring clamp terminals. These connectors plug into headers on the DGC-2020ES. The connectors and headers have a dovetailed edge that ensures proper connector orientation. Each connector and header is uniquely keyed to ensure that a connector mates only with the correct header. Spring clamp terminals accept a maximum wire size of 12 AWG.
B	The mini-B USB socket mates with a standard USB cable and is used with a PC running BESTCOMSP <i>Plus</i> <sup>®</sup> software for local communication with the DGC-2020ES.

## Connections

DGC-2020ES connections are dependent on the application. Incorrect wiring may result in damage to the controller.

Note
<p>Be sure that the DGC-2020ES is hard-wired to earth ground with no smaller than 12 AWG copper wire attached to the chassis ground terminal (terminal 1) on the rear of the controller.</p> <p>Operating power from the battery must be of the correct polarity. Although reverse polarity will not cause damage, the DGC-2020ES will not operate.</p> <p>For the DGC-2020ES to correctly meter power factor, the generator must be rotating clockwise (A-B-C).</p>

The DGC-2020ES terminals are grouped by function and include operating power, generator current sensing, generator voltage sensing, bus voltage sensing, analog engine sender inputs, magnetic pickup input, contact sensing inputs, output contacts, USB interface, CAN interface, and Remote Display Panel connections.

DGC-2020ES terminal groups are described in the following paragraphs.

## Operating Power

The DGC-2020ES operating power input accepts either 12 Vdc or 24 Vdc and tolerates voltage over the range of 6 to 32 Vdc. Operating power must be of the correct polarity. Although reverse polarity will not cause damage, the DGC-2020ES will not operate. Operating power terminals are listed in Table 9.

It is recommended that a fuse be added for additional protection for the wiring to the battery input of the DGC-2020ES. A fuse helps prevent wire damage and nuisance trips due to initial power supply inrush current. To follow UL guidelines, a 5 A maximum, 32 Vdc supplementary fuse must be implemented in the battery input circuit to the DGC-2020ES

**Table 9. Operating Power Terminals**

Terminal	Description
16 (CHASSIS)	Chassis ground connection
17 (BATT-)	Negative side of operating power input
18 (BATT+)	Positive side of operating power input

## Generator Current Sensing

The DGC-2020ES has sensing inputs for A-phase, B-phase, and C-phase generator current. A DGC-2020ES with a style number of 1xx has a 1 Aac nominal current sensing and a DGC-2020ES with a style number of 5xx indicates 5 Aac nominal current sensing. Generator current sensing terminals are listed in Table 10.

**Table 10. Generator Current Sensing Terminals**

Terminals	Description
37 (IA-)	A-phase current sensing input
38 (IA+)	
35 (IB-)	B-phase current sensing input
36 (IB+)	
33 (IC-)	C-phase current sensing input
34 (IC+)	

### Note

Unused current sensing inputs should be shorted to minimize noise pickup.

### Caution

Generator current sensing terminals 37 (IA-), 35 (IB-), and 33 (IC-) must be terminated to ground for proper operation.

## Generator Voltage Sensing

The DGC-2020ES accepts either line-to-line or line-to-neutral generator sensing voltage over the range of 12 to 576 volts, rms line-to-line. Generator voltage sensing terminals are listed in Table 11.

**Table 11. Generator Voltage Sensing Terminals**

Terminal	Description
40 (GEN VN)	Neutral generator voltage sensing input
41 (GEN VC)	C-phase generator voltage sensing input
43 (GEN VB)	B-phase generator voltage sensing input
45 (GEN VA)	A-phase generator voltage sensing input

## Bus Voltage Sensing

Sensing of bus voltage enables the DGC-2020ES to detect failures of the mains (utility). The DGC-2020ES senses A-phase, B-phase, and C-phase bus voltage. Bus voltage sensing terminals are listed in Table 12.

**Table 12. Bus Voltage Sensing Terminals**

Terminal	Description
46 (BUS VA)	A-phase bus voltage sensing input
48 (BUS VB)	B-phase bus voltage sensing input
50 (BUS VC)	C-phase bus voltage sensing input

## **Analog Engine Sender Inputs**

Inputs are provided for oil pressure, fuel level, and coolant temperature senders. For a listing of oil pressure, fuel level, and coolant temperature senders that are compatible with the DGC-2020ES, refer to the *Engine Sender Inputs* chapter. Analog engine sender input terminals are listed in Table 13.

**Table 13. Sender Input Terminals**

Terminal	Description
1 (FUEL)	Fuel level sender input
2 (SENDER COM)	Sender return terminal
52 (OIL)	Oil pressure sender input
53 (COOLANT)	Coolant temperature sender input

## **Magnetic Pickup Input**

The magnetic pickup input accepts a speed signal over the range of 3 to 35 volts peak and 32 to 10,000 hertz. Magnetic pickup input terminals are listed in Table 14.

**Table 14. Magnetic Pickup Input Terminals**

Terminals	Description
31 (MPU-)	Magnetic pickup return input
32 (MPU+)	Magnetic pickup positive input

## **Contact Sensing Inputs**

Contact sensing inputs consist of seven programmable inputs. The programmable inputs accept normally open, dry contacts. Terminal 17 (BATT-) serves as the common return line for the programmable inputs. While input 1 is programmed to recognize an emergency stop input by default, it can be programmed for any function. Information about configuring the programmable inputs is provided in the *Contact Inputs* chapter. Contact sensing input terminals are listed in Table 15.

**Table 15. Contact Sensing Inputs**

Terminal	Description
17 (BATT-)	Common return line for programmable contact inputs
3 (INPUT 1)	Programmable contact input 1 (ESTOP by default)
4 (INPUT 2)	Programmable contact input 2
5 (INPUT 3)	Programmable contact input 3
6 (INPUT 4)	Programmable contact input 4
7 (INPUT 5)	Programmable contact input 5
8 (INPUT 6)	Programmable contact input 6
9 (INPUT 7)	Programmable contact input 7

## Output Contacts

The DGC-2020ES has three sets of fixed-function output contacts: Pre, Start, and Run. The Pre contacts supply battery power to the engine glow plugs, the Start contacts supply power to the starter solenoid, and the Run contacts supply power to the fuel solenoid. Connections to the three sets of contacts are made at terminals 19 through 24. The Pre, Start, and Run relay terminals are listed in Table 16.

**Table 16. Fixed-Function Output Contact Terminals**

Terminal	Description
19 (START)	Start output contact (Start solenoid)
20 (START)	
21 (RUN)	Run output contact (Fuel solenoid)
22 (RUN)	
23 (PRE)	Pre-start output contact (Glow plugs)
24 (PRE)	

Four programmable output contacts are provided in two sets. Each set of two output contacts share a common terminal. Programmable output contact terminals are listed in Table 17.

**Table 17. Programmable Output Contact Terminals**

Terminal	Description
25 (COM 1, 2)	Common connection for outputs 1 and 2
26 (OUT 1)	Programmable output 1
27 (OUT 2)	Programmable output 2
28 (COM 3, 4)	Common connection for outputs 3 and 4
29 (OUT 3)	Programmable output 3
30 (OUT 4)	Programmable output 4

## USB Interface

A mini-B USB socket enables local communication with a PC running BESTCOM*Plus* software. The DGC-2020ES is connected to a PC using a standard USB cable equipped with a type A plug on one end (PC termination) and a mini-B plug on the other end (DGC-2020ES termination).

## CAN Interface

These terminals provide communication using the SAE J1939 protocol or the MTU protocol and provide high-speed communication between the DGC-2020ES and an ECU on an electronically controlled engine. Connections between the ECU and DGC-2020ES should be made with twisted-pair, shielded cable. CAN interface terminals are listed in Table 18. For typical CAN connections, refer to the *Typical Connections* chapter.

**Table 18. CAN Interface Terminals**

Terminals	Description
13 (CAN H)	CAN high connection
14 (CAN L)	CAN low connection
15 (SHIELD)	CAN drain connection

### Note

1. If the DGC-2020ES is providing one end of the J1939 bus, a 120  $\Omega$ , ½ watt terminating resistor should be installed across terminals 14 (CANL) and 13 (CANH).
2. If the DGC-2020ES is not providing one end of the J1939 bus, the stub connecting the DGC-2020ES to the bus should not exceed 914 mm (3 ft) in length.
3. The maximum bus length, not including stubs, is 40 m (131 ft).
4. The J1939 drain (shield) should be grounded at one point only. If grounded elsewhere, do not connect the drain to the DGC-2020ES

## Optional Remote Display Panel Connections

Terminals are provided for connection with the optional Remote Display Panel. These terminals provide dc operating power to the Remote Display Panel and enable communication between the DGC-2020ES and Remote Display Panel. Twisted-pair conductors are recommended for connecting the communication terminals of the DGC-2020ES and Remote Display Panel. Communication may become unreliable if the connection wires exceed 1,219 m (4,000 ft). Table 19 lists the DGC-2020ES terminals that connect to the Remote Display Panel.

**Table 19. Remote Display Panel Interface Terminals**

Terminal	Description
10 (RDP TxD-)	Remote Display Panel terminal (TxD-)
11 (RDP TxD+)	Remote Display Panel terminal (TxD+)
17 (BATT-)	Remote Display Panel terminal DC COM (-)
18 (BATT+)	Remote Display Panel terminal 12/24 (+)

# Typical Connections

Typical connection diagrams are provided in this chapter as a guide when wiring the DGC-2020ES for communication, mechanical senders, contact inputs and outputs, sensing, and operating power.

## Connections for Typical Applications

Typical connections for applications using three-phase wye, three-phase delta, single-phase AB, and single-phase AC generator voltage sensing are shown on the following pages.

Figure 46 illustrates typical three-phase wye generator voltage sensing connections.




Figure 46. 3-Phase Wye Connections for Typical Applications

Figure 47 illustrates typical three-phase delta generator voltage sensing connections.





Figure 47. 3-Phase Delta Connections for Typical Applications

Figure 48 illustrates typical single-phase A-B generator voltage sensing connections.



- ⚠️ 1 Current inputs are 1A or 5A, depending on style.
- ⚠️ 2 Bus sensing inputs are optional, depending on style.
- ⚠️ 3 Oil pressure and coolant temperature senders are *only* available when the DGC-2020ES has the Analog Senders option (style xAx). The fuel sender is always available.
- ⚠️ 4 Connect near engine block (negative battery terminal) side of senders.
- ⚠️ 5 If component is under ECU control, do not connect to DGC-2020ES.
- ⚠️ 6 Connect to the ECU on an electronically controlled engine when the DGC-2020ES has the J1939 CAN interface option (style xCx).
- ⚠️ 7 Labels indicate the functions assigned by the default programmable logic to the contact inputs.

Figure 48. Single-Phase A-B Connections for Typical Applications



## CAN Connections

Typical CAN connections are shown in Figure 50 and Figure 51.

### Note

1. If the DGC-2020ES is providing one end of the J1939 bus, a 120  $\Omega$ , 1/2 watt terminating resistor should be installed across terminals 14 (CANL) and 13 (CANH).
2. If the DGC-2020ES is not providing one end of the J1939 bus, the stub connecting the DGC-2020ES to the bus should not exceed 914 mm (3 ft) in length.
3. The maximum bus length, not including stubs, is 40 m (131 ft).
4. The J1939 drain (shield) should be grounded at one point only. If grounded elsewhere, do not connect the drain to the DGC-2020ES.




Figure 50. CAN Interface with DGC-2020ES Providing One End of the Bus




Figure 51. CAN Interface with Other Devices

## CEM-2020 Connections

The CEM-2020 (Contact Expansion Module) is an optional module that may be installed with the DGC-2020ES. It is a remote auxiliary device that provides additional contact inputs and outputs for the DGC-2020ES. This module interfaces to the DGC-2020ES via CAN, thus the CAN terminals are the only common connections (Figure 52) between the DGC-2020ES and CEM-2020. Refer to the *CEM-2020* chapter for more information.

Refer to *Terminals and Connectors* for details on DGC-2020ES CAN connections.




Figure 52. DGC-2020ES and CEM-2020 CAN Connections

## Installation for CE Systems

For CE compliant systems, it may be required to route ac voltage and current sensing wires separately from other wires.

# BESTCOMSP<sup>Plus</sup>®

BESTCOMSP<sup>Plus</sup>® is a Windows®-based, PC application that provides a user-friendly, graphical user interface (GUI) for use with Basler Electric communicating products. The name BESTCOMSP<sup>Plus</sup> is an acronym that stands for Basler Electric Software Tool for Communications, Operations, Maintenance, and Settings.

BESTCOMSP<sup>Plus</sup> provides the user with a point-and-click means to set and monitor the DGC-2020ES. The capabilities of BESTCOMSP<sup>Plus</sup> make the configuration of one or several DGC-2020ES controllers fast and efficient. A primary advantage of BESTCOMSP<sup>Plus</sup> is that a settings scheme can be created, saved as a file, and then uploaded to the DGC-2020ES at the user's convenience.

BESTCOMSP<sup>Plus</sup> uses plugins, allowing the user to manage several different Basler Electric products. The DGC-2020ES plugin must be activated before use. The plugin can be activated automatically by connecting to a DGC-2020ES, or manually by requesting an activation key from Basler Electric.

The DGC-2020ES plugin opens inside the BESTCOMSP<sup>Plus</sup> main shell. The same default logic scheme that is shipped with the DGC-2020ES is brought into BESTCOMSP<sup>Plus</sup> by downloading settings and logic from the DGC-2020ES. This gives the user the option of developing a custom setting file by modifying the default logic scheme or by building a unique scheme from scratch.

BESTlogic™<sup>Plus</sup> Programmable Logic is used to program DGC-2020ES logic for protection elements, inputs, outputs, alarms, etc. This is accomplished by drag-and-drop method. The user can drag elements, components, inputs, and outputs onto the program grid and make connections between them to create the desired logic scheme.

Figure 53 illustrates the typical user interface components of the DGC-2020ES plugin with BESTCOMSP<sup>Plus</sup>.




Figure 53. Typical User Interface Components

## System Recommendations

BESTCOMSP*lus* software is built on the Microsoft® .NET Framework. The setup utility that installs BESTCOMSP*lus* on your PC also installs the DGC-2020ES plugin and the required version of .NET Framework (if not already installed). BESTCOMSP*lus* operates with systems using Windows® XP 32-bit SP2/SP3, Windows Vista 32-bit (all editions), Windows 7 32-bit (all editions), and Windows 7 64-bit (all editions). Microsoft Internet Explorer 5.01 or later must be installed on your PC before installing BESTCOMSP*lus*. System recommendations for the .NET Framework and BESTCOMSP*lus* are listed in Table 20.

**Table 20. System Recommendations for BESTCOMSP*lus* and the .NET Framework**

System Type	Component	Recommendation
32/64 bit	Processor	1.0 GHz
32/64 bit	RAM	512 MB (minimum)
32 bit	Hard Drive	75 MB (if .NET Framework is already installed on PC)
		925 MB (if .NET Framework is not already installed on PC)
64 bit	Hard Drive	75 MB (if .NET Framework is already installed on PC)
		2.1 GB (if .NET Framework is not already installed on PC)

To install and run BESTCOMSP*lus*, a Windows user must have Administrator rights. A Windows user with limited rights might not be permitted to save files in certain folders.

## Installation

### Note

Do not connect a USB cable until setup completes successfully. Connecting a USB cable before setup is complete may result in errors.

1. Insert the BESTCOMSP*lus* CD-ROM into the PC CD-ROM drive.
2. When the BESTCOMSP*lus* Setup and Documentation CD menu appears, click the *Install* button for the BESTCOMSP*lus* application. The setup utility installs BESTCOMSP*lus*, the .NET Framework (if not already installed), the USB driver, and the DGC-2020ES plugin for BESTCOMSP*lus* on your PC.

When BESTCOMSP*lus* installation is complete, a Basler Electric folder is added to the Windows programs menu. This folder is accessed by clicking the Windows *Start* button and then accessing the Basler Electric folder in the *Programs* menu. The Basler Electric folder contains an icon that starts BESTCOMSP*lus* when clicked.

## Activation of the DGC-2020ES Plugin

The DGC-2020ES plugin is a module that runs inside the BESTCOMSP*lus* shell. The DGC-2020ES plugin contains specific operational and logic settings for only the DGC-2020ES. Uploading settings to the DGC-2020ES is possible only after activating the DGC-2020ES plugin.

The DGC-2020ES plugin can be activated automatically or manually. Automatic activation is achieved by using a USB cable to establish communication between the DGC-2020ES and BESTCOMSP*lus*. Manual activation is initiated by contacting Basler Electric for an activation key and entering the key into BESTCOMSP*lus*. Manual activation is useful if you want to create a settings file prior to receiving your DGC-2020ES. Refer to *Manual Activation of DGC-2020ES Plugin*.

## Connect a USB Cable

The USB driver was copied to your PC during BESTCOMSP*lus* installation and is installed automatically after powering the DGC-2020ES. USB driver installation progress is shown in the Windows taskbar area. Windows will notify you when installation is complete.

Connect a USB cable between the PC and your DGC-2020ES. Apply operating power to the DGC-2020ES. Wait until the boot sequence is complete.

## Start BESTCOMSP*lus*® and Activate the DGC-2020ES Plugin Automatically

To start BESTCOMSP*lus*, click the Windows *Start* button, point to *Programs, Basler Electric*, and then click the *BESTCOMSP*lus** icon. During initial startup, the *BESTCOMSP*lus* Select Language* screen is displayed (Figure 54). You can choose to have this screen displayed each time BESTCOMSP*lus* is started, or you can select a preferred language and this screen will be bypassed in the future. Click *OK* to continue. This screen can be accessed later by selecting *T*ools** and *S*elect Language** from the menu bar.




Figure 54. BESTCOMSP*lus* Language Selection Dialog

The BESTCOMSP*lus* platform window opens. Select *N*ew Connection** from the *C*ommunication** pull-down menu and select *DGC-2020ES*. See Figure 55. The DGC-2020ES plugin is activated automatically after connecting to a DGC-2020ES.






Figure 55. Communication Pull-Down Menu

The *DGC-2020ES Connection* screen, shown in Figure 56, appears.



**Figure 56. DGC-2020ES Connection Dialog**

Select *USB via Serial RS232*, *USB*, and enter *COM Port*. The USB drivers are installed automatically during the *BESTCOMSPiPlus* installation process. To select the correct *COM Port*, open the Windows Device Manager and expand the *Ports (COM & LPT)* branch. Locate the device named *CP2101 USB to UART Bridge Controller (COMx)*. The *COM Port* number will be displayed in parenthesis (*COMx*). Be sure operating power is applied to the DGC-2020ES and the USB cable is connected before opening the Device Manager. See Figure 57.



**Figure 57. Device Manager**

The DGC-2020ES plugin opens indicating that activation was successful. You can now configure the DGC-2020ES communication ports and other settings.

### Installing the USB Driver if Automatic Installation Fails

To install the USB driver for the DGC-2020ES:

1. Apply operating power to the DGC-2020ES and wait for the boot sequence to complete.
2. Connect a USB cable between the PC and DGC-2020ES.
3. The *Found New Hardware Wizard* dialog box appears.
4. Select **"No, not this time"** and select *Next* to continue.
5. Choose to **"Install from a list or specific location (Advanced)"** and select *Next* to continue.
6. Insert the CD-ROM labeled *BESTCOMSPiPlus* into the PC CD-ROM drive.
7. Navigate to `C:\Program Files\Basler Electric\BESTCOMSPiPlus\USBDeviceDrivers\` and select *Next* to continue.

When installation of the driver is complete, you may be asked to restart your computer.

## Manual Activation of the DGC-2020ES Plugin

Manual activation of the DGC-2020ES plugin is required only if your initial use of BESTCOMSP<sup>Plus</sup> will be on a PC that is not connected to a DGC-2020ES. Manual activation is described in the following paragraphs.

### Requesting an Activation Key

When initially running the DGC-2020ES plugin, the *Activate Device Plugin* pop-up appears. You must contact Basler Electric for an activation key before you can activate the DGC-2020ES plugin. You can request an activation key through email or the Basler Electric website. Click either the *Website* or *Email* button. Click the *Activate* button when you are ready to enter the activation key you received from Basler Electric. The *Activate Device Plugin* pop-up appears. Refer to Figure 58.

### Entering an Activation Key

Select DGC-2020ES from the *Device* pull-down menu. Enter your *Email Address* and *Activation Key* provided by Basler Electric. If you received an email containing the *Activation Key*, you can select all of the text in the email and copy it to the Windows clipboard using normal Windows techniques. The *Get Data* button will extract the *Device*, *Email Address*, and *Activation Key* from the Windows clipboard and paste it into the appropriate fields. Click the *Activate* button to continue. The *Activate Device Plugin* screen is also found by selecting *Activate Device* from the Tools pull-down menu of the BESTCOMSP<sup>Plus</sup> main screen.

Figure 58. Activate Device Plugin

## Menu Bars

The menu bars are located near the top of the BESTCOMSP<sup>Plus</sup> window (see Figure 53). The upper menu bar has five pull-down menus. With the upper menu bar, it is possible to manage settings files, configure communication settings, upload and download settings/security files, and compare settings files. The lower menu bar consists of clickable icons. The lower menu bar is used to change BESTCOMSP<sup>Plus</sup> views, save or load a BESTspace™ workspace, open a settings file, connect/disconnect, preview metering printout, export metering, switch to live mode, and send settings to the DGC-2020ES.

### Upper Menu Bar (BESTCOMSP<sup>Plus</sup>® Shell)

Upper menu bar functions are listed and described in Table 21.

Table 21. Upper Menu Bar (BESTCOMSPPlus Shell)

Menu Item	Description
<b><i>File</i></b>	
New	Create a new settings file
Open	Open an existing settings file
Open File As Text	Generic file viewer for *.csv, *.txt, etc. files
Close	Close settings file
Save	Save settings file
Save As	Save settings file with a different name
Export To File	Save settings as a *.csv file
Print	Print, export, or send a settings file
Properties	View properties of a settings file
History	View history of a settings file
Recent Files	Open a previously opened file
Exit	Close BESTCOMSPPlus program
<b><i>Communication</i></b>	
New Connection	Choose new device or DGC-2020ES
Close Connection	Close communication between BESTCOMSPPlus and DGC-2020ES
Download Settings and Logic from Device	Download operational and logic settings from the device
Upload Settings and Logic to Device	Upload operational and logic settings to the device
Upload Settings to Device	Upload operational settings to the device
Upload Logic to Device	Upload logic settings to the device
Download Security from Device	Download security settings from the device
Upload Security to Device	Upload security settings to the device
Upload Device Files	Upload firmware to the device
<b><i>Tools</i></b>	
Select Language	Select BESTCOMSPPlus language
Activate Device	Activate the DGC-2020ES plugin
Set File Password	Password protect a settings file
Compare Settings Files	Compare two settings files
Auto Export Metering	Exports metering data on a user-defined interval
Event Log - View	View the BESTCOMSPPlus event log
Event Log - Clear	Clear the BESTCOMSPPlus event log
Event Log - Set New File Name	Set a new file name for event log
<b><i>Window</i></b>	
Cascade All	Cascade all windows
Tile	Tile horizontally or vertically
Maximize All	Maximize all windows
<b><i>Help</i></b>	
Check for Updates	Check for BESTCOMSPPlus updates via the internet
Check for Update Settings	Enable or change automatic checking for updates
About	View general, detailed build, and system information

## Lower Menu Bar (DGC-2020ES Plugin)

The lower menu bar functions are listed and described in Table 22.

**Table 22. Lower Menu Bar (DGC-2020ES Plugin)**

Menu Button	Description
View ▾	Enables you to show/hide the Metering Panel, Settings Panel, or Settings Info Panel.  Opens and saves BESTspace™ workspaces. Customized workspaces make switching between tasks easier and more efficient.
 Open File	Opens a saved settings file.
 Connect	Connect: Opens the <i>DGC-2020ES Connection</i> screen which enables you to connect to the DGC-2020ES via USB or a modem. This button only appears when a DGC-2020ES is not connected.
 Disconnect	Disconnect: Used to disconnect a connected DGC-2020ES. This button only appears when a DGC-2020ES is connected.
 Preview Metering	Displays the <i>Print Preview</i> screen where a preview of the Metering printout is shown. Click on the printer button to send to a printer.
 Export Metering	Enables all metering values to be exported into a *.csv file.
Options ▾	Displays a drop-down list entitled <i>Live Mode Settings</i> which enables <i>Live</i> mode where settings are automatically sent to the device in real time as they are changed.
Send Settings	Sends settings to the DGC-2020ES when BESTCOMSPPlus is not operating in Live Mode. Click this button after making a setting change to send the modified setting to the DGC-2020ES.

## Settings Explorer

The Settings Explorer is a convenient tool within BESTCOMSPPlus used to navigate through the various settings screens of the DGC-2020ES plugin.

These screens allow the user to edit general settings, communications, system parameters, programmable inputs, programmable outputs, alarm configuration, generator protection, breaker management, programmable senders, and BESTlogicPlus programmable logic.

Logic setup will be necessary after making certain setting changes. For more information, refer to the BESTlogicPlus chapter.

## Metering Explorer

The Metering Explorer is a convenient tool within BESTCOMSPPlus used to navigate through the various metering screens of the DGC-2020ES plugin.

These screens allow the user to view real-time system data including generator voltages and currents, input/output status, alarms, reports, and other parameters. Refer to the Metering chapter for more information on the Metering Explorer.

## BESTspace™

BESTspace provides the ability to manage customized workspaces. A workspace consists of the position and size of all open screens within BESTCOMSPPlus. Pre-saved workspaces can be quickly loaded to fit the specific task at hand. Any number of different workspaces can be saved including a default workspace which loads when the DGC-2020ES plug-in is started. The Metering Explorer screens and the Settings Explorer screens can be saved independently into the workspace file. A *Comments* box is provided for writing a description or leaving notes for each saved workspace. To access BESTspace, click *View* (on the lower menu bar) and hover over *BESTspace*. Figure 59 illustrates the BESTspace options found under the *View* pull-down menu. Figure 60 illustrates the options included in the Load/Save Workspace File screen.




Figure 59. View Menu, BESTspace™ Options




Figure 60. View Menu, BESTspace™, Save Workspace Screen

## Settings File Management

A settings file contains all DGC-2020ES settings, including logic. A settings file assumes a file extension of “\*.bstx”. It is possible to save the logic only as a separate logic library file on the BESTlogicPlus Programmable Logic screen. This function is helpful when similar logic is required for several devices. A logic library file assumes a file extension of “\*.bslx”. It is important to note that settings and logic can be uploaded to the device together or separately, but are always downloaded together. For more information on logic files, refer to the *BESTlogicPlus* chapter.

## Opening a Settings File

To open a DGC-2020ES settings file with BESTCOMSP*lus*, pull down the *File* menu and choose *Open*. The *Open* dialog box appears. This dialog box allows you to use normal Windows techniques to select the file that you want to open. Select the file and choose *Open*. You can also open a file by clicking on the *Open File* button on the lower menu bar. If connected to a device, you will be asked to upload the settings and logic from the file to the current device. If you choose *Yes*, the settings displayed in BESTCOMSP*lus* will be overwritten with the settings of the opened file.

## Saving a Settings File

Select *Save* or *Save As* from the *File* pull-down menu. A dialog box appears allowing you to enter a filename and location to save the file. Select the *Save* button to complete the save.

## Upload Settings and/or Logic to Device

To upload a settings file to the DGC-2020ES, open the file through BESTCOMSP*lus* or create the file using BESTCOMSP*lus*. Then pull down the *Communication* menu and select *Upload Settings and Logic to Device*. If you want to upload operational settings without logic, select *Upload Settings to Device*. If you want to upload logic without operational settings, select *Upload Logic to Device*. You are prompted to enter the password. The default password is "OEM". If the password is correct, the upload begins and the progress bar is shown.

## Download Settings and Logic from Device

To download settings and logic from the DGC-2020ES, pull down the *Communication* menu and select *Download Settings and Logic from Device*. If the settings in BESTCOMSP*lus* have changed, a dialog box will open asking if you want to save the current settings changes. You can choose *Yes* or *No*. After you have taken the required action to save or discard the current settings, downloading begins. BESTCOMSP*lus* will read all settings and logic from the DGC-2020ES and load them into BESTCOMSP*lus* memory.

## Print a Settings File

To view a preview of the settings printout, select *Print Preview* from the *File* pull-down menu. To print the settings, select the printer icon in the upper left corner of the *Print Preview* screen.

You can skip the print preview and go directly to print by pulling down the *File* menu and selecting *Print*. A dialog box opens containing the typical Windows options for setting the properties of the printer. Configure these settings as necessary and then select *Print*.

## Compare Settings Files

BESTCOMSP*lus* has the ability to compare two settings files. To compare files, pull down the *Tools* menu and select *Compare Settings Files*. The *BESTCOMSP*lus* Settings Compare Setup* dialog box appears (Figure 61). Select the location of the first file under *Left Settings Source* and select the location of the second file under *Right Settings Source*. If you are comparing a settings file located on your PC hard drive or portable media, click the folder button and navigate to the file. If you want to compare settings downloaded from a unit, click the *Select Unit* button to set up the communication port. Click the *Compare* button to compare the selected settings files.




Figure 61. Tools, Compare Settings Files Screen

A dialog box appears, displaying the results of the comparison. The *BESTCOMSPiPlus Settings Compare* dialog box (Figure 62) is displayed where you can view all settings (*Show All Settings*), view only the differences (*Show Settings Differences*), view all logic (*Show All Logic Paths*), or view only logic differences (*Show Logic Path Differences*). Select *Close* when finished.




Figure 62. Settings Comparison Results Screen

## Firmware Updates

Future enhancements to the DGC-2020ES functionality will make a firmware update desirable. Because default settings are loaded when DGC-2020ES firmware is updated, your settings should be saved in a file prior to upgrading firmware.

### Note

The latest version of BESTCOMS*Plus* software should be downloaded from the Basler Electric website and installed before performing a firmware upgrade.

A device package contains firmware and a language module. Embedded firmware is the operating program that controls the actions of the DGC-2020ES. The DGC-2020ES stores firmware in nonvolatile flash memory that can be reprogrammed through the communication ports. It is not necessary to replace EPROM chips when updating the firmware with a newer version.

The language of the front panel LCD can be changed by uploading a different language module into the DGC-2020ES. The DGC-2020ES stores the language module in nonvolatile flash memory; the language module contains all language translations for the DGC-2020ES. The language module can be reprogrammed through the communications port. In general, any time a firmware upgrade is made to the DGC-2020ES, the language module should be uploaded as well.

The DGC-2020ES can be used in conjunction with the Contact Expansion Module (CEM-2020) which expands the DGC-2020ES capabilities. When upgrading the firmware in any component of this system, the firmware in ALL of the components of the system should be upgraded to ensure compatibility of communications between the components.

### Caution

The order in which the components are upgraded is critical. Assuming a system of a DGC-2020ES and expansion module is in a state where the DGC-2020ES is communicating with the system expansion module, **the expansion module must be upgraded before the DGC-2020ES**. This is necessary because the DGC-2020ES must be able to communicate with the expansion module before the DGC-2020ES can send firmware to it. If the DGC-2020ES were upgraded first, and the new firmware included a change to the expansion module communication protocol, it is possible that the expansion module could no longer communicate with the upgraded DGC-2020ES. Without communications between the DGC-2020ES and the expansion module, upgrading the expansion module is not possible.


### Note

If power is lost or communication is interrupted during file transfer to the DGC-2020ES, it will cease to operate and will not recover automatically. If this occurs or if the front panel HMI becomes blank and all LEDs are flashing at a two-second rate, the DGC-2020ES will not have valid firmware installed and the firmware must be uploaded again. To accomplish this, cycle power to the DGC-2020ES and activate the DGC-2020ES plugin in BESTCOMS*Plus*. Select *Upload Device Files* from the *Communication* pull-down menu and proceed normally.

## Upgrading Firmware in Expansion Modules

The following procedure is used to upgrade firmware in the DGC-2020ES expansion module. This must be completed before upgrading firmware in the DGC-2020ES. If no expansion module is present, proceed to *Upgrading Firmware in the DGC-2020ES*.

1. Place the DGC-2020ES in OFF mode. This can be accomplished by clicking the *Off* button on the *Control* screen inside the Metering Explorer or by pressing the *Off* button on the DGC-2020ES front panel.
2. Enable the expansion module that is present in the system. If it has not already been enabled, enable the expansion module on the SETTINGS->SYSTEM PARAMETERS->REMOTE MODULE SETUP screen.
3. Verify that the DGC-2020ES and the associated expansion module are communicating. This can be verified by examining the pre-alarm status using the Metering Explorer in BESTCOMSP*Plus* or from the front panel by navigating to METERING->ALARMS-STATUS->PRE-ALARMS. There should be no *Loss of Comms* pre-alarms in the pre-alarm status when communications are functioning properly.
4. Connect to the DGC-2020ES through the USB port if not already connected.
5. Select *Upload Device Files* from the *C*ommunication pull-down menu.
6. You will be asked to save the current settings file. Select *Yes* or *No*.
7. When the *Basler Electric Device Package Uploader* screen (Figure 63) appears, click on the *Open* button to browse for the device package you have received from Basler Electric. The *Package Files* along with *File Details* are listed. Place a check in the boxes next to the individual files you want to upload.



**Figure 63. Basler Electric Device Package Uploader**

8. Click on the *Upload* button and the *Proceed with Device Upload* screen will appear. Select *Yes* or *No*.
9. After selecting *Yes*, the *DGC-2020ES Selection* screen will appear. Select the communication port to begin upload. Refer to Figure 64.
10. After file(s) have been uploaded, click the *Close* button on the *Basler Electric Device Package Uploader* screen and disconnect communication to the DGC-2020ES.




Figure 64. DGC-2020ES Selection

## Upgrading Firmware in the DGC-2020ES

Upgrade DGC-2020ES firmware and then load a saved settings file.

1. Upgrade the DGC-2020ES firmware and language module.
  - a. Connect to the DGC-2020ES with *BESTCOMSPPlus*. Check the firmware Application Version on the GENERAL SETTINGS->VERSION INFO->DGC-2020ES screen.
  - b. Select *Upload Device Files* from the *Communication* pull-down menu. You do not have to be connected to the DGC-2020ES at this time. Save settings when prompted, if desired.
  - c. Open the desired device package file (\*\*\*\*DGC-2020ES-\*\*\*\*\*\_xyyyz.bef, where \*\*\*\* may be additional descriptive text of varying length, and xx.yy.zz is the version number of the device package file.)
  - d. Check the boxes for *DGC-2020ES Firmware* and *DGC-2020ES Language Module*. Note the version number of the DGC-2020ES firmware; this is the version that will be used to set the Application Version in the settings file in a later step. This is NOT the same as the version of the package file that is contained in the fields xx.yy.zz in the package file name.
  - e. Click the *Upload* button and follow the instructions that appear to begin the upgrade process.
  - f. After the upload is complete, disconnect communication to the DGC-2020ES.
2. Load the saved settings file into the DGC-2020ES.
  - a. Close all settings files.
  - b. From the *File* pull-down menu, select *New, DGC-2020ES*.
  - c. Connect to the DGC-2020ES.
  - d. Once all settings have been read from the DGC-2020ES, open the saved settings file by selecting the file with *File, Open File* in the *BESTCOMSPPlus* menu.
  - e. When *BESTCOMSPPlus* asks if you wish to upload settings and logic to the device, click *Yes*.
  - f. If you are receiving upload failures and indications that the logic is incompatible with the firmware version, check that the DGC-2020ES style number in the saved file matches that of the DGC-2020ES into which the file is being uploaded. The style number in the settings file is found under GENERAL SETTINGS->STYLE NUMBER in *BESTCOMSPPlus*.
  - g. If the style number of the settings file does not match that of the DGC-2020ES into which it is to be loaded, disconnect from the DGC-2020ES, then modify the style number in the settings file. Then repeat the steps titled *Load the Settings File into the DGC-2020ES*.

---

## ***BESTCOMSPi<sup>®</sup> Updates***

---

Ongoing DGC-2020ES functionality enhancements may make future DGC-2020ES firmware updates desirable. Enhancements to DGC-2020ES firmware typically coincide with enhancements to the DGC-2020ES plugin for BESTCOMSPi. When a DGC-2020ES is updated with the latest version of firmware, the latest version of BESTCOMSPi should also be obtained.

- If you obtained a CD-ROM containing a firmware update from Basler Electric, then that CD-ROM will also contain the corresponding version of BESTCOMSPi software.
- You can check for BESTCOMSPi updates by visiting [www.basler.com](http://www.basler.com).
- You can use the manual “check for updates” function in BESTCOMSPi to ensure that the latest version is installed by selecting Check for Updates in the Help drop-down menu. (An internet connection is required.)

# BESTlogic™ Plus

BESTlogicPlus Programmable Logic is a programming method used for managing the input, output, protection, control, monitoring, and reporting capabilities of Basler Electric's DGC-2020ES Digital Genset Controller. Each DGC-2020ES has multiple, self-contained logic blocks that have all of the inputs and outputs of its discrete component counterpart. Each independent logic block interacts with control inputs and hardware outputs based on logic variables defined in equation form with BESTlogicPlus. BESTlogicPlus equations entered and saved in the DGC-2020ES system's nonvolatile memory integrate (electronically wire) the selected or enabled protection and control blocks with control inputs and hardware outputs. A group of logic equations defining the logic of the DGC-2020ES is called a logic scheme.

One default active logic scheme is preloaded into the DGC-2020ES. This scheme is configured for a typical protection and control application and virtually eliminates the need for "start-from-scratch" programming. BESTCOMSPPlus® can be used to open a logic scheme that was previously saved as a file and upload it to the DGC-2020ES. The default logic scheme can also be customized to suit your application. Detailed information about logic schemes is provided later in this section.

BESTlogicPlus is not used to define the operating settings (modes, pickup thresholds, and time delays) of the individual protection and control functions. Operating settings and logic settings are interdependent but separately programmed functions. Changing logic settings is similar to rewiring a panel and is separate and distinct from making the operating settings that control the pickup thresholds and time delays of a DGC-2020ES. Detailed information about operating settings is provided in the BESTCOMSPPlus chapter.

## Overview of BESTlogic™ Plus

Use BESTCOMSPPlus to change BESTlogicPlus settings. Use the Settings Explorer to open the BESTlogicPlus Programmable Logic tree branch as shown in Figure 65.

The BESTlogicPlus Programmable Logic screen contains a logic library for opening and saving logic files, tools for creating and editing logic documents, and protection settings.




Figure 65. Settings Explorer, BESTlogicPlus Programmable Logic Screen












## BESTlogic™ Plus Composition

There are three main groups of objects used for programming BESTlogicPlus. These groups are *I/O*, *Components*, and *Elements*. For details on how these objects are used to program BESTlogicPlus, see the paragraphs on *Programming BESTlogicPlus*, later in this chapter.

### I/O

This group contains Input Objects, Output Objects, Alarms, Pre-Alarms, Senders, and Logic Control Relays. Table 23 lists the names and descriptions of the objects in the I/O group.














**Table 23. I/O Group, Names and Descriptions**














Name	Description	Symbol
<b>Input Objects</b>		
Logic 0	Always false (Low).	
Logic 1	Always true (High).	
<i>Physical Inputs</i> IN1 – IN7	True when Physical Input x is active.	<b>Input - IN1</b> 
<i>Remote Inputs</i> IN8 – IN17	True when Remote Input x is active. (Available when an optional CEM-2020 is connected.)	<b>Input - IN8</b> 
<i>Virtual Inputs</i> VIN1 – VIN4	True when Virtual Input x is active.	<b>Input - VIN1</b> 
<i>Status Input</i> Alarm Silence	True when the Alarm Silence logic element is true or the Alarm Silence button is pressed on the front panel.	<b>Status Input</b> 
<i>Status Input</i> Alternate Frequency Override	True when the Alternate Frequency Override logic element is true.	<b>Status Input</b> 
<i>Status Input</i> ATS Input	True when the ATS (Auto Transfer Switch) input is true or the ATS logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Audible Horn	True when the Audible Horn is active.	<b>Status Input</b> 
<i>Status Input</i> Auto Mode	True when the DGC-2020ES is in Auto Mode or the Auto Mode logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Auto Restart	True when the Automatic Restart function is active.	<b>Status Input</b> 
<i>Status Input</i> Battery Charger Fail	True when the Battery Charger Fail input is true.	<b>Status Input</b> 
<i>Status Input</i> Battle Override	True when the Battle Override input is true.	<b>Status Input</b> 
<i>Status Input</i> Bus Dead	True when the Bus Dead condition settings have been exceeded.	<b>Status Input</b> 
















Name	Description	Symbol
<i>Status Input</i> Bus Fail	True when the Bus Fail condition settings have been exceeded.	<b>Status Input</b> BUSFAIL 
<i>Status Input</i> Bus Forward Rotation	True when the bus rotation matches the Phase Rotation setting.	<b>Status Input</b> BUSFORWARDROTATION 
<i>Status Input</i> Bus Reverse Rotation	True when the bus rotation is opposite of the Phase Rotation setting.	<b>Status Input</b> BUSREVERSEROTATION 
<i>Status Input</i> Bus Stable	True when the Bus Stable condition settings have been exceeded.	<b>Status Input</b> BUSSTABLE 
<i>Status Input</i> CANBus Bus Off	True when the CANBus bus is off.	<b>Status Input</b> CANBUSBUSOFF 
<i>Status Input</i> CANBus Error Passive	True when a passive error is annunciated by the CANBus.	<b>Status Input</b> CANBUSERRORPASSIVE 
<i>Status Input</i> Configurable Elements 1-8	True when the Configurable Element x logic element is true.	<b>Status Input</b> CONFIGELEMENT1 
<i>Status Input</i> Contact Expansion Module	Contact Expansion Module Connected. True when an optional CEM-2020 is connected to the DGC-2020ES.	<b>Status Input</b> CEMCONNECTED 
<i>Status Input</i> Cool Down Timer Active	True when the Cool Down Timer is timing out. The Cool Down Timer is true under two circumstances: <ol style="list-style-type: none"> <li>1. The unit is in auto and ATS is removed, causing the DGC-2020ES to go into a cooldown state.</li> <li>2. The engine is running (in RUN or AUTO mode with ATS applied) and the load has been removed (i.e. the EPSSUPLOAD status input is false due to small load). If the load is reapplied, the Cool Down Timer stops and resets, and it will restart when the load is removed the next time.</li> </ol>	<b>Status Input</b> CDOWNTMRACT 
<i>Status Input</i> Emergency Stop	True when the Emergency Stop button has been pressed.	<b>Status Input</b> EMERGSTOP 
<i>Status Input</i> Engine Running	True while the Engine is Running.	<b>Status Input</b> ENGRUNNING 
<i>Status Input</i> EPS Supplying Load	True while the EPS is supplying load.	<b>Status Input</b> EPSSUPLOAD 
<i>Status Input</i> Front Panel Buttons	True while the <i>Auto</i> front panel button is pressed.	<b>Status Input</b> AUTOBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Down</i> front panel button is pressed.	<b>Status Input</b> DOWNBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Edit</i> front panel button is pressed.	<b>Status Input</b> EDITBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Up and Down</i> front panel buttons are simultaneously pressed.	<b>Status Input</b> LAMPBUTTON 










Name	Description	Symbol
<i>Status Input</i> Front Panel Buttons	True while the <i>Off</i> front panel button is pressed.	<b>Status Input</b> OFFBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Back</i> front panel button is pressed.	<b>Status Input</b> RESETBUTTON 
<i>Status Input</i> Restart Delay Active	True when the restart delay is currently active.	<b>Status Input</b> RESTARTDELAYACTIVE 
<i>Status Input</i> Front Panel Buttons	True while the <i>Run</i> front panel button is pressed.	<b>Status Input</b> RUNBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Back and Edit</i> front panel buttons are simultaneously pressed.	<b>Status Input</b> SILENCEBUTTON 
<i>Status Input</i> Front Panel Buttons	True while the <i>Up</i> front panel button is pressed.	<b>Status Input</b> UPBUTTON 
<i>Status Input</i> Fuel Leak	True when the Fuel Leak Detect input is true.	<b>Status Input</b> FUELLEAK 
<i>Status Input</i> Generator Breaker Status	True when the generator breaker is closed.	<b>Status Input</b> GENBREAKERSTATUS 
<i>Status Input</i> Generator Dead	True when the Gen Dead condition settings have been exceeded.	<b>Status Input</b> GENDEAD 
<i>Status Input</i> Generator Fail	True when the Gen Fail condition settings have been exceeded.	<b>Status Input</b> GENFAIL 
<i>Status Input</i> Generator Forward Rotation	True when the generator rotation matches the Phase Rotation setting.	<b>Status Input</b> GENFORWARDROTATION 
<i>Status Input</i> Generator Protection	True when the 27 element is tripped.	<b>Status Input</b> 27UNDRVLTTTRIPSTATUS 
<i>Status Input</i> Generator Protection	True when the 59 element is tripped.	<b>Status Input</b> 59OVOLTTRIPSTATUS 
<i>Status Input</i> Generator Protection	True when the 47 element is tripped.	<b>Status Input</b> 47PH_IMBTRIPSTATUS 
<i>Status Input</i> Generator Protection	True when the 50 element is tripped.	<b>Status Input</b> 50OCURRTTRIPSTATUS 
<i>Status Input</i> Generator Protection	True when the 81 Over element is tripped.	<b>Status Input</b> 81OFRQTRIPSTATUS 
<i>Status Input</i> Generator Protection	True when the 81 Under element is tripped.	<b>Status Input</b> 81UFRQTRIPSTATUS 

Name	Description	Symbol
<i>Status Input</i> Generator Reverse Rotation	True when the generator rotation is opposite of the Phase Rotation setting.	<b>Status Input</b> GENREVERSEROTATION 
<i>Status Input</i> Generator Stable	True when the Gen Stable condition settings have been exceeded.	<b>Status Input</b> GENSTABLE 
<i>Status Input</i> Generator Test Loaded	True when the Exercise Timer has started the generator and run with load is selected.	<b>Status Input</b> GENTESTLOADED 
<i>Status Input</i> Generator Test	True when the Exercise Timer has started the generator.	<b>Status Input</b> GENTEST 
<i>Status Input</i> Global Low Coolant Level	True when the Low Coolant Level input is true.	<b>Status Input</b> GLBLOWCOOLLVL 
<i>Status Input</i> Ground Delta Override	True when the Grounded Delta Override input is true.	<b>Status Input</b> GNDDLTAORIDE 
<i>Status Input</i> Idle Request	True when the Idle Request logic element is true.	<b>Status Input</b> IDLEREQUESTIN 
<i>Status Input</i> In Alarm State	True when the DGC-2020ES is in the alarm state.	<b>Status Input</b> INALARMSTATE 
<i>Status Input</i> In Connecting State	True when the DGC-2020ES is in the connecting state.	<b>Status Input</b> INCONNECTINGSTATE 
<i>Status Input</i> In Cooling State	True when the DGC-2020ES is in the cooling state.	<b>Status Input</b> INCOOLINGSTATE 
<i>Status Input</i> In Cranking State	True when the DGC-2020ES is in the cranking state.	<b>Status Input</b> INCRANKINGSTATE 
<i>Status Input</i> In Disconnect State	True when the DGC-2020ES is in the disconnect state.	<b>Status Input</b> INDISCONNECTSTATE 
<i>Status Input</i> In Prestart State	True when the DGC-2020ES is in the pre-start state.	<b>Status Input</b> INPRESTARTSTATE 
<i>Status Input</i> In Pulsing State	True when the DGC-2020ES is in the pulsing state.	<b>Status Input</b> INPULSINGSTATE 
<i>Status Input</i> In Ready State	True when the DGC-2020ES is in the ready state.	<b>Status Input</b> INREADYSTATE 
<i>Status Input</i> In Resting State	True when the DGC-2020ES is in the resting state.	<b>Status Input</b> INRESTINGSTATE 
<i>Status Input</i> In Running State	True when the DGC-2020ES is in the running state.	<b>Status Input</b> INRUNNINGSTATE 
<i>Status Input</i> Lamp Test	True when the Lamp Test logic element is true or the Lamp Test button is pressed on the front panel.	<b>Status Input</b> LAMPTESTIN 

Name	Description	Symbol
<i>Status Input</i> Load Take Over	True when the Load Take Over logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Low Line Override	True when the Low Line Override input is true.	<b>Status Input</b> 
<i>Status Input</i> Mains Breaker Status	True when the mains breaker is closed.	<b>Status Input</b> 
<i>Status Input</i> Mains Fail Test	True when the Mains Fail Test logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Mains Fail Transfer Complete	True when the DGC-2020ES is configured for mains fail transfers and has successfully transferred to the generator from the utility. It remains true until the utility power is deemed good and the DGC-2020ES transfers the load back to utility power.	<b>Status Input</b> 
<i>Status Input</i> Off Mode	True when the DGC-2020ES is in Off Mode or the Off Mode logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Off Mode Cooldown	True when the DGC-2020ES is in Off Mode and cooling down.	<b>Status Input</b> 
<i>Status Input</i> Pre Start Condition in Effect	True while in the Pre Start state.	<b>Status Input</b> 
<i>Status Input</i> Pre Start Input	True when the DGC-2020ES is indicating that the Pre Start relay should be closed.	<b>Status Input</b> 
<i>Status Input</i> Reset Active	True when the Reset logic element is true or when the Reset key on the front panel is pressed.	<b>Status Input</b> 
<i>Status Input</i> Restart Delay Active	True when the Restart Delay timer is timing out.	<b>Status Input</b> 
<i>Status Input</i> Run Input	True when the DGC-2020ES is indicating that the Run relay should be closed.	<b>Status Input</b> 
<i>Status Input</i> Run Mode	True when the DGC-2020ES is in Run Mode or the Run Mode logic element is true.	<b>Status Input</b> 
<i>Status Input</i> Single Phase Connection Override	True when the Single Phase Override input is true.	<b>Status Input</b> 
<i>Status Input</i> Switch not in Auto	True when the DGC-2020ES is not in Auto Mode.	<b>Status Input</b> 
<i>Status Input</i> Start Input	True when the DGC-2020ES is indicating that the Start relay should be closed to start the engine.	<b>Status Input</b> 

Name	Description	Symbol
<b>Output Objects</b>		
<i>Physical Outputs</i> OUT1 – OUT4	Physical Outputs 1 through 4.	<b>Output - OUT1</b> 
<i>Remote Outputs</i> OUT5 – OUT28	Remote Outputs 5 through 28. (Available when an optional CEM-2020 is connected.)	<b>Output - OUT5</b> 
<b>Alarms</b>		
Auto Restart Fail	True after the Automatic Restart function fails to restart the generator.	<b>Alarm</b> 
Battery Charger Fail	True when the Battery Charger Fail function is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
Coolant Level Sender Fail	True when a low coolant level error status code is received from the ECU. CANBus must be enabled.	<b>Alarm</b> 
Coolant Temp Sender Fail	True when the Coolant Temp Sender Fail is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
ECU Comm Loss	True when communication to ECU has been lost.	<b>Alarm</b> 
ECU Shutdown	True when ECU has Shutdown the engine.	<b>Alarm</b> 
Emergency Stop	True when the Emergency Stop button has been pressed.	<b>Alarm</b> 
Fuel Leak	True when the Fuel Leak Detect function is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
Fuel Level Sender Fail	True when the Fuel Level Sender Fail is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
<i>Generator Protection</i> 27	True when the 27 element is configured as an alarm and has tripped.	<b>Alarm</b> 
<i>Generator Protection</i> 59	True when the 59 element is configured as an alarm and has tripped.	<b>Alarm</b> 
<i>Generator Protection</i> 47	True when the 47 element is configured as an alarm and has tripped.	<b>Alarm</b> 
<i>Generator Protection</i> 50	True when the 50 element is configured as an alarm and has tripped.	<b>Alarm</b> 
<i>Generator Protection</i> 81 Over	True when the 81 Over element is configured as an alarm and has tripped.	<b>Alarm</b> 
<i>Generator Protection</i> 81 Under	True when the 81 Under element is configured as an alarm and has tripped.	<b>Alarm</b> 

Name	Description	Symbol
Global Alarm	True when one or more alarms are set.	<b>Alarm</b> 
Global Sender Fail	True when one or more of the Sender Fails are configured as alarms and are true.	<b>Sender Fail</b> 
Hi Coolant Temp	True when the High Coolant Temp Alarm settings have been exceeded.	<b>Alarm</b> 
Low Coolant Level	True when the Low Coolant Level function is configured as an alarm and the activation delay has expired. In addition, true when CANBus is enabled and the Low Coolant Level Alarm threshold has been exceeded.	<b>Alarm</b> 
Low Fuel Level	True when the Low Fuel Level Alarm settings have been exceeded.	<b>Alarm</b> 
Low Oil Pressure	True when the Low Oil Pressure Alarm settings have been exceeded.	<b>Alarm</b> 
Oil Pressure Sender Fail	True when the Oil Pressure Sender Fail is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
Overcrank	True when an Overcrank condition exists.	<b>Alarm</b> 
Overspeed	True when the Overspeed Alarm settings have been exceeded.	<b>Alarm</b> 
Speed Sender Fail	True when the Speed Sender Fail activation delay has expired.	<b>Alarm</b> 
Unexpected Shutdown Alarm	True when the metered engine speed (RPM) unexpectedly drops to 0 while the engine is running.	<b>Alarm</b> 
Voltage Sensing Fail	True when the Voltage Sensing Fail is configured as an alarm and the activation delay has expired.	<b>Alarm</b> 
<b>Pre-Alarms</b>		
Battery Charger Fail	True when the Battery Charger Fail function is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> 
Battery Overvoltage	True when the Battery Overvoltage pre-alarm threshold has been exceeded.	<b>Pre-Alarm</b> 
Checksum Failure	True when some of the user settings or firmware code has been corrupted. Refer to the <i>Reporting and Alarms</i> chapter for more details.	<b>Pre-Alarm</b> 
<i>Contact Expansion Module</i> Multiple Contact Expansion Modules Connected	True when more than one CEM-2020 is connected.	<b>Pre-Alarm</b> 

Name	Description	Symbol
<i>Contact Expansion Module</i> Contact Expansion Module Comm Fail	True when communication from the CEM-2020 to the DGC-2020ES has been lost.	<b>Pre-Alarm</b> 
<i>Contact Expansion Module</i> Contact Expansion Modules Hardware Mismatch	True when the connected CEM-2020 does not have the same number of outputs as defined on the <i>System Parameters, Remote Module Setup</i> screen in <i>BESTCOMSPlus</i> .	<b>Pre-Alarm</b> 
Coolant Temp Sender Fail	True when the Coolant Temp Sender Fail is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> 
DEF Engine Derate	This is the lowest level of inducement not to operate the engine when Diesel Exhaust Fluid (DEF) is low or of poor quality or there is a problem with the Exhaust After Treatment System (EATS). The engine is operating in a reduced power mode. Eventually the level of inducement will be increased unless the problem with the DEF or malfunction in the EATS is corrected.	<b>Pre-Alarm</b> 
DEF Fluid Empty	True when the engine ECU reports via CANBus that Diesel Exhaust Fluid (DEF) is at a level below 8%.	<b>Pre-Alarm</b> 
DEF Fluid Low	True when the engine ECU reports via CANBus that the Diesel Exhaust Fluid (DEF) is at a level between 8 and 23%.	<b>Pre-Alarm</b> 
DEF Inducement Override	This pre-alarm indicates a temporary override of inducement not to operate the engine. This is set by the ECU and is not a user setting.	<b>Pre-Alarm</b> 
DEF Pre-severe Inducement	This pre-alarm indicates a high level of inducement not to operate the engine due to low or poor quality Diesel Exhaust Fluid (DEF), or a malfunction in the Exhaust After Treatment System (EATS). The engine may operate in a reduced power mode, or for a limited time, after which it will enter a state of severe inducement unless the problem with the DEF or malfunction in the EATS is corrected.	<b>Pre-Alarm</b> 
DEF Severe Inducement	This pre-alarm indicates the highest level of inducement not to operate the engine due to low or poor quality Diesel Exhaust Fluid (DEF), or a malfunction in the Exhaust After Treatment System (EATS). The engine may operate in a reduced power mode, or for a limited time, or may be prevented from starting by the ECU until the problem is corrected. A service tool may be required to restart the engine.	<b>Pre-Alarm</b> 
Diag Trouble Code	True when a Diagnostic Trouble Code exists.	<b>Pre-Alarm</b> 
DPF Regenerate Disabled	True when the Diesel Particulate Filter (DPF) lamp status broadcast over CANBus indicates that DPF regeneration is inhibited.	<b>Pre-Alarm</b> 

Name	Description	Symbol
DPF Regenerate Required	True when the Diesel Particulate Filter (DPF) lamp status broadcast over CANBus indicates that DPF regeneration is required.	<b>Pre-Alarm</b> DPFREGENREQPALM 
DPF Soot Level High	True when the engine ECU reports via CANBus that Diesel Particulate Filter (DPF) soot level is high.	<b>Pre-Alarm</b> DPFSOOTHIPALM 
DPF Soot Level Moderately High	True when Diesel Particulate Filter (DPF) lamp status (yellow warning) broadcast over CANBus indicates that the soot level is moderately high.	<b>Pre-Alarm</b> DPFSOOTMODHIPALM 
DPF Soot Level Severely High	True when Diesel Particulate Filter (DPF) lamp status (red warning) broadcast over CANBus indicates that the soot level is severely high.	<b>Pre-Alarm</b> DPFSOOTEXTHIPALM 
ECU Comm Loss	True when communication to ECU has been lost.	<b>Pre-Alarm</b> LOSSECUCOMMPALM 
Fuel Leak	True when the Fuel Leak Detect function is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> FUELLEAKPALM 
Fuel Level Sender Fail	True when the Fuel Level Sender Fail is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> FUELLENDFAILPALM 
Generator Breaker Close Fail	True when a generator breaker close fail pre-alarm occurs. The pre-alarm occurs when the DGC-2020ES has issued a generator breaker close output but does not receive a generator breaker status input that indicates the breaker has closed before the breaker close wait time has expired.	<b>Pre-Alarm</b> GENBRKCLOSEFAIL 
Generator Breaker Open Fail	True when a generator breaker open fail pre-alarm occurs. The pre-alarm occurs when the DGC-2020ES has issued a generator breaker open output but does not receive a generator breaker status input that indicates the breaker has opened before the breaker close wait time has expired.	<b>Pre-Alarm</b> GENBRKOPENFAIL 
<i>Generator Protection 27</i>	True when the 27 element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 27UNDRVLTALM 
<i>Generator Protection 59</i>	True when the 59 element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 59OVOLTPALM 
<i>Generator Protection 47</i>	True when the 47 element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 47PH_IMBPALM 
<i>Generator Protection 50</i>	True when the 50 element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 50OCCURPALM 
<i>Generator Protection 81 Over</i>	True when the 81 Over element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 81OFRQPALM 
<i>Generator Protection 81 Under</i>	True when the 81 Under element is configured as a pre-alarm and has tripped.	<b>Pre-Alarm</b> 81UFRQPALM 
Global Pre-Alarm	True when one or more pre-alarms are set.	<b>Pre-Alarm</b> GLBPALM 

Name	Description	Symbol
Hi Coolant Temp	True when the High Coolant Temp Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> HITEMPPALM 
High Exhaust Temperature	True when Diesel Particulate Filter (DPF) lamp status broadcast over CANBus indicates high exhaust temperature.	<b>Pre-Alarm</b> HIGHEXHTEMPALM 
High Fuel Level	True when the High Fuel Level Pre-Alarm settings have been exceeded.	<b>Pre-Alarm</b> HIFUELLPALM 
Low Battery Voltage	True when the Low Battery Voltage Pre-Alarm settings have been exceeded.	<b>Pre-Alarm</b> LOWBATVPALM 
Low Coolant Level	True when the Low Coolant Level function is configured as a pre-alarm and the activation delay has expired. In addition, true when CANBus is enabled and the Low Coolant Level Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> LOWCOOLLVLPALM 
Low Coolant Temp	True when the Low Coolant Temp Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> LOWTEMPPALM 
Low Fuel Level	True when the Low Fuel Level Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> LOWFUELLPALM 
Low Oil Pressure	True when the Low Oil Pressure Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> LOWOILPRPALM 
Mains Breaker Close Fail	True when a mains breaker close fail pre-alarm occurs. The pre-alarm occurs when the DGC-2020ES has issued a mains breaker close output but does not receive a mains breaker status input that indicates the breaker has closed before the breaker close wait time has expired.	<b>Pre-Alarm</b> MAINBRKCLOSEFAIL 
Mains Breaker Open Fail	True when a mains breaker open fail pre-alarm occurs. The pre-alarm occurs when the DGC-2020ES has issued a mains breaker open output but does not receive a mains breaker status input that indicates the breaker has opened before the breaker close wait time has expired.	<b>Pre-Alarm</b> MAINBRKOPENFAIL 
Mains Fail Transfer Failed	True when a mains fail transfer fail pre-alarm occurs. The pre-alarm occurs when the DGC-2020ES is configured for mains fail transfers, but has not transferred to the generator from the utility before the Mains Fail Max Transfer Time has expired. It remains true until the pre-alarm is cleared by pressing the <i>Reset</i> button on the front panel.	<b>Pre-Alarm</b> MAINSFLTRFAIL 
Maintenance Interval	True when the Maintenance Interval Pre-Alarm threshold has been exceeded.	<b>Pre-Alarm</b> MAINTINTPALM 
MPU Fail	True when the MPU has failed.	<b>Pre-Alarm</b> MPUFAILPALM 
Oil Pressure Sender Fail	True when the Oil Pressure Sender Fail is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> OILPRESSENDFAILPALM 
Reverse Rotation	True when the generator rotation is opposite of the Phase Rotation setting.	<b>Pre-Alarm</b> GENREVERSEROTATIONPALM 








Name	Description	Symbol
Voltage Sensing Fail	True when the Voltage Sensing Fail is configured as a pre-alarm and the activation delay has expired.	<b>Pre-Alarm</b> VOLTSSENSFAILPALM
Weak Battery	True when the Weak Battery Voltage Pre-Alarm settings have been exceeded.	<b>Pre-Alarm</b> WEAKBATPALM
<b>Senders</b>		
Coolant Temp Sender Fail	True when the Coolant Temp Sender Fail is configured as either a pre-alarm or alarm and the activation delay has expired.	<b>Sender Fail</b> COOLTEMPSEDFAIL
Fuel Level Sender Fail	True when the Fuel Level Sender Fail is configured as either a pre-alarm or alarm and the activation delay has expired.	<b>Sender Fail</b> FUELLESEDFAIL
Oil Pressure Sender Fail	True when the Oil Pressure Sender Fail is configured as either a pre-alarm or alarm and the activation delay has expired.	<b>Sender Fail</b> OILPRESSEDFAIL
Speed Sender Fail	True when the Speed Sender Fail activation delay has expired.	<b>Sender Fail</b> SPDSEDFAIL
Voltage Sensing Fail	True when the Voltage Sensing Fail is configured as either a pre-alarm or alarm and the activation delay has expired.	<b>Sender Fail</b> VOLTSSENSFAIL
<b>Logic Control Relays</b>		
<p>The logic control relays (LCR) consist of LCR outputs and LCR inputs. The output can be used to terminate the “output” end of a logic network, and then use the corresponding input as an input to logic elsewhere in the logic scheme. When a given LCR output is true the corresponding LCR input is true. In other words, when LCR Output N (N being a number from 1 to 16) becomes true, then LCR Input N is true also. If you get a “too many logic levels” error while building a logic network, LCR outputs and inputs can be used as a solution to this problem. Place an LCR output on the end of the partial logic network and then use the corresponding LCR input to build more logic than was previously possible.</p>		
<i>Inputs</i> Input 1-16	See description above.	<b>LCR Input</b> LCRINPUT1
<i>Outputs</i> Output 1-16	See description above.	<b>LCR Output</b> LCROUTPUT1


### Components

This group contains Logic Gates, Pickup and Dropout Timers, Latches, and Comment Blocks. Table 24 lists the names and descriptions of the objects in the *Components* group.

**Table 24. Components Group, Names and Descriptions**

Name	Description	Symbol										
<b>Logic Gates</b>												
AND	<table border="1"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0   0</td> <td>0</td> </tr> <tr> <td>0   1</td> <td>0</td> </tr> <tr> <td>1   0</td> <td>0</td> </tr> <tr> <td>1   1</td> <td>1</td> </tr> </tbody> </table>	Input	Output	0   0	0	0   1	0	1   0	0	1   1	1	
Input	Output											
0   0	0											
0   1	0											
1   0	0											
1   1	1											

Name	Description	Symbol										
NAND	<table border="1" data-bbox="662 216 862 373"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0 0</td> <td>1</td> </tr> <tr> <td>0 1</td> <td>1</td> </tr> <tr> <td>1 0</td> <td>1</td> </tr> <tr> <td>1 1</td> <td>0</td> </tr> </tbody> </table>	Input	Output	0 0	1	0 1	1	1 0	1	1 1	0	
Input	Output											
0 0	1											
0 1	1											
1 0	1											
1 1	0											
OR	<table border="1" data-bbox="662 390 862 548"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0 0</td> <td>0</td> </tr> <tr> <td>0 1</td> <td>1</td> </tr> <tr> <td>1 0</td> <td>1</td> </tr> <tr> <td>1 1</td> <td>1</td> </tr> </tbody> </table>	Input	Output	0 0	0	0 1	1	1 0	1	1 1	1	
Input	Output											
0 0	0											
0 1	1											
1 0	1											
1 1	1											
NOR	<table border="1" data-bbox="662 564 862 722"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0 0</td> <td>1</td> </tr> <tr> <td>0 1</td> <td>0</td> </tr> <tr> <td>1 0</td> <td>0</td> </tr> <tr> <td>1 1</td> <td>0</td> </tr> </tbody> </table>	Input	Output	0 0	1	0 1	0	1 0	0	1 1	0	
Input	Output											
0 0	1											
0 1	0											
1 0	0											
1 1	0											
XOR	<table border="1" data-bbox="662 739 862 896"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0 0</td> <td>0</td> </tr> <tr> <td>0 1</td> <td>1</td> </tr> <tr> <td>1 0</td> <td>1</td> </tr> <tr> <td>1 1</td> <td>0</td> </tr> </tbody> </table>	Input	Output	0 0	0	0 1	1	1 0	1	1 1	0	
Input	Output											
0 0	0											
0 1	1											
1 0	1											
1 1	0											
XNOR	<table border="1" data-bbox="662 913 862 1071"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0 0</td> <td>1</td> </tr> <tr> <td>0 1</td> <td>0</td> </tr> <tr> <td>1 0</td> <td>0</td> </tr> <tr> <td>1 1</td> <td>1</td> </tr> </tbody> </table>	Input	Output	0 0	1	0 1	0	1 0	0	1 1	1	
Input	Output											
0 0	1											
0 1	0											
1 0	0											
1 1	1											
NOT (INVERTER)	<table border="1" data-bbox="662 1087 862 1182"> <thead> <tr> <th>Input</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1</td> </tr> <tr> <td>1</td> <td>0</td> </tr> </tbody> </table>	Input	Output	0	1	1	0					
Input	Output											
0	1											
1	0											
<b>Pickup and Dropout Timers</b>												
Drop Out Timer	Used to set a delay in the logic. For more information, refer to <i>Programming BESTlogicPlus, Pickup and Dropout Timers</i> , later in this section.											
Pickup Up Timer	Used to set a delay in the logic. For more information, refer to <i>Programming BESTlogicPlus, Pickup and Dropout Timers</i> , later in this section.											
<b>Latches</b>												
Reset Priority Latch	When the Set input is on and the Reset input is off, the latch will go to the SET (ON) state. When the Reset input is on and the Set input is off, the latch will go to the RESET (OFF) state. If both the Set and Reset inputs are on at the same time, a reset priority latch will go to the RESET (OFF) state.											


Name	Description	Symbol
Set Priority Latch	When the Set input is on and the Reset input is off, the latch will go to the SET (ON) state. When the Reset input is on and the Set input is off, the latch will go to the RESET (OFF) state. If both the Set and Reset inputs are on at the same time, a set priority latch will go to the SET (ON) state.	
<b>Other</b>		
Comment Block	Enter user comments.	

## Elements

This group contains elements for the 27, 47, 50, 59, and 81. It also contains elements for Generator Breaker, Mains Breaker, Logic Alarm, Logic Pre-Alarm, Configurable Elements, AUTO Mode, OFF Mode, RUN Mode, Run with Load, Engine Run, ATS, Run Inhibit, Test Inhibit, Pre-Start Output, Start Output, Run Output, Cool Stop Request, Cool Down Request, External Start Delay, Start Delay Bypass, Alternate Frequency Override, Mains Fail Test, Load Take Over, Reset, Alarm Silence, Lamp Test, Idle Request, Low Fuel Pre-Alarm, Diesel Particulate Filter Manual Regeneration, Diesel Particulate Filter Regeneration Inhibit, Emergency Stop, Speed Raise, Speed Lower, MTU Cylinder Cutout Disable, and Automatic Breaker Operation Inhibit from PLC.




Table 25 lists the names and descriptions of the elements in the *Elements* group.




**Table 25. Elements Group, Names and Descriptions**




Name	Description	Symbol
<b>Protection</b>		
27TRIP	True when the 27-1 undervoltage is in a TRIP condition. Connect to another logic block input.	
47TRIP	True when the 47 phase imbalance is in a TRIP condition. Connect to another logic block input.	
50TRIP	True when the 50 overcurrent is in a TRIP condition. Connect to another logic block input.	
59TRIP	True when the 59-1 overvoltage is in a TRIP condition. Connect to another logic block input.	
81TRIP	True when the 81 frequency is in a TRIP condition. Connect to another logic block input.	



Name	Description	Symbol
<b>Other</b>		
ALARMSILENCE	The alarm will be silenced when this element is true. The alarm can also be silenced by pressing the Alarm Silence button on the front panel of the DGC-2020ES.	<b>ALARMSILENCE</b> 
ALTFREQOVER	When this logic element is true, protection and bus condition detection is forced to operate at the Alternate Frequency instead of the Rated Frequency.	<b>ALTFREQOVER</b> 
ATS	When this logic element is true, and the DGC-2020ES is in AUTO mode, the generator will run. This can be used in place of the ATS programmable function if it is desired to generate the ATS signal as a combination of programmable logic rather than a simple contact input. If either the ATS logic element is true <u>or</u> the contact mapped to the ATS programmable function is true, <u>and</u> the DGC-2020ES is in AUTO mode, the generator will run. If <u>both</u> the ATS logic element <u>and</u> the ATS programmable function are false, and the DGC-2020ES is in AUTO mode, the generator will cool down and stop.	<b>ATS</b> 
AUTOMODE	When this input is true, and the DGC-2020ES is in OFF mode, the DGC-2020ES will switch to AUTO mode. This is a pulsed input. It does not need to be held after the desired mode switch has occurred.	<b>AUTOMODE</b> 
AUTOBRKOP-INHIBIT	Automatic breaker operation is inhibited when the Set input is true.	<b>AUTOBRKOPINHIBIT</b> 
CONFELMNTX (X = 1 to 8)	Configurable elements (CONFELMNT1-8) are connected to the logic scheme as outputs. These elements are configurable in BESTCOMSPlus under <i>Programmable Outputs, Configurable Elements</i> . The user can assign a string of up to 16 characters, configure whether the element should generate an alarm or pre-alarm. If used for alarm or pre-alarm, the user's text is what will appear in the alarm or pre-alarm annunciation and in the DGC-2020ES event log.	<b>CONFELMNT1 CONFIG ELEMENT 1</b> 





Name	Description	Symbol
COOLSTOPREQ	<p><u>RUN Mode</u> If the unit is in RUN mode when the Cool Stop Request is received, the unit will unload, open its breaker, and go into a cooldown cycle. While in the cooldown cycle, the unit will display “COOL &amp; STOP REQ” in addition to displaying the cooldown timer. After the cooldown timer expires, the unit will go to OFF mode. The Cool Stop Request must be removed before the unit can be run again.</p> <p>If the Cool Stop Request is removed during the cooldown process, the unit will remain running. Furthermore, if a condition occurs that normally causes the unit to close its breaker in RUN mode, the unit will close its breaker and reload.</p> <p><u>AUTO Mode</u> If the unit is in AUTO mode when the Cool Stop Request is received, all conditions that would normally cause the unit to run in AUTO mode are cleared. Since all conditions that cause the unit to run have been removed, the unit goes into a cooldown cycle. While in the cooldown cycle, the unit will display “COOL &amp; STOP REQ” in addition to displaying the cooldown timer. After the cooldown timer expires, the unit will shut down, remaining in AUTO. The Cool Stop Request must be removed before the unit can be run again.</p> <p>If the Cool Stop Request is removed during the cooldown process and some condition that would normally cause the unit to run in AUTO mode is true, the unit will remain running. Furthermore, if a condition occurs that normally causes the unit to close its breaker, the unit will close its breaker and reload.</p>	<p><b>COOLSTOPREQ</b></p> 
COOLDOWNREQ	<p><u>RUN Mode</u> If the unit is in RUN mode when the Cool Down Request is received, the unit is forced to unload and open its breaker and then go into a cooldown cycle. While in the cool down cycle, the unit will display “COOLDOWN REQ” in addition to displaying the cooldown timer. After the cooldown timer expires, the unit will remain running in RUN mode. The Cool Down Request must be removed before the breaker can be closed again; this element blocks breaker closures.</p> <p>If the Cool Down Request is removed during the cool down process, the unit will remain running in RUN mode. Furthermore, if a condition occurs that normally causes the unit to close its breaker in RUN mode, the unit will close its breaker and reload.</p> <p><u>AUTO Mode</u> If the unit is in AUTO mode and the Cool Down Request is received, the unit is forced to unload and open its breaker and go into a cooldown cycle. While in the cooldown cycle, the unit will display “COOLDOWN REQ” in addition to displaying the cooldown timer. After the cool down timer expires, the unit will remain running in AUTO mode, unless there are no conditions that cause the unit to run in AUTO mode, in which case it will shut down and remain in AUTO mode. The Cool Down Request must be removed before the breaker can be closed again; this element blocks breaker closures.</p> <p>If the Cool Down Request is removed during the cool down process and some condition that would normally cause the unit to run in AUTO mode is true, the unit will remain running in AUTO mode. Furthermore, if a condition occurs that normally causes the unit to close its breaker, the unit will close its breaker and reload.</p>	<p><b>COOLDOWNREQ</b></p> 


Name	Description	Symbol
DPFMANREGEN	Diesel Particulate Filter Regeneration is forced manually when the Set input is true.	<b>DPFMANREGEN</b> 
DPFREGENINHIBIT	Diesel Particulate Filter Regeneration is inhibited when the Set input is true.	<b>DPFREGENINHIBIT</b> 
ESTOP	When this element is true, an Emergency Shutdown alarm is annunciated and the Emergency Stop LED on the RDP-110 is illuminated.	<b>ESTOP</b> 
ENGINERUN	The Start input starts the generator. No load is applied. The breaker remains open. The Stop input stops the generator. The DGC-2020ES only responds to this logic element when in AUTO mode.	<b>ENGINERUN</b> 
EXTSTARTDEL	If the Set input is true while the DGC-2020ES is in the Pre Start state, the DGC-2020ES will remain in the Pre Start state until the Set input is false.	<b>EXTSTARTDEL</b> 

Name	Description	Symbol
GENBRK	<p>This element is used to connect the breaker open and close output signals from the DGC-2020ES to physical output contacts to open and close the generator breaker, and map breaker status feedback to a contact input. In addition, contact inputs can be mapped to allow switches to be implemented to manually initiate breaker open and close requests.</p> <p><u>Inputs</u></p> <p><i>Status</i>: This input allows a contact input to be mapped that will provide breaker status feedback to the DGC-2020ES. When the contact input is closed, the breaker is indicated to be closed. When the contact input is open, the breaker is indicated to be open.</p> <p><i>Open</i>: This input allows a contact input to be mapped that can be used to initiate a manual breaker open request. When this input is pulsed closed while the DGC-2020ES is in RUN or AUTO mode, the breaker will open.</p> <p><i>Close</i>: This input allows a contact input to be mapped that can be used to initiate a manual breaker close request. When this input is pulsed and the DGC-2020ES is in AUTO or RUN mode, and the generator is stable, a close request will be initiated. If bus is dead, the breaker will close; if the bus is not dead the generator breaker will not be closed.</p> <p><u>Outputs</u></p> <p>The outputs must be mapped to the contact outputs of the DGC-2020ES that will be used to drive the breaker.</p> <p><i>Open</i>: This output is pulsed true (closes the output contact it is mapped to) when the DGC-2020ES is providing a signal to the breaker to open. It will be a pulse if the Breaker Output Contact Type is set to Pulse on the Breaker Hardware screen under Breaker Management in the Settings Explorer, and the length is determined by the Open Pulse Time. It will be a constant output if the Generator Breaker Hardware Contact Type is set to continuous. Note the pulse time must be set long enough for the breaker to actually open before the pulse is removed.</p> <p><i>Close</i>: This output is pulsed true (closes the output contact it is mapped to) when the DGC-2020ES is providing a signal to the breaker to close. It will be a pulse if the Breaker Output Contact Type is set to Pulse on the Breaker Hardware screen under Breaker Management in the Settings Explorer, and the length is determined by the Open Pulse Time. It will be a constant output if the Generator Breaker Hardware Contact Type is set to continuous. Note the pulse time must be set long enough for the breaker to actually open before the pulse is removed.</p>	 <p>The diagram shows a rectangular box labeled 'GENBRK'. On the left side, there are three red triangles pointing right, representing inputs. The top input is labeled 'Status' and has 'Open' written to its right. The middle input is labeled 'Open' and has 'Close' written to its right. The bottom input is labeled 'Close'.</p>
IDLEREQUEST	<p>When this element is true, the DGC-2020ES sends an idle request to the ECU on J1939 engines that are equipped to receive such a request. The request consists of an enable bit command and an idle RPM setting. At this time, only Volvo and Cummins are implemented. ECUs that accept the idle RPM setting set the engine to the requested RPM. ECUs that accept only the enable bit command, set the engine to their internal idle speed setting, ignoring the requested idle RPM from the DGC-2020ES.</p>	 <p>The diagram shows a rectangular box labeled 'IDLEREQUEST'. On the left side, there is a red triangle pointing right, representing an input labeled 'Set'.</p>
LAMPTEST	<p>The lamp test will be performed when this element is true. The lamp test can also be accomplished by simultaneously pressing the <i>Up</i> and <i>Down</i> buttons on the front panel of the DGC-2020ES.</p>	 <p>The diagram shows a rectangular box labeled 'LAMPTEST'. On the left side, there is a red triangle pointing right, representing an input labeled 'Set'.</p>

Name	Description	Symbol
LOADTAKEOVER	When this logic element is true, the generator is forced to start, assume load, and disconnect from the mains, in an open transition.	<b>LOADTAKEOVER</b> 
LOGICALM	When this input is true, the DGC-2020ES goes into an alarm condition.	<b>LOGICALM</b> 
LOGICPALM	When this input is true, the DGC-2020ES goes into a Pre-alarm condition.	<b>LOGICPALM</b> 
LOWFUELPALM	When this element is true, a Low Fuel Pre-Alarm is annunciated and the Low Fuel Level LED on the RDP-110 is illuminated.	<b>LOWFUELPALM</b> 
MAINSFAILTEST	When this element is true, the DGC-2020ES will exercise its mains fail transfer function exactly as it would if the mains were to fail on a mains fail machine. This can be used as a test of the mains fail transfer capability of the unit without having to cause a true mains failure.	<b>MAINSFAILTEST</b> 
MAINSFLTRINHIBIT	The mains fail transfer function is inhibited when the Set input is true.	<b>MAINSFLTRINHIBIT</b> 

Name	Description	Symbol
<p><b>MAINSBRK</b></p>	<p>This element is used to connect the breaker open and close output signals from the DGC-2020ES to physical output contacts to open and close the mains breaker and map breaker status feedback to a contact input. In addition, contact inputs can be mapped to allow switches to be implemented to manually initiate breaker open and close requests. This element is only available when the Mains Breaker Hardware is configured on the <i>Breaker Hardware</i> screen via the <i>Breaker Management</i> tree branch.</p> <p><u>Inputs</u>  <i>Status</i>: This input allows a contact input to be mapped that will provide breaker status feedback to the DGC-2020ES. When the contact input is closed, the breaker is indicated to be closed. When the contact input is open, the breaker is indicated to be open.  <i>Open</i>: This input allows a contact input to be mapped that can be used to initiate a manual breaker open request. When this input is pulsed closed while the DGC-2020ES is in RUN or AUTO mode, the breaker will open.  <i>Close</i>: This input allows a contact input to be mapped that can be used to initiate a manual breaker close request. When this input is pulsed, the mains is stable, and both breakers are open, a close request will be initiated.</p> <p><u>Outputs</u>                      The outputs must be mapped to the contact outputs of the DGC-2020ES that will be used to drive the breaker.  <i>Open</i>: This output is pulsed true (closes the output contact it is mapped to) when the DGC-2020ES is providing a signal to the breaker to open. It will be a pulse if the Breaker Output Contact Type is set to Pulse on the Breaker Hardware screen under Breaker Management in the Settings Explorer, and the length is determined by the Open Pulse Time. It will be a constant output if the Mains Breaker Hardware Contact Type is set to continuous. Note the pulse time must be set long enough for the breaker to actually open before the pulse is removed.  <i>Close</i>: This output is pulsed true (closes the output contact it is mapped to) when the DGC-2020ES is providing a signal to the breaker to close. It will be a pulse if the Breaker Output Contact Type is set to Pulse on the Breaker Hardware screen under Breaker Management in the Settings Explorer, and the length is determined by the Open Pulse Time. It will be a constant output if the Mains Breaker Hardware Contact Type is set to continuous. Note the pulse time must be set long enough for the breaker to actually open before the pulse is removed.</p>	 <p>The symbol for MAINSBRK is a rectangular box with three red triangles on the left side pointing into the box. The top triangle is labeled 'Status' and 'Open' with an arrow pointing right. The middle triangle is labeled 'Open' and 'Close' with an arrow pointing right. The bottom triangle is labeled 'Close'.</p>
<p><b>MTUCYLCUTOUT-DISABLE</b> (MTU Cylinder Cutout Disable)</p>	<p>When this logic element is true, Cylinder Cutout Disable 1 and Cylinder Cutout Disable 2 are both sent to the engine ECU with true status. When this logic element is false, Cylinder Cutout Disable 1 and Cylinder Cutout Disable 2 are sent to the engine ECU with states set by the values programmed for the Cylinder Cutout Disable 1 and Cylinder Cutout Disable 2 DGC-2020ES settings which are configured on the ECU Setup screen in <i>BESTCOMSPlus</i>.</p>	 <p>The symbol for MTUCYLCUTOUTDISABLE is a rectangular box with a red triangle on the left side pointing into the box, labeled 'Set'.</p>
<p><b>OFFMODE</b></p>	<p>When this input is true, the DGC-2020ES will switch to OFF mode. This is a pulsed input. It does not need to be held after the desired mode switch has occurred.</p>	 <p>The symbol for OFFMODE is a rectangular box with a red triangle on the left side pointing into the box, labeled 'Set'.</p>

Name	Description	Symbol
PRESTARTOUT	This element is used to drive the prestart output relay from logic when the Prestart Output Relay configuration is set to "Programmable". When the Prestart Output Relay configuration is set to "Programmable", the prestart relay will not close unless logic is used to drive this element. When the Prestart Output Relay configuration is set to "Predefined", the prestart relay is closed according to the predefined prestart functionality of the DGC-2020ES. When the "Predefined" functionality is selected, the relay will not respond to this element.	<p><b>PRESTARTOUT</b></p> 
RDPPROGALM1	When true, this element illuminates the <i>Fuel Leak/Sender Failure</i> LED on the Remote Display Panel RDP-110. When this element is connected in logic, it overrides all other commands to the LED. Otherwise, the LED operates as normal.	<p><b>RDPPROGALM1</b></p> 
RDPPROGALM2	When true, this element illuminates the <i>Sender Failure</i> LED on the Remote Display Panel RDP-110. When this element is connected in logic, it overrides all other commands to the LED. Otherwise, the LED operates as normal.	<p><b>RDPPROGALM2</b></p> 
RDPPROGPREALM1	When true, this element illuminates the <i>Battery Overvoltage</i> LED on the Remote Display Panel RDP-110. When this element is connected in logic, it overrides all other commands to the LED. Otherwise, the LED operates as normal.	<p><b>RDPPROGPREALM1</b></p> 
RDPPROGPREALM2	When true, this element illuminates the <i>Battery Charger Failure</i> LED on the Remote Display Panel RDP-110. When this element is connected in logic, it overrides all other commands to the LED. Otherwise, the LED operates as normal.	<p><b>RDPPROGPREALM2</b></p> 
RESET	Reset will be active when this element is true. Reset can also be accomplished by pressing the Reset button on the front panel of the DGC-2020ES.	<p><b>RESET</b></p> 
RUNINHIBIT	When this logic element is true, the DGC-2020ES is prevented from starting and running the generator, regardless of any condition that would normally cause the generator to run. If this element is false and there is <u>any</u> condition in effect which will cause the generator to run, the DGC-2020ES will start and run the generator.	<p><b>RUNINHIBIT</b></p> 
RUNMODE	When this input is true, and the DGC-2020ES is in OFF mode, the DGC-2020ES will switch to RUN mode. This is a pulsed input. It does not need to be held after the desired mode switch has occurred.	<p><b>RUNMODE</b></p> 
RUNOUTPUT	This element is used to drive the run output relay from logic when the Run Output Relay configuration is set to "Programmable". When the Run Output Relay configuration is set to "Programmable", the run relay will not close unless logic is used to drive this element. When the Run Output Relay configuration is set to "Predefined", the run relay is closed according to the predefined run functionality of the DGC-2020ES. When the "Predefined" functionality is selected, the relay will not respond to this element.	<p><b>RUNOUTPUT</b></p> 
RUNWLOAD	The Start input starts the generator and closes the Gen breaker. The Stop input stops the generator and opens the Gen breaker. The DGC-2020ES only responds to this logic element when in AUTO mode.	<p><b>RUNWLOAD</b></p> 

Name	Description	Symbol
SPEEDLOWER	This element lowers the speed setting of the DGC-2020ES by up to 2 rpm per second. After the speed has not been lowered for 30 seconds, the modified speed is saved to nonvolatile memory.	<b>SPEEDLOWER</b> 
SPEEDRAISE	This element raises the speed setting of the DGC-2020ES by up to 2 rpm per second. After the speed has not been raised for 30 seconds, the modified speed is saved to nonvolatile memory.	<b>SPEEDRAISE</b> 
STARTDELBYB	This element allows the Pre Start state to be skipped based on logic. For example, a start delay may not be necessary when the engine is warm. This also allows an external device, such as an ECU, to control the pre start interval.	<b>STARTDELBYB</b> 
STARTOUTPUT	This element is used to drive the start output relay from logic when the Start Output Relay configuration is set to "Programmable". When the Start Output Relay configuration is set to "Programmable", the start relay will not close unless logic is used to drive this element. When the Start Output Relay configuration is set to "Predefined", the start relay is closed according to the predefined start functionality of the DGC-2020ES. When the "Predefined" functionality is selected, the relay will not respond to this element.	<b>STARTOUTPUT</b> 
TESTINHIBIT	When this logic element is true, the generator exercise timer cannot start the generator. If the TESTINHIBIT logic function is false during an exercise period, or transitions from true to false at any time during an exercise period, the DGC-2020ES will start and run the generator for the duration of the exercise period.	<b>TESTINHIBIT</b> 

## Logic Schemes

A logic scheme is a group of logic variables written in equation form that defines the operation of a DGC-2020ES Digital Genset Controller. Each logic scheme is given a unique name. This gives you the ability to select a specific scheme and be confident that the selected scheme is in operation. One logic scheme is configured for typical control applications and is the default active logic scheme. Only one logic scheme can be active at a given time. In most applications, preprogrammed logic schemes eliminate the need for custom programming. Preprogrammed logic schemes may provide more inputs, outputs, or features than are needed for a particular application. This is because a preprogrammed scheme is designed for a large number of applications with no special programming required. Unneeded logic block outputs may be left open to disable a function or a function block can be disabled through operating settings.

When a custom logic scheme is required, programming time is reduced by modifying the default logic scheme.

### The Active Logic Scheme

Digital Genset Controllers must have an active logic scheme in order to function. All Basler Electric DGC-2020ES units are delivered with a default, active logic scheme pre-loaded in memory. If the function block configuration and output logic of the default logic scheme meets the requirements of your application, then only the operating settings (power system parameters and threshold settings) need to be adjusted before placing the DGC-2020ES in service.

### Copying and Renaming Preprogrammed Logic Schemes

Copying a saved logic scheme to the active logic and assigning a unique name is accomplished by loading the saved logic scheme into BESTCOMSP*lus* and then typing over the logic scheme's name. Changes are not activated until the new settings have been saved and uploaded to the device.

## Sending and Retrieving Logic Schemes

To retrieve settings from the DGC-2020ES, it must be connected to a computer through a communications port. Once the necessary connections are made, settings can be downloaded from the DGC-2020ES by selecting *Download Settings and Logic* on the *Communication* pull-down menu.

To send settings to the DGC-2020ES, it must be connected to a computer through a communications port. Once the necessary connections are made, settings can be uploaded to the DGC-2020ES by selecting *Upload Settings and Logic* on the *Communication* pull-down menu.

### Caution

Always remove the DGC-2020ES from service prior to changing or modifying the active logic scheme. Attempting to modify a logic scheme while the DGC-2020ES is in service could generate unexpected or unwanted outputs.

Modifying a logic scheme in *BESTCOMSPPlus* does not automatically make that scheme active in the DGC-2020ES. The modified scheme must be uploaded into the DGC-2020ES.

## Programming *BESTlogic™Plus*

Use *BESTCOMSPPlus* to program *BESTLogicPlus*. Using *BESTCOMSPPlus* is analogous to physically attaching wire between discrete DGC-2020ES terminals. To program *BESTLogicPlus*, use the Settings Explorer within *BESTCOMSPPlus* to open the *BESTLogicPlus Programmable Logic* tree branch as shown in Figure 65.

The drag and drop method is used to connect a variable or series of variables to the logic inputs, outputs, components, and elements. To draw a wire/link from port to port (triangles), click the left mouse button on a port, pull the wire onto another port, and release the left mouse button. A red port indicates that a connection to the port is required or missing. A black port indicates that a connection to the port is not required. Drawing wires/links from input to input or output to output is not allowed. Only one wire/link can be connected to any one output. If the proximity of the endpoint of the wire/link is not exact, it may attach to an unintended port.

If an object or element is disabled, it will have a yellow X on it. To enable the element, navigate to the settings page for that element. A red X indicates that an object or element is not available per the style number of the DGC-2020ES.

The view of the Main Logic, Physical Outputs, Remote Outputs, and LCR Outputs can be automatically arranged by clicking the right mouse button on the window and selecting *Auto-Layout*.

The following must be met before *BESTCOMSPPlus* will allow logic to be uploaded to the DGC-2020ES:

- A minimum of two inputs and a maximum of four inputs on any multi-port (AND, OR, NAND, NOR, XOR, and XNOR) gate.
- A maximum of five logic levels for any particular path. A path being an input block or an output side of an element block through gates to an output block or an input side of an element block. This is to include any OR gates on the Physical Output or Remote Output tab/pages, but not the matched pairs of Physical Output blocks or Remote Output blocks.
- Only 10 gates per logic level. All output blocks and input sides of element blocks are at the maximum logic level of the diagram. All gates are pushed forward/upwards in logic levels and buffered to reach the final output block or element block if needed. A maximum of 50 gates allowed per diagram.

- At all levels there can only be 64 used link/wired or endpoints. Endpoints being inputs, outputs, both sides of element blocks.

Three status LEDs are located in the lower right corner of the BESTlogicPlus window. These LEDs show the *Logic Save Status*, *Logic Diagram Status*, and *Logic Layer Status*. Table 26 defines the colors for each LED.

**Table 26. Status LEDs**

LED	Color	Definition
Logic Save Status (Left LED)	Orange	Logic has changed since last save.
	Green	Logic has NOT changed since last save.
Logic Diagram Status (Center LED)	Red	Requirements NOT met as listed above.
	Green	Requirements met as listed above.
Logic Layer Status (Right LED)	Red	Requirements NOT met as listed above.
	Green	Requirements met as listed above.

### Pickup and Dropout Timers

A pickup timer produces a true output when the elapsed time is greater than or equal to the Pickup Time setting after a false to true transition occurs on the Initiate input from the connected logic. Whenever the Initiate input status transitions to false, the output transitions to false immediately.


A drop out timer produces a true output when the elapsed time is greater than or equal to the Dropout Time setting after a true to false transition occurs on the Initiate input from the connected logic. Whenever the Initiate input transitions to true, the output transitions to false immediately.

Refer to Figure 66.

To program logic timer settings, use the Settings Explorer within BESTCOMSPlus to open the *BESTlogicPlus Programmable Logic/Logic Timers* tree branch. Enter a *Name* label that you want to appear on the timer logic block. The *Time Delay* value range is 0 to 250 hours in 1 hour increments, 0 to 250 minutes in 1 minute increments, or 0 to 1,800 seconds in 0.1 second increments.

Next, open the *Components* tab inside the BESTlogicPlus window and drag a timer onto the program grid. Right click on the timer to select the timer you want to use that was previously set on the *Logic Timers* tree branch. The *Logic Timer Properties Dialog Box* will appear. Select the timer you want to use.

Timing accuracy is ±15 milliseconds.



**Figure 66. Pickup and Dropout Timer Logic Blocks**

## BESTlogic™ Plus File Management

To manage BESTlogicPlus files, use the Settings Explorer to open the *BESTlogicPlus Programmable Logic* tree branch. Use the BESTlogicPlus Programmable Logic toolbar to manage BESTlogicPlus files. Refer to Figure 67. For information on Settings Files management, refer to the *BESTCOMSPlus* chapter.



Figure 67. BESTlogicPlus Programmable Logic Toolbar

### Saving a BESTlogicPlus File

After programming BESTlogicPlus settings, click on the *Save* button to save the settings to memory.

Before the new BESTlogicPlus settings can be uploaded to the DGC-2020ES, you must select *Save* from the *File* pull-down menu located at the top of the BESTCOMSPlus main shell. This step will save both the BESTlogicPlus settings and the operating settings to a file.

The user also has the option to save the BESTlogicPlus settings to a unique file that contains only BESTlogicPlus settings. Click on the *Logic Library* drop-down button and select *Save Logic Library File*. Use normal Windows® techniques to browse to the folder where you want to save the file and enter a filename.

### Opening a BESTlogicPlus File

To open a saved BESTlogicPlus file, click on the *Logic Library* drop-down button on the BESTlogicPlus Programmable Logic toolbar and select *Open Logic Library File*. Use normal Windows techniques to browse to the folder where the file is located.

### Protecting a BESTlogicPlus File

Objects in a logic diagram can be locked so that when the logic document is protected these objects cannot be changed. Locking and protecting is useful when sending logic files to other personnel to be modified. The locked object(s) cannot be changed. To view the lock status of the object(s), select *Show Lock Status* from the *Protection* drop-down menu. To lock object(s), use the mouse to select object(s) to be locked. Right click on the selected object(s) and select *Lock Object(s)*. The gold colored padlock next to the object(s) will change from an open to a locked state. To protect a logic document, select *Protect Logic Document* from the *Protection* drop-down button. A password is optional.

### Uploading a BESTlogicPlus File

To upload a BESTlogicPlus file to the DGC-2020ES, you must first open the file through BESTCOMSPlus or create the file using BESTCOMSPlus. Then pull down the *Communication* menu and select *Upload Logic*.

### Downloading a BESTlogicPlus File

To download a BESTlogicPlus file from the DGC-2020ES, you must pull down the *Communication* menu and select *Download Logic*. If the logic in your BESTCOMSPlus has changed, a dialog box will open asking you if you want to save the current logic changes. You may choose *Yes* or *No*. After you have taken the required action to save or not save the current logic, the downloading is executed.

### Printing a BESTlogicPlus File

To view a preview of the printout, click on the *Print Preview* icon located on the BESTlogicPlus Programmable Logic toolbar. If you wish to print to a printer, select the printer icon in the upper left corner of the *Print Preview* screen.

You may skip the print preview and go directly to print by clicking on the *Printer* icon on the BESTlogicPlus Programmable Logic toolbar. A dialog box, *Select Views to Print* opens allowing you to

check which views you would like to print. Next, the *Print* dialog box opens with the typical Windows choice to setup the properties of printer. Execute this command, as necessary, and then select *Print*.

A *Page Setup* icon is also provided on the BESTlogicPlus Programmable Logic toolbar allowing you to select *Paper Size*, *Paper Source*, *Orientation*, and *Margins*.

### Clearing the On-Screen Logic Diagram

Click on the *Clear* button to clear the on-screen logic diagram and start over.

## BESTlogic™Plus Examples

### Example 1 - GENBRK Logic Block Connections

Figure 68 illustrates the GENBRK logic block, three input logic blocks, and two output logic blocks. Output 3 is active while the GENBRK is sending an “open breaker” command and Output 4 is active while the GENBRK is sending the “close breaker” command.




Figure 68. Example 1 – GENBRK Logic Block Connections

### Example 2 - AND Gate Connections

Figure 69 illustrates a typical AND gate connection. In this example, Output 11 will become active when the Low Fuel alarm AND the Low Oil Pressure alarm are true.




Figure 69. Example 2 – AND Gate Connections

### Example 3 - Multiple Logic Connections

In this example, there are two comment boxes, which may be placed on the logic diagram. Double-click a comment box to modify the inside text. Output 3 becomes true when the 27TRIP is true. Output 1 becomes true when the High Coolant Temp is true. Output 2 becomes true when the DGC-2020ES is in RUN mode (RUN Mode true). Refer to Figure 70.




Figure 70. Example 3 – Multiple Logic Connections



# Communication

DGC-2020ES communication ports include a mini-B USB port, CAN terminals, and provisions for an optional Remote Display Panel. The following paragraphs describe the DGC-2020ES communication ports in detail.

## USB

The rear-panel, mini-B USB port enables local communication with a PC running BESTCOMSP<sup>Plus</sup>® software. The DGC-2020ES is connected to a PC using a standard USB cable. BESTCOMSP<sup>Plus</sup> is a Windows®-based communication software package that is supplied with the DGC-2020ES. A detailed description of BESTCOMSP<sup>Plus</sup> is provided in the BESTCOMSP<sup>Plus</sup> chapter.

## CAN

A Controller Area Network (CAN) is a standard interface that enables communication between multiple controllers on a common network using a standard message protocol. DGC-2020ES controllers have a CAN interface that supports the SAE J1939 protocol and the MTU protocol.

Applications using an engine-driven generator set controlled by a DGC-2020ES may also have an Engine Control Unit (ECU). The CAN interface allows the ECU and DGC-2020ES to communicate. The ECU reports operating information to the DGC-2020ES through the CAN interface. Operating parameters and diagnostic information, if supported by the ECU, are decoded and displayed for monitoring.

The primary use of the CAN interface is to obtain engine operating parameters for monitoring speed, coolant temperature, oil pressure, coolant level, and engine hours without the need for direct connection to individual senders. Table 27 lists the ECU parameters and Table 28 lists the engine configuration parameters supported by the DGC-2020ES CAN interface. These parameters are transmitted via the CAN interface at preset intervals. See the column labeled Update Rate in Table 27 for transmission rates.

CAN interface connections are made at 13 (CAN H), 14 (CAN L), and 15 (SHIELD).

**Table 27. ECU Parameters Obtained from CAN Interface**

ECU Parameter	Metric Units	English Units	Update Rate	* SPN
Actual Engine Percent Torque	%	%	Engine Speed Dependent	513
Air Filter Differential Pressure	kPa	psi	500 ms	107
Air Inlet Temperature	kPa	°F	1 s	172
Alarm Reset Feedback	Binary (0 or 1)		1 s	2815
Ambient Air Temperature	°C	°F	1 s	171
Auxiliary Pressure 1	kPa	psi	On Request	1387
Auxiliary Pressure 2	kPa	psi	On Request	1388
Barometric Pressure	kPa	psi	1 s	108
Battery Voltage	Vdc	Vdc	1 s	168
Boost Pressure	kPa	psi	500 ms	102
Charge Air Temperature	°C	°F	1 s	2629
Coolant Level	%	%	500 ms	111
Coolant Pressure	kPa	psi	500 ms	109
ECU Temperature	°C	°F	1 s	1136
Engine Coolant Temperature	°C	°F	1 s	110
Engine Intercooler Temperature	°C	°F	1 s	52

ECU Parameter	Metric Units	English Units	Update Rate	* SPN
Engine Oil Level	%	%	500 ms	98
Engine Oil Pressure	kPa	psi	500 ms	100
Engine Oil Temperature	°C	°F	1 s	175
Engine Speed	rpm	rpm	Engine Speed Dependent	190
Exhaust Gas Temperature	°C	°F	500 ms	173
Exhaust Temperature A	°C	°F	500 ms	2433
Exhaust Temperature B	°C	°F	500 ms	2434
Fuel Delivery Pressure	kPa	psi	500 ms	94
Fuel Leak Filter 1	Binary (0 or 1)		1 s	1239
Fuel Leak Filter 2	Binary (0 or 1)		1 s	1240
Fuel Rate	liter/hr	gal/hr	100 ms	183
Fuel Temperature	°C	°F	1 s	174
High Exhaust System Temp (HEST) Lamp/Indicator	—	—	500 ms	3698
Injection Control Pressure	MPa	psi	500 ms	164
Injector Metering Rail Pressure	MPa	psi	500 ms	157
Intake Manifold Temperature	°C	°F	500 ms	105
Particulate Filter (DPF) Lamp/Indicator	—	—	500 ms	3697
Percent Load at Current rpm	%	%	50 ms	92
Rated Power	watts	watts	On Request	166
Rated rpm	rpm	rpm	On Request	189
Regeneration Disabled (Inhibit) Lamp/Indicator	—	—	500 ms	3703
Shutdown from ECU	Binary (0 or 1)		1 s	1110
Switched Battery Voltage (at ECU)	Vdc	Vdc	1 s	158
Throttle (Accelerator Pedal) Position	%	%	50 ms	91
Total Engine Hours	hours	hours	Requested 1.5 s	247
Total Fuel Used	liters	gallons	Requested 1.5 s	250
Transmission Oil Pressure	kPa	psi	1 s	127
Transmission Oil Temperature	°C	°F	1 s	177
Trip Fuel	liters	gallons	Requested 1.5 s	182
Winding 1 Temperature	°C	°F	1 s	1124
Winding 2 Temperature	°C	°F	1 s	1125
Winding 3 Temperature	°C	°F	1 s	1126

\* SPN is suspect parameter number.

**Table 28. Engine Configuration Parameters Obtained from CAN Interface**

ECU Parameter	Metric Units	English Units	Update Rate	* SPN
Engine Speed at High Idle Point 6	rpm	rpm	5 s	532
Engine Speed at Idle Point 1	rpm	rpm	5 s	188
Engine Speed at Point 2	rpm	rpm	5 s	528
Engine Speed at Point 3	rpm	rpm	5 s	529
Engine Speed at Point 4	rpm	rpm	5 s	530
Engine Speed at Point 5	rpm	rpm	5 s	531
Gain (Kp) of End Speed Governor	%/rpm	%/rpm	5 s	545
Maximum Momentary Engine Override Speed Point 7	rpm	rpm	5 s	533
Maximum Momentary Engine Override Time Limit	seconds	seconds	5 s	534
Percent Torque at Idle Point 1	%	%	5 s	539
Percent Torque at Point 2	%	%	5 s	540
Percent Torque at Point 3	%	%	5 s	541
Percent Torque at Point 4	%	%	5 s	542
Percent Torque at Point 5	%	%	5 s	543
Reference Engine Torque	N•m	ft-lb	5 s	544
Requested Speed Control Range Lower Limit	rpm	rpm	5 s	535
Requested Speed Control Range Upper Limit	rpm	rpm	5 s	536
Requested Torque Control Range Lower Limit	%	%	5 s	537
Requested Torque Control Range Upper Limit	%	%	5 s	538

\* SPN is suspect parameter number.

### Caution

When the CAN is enabled, the DGC-2020ES ignores the following sender inputs: oil pressure, coolant temperature, and magnetic pickup.

Under certain circumstances, the following strings may be displayed on the front panel HMI and in the Metering Explorer of BESTCOMSPUs:

- *NC (Not Connected)* - String displayed for a J1939 parameter when the engine ECU is not connected to the DGC-2020ES.
- *SF (Sender Fail)* - String displayed for a J1939 parameter when the engine ECU sends a special code indicating a measurement failure for the parameter. For example, if oil sender is determined to be bad by the ECU, it sends a special code in place of the J1939 oil pressure data indicating a sender fail condition.
- *NS (Not Sent)* - String displayed for a J1939 parameter when the J1939 parameter has not been sent to the DGC-2020ES by the engine ECU.
- *NA (Not Applicable)* - String displayed for a J1939 parameter when the engine ECU sends a special code for the parameter indicating that the parameter is not implemented or not applicable in the ECU.
- *UF (Unknown Failure)* - String displayed when the J1939 parameter data received by the ECU is not within the valid J1939 data range for the parameter but is not one of the special codes above.

Table 29 lists the J1939 data transmitted from the DGC-2020ES.

**Table 29. J1939 Data Transmitted from the DGC-2020ES**

ECU Parameter	Update Rate	* SPN
Battle Override Switch	100 ms	1237
Speed Request	10 ms	518
Note: Requests from the DGC-2020 to the Engine ECU for various parameters are made by issuing the request.		
Address Claim Request	Once on power up, and any time a Global Request for Address Claim (GRAC) PGN is received.	NA
Currently Active Diagnostic Trouble Codes Request	Whenever a refresh of Currently Active Diagnostic Trouble Code Requests is received.	NA
Previously Active Diagnostic Trouble Codes Request	2 s	NA
Clear Currently Active Diagnostic Trouble Codes Request	Whenever a request to reset Currently Active Diagnostic Trouble Code Request is made.	NA
Clear Previously Active Diagnostic Trouble Codes Request	Whenever a request to reset Previously Active Diagnostic Trouble Code Request is made.	NA
Engine Hours/Revolutions Request	2 s	NA
Fuel Consumption Request	2 s	NA
Electronic Engine Controller #4 (Rated Speed and Power) Request	2 s	NA
Auxiliary Analog Information	2 s	N/A

## CAN Setup

The following paragraphs describe the settings found on the CAN Setup screen. This screen is found in the BESTCOMSPi<sup>us</sup> *Settings Explorer*, under the *Communications, CAN Bus* category. If using the front panel, navigate to Settings > Communications > CAN Bus Setup > CAN Bus Setup. Figure 71 illustrates the BESTCOMSPi<sup>us</sup> CAN Bus Setup screen.

### Enable ECU Support

Set to Enabled for the DGC-2020ES to communicate with the ECU.

### Enable DTC (Diagnostic Trouble Code) Support

If the ECU is a J1939 ECU, enable DTC support. If the ECU does not support it, no diagnostic trouble codes will be logged by the DGC-2020ES.

### SPN Conversion Method

The most common SPN conversion method is 4 and is the default for the DGC-2020ES. Refer to ECU manufacturer documentation to determine the correct SPN conversion method of the ECU and set the SPN Conversion Method setting in the DGC-2020ES accordingly.

### CAN bus Address

This parameter sets a unique address number for the DGC-2020ES operating on a CAN. The CAN Address is set internally by the DGC-2020ES when certain types of ECUs are selected on the ECU Setup screen, and in this case, the user-entered value does not apply.

### ECU Contact Control - Output Select

Select whether the RUN output relay or the PRE (Prestart) output relay closes to give the ECU its “energize to run” signal. In some implementations, this relay may actually be providing ECU power.

### ECU Contact Control - Pulsing Enable

Select if the ECU is not to be on line at all times. Often ECUs are allowed to go “off line” to conserve battery drain when the engine is not running. The DGC-2020ES will “pulse” it periodically to force it to be

active to allow the DGC-2020ES to read data such as coolant temperature and coolant level. This is required if the DGC-2020ES is to report low coolant temperature conditions (which may indicate a failure of a block heater), or low coolant level conditions (if a leak occurs while the machine is not running). Pulsing is also used to check the integrity of CAN communications when the machine is not running.

#### ECU Related Time Values - Engine Shut Down

Set this parameter for a value longer than the duration required to stop the engine after being shut down. The ECU is pulsed after this time expires. If the time is too short, the pulse may occur while the engine is still turning which could cause a brief re-start and possibly damage the flywheel and starter system.

#### ECU Related Time Values - Pulse Cycle Time

Set this parameter for the desired time between ECU pulse cycles.

#### ECU Related Time Values - Settling Time

This parameter is the duration of the “on line” time of the pulse cycle during which the DGC-2020ES reads data from the ECU. The settling time should be set long enough so that any ECU parameters that require time to “settle down” after the ECU is on line can do so. Since the DGC-2020ES may use some of the ECU data for alarm or pre-alarm annunciation, it is important that the data have time to settle.

#### ECU Related Time Values - Response Timeout

This setting defines the amount of time that the DGC-2020ES will wait to receive data from the ECU during a pulse cycle or start attempt. If no data is received during this time in a pulse cycle, a LOSS OF ECU COMMS pre-alarm is annunciated. If no data is received in this time during an engine starting attempt, a LOSS OF ECU COMMS alarm is annunciated.

Figure 71. Settings Explorer, Communications, CAN bus, CAN bus Setup

## ECU Setup

The following paragraphs describe the settings on the ECU Setup screen. This screen is found in the BESTCOMSP<sup>Plus</sup> Settings Explorer, under the *Communications, CAN Bus* category. If using the front panel, navigate to Settings > Communications > CAN Bus Setup > ECU Setup. Refer to Figure 72.

### ECU Type

The DGC-2020ES can be configured for Standard, Volvo Penta, MTU MDEC, MTU ADEC, MTU ECU7/ECU8, GM/Doosan, Cummins, or MTU Smart Connect.

### Generator Parameter Transmit

When the Generator Parameter Transmit setting is enabled, the DGC-2020ES broadcasts generator metered parameters over CAN as listed in Table 30. The Generator Parameter Transmit setting is not used when ECU Type is set for MTU MDEC, MTU ECU7/ECU8, or MTU Smart Connect.

### Engine Parameter Transmit

When the Engine Parameter Transmit setting is enabled, the DGC-2020ES broadcasts engine metered parameters over CAN. When the Engine Parameter Transmit setting is disabled, transmission of J1939 commands from the DGC-2020ES to the engine are disabled, but commands from the engine to the DGC-2020ES are allowed.

**Table 30. Generator Parameter Transmit**

PGN Name	PGN	Hex	SPN	Parameter	Bytes Within PGN Data
Generator Total AC Energy	65018	FDFA	2468	Generator Total kW Hours Export	1 to 4
			2469	Generator Total kW Hours Import	5 to 8
Generator Total AC Reactive Power	65028	FE04	2456	Generator Total Reactive Power	1 to 4
			2464	Generator Overall Power Factor	5 to 6
			2518	Generator Overall Power Factor Lagging	7, bits 1 & 2
Generator Total AC Power	65029	FE05	2452	Generator Total Real Power	1 to 4
			2460	Generator Total Apparent Power	5 to 8
Generator Average Basic AC Quantities	65030	FE06	2440	Generator Average L-L AC RMS Voltage	1 to 2
			2444	Generator Average L-N AC RMS Voltage	3 to 4
			2436	Generator Average AC Frequency	5 to 6
			2448	Generator Average AC RMS Current	7 to 8
Engine Temperature	65262	FEEE	110	Engine Coolant Temperature (Not sent when CAN is enabled.)	1
Engine Fluid Level/Pressure	65263	FEEF	100	Engine Oil Pressure (Not sent when CAN is enabled.)	4
Dash Display	65276	FEFC	96	Fuel Level	2

### Diesel Particulate Filter (DPF)

The diesel particulate filter settings are used when the ECU is configured for Standard, Volvo Penta, MTU ADEC, GM/Doosan, Cummins, or MTU Smart Connect. The DGC-2020ES supports the CAN parameters that are related to the diesel particulate filter implemented on certain engines to meet Tier 4 emission requirements.

Two parameters are provided to initiate or disable DPF regeneration. The first, *Manual Regeneration*, is transmitted to the engine via CAN to initiate DPF regeneration. The second, *Disable Regeneration*, is transmitted to the engine via CAN to disable DPF regeneration. Extended operation with regeneration disabled is not recommended.

### Speed Setup

Speed control over J1939 and ECU7/ECU8 is implemented over CAN when the CAN bus RPM Request setting is enabled. This is implemented for all ECUs. The Engine RPM setting defines the nominal requested engine rpm. The Idle RPM setting is the requested rpm when the IDLE REQUEST logic element is true.

Figure 72. Settings Explorer, CAN bus, ECU Setup

### Volvo Penta

Configuring the DGC-2020ES for Volvo Penta\* necessitates the configuration of two additional settings: Speed Select and Accelerator Position. The Speed Select setting configures the Volvo Penta ECU to operate the engine at the primary or secondary base speed. If the engine is configured by Volvo for 60 Hz applications, the primary base speed is 1,800 rpm and the secondary base speed is 1,500 rpm. If the engine is configured by Volvo for 50 Hz applications, the primary base speed is 1,500 rpm and the secondary base speed is 1,800 rpm. The Accelerator Position setting is expressed as a percentage and tells the Volvo Penta ECU where to set the engine speed (trim) relative to the base speed. The range of the setting is the base speed  $\pm 120$  rpm. A setting of 0% will cause the engine to run at 120 rpm below the base speed, a setting of 50% will cause the engine to run at the base speed, and a setting of 100% will cause the engine to run at 120 rpm above the base speed. The Accelerator Position setting is linear with a gain of 2.4 rpm/percentage. This setting is not saved in nonvolatile memory and defaults back to 50% after DGC-2020ES operating power is cycled.

The DGC-2020ES sends the following parameters to a Volvo Penta ECU through Volvo Proprietary J1939 communications:

- Start Request - sent when starting the engine.
- Stop Request - sent when shutting down the engine.
- Idle Request - sent when the Idle Request logic element is true in *BESTLogicPlus*.
- Preheat Request - sent anytime the DGC-2020ES would normally have its PRE relay closed for engines requiring a preheat contact.
- Accelerator Pedal Position - sent based on the Accelerator Position setting.
- Primary/Secondary Engine Speed - sent based on the Speed Select setting and the state of the Alternate Frequency Override element in *BESTLogicPlus*. Primary speed is sent when the Speed Select setting is set for Primary and Secondary speed is sent when the Speed Select setting is set for Secondary. However, these are reversed if the Alternate Frequency Override is true. A setting of Primary results in Secondary being sent and a setting of Secondary results in Primary being sent when the Alternate Frequency Override is true.

\* The Volvo Penta ECU configuration is applicable only to the EDC3 and EMS2 models of Volvo Penta engine controllers.

### Cummins

When Cummins is selected as the ECU type, the following parameters are sent to the engine via Cummins Proprietary J1939 communications:

- Start Request - sent when starting or running the engine.
- Stop Request - sent when stopping the engine.
- Idle Request - sent when the Idle Request logic element is true in BESTLogicPlus.
- Rated Speed (50 or 60 Hz) - sent based on the Rated Speed setting of the DGC-2020ES. However, these are reversed if the Alternate Frequency Override is true. A setting of 60 Hz Rated Speed results in 50 Hz being sent and a setting of 50 Hz Rated Speed results in 60 Hz being sent when the Alternate Frequency Override is true.

### MTU

If the engine is configured as MTU MDEC, the configuration of the following settings is necessary:

- MDEC Module Type - Specifies the type of MDEC module.
- Speed Demand Switch - Specifies speed demand source for the MTU engine ECU.
- NMT Alive Transmit Rate - Specifies the rate at which messages are transmitted to the MTU engine.

If the engine is configured as MTU ADEC, the configuration of the following settings is necessary:

- Speed Demand Switch - Specifies speed demand source for the MTU engine ECU.
- Overspeed Test - Temporarily drives an MTU ECU into overspeed for testing overspeed.
- Governor Param Switch Over - Specifies which governor parameters an MTU ECU should use.
- Trip Reset - Resets trip information such as trip fuel used, trip hours, trip idle time, etc.
- Int Oil Prime - Causes an MTU ECU engine to perform an internal lubrication cycle.

If the engine is configured as MTU ECU7/ECU8, the configuration of the following settings is necessary:

- Speed Demand Switch - Specifies speed demand source for the MTU engine ECU.
- Overspeed Test - Temporarily drives an MTU ECU into overspeed for testing overspeed.
- Speed Up - Increases speed of the MTU ECU.
- Speed Down - Decreases speed of the MTU ECU.
- Idle Request - Turns the idle request on or off.
- Increased Idle - Sets the MTU ECU idle.
- Trip Reset - Resets trip information such as trip fuel used, trip hours, trip idle time, etc.
- Int Oil Prime - Causes an MTU ECU engine to perform an internal lubrication cycle.
- MTU 50 Hz 60 Hz Switch Setting - Set automatically based on rated frequency of the DGC-2020ES and the state of the alternate frequency override.
- Engine Start Prime - Turns the engine start prime on or off.
- Fan Override - Turns the fan override on or off.
- Mode Switch - Turns the mode switch on or off.
- Governor Param Set Select - Sets the governor parameter set select.
- CAN Rating Switch 1 & 2 - Turns the CAN rating switch 1 & 2 on or off.
- Cylinder Cutout Disable 1 & 2 - Turns the cylinder cutout disable 1 & 2 on or off.
- MTU ECU7/ECU8 Module Type - Specifies ECU7/ECU8 Module type.
- NMT Alive Transmit Rate - Specifies the rate at which messages are transmitted to the MTU engine.

If the engine is configured as MTU Smart Connect, the configuration of the following settings is necessary:

- Speed Demand Switch - Specifies speed demand source for the MTU engine ECU.
- Overspeed Test - Temporarily drives an MTU ECU into overspeed for testing overspeed.
- Speed Up - Increases speed of the MTU ECU.
- Speed Down - Decreases speed of the MTU ECU.
- Idle Request - Turns the idle request on or off.

- Trip Reset - Resets trip information such as trip fuel used, trip hours, trip idle time, etc.
- Int Oil Prime - Causes an MTU ECU engine to perform an internal lubrication cycle.
- Governor Param Switch Over - Specifies which governor parameters an MTU ECU should use.
- Cylinder Cutout Disable 2 - Turns the cylinder cutout disable 2 on or off.
- Engine Operating Mode - Selects engine operating mode 1 or 2.

## ***Remote Display Panel (optional)***

---

Applications that require remote annunciation can use Basler Electric's Remote Display Panel. This device provides remote indication of many pre-alarm and alarm conditions.

Remote Display Panel connections are made at 10 (RDP TxD-), 11 (RDP TxD+), 17 (BATT-), and 18 (BATT+).

The following pre-alarm conditions are indicated by LEDs on the Remote Display Panel:

- High coolant temperature
- Low coolant temperature
- Low oil pressure
- Low fuel level\*
- Weak battery
- Battery overvoltage†
- Battery charger failure\*†

The following alarm conditions are indicated by LEDs and an audible alarm on the Remote Display Panel:

- Low coolant level\*
- High coolant temperature
- Low oil pressure
- Overcrank
- Overspeed
- Emergency stop activated
- Fuel leak/Sender failure\*†
- Sender failure†


\* This can be configured in the DGC-2020ES as *None*, *Alarm*, or *Pre-alarm*. See the *Contact Inputs* chapter for more information. The LED on the Remote Display Panel illuminates when the input that is assigned to the programmable function is closed, whether the function is configured as *None*, *Alarm*, or *Pre-alarm*.

† This LED can be reprogrammed in the DGC-2020ES to suit the needs of a particular application. The condition listed above is annunciated by default.

Additionally, the Remote Display Panel indicates when the DGC-2020ES is not operating in Auto mode and when the generator is supplying load or when the DGC-2020ES is in an alarm state not listed above.

Refer to Basler Publication 9318100990 for more information on the Remote Display Panel.

See the *Terminals and Connectors* chapter for more information on connecting the Remote Display Panel to the DGC-2020ES.



# Configuration

System parameters configure the DGC-2020ES for operation with a specific application. This chapter lists items to consider when configuring the DGC-2020ES. These items consist of system settings and rated data, remote module setup, crank settings, automatic restart settings, exercise timer settings, sensing transformer ratings, relay control settings, and system configuration detection settings.

## System Settings

---

The System Settings parameters consist of number of fly wheel teeth, speed signal source, power-up delay, fuel level function, NFPA compliance level, EPS supplying load, system units, and metric pressure units. The System Settings screen is found in the BESTCOMSP<sup>lus</sup>® Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > System Settings.

### Number Flywheel Teeth

The Number Fly Wheel Teeth setting accepts a value from 1 to 500, in increments of 0.1. This value is used when calculating engine rpm.

### Speed Signal Source

The DGC-2020ES can be configured to detect engine speed from a magnetic pickup (MPU), the genset frequency, or both the MPU and genset frequency. On engines with CAN ECUs, if MPU or MPU Freq is selected as the Speed Signal Source, the DGC-2020ES uses CAN as the speed source when CAN is enabled. If Gen Freq is set as the Speed Signal Source, the DGC-2020ES uses the generator frequency.

When engine speed is obtained from the genset frequency, the DGC-2020ES uses the rated (nominal) genset frequency and nominal rpm rating when calculating engine rpm.

When engine speed is obtained from an MPU, the DGC-2020ES uses the nominal rpm rating and the number of flywheel teeth when calculating engine rpm.

The speed signal from the MPU takes priority when both the genset frequency and MPU are selected as the engine speed source. If both MPU and genset frequency are selected and the MPU fails, the DGC-2020ES automatically switches to the genset frequency as the engine speed source.

### Power Up Delay

In some cases, the ECU takes longer than the DGC-2020ES to power up. The power up delay setting is used to delay the initial pulsing of the ECU for data on DGC-2020ES power up. This setting ranges from 0 to 60 seconds in 1 second increments.

### Fuel Level Function

This setting determines whether the fuel level indications and the related alarm and pre-alarm are enabled or disabled. Setting selections include, Fuel Lvl (Fuel Level), Natural Gas, Liquid Propane, or Disabled. Selecting a fuel type other than Fuel Lvl disables any fuel level indication, alarm, or pre-alarm. This includes the Fuel Level value on the *Metering Explorer, Engine* screen in BESTCOMSP<sup>lus</sup>.

### NFPA Compliance Level

The DGC-2020ES can be used in an application requiring compliance with NFPA Standard 110. Levels 1 and 2 of Standard 110 are supported. Selecting level 1 or 2 affects DGC-2020ES operation in the following ways:

- The number of crank cycles is fixed at 3
- Crank cycle time is fixed at 15 seconds
- Continuous crank time is fixed at 45 seconds
- The low coolant temperature pre-alarm setting is fixed at 70°F

## EPS Supplying Load

EPS Supplying Load settings consist of Low Line Scale Factor and EPS Threshold. These settings are described in the following paragraphs.

### Low Line Scale Factor

Low Line Scale Factor automatically adjusts the EPS threshold setting in applications utilizing more than one type of genset connection. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate scaling of the settings. The value of the scale factor setting serves as a multiplier for the threshold setting. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the threshold setting is doubled (2.000 x Threshold setting).

### EPS Threshold

Indication that the emergency power system is supplying load is determined by a user-adjustable threshold setting. This setting is expressed as a percentage of the genset CT (nominal) primary rating.

This setting accepts values from 3 to 10, in increments of 1%.

## System Units

Engine oil pressure and coolant temperature can be displayed in English or metric units of measure.

## Metric Pressure Units

This setting allows engine oil pressure to be displayed in bar or kPa/MPa.

The screenshot shows the 'System Settings' screen with the following values:

- System Type: Single Generator
- Number Fly Wheel Teeth x10: 126.0
- Speed Signal Source: MPU\_Freq
- Power Up Delay (s): 1
- Fuel Level Function: Fuel Lvl
- NFWA Level: Zero
- System Units: English
- Metric Pressure Units: bar
- EPS Supplying Load:
  - Low Line Scale Factor: 1.000
  - EPS Threshold (% of CT Pri): 3

Figure 73. Settings Explorer, System Parameters, System Settings Screen

## Rated Data

Rated Data parameters consist of sensing transformer ratings, voltage, power factor, kW, engine RPM, frequency, battery volts, generator and bus connection types, and phase rotation. The Rated Data screen is found in the BESTCOMSP<sup>Plus</sup> Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > System Settings.

Click the Edit button on the BESTCOMSP<sup>Plus</sup> Rated Data settings screen to adjust values. Click OK to accept the changes, and Cancel to discard them.

## Sensing Transformers

For information on sensing transformers settings, see *Sensing Transformers*, below.

## Rated Data

Genset nameplate data used by the DGC-2020ES includes the rated voltage, power factor, kW, and engine RPM.

### Rated Volts (V L-L)

This setting accepts values from 1 to 99,999, in increments of 1.

### Rated Power Factor (PF)

This setting accepts values from -1 to 1, in increments of 0.001.

### Genset kW Rating

This setting accepts values from 5 to 9,999, in increments of 1.

### Rated Engine RPM

This setting accepts values from 750 to 3,600, in increments of 1.

### Calculated Rated Data

Rated Secondary Volts, Rated Phase Amps, Rated Secondary Phase Amps, Rated kVA, and Rated kvar are calculated automatically. The equations used for these calculations are listed below.

$$\text{Rated Secondary Volts} = \text{Rated Volts} \left( \frac{\text{Gen PT Secondary Volts}}{\text{Gen PT Primary Volts}} \right)$$

$$\text{Error! Bookmark not defined. Rated Phase Amps (3-phase machine)} = \frac{\text{Rated kVA}}{\text{Rated L-L Volts} \sqrt{3}}$$

$$\text{Rated Phase Amps (1-phase machine)} = \frac{\text{Rated kVA}}{\text{Rated L-L Volts}}$$

$$\text{Rated Secondary Phase Amps} = \text{Rated Phase Amps} \left( \frac{\text{CT Secondary Amps}}{\text{CT Primary Amps}} \right)$$

$$\text{Rated kVA} = \frac{\text{Rated kW}}{\text{Rated PF}}$$

$$\text{Rated kvar} = \text{Rated kVA} \sqrt{1 - \text{Rated PF}^2}$$

## Frequency

The frequency settings allow selection of the rated frequency of the generator and an alternate frequency.

### Rated Frequency of the Unit

Rated frequency settings consist of 50 and 60 Hz.

### Alternate Frequency

This setting accepts values from 10 to 450, in increments of 0.01.

## Battery Volts

The nominal voltage of the starter battery is used by the DGC-2020ES to detect and annunciate battery overvoltage and low or weak battery voltage. The Battery Volts settings consist of 12 V and 24 V.

## Generator Connection

Genset connection types accommodated by the DGC-2020ES include three, three-phase connections (delta, wye, and grounded delta) and a single-phase configuration (sensing across phases A and B.)

## Bus Connection

Bus connection types consist of single- and three-phase. Single-phase bus voltage is sensed across phases A and B.

## Phase Rotation

The Phase Rotation setting allows selection of ABC or CBA rotation according to the phase rotation connection of the machine. The DGC-2020ES calculates the power angle as the angle between the Phase AB voltage and phase B current. An angle compensation factor, determined by the phase rotation setting, is then applied. If the actual phase rotation connection of the machine does not match the phase rotation setting, calculation of the power angle will be incorrect, which may result in a miscalculation of kW, kvar, and power factor.

The screenshot shows the 'Rated Data' screen in the Settings Explorer. The screen is titled 'Rated Data' and has 'OK' and 'Cancel' buttons in the top right corner. The screen is divided into several sections:

- Sensing Transformers:**
  - Generator PT:** Gen PT Primary Volts (V) is 480; Gen PT Secondary Volts (V) is 480.
  - Bus PT:** Bus PT Primary Volts (V) is 480; Bus PT Secondary Volts (V) is 480.
  - Generator CT:** Current Sensing Input Type is 5A CTs; Gen CT Primary Amps (A) is 500; Gen CT Low Line Scale Factor is 1.000.
- Rated Data:**
  - Rated Volts (V L-L) is 480.
  - Rated Secondary Volts (V L-L) is 480.
  - Rated Phase Amps (A) is 451.
  - Rated Secondary Phase Amps (A) is 4.51.
  - Rated Power Factor (PF) is 0.800.
  - Genset KW Rating (kW) is 300.
  - Rated kVA is 375.
  - Rated kvar is 225.
  - Rated Engine RPM (rpm) is 1800.
- Battery Volts:** 12V is unselected; 24V is selected.
- Miscellaneous:**
  - Generator Connection is Wye.
  - Bus Connection is Single Phase.
  - Phase Rotation is ABC.
- Frequency:**
  - Rated frequency of the unit is 60 Hz.
  - Alternate Frequency (Hz) is 60.00.

Figure 74. Settings Explorer, System Parameters, Rated Data Screen

## Remote Module Setup

When the optional CEM-2020 is enabled, a J1939 address must be entered. Select the appropriate number of outputs available on the CEM-2020. The low current module (CEM-2020) provides 24 contact outputs and the high current module (CEM-2020H) provides 18 contact outputs.

The Remote Module Setup screen is found in the BESTCOMS*Plus* Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Remote Module Setup.

The BESTCOMS*Plus* Remote Module Setup screen is illustrated in Figure 75.




Figure 75. Settings Explorer, System Parameters, Remote Module Setup Screen

## Crank Settings

The Crank Settings consist of pre-start, restart, cranking, crank disconnect, and cooldown. These settings are described in the paragraphs below.

The Crank Settings screen is found in the BESTCOMS*Plus* Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Crank Settings.

The BESTCOMS*Plus* Crank Settings screen is illustrated in Figure 76.

### Pre-Start

If desired, cycle or continuous cranking can be delayed after initiating engine startup. During this delay, the Pre-Start output closes to energize glow plugs or pre-start the lubrication pump. The Pre-crank Delay setting accepts values from 0 to 30, in increments of 1 second.

The Pre-Start output can be configured to open upon the conclusion of engine cranking or remain closed as long as the engine is running.

The Pre-Start output can be configured during the resting state. If Preheat Before Crank is selected, the Pre-Start output is closed for the duration of the Pre-crank Delay time prior to re-entering the cranking state. If the Pre-crank delay setting is longer than the rest interval, the Pre-Start output is closed for the entire duration of the rest time.

### Restart

Attempting to start an engine after a normal shutdown but before the engine RPM has settled to zero can stress an engine in certain situations. The Restart Delay inhibits attempts to start the engine immediately after a normal shutdown for the duration of the Restart Delay timer. This delay should allow an engine to

properly spin down before attempting to restart. This setting accepts values from 0 to 120, in increments of 1 second.

## **Cranking**

The DGC-2020ES can be programmed for either cycle or continuous cranking.

Cycle cranking provides multiple engine starting attempts. Each starting attempt consists of a fixed interval of engine cranking followed by a rest interval of the same duration. The Number of Crank Cycles setting accepts values from 1 to 7, in increments of 1. The Cycle Crank Time setting accepts values from 5 to 15, in increments of 1 second.

Continuous cranking provides a single, extended engine-starting attempt. The Continuous Crank Time setting accepts values from 5 to 60, in increments of 1 second.

## **Crank Disconnect**

Under normal operation, engine rpm is used to determine crank disconnect. The Crank Disconnect Limit setting establishes the engine rpm percentage at which the starter is disconnected. This setting accepts values from 10 to 100, in increments of 1 percent.

The Oil Pressure Crank Disconnect provides a secondary indication that the engine is running. This ensures that the starter is disconnected, even if no engine rpm sources are functioning. When enabled, oil pressure is used to determine if the engine is running. If the engine oil pressure is above the threshold, the starter is disconnected from the engine. The Crank Disconnect Pressure threshold setting accepts values from 2.9 to 150 psi, 0.2 to 10.3 bar, and 20 to 1,034.5 kPa, in increments of 0.1.

## **Cool Down**

After the load is removed from a genset, the DGC-2020ES implements a smart cooldown function. This function ensures that the engine and turbocharger properly cool down by maintaining engine operation for a user-defined duration. The No Load Cool Down Time setting accepts values from 0 to 60, in increments of 1 minute.

This cooldown function is initiated for any one of the following conditions:

- Genset load is removed and engine shutdown is permitted while in AUTO mode
- Auto Transfer switch (ATS) opens while operating in AUTO mode
- Remote shutdown is initiated while in AUTO mode
- Off Mode Cooldown is initiated
- The Cooldown Request logic element is initiated
- The Cool and Stop Request logic element is initiated

### Smart Cooldown Function

The smart cooldown function reduces unnecessary fuel expenditure by considering overall cooldown time through multiple requests. For example, a new cooldown request is initiated after a previous cooldown sequence has already started. The cooldown timer is not simply reset with each new request. Instead, the amount of time that the engine has spent cooling down is factored into the new request. This saves time and fuel by running the engine no longer than necessary to achieve proper cooldown.

**Crank Settings**

**Pre-Start**

Pre-crank Delay (s)  
0

**Pre Start Contact Config**

Open After Disconnect  
 Closed While Running

**Prestart Rest Configuration**

Off During Rest  
 On During Rest  
 Preheat Before Crank

**Restart**

Restart Delay (s)  
0

**Cranking**

**Cranking Style**

Cycle  
 Continuous

**Cycle**

Number of Crank Cycles  
2

Cycle Crank Time (s)  
5

**Continuous**

Continuous Crank Time (s)  
10

**Crank Disconnect**

Crank Disconnect Limit (%)  
30

**Oil Pressure Crank Disconnect Enable**

Disable  
 Enable

Crank Disconnect Pressure (psi)  
35.0

**Cool Down**

Off Mode Cool Down Enable  
Disable

No Load Cool Down Time (min)  
0

Figure 76. Settings Explorer, System Parameters, Crank Settings Screen

## Automatic Restart

When enabled, the Automatic Restart clears all alarms automatically if the DGC-2020ES shuts down due to an alarm condition. An attempt to restart the engine is made, after a predetermined time delay, if the ATS contact input is closed. If an ATS contact is not present, the unit remains in the READY state with alarms cleared. A restart is not attempted if a low fuel alarm or emergency stop is present. The number of restart attempts is programmable. Automatic restart attempts are recorded in the event log.

The Auto Restart Interval setting accepts values from 0.5 to 30, in increments of 0.5 minutes. The Auto Restart Attempts setting accepts values from 1 to 10, in increments of 1.

The Automatic Restart screen is found in the BESTCOMSP<sup>Plus</sup> Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Automatic Restart.

The BESTCOMSP<sup>Plus</sup> Automatic Restart screen is illustrated in Figure 77.

**Automatic Restart**

Auto Restart Enable  
Enable

Auto Restart Interval (min)  
0.5

Auto Restart Attempts  
1

Figure 77. Settings Explorer, System Parameters, Automatic Restart Screen

## Exercise Timer

The exercise timer is used to start the genset at a predetermined time and run for a user-defined period. The mode defines how often the genset will run. If monthly is selected, the day of the month to start must also be selected. If weekly is selected, the day of the week to start must also be selected. Settings for Start Hour and Start Minute can also be defined. The Run Period Hours and Minutes define how long the genset will run each session. The Start Hour and Run Period Hours settings accept values from 0 to 23, in increments of 1 hour. The Start Minute and Run Period Minutes settings accept values from 0 to 59, in increments of 1. If Run with Load is enabled, the DGC-2020ES closes the generator breaker during the run time.

Contact inputs and outputs can be assigned to this function. Refer to the *BESTlogicPlus* chapter for more information.

The Exercise Timer screen is found in the BESTCOMS*Plus* Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Exercise Timer.

The BESTCOMS*Plus* Exercise Timer screen is illustrated in Figure 78.

The screenshot shows the 'Exercise Timer' configuration window. It contains the following elements:

- Mode:** A dropdown menu set to 'Monthly'.
- Start Day Of Month:** A text input field containing the number '1'.
- Start Day Of Week:** A dropdown menu set to 'Sunday'.
- Start Hour:** A text input field containing '0'.
- Start Minute:** A text input field containing '0'.
- Run Period Hours:** A text input field containing '0'.
- Run Period Minutes:** A text input field containing '0'.
- Run with Load:** An unchecked checkbox.

Figure 78. Settings Explorer, System Parameters, Exercise Timer Screen

## Sensing Transformers

Three sets of transformer settings configure the DGC-2020ES for operation with a specific system. These settings, along with the generator voltage, generator current, and bus voltage detected by the DGC-2020ES, enable it to accurately meter system values and offer generator protection.

The Sensing Transformers screen is found in the BESTCOMS*Plus* Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Sensing Transformers.

When adjusting these settings using BESTCOMS*Plus*, click the *Rated Data* button. See *Rated Data*, above, for more information.

### Generator PT

The generator PT settings establish the nominal primary (generator side) and secondary (DGC-2020ES side) voltage levels at the generator voltage-sensing transformer. The Generator PT Primary setting

accepts values from 1 to 99,999, in increments of 1. The Generator PT Secondary setting accepts values from 1 to 480, in increments of 1.

## Bus PT

Primary and secondary bus transformer ratings are used by the optional automatic transfer switch function. This function monitors a three-phase bus input to detect mains failure. The primary setting establishes the nominal voltage present at phases A, B, and, C of the bus. This setting accepts values from 1 to 99,999, in increments of 1. The secondary setting establishes the nominal voltage detected at the bus voltage input of the DGC-2020ES. This setting accepts values from 1 to 480, in increments of 1.

## Generator CT

The generator CT setting establishes the nominal, primary (generator side) current level at the generator current sensing transformer. This setting accepts values from 1 to 9,999, in increments of 1. The secondary value of the generator CT is dictated by the style number of the controller. A DGC-2020ES with a style number of 1xx uses a nominal CT secondary rating of 1 Aac. A DGC-2020ES with a style number of 5xx uses a nominal CT secondary rating of 5 Aac.

The Gen CT Low Line Scale Factor setting is used to automatically adjust the Gen CT Primary Amps setting in applications that may utilize more than one type of genset connection. This setting accepts a value from 0.001 to 3, in increments of 0.001. The scale factor setting is implemented when the DGC-2020ES senses a contact closure at a contact input programmed to activate scaling of the settings. The value of the scale factor setting serves as a multiplier for the Gen CT Primary Amps setting. For example, if a scale factor contact input is received by the DGC-2020ES and the scale factor setting is 2.000, the Gen CT Primary Amps setting is doubled (2.000 x Gen CT Primary Amps).

## Relay Control

The default operational setting for the Start, Run, and Pre-start relays is *Predefined* or standard. Any of these relays can be logic driven by selecting the *Programmable* setting. Logic driven (programmable relays must be set up using BESTLogicPlus.

The Relay Control screen is found in the BESTCOMSPlus Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Relay Control.

The BESTCOMSPlus Relay Control screen is illustrated in Figure 79.




Figure 79. Settings Explorer, System Parameters, Relay Control Screen

## System Configuration Detection

When enabled, this feature allows the DGC-2020ES to automatically detect its sensing configuration in relation to the generator. Upon starting the genset, the configuration of the generator is automatically detected. The Single Phase Override and Low Line Override programmable function settings are then adjusted accordingly.

There is a one-second delay in the detection to prevent the DGC-2020ES from alternating between detected configurations. When the DGC-2020ES is in the *Off* mode or the engine is not running, the Automatic Configuration Detection function is disabled. The DGC-2020ES is assumed to be in the last valid automatically detected configuration.

It is recommended that the Single Phase Override and Low Line Override programmable functions are not assigned to contact inputs when Automatic Configuration Detection is enabled.

### Single Phase Detect Threshold

If the difference between the maximum and minimum line-to-line voltage exceeds this threshold, the unit is determined to be in single-phase configuration. If determined to be in single-phase configuration, the Single Phase Override programmable function forces the DGC-2020ES into single-phase mode. The single-phase mode connection is determined by the *Single Phase Detect Generator Connection*, below.

If the Single Phase Override function is assigned to a contact output, the state of the contact output and the detected configuration are ORed. This means, if one or both are true, then the system is determined to be configured for single phase.

### Low Line Detect Threshold

If the average of the valid line-to-line voltages for the detected configuration is above this threshold, the unit is determined to be in a high-line configuration. If the average is below this threshold, it is determined to be in a low-line configuration. If determined to be in low-line configuration, the Low-Line Override function forces the DGC-2020ES into the low-line configuration.

If the Low-Line Override function is assigned to a contact output, the state of the contact output and the detected configuration are ORed. This means, if one or both are true, then the system is determined to be configured for low-line.

### Single Phase Detect Generator Connection

This setting specifies which single-phase connection to use when the system is determined to be single-phase. Single-phase AB or Single-phase AC can be selected.

The *Auto Config Detection* screen is found in the BESTCOMS*Plus* Settings Explorer under the System Parameters category. If using the front panel, navigate to Settings > System Parameters > Auto Config Detect. The BESTCOMS*Plus* Auto Config Detection screen is illustrated in Figure 80.

The screenshot shows the 'Auto Config Detection' settings screen. It contains the following elements:

- Auto Config Detection** (Section Header)
- Enable**: A dropdown menu currently set to 'Disable'.
- Single Phase Detect Threshold (V)**: A text input field containing '40' and a unit selector 'V L-L'.
- Low Line Detect Threshold (V)**: A text input field containing '200' and a unit selector 'V L-L'.
- Single Phase Detect Generator Connection**: A dropdown menu currently set to 'A-B'.

**Figure 80. Settings Explorer, System Parameters, Auto Config Detection Screen**

# Security

Password protection guards against unauthorized changing of DGC-2020ES settings. Three levels of password protection are available. Each level is described in the following paragraphs.

- **OEM Access.** This password level allows access to all settings. The default, OEM-access password is **OEM**.
- **Settings Access.** This password level allows all except uploading of firmware and clearing of device event log. The default, settings-access password is **SET**.
- **Operator Access.** The default, operator-access password is **OP**. This password level allows all settings to be read and allows changes to be made to the following:
  - LCD Contrast
  - Sleep Mode
  - Date/Time
  - All Sender Fail Time Delays
  - Metric Conversion
  - Low Fuel Pre-Alarm Level
  - Low Fuel Alarm Level
  - Pre-Start Contact after Cranking
  - Cooldown Time
  - Pre-Crank Time Delay
  - Reset of Maintenance Interval
  - All controls on the Control screen available via the Metering Explorer in BESTCOMSPPlus®

## Changing Passwords

Passwords can be changed only after communication between the PC and DGC-2020ES is established. Changes to passwords are made through the *Device Security Setup* screen. Use the Settings Explorer in BESTCOMSPPlus to open the *General Settings, Device Security Setup* screen.

The content of the *Device Security Setup* screen depends on the password level used when accessing the screen. For example, someone logged in with a settings-access password will be able to change only the settings-access and operator-access passwords - not the OEM-access password.

The BESTCOMSPPlus Device Security Setup screen is illustrated in Figure 81. All three access levels are shown.

A password is changed by clicking on the access level, entering the new password, and then clicking on the *Save Password* button. DGC-2020ES passwords are case sensitive.

## Saving Passwords in a DGC-2020ES Settings File

The passwords can be modified while BESTCOMSPPlus is connected to a DGC-2020ES. The settings from the BESTCOMSPPlus session can then be saved into a settings file. The settings file will contain the new passwords. Also, the passwords in a settings file can be modified off line, saved with the file, and then later loaded into a DGC-2020ES.

### Saving Passwords to a Settings File when On Line.

The following procedure describes how to save passwords to a settings file when BESTCOMSPPlus is connected to a DGC-2020ES (on line):

1. When connected to a DGC-2020ES with BESTCOMSPPlus, click on SETTINGS EXPLORER→GENERAL SETTINGS→DEVICE SECURITY.
2. You will be prompted to enter a password.

3. Enter a password that is of a level as high as or higher than the password you wish to modify. BESTCOMS*Plus* will display all passwords of a level equal to and below the level of the password that was entered.
4. Click on the password you wish to modify. Type in the new password under the “Password” setting that became active when the password to modify was clicked.
5. Click the “Save” button to save the new password into BESTCOMS*Plus* memory (it’s not in the DGC-2020ES yet).
6. Repeat steps 4 and 5 for all password levels you wish to modify.
7. Once all password modifications are complete, in the main menu of BESTCOMS*Plus*, select *Upload Security* from the *Communications* pull-down menu. This is the step where passwords are sent to the DGC-2020ES. Failure to perform this step might cause all password modifications to be lost.
8. Close the *Device Security* tab in BESTCOMS*Plus*.
9. Re-open the *Device Security* tab in BESTCOMS*Plus*. This will read the passwords back out of the DGC-2020ES.
10. Verify the passwords obtained from the DGC-2020ES are correct.
11. Once all desired settings have been loaded into the DGC-2020ES, save the settings file. The resulting settings file has the passwords saved as part of the saved settings.
12. At this point, the password information has been successfully saved in the settings file. The process of saving the passwords into the settings file is complete.

### **Saving Passwords to a Settings File when Off Line**

The following procedure describes how to save passwords to a settings file when working off line:

1. When the settings file is open in BESTCOMS*Plus*, click on SETTINGS EXPLORER→GENERAL SETTINGS→DEVICE SECURITY.
2. You will be prompted to enter a password.
3. Enter a password that is of a level as high as or higher than the password you wish to modify. BESTCOMS*Plus* will display all passwords of a level equal to and below the level of the password that was entered.
4. Click on the password you wish to modify. Type in the new password under the “Password” setting that became active when the password to modify was clicked.
5. Click the “Save” button to save the new password into BESTCOMS*Plus* memory.
6. Repeat steps 4 and 5 for all password levels you wish to modify.
7. Close the *Device Security* tab in BESTCOMS*Plus*.
8. Save the settings file.
9. Close the settings file by clicking on the X in the upper right-hand corner of the settings file, or close BESTCOMS*Plus*.
10. Restart BESTCOMS*Plus* if you have shut it down.
11. Re-open the settings file that you have saved with the password information.
12. When the settings file is open in BESTCOMS*Plus*, click on SETTINGS EXPLORER→GENERAL SETTINGS→DEVICE SECURITY.
13. You will be prompted to enter a password.
14. Enter the password for the highest level of password modified; it should be the new modified password.
15. When passwords are shown, verify they are correct.

16. At this point the password information has been successfully saved in the settings file. The process of saving the passwords into the settings file is complete.

## ***Loading Passwords from a Settings File into the DGC-2020ES***

1. Connect to the DGC-2020ES with BESTCOMSPlus.
2. Once connected, click the “Open File” button that is used to load a settings file into the DGC-2020ES.
3. You will be prompted asking if you wish to load settings and logic into the DGC-2020ES. Select *Yes* if you need to upload settings logic. Select *No* if all you need to do is update security. If you select *No*, the settings file opens into BESTCOMSPlus memory.
4. Whether you have loaded settings and logic to the DGC-2020ES or not, the next step is to select *Upload Security* from the *Communications* pull-down menu.
5. DO NOT try to view the passwords before performing step 4. This would download the existing passwords from the DGC-2020ES and they will overwrite the new passwords that were loaded into BESTCOMSPlus memory from opening the settings file.
6. If you are prompted for a password, enter a password of a level equal to that of the highest level password you wish to modify.
7. The passwords are uploaded to the DGC-2020ES.
8. After you have uploaded the new passwords, select GENERAL SETTINGS→DEVICE SECURITY SETUP in the settings explorer of BESTCOMSPlus. Verify the passwords are correct.
9. This concludes loading passwords from a settings file into the DGC-2020ES.

The screenshot shows the 'Device Security Setup' interface. On the left, there is a table with two columns: 'Access Level' and 'Password'. The 'OEM' row is selected. On the right, there is a 'Selected User Information' section with two input fields: 'Access Level' (containing 'OEM') and 'Password' (containing 'OEM'). Below these fields is a 'Save Password' button.

Access Level	Password
OEM	OEM
Operator	OP
Settings	SET


Selected User Information

Access Level  
OEM

Password  
OEM

Save Password

**Figure 81. Settings Explorer, General Settings, Device Security Setup Screen**



# Timekeeping

The DGC-2020ES provides a real-time clock with capacitor backup that is capable of operating the clock for up to 24 hours after power is removed from the controller. As the capacitor nears depletion, an internal backup battery takes over and maintains timekeeping. The battery will maintain the clock for approximately ten years depending on conditions. The battery is not replaceable.

The clock is used by the events recorder function to time-stamp events and the exercise timer to start and stop the genset when the exercise feature is utilized.

## Clock Setup

Clock settings are made through the communication ports using BESTCOMSPlus<sup>®</sup> or through the front-panel interface. Write access to ports is required to program the clock. An alarm is provided to detect when the DGC-2020ES has powered up and the clock has not been set.

The clock settings are made through BESTCOMSPlus by selecting *Clock Setup* under *General Settings*. If using the front panel, navigate to Settings > General Settings > Configure Date/Time.

The BESTCOMSPlus *Clock Setup* screen is illustrated in Figure 82. Settings are listed in Table 31.

The local time zone is configured on this screen. The Time Zone Offset is the local offset to UTC (Coordinated Universal Time). The Time Zone Offset is required when the Start/End Time Reference is set to UTC (Coordinated Universal Time). The Start/End Time Reference is set to UTC time if required by local daylight savings time rules. The Start/End Hour/Minute settings determine the time when the DST will go into effect. The Bias setting is the amount of time that the clock moves forward or backward. The user is notified when the clock is not set when the Clock Not Set Warning is enabled.

**Clock Setup**

**Time Zone Offset Setup**

UTC Offset (min)  
0

**Daylight Saving Time Setup**

DST Configuration  
Floating

**Start/End Time Reference**

Respective to Local Time  
 Respective to UTC Time

**Start Day**

Month	Occurrence of Day	Weekday	Hour	Minute
March	Second	Sunday	2	0

**End Day**

Month	Occurrence of Day	Weekday	Hour	Minute
November	First	Sunday	2	0

**Bias Setup**

Hour	Minute
1	0

**Clock Not Set Warning**

Disable  
 Enable

Figure 82. Settings Explorer, General Settings, Clock Setup Screen

Table 31. Settings for Clock

Setting	Range	Increment	Unit	Default
UTC Offset	-1,440 to 1,440	1	minutes	-6
DST Configuration	Floating Dates or Fixed Dates	n/a	n/a	Disabled
Start/End Time Reference	Respective to Local Time or Respective to UTC Time	n/a	n/a	Respective to Local Time
Bias Setup (Hour)	-12 to 12	1	hours	Disabled
Bias Setup (Minute)	-59 to 59	1	minutes	0
Clock Not Set Warning	Disable or Enable	n/a	n/a	Disable

## Setting the Time and Date

Time and date settings are made through BESTCOMSP<sup>Plus</sup> on the Real Time Clock screen (Figure 83) of the Metering Explorer. Settings can also be made through the front panel.




Figure 83. Metering Explorer, Real Time Clock Screen

## Real-Time Clock Specifications

Resolution ..... 1 s  
 Accuracy.....  $\pm 1.73$  s/d at 25°C

### Clock Holdup

Capacitor Holdup Time ..... Up to 24 hours depending on conditions  
 Battery Holdup Time ..... Approximately ten years depending on conditions

# Maintenance and Troubleshooting

## ***Maintenance***

---

Preventive maintenance consists of periodically checking that the connections between the DGC-2020ES and the system are clean and tight. Periodically check that the mounting hardware is clean and fastened with the proper amount of torque. DGC-2020ES units are manufactured using state-of-the-art, surface-mount technology. These components are encased in potting material. As such, Basler Electric recommends that no repair procedures be attempted by anyone other than Basler Electric personnel.

## ***Storage***

---

This device contains long-life aluminum electrolytic capacitors. For devices that are not in service (spares in storage), the life of these capacitors can be maximized by energizing the device for 30 minutes once per year.

## ***Troubleshooting***

---

If you do not get the results that you expect from the DGC-2020ES, first check the programmable settings for the appropriate function. Use the following troubleshooting procedures when difficulties are encountered in the operation of your genset control system.

### **Communications**

#### *USB Port Does Not Operate Properly*

Step 1. Verify that the proper port of your computer is being used. For more information, refer to the *Communication* chapter.

#### *CAN Communication Does Not Operate Properly*

- Step 1: Verify that there is a 120-ohm termination resistor on each end of the bus section of the wiring, and that there are not any termination resistors at any node connections that are on stubs from the main bus.
- Step 2: Check all CAN wiring for loose connections and verify that the CAN H and CAN L wires have not gotten switched somewhere on the network.
- Step 3: Verify that the cable length of the bus section of the wiring does not exceed 40 meters (131 feet), and verify that any stubs from the main bus do not exceed 3 meters (9.8 feet) in length.
- Step 4: If the engine is equipped with a Volvo or MTU ECU, verify that the ECU Configuration setting is set to match the actual ECU configuration.

### **Inputs and Outputs**

#### *Programmable Inputs Do Not Operate as Expected*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Confirm that the inputs are programmed properly.
- Step 3. Ensure that the input at the DGC-2020ES is actually connected to the BATT– terminal (17).

#### *Programmable Outputs Do Not Operate as Expected*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Confirm that the outputs are programmed properly.

## Metering/Display

### *Incorrect Display of Battery Voltage, Coolant Temperature, Oil Pressure, or Fuel Level*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Confirm that the SENDER COM terminal (2) is connected to the negative battery terminal and the engine-block side of the senders. Current from other devices sharing this connection can cause erroneous readings.
- Step 3. If the displayed battery voltage is incorrect, ensure that the proper voltage is present between the BATT+ terminal (18) and the SENDER COM terminal (2).
- Step 4. Verify that the correct senders are being used.
- Step 5. Use a voltmeter connected between the BATT– terminal (17) and the SENDER COM terminal (2) on the DGC 2020 to verify that there is no voltage difference at any time. Any voltage differences may manifest themselves as erratic sender readings. Wiring should be corrected so that no differences exist.
- Step 6: Check the sender wiring and isolate sender wiring from any of the ac wiring in the system. The sender wiring should be located away from any power ac wiring from the generator and any ignition wiring. Separate conduits should be used for sender wiring and any ac wiring.

### *Incorrect Display of Generator Voltage*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Ensure that the proper voltage is present at the DGC-2020ES voltage sensing inputs (40, 41, 43, and 45).
- Step 3. Verify that the voltage transformer ratio and sensing configuration is correct.
- Step 4. Confirm that the voltage sensing transformers are correct and properly installed.

### *Incorrect Measurement or Display of Generator Current*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Ensure that the proper current is present at the DGC-2020ES current sensing inputs 33, 34, 35, 36, 37, and 38.
- Step 3. Verify that the current sensing transformer ratios are correct.
- Step 4. Confirm that the current sensing transformers are correct and properly installed.

### *Incorrect Display of Engine RPM*

- Step 1. Verify that all wiring is properly connected. Refer to the *Typical Connections* chapter.
- Step 2. Verify that the flywheel teeth setting is correct.
- Step 3. Verify that the prime mover governor is operating properly.
- Step 4. Verify that the measured frequency of the voltage at the MPU input (31 and 32) is correct.
- Step 5. If the MPU is shared with the governor, verify that the polarity of the MPU input to the governor matches the polarity of the MPU input to the DGC-2020ES.

### *DGC-2020ES Indicates Incorrect Power Factor*

Check the rotation of the machine and the labeling of the A-B-C terminals. The machine must be rotating in the same phase sequence as dictated by the generator phase rotation setting for correct power factor metering. A power factor indication of 0.5 with resistive load present is a symptom of incorrect phase rotation.

### *LCD is Blank and all LEDs are Flashing at Approximately 2 Second Intervals*

This indicates that the DGC-2020ES does not detect that valid application firmware is installed. The unit is running its boot loader program, waiting to accept a firmware upload.

- Step 1. Start BESTCOMS*Plus*<sup>®</sup>. Use the top pull-down menu and select FILE→ NEW→ DGC-2020ES.
- Step 2. Select COMMUNICATIONS→ UPLOAD DEVICE FILES and select the device package file that contains the firmware and language you want to upload.
- Step 3. Check the boxes for DGC-2020ES Firmware and DGC-2020ES Language Module. Click the UPLOAD button to start the upload process.

## Generator Breaker and Mains Breaker

### Generator Breaker Will Not Close to a Dead Bus

- Step 1: Review the description of how the generator breaker logic element functions contained in the GENBRK logic element description in the BESTlogic™*Plus* chapter.
- Step 2: Review the section on breaker close requests in the *Breaker Management* chapter.
- Step 3: Navigate to the SETTINGS→BREAKER MANAGEMENT→BREAKER HARDWARE→GEN BREAKER screen and set DEAD BUS CL ENBL to ENABLE.
- Step 4: Verify that the Generator status is stable. The breaker will not close if the generator status is not stable. Check status by using the Metering Explorer in BESTCOMS*Plus* and verify that when the generator is running, the GEN STABLE status LED is lit. If necessary, modify the settings on the SETTINGS→BREAKER MANAGEMENT→BUS CONDITION DETECTION screen.
- Step 5: Verify the bus status is DEAD. Check status by using the Metering Explorer in BESTCOMS*Plus* and verify that when the generator is running, the BUS DEAD status LED is lit. If necessary, modify the settings on the SETTINGS→BREAKER MANAGEMENT→BUS CONDITION DETECTION screen.
- Step 6: Verify the connections in BESTlogic*Plus* Programmable Logic to the generator breaker logic element. The *Status* input must be driven by an “A” or normally open contact from the generator breaker. The OPEN and CLOSE command inputs on the left side of the logic block are inputs for open and close commands. These can be wired to physical inputs if it is desired to have open and close command switches. If they are wired, they must either be pulsed inputs, or some logic must be employed so that the open and close command inputs are never driven at the same time. If these are both driven at the same time, the breaker is receiving open and close commands simultaneously. The breaker will not change state if it is being commanded to open and close at the same time.
- Step 7: Verify the breaker is receiving a close command. Breaker close command sources are:
  - The DGC-2020ES itself when the automatic mains fail transfer (ATS) feature is enabled.
  - The DGC-2020ES itself when the RUN WITH LOAD logic element receives a *Start* pulse in the programmable logic.
  - The DGC-2020ES itself when started from the Exercise Timer and the Run with Load box is checked in the Generator Exerciser settings.
  - Manual Breaker Close Input Contacts applied to the Open and Close inputs on the left side of the Generator Breaker logic element in the programmable logic.
- Step 8: Verify the wiring to the breaker from the DGC-2020ES. If it seems OK, you can do a manual close and open by modifying the programmable logic. Map some unused outputs to the OPEN and CLOSE outputs from the Gen Breaker Block in the programmable logic. Map a virtual switch to the logic output that would normally be the breaker open output. Map another virtual switch to the logic output that would normally be the breaker close output. Connect with BESTCOMS*Plus*, and exercise the virtual switches using the Control panel located in the Metering Explorer. Never turn open and close on at the same time. This could damage the breaker and/or motor operator. If everything is working as expected, restore the logic to its original diagram.

### Generator Breaker Does Not Open When It Should

- Step 1: Review the description of how the generator breaker logic element functions contained in the GENBRK logic element description in the *BESTlogicPlus* chapter.
- Step 2: Review the section on breaker operation requests in the *Breaker Management* chapter.
- Step 3: Verify the connections in *BESTlogicPlus* Programmable Logic to the generator breaker logic element. The *Status* input must be driven by an “A” or normally open contact from the generator breaker. The OPEN and CLOSE command inputs on the left side of the logic block are inputs for open and close commands. These can be wired to physical inputs if it is desired to have open and close command switches. If they are wired, they must either be pulsed inputs, or some logic must be employed so that the open and close command inputs are never driven at the same time. If these are both driven at the same time, the breaker is receiving open and close commands simultaneously. The breaker will not change state if it is being commanded to open and close at the same time.
- Step 4: Verify the breaker is receiving an open command. Breaker open command sources are:
- The DGC-2020ES itself when the automatic transfer (ATS) feature is enabled.
  - The DGC-2020ES itself when the RUN WITH LOAD logic element receives a *Stop* pulse in the programmable logic.
  - The DGC-2020ES itself when shutting down the engine due to an active alarm.
  - The DGC-2020ES itself when ending a run session from the Exercise Timer and the *Run with Load* box is checked in the Generator Exerciser settings.
  - Manual Breaker Open Input Contacts applied to the Open and Close inputs on the left side of the Generator Breaker logic element in the programmable logic.
- Step 5: Verify the wiring to the breaker from the DGC-2020ES. If it seems OK, you can do a manual close and open by modifying the programmable logic. Map some unused outputs to the OPEN and CLOSE outputs from the Gen Breaker Block in the programmable logic. Map a virtual switch to the logic output that would normally be the breaker open output. Map another virtual switch to the logic output that would normally be the breaker close output. Connect with *BESTCOMSPPlus*, and exercise the virtual switches using the Control panel located in the Metering Explorer. Never turn open and close on at the same time. This could damage the breaker and/or motor operator. If everything is working as expected, restore the logic to its original diagram.

### Mains Breaker Does Not Open When Mains Fails

- Step 1: Verify that a Mains Breaker has been configured by examining the settings on the SETTINGS→BREAKER MANAGEMENT→BREAKER HARDWARE screen.
- Step 2: Verify the mains breaker has been correctly included in the programmable logic.
- Step 3: Verify that the MAINS FAIL TRANSFER parameter is set to ENABLE on the SETTINGS→BREAKER MANAGEMENT→BREAKER HARDWARE screen.
- Step 4: Verify that a failure of the mains is detected by the DGC-2020ES. Check status using the Metering Explorer in *BESTCOMSPPlus* and verify that the MAINS FAIL status LED is lit when the power on the DGC-2020ES bus voltage input is either out of voltage or frequency range. If necessary, modify the settings on the SETTINGS→BREAKER MANAGEMENT→BUS CONDITION DETECTION screen to achieve correct detection.
- Step 5: Verify the wiring to the breaker from the DGC-2020ES. If it seems OK, you can do a manual close and open by modifying the programmable logic. Map some unused outputs to the OPEN and CLOSE outputs from the Gen Breaker Block in the programmable logic. Map a virtual switch to the logic output that would normally be the breaker close output. Map another virtual switch to the logic output that would normally be the breaker close output. Connect with *BESTCOMSPPlus*, and exercise the virtual switches using the Control panel located in the Metering Explorer. Never turn open and close on at the same time. This could damage the

breaker and/or motor operator. If everything is working as expected, restore the logic to its original diagram.

#### Mains Breaker Does Not Close After Mains Returns

- Step 1: Verify that a Mains Breaker has been configured by examining the settings on the SETTINGS→BREAKER MANAGEMENT→BREAKER HARDWARE screen.
- Step 2: Verify the mains breaker has been correctly included in the programmable logic.
- Step 3: Verify that the MAINS FAIL TRANSFER parameter is set to ENABLE on the SETTINGS→BREAKER MANAGEMENT→BREAKER HARDWARE screen.
- Step 4: Verify that stable mains power is detected by the DGC-2020ES. Check status using the Metering Explorer in BESTCOMSP<sup>lus</sup> and verify that the MAINS STABLE status LED is lit when the power on the DGC-2020ES bus voltage input is good. If necessary, modify the settings on the SETTINGS→BREAKER MANAGEMENT→BUS CONDITION DETECTION screen to achieve correct detection.
- Step 5: Verify the wiring to the breaker from the DGC-2020ES. If it seems OK, you can do a manual close and open by modifying the programmable logic. Map some unused outputs to the OPEN and CLOSE outputs from the Gen Breaker Block in the programmable logic. Map a virtual switch to the logic output that would normally be the breaker open output. Map another virtual switch to the logic output that would normally be the breaker close output. Connect with BESTCOMSP<sup>lus</sup>, and exercise the virtual switches using the Control panel located in the Metering Explorer. Never turn open and close on at the same time. This could damage the breaker and/or motor operator. If everything is working as expected, restore the logic to its original diagram.

### **DGC-2020ES Front Panel Debug Screen**

There is one debug screen in the DGC-2020ES that can be useful for debugging I/O module related issues. The following debug screen is available: CEM DEBUG


#### CEM DEBUG

This screen shows the binary data that is being sent between the CEM-2020 (Contact Expansion Module) and the DGC-2020ES.

The CEM DEBUG screen is located on the front panel at SETTINGS→SYSTEM PARAMS→REMOTE MODULE SETUP→CEM SETUP→CEM DEBUG MENU.

The following parameters are visible on the CEM DEBUG screen:

- DGC TO CEM BP: DGC-2020ES to CEM-2020 Binary Points. This is the status of the CEM-2020 output relays being transmitted from the DGC-2020ES to the CEM-2020. This is a 32-bit, bit packed number representing the desired states of the CEM-2020 outputs. The left most bit is the first output, etc.
- CEM TO DGC BP: CEM-2020 to DGC-2020ES Binary Points. This is the status of the CEM-2020 inputs being transmitted from the CEM-2020 to the DGC-2020ES. This is a 32-bit, bit packed number representing the metered states of the CEM-2020 inputs. The left most bit is the first input, etc.



# Specifications

DGC-2020ES electrical and physical characteristics are listed in the following paragraphs.

## ***Operating Power***

---

Nominal .....	12 or 24 Vdc
Range .....	6 to 32 Vdc
Terminals.....	18 (+), 17 (-), 16 (chassis ground)

## **Power Consumption**

Sleep Mode .....	4.5 W - LCD heater off, all relays de-energized
Normal Operational Mode .....	6.5 W - Run mode, LCD heater off, 3 relays energized
Maximum Operational Mode.....	14 W - Run mode, LCD heater on, 7 relays energized

## ***Battery Ride Through***

---

Starting at 10 Vdc, withstands cranking ride-through down to 0 Vdc for 50 ms

## ***Current Sensing***

---

Burden.....	1 VA
Terminals.....	38, 37 (A-phase)
	36, 35 (B-phase)
	34, 33 (C-phase)

### **1 Aac Current Sensing**

Continuous Rating.....	0.02 to 1.0 Aac
1 Second Rating.....	5 Aac
0.050 Second Rating.....	10 Aac

### **5 Aac Current Sensing**

Continuous Rating.....	0.1 to 5.0 Aac
1 Second Rating.....	25 Aac
0.050 Second Rating.....	50 Aac

## ***Voltage Sensing***

---

Range.....	12 to 576 V rms, line-to-line
Frequency .....	50/60 Hz
Frequency Range.....	10 to 72 Hz
Burden.....	1 VA
1 Second Rating.....	720 V rms

### ***Generator Sensing***

Configuration.....	Line-to-line or line-to-neutral
Generator Sensing Terminals .....	45 (A-phase)
	43 (B-phase)
	41 (C-phase)
	40 (Neutral)

***Bus Sensing***

Configuration .....	Line-to-line
Bus Sensing Terminals .....	46 (A-phase)
(Optional with style number xx2)	48 (B-phase)
	50 (C-phase)

***Contact Sensing***

Contact sensing inputs include seven programmable inputs. All inputs accept dry contacts.

Time from a DGC-2020ES input application to:

- Shutdown the generator via an alarm = 490 ms max
- Close a relay on board the DGC-2020ES = 215 ms max
- Close a relay on board the CEM-2020 = 400 ms max

**Terminals**

Input 1 .....	3, 17
Input 2 .....	4, 17
Input 3 .....	5, 17
Input 4 .....	6, 17
Input 5 .....	7, 17
Input 6 .....	8, 17
Input 7 .....	9, 17

***Engine System Inputs***

Stated accuracies are subject to the accuracy of the senders used. Values within these ranges are deemed “good” and the DGC-2020ES will use them for the appropriate calculation and protection. Values outside these ranges are deemed “bad” and the DGC-2020ES will begin timing towards a sender failure condition.

**Fuel Level Sensing**

Resistance Range .....	5 to 250 $\Omega$ nominal
Terminals.....	1, 2 (sender common)

**Coolant Temperature Sensing**

Resistance Range .....	5 to 2,750 $\Omega$ nominal
Terminals.....	53, 2 (sender common)

**Oil Pressure Sensing**

Resistance Range .....	5 to 250 $\Omega$ nominal
Terminals.....	52, 2 (sender common)

**Engine Speed Sensing*****Magnetic Pickup***

Voltage Range .....	3 to 35 V peak (6 to 70 V peak-peak)
Frequency Range.....	32 to 10,000 Hz
Terminals.....	32 (+), 31 (-)

***Generator Voltage***

Range.....	12 to 576 V rms
Terminals.....	45 (A-phase)
	43 (B-phase)
	41 (C-phase)



Measurement/Calculation Methods

Total .....	$kVA = (V_{L-L} \times I_L \times \sqrt{3}) \div 1000$
4-Wire, Line-to-Neutral .....	kVA calculated with respect to neutral
3-Wire, Line-to-Line.....	A-phase $kVA = V_{AB} \times I_A \div 1000 \div \sqrt{3}$
	B-phase $kVA = V_{BC} \times I_B \div 1000 \div \sqrt{3}$
	C-phase $kVA = V_{CA} \times I_C \div 1000 \div \sqrt{3}$
Accuracy.....	$\pm 5\%$ of the full-scale indication or $\pm 6$ kVA *

\* Applies when temperature is between  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ . KVA metering indicates 0 kVA when the generator kVA is below 2% of the full-scale rating.

**Power Factor**

Metering Range.....	0.2 leading to 0.2 lagging
Calculation Method .....	PF = cosine of the angle between phase AB voltage (Vab) and phase A current (Ia) *
Accuracy.....	$\pm 0.02$ †

\* In single-phase AC-connected machines, it is the cosine of the angle between phase CA voltage (Vca) and phase C current (Ic).

† Applies when temperature is between  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$  ( $-40^{\circ}\text{F}$  to  $+158^{\circ}\text{F}$ ).

**NOTE**

For the DGC-2020ES to correctly meter power factor, the generator must be rotating in the same phase sequence as dictated by the generator phase rotation setting.

**Real Power**

Indicates total kW and individual line kW (4-wire, line-to-neutral or 3-wire line-to-line)

Measurement/Calculation Methods

Total .....	PF $\times$ Total kVA
4-Wire, Line-to-Neutral.....	kW calculated with respect to neutral
3-Wire, Line-to-Line.....	A-phase $kW = V_{AB} \times I_A \times PF \div 1000 \div \sqrt{3}$
	B-phase $kW = V_{BC} \times I_B \times PF \div 1000 \div \sqrt{3}$
	C-phase $kW = V_{CA} \times I_C \times PF \div 1000 \div \sqrt{3}$
Accuracy.....	$\pm 5\%$ of the full-scale indication or $\pm 4$ kW *

\* Applies when temperature is between  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ . KW metering indicates 0 kW when the generator kW is below 2% of the full-scale rating.

**Oil Pressure**

Metering Range.....	0 to 150 psi, 0 to 10.3 bar, or 0 to 1,034 kPa
Accuracy.....	$\pm 3\%$ of actual indication or $\pm 2$ psi, $\pm 0.12$ bar, or $\pm 12$ kPa (subject to accuracy of sender)
Display Resolution .....	1 psi, 0.1 bar, or 1 kPa

**Coolant Temperature**

Metering Range.....	32 to 410°F or 0 to 204°C
Accuracy.....	$\pm 3\%$ of actual indication or $\pm 2^{\circ}$ (subject to accuracy of sender)

**Battery Voltage**

Metering Range.....	6 to 32 Vdc
---------------------	-------------



## Phase Imbalance (47)

Pickup Range .....	5 to 100 Vac
Pickup Increment .....	1 Vac
Activation Delay Range .....	0 to 30 s
Activation Delay Increment .....	0.1 s

## Logic Timers

Hours Setting Range .....	0 to 250
Hours Setting Increment .....	1
Minutes Setting Range .....	0 to 250
Minutes Setting Increment .....	1
Seconds Setting Range .....	0 to 1,800
Seconds Setting Increment .....	0.1
Accuracy .....	±15 ms

## Communication Interface

### USB

Specification Compatibility .....	USB 2.0
Data Transfer Speed .....	115,200 baud
Connector Type .....	Mini-B jack

### RDP-110

Minimum Wire Size .....	20 AWG
Maximum Wire Length .....	4,000 feet (1,219 meters)
Terminals .....	11 (RDP TxD+), 10 (RDP TxD-)

### CAN

Differential Bus Voltage .....	1.5 to 3 Vdc
Maximum Voltage .....	-32 to +32 Vdc with respect to negative battery terminal
Communication Rate .....	250 kb/s
Terminals .....	14 (low), 13 (high), and 15 (shield)

### NOTES

1. If the DGC-2020ES is providing one end of the J1939 bus, a 120  $\Omega$ , ½ watt terminating resistor should be installed across terminals 14 (CANL) and 13 (CANH).
2. If the DGC-2020ES is not part of the J1939 bus, the stub connecting the DGC-2020ES to the bus should not exceed 914 mm (3 ft) in length.
3. The maximum bus length, not including stubs, is 40 m (131 ft).
4. The J1939 drain (shield) should be grounded at one point only. If grounded elsewhere, do not connect the drain to the DGC-2020ES.

## ***Real-Time Clock***

---

Clock has leap year and selectable daylight saving time correction. Backup capacitor and backup battery sustain timekeeping during losses of DGC-2020ES operating power.

Resolution ..... 1 s  
Accuracy.....  $\pm 1.73$  s/d at 25°C

### **Clock Holdup**

Battery Holdup Time ..... Approximately 10 yrs

## ***Liquid Crystal Display (LCD)***

---

Display ..... 128 by 64 dot pixels LCD with LED Backlight  
Operating Temperature..... -40 to +70°C (-40 to +158°F)  
Storage Temperature..... -40 to +80°C (-40 to +176°F)

### **LCD Heater**

The ambient temperature is monitored by a temperature sensor located near the LCD inside the DGC-2020ES. The LCD heater turns on when the ambient temperature falls below 0°C (32°F). The heater turns off when the ambient temperature rises above 5°C (41°F). This range of operation implements 5°C (9°F) of hysteresis between heater turn-on and turn-off.

## ***Type Tests***

---

Shock and Vibration ..... EN60068-2-6  
Dielectric Strength..... IEC 255-5  
Impulse ..... EN60664-1  
Transients..... EN61000-4-4  
Static Discharge ..... EN61000-4-2

### **Shock**

Withstands 15 G in three perpendicular planes.

### **Vibration**

Tested in three mutually perpendicular planes for 8 hours over the following ranges:  
3 to 25 Hz at 1.6 mm (0.063 inches), peak amplitude  
25 to 2,000 Hz at 5G

### **Radio Interference**

Type tested using a 5 W, hand-held transceiver operating at random frequencies centered around 144 and 440 MHz with the antenna located within 150 mm (6") of the device in both vertical and horizontal planes.

### **HALT (Highly Accelerated Life Testing)**

HALT is used by Basler Electric to prove that our products will provide the user with many years of reliable service. HALT subjects the device to extremes in temperature, shock, and vibration to simulate years of operation, but in a much shorter period span. HALT allows Basler Electric to evaluate all possible design elements that will add to the life of this device. As an example of some of the extreme testing conditions, the DGC-2020ES was subjected to temperature tests (tested over a temperature range of -100°C to +130°C), vibration tests (of 5 to 50 G at +20°C), and temperature/vibration tests (tested at 50 G over a temperature range of -95°C to +125°C). Combined temperature and vibration testing at these extremes proves that the DGC-2020ES is expected to provide long-term operation in a rugged

environment. Note that the vibration and temperature extremes listed in this paragraph are specific to HALT and do not reflect recommended operation levels.

### **Ignition System**

Tested in close proximity to an unshielded, unsuppressed Altronic DISN 800 Ignition System.

### ***Environment***

---

Operating Temperature..... –40 to +70°C (–40 to +158°F)  
 Storage Temperature..... –40 to +85°C (–40 to +185°F)  
 Humidity ..... IEC 68-2-38  
 Salt Spray..... IEC 68-2-52  
 Ingress Protection ..... IEC IP56 for front panel

### ***UL Approval***

---

The DGC-2020ES is recognized to applicable Canadian and US safety standards and requirements by UL.

Standards used for evaluation:

- UL6200
- CSA C22.2 No. 14

### ***CSA Certification***

---

The DGC-2020ES was tested and has met the certification requirements for electrical, plumbing and/or mechanical products.

Standards used for evaluation:

- CSA C22.2 No. 14

### ***NFPA Compliance***

---

Complies with NFPA Standard 110, *Standard for Emergency and Standby Power*.

### ***CE Compliance***

---

This product has been evaluated and complies with the relevant essential requirements set forth by the EU legislation.

EC Directives:

- Low Voltage Devices (LVD) - 73/23/EEC as amended by 93/68/EEC
- Electromagnetic Compatibility (EMC) - 89/336/EEC as amended by 92/31/EEC and 93/68/EEC

Harmonized Standards used for evaluation:

- EN 50178 - Electronic Equipment for use in Power Installations
- EN 61000-6-4 - Electromagnetic Compatibility (EMC), Generic Standards, Emission Standard for Industrial Environments
- EN 61000-6-2 - Electromagnetic Compatibility (EMC), Generic Standards, Immunity for Industrial Environments

### ***Physical***

---

Weight ..... 1.9 lb (0.86 kg)  
 Dimensions..... See the *Mounting* chapter.

# CEM-2020

## General Information

The optional CEM-2020 is a remote auxiliary device that provides additional DGC-2020ES contact inputs and outputs. Two types of modules are available. A low current module (CEM-2020) provides 24 contact outputs and high current module (CEM-2020H) provides 18 contact outputs.

## Features

CEM-2020s have the following features:

- 10 Contact Inputs
- 18 Contact Outputs (CEM-2020H) or 24 Contact Outputs (CEM-2020)
- Functionality of Inputs and Outputs assigned by BESTlogic™ *Plus* Programmable Logic
- Communications via CAN

## Specifications

### Operating Power

Nominal .....	12 or 24 Vdc
Range .....	8 to 32 Vdc (Withstands cranking ride-through down to 6 Vdc for 500 ms)

### Maximum Power Dissipation

CEM-2020 .....	14 W
CEM-2020H.....	8 W

### Contact Inputs

The CEM-2020 contains 10 programmable inputs that accept dry contacts.

Time from a CEM-2020 input application to:

- Shut down the generator via an alarm = 700 ms max
- Close a relay on board the DGC-2020ES = 300 ms max
- Close a relay on board the CEM-2020 = 550 ms max

### Contact Outputs

#### Ratings

#### CEM-2020

Outputs 5 through 16 .....	1 Adc at 30 Vdc, Form C, gold contacts
Outputs 17 through 28 .....	4 Adc at 30 Vdc, Form C

#### CEM-2020H

Outputs 5 through 16 .....	2 Adc at 30 Vdc, Form C, gold contacts
Outputs 17 through 22 .....	10 Adc at 30 Vdc, Form C

### Communications Interface

#### CAN

Differential Bus Voltage.....	1.5 to 3 Vdc
Maximum Voltage .....	-32 to +32 Vdc with respect to negative battery terminal
Communication Rate.....	250 kb/s

## Type Tests

### Shock

Withstands 15 G in three perpendicular planes.

### Vibration

Swept over the following ranges for 12 sweeps in each of three mutually perpendicular planes with each 15-minute sweep consisting of the following:

5 to 29 to 5 Hz ..... 1.5 G peak for 5 min.  
 29 to 52 to 29 Hz ..... 0.036" Double Amplitude for 2.5 min.  
 52 to 500 to 52 Hz ..... 5 G peak for 7.5 min.

### Ignition System

Tested in close proximity to an unshielded, unsuppressed Altronic DISN 800 ignition system.

### HALT (Highly Accelerated Life Testing)

HALT is used by Basler Electric to prove that our products will provide the user with many years of reliable service. HALT subjects the device to extremes in temperature, shock, and vibration to simulate years of operation, but in a much shorter period span. HALT allows Basler Electric to evaluate all possible design elements that will add to the life of this device. As an example of some of the extreme testing conditions, the CEM-2020 was subjected to temperature tests (tested over a temperature range of  $-80^{\circ}\text{C}$  to  $+130^{\circ}\text{C}$ ), vibration tests (of 5 to 50 G at  $+25^{\circ}\text{C}$ ), and temperature/vibration tests (tested at 10 to 20 G over a temperature range of  $-60^{\circ}\text{C}$  to  $+100^{\circ}\text{C}$ ). Combined temperature and vibration testing at these extremes proves that the CEM-2020 is expected to provide long-term operation in a rugged environment. Note that the vibration and temperature extremes listed in this paragraph are specific to HALT and do not reflect recommended operation levels. These operational ratings are included in this section.

## Environment

Humidity ..... Complies with IEC 68-2-38

### Temperature

Operating .....  $-40$  to  $+70^{\circ}\text{C}$  ( $-40$  to  $+158^{\circ}\text{F}$ )  
 Storage .....  $-40$  to  $+85^{\circ}\text{C}$  ( $-40$  to  $+185^{\circ}\text{F}$ )

## UL Approval (CEM-2020 Only)

"cURus" recognized to UL Standard 508 & CSA Standard C22.2 No. 14.

## UL Approval (CEM-2020H Only)

UL recognized to UL Standard 508.

## CSA Certification

CSA certified to Standard C22.2 No.14.

## NFPA Compliance

Complies with NFPA Standard 110, *Standard for Emergency and Standby Power*.

## CE Compliance

This product complies with the requirements of the following EC Directives:

- Low Voltage Directive (LVD) - 73/23/EEC as amended by 93/68/EEC
- Electromagnetic Compatibility (EMC) - 89/336/EEC as amended by 92/31/EEC and 93/68/EEC

This product conforms to the following Harmonized Standards:

- EN 50178:1997 - *Electronic Equipment for use in Power Installations*
- EN 61000-6-4:2001 - *Electromagnetic Compatibility (EMC), Generic Standards, Emission Standard for Industrial Environments*
- EN 61000-6-2:2001 - *Electromagnetic Compatibility (EMC), Generic Standards, Immunity for Industrial Environments*

## Physical

Dimensions..... See *Installation* later in this chapter.

### Weight

CEM-2020 ..... 2.25 lb (1.02 kg)  
CEM-2020H..... 1.90 lb (0.86 kg)

## ***Functional Description***

---

### **Contact Inputs**

The CEM-2020 provides 10 programmable contact inputs with the same functionality as the contact inputs on the DGC-2020ES. The label text of each contact input is customizable.

### **Contact Outputs**

#### CEM-2020

The CEM-2020 provides 24 programmable contact outputs with the same functionality as the contact outputs on the DGC-2020ES. Outputs 5 through 16 can carry 1 A. Outputs 17 through 28 can carry 4 A. The label text of each contact output is customizable.

#### CEM-2020H

The CEM-2020H provides 18 programmable contact outputs with the same functionality as the contact outputs on the DGC-2020ES. Outputs 5 through 16 can carry 2 A. Outputs 17 through 22 can carry 10 A. The label text of each contact output is customizable.

### **Communications**

#### CAN

A Control Area Network (CAN) is a standard interface that enables communication between the CEM-2020 and the DGC-2020ES.

## ***BESTCOMSPlus® Software***

---

BESTCOMSPlus provides the user with a point-and-click means to set and monitor the Contact Expansion Module. Installation and operation of BESTCOMSPlus is described in the BESTCOMSPlus chapter.

## ***Installation***

---


Contact Expansion Modules are delivered in sturdy cartons to prevent shipping damage. Upon receipt of a module, check the part number against the requisition and packing list for agreement. Inspect for damage, and if there is evidence of such, immediately file a claim with the carrier and notify the Basler Electric regional sales office or your sales representative.

If the device is not installed immediately, store it in the original shipping package in a moisture- and dust-free environment.

### Mounting

Contact Expansion Modules are contained in a potted plastic case and may be mounted in any convenient position. The construction of a Contact Expansion Module is durable enough to mount directly on a genset using ¼-inch hardware. Hardware selection should be based on any expected shipping/transportation and operating conditions. The torque applied to the mounting hardware should not exceed 65 in-lb (7.34 N•m).

See Figure 84 for CEM-2020 overall dimensions. All dimensions are shown in inches with millimeters in brackets.



**Figure 84. CEM-2020 Overall Dimensions**

See Figure 85 for CEM-2020H overall dimensions. All dimensions are shown in inches with millimeters in brackets.




Figure 85. CEM-2020H Overall Dimensions

## Connections

Contact Expansion Module connections are dependent on the application. Incorrect wiring may result in damage to the module.

### Note

Operating power from the battery must be of the correct polarity. Although reverse polarity will not cause damage, the CEM-2020 will not operate.

Be sure that the CEM-2020 is hard-wired to earth ground with no smaller than 12 AWG copper wire attached to the chassis ground terminal on the module.

## Terminations

The terminal interface consists of plug-in connectors with screw-down compression terminals.

CEM-2020 connections are made with one 5-position connector, two 18-position connectors, and two 24-position connectors with screw-down compression terminals. These connectors plug into headers on the CEM-2020. The connectors and headers have dovetailed edges that ensure proper connector orientation. The connectors and headers are uniquely keyed to ensure that the connectors mate only with the correct headers. Connector screw terminals accept a maximum wire size of 12 AWG (3.31 mm<sup>2</sup>). Maximum screw torque is 5 inch-pounds (0.56 N•m).

### Operating Power

The Contact Expansion Module operating power input accepts either 12 Vdc or 24 Vdc and tolerates voltage over the range of 6 to 32 Vdc. Operating power must be of the correct polarity. Although reverse polarity will not cause damage, the CEM-2020 will not operate. Operating power terminals are listed in Table 32.

It is recommended that a fuse be added for additional protection for the wiring to the battery input of the Contact Expansion Module. A Bussmann ABC-7 fuse or equivalent is recommended.

**Table 32. Operating Power Terminals**

<b>Terminal</b>	<b>Description</b>
P1- ⚡ (SHIELD)	Chassis ground connection
P1- (BATT-)	Negative side of operating power input
P1 + (BATT+)	Positive side of operating power input

### Contact Inputs and Contact Outputs

The CEM-2020 (Figure 86) has 10 contact inputs and 24 contact outputs. The CEM-2020H (Figure 87) has 10 contact inputs and 18 contact outputs.

#### **Note**

To follow UL guidelines, a fuse must be implemented in the 2Adc contact circuits (Outputs 5 through 16) of the CEM-2020H used in hazardous locations. The suggested fuse size in Adc = (100/Contact Voltage) with a maximum fuse size of 5Adc.





Figure 86. CEM-2020 Contact Input and Contact Output Terminals



**Figure 87. CEM-2020H Contact Input and Contact Output Terminals**

CAN Interface

These terminals provide communication using the SAE J1939 protocol and provide high-speed communication between the Contact Expansion Module and the DGC-2020ES. Connections between the CEM-2020 and DGC-2020ES should be made with twisted-pair, shielded cable. CAN interface terminals are listed in Table 33. Refer to Figure 88 and Figure 89.

**Table 33. CAN Interface Terminals**

Terminal	Description
P1- HI (CAN H)	CAN high connection (yellow wire)
P1- LO (CAN L)	CAN low connection (green wire)
P1-  (SHIELD)	CAN drain connection

### Note

1. If the CEM-2020 is providing one end of the J1939 bus, a 120  $\Omega$ , ½ watt terminating resistor should be installed across terminals P1- LO (CANL) and P1- HI (CANH).
2. If the CEM-2020 is not part of the J1939 bus, the stub connecting the CEM-2020 to the bus should not exceed 914 mm (3 ft) in length.
3. The maximum bus length, not including stubs, is 40 m (131 ft).
4. The J1939 drain (shield) should be grounded at one point only. If grounded elsewhere, do not connect the drain to the CEM-2020.




Figure 88. CAN Interface with CEM-2020 providing One End of the Bus




Figure 89. CAN Interface with DGC-2020ES providing One End of the Bus

## Remote Contact Input Configuration

The CEM-2020 provides 10 contact inputs. Each of the 10 contact inputs can be independently configured to annunciate an alarm or pre-alarm when the input senses a contact closure. A user-adjustable time delay can be set to delay recognition of a contact input. By default, all inputs are configured so that they do not trigger an alarm or pre-alarm.

To make identifying the contact inputs easier, a user-assigned name can be given to each input.

Contacts can be recognized always or only while the engine is running.

The remote contact inputs are incorporated into a BESTlogicPlus programmable logic scheme by selecting them from the I/O group in BESTlogicPlus. For more details, refer to the BESTlogicPlus chapter.

Remote contact input status is available in BESTlogicPlus Programmable Logic when “None” is selected for Alarm Configuration.

The *Remote Contact Inputs* screen is found in the BESTCOMSPlus *Settings Explorer* under the *Programmable Inputs* category. If using the front panel, navigate to Settings > Programmable Inputs > Configurable Inputs. The BESTCOMSPlus Remote Contact Inputs screen is illustrated in Figure 90.

The screenshot shows the 'Remote Contact Inputs' configuration screen. It features six distinct configuration panels for individual inputs, labeled 'Input #8' through 'Input #13'. Each panel contains the following settings:

- Alarm Configuration:** A dropdown menu set to 'None'.
- Activation Delay (s):** A text input field containing the value '0'.
- Label Text:** A text input field containing the label 'INPUT 8', 'INPUT 9', 'INPUT 10', 'INPUT 11', 'INPUT 12', or 'INPUT 13'.
- Contact Recognition:** A dropdown menu set to 'Always'.

Figure 90. Settings Explorer, Programmable Inputs, Remote Contact Inputs Screen

## Remote Contact Output Configuration

To make identifying the contact outputs easier, each of the contact outputs can be given a user-assigned name.

The contact outputs are incorporated into a BESTlogicPlus programmable logic scheme by selecting them from the I/O group in BESTlogicPlus. For more details, refer to the BESTlogicPlus chapter.

The *Remote Contact Outputs* screen is found in the BESTCOMSPlus *Settings Explorer* under the *Programmable Outputs* category. If using the front panel, navigate to Settings > Programmable Outputs > Configurable Outputs. The BESTCOMSPlus Contact Outputs screen is illustrated in Figure 91.

Remote Contact Outputs

Output #5 Label Text OUTPUT 5	Output #6 Label Text OUTPUT 6	Output #7 Label Text OUTPUT 7
Output #8 Label Text OUTPUT 8	Output #9 Label Text OUTPUT 9	Output #10 Label Text OUTPUT 10
Output #11 Label Text	Output #12 Label Text	Output #13 Label Text

Figure 91. Settings Explorer, Programmable Outputs, Remote Contact Outputs Screen

## Maintenance

Preventive maintenance consists of periodically checking that the connections between the CEM-2020 and the system are clean and tight. Contact Expansion Modules are manufactured using state-of-the-art surface-mount technology. As such, Basler Electric recommends that no repair procedures be attempted by anyone other than Basler Electric personnel.



# MTU Fault Codes

A DGC-2020ES connected to a genset equipped with an MTU engine ECU tracks and displays the active fault codes issued by the MTU engine ECU. Active MTU fault codes can be viewed through BESTCOMSPi<sup>us</sup>® by using the Metering Explorer to expand the MTU tree or through the front panel display by navigating to METERING, ALARMS-STATUS, MTU FAULT CODES.

Each fault code is displayed with a fault description and the fault number. If the DGC-2020ES does not have descriptive information about a fault number that was received, the fault description will display as “NO TEXT AVAILABLE”. Fault codes displayed by the DGC-2020ES are listed in Table 34.

**Table 34. MTU Fault Codes**

Fault Code Number	String	Description
3	HI T FUEL	Fuel temperature too high (limit 1).
4	SS T FUEL	Fuel temperature too high (limit 2).
5	HI T CHRG AIR	Charge air temperature too high (limit 1).
6	SS T CHRG AIR	Air temperature too high (limit 2).
9	HI T INTERCOOLER	Coolant temperature of intercooler too high (limit 1).
10	SS T INTERCOOLER	Coolant temperature of intercooler too high (limit 2)
15	LO P LUBE OIL	Pressure of lube oil too low (limit 1).
16	SS P LUBE OIL	Pressure of lube oil too low (limit 2).
19	HI T EXHAUST A	Exhaust gas temperature (A-side) too high (limit 1).
20	SS T EXHAUST A	Exhaust gas temperature (A-side) too high (limit 2)
21	HIT T EXHAUST B	Exhaust gas temperature (B-side) too high (limit 1).
22	SS T EXHAUST B	Exhaust gas temperature (B-side) too high (limit 2).
23	LO COOLANT LEVEL	Coolant level too low (limit 1).
24	SS COOLANT LEVEL	Coolant level too low (limit 2).
25	HI P DIFF LUBE OIL	Differential pressure of oil filter too high (limit 1).
26	SS P DIFF LUBE OIL	Differential pressure of oil filter too high (limit 2).
27	HI LEVEL LEAKAGE FUEL	Level of leakage fuel too high (limit 1).
29	HI ETC IDLE SPD TOO HI	Idle speed of one of the switchable chargers too high.
30	SS ENGINE OVERSPEED	Engine overspeed (limit 2).
31	HI ETC1 OVERSPEED	Speed of basic charger too high (limit 1).
32	SS ETC1 OVERSPEED	Speed of basic charger too high (limit 2).
33	L1 P FUELFLT DIF	Differential pressure of fuel filter too high (limit 1).
36	HI ETC2 OVERSPEED	Speed of 1 <sup>st</sup> switchable charger too high (limit 1).
37	SS ETC2 OVERSPEED	Speed of 1 <sup>st</sup> switchable charger too high (limit 2).
38	AL ETC SPEED DEVIATION	Speed deviation between basic turbocharger and one of the switchable chargers.
39	AL ETC2 CUTIN FAIL	Switching of charger ETC2 failed.
44	LO LEVEL INTRCLR	Coolant level of intercooler too low (limit 1).
45	FAULT L2 LEVEL INTRCLR	Coolant level of intercooler too low (limit 2).
51	HI T LUBE OIL	Lube oil temperature too high (limit 1).
52	SS T LUBE OIL	Lube oil temperature too high (limit 2).
57	LO P COOLANT	Coolant pressure too low (limit 1).

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
58	SS P COOLANT	Coolant pressure too low (limit 2).
59	SS T COOLANT L3	Coolant temperature too high/too low (limit 3).
60	SS T COOLANT L4	Coolant temperature too high/too low (limit 4).
63	HI P CRANKCASE	Crankcase pressure too high (limit 1).
64	SS P CRANK CASE	Crankcase pressure too high (limit 2).
65	LO P FUEL	Fuel supply pressure too low (limit 1).
66	SS P FUEL	Fuel supply pressure too low (limit 2).
67	HI T COOLANT	Coolant temperature too high (limit 1).
68	SS T COOLANT	Coolant temperature too high (limit 2).
69	L1 T EXTERN 1	Limit 1, out of range.
70	L2 T EXTERN 1	Limit 2, out of range.
71	L1 T EXTERN 2	Limit 1, out of range.
72	L2 T EXTERN 2	Limit 2, out of range.
73	L1 P EXTERN 1	Limit 1, out of range.
74	L2 P EXTERN 1	Limit 2, out of range.
75	L1 P EXTERN 2	Limit 1, out of range.
76	L2 P EXTERN 2	Limit 2, out of range.
77	LIM EXT CLNT LEV	Binary signal 1 Plant active.
78	LIM INTERCLR LEV	Binary signal 2 Plant active.
79	L BIN EXTERN 3	Binary signal 3 Plant active.
80	L BIN EXTERN 4	Binary signal 4 Plant active.
81	AL RAIL LEAKAGE	Rail pressure gradient too low for Start or too high for Stop.
82	HI P FUEL COMON RAIL	Rail pressure > setpoint value.
83	LO P FUEL COMMON RAIL	Rail pressure < setpoint value.
85	HI T UMBLASSEN	'Umblasen' temperature too high (limit 1).
86	SS T UMBLASSEN	'Umblasen' temperature too high (limit 2).
89	SS SPEED TOO LOW	Engine is being stalled. The engine speed of the normally operating engine dropped below the limit from parameter 2.2500.027 Limit Engine Speed Low without any stop request. For safety reason the engine is stopped when this event occurs.
90	SS IDLE SPEED LOW	Idle speed not reached.
91	SS RELEASE SPEED LO	Acceleration speed not reached.
92	SS STARTER SPEED LO	Starter speed not reached.
93	SS PREHT TMP	Preheat temperature too low (limit 2).
94	LO PREHT TMP	Preheat temperature too low (limit 1).
95	AL PRELUBE FAULT	Pre-lubrication fault.
100	EDM NOT VALID	Checksum fault EDM.
101	IDM NOT VALID	Checksum fault IDM.
102	INVLD FUEL CNS 1	Fuel consumption counter detect.
103	INVLD FUEL CNS 2	Consumption monitoring 2 not valid.
104	ENG HRS INVALID 1	Engine Hours Counter defect.
105	ENG HRS INVALID 2	Checksum fault.
106	ERR REC1 INVALID	Checksum fault.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
107	ERR REC2 INVALID	Checksum fault.
118	LO ECU SUPPLY VOLTS	Power supply voltage too low (limit 1).
119	LOLO ECU SUPPLY VOLTS	Power supply voltage too low (limit 2).
120	HI ECU SUPPLY VOLTS	Power supply voltage too high (limit 1).
121	HIHI ECU SUPPLY VOLTS	Power supply voltage too high (limit 2).
122	HI T ECU	Temperature of electronic too high (limit 1).
134	15v POSECU DEFCT	Internal electronic fault.
136	15V NEGECU DEFCT	Internal electronic fault.
137	L1 5V BUFFR TEST	Pressure-sensor fault, pressure-sensor wiring, or internal electronic fault.
138	SENSOR PWR DEFCT	Pressure-sensor fault, pressure-sensor wiring, or internal electronic fault.
139	L1 TE BUFFR TEST	Internal electronic fault.
140	TE BUF ECU DEFCT	Internal electronic fault.
141	AL POWER TOO HIGH	AL power too high.
142	MCR EXCEEDED 1 HR STR	AL MCR exceeded 1 hour.
143	BANK1 ECU DEFECT	Internal electronic fault.
144	BANK2 ECU DEFECT	Internal electronic fault.
145	15V GOODECU DFCT	Internal electronic fault.
147	AD TST1ECU DEFCT	Internal electronic fault.
149	AD TST2ECU DEFCT	Internal electronic fault.
151	AD TST3ECU DEFCT	Internal electronic fault.
170	MI MODULE FAIL	Module in maintenance indicator defect.
171	MI NOT ACTIVE	WI not active anymore.
172	TBO EXPIRED	TBO expired.
173	MODL WRITE LIMIT	EEPROM write limit reached.
176	AL LIFE DATA NA	No (fitting) LifeData-Backup-System is available within a delay time after ECU Reset.
177	AL LIFE DATA INCPLT	If the ADEC has to restore the LifeData from the backup-system and at least one checksum is wrong after the upload or the upload is incomplete, then this failure is set.
180	AL CAN1 NODE LOST	Connection to a node on CAN 1 lost.
181	AL CAN2 NODE LOST	Connection to a node on CAN 2 lost.
182	AL CAN WRONG PARAMS	Incorrect CAN parameter values have been entered.
183	AL CAN NO PU DATA	A CAN mode is selected which the communication is initialized aided of the PU data module. However, required PU data module is not present or is not valid.
184	AL CAN PUDATA ERR	During attempt to copy a received PU data module to Flash module, a program error occurred.
185	CAN LESS MAILBXS	CAN less mailboxes.
186	AL CAN1 BUS OFF	CAN controller 1 is in "Bus Off" state.
187	AL CAN1 ERR PASSV	CAN controller 1 has signaled a warning.
188	AL CAN2 BUS OFF	CAN controller 2 is in "Bus Off" state.
189	AL CAN2 ERROR PASSV	CAN controller 2 has signaled a warning.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
190	AL EMU PARAM NO SUPPORT	EMU parameters are not supported.
201	SD T COOLANT	Coolant temperature-sensor defect.
202	SD T FUEL	Fuel temperature-sensor defect.
203	SD T CHARGE AIR	Charge air temperature-sensor defect.
205	SD T CLNT INTERC	Intercooler coolant temperature-sensor defect.
206	SD T EXHAUST A	Exhaust gas temperature-sensor on A-side defect.
207	SD T EXHAUST B	Exhaust gas temperature-sensor on B-side defect.
208	SD P CHARGE AIR	Charge air pressure-sensor defect.
211	SD P LUBE OIL	Lube oil pressure-sensor defect.
212	SD P COOLANT	Coolant pressure-sensor defect.
213	SD P COOLANT INTRCOOLR	Intercooler coolant pressure-sensor defect.
214	SD P CRANKCASE	Crankcase pressure-sensor defect.
215	SD P HD	Rail pressure-sensor defect.
216	SD T LUBE OIL	Lube oil temperature-sensor defect.
219	SD T INTAKE AIR	Intake air temperature-sensor defect.
220	SD COOLANT LEVEL	Sensor for coolant level defect.
221	SD P DIFF LUBE OIL	Sensor for differential pressure of lube oil defect.
222	SL LVL LKG FUEL	Sensor for leakage level of fuel defect.
223	SD LVL INTERCLR	Sensor for coolant level of intercooler defect.
227	SD PRE FILT P LUBE OIL	Pressure sensor for lube oil before filter defect.
229	AL SD CAM STOP	Sensor of Camshaft defect and sensor of crankshaft defect before.
230	SD CRANKSHFT SPD	Sensor defect on crankshaft.
231	SD CAMSHAFT SPD	Sensor defect on camshaft.
232	SD CHARGER1 SPEED	Speed-sensor of basic charger defect.
233	SD CHARGER2 SPEED	Speed-sensor of switching charger defect.
240	SD P FUEL	Fuel pressure-sensor defect.
241	SD T UMBLASSEN	Temperature-sensor of recirculated charge air defect.
242	SD T COOLANT R	Redundant coolant temperature-sensor defect.
244	SD P LUBE OIL R	Redundant pressure sensor for lube oil defect.
245	SD POWER SUPPLY	Internal ECU error.
246	SD T ELECTRONIC	Internal ECU fault.
249	SD CAN STOP	Missing data CAN.
250	SD CAN SPD DEMND	Missing data CAN.
251	SD CAN UP DOWN	Missing data CAN.
252	SD CAN NOTCH POS	Missing data CAN.
253	SD CAN OVERRIDE	Missing data CAN.
254	SD CAN TST OVRSP	Missing data CAN.
255	SD CAN ENGAGE SIG	Missing data CAN.
256	SD CAN CYL CUTOUT	Missing data CAN.
257	SD CAN LOCAL	Missing data CAN.
258	SD CAN RCS ENGAGE	Missing data CAN.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
259	SD CAN RCS CYL CT	Missing data CAN.
260	SD 15V POS SPPLY	Internal ECU fault.
261	15V POS SPPLY	Internal ECU fault.
262	SD 5V BUFFR TEST	Internal ECU fault.
263	SD TE BUFFR TEST	Internal ECU fault.
264	SD BANK 1 TEST	Internal ECU fault.
265	SD BANK 2 TEST	Internal ECU fault.
266	SD SPD DEMAND AN	Analog speed demand defect.
267	SD SPDMTEST BNCH	Short circuit, cable breakage.
268	SD SPINUT	Analog spinning value defect.
269	SD LOAD ANLG FLT	Filtered analog load pulse signal not available.
270	SD FREQUENCY INPUT	Frequency input defect.
271	SD T EXTERN 1	Missing data CAN.
272	SD T EXTERN 2	Missing data CAN.
273	SD P EXTERN 1	Missing data CAN.
274	SD P EXTERN 2	Missing data CAN.
275	SD EXT CLNT LVL	Missing data CAN.
276	SD INTERCLER LVL	Missing data CAN.
277	SD BIN EXT3	Missing data CAN.
278	SD BIN EXT4	Missing data CAN.
279	SD CANRES TRIPFL	Missing data CAN.
280	SD CAN ALRM RST	Missing data CAN.
281	SD ADTEST1 SPPLY	Internal ECU fault.
282	SD ADTEST 2 SPPLY	Internal ECU fault.
283	SD ADTEST3 SPPLY	Internal ECU fault.
284	SD CAN LAMP TEST	Missing data CAN.
285	SD CAN IDLE RQ SR	Missing data CAN.
286	SD CAN IDLE REQ	Missing data CAN.
287	SD CAN IDLE REQ	Missing data CAN.
288	SD CAN TRBOSW LCK	Missing data CAN.
301	TIMING CYLNDR A1	Error in timing of injector cylinder A1: timing value too low/high.
302	TIMING CYLNDR A2	Error in timing of injector cylinder A2: timing value too low/high.
303	TIMING CYLNDR A3	Error in timing of injector cylinder A3: timing value too low/high.
304	TIMING CYLNDR A4	Error in timing of injector cylinder A4: timing value too low/high.
305	TIMING CYLNDR A5	Error in timing of injector cylinder A5: timing value too low/high.
306	TIMING CYLNDR A6	Error in timing of injector cylinder A6: timing value too low/high.
307	TIMING CYLNDR A7	Error in timing of injector cylinder A7: timing value too low/high.
308	TIMING CYLNDR A8	Error in timing of injector cylinder A8: timing value too low/high.
309	TIMING CYLNDR A9	Error in timing of injector cylinder A9: timing value too low/high.
310	TIMING CYLNDR A10	Error in timing of injector cylinder A10: timing value too low/high.
311	TIMING CYLNDR B1	Error in timing of injector cylinder B1: timing value too low/high.
312	TIMING CYLNDR B2	Error in timing of injector cylinder B2: timing value too low/high.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
313	TIMING CYLNDR B3	Error in timing of injector cylinder B3: timing value too low/high.
314	TIMING CYLNDR B4	Error in timing of injector cylinder B4: timing value too low/high.
315	TIMING CYLNDR B5	Error in timing of injector cylinder B5: timing value too low/high.
316	TIMING CYLNDR B6	Error in timing of injector cylinder B6: timing value too low/high.
317	TIMING CYLNDR B7	Error in timing of injector cylinder B7: timing value too low/high.
318	TIMING CYLNDR B8	Error in timing of injector cylinder B8: timing value too low/high.
319	TIMING CYLNDR B9	Error in timing of injector cylinder B9: timing value too low/high.
320	TIMING CYLNDR B10	Error in timing of injector cylinder B10: timing value too low/high.
321	WIRING CYLNDR A1	Short circuit in injector cable of cylinder A1.
322	WIRING CYLNDR A2	Short circuit in injector cable of cylinder A2.
323	WIRING CYLNDR A3	Short circuit in injector cable of cylinder A3.
324	WIRING CYLNDR A4	Short circuit in injector cable of cylinder A4.
325	WIRING CYLNDR A5	Short circuit in injector cable of cylinder A5.
326	WIRING CYLNDR A6	Short circuit in injector cable of cylinder A6.
327	WIRING CYLNDR A7	Short circuit in injector cable of cylinder A7.
328	WIRING CYLNDR A8	Short circuit in injector cable of cylinder A8.
329	WIRING CYLNDR A9	Short circuit in injector cable of cylinder A9.
330	WIRING CYLNDR A10	Short circuit in injector cable of cylinder A10.
331	WIRING CYLNDR B1	Short circuit in injector cable of cylinder B1.
332	WIRING CYLNDR B2	Short circuit in injector cable of cylinder B2.
333	WIRING CYLNDR B3	Short circuit in injector cable of cylinder B3.
334	WIRING CYLNDR B4	Short circuit in injector cable of cylinder B4.
335	WIRING CYLNDR B5	Short circuit in injector cable of cylinder B5.
336	WIRING CYLNDR B6	Short circuit in injector cable of cylinder B6.
337	WIRING CYLNDR B7	Short circuit in injector cable of cylinder B7.
338	WIRING CYLNDR B8	Short circuit in injector cable of cylinder B8.
339	WIRING CYLNDR B9	Short circuit in injector cable of cylinder B9.
340	WIRING CYLNDR B10	Short circuit in injector cable of cylinder B10.
341	OPN LD CYLNDR A1	Open load in injector cable of cylinder A1.
342	OPN LD CYLNDR A2	Open load in injector cable of cylinder A2.
343	OPN LD CYLNDR A3	Open load in injector cable of cylinder A3.
344	OPN LD CYLNDR A4	Open load in injector cable of cylinder A4.
345	OPN LD CYLNDR A5	Open load in injector cable of cylinder A5.
346	OPN LD CYLNDR A6	Open load in injector cable of cylinder A6.
347	OPN LD CYLNDR A7	Open load in injector cable of cylinder A7.
348	OPN LD CYLNDR A8	Open load in injector cable of cylinder A8.
349	OPN LD CYLNDR A9	Open load in injector cable of cylinder A9.
350	OPN LD CYLNDR A10	Open load in injector cable of cylinder A10.
351	OPN LD CYLNDR B1	Open load in injector cable of cylinder B1.
352	OPN LD CYLNDR B2	Open load in injector cable of cylinder B2.
353	OPN LD CYLNDR B3	Open load in injector cable of cylinder B3.
354	OPN LD CYLNDR B4	Open load in injector cable of cylinder B4.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
355	OPN LD CYLNDR B5	Open load in injector cable of cylinder B5.
356	OPN LD CYLNDR B6	Open load in injector cable of cylinder B6.
357	OPN LD CYLNDR B7	Open load in injector cable of cylinder B7.
358	OPN LD CYLNDR B8	Open load in injector cable of cylinder B8.
359	OPN LD CYLNDR B9	Open load in injector cable of cylinder B9.
360	OPN LD CYLNDR B10	Open load in injector cable of cylinder B10.
361	AL POWER STAGE LOW	Internal error of electronic.
362	AL POWER STAGE HIGH	Internal error of electronic.
363	AL STOP POWER STAGE	Internal error of electronic.
364	AL STOP POWER STAGE 2	Internal error of electronic.
365	AL MV WIRING GND	Cable line error.
371	AL WIRING TO 1	Short circuit or open load on transistor output 1 (TO 1).
372	AL WIRING TO 2	Short circuit or open load on transistor output 2 (TO 2).
373	AL WIRING TO 3	Short circuit or open load on transistor output 3 (TO 3).
374	AL WIRING TO 4	Short circuit or open load on transistor output 4 (TO 4).
381	AL WIRING TOP 1	Short circuit or open load on transistor output plant 1 (TOP 1).
382	AL WIRING TOP 2	Short circuit or open load on transistor output plant 2 (TOP 2).
383	AL WIRING TOP 3	Short circuit or open load on transistor output plant 3 (TOP 3).
384	AL WIRING TOP 4	Short circuit or open load on transistor output plant 4 (TOP 4).
385	AL WIRING TOP 5	Short circuit or open load on transistor output plant 5 (TOP 5).
386	AL WIRING TOP 6	Short circuit or open load on transistor output plant 6 (TOP 6).
390	AL MCR EXCEEDED	DBR/MCR Function: MCR (Maximum Continuous Rating) in exceeded.
392	HI T COOLNT R	Redundant coolant temperature too high (limit 1).
393	SS T COOLNT R	Redundant coolant temperature too high (limit 2).
394	LO P LUBE OIL R	Redundant pressure of lube oil too low (limit 1).
395	SS P LUBE OIL R	Redundant pressure of lube oil too low (limit 2).
396	TD T COOLANT	Maximum deviation of T-Coolant sensors.
397	TD P LUBE OIL	Maximum deviation of P-Oil sensors.
399	AL INTERFACE ECU	Interface ECU.
400	AL OPN LD DIGIN 1	Open load on digital input 1.
401	AL OPN LD DIGIN 2	Open load on digital input 2.
402	AL OPN LD DIGIN 3	Open load on digital input 3.
403	AL OPN LD DIGIN 4	Open load on digital input 4.
404	AL OPN LD DIGIN 5	Open load on digital input 5.
405	AL OPN LD DIGIN 6	Open load on digital input 6.
406	AL OPN LD DIGIN 7	Open load on digital input 7.
407	AL OPN LD DIGIN 8	Open load on digital input 8.
408	AL OPN LD E STOP	Open load on input for emergency stop.
410	LO U PDU	Power driver voltage (injectors) too low (limit 1).
411	LOLO U PDU	Power driver voltage (injectors) too low (limit 2).
412	HI U PDU	Power driver voltage (injectors) too high (limit 1).

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
413	HIHI U PDU	Power driver voltage (injectors) too high (limit 2).
414	HI L WATER FUEL PREFILT	Water level of fuel prefilter too high (limit 1).
415	LO P COOLANT INTRCOOLR	Coolant pressure of intercooler too low (limit 1).
416	SS P COOLANT INTRCOOLR	Coolant pressure of intercooler too low (limit 2).
417	SD L WATER FUEL PREFILT	Water level-sensor of fuel pre-filter defect.
420	AL L1 AUX 1	Input of Aux 1 injured limit 1.
421	AL L2 AUX 1	Input of Aux 1 injured limit 2.
428	AL L1 T AUX 1	Temperature input of Aux 1 injured limit 1.
438	LO P FUEL RAIL 2 STR	Low pressure on fuel rail 2.
439	HI P FUEL RAIL 2 STR	Hi pressure on fuel rail 2.
440	AL L1 P AUX 1	Pressure input of Aux 1 injured limit 1.
441	AL RAIL 2 LEAKAGE STR	Alarm fuel rail 2 leak detected.
442	AL L2 P AUX 1	Pressure input of Aux 1 injured limit 2.
444	SD U PDU	Sensor defect of Injector Power driver unit.
445	SD P AMBIENT AIR	Ambient air pressure-sensor defect.
448	HI P CHARGE AIR	Pressure of charge air too high (limit 1).
449	SS P CHARGE AIR	Pressure of charge air too high (limit 2).
450	SD IDLE END TRQ IN	Input of Idle/End-Torque defect
454	SS PWR RED ACT	Power Reduction is activated.
455	AL L1 AUX1 PLANT	Input of Aux 1 (plant) injured limit 1.
456	AL L2 AUX1 PLANT	Input of Aux 1 (plant) injured limit 2.
461	LO T EXHAUST EMU	Exhaust gas temperature of EMU too low (limit 1).
462	HI T COOLANT EMU	Coolant temperature of EMU injured limit 1.
463	SD AUX 2	Sensor defect on Aux 2.
464	SD P AUX 1	Analog input for pressure Aux 1 defect.
467	AL L2 T AUX 1	Temperature input of Aux 1 injured limit 2.
468	SD T AUX 1	Analog input for Temperature Aux 1 defect.
469	SD AUX 1	Analog input for Aux 1 defect.
470	SD T ECU	ECU temperature-sensor defect.
471	SD COIL CURRENT	Coil Current sensor defect.
472	AL STOP SD	Engine stop, because critical channel has sensor defect.
473	AL WIRING PWM CM2	Open load or short circuit on channel PWM_CM2.
474	AL WIRING FREQ OUT	Open load or short circuit on frequency output (FO) channel.
475	AL CR TRIG ENG ST	Released in case of an engine stop in order to trigger the crash recorder.
476	AL CRASH REC ERR	Initial error of crash recorder.
478	AL COMB ALM YEL	Combined Alarm YELLOW (Plant).
479	AL COMB ALM RED	Combined Alarm RED (Plant).
480	AL EXT ENG PROT	External Engine Protection function active.
500	AL WIRING POM STARTER 1	A wiring fault has been detected in the connection of starter 1 of POM.
501	AL WIRING POM STARTER 2	A wiring fault has been detected in the connection of starter 2 of POM.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
502	AL OPEN LD POM ALTRNATR	An open load on POM's alternator output has been detected.
503	AL BATT NOT CHARGING	Battery is not being charged by alternator.
504	AL CAN POM NODE LOST	POM is missing on CAN bus.
505	AL NEW POM FOUND	New POM found.
506	AL LOW STARTER VOLTS	Battery voltage is too low for starting.
507	AL POM ERROR	A general POM error has been detected.
508	AL WRONG POM ID	POM sends a different identification number (ID) than expected.
509	AL CHECK POM FUSE	Check POM fuse.
510	AL OVERRIDE APPLIED	Override applied.
515	STARTER NOT ENGAGED	Starter of POM could not be engaged.
543	MULTIPLE FDH SLAVES	There is more than one device which is configured as Backup for FDH-Functionality.
544	CONFIGURATION CHANGED	Gets active in case of changing system configuration e.g. by changing ECU- or SAM-Device. Remains until undo procedure or data is transferred by a valid maintenance case. Is cancelled automatically.
549	AL PWR CUTOFF STR	This is the alarm from the function Emergency Stop Counter. ECU power was disconnected while the engine was still running. This could lead to a possible overpressure in the high pressure system which might damage the engine.
555	AL CALL FIELD SERVICE	Gets active in case of completing a maintenance-case which manipulates Engine-Parameters. Remains also after switching on-off ECU until a valid release code is entered via Display- and Button-Control of SAM-Device. Release Code is available via Internet by a special procedure.
576	AL ESCM OVERRIDE STR	Exceeding of the corrected current MCR - odr DBR/MCR value.
594	AL L1 PRV 1 DEFECT STR	Yellow alarm pressure relief valve first rail.
595	AL L2 PRV 1 DEFECT STR	Red alarm pressure relief valve first rail.
598	AL L1 PRV 2 DEFECT STR	Yellow alarm pressure relief valve second rail.
599	AL L2 PRV 2 DEFECT STR	Red alarm pressure relief valve second rail.
610	AL WIRING SUCK RESTRCT 1 STR	Open load or short circuit on PWM HP fuel control block channel.
611	AL WIRING SUCK RESTRCT 2 STR	Open load or short circuit on PWM HP fuel control block channel 2.
612	AL WIRING PRESS CTRL VLV 1 STR	Open load or short circuit on PWM pressure regulating valve channel.
613	AL WIRING PRESS CTRL VLV 2 STR	Open load or short circuit on PWM pressure regulating valve channel 2.
615	AL EIL PROTECTION STR	Alarm for Protection Module in response to faulty or manipulated EIL.
692	AL ECU PWR OFF ON REQ STR	ECU configuration changed, switch power off/on.
696	AL SMARTCONCT USB ERR STR	Alarm configuration parameter.
697	AL SMARTCONCT RS485 ERR STR	Alarm configuration parameter.
698	AL SD STOP BUTTON STR	Channel signals open load or internal error.
700	AL SD START BUTTON STR	Channel signals open load.

<b>Fault Code Number</b>	<b>String</b>	<b>Description</b>
701	AL SD UP BUTTON STR	Channel signals open load.
702	AL SD DN BUTTON STR	Channel signals open load or internal error.
703	AL SD EXT SPEED DMD SW STR	Channel signals open load.
704	AL SD SPEED DMD INCREASE STR	Channel signals open load or internal error.
705	AL SD BINARY SPD DMD LMT STR	Channel signals open load or internal error.
706	AL SD DROOP 2 SWITCH STR	Channel signals open load or internal error.
707	AL SD FREQUENCY SWITCH STR	Channel signals open load or internal error.
709	AL SD OVERRIDE BUTTON STR	Channel signals open load or internal error.
710	AL SD ALARM RESET STR	Channel signals open load or internal error.
711	AL SD CYLINDER CUTOFF STR	Channel signals open load or internal error.
712	AL SD RQST BIN OUT TST STR	Channel signals open load or internal error.
713	AL SD EXT ENGINE PROTECTN STR	Channel signals open load or internal error.
714	AL SD PRELUBE SIGNAL STR	Channel signals open load.
715	AL SD EXT INC IDLE BIN STR	Channel signals open load.
716	AL SD EXT INC IDLE BIN BRK STR	Channel signals open load.
717	AL SD RQST PLANT DBR STR	Channel signals open load.

# Exhaust Treatment

## ***Diesel Particulate Filter (DPF)***

---

In order to meet Tier 4 emission requirements, some engine manufacturers are applying Diesel Particulate Filters (DPF) to the exhaust system of the engine. A Diesel Particulate Filter traps particulate matter contained in diesel exhaust and prevents it from distributing into the air. The particulate matter is later burned off during a regeneration process.

The DGC-2020ES communicates DPF control and status information to and from the engine ECU via J1939 communications in the form of various Parameter Group Numbers (PGN) and Suspect Parameter Numbers (SPN). These are summarized in the following paragraphs.

### **Regeneration**

Regeneration is accomplished by operating the engine at elevated exhaust temperatures where the accumulated particulate is burned off. If, in normal operation, the engine can be loaded to a high enough level to achieve the elevated exhaust temperature, then regeneration can occur as a part of normal operation. This is known as *passive regeneration*.

High exhaust temperatures can also be accomplished by methods such as providing dampers in the exhaust stream or heating the exhaust through the burning of fuel. This is known as *active regeneration* since it is outside of normal engine operation.

Heavily loaded engines will seldom require active regeneration. A lightly loaded engine will likely undergo active regeneration when regeneration is required.

### **DPF Control**

DPF control information is sent from the DGC-2020ES to the Engine ECU through PGN Number 57244 (0xE000). A manual regeneration request is sent using SPN 3695, Diesel Particulate Filter Regeneration Force Switch. Regeneration can be inhibited by SPN 3695, Diesel Particulate Filter Regeneration Inhibit Switch.

#### Manual Regeneration

The operator can force a regeneration cycle by turning on the Manual Regeneration setting found on the front panel under Settings→Communication→CANbus Setup→ECU Setup→DPF Regenerate Setup. The parameter will remain on for a few seconds then go off. The ECU will respond to the momentary setting by logging the request to force a manual regeneration. A continuous request is not used because this can be problematic for some engine ECUs.

Manual regeneration can also be initiated by clicking the *Manual Regeneration* button on the ECU Setup screen in BESTCOMSPlus®. BESTlogic™ Plus programmable logic can also be used to initiate manual regeneration by setting the DPF Manual Regeneration (DPFMANREGEN) logic element true.

#### Regeneration Inhibit

The operator can inhibit regeneration by turning on the DPF Regeneration Disable setting found on the ECU Setup screen in BESTCOMSPlus.

Regeneration can also be disabled by turning on the Disable Regeneration setting on the ECU Setup screen in BESTCOMSPlus.

BESTlogicPlus programmable logic can also be used to inhibit regeneration by setting the DPF Regeneration Inhibit (DPFREGENINHIBIT) logic element true.


## DPF Status and Pre-Alarms

The DGC-2020ES receives DPF status information which is broadcast from the engine ECU in various Parameter Group Numbers (PGN) and Suspect Parameter Numbers (SPN). The DGC-2020ES displays this information on the front panel, and in BESTCOMS*Plus*, via DPF related pre-alarms. The J1939 parameters and the resulting DGC-2020ES pre-alarms are summarized in the following paragraphs.

- PGN 64892 (0xFD7C) Diesel Particulate Filter Control 1


- *SPN 3697, Diesel Particulate Filter Lamp Command*

DPF REGEN REQUIRED Pre-Alarm: When SPN 3697 has a value of 1 or 4 indicating the DPF lamp is on, the DGC-2020ES will annunciate a pre-alarm with text of DPF REGEN REQUIRED. The DPF symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel.



- *SPN 3698, Exhaust System High Temperature Lamp Command*

HIGH EXHAUST TEMP Pre-Alarm: When SPN 3698 has a value of 1 indicating the high exhaust temperature lamp is on, the DGC-2020ES will annunciate a pre-alarm with text of HIGH EXHAUST TEMP. The high exhaust temperature symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel.



- *SPN 3703 Diesel Particulate Filter Active Regeneration Inhibited Due to Inhibit Switch*

DPF REGEN INHIBITED Pre-Alarm: When SPN 3703 has a value of 1 indicating the DPF Regeneration is inhibited due to the inhibit switch being set, the DGC-2020ES will annunciate a pre-alarm with text of DPF REGEN INHBTD. The DPF regeneration inhibited symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel.




- DPF Soot Level Annunciation via Diagnostic Trouble Code (DTC) SPN 3719 Diesel Particulate Filter Soot Load Percent

In addition to the standard diagnostic trouble code annunciation, the DGC-2020ES will annunciate a pre-alarm under circumstances described below.

- *FMI = 15: Data Valid But Above Normal Operating Range Least Severe Level*

DPF SOOT LEVEL HIGH Pre-Alarm: When the FMI is equal to 15, the DGC-2020ES will annunciate a pre-alarm with text of DPF SOOT LVL HI. The DPF symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel.



- *FMI = 16: Data Valid But Above Normal Operating Range Moderately Severe Level*

DPF SOOT LEVEL MODERATELY HIGH Pre-Alarm: When the FMI is equal to 16, the DGC-2020ES will annunciate a pre-alarm with text of DPF SOOT LVL MOD HI. The DPF warning symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel.



- *FMI = 0: Data Valid But Above Normal Operating Range Most Severe Level*

DPF SOOT LEVEL EXTREMELY HIGH Pre-Alarm: When the FMI is equal to 0, the DGC-2020ES will annunciate a pre-alarm with text of DPF SOOT LVL EXT HI. The DPF stop symbol, shown to the right, will accompany the text when the pre-alarm appears on the DGC-2020ES front panel. If the DPF soot level reaches the most severe level, the engine ECU may shut the engine down and prevent it from running or it may allow it to run, but at a reduced



power level. The DGC-2020ES only indicates a pre-alarm. It does not prevent the engine from running or cause operation at a reduced power level, but the operator should be aware that the engine ECU or after treatment system may cause such behavior.

## ***Exhaust After-Treatment Systems (EATS)***

In order to meet Tier 4 emission requirements, some engine manufacturers are adding Exhaust After Treatment Systems (EATS) which treat the engine exhaust within the exhaust system to reduce particulate matter and harmful contaminants prior to releasing the exhaust into the atmosphere. One such system uses urea-based Diesel Exhaust Fluid (DEF) catalyst which is combined with the exhaust gasses in the EATS to bring the emissions to acceptable levels.

The DGC-2020ES meters EATS information from the engine ECU via J1939 CANbus and displays the DEF level within the DEF tank(s), and also displays several pre-alarms related to the EATS system. Any DEF related pre-alarms annunciated on the front panel displays the symbol used for DEF functions which is shown to the right.



Most systems will contain one DEF tank, while some may contain two tanks. The DGC-2020ES front panel displays the level of DEF in each tank under Metering→Alarms-Status→J1939 Status→DEF Tank1 LVL% and Metering→Alarms-Status→J1939 Status→DEF Tank2 LVL%. The tank 1 level is sent from the ECU via SPN 1761 in J1939 PGN 65110 - After Treatment 1 Reagent Tank 1 Information. The tank 2 level is sent from the ECU via SPN 4367 in J1939 PGN 64829 - After Treatment 1 Reagent Tank 2 Information. The tank levels are expressed in units of percent.

### **Pre-Alarms**

The ECU sends DEF level diagnostics to the DGC as SPNs 5245 and 5246 in PGN 65110 (the AT1TI PGN). SPN 5245 communicated DEF level diagnostics, whereas SPN 5246 communicates DEF inducement level status.

There are several pre-alarms related to the EATS which annunciate DEF level diagnostics and DEF inducement level status. They are always enabled and will annunciate when received from the engine ECU. Each of them contains the symbol for DEF functions when annunciated on the front panel; however it will not be displayed in BESTCOMSP<sup>Plus</sup>. The pre-alarms are summarized in the following paragraphs.

- DEF FLUID LOW: This pre-alarm displays when SPN 5245 has a value of 1, indicating that the DEF tank level is low. A DEF level of 8% to 23% causes this annunciation.
- DEF FLUID EMPTY: This pre-alarm displays when SPN 5245 has a value of 4, indicating that the DEF tank level is low. The low condition is announced when the tank level is below 8%. When this occurs and is not remedied, the engine ECU may enter a mode of inducement not to operate the engine where some of the conditions in the pre-alarms descriptions below may occur.
- DEF ENGINE DERATE: This pre-alarm displays when SPN 5246 has a value of 3, indicating the Engine Derate level of inducement. This indicates that the engine is going into a reduced power mode indicating the lowest level of inducement not to operate the engine when the EATS is not functioning properly or out of DEF.
- DEF PRESEVERE INDUCEMENT: This pre-alarm displays when SPN 5246 has a value of 4, indicating the Pre-Severe Inducement level of inducement. This indicates that the engine has entered the second highest level of inducement not to operate the engine when the EATS is not functioning properly or the DEF level is low. The ECU will allow the engine to run for a maximum of 3 hours in this condition. After expiration of the 3 hours, the engine will enter the severe inducement state and cannot be restarted until the DEF level is raised above 14%.
- DEF SEVERE INDUCEMENT: This pre-alarm displays when SPN 5246 has a value of 5, indicating the Severe Inducement level of inducement. This indicates that the engine has entered the highest level of inducement not to operate the engine when the EATS is not functioning properly or DEF level is low. The ECU will allow the engine to run for a maximum of 3 hours in this condition. After expiration of the 3 hours, the engine will enter the severe inducement state and cannot be restarted until the DEF level is raised above 14%.

- **DEF INDUCEMENT OVERRIDE:** This pre-alarm displays when SPN 5246 has a value of 6, indicating the Temporary Override of inducement. This indicates DEF inducement is temporarily overridden. The engine may operate with reduced power, or for a limited time, after which time it may re-enter the SEVERE INDUCEMENT state.

#### **Exit Conditions for DEF Severe Inducement**

- **First Restart:** Return to 0% torque reduction in exit condition, until proper DEF level and quality evaluation. If low level or poor DEF quality is detected during the next monitoring cycle, the severe inducement will be active after the next restart. After the second restart, a service tool is required to exit the severe inducement.
- **With Service Tool Clearing:** Invoke 0% torque reduction with service tool clearing until proper DEF level and quality evaluation. If low level or poor DEF quality is detected during the next monitoring cycle, the severe inducement will be active after the next restart.

# Diagnostic Trouble Codes

Diagnostic engine information is obtained from a compatible engine control unit (ECU). The DGC-2020ES will receive an unsolicited message of a currently active diagnostic trouble code (DTC). Previously active DTCs are available upon request. Active and previously active DTCs can be cleared on request. Table 35 lists the diagnostic information that the DGC-2020ES obtains over the CAN interface.

**Table 35. Diagnostic Information Obtained Over the CAN Interface**

Parameter	Transmission Repetition Rate
Active diagnostic trouble code	1 s
Lamp status	1 s
Previously active diagnostic trouble code	On request
Request to clear active DTCs	On request
Request to clear previously active DTCs	On request

DTCs are reported in coded diagnostic information that includes the Suspect Parameter Number (SPN), Failure Mode Identifier (FMI), and Occurrence Count (OC). All parameters have an SPN and are used to display or identify the items for which diagnostics are being reported. The FMI defines the type of failure detected in the subsystem identified by an SPN. The reported problem may not be an electrical failure but a subsystem condition needing to be reported to an operator or technician. The OC contains the number of times that a fault has gone from active to previously active.

For certain DTCs, if the DGC-2020ES recognizes a pair of SPN and FMI numbers, it displays a single string as listed in Table 36. If the DGC-2020ES recognizes an SPN in Table 36, but the FMI does not match the FMI in Table 36, then it displays the string from Table 36 corresponding to the table entry where the FMI is # and a second string corresponding to the FMI number listed in Table 37. For example, if the DGC-2020ES receives SPN 29 and FMI 13, it displays ACCEL PEDAL 2 POSITN and OUT OF CALIBRATION. If the DGC-2020ES does not have descriptive information about an SPN and FMI that was received, the description will display as "NO TEXT AVAILABLE".

**Table 36. DTCs Displayed by the DGC-2020ES**

SPN	FMI	String Displayed	Description
28	3	Throttle Volt HI	Throttle Voltage High
28	4	Throttle Volt LO	Throttle Voltage Low
28	14	Throttle Volt OOR	Throttle Input Voltage Out of Range
29	3	Throttle Volt HI	Throttle Voltage High
29	4	Throttle Volt LO	Throttle Voltage Low
29	14	Throttle Volt OOR	Throttle Input Voltage Out of Range
29	#	ACCEL PEDAL 2 POSITN	Caption string for accelerator pedal 2 position
52	15	INTERCOOLER TEMP HI	Engine Intercooler Temperature is above the HIGH threshold
91	3	Thr Pos Sns Volt HI	Throttle Position Sensor Input Voltage (High)
91	4	Thr Pos Sns Volt LO	Throttle Position Sensor Input Voltage (Low)
91	14	Thr Pos Sns Volt OOR	Throttle Voltage (Out of Range)
94	1	FUEL DELIV PRS LO LO	Engine Fuel Delivery Pressure is below the LOW LOW threshold
94	3	Fuel Pmp Prs Volt HI	Fuel Pump Pressure Input Voltage (High)
94	4	Fuel Pmp Prs Volt LO	Fuel Pump Pressure Input Voltage (Low)
94	17	Fuel Pressure LO	Fuel Supply Pressure (Low Least Severe)
97	3	Water In FI Volt HI	Water In Fuel Signal Voltage High

SPN	FMI	String Displayed	Description
97	4	Water In FI Volt LO	Water In Fuel Signal Voltage Low
97	16	Water in Fuel	Water In Fuel Detected
98	#	ENG OIL LEVEL	Caption used on front panel for Display of J1939 Parameter
99	#	OIL FILTER DIFF PRESS	Caption string for oil filter differential pressure parameter
100	1	ENG OIL PRESS LO LO	Engine Oil Pressure is below the LOW LOW threshold
100	3	Oil Prs Snr Volt HI	Oil Pressure Sensor Input Voltage (High)
100	4	Oil Prs Snr Volt LO	Oil Pressure Sensor Input Voltage (Low)
100	17	ENG OIL PRESS LO	Engine Oil Pressure is below the LOW threshold
100	18	Oil Prs Snr Volt MLO	Oil Pressure Sensor Input Voltage (Moderately Low)
100	31	Oil Pressure INVLD	Oil Pressure (Invalid)
101	#	CRANKCASE PRESSURE	Caption string for crankcase pressure
102	2	Manifld Air Prs INVD	Manifold Air Pressure Invalid
102	3	Mnflld AirP Snsvlt HI	Manifold Air Pressure Sensor Input Voltage High
102	4	Mnflld AirP Snsvlt LO	Manifold Air Pressure Sensor Input Voltage Low
103	0	Trbo Overspd Severe	Turbo Overspeed (Most Severe)
103	2	Trbo Speed MisMatch	Turbo Speed (Mismatch)
103	5	Trbo Spd Sns Curr LO	Turbo Speed Sensor Current (Low)
103	6	Trbo Spd Sns Curr HI	Turbo Speed Sensor Current (High)
103	8	Trbo Speed INVLD	Turbo Speed (Invalid)
103	31	Trbo Speed MISSING	Turbo Speed (Missing)
105	0	EGR Mixed Air Tmp HI	Exhaust Gas Recirculation Mixed Air High (Least Severe)
105	3	EGR Air Temp Vlt HI	Exhaust Gas Recirculation Mixed Air Temp Voltage (High)
105	4	EGR Air Temp Vlt LO	Exhaust Gas Recirculation Mixed Air Temp Voltage (Low)
105	15	EGR Mixed Air Tmp HI	Exhaust Gas Recirculation Mixed Air High (Least Severe)
105	16	EGR MxdAir Tmp MHI	Exhaust Gas Recirculation Mixed Air Temp (Moderately High)
107	0	Air Filt Restricted	Air Filter Restriction (High)
108	2	Barometric Prs INVLD	Barometric Pressure (Invalid)
108	31	Barometric Prs ERR	Barometric Pressure (Error)
109	1	ENG COOLNT PRS LO LO	Engine Coolant Pressure is below the LOW LOW threshold
109	17	ENG COOLANT PRS LO	Engine Coolant Pressure is below the LOW threshold
110	0	ENG COOLNT TMP HI HI	Engine Coolant Temperature is above the HIGH HIGH threshold
110	3	Cool Tmp Sns Volt HI	Coolant Temp Sensor Input Voltage (High)
110	4	Cool Tmp Sns Volt LO	Coolant Temp Sensor Input Voltage (Low)
110	15	ENG COOLANT TEMP HI	Engine Coolant Temperature is above the HIGH threshold
110	16	Cool Temp MHI	Coolant Temp Sensor Input (Moderately High)
110	17	Cool Temp LO	Coolant Temp Sensor Input (Low Least Severe)
111	1	Coolnt Lvl LO	Coolant Level (Low)
111	17	ENG COOLANT LVL LO	Engine Coolant Level is below the LOW threshold
111	#	LOW COOL LEVEL	Low Coolant Level string used in event log and/or Alarm and Prealarm annunciation
157	3	Fuel Rail Prs Vlt HI	Fuel Rail Pressure Input Voltage (High)
157	4	Fuel Rail Prs Vlt LO	Fuel Rail Pressure Input Voltage (Low)
157	10	Fuel Rail Prs LOSS	Fuel Rail Pressure Loss Detected

SPN	FMI	String Displayed	Description
157	17	Fuel RI Prs NOT DEV	Fuel Rail Pressure Not Developed
158	0	KSW BATT VOLTS HI HI	Key Switch Battery Potential is above the HIGH HIGH threshold
158	1	KSW BATT VOLTS LO LO	Key Switch Battery Potential is below the LOW LOW threshold
158	15	KSW BATT VOLTS HI	Key Switch Battery Potential is above the HIGH threshold
158	17	KSW BATT VOLTS LO	Key Switch Battery Potential is below the LOW threshold
168	#	LOW BATT VOLT	Low Battery Voltage string used in event log and/or Alarm and Prealarm annunciation
174	0	Fuel Temp EXT HI	Fuel Temp (Extremely High)
174	3	Fuel Tmp Sns Volt HI	Fuel Temp Sensor Input Voltage (High)
174	4	Fuel Tmp Sns Volt LO	Fuel Temp Sensor Input Voltage (Low)
174	16	Fuel Temp MHI	Fuel Temp (Moderately High)
175	#	ENG OIL TEMP	Caption used on front panel for Display of J1939 Parameter
188	17	SPEED AT IDLE LO	Metering string for ECU trouble code metering indicates Engine Idle speed is below the LOW threshold
189	0	Engine Spd DERATE	Engine Speed Derate
190	0	Engine OvrSpd EXTRM	Engine Overspeed (Extreme)
190	1	ENGINE SPEED LOW	Engine speed is below the LOW threshold
190	16	Engine OvrSpd MODRT	Engine Overspeed (Moderate)
190	17	SPEED AT IDLE LO	Engine Idle speed is below the LOW threshold
190	#	ENGINE SPEED	Caption used on front panel for Display of J1939 Parameter
237	2	VIN Data MisMatch	VIN Data Mismatch with other controllers
412	0	EGR Temp EXT HI	Exhaust Gas Recirculation Temp (Extremely High)
412	3	EGR Temp In Vlt HI	Exhaust Gas Recirculation Temp Input Voltage (High)
412	4	EGR Temp In Vlt LO	Exhaust Gas Recirculation Temp Input Voltage (Low)
412	16	EGR Temp MHI	Exhaust Gas Recirculation Temp (Moderately High)
520	#	RETARDER % TORQUE	Caption string for retarder % torque
563	#	ABS ACTIVE	Caption String for Antilock Brake System (ABS) active
611	3	Inj Short to PWR	Injector Wiring Shorted to Power
611	4	Inj Short to GND	Injector Wiring Shorted to Ground
624	#	DIAGNOSTIC LAMP	Caption String for Diagnostic Lamp
627	1	Inj Spply Vlt Problm	Injector Supply Voltage Problem
627	16	ECU Power Volt HI	ECU Power High Voltage
627	18	ECU Power Volt LO	ECU Power Low Voltage
627	13	ECU ERROR	ECU Error
630	#	ECU INTERNAL ERROR	Caption string for ECU Internal Error
636	2	Pump Pos Sns Noisy	Pump Position Sensor Input Noise
636	5	Pump Pos Sns Curr LO	Pump Position Sensor Current (Low)
636	6	Pump Pos Sns Curr HI	Pump Position Sensor Current (High)
636	8	Pump Pos Sns In MSNG	Pump Position Sensor Input Missing
636	10	Pump Pos Sns In ERR	Pump Position Sensor Input Pattern Error
637	2	Crank Pos Sns Noisy	Crank Position Input Noise
637	5	Crank Pos Sns Curr LO	Crank Position Sensor Current (Low)
637	6	Crank Pos Sns Curr HI	Crank Position Sensor Current (High)

SPN	FMI	String Displayed	Description
637	7	Crnk/Pmp Pos Tmg OOS	Crank/Pump Position Timing Moderately Out of Sync
637	8	Crank Pos Sns MSNG	Crank Position Missing
637	10	Crank Pos Sns In ERR	Crank Position Input Pattern Error
639	#	J1939 NETWORK 1	Caption String for J1939 Network number 1
641	4	Trbo Actuator ERR	Turbo Actuator Error
641	12	ECU/Trbo Comm ERR	ECU/Turbo Communication Error
641	13	TrboAct Lrnd Val ERR	Turbo Actuator Learned Value Error
641	16	Trbo Act Temp MHI	Turbo Actuator Temp (Moderately High)
651	2	Cyl 1 EUI PN INVLD	Cylinder #1 EUI Part Number (Invalid)
651	5	Cyl 1 EUI Ckt OPEN	Cylinder #1 EUI Circuit (Open)
651	6	Cyl 1 EUI Ckt SHORT	Cylinder #1 EUI Circuit (Shorted)
651	7	Cyl 1 EUI Ckt MECH FL	Cylinder #1 EUI Circuit (Mechanical Failure)
651	13	Cyl 1 EUI QR INVLD	Cylinder #1 EUI Circuit QR Code (Invalid)
651	#	CYLINDER 1 INJECTOR	Caption String for Cylinder 1 Injector
652	2	Cyl 2 EUI PN INVLD	Cylinder #2 EUI Part Number (Invalid)
652	5	Cyl 2 EUI Ckt OPEN	Cylinder #2 EUI Circuit (Open)
652	6	Cyl 2 EUI Ckt SHORT	Cylinder #2 EUI Circuit (Shorted)
652	7	Cyl 2 EUI Ckt MECH FL	Cylinder #2 EUI Circuit (Mechanical Failure)
652	13	Cyl 2 EUI QR INVLD	Cylinder #2 EUI Circuit QR Code (Invalid)
652	#	CYLINDER 2 INJECTOR	Caption String for Cylinder 2 Injector
653	2	Cyl 3 EUI PN INVLD	Cylinder #3 EUI Part Number (Invalid)
653	5	Cyl 3 EUI Ckt OPEN	Cylinder #3 EUI Circuit (Open)
653	6	Cyl 3 EUI Ckt SHORT	Cylinder #3 EUI Circuit (Shorted)
653	7	Cyl 3 EUI Ckt MECH FL	Cylinder #3 EUI Circuit (Mechanical Failure)
653	13	Cyl 3 EUI QR INVLD	Cylinder #3 EUI Circuit QR Code (Invalid)
653	#	CYLINDER 3 INJECTOR	Caption String for Cylinder 3 Injector
654	2	Cyl 4 EUI PN INVLD	Cylinder #4 EUI Part Number (Invalid)
654	5	Cyl 4 EUI Ckt OPEN	Cylinder #4 EUI Circuit (Open)
654	6	Cyl 4 EUI Ckt SHORT	Cylinder #4 EUI Circuit (Shorted)
654	7	Cyl 4 EUI Ckt MECH FL	Cylinder #4 EUI Circuit (Mechanical Failure)
654	13	Cyl 4 EUI QR INVLD	Cylinder #4 EUI Circuit QR Code (Invalid)
654	#	CYLINDER 4 INJECTOR	Caption String for Cylinder 4 Injector
655	2	Cyl 5 EUI PN INVLD	Cylinder #5 EUI Part Number (Invalid)
655	5	Cyl 5 EUI Ckt OPEN	Cylinder #5 EUI Circuit (Open)
655	6	Cyl 5 EUI Ckt SHORT	Cylinder #5 EUI Circuit (Shorted)
655	7	Cyl 5 EUI Ckt MECH FL	Cylinder #5 EUI Circuit (Mechanical Failure)
655	13	Cyl 5 EUI QR INVLD	Cylinder #5 EUI Circuit QR Code (Invalid)
655	#	CYLINDER 5 INJECTOR	Caption String for Cylinder 5 Injector
656	2	Cyl 6 EUI PN INVLD	Cylinder #6 EUI Part Number (Invalid)
656	5	Cyl 6 EUI Ckt OPEN	Cylinder #6 EUI Circuit (Open)
656	6	Cyl 6 EUI Ckt SHORT	Cylinder #6 EUI Circuit (Shorted)
656	7	Cyl 6 EUI Ckt MECH FL	Cylinder #6 EUI Circuit (Mechanical Failure)
656	13	Cyl 6 EUI QR INVLD	Cylinder #6 EUI Circuit QR Code (Invalid)

SPN	FMI	String Displayed	Description
656	#	CYLINDER 6 INJECTOR	Caption String for Cylinder 6 Injector
657	#	CYLINDER 7 INJECTOR	Caption String for Cylinder 7 Injector
658	#	CYLINDER 8 INJECTOR	Caption String for Cylinder 8 Injector
659	#	CYLINDER 9 INJECTOR	Caption String for Cylinder 9 Injector
660	#	CYLINDER 10 INJECTOR	Caption String for Cylinder 10 Injector
661	#	CYLINDER 11 INJECTOR	Caption String for Cylinder 11 Injector
662	#	CYLINDER 12 INJECTOR	Caption String for Cylinder 12 Injector
663	#	CYLINDER 13 INJECTOR	Caption String for Cylinder 13 Injector
664	#	CYLINDER 14 INJECTOR	Caption String for Cylinder 14 Injector
665	#	CYLINDER 15 INJECTOR	Caption String for Cylinder 15 Injector
666	#	CYLINDER 16 INJECTOR	Caption String for Cylinder 16 Injector
667	#	CYLINDER 17 INJECTOR	Caption String for Cylinder 17Injector
668	#	CYLINDER 18 INJECTOR	Caption String for Cylinder 18 Injector
669	#	CYLINDER 19 INJECTOR	Caption String for Cylinder 19 Injector
670	#	CYLINDER 20 INJECTOR	Caption String for Cylinder 20 Injector
671	#	CYLINDER 21 INJECTOR	Caption String for Cylinder 21 Injector
672	#	CYLINDER 22 INJECTOR	Caption String for Cylinder 22 Injector
673	#	CYLINDER 23 INJECTOR	Caption String for Cylinder 23 Injector
674	#	CYLINDER 24 INJECTOR	Caption String for Cylinder 24 Injector
676	#	ENG GLOW PLUG RELAY	Caption String for Engine Glow Plug Relay
677	#	ENGINE START RELAY	Caption String for Engine Start Relay
701	#	AUX I/O 1	Caption String for Auxiliary I/O 1
702	#	AUX I/O 2	Caption String for Auxiliary I/O 2
703	#	AUX I/O 3	Caption String for Auxiliary I/O 3
704	#	AUX I/O 4	Caption String for Auxiliary I/O 4
705	#	AUX I/O 5	Caption String for Auxiliary I/O 5
706	#	AUX I/O 6	Caption String for Auxiliary I/O 6
707	#	AUX I/O 7	Caption String for Auxiliary I/O 7
708	#	AUX I/O 8	Caption String for Auxiliary I/O 8
709	#	AUX I/O 9	Caption String for Auxiliary I/O 9
710	#	AUX I/O 10	Caption String for Auxiliary I/O 10
711	#	AUX I/O 11	Caption String for Auxiliary I/O 11
712	#	AUX I/O 12	Caption String for Auxiliary I/O 12
713	#	AUX I/O 13	Caption String for Auxiliary I/O 13
714	#	AUX I/O 14	Caption String for Auxiliary I/O 14
715	#	AUX I/O 15	Caption String for Auxiliary I/O 15
716	#	AUX I/O 16	Caption String for Auxiliary I/O 16
898	2	REQ SPD DATA ERRATIC	Speed Demand Data is erratic
898	9	Spd/Trq Msg INVLD	Vehicle Speed/Torque Message Invalid
898	#	ENGINE REQSTED SPEED	Caption String for Engine Requested Speed
923	#	PWM OUTPUT	Caption String for Engine PWM Output
970	2	Aux Eng SD SW INVLD	Auxiliary Engine Shutdown Switch (Invalid)
970	31	Aux Eng SD SW ACTV	Auxiliary Engine Shutdown Switch Active

SPN	FMI	String Displayed	Description
971	31	Eng Derate SW ACTV	External Engine Derate Switch Active
975	#	FAN SPEED	Caption String for Engine Fan Speed
1072	#	ENG BRAKE OUTPUT 1	Caption String for Engine Brake Output 1
1074	#	ENG EXHAUST BRAKE OUT	Caption String for Engine Exhaust Brake Output
1075	5	Fuel TR Pump Curr LO	Fuel Transfer Pump Current (Low)
1075	6	Fuel TR Pump Curr HI	Fuel Transfer Pump Current (High)
1075	12	Fuel TR Pump ERR	Fuel Transfer Pump (Error)
1079	#	SENSOR SUPPLY VOLTS 1	Caption String for Sensor Supply Voltage 1
1080	3	Snsr Supp 1 Volt LO	Sensor Supply 1 Voltage (Low)
1080	4	Snsr Supp 1 Volt HI	Sensor Supply 1 Voltage (High)
1080	#	SENSOR SUPPLY VOLTS 2	Caption String for Sensor Supply Voltage 2
1081	#	ENG WAIT TO START LMP	Caption String for Engine Wait to Start Lamp
1109	31	Eng Shutdown WARNING	Engine Shutdown Warning
1109	#	EPS SHUTDN APPROACHG	Caption String for indication that Engine Protective System Shutdown Is Approaching
1110	31	Eng Prot Shutdown	Engine Protection Shutdown
1136	0	ECU Temp EXT HI	ECU Temperature (Extremely High)
1136	15	ENG ECU TEMP HI	ECU Temperature has exceeded the HIGH level
1136	16	ECU Temp MHI	ECU Temperature (Moderately High)
1172	3	Trbo Cmp Tmp Volt HI	Turbo Compressor Inlet Temp Input Voltage (High)
1172	4	Trbo Cmp Tmp Volt LO	Turbo Compressor Inlet Temp Input Voltage (Low)
1172	16	Trbo Cmp In Tmp MHI	Turbo Compressor Inlet Temp (Moderately High)
1180	0	Trbo Trbn Tmp EXT HI	Turbo Turbine Inlet Temp (Extremely High)
1180	16	Trbo Trbn In Tmp MHI	Turbo Turbine Inlet Temp (Moderately High)
1231	#	J1939 NETWORK 2	Caption String for J1939 Network number 2
1235	#	J1939 NETWORK 3	Caption String for J1939 Network number 3
1237	#	ENG SHUTDN ORIDE SW	Caption String for Engine Shutdown Override Switch
1322	#	MULTI CYL MISFIRE	Caption String for Misfire detected on multiple engine cylinders
1323	#	MISFIRE CYLINDER 1	Caption String for Misfire detected on a single engine cylinder
1324	#	MISFIRE CYLINDER 2	Caption String for Misfire detected on a single engine cylinder
1325	#	MISFIRE CYLINDER 3	Caption String for Misfire detected on a single engine cylinder
1326	#	MISFIRE CYLINDER 4	Caption String for Misfire detected on a single engine cylinder
1327	#	MISFIRE CYLINDER 5	Caption String for Misfire detected on a single engine cylinder
1328	#	MISFIRE CYLINDER 6	Caption String for Misfire detected on a single engine cylinder
1329	#	MISFIRE CYLINDER 7	Caption String for Misfire detected on a single engine cylinder
1330	#	MISFIRE CYLINDER 8	Caption String for Misfire detected on a single engine cylinder
1331	#	MISFIRE CYLINDER 9	Caption String for Misfire detected on a single engine cylinder
1332	#	MISFIRE CYLINDER 10	Caption String for Misfire detected on a single engine cylinder
1333	#	MISFIRE CYLINDER 11	Caption String for Misfire detected on a single engine cylinder
1334	#	MISFIRE CYLINDER 12	Caption String for Misfire detected on a single engine cylinder
1335	#	MISFIRE CYLINDER 13	Caption String for Misfire detected on a single engine cylinder
1336	#	MISFIRE CYLINDER 14	Caption String for Misfire detected on a single engine cylinder
1337	#	MISFIRE CYLINDER 15	Caption String for Misfire detected on a single engine cylinder

SPN	FMI	String Displayed	Description
1338	#	MISFIRE CYLINDER 16	Caption String for Misfire detected on a single engine cylinder
1339	#	MISFIRE CYLINDER 17	Caption String for Misfire detected on a single engine cylinder
1340	#	MISFIRE CYLINDER 18	Caption String for Misfire detected on a single engine cylinder
1341	#	MISFIRE CYLINDER 19	Caption String for Misfire detected on a single engine cylinder
1342	#	MISFIRE CYLINDER 20	Caption String for Misfire detected on a single engine cylinder
1343	#	MISFIRE CYLINDER 21	Caption String for Misfire detected on a single engine cylinder
1344	#	MISFIRE CYLINDER 22	Caption String for Misfire detected on a single engine cylinder
1345	#	MISFIRE CYLINDER 23	Caption String for Misfire detected on a single engine cylinder
1346	#	MISFIRE CYLINDER 24	Caption String for Misfire detected on a single engine cylinder
1347	3	Pump Ctrl Vlv Curr HI	Pump Control Valve Current (High)
1347	5	Pmp Ctrl Vlv C MSMCH	Pump Control Valve Current (Mismatch)
1347	7	Fuel RI Prs Ctrl ERR	Fuel Rail Pressure Control (Error)
1569	31	Fuel Derate	Fuel Derate
1638	#	HYDRAULIC TEMP	Caption String for Hydraulic Temperature
1639	1	Fan Speed Zero	Fan Speed Detected (Zero)
1639	16	Fan Speed HI	Fan Speed Detected (High)
1639	18	Fan Speed LO	Fan Speed Detected (Low)
2000	13	Security Violation	Security Violation
2005	9	TSC CAN Msg NT RCV	TSC CAN Message Not Received
2030	9	AC Clutch Msg NT RCV	A/C Clutch Status CAN Message Not Received
2071	9	Tr Oil Can Msg NT RCV	Trans. Oil, Tier Size, Vehicle Speed CAN Message Not Received
2629	0	TRBO 1 OUT TMP HI HI	Turbocharger 1 outlet pressure is above the HIGH HIGH threshold
2629	15	TURBO 1 OUT TMP HI	Turbocharger 1 outlet pressure is above the HIGH threshold
2630	0	EGR FrAir Tmp EXT HI	Exhaust Gas Recirculation Fresh Air Temp (Extremely High)
2630	3	EGR FrAir Tmp Vlt HI	Exhaust Gas Recirculation Fresh Air Temp Input Voltage (High)
2630	4	EGR FrAir Tmp Vlt LO	Exhaust Gas Recirculation Fresh Air Temp Input Voltage (Low)
2630	15	EGR FrAir Tmp HI	Exhaust Gas Recirculation Fresh Air Temp (High Least Severe)
2630	16	EGR FrAir Tmp MHI	Exhaust Gas Recirculation Fresh Air Temp (Moderately High)
2634	#	POWER RELAY	Caption String for main Power Relay
2659	2	EGR Flo/Tmp MISMATCH	Exhaust Gas Recirculation Flow/Temp Mismatch
2659	15	EGR Flo Rt High	Exhaust Gas Recirculation Flow Rate (High Least Severe)
2659	17	EGR Flo Rt LO	Exhaust Gas Recirculation Flow Rate (Low Least Severe)
2790	16	Trbo Cmp Out Tmp HI	Turbo Compressor Outlet Temp (Moderately High)
2791	2	EGR Vlv Pos Invlid	Exhaust Gas Recirculation Valve Position Invalid
2791	3	EGRVlv Pos In Vlt HI	Exhaust Gas Recirculation Valve Position Input Voltage (High)
2791	4	EGRVlv Pos In Vlt LO	Exhaust Gas Recirculation Valve Position Input Voltage (Low)
2791	13	EGR Vlv Control ERR	Exhaust Gas Recirculation Valve Control Error
2791	31	EGR Valve Cal ERR	Exhaust Gas Recirculation Valve Calibration Error
2791	#	EGR VALVE CONTROL	Caption String for EGR Valve Control
2795	7	Trbo Act Pos MSMATCH	Turbo Actuator Position Mismatch

SPN	FMI	String Displayed	Description
3719	0	DPF SOOT LVL EXT HI	String for Diagnostic Trouble Code Indicating Diesel Particulate Filter Soot Level High - Most Severe Level
3719	15	DPF SOOT LVL HI	String for Diagnostic Trouble Code Indicating Diesel Particulate Filter Soot Level High - Least Severe Level
3719	16	DPF SOOT LVL MOD HI	String for Diagnostic Trouble Code Indicating Diesel Particulate Filter Soot Level High - Moderately Severe Level
520837	1	STARTER SPEED LO LO	Starter Speed is below the LOW LOW threshold
520838	1	RUN UP SPEED LO LO	Run Up Speed is below the LOW LOW threshold
522192	12	MTU ENGINE BAD	Component failure of the MTU engine control ECU
523212	#	ENGPRT CAN MSG	Caption String for CAN Message
523216	#	PREHTENCMD CAN MSG	Caption String for CAN Message
523218	#	RxCCVS CAN MSG	Caption String for CAN Message
523222	#	TC01 CAN MSG	Caption String for CAN Message
523238	#	SWTOUT CAN MSG	Caption String for CAN Message
523239	#	DECV1 CAN MSG	Caption String for CAN Message
523240	#	FUNMODCTL CAN MSG	Caption String for CAN Message
523350	#	CYL BANK 1 INJECTORS	Caption String for Cylinder Bank 1 Injectors
523351	#	CYL BANK 1 INJECTORS	Caption String for Cylinder Bank 1 Injectors
523352	#	CYL BANK 2 INJECTORS	Caption String for Cylinder Bank 2 Injectors
523353	#	CYL BANK 2 INJECTORS	Caption String for Cylinder Bank 2 Injectors
523354	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523355	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523370	#	RAIL PRESSURE	Caption String for Rail Pressure
523420	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523450	#	MULTI STATE SWITCH 1	Caption String for Multi State Switch 1
523451	#	MULTI STATE SWITCH 2	Caption String for Multi State Switch 2
523452	#	MULTI STATE SWITCH 3	Caption String for Multi State Switch 3
523470	#	RAIL PRESSURE LMT VLV	Caption String for Rail Pressure Limit Valve
523490	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523500	#	CAN MSG TIMEOUT	Caption String indicating Can Message Timeout has occurred
523550	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523561	#	INJECTN PERIOD CYL 1	Caption String for Single Cylinder Injection Period
523562	#	INJECTN PERIOD CYL 2	Caption String for Single Cylinder Injection Period
523563	#	INJECTN PERIOD CYL 3	Caption String for Single Cylinder Injection Period
523564	#	INJECTN PERIOD CYL 4	Caption String for Single Cylinder Injection Period
523565	#	INJECTN PERIOD CYL 5	Caption String for Single Cylinder Injection Period
523566	#	INJECTN PERIOD CYL 6	Caption String for Single Cylinder Injection Period
523567	#	INJECTN PERIOD CYL 7	Caption String for Single Cylinder Injection Period
523568	#	INJECTN PERIOD CYL 8	Caption String for Single Cylinder Injection Period
523600	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523601	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523602	#	FAN SPEED	Caption String for Engine Fan Speed
523604	#	RXENGTMP CAN MSG	Caption String for CAN Message
523605	#	TSC1-AE MSG MISSING	Caption String for CAN Message

SPN	FMI	String Displayed	Description
523606	#	TSC1-AR MSG MISSING	Caption String for CAN Message
523607	#	TSC1-DE MSG MISSING	Caption String for CAN Message
523608	#	TSC1-DR MSG MISSING	Caption String for CAN Message
523609	#	TSC1-PE MSG MISSING	Caption String for CAN Message
523610	#	TSC1-VE MSG MISSING	Caption String for CAN Message
523611	#	TSC1-VR MSG MISSING	Caption String for CAN Message
523612	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error
523613	#	RAIL PRESSURE	Caption String for Rail Pressure
523615	#	METERING UNIT VALVE	Caption String for Metering Unit Valve
523617	#	ECU ERROR	String for Diagnostic Trouble Code Indicating ECU Error

**Table 37. DTCs Displayed by the DGC-2020ES (FMI Strings)**

FMI	String Displayed	Description
0	DATA HI MOST SEVERE	Data is higher than expected at the most severe level
1	DATA LO MOST SEVERE	Data is lower than expected at the most severe level
2	DATA ERRATIC OR BAD	Data is erratic, intermittent, or incorrect
3	VOLTS HI OR SHORTED	Measured voltage is higher than expected or shorted to a high source
4	VOLTS LO OR SHORTED	Measured voltage is lower than expected or shorted to a low source
5	CURRENT LO OR OPEN	Measured current is lower than expected or the circuit is open
6	CURRENT HI OR SHORTED	Measured current is higher than expected or shorted
7	MECHANICAL SYSTM ERR	Mechanical system error
8	FREQ OR PWM ERROR	Error in frequency, pulse width or period of any frequency or PWM signal is outside its predetermined limits
9	ABNORMAL UPDATE RATE	Update rate of parameter is abnormal
10	DATA RT OF CHG ERR	Rate of change of data is abnormal
11	FAILURE CAUSE UNKNOWN	String indicating failure cause is unknown
12	BAD INTELLIGNT DEVICE	Engine ECU is reporting that an intelligent device or component failure has been detected
13	OUT OF CALIBRATION	Device or parameter is out of calibration
14	CONSULT ENG MFG DATA	User should consult engine manufacturer's data
15	DATA HI LST SEVERE	Data is higher than expected at the least severe level
16	DATA HI MODERATE SVR	Data is higher than expected at a moderately severe level
17	DATA LO LST SEVERE	Data is lower than expected at the least severe level
18	DATA LO MODERATE SVR	Data is lower than expected at a moderately severe level
19	NETWORK DATA ERR	String Indicating Network Data contained an error indication



# Revision History

Table 38 provides a historical summary of the changes made to the DGC-2020ES hardware. Firmware changes are listed in Table 39 and software changes are listed in Table 40. The corresponding revisions made to this instruction manual are summarized in Table 41. Revisions are listed in chronological order.

**Table 38. Hardware Revision History**

Hardware Version and Date	Change
A, 03/13	<ul style="list-style-type: none"> <li>Initial release</li> </ul>

**Table 39. Firmware Revision History**


Firmware Version and Date	Change
1.00.00, 03/13	<ul style="list-style-type: none"> <li>Initial release</li> </ul>

**Table 40. Software Revision History**

Software Version and Date	Change
3.03.00, 03/13	<ul style="list-style-type: none"> <li>Initial Release</li> </ul>

**Table 41. Instruction Manual Revision History**

Manual Revision and Date	Change
A, 03/13	<ul style="list-style-type: none"> <li>Initial release</li> </ul>
B, 02/14	<ul style="list-style-type: none"> <li>Expanded description of RDP alarm annunciation</li> <li>Added BESTlogic<i>Plus</i> status input blocks GENBREAKERSTATUS and MAINSBREAKERSTATUS.</li> <li>Removed product registration information</li> <li>Moved <i>Revision History</i> to back of manual</li> <li>Minor text edits</li> </ul>





 **Basler Electric**  
**www.basler.com**

12570 State Route 143  
Highland IL 62249-1074 USA  
Tel: +1 618.654.2341  
Fax: +1 618.654.2351  
email: [info@basler.com](mailto:info@basler.com)

P.A.E. Les Pins  
67319 Wasselonne Cedex  
FRANCE  
Tel: +33 3.88.87.1010  
Fax: +33 3.88.87.0808  
email: [franceinfo@basler.com](mailto:franceinfo@basler.com)

No. 59 Heshun Road Loufeng District (N)  
Suzhou Industrial Park  
215122 Suzhou  
P.R. CHINA  
Tel: +86 512.8227.2888  
Fax: +86 512.8227.2887  
email: [chinainfo@basler.com](mailto:chinainfo@basler.com)

111 North Bridge Road  
15-06 Peninsula Plaza  
Singapore 179098  
Tel: +65 68.44.6445  
Fax: +65 68.44.8902  
email: [singaporeinfo@basler.com](mailto:singaporeinfo@basler.com)