

Operator Manual

Generator Set

QSJ2.4 Engine with PowerCommand® 1.1 Control

C20 N6 (Spec A), C22 N6 (Spec A)

C25 N6 (Spec A), C30 N6 (Spec A)

C36 N6 (Spec A), C40 N6 (Spec A)

C30 N6H (Spec A), C36 N6H (Spec A)

C40 N6H (Spec A), C45 N6H (Spec A)

C50 N6H (Spec A), C60 N6H (Spec A)

CALIFORNIA Proposition 65

Warning: Natural Gas/Liquid Propane Gas engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Table of Contents

| 1. | IMPORTANT SAFETY INSTRUCTIONS | 1 |
|----|---|----|
| | 1.1 Warning, Caution, and Note Styles Used in This Manual | 1 |
| | 1.2 General Information | |
| | 1.3 Generator Set Safety Code | 4 |
| | 1.4 Moving Parts Can Cause Severe Personal Injury or Death | 4 |
| | 1.5 Electrical Shocks and Arc Flashes Can Cause Severe Personal Injury or Death | |
| | 1.6 Fuel and Fumes Are Flammable | |
| | 1.7 Batteries Can Explode | 6 |
| | 1.8 Exhaust Gases Are Deadly | 7 |
| | 1.9 The Hazards of Carbon Monoxide | 9 |
| | 1.10 Earth Ground Connection | |
| 2. | INTRODUCTION | 11 |
| ۵. | 2.1 Safety | 11 |
| | 2.2 About This Manual | 11 |
| | 2.3 Schedule of Abbreviations | 12 |
| | 2.4 Related Literature | 14 |
| | 2.5 Model Specifications | 15 |
| | 2.6 After Sales Services | 20 |
| | 2.0 Titol Guido Gol vioco | |
| 3. | CONTROL SYSTEM | 25 |
| | 3.1 Control System Description | 25 |
| | 3.2 Display Text or Symbolic Version | 29 |
| | 3.3 Exercise Settings | 30 |
| | 3.4 Time Setup (1-Phase ATS) | 34 |
| | 3.5 Brightness and Contrast | 38 |
| | 3.6 History and About Menu | 40 |
| | 3.7 Fault Log | 42 |
| | 3.8 Operating Modes | 44 |
| | 3.9 Selecting Operating Modes | 44 |
| 4 | OPERATION | 51 |
| • | 4.1 Safety Considerations | 51 |
| | 4.2 Introduction | 52 |
| | 4.3 Maintenance | 52 |
| | 4.4 Operating Recommendations | 52 |
| | 4.5 Generator Set Operation | 54 |
| | · | |
| 5. | MAINTENANCE | 65 |
| | 5.1 Maintenance Safety | 65 |
| | 5.2 Periodic Maintenance | 68 |
| | 5.3 Engine Oil | 76 |
| | 5.4 Air Intake System | 81 |

| 5.5 Generator Set Output - AC Electric System Checks | |
|--|--|
| 5.6 DC Electrical System | |
| 5.7 Batteries | |
| 5.8 Spark Plugs | |
| 5.9 Cleaning the Generator Set Housing | |
| 5.10 Complete System Test | |
| 6. TROUBLESHOOTING | |
| 6.1 Avoiding Generator Set Shutdowns | |
| 6.2 Control System | |
| 6.3 Fault Finding | |
| 6.4 Fault/Status Codes - PowerCommand 1.1 | |

1 IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS. This manual contains important instructions that should be followed during installation and maintenance of the generator set and batteries.

Safe and efficient operation can be achieved only if the equipment is properly operated and maintained. Many accidents are caused by failure to follow fundamental rules and precautions.

1.1 Warning, Caution, and Note Styles Used in This Manual

The following safety styles and symbols found throughout this manual indicate potentially hazardous conditions to the operator, service personnel, or equipment.

▲ DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

⚠ WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

⚠ CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates information considered important, but not hazard-related (e.g., messages relating to property damage).

1.2 General Information

This manual should form part of the documentation package supplied by Cummins Inc. with specific generator sets. If this manual has been supplied in isolation, please contact your authorized dealer.

NOTICE

It is in the operator's interest to read and understand all warnings and cautions contained in the documentation relevant to the generator set operation and daily maintenance.

General Safety Precautions

⚠ WARNING

Hot Pressurized Liquid

Contact with hot liquid can cause severe burns.

Do not open the pressure cap while the engine is running. Let the engine cool down before removing the cap. Turn the cap slowly and do not open it fully until the pressure has been relieved.

⚠ WARNING

Moving Parts

Moving parts can cause severe personal injury.

Use extreme caution around moving parts. All guards must be properly fastened to prevent unintended contact.

⚠ WARNING

Toxic Hazard

Used engine oils have been identified by some state and federal agencies to cause cancer or reproductive toxicity.

Do not ingest, breathe the fumes, or contact used oil when checking or changing engine oil. Wear protective gloves and face guard.

⚠ WARNING

Electrical Generating Equipment

Incorrect operation and maintenance can result in severe personal injury or death.

Do not operate equipment when fatigued, or after consuming any alcohol or drug.

Make sure that only suitably trained and experienced service personnel perform electrical and/or mechanical service.

⚠ WARNING

Toxic Gases

Substances in exhaust gases have been identified by some state and federal agencies to cause cancer or reproductive toxicity.

Do not breathe in or come into contact with exhaust gases.

⚠ WARNING

High Noise Level

Generator sets in operation emit noise, which can cause hearing damage. Wear appropriate ear protection at all times.

⚠ WARNING

Hot Surfaces

Contact with hot surfaces can cause severe burns.

The unit is to be installed so that the risk of hot surface contact by people is minimized. Wear appropriate PPE when working on hot equipment and avoid contact with hot surfaces.

⚠ WARNING

Toxic Hazard

Ethylene glycol, used as an engine coolant, is toxic to humans and animals. Wear appropriate PPE. Clean up coolant spills and dispose of used coolant in accordance with local environmental regulations.

⚠ WARNING

Combustible Liquid

Ignition of combustible liquids is a fire or explosion hazard which can cause severe burns or death.

Do not store fuel, cleaners, oil, etc., near the generator set. Do not use combustible liquids like ether.

⚠ WARNING

Combustible Gases

Generator sets in operation have combustible gases under pressure, which if ignited can cause eye and ear damage.

Wear appropriate eye and ear protection at all times.

↑ WARNING

Combustible Gases

Generator sets in operation have combustible gases under pressure, which if ignited can cause severe injury.

Do not operate the generator set with any doors open.

⚠ WARNING

Fire Hazard

Materials drawn into the generator set, as well as accumulated grease and oil, are a fire hazard. Fire can cause severe burns or death.

Keep the generator set and the surrounding area clean and free from obstructions. Make sure the generator set is mounted in a manner to prevent combustible materials from accumulating under the unit.

⚠ WARNING

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death.

Isolate all auxiliary supplies and use an insulated wrench to disconnect the starting battery cables (negative [–] first).

NOTICE

Keep multi-type ABC fire extinguishers close by. Class A fires involve ordinary combustible materials such as wood and cloth. Class B fires involve combustible and flammable liquid fuels and gaseous fuels. Class C fires involve live electrical equipment. (Refer to NFPA No. 10 in the applicable region.)

NOTICE

Before performing maintenance and service procedures on enclosed generator sets, make sure the service access doors are secured open.

NOTICE

Stepping on the generator set can cause parts to bend or break, leading to electrical shorts, or to fuel, coolant, or exhaust leaks. Do not step on the generator set when entering or leaving the generator set room.

1.3 Generator Set Safety Code

Before operating the generator set, read the manuals and become familiar with them and the equipment. Safe and efficient operation can be achieved only if the equipment is properly operated and maintained. Many accidents are caused by failure to follow fundamental rules and precautions.

Electrical Generating Equipment

Incorrect operation and maintenance can result in severe personal injury or death.

Read and follow all Safety Precautions, Warnings, and Cautions throughout this manual and the documentation supplied with the generator set.

1.4 Moving Parts Can Cause Severe Personal Injury or Death

Keep hands, clothing, and jewelry away from moving parts.

- Before starting work on the generator set, disconnect the battery charger from its AC source, then disconnect the starting batteries using an insulated wrench, negative (–) cable first. This will prevent accidental starting.
- Make sure that fasteners on the generator set are secure. Tighten supports and clamps; keep guards in position over fans, drive belts, etc.
- Do not wear loose clothing or jewelry in the vicinity of moving parts or while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts.
- If any adjustments must be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.

1.5 Electrical Shocks and Arc Flashes Can Cause Severe Personal Injury or Death

- Only qualified service personnel certified and authorized to work on power circuits should work on exposed energized power circuits.
- All relevant service material must be available for any electrical work performed by certified service personnel.
- Exposure to energized power circuits with potentials of 50 VAC or 75 VDC or higher poses a significant risk of electrical shock and electrical arc flash.
- Refer to standard NFPA 70E, or equivalent safety standards in corresponding regions, for details of the dangers involved and for safety requirements.

1.6 Fuel and Fumes Are Flammable

Fire, explosion, and personal injury or death can result from improper practices.

- Do not fill fuel tanks while the engine is running unless the tanks are outside the engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- Do not permit any flame, cigarette, pilot light, spark, arcing equipment, or other ignition source near the generator set or fuel tank.
- Fuel lines must be adequately secured and free of leaks. Fuel connection at the engine should be made with an approved flexible line. Do not use copper piping on flexible lines as copper will become brittle if continuously vibrated or repeatedly bent.
- Make sure all fuel supplies have a positive shutoff valve.
- Make sure the battery area has been well-ventilated prior to servicing near it.
 Lead-acid batteries emit a highly explosive hydrogen gas that can be ignited by arcing, sparking, smoking, etc.

Do Not Operate in Flammable and Explosive Environments

Flammable vapor can cause an engine to over speed and become difficult to stop, resulting in possible fire, explosion, severe personal injury, and death. Do not operate a generator set where a flammable vapor environment can be created, unless the generator set is equipped with an automatic safety device to block the air intake and stop the engine. The owners and operators of the generator set are solely responsible for operating the generator set safely. Contact your authorized Cummins distributor for more information.

Spillage

Any spillage that occurs during fueling, oil top-off, or oil change must be cleaned up before starting the generator set.

Fluid Containment

NOTICE

Where spillage containment is not part of a Cummins supply, it is the responsibility of the installer to provide the necessary containment to prevent contamination of the environment, especially water courses and sources.

If fluid containment is incorporated into the bedframe, it must be inspected at regular intervals. Any liquid present should be drained out and disposed of in line with local health and safety regulations. Failure to perform this action may result in spillage of liquids which could contaminate the surrounding area.

Any other fluid containment area must also be checked and emptied, as described above.

1.7 Batteries Can Explode

Batteries can explode, causing severe skin and eye burns and can release toxic electrolytes.

⚠ WARNING

Combustible Gases

Batteries can explode, causing severe skin and eye burns, and can release toxic electrolytes.

Do not dispose of the battery in a fire, because it is capable of exploding. Do not open or mutilate the battery. Do not charge frozen batteries.

MARNING

Electric Shock Hazard

Batteries present the risk of high short circuit current.

When servicing the generator set:

- · Remove watches, rings, or other metal objects.
- Use tools with insulated handles.

NOTICE

Servicing of batteries must be performed or supervised by personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries.

- · Wear safety glasses.
- · Do not smoke.
- Do not charge frozen batteries.
- To prevent arcing when disconnecting the battery:
 - 1. Press the Off switch from the display and then press the E-Stop button.
 - 2. Disconnect AC power from any battery chargers.
 - 3. Remove the negative (-) battery cable to prevent starting.
- To prevent arcing when reconnecting the battery:
 - 1. Reconnect the positive (+) cable.
 - 2. Reconnect the negative (-) cable.
 - 3. Reconnect the battery charger to AC power supply.
- When replacing the generator set battery, always replace it with a battery as specified in this manual.

1.8 Exhaust Gases Are Deadly

- Provide an adequate exhaust system to properly expel discharged gases away
 from enclosed or sheltered areas, and areas where individuals are likely to
 congregate. Visually and audibly inspect the exhaust system daily for leaks per
 the maintenance schedule. Make sure that exhaust manifolds are secured and
 not warped. Do not use exhaust gases to heat a compartment.
- Make sure the unit is well ventilated.

Exhaust Precautions

⚠ WARNING

Hot Exhaust Gases

Contact with hot exhaust gases can cause severe burns.

Wear personal protective equipment when working on equipment.

⚠ WARNING

Hot Surfaces

Contact with hot surfaces can cause severe burns.

The unit is to be installed so that the risk of hot surface contact by people is minimized. Wear appropriate PPE when working on hot equipment and avoid contact with hot surfaces.

⚠ WARNING

Toxic Gases

Inhalation of exhaust gases can cause asphyxiation and death.

Pipe exhaust gas outside and away from windows, doors, or other inlets to buildings. Do not allow exhaust gas to accumulate in habitable areas.

⚠ WARNING

Fire Hazard

Contaminated insulation is a fire hazard. Fire can cause severe burns or death.

Remove any contaminated insulation and dispose of it in accordance with local regulations.

The exhaust outlet may be sited at the top or bottom of the generator set. Make sure that the exhaust outlet is not obstructed. Personnel using this equipment must be made aware of the exhaust position. Position the exhaust away from flammable materials - in the case of exhaust outlets at the bottom, make sure that vegetation is removed from the vicinity of the exhaust.

The exhaust pipes may have some insulating covers fitted. If these covers become contaminated they must be replaced before the generator set is run.

To minimize the risk of fire, make sure the following steps are observed:

- Make sure that the engine is allowed to cool thoroughly before performing maintenance or operation tasks.
- Clean the exhaust pipe thoroughly.

1.9 The Hazards of Carbon Monoxide

Carbon monoxide (CO) is an odorless, colorless, tasteless and non-irritating gas. You cannot see it or smell it. Red blood cells, however, have a greater affinity for CO than for oxygen. Therefore, exposure even to low levels of CO for a prolonged period can lead to asphyxiation (lack of oxygen) resulting in death. Mild effects of CO poisoning include eye irritation, dizziness, headaches, fatigue and the inability to think clearly. More extreme symptoms include vomiting, seizures and collapse.

Engine-driven generator sets produce harmful levels of carbon monoxide that can injure or kill you.

Special Risks of CO near the Home

↑ WARNING

Toxic Gases

Carbon monoxide (CO) gas can cause nausea, fainting, or death. Residents can be exposed to lethal levels of CO when the generator set is running. Depending on air temperature and wind, CO can accumulate in or near the home.

To protect yourself and others from the dangers of CO poisoning, it is recommended that reliable, approved, and operable CO detector alarms are installed in proper locations in the home as specified by their manufacturer.

Protecting Yourself from CO Poisoning

- Locate the generator set in an area where there are no windows, doors, or other access points into the home.
- Make sure all CO detectors are installed and working properly.
- Pay attention for signs of CO poisoning.
- Check the exhaust system for corrosion, obstruction, and leaks every time you start the generator set and every eight hours when you run it continuously.

1.10 Earth Ground Connection

The neutral of the generator set may be required to be bonded to earth ground at the generator set location, or at a remote location, depending on system design requirements. Consult the engineering drawings for the facility or a qualified electrical design engineer for proper installation.

NOTICE

The end user is responsible to make sure that the ground connection point surface area is clean and free of rust before making a connection.

NOTICE

The end user is responsible for making sure that an earthing arrangement that is compliant with local conditions is established and tested before the equipment is used.

2 Introduction

2.1 Safety

⚠ WARNING

Hazardous Voltage

Contact with high voltages can cause severe electrical shock, burns, or death.

Make sure that only a trained and experienced electrician makes generator set electrical output connections, in accordance with the installation instructions and all applicable codes.

⚠ WARNING

Electrical Generating Equipment

Faulty electrical generating equipment can cause severe personal injury or death.

Generator sets must be installed, certified, and operated by trained and experienced person in accordance with the installation instructions and all applicable codes.

2.2 About This Manual

The purpose of this manual is to provide the users with sound, general information. It is for guidance and assistance with recommendations for correct and safe procedures. Cummins Inc. cannot accept any liability whatsoever for problems arising as a result of following recommendations in this manual.

The information contained within the manual is based on information available at the time of going to print. In line with Cummins Inc. policy of continuous development and improvement, information may change at any time without notice. The users should therefore make sure that they have the latest information available before starting any work. The latest version of this manual is available on QuickServe Online (https://quickserve.cummins.com).

Users are respectfully advised that, in the interests of good practice and safety, it is their responsibility to employ competent people to carry out any installation work. Consult your authorized dealer for further installation information. It is essential that the utmost care is taken with the application, installation, and operation of any generator set due to their potentially hazardous nature. Careful reference should also be made to other Cummins Inc. literature. You must operate and maintain your generator set properly if you are to expect safe and reliable operation.

For further assistance, contact your authorized Cummins Inc. dealer.

NOTICE

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interferences.
- This device must accept any interference received, including interference that may cause undesired operation.

2.3 Schedule of Abbreviations

This list is not exhaustive. For example, it does not identify units of measure or acronyms that appear only in parameters, event/fault names, or part/accessory names.

| Abbr. | Description | Abbr. | Description |
|------------------------------------|---|--------------|------------------------------------|
| AC | Alternating Current | LED | Light-Emitting Diode |
| AMP | AMP, Inc. (part of Tyco I Electronics) | | Multifunction Monitor |
| ANSI | American National Standards Institute | Mil Std | Military Standard |
| ASOV | Automatic Shut Off Valve | MPU | Magnetic Pickup |
| ASTM | American Society for Testing and Materials (ASTM International) | NC | Normally Closed |
| ATS | Automatic Transfer Switch | NC | Not Connected |
| AVR | Automatic Voltage Regulator | NFPA | National Fire Protection Agency |
| AWG | American Wire Gauge | NO | Normally Open |
| CAN | Controlled Area Network | NWF | Network Failure |
| CB Circuit Breaker | | OEM | Original Equipment Manufacturer |
| CE | Conformité Européenne | OOR | Out Of Range |
| CCA Cold Cranking Ampere | | OORH/ ORH | Out Of Range High |
| CFM | Cubic Feet per Minute | OORL/ORL | Out Of Range Low |
| CGT Cummins Generator Technologies | | PB | Push Button |
| СММ | Cubic Meters per Minute | PCC | PowerCommand® Control |

3-2018 2. Introduction

| Abbr. | Description | Abbr. | Description |
|--------|--|-------|--------------------------------------|
| СТ | | | Power Generation Interface |
| DC | Direct Current | PGN | Parameter Group Number |
| DEF | Diesel Exhaust Fluid | PI | Proportional/Integral |
| DPF | Diesel Particulate Filter | PID | Proportional/Integral/ Derivative |
| EBS | Excitation Boost System | PLC | Programmable Logic Controller |
| ECM | Engine Control Module | PMG | Permanent Magnet Generator |
| ECS | Engine Control System | PPE | Personal Protective Equipment |
| EMI | Electromagnetic Interference | PT | Potential Transformer |
| EN | European Standard | PTC | Power Transfer Control |
| EPS | Engine Protection System | PWM | Pulse-Width Modulation |
| E-Stop | Emergency Stop | RFI | Radio Frequency Interference |
| FAE | Full Authority Electronic | RH | Relative Humidity |
| FMI | Failure Mode Identifier | RMS | Remote Monitoring System |
| FSO | Fuel Shutoff | RMS | Root Mean Square |
| Genset | Generator Set | RTU | Remote Terminal Unit |
| GCP | Generator Control Panel | SAE | Society of Automotive Engineers |
| GND | Ground | scfh | Standard Cubic Feet of gas per Hour |
| НМІ | Human-Machine Interface | SCR | Selective Catalytic Reduction |
| IC | Integrated Circuit | SPN | Suspect Parameter Number |
| ISO | International Organization for Standardization | SW_B+ | Switched B+ |
| LBNG | Lean-Burn Natural Gas | UL | Underwriters Laboratories |

| Abbr. | Description | Abbr. | Description |
|-------|----------------------------|-------|------------------------------|
| LCD | Liquid Crystal Display | UPS | Uninterruptible Power Supply |
| LCT | Low Coolant Temperature | | |

2.4 Related Literature

The literature provided with the generator set is as follows:

- Installation Manual (A045R241)
- Operator Manual (A045R242)

⚠ CAUTION

A generator set must be operated and maintained properly if you are to expect safe and reliable operation. The Operator Manual includes a maintenance schedule and a troubleshooting guide.

The Health and Safety Manual must be read in conjunction with this manual for the safe operation of the generator set:

- Health and Safety Manual (0908-0110)
- Warranty Statement (A040H442)
- Emissions Component Defect Warranty Statement (A028X278)

The relevant manuals appropriate to your generator set are also available. The documents below are in English:

- Service Manual (A045R243)
- Parts Manual (A046Z094)
- EControls, Inc. Service Manual (A035C596)
- Global Control Platform (GCP) Engine Display Interface Software (EDIS) Training Manual (A035C608)
- RA Series Transfer Switch Owner Manual (A046S594) (if applicable)
- PowerCommand® 1302 Controller Owner's Manual (900-0661)
- Standard Repair Times (SRT) Manual (A046Z674)
- Application Manual T-030 for application information (A040S369)
- Service Tool Manual (A043D529)

3-2018 2. Introduction

2.5 Model Specifications

TABLE 1. 2.4L MODEL VARIATIONS

| Models | Description |
|--|-----------------|
| C20 N6, C22 N6, C25 N6, C30 N6, C36 N6, C40 N6 | 60 Hz, 1800 RPM |
| C30 N6H, C36 N6H, C40 N6H, C45 N6H, C50 N6H, C60 N6H | 60 Hz, 3600 RPM |

TABLE 2. COLD WEATHER SPECIFICATIONS (ALL MODELS)

| Temperature | Description | Battery Type | Group |
|--|--|--------------|-------|
| Above 4 °C (40 °F) | No starting aids required. | Standard | 26 |
| -17 to 4 °C (0 to 40 °F) Additional coolant heater and battery charger recommended for starting. Factory options available. | | Standard | 26 |
| Below -17 °C (0 °F) | All starting aides (battery heater, coolant heater, battery charger) recommended. Factory options available. | Larger | 34 |

| NOTICE NOTICE |
|--|
| For NFPA 110 applications, a coolant heater is required. A factory option is |
| available. |

TABLE 3. FUEL SPECIFICATIONS 60 HZ, 1800 RPM

| | C20 N6 | C22 N6 | C25 N6 | C30 N6 | C36 N6 | C40 N6 |
|---|---|---------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Full Load (Propane) | 105.1 scfh 265,000 BTU/hr | 112.7 scfh 285,000 BTU/hr | 125.4 scfh 315,000 BTU/hr | 164.1 scfh 410,000 BTU/hr | 182.7 scfh 460,000 BTU/hr | 193.6 scfh 490,000 BTU/hr |
| Full Load (Natural Gas) 259.6 scfh 278.8 scfh 270,000 BTU/hr BTU/hr | | 309.5 scfh 320,000 BTU/hr | 380.9 scfh 395,000 BTU/hr | 472.3 scfh 490,000 BTU/hr | 519 scfh 540,000 BTU/hr | |
| Fuel Pressure | ure 6-13 inches of water column (1.5 - 3.2 kPa) under any condition | | | | | |

TABLE 4. FUEL SPECIFICATIONS 60 HZ, 3600 RPM

| | C30 N6H | C36 N6H | C40 N6H | C45 N6H | C50 N6H | C60 N6H |
|------------------------|--|---------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Full Load (Propane) | 195.5 scfh 490,000 BTU/hr | 219.6 scfh 550,000 BTU/hr | 236.2 scfh 595,000 BTU/hr | 256.9 scfh 645,000 BTU/hr | 289.5 scfh 725,000 BTU/hr | 324.6 scfh 820,000 BTU/hr |
| Full load | | | 573.2 scfh 595,000 BTU/hr | 623.0 scfh 645,000 BTU/hr | 704.7 scfh 730,000 BTU/hr | 814.2 scfh 840,000 BTU/hr |
| Fuel Pressure | sure 6-13 inches of water column (1.5 - 3.2 kPa) under any condition | | | | | |

TABLE 5. ENGINE SPECIFICATIONS (ALL MODELS)

| Specification | Value |
|-------------------------|--|
| Engine | 4 cylinder-in-line, SOHC, liquid-cooled, 4-stroke, spark ignited |
| Displacement | 2351 cc (144 in³) |
| Spark Plug Gap | 1.0 mm (0.040 in) (NA) 0.76 mm (0.030 in) (T/TAA) |
| Spark Plug Torque | 20 Nm (15 ft-lb) |
| Coolant | 50/50 coolant solution (50% pure water and 50% ethylene glycol) |
| High Crankcase Pressure | No higher than 1.5 kPa |
| Low Compression | 135 psi (dry test) or higher with less than 15 psi range between cylinders |
| Oil Capacity | 4.3 L (4.54 quarts) |
| Oil Recommendation | 5W30 API SM or newer |

TABLE 6. GENERATOR SET SIZE SPECIFICATIONS WITH SOUND LEVEL 1 ENCLOSURE (L X W X H)

| kW | RPM | mm | in | | |
|-------|------|-------------------|----------------|---------------------|------------|
| 20-25 | 1800 | | | 4000 004 4450 70 04 | 70 04 45 0 |
| 30 | 3600 | 1830 x 864 x 1152 | 72 x 34 x 45.2 | | |
| 30-40 | 1800 | 0004 004 4450 | 04 04 45 0 | | |
| 36-60 | 3600 | 2384 x 864 x 1152 | 94 x 34 x 45.2 | | |

3-2018 2. Introduction

TABLE 7. GENERATOR SET WEIGHT 60 HZ, 1800 RPM

| Sound Level 1 (Wet) | C20 N6 | C22 N6 | C25 N6 | C30 N6 | C36 N6 | C40 N6 |
|---------------------|--------|--------|--------|--------|--------|--------|
| kg | 503 | 503 | 520 | 580 | 615 | 646 |
| lb | 1109 | 1109 | 1147 | 1279 | 1356 | 1424 |

TABLE 8. GENERATOR SET WEIGHT 60 HZ, 3600 RPM

| Sound Level 1 (Wet) | C30 N6H | C36 N6H | C40 N6H | C45 N6H | C50 N6H | C60 N6H |
|---------------------|---------|---------|---------|---------|---------|---------|
| kg | 514 | 567 | 635 | 635 | 635 | 648 |
| lb | 1134 | 1249 | 1399 | 1399 | 1399 | 1429 |

TABLE 9. ALTERNATOR SPECIFICATIONS 60 HZ, 1800 RPM

| | C20 N6 | C22 N6 | C25 N6 | C30 N6 | C36 N6 | C40 N6 | |
|---------------------|---------|------------|--------------|----------------|-------------|--------|--|
| Alternator | | Brushless, | 4-pole rotat | ing field, sin | gle bearing | | |
| Power (kVa): | | | | | | | |
| 1-Phase | 20 | 22 | 25 | 30 | 36 | 40 | |
| 3-Phase | 25 | 27.5 | 31.3 | 37.5 | 45 | 50 | |
| Rated Voltages (V): | | | | | | | |
| 1-Phase | 120/240 | | | | | | |
| | 120/240 | | | | | | |
| 3 Phase | 120/208 | | | | | | |
| 3-Phase 277/480 | | | | | | | |
| | | 347/600 | | | | | |

TABLE 10. ALTERNATOR SPECIFICATIONS 60 HZ, 3600 RPM

| | C30 N6H | C36 N6H | C40 N6H | C45 N6H | C50 N6H | C60 N6H |
|---------------------|--|---------|---------|---------|---------|---------|
| Alternator | Brushless, 2-pole rotating field, single bearing | | | | | |
| Power (kVa): | | | | | | |
| 1-Phase | 30 | 36 | 40 | 45 | 50 | 60 |
| 3-Phase | 37.5 45 50 56.3 62.5 75 | | | | | |
| Rated Voltages (V): | | | | | | |
| 1-Phase | | 120/240 | | | | |

| | C30 N6H | C36 N6H | C40 N6H | C45 N6H | C50 N6H | C60 N6H |
|---------|---------|---------|---------|---------|---------|---------|
| | 120/240 | | | | | |
| 3-Phase | 120/208 | | | | | |
| | 277/480 | | | | | |

| | NOTICE | |
|-----------------------|--------|--|
| Maximum $I_2 = 8\%$. | | |

3-2018 2. Introduction

TABLE 11. GENERATOR SET DERATING GUIDELINES

| | | Engine Power Av | /ailable Up To | Der | ate At |
|---------|--------|-------------------|------------------------|--------------------|--|
| Model | Fuel | Elevation | Ambient Temperature | Elevation | Temperature |
| C20 N6 | NG, LP | 1005 m (3300 ft) | 40 °C (104 °F) | | 2% per 10 °C |
| C22 N6 | NG | 670.5 m (2200 ft) | 40 °C (104 °F) | | (18 °F) |
| C22 N6 | LP | 1005 m (3300 ft) | 40 °C (104 °F) | | above 40 °C |
| C25 N6 | NG | 0 m (0 ft) | 25 °C (77 °F) | | (104 °F) |
| C25 N6 | LP | 114 m (375 ft) | 25 °C (77 °F) | | 2% per 10 °C (18 °F) above 25 °C (77 °F) |
| C30 N6 | NG | 762 m (2500 ft) | 40 °C (104 °F) | | |
| C30 N6 | LP | 1005 m (3300 ft) | 40 °C (104 °F) | | |
| C36 N6 | NG, LP | 1005 m (3300 ft) | 40 °C (104 °F) | | |
| C40 N6 | NG, LP | 114 m (375 ft) | 40 °C (104 °F) | 4% per | 2% per 10 °C |
| C30 N6H | NG, LP | 945 m (3100 ft) | 40 °C (104 °F) | 305 m (1000 ft) | (18 °F) above 40 °C |
| C36 N6H | NG, LP | 1005 m (3300 ft) | 40 °C (104 °F) | (1000 11) | (104 °F) |
| C40 N6H | NG, LP | 1005 m (3300 ft) | 40 °C (104 °F) | | , , |
| C45 N6H | LP | 1005 m (3300 ft) | 40 °C (104 °F) | | |
| C45 N6H | NG, LP | 914 m (3000 ft) | 40 °C (104 °F) | | |
| C50 N6H | NG, LP | 114 m (375 ft) | 25 °C (77 °F) | | 2% per 10 °C (18 °F) above 25 °C (77 °F) |
| C60 N6H | NG, LP | 114 m (375 ft) | 40 °C (104 °F) | | 2% per 10 °C (18 °F) above 40 °C (104 °F) |

TABLE 12. CONTROL SPECIFICATION (ALL MODELS)

| | | | | | | 70 | | |
|---|---|---|----|---|----|----|---|---|
| S | n | Δ | CI | ш | ca | м | n | ľ |

Integrated microprocessor based engine, generator, transfer switch control

TABLE 13. DC SYSTEM SPECIFICATIONS (ALL MODELS)

| Specification | Value |
|----------------------------|--|
| Nominal Battery Voltage | 12 VDC |
| Battery Group | 26 standard, 34 high capacity (a high capacity battery requires an accessory battery tray) |
| Battery Type | Maintenance free |
| Minimum Cold Crank Amps | 545 standard, 850 high capacity (a high capacity battery requires an accessory battery tray) |

2.6 After Sales Services

Cummins offers a full range of maintenance and warranty services.

Maintenance

↑ WARNING

Electrical Generating Equipment

Incorrect service or parts replacement can result in severe personal injury, death, and/or equipment damage.

Make sure service personnel are qualified to perform electrical and mechanical service.

For expert generator set service at regular intervals, contact your Cummins Inc. service provider. See power.cummins.com/sales-service-locator for service locations that service this application. Maintenance tasks should only be undertaken by trained and experienced technicians provided by your Cummins Inc. service provider.

Warranty

For details of the warranty coverage for your generator set, refer to the *Warranty Statement* listed in the Related Literature section

Extended warranty coverage is also available. In the event of a breakdown, prompt assistance can normally be given by factory trained service technicians with facilities to undertake all minor and many major repairs to equipment on site.

For further warranty details, contact your authorized dealer.

NOTICE

Damage caused by failure to follow the manufacturer's recommendations will not be covered by the warranty. Please contact your authorized dealer.

3-2018 2. Introduction

Warranty Limitations

For details of the warranty limitations for your generator set, refer to the warranty statement applicable to the generator set.

How to Obtain Service

For parts, service, and product information, contact the nearest authorized Cummins Inc. dealer. To easily locate the nearest certified distributor/dealer for Cummins generator sets in your area, or for more information, contact us at 1-800-CUMMINS™ (1-800-286-6467) or visit www.cummins.com/support.

Generator Set Nameplate

⚠ WARNING

Electrical Generating Equipment

Improper service or replacement of parts can lead to severe personal injury or death and to damage to equipment and property.

Make sure service personnel are qualified to perform electrical and mechanical service.

NOTICE

Unauthorized modifications or replacement of fuel, exhaust, air intake or speed control system components that affect engine emissions are prohibited by law in the State of California.

Model, Spec, and Serial Numbers: Be ready to provide the model, spec, and serial numbers on the generator set nameplate when contacting Cummins Inc. for information, parts, and service. The nameplate is located on the inside of the customer access door on enclosed generator sets.

Record these numbers so that they are easy to find when needed. Each character in these numbers is significant for obtaining the right parts listed in the Parts Catalog. Genuine Cummins Inc. replacement parts are recommended for best results.

| My Generator Set Information | | | | |
|------------------------------|--|--|--|--|
| Model | | | | |
| Spec | | | | |
| Serial Number | | | | |

Manufacturing Facilities

| Facility | Address | Phone Numbers |
|--------------------|---|--|
| U.S. and CANADA | Cummins Inc. 1400 73rd Ave. NE Minneapolis, MN 55432 USA | Toll Free 1-800-CUMMINS™ (1-800-286-6467) Phone +1 763-574-5000 Fax +1 763-574-5298 |
| EMEA, CIS | Cummins Inc. Columbus Avenue Manston Park Manston, Ramsgate Kent CT12 5BF United Kingdom Cummins Inc. Royal Oak Way South Daventry Northamptonshire NN11 8NU United Kingdom | Phone +44 1843 255000 Fax +44 1843 255902 |
| ASIA PACIFIC | Cummins Inc. 10 Toh Guan Road #07-01 TT International Tradepark Singapore 608838 | Phone +65 6417 2388 Fax +65 6417 2399 |
| BRAZIL | Rua Jati, 310, Cumbica Guarulhos, SP 07180-900 Brazil | Phone +55 11 2186 4195 Fax +55 11 2186 4729 |
| CHINA | Cummins Inc. 2 Rongchang East Street, Beijing Economic – Technological Development Area Beijing 100176, P.R. China | Phone 86 10 59023001 Fax +86 10 5902 3199 |
| INDIA | Cummins Inc. Plot No B-2, SEZ Industrial Area, Village-Nandal & Surwadi, Taluka- Phaltan Dist- Satara, Maharashtra 415523 India | Phone +91 021 66305514 |
| LATIN AMERICA | 3350 Southwest 148th Ave. Suite 205 Miramar, FL 33027 USA | Phone +1 954 431 551 Fax +1 954 433 5797 |

3-2018 2. Introduction

| Facility | Address | Phone Numbers |
|----------|---------------------------------|------------------------|
| MEXICO | Eje 122 No. 200 Zona Industrial | Phone +52 444 870 6700 |
| | San Luis Potosi, S.L.P. 78395 | Fax +52 444 824 0082 |
| | Mexico | |

This page is intentionally blank.

3 Control System

3.1 Control System Description

The control system is used to start and stop the generator set, and provides full generator set monitoring capability and protection in a stand-alone situation (non-paralleling) from the display screen. It monitors the engine for temperature, as well as oil pressure and speed. It also provides voltage and current metering. In the event of a fault, the unit indicates the fault type and, on critical faults, automatically shuts down the generator set.

All indicators, control buttons, and the display screen are on the face of the operator panel, as illustrated in the figure below.

There are three fault level signals generated by the control system:

- Event: Signals that a temporary condition exists.
- **Warning:** Signals an imminent or non-critical fault for the engine. The control provides an indication only for this condition.
- **Shutdown:** Signals a potentially critical fault for the engine. The control immediately takes the engine off-load and automatically shuts it down.

The standard control system operates on 12 VDC (or 24 VDC if applicable) battery power. History data is stored in non-volatile memory and is not deleted if battery power is lost.

Standard Operator Panel

The operator panel includes indicator lights (LEDs), display buttons used to navigate through the menus, control mode buttons, and an LCD display. The display enables the operator to check the status, adjust the settings, and start and stop the generator set. The standard operator panel (show below) is located on every generator set. An optional in-home operator panel accessory is also available for location inside the home.

3. Control System 3-2018




FIGURE 1. STANDARD OPERATOR PANEL (HMI211)

Standard Key Functions (HMI211)

The user interface includes two fixed action buttons and four soft key buttons. The action of the soft key buttons changes to meet the requirements of each screen.

TABLE 14. KEY FUNCTIONS

| Key/Symbol | Action |
|-------------------|---|
| 0 | Switches to Off mode (fixed action button). |
| PAUTO | Switches to Auto mode. |
| (1) | Switches to Manual Run mode. |
| • | Navigates to the previous menu level (fixed action button). |
| • | (Up Arrow) Navigates to the previous screen/menu in a list. |
| ▼ | (Down Arrow) Navigates to the next screen/menu in a list. |
| _and - | Hold the up and down arrows simultaneously for two seconds from any Info Menu to navigate to the Menu screen. |
| Save | Saves changes and navigates to the associated screen. |
| Adjust | Navigates to the Adjust Menu of a specific menu. |
| → | (Right Arrow) Advances the highlighted field to the next editable field. |

3-2018 3. Control System

| Key/Symbol | Action |
|------------|--|
| - | Decreases value of the highlighted editable field. |
| + | Increases value of highlighted editable field. |

Standard LED Indicators (HMI211)

The operator panel has six LED indicators. Colors, flashing frequency, and conditions to turn them on/off/blink are included in the table below.

TABLE 15. LED INDICATORS

| LED | Color | Action |
|-----------------|--------|---|
| Not in Auto | Red | Indicates the generator set is in Manual or Off Mode. |
| Shutdown | Red | Indicates a Shutdown Fault has occurred. |
| Warning | Yellow | Indicates a Warning Fault has occurred. |
| Remote Start | Green | Indicates that the generator set has received a Remote Start Command. |
| Auto | Green | Indicates that the generator set is in Auto Mode. The generator starts when it receives a Remote Start Command. |
| Manual Run | Green | Indicates that the generator set has received a Manual Run Command. |

In-Home Operator Panel (Accessory)

The in-home operator panel is an optional display that may be purchased. This panel is intended to serve as a convenience option to the standard operator panel mounted on the generator set.

3. Control System 3-2018




FIGURE 2. IN-HOME OPERATOR PANEL

Key Functions (In-Home Operator Panel)

The user interface includes two fixed action buttons and four soft key buttons. The action of the soft key buttons changes to meet the requirements of each screen.

TABLE 16. KEY FUNCTIONS

| Key/Symbol | Action |
|---------------------------|---|
| Stop | Switches to Off mode. This key works from any screen (fixed action button). |
| • | (Up Arrow) Navigates to the previous screen/menu in a list. |
| • | (Down Arrow) Navigates to the next screen/menu in a list. |
| _ and - | Hold the up and down arrows simultaneously for two seconds from any Info Menu to navigate to the Service Menu. |
| Back | Navigates to the previous screen/menu in a list (fixed action button). In Adjust screens, settings are not saved. |
| Save | Saves changes and navigates to the associated screen. |
| Adjust | Navigates to the Adjust Menu of a specific menu. |
| → | (Right Arrow) Advances the highlighted field to the next editable field. |
| _ | Decreases value of the highlighted editable field. |
| + | Increases value of highlighted editable field. |

3-2018 3. Control System

LED Indicators (In-Home Operator Panel)

The operator panel has five LED indicators. Colors, flashing frequency, and conditions to turn them on/off/blink are included in the table below.

TABLE 17. LED INDICATORS

| LED | Color | Action |
|------------|--------|---|
| Shutdown | Red | Indicates a Shutdown Fault has occurred. |
| Warning | Yellow | Indicates a Warning Fault has occurred. |
| Auto Start | Green | Indicates that the generator set has received a Remote Start Command. |
| Auto | Green | Indicates that the generator set is in Auto Mode. The generator starts when it receives a Remote Start Command. |
| Manual Run | Green | Indicates that the generator set has received a Manual Run Command. |

3.2 Display Text or Symbolic Version

The operator panel graphical display can be set to show text (English only) or symbols for fault messages, operator menus, and the Mode Change Menu. Descriptions of commonly used symbols are included in the following table. Combinations of symbols are used to display some fault conditions.

When shipped from the factory, the display is set to display symbols. Qualified service personnel are required to change the default setting.

TABLE 18. SYMBOLS

| Symbol | Text |
|---------------------|-----------------------------------|
| ① | Generator Warning Fault |
| \otimes | Generator Shutdown Fault |
| ~ ! | Coolant Temperature |
| | Oil Pressure |
| > | Voltage Alternating Current (VAC) |
| $\overline{\nabla}$ | Voltage Direct Current (VDC) |
| \widetilde{A} | AC Current |
| Hz | Frequency |

3. Control System 3-2018

| Symbol | Text |
|---------------|------------------|
| - + | Battery |
| < > | Out of Range |
| 1 | High or Pre-High |
| 1 | Low or Pre-Low |
| X | Annunciator |
| | Over Speed |
| Ί | Crank Fail |
| 0 | Emergency Stop |

3.3 Exercise Settings

NOTICE

When battery power is lost, these settings must be reset.

NOTICE

Not applicable without a single phase RA series transfer switch.

To access the Clock/Exerciser Menu:

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- 2. Navigate through the screens to find and select **Clock/Excr** in the Service Menu.

NOTICE

The following screens represent the standard operator panel (that is, HMI211). If using an in-home operator panel, which may be additionally purchased as an option, the screens may look slightly different. This procedure applies to both operator panels.

3-2018 3. Control System




FIGURE 3. CLOCK/EXERCISER MENU NAVIGATION

3. Control System 3-2018

Updating Exercise Frequency (1-Phase ATS)

NOTICE

Not applicable without a single phase RA series transfer switch.

To update the exercise frequency and dates on the Clock/Exerciser Menu:

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- Access the Time Setup screen by selecting Clock Exerciser on the Genset Service Menu.
- 3. Press the down key on the Time Setup screen to access the Daylight Saving Adjust screen.
- 4. Select Adjust.
- 5. Press the down key on the Daylight Saving Adjust Start screen.
- Select Adjust.
- 7. Press **Exercise Schdr** on the Daylight Saving Adjust End screen.
- 8. Press Adjust.

When updating these settings, the functions of the keys are as follows:

- The horizontal right arrow key is used to select successive blocks for editing settings on the screen.
- Use the + or keys to edit the following settings:
 - Schdr Enable: Enable or Disable
 - Exercise Schedule: Semi-Annual (every six months), Quarterly, Monthly, Bi-Monthly (the first and third week of every month based on the time set when the Bi-Monthly option is selected), or Weekly
 - Exercise Schedule: Day, Hours, Minutes, AM/PM
- Press Save to save any changes. After saving, the Save button changes to the Adjust button.




FIGURE 4. EXERCISE FREQUENCY NAVIGATION

Updating Exercise Duration (1-Phase ATS)

NOTICE

Not applicable without a single phase RA series transfer switch.

To update the exercise duration on the Clock/Exerciser Menu:

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- 2. Access the Time Setup screen by selecting **Clock Exerciser** on the Genset Service Menu.
- 3. Press the down key on the Time Setup screen to access the Daylight Saving Adjust screen.
- Select Adjust.
- 5. Press the down key on the Daylight Saving Adjust Start screen.
- Select Adjust.
- 7. Press Exercise Schdr on the Daylight Saving Adjust End screen.
- 8. Press the down key on the Exercise Schdr Menu.
- 9. Press Adjust.

When updating these settings, the functions of the keys are as follows:

- The horizontal right arrow key is used to select the duration block for editing exercise duration.
- Use the + or keys to edit the exercise duration minutes.

 Press Save to save any changes. After saving, the Save button changes to the Adjust button.




FIGURE 5. EXERCISE DURATION NAVIGATION

3.4 Time Setup (1-Phase ATS)

NOTICE

When battery power is lost, these settings must be reset.

NOTICE

Not applicable without a single phase RA series transfer switch.

To set up the generator set clock for the current date and time:

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- Access the Time Setup screen by selecting Clock Exerciser on the Genset Service Menu.
- Select Adjust.

When updating these settings, the functions of the keys are as follows:

- The horizontal right arrow key is used to select successive blocks for editing settings on the screen.
- Select the left arrow to return to the previous screen.
- Adjust values by using the + or keys on the Adjust Menu of the Time Setup screen.

 Press Save to save any changes. After saving, the Save button changes to the Adjust button.




FIGURE 6. TIME SETUP SCREEN

Updating Daylight Saving Adjust Screens

Update Values on the Daylight Saving Adjust Screen

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- Navigate to the Genset Service Menu.
- 3. Select **Clock Exerciser** to access the Time Setup screen.
- 4. Press the down key on the Time Setup screen to access the Daylight Saving Adjust screen.
- 5. Select **Adjust**. When updating these settings, the functions of the keys are as follows:

TABLE 19. KEY FUNCTIONS ON THE DAYLIGHT SAVING ADJUST SCREEN

| Key/Button | Function |
|----------------------------|--|
| Horizontal right arrow key | Select successive blocks for editing settings on the screen |
| Left arrow key | Return to the previous screen |
| + or - keys | Adjust values on the Adjust screen of the Daylight Saving Adjust screen |
| Save button | Save any changes; after saving, the Save button changes to the Adjust button |




FIGURE 7. "DAYLIGHT SAVING ADJUST SAVING TIME" SCREEN NAVIGATION
Access and Update the Daylight Saving Adjust Start Screen

- 1. Press the down arrow key on the Daylight Saving Adjust screen.
- 2. Press **Adjust**. When updating these settings, the functions of the keys are as follows:

TABLE 20. KEY FUNCTIONS ON THE DAYLIGHT SAVING ADJUST START SCREEN

| Key/Button | Function |
|----------------------------|--|
| Horizontal right arrow key | Select successive blocks for editing settings on the screen |
| + or - keys | Adjust Month, Week, Day or Hour |
| Save button | Save any changes; after saving, the Save button changes to the Adjust button |




FIGURE 8. DAYLIGHT SAVING ADJUST START SCREEN Update the Daylight Saving Adjust End Screen

- 1. Press the down key on the Daylight Saving Adjust Start screen.
- 2. Press **Adjust**. When updating these settings, the functions of the keys are as follows:

TABLE 21. KEY FUNCTIONS ON THE DAYLIGHT SAVING ADJUST END SCREEN

| Key/Button | Function |
|----------------------------|--|
| Horizontal right arrow key | Select successive blocks for editing settings on the screen |
| + or - keys | Adjust Month, Week, Day or Hour |
| Save button | Save any changes; after saving, the Save button changes to the Adjust button |




FIGURE 9. DAYLIGHT SAVING ADJUST END SCREEN

3.5 Brightness and Contrast

The Screen Adjust screen allows the contrast, brightness, and units to be set. To access the Screen Adjust screen:

- 1. From any Information screen, hold down the up and down arrows simultaneously for two seconds to gain access to the Service Menu screen.
- 2. Select Screen Adjust.

To adjust the contrast, brightness, or units from the Screen Adjust screen:

- 1. From the Screen Adjust screen, select Adjust to access the screen variables.
- 2. Press the right arrow to move between the variables.
- 3. Adjust settings, and press **Save** to save any changes.

When updating these settings, the functions of the keys are as follows:

- The horizontal right arrow key is used to select successive blocks for editing settings on the screen.
- Select the left arrow to return to the previous screen.
- Adjust values by using the + or keys on the Adjust screen of the Display Setup screen.
- Press Save to save any changes. After saving, the Save button changes to the Adjust button.

NOTICE

The following screens represent the standard operator panel (HMI211). If using an in-home operator panel, which may be additionally purchased as an option, the screens may look slightly different. This procedure applies to both operator panels.




FIGURE 10. BRIGHTNESS AND CONTRAST SCREEN NAVIGATION

39

NOTICE

Adjusting the brightness on the operator panel adjusts the brightness of both the LCD backlight and the LEDs on the display. The contrast should never be 0 or 100% on any of the screens. The default value for Brightness is 50%.

3.6 History and About Menu

To access the History/About screen:

- 1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.
- 2. Select History/About.
- 3. Advance through the screens to view information about the generator set, control, and display.

NOTICE

The following screens represent the standard operator panel (HMI211). If using an in-home operator panel, which may be additionally purchased as an option, the screens may look slightly different. This procedure applies to both operator panels.




FIGURE 11. HISTORY/ABOUT MENU

3.7 Fault Log

To check the fault log:

1. From any Information Menu, hold down the up and down arrows simultaneously for two seconds. The Service Menu appears.

2. Select Fault History.

NOTICE

The active faults are displayed first. If there are no active faults, this screen is skipped. Following the Active Faults screen are the Fault History screens. These screens display the faults in chronological order from newest to oldest.

NOTICE

The following screens represent the standard operator panel (HMI211). If using an in-home operator panel, which may be additionally purchased as an option, the screens may look slightly different. This procedure applies to both operator panels.




FIGURE 12. FAULT LOG SCREEN

3.8 Operating Modes

The generator set's PowerCommand® control has **Manual Run**, **Off**, and **Auto** operating modes that are available from the operator panel.

Off Mode

When in the Off mode, the control does not allow the generator set to start.

If the generator set is running in either Manual Run or Auto mode and the Off button is pressed, the control immediately stops the generator set, and the control transitions to the Off mode.

Pressing the Off mode button resets all active faults.

Manual Run Mode

When in Manual Run mode, the generator set starts and continues to run until the control is put into the Off mode. While in Manual Run mode, the remote start signal is ignored.

Auto Mode

When in Auto mode, the control allows the generator set to be started at any time with a remote signal only. When a remote start signal is received, the generator set starts after a time delay start is completed (default delay is zero seconds).

When all remote start signals are removed, the control performs a normal shutdown sequence which includes a time delay stop (default delay is five minutes).

If the generator set is running in Auto mode and the Off button is pressed, the control immediately stops the generator set and the control transitions to the Off mode.

3.9 Selecting Operating Modes

Selecting Manual Run Mode

⚠ WARNING

Electrical Generating Equipment

When changing modes, the generator set can start or stop without warning (for example, Auto Mode may have been selected with no mains (utility) power available).

Make sure there is no danger to personnel or equipment, if the generator set starts or stops when changing modes.

- 1. Before proceeding to change the mode, make sure that it is safe to do so.
- 2. Press the Manual Run button on any of the Operator menus or the "Establishing/Re-establishing communication with control" menus.

3. If the Mode Change Access Code menu is enabled, the Mode Change Access Code is displayed. Enter the Mode Change Access Code.

4. A menu with alternating arrows is displayed above a second symbol.

5. Press the second Manual Run button, and the generator set will now begin the Manual start sequence. The Operator menu that was displayed before Manual Run mode was selected is re-displayed, but with the symbol blacked out.

NOTICE

To disable Manual Run mode, press the Off button.

NOTICE

Auto mode can also be selected while in Manual Run mode. Switching to Auto mode may result in the generator set shutting down.




FIGURE 13. SELECTING MANUAL RUN MODE

Selecting Auto Mode

⚠ WARNING

Electrical Generating Equipment

When changing modes, the generator set can start or stop without warning (for example, Auto Mode may have been selected with no mains (utility) power available).

Make sure there is no danger to personnel or equipment, if the generator set starts or stops when changing modes.

To switch to Auto mode (see Figure 14 on page 48),

- 1. Ensure that it is safe to do so before proceeding to change the mode.
- 2. Press the Auto button on any of the Operator menus, or the 'Establishing/Re-establishing communication with control' menus.
- 3. If the mode change access code feature is enabled, the Mode Change Access Code menu is displayed. Enter the Mode Change Access Code.
- 4. A menu with alternating arrows will then be displayed above a second Auto symbol.
- 5. Press this second Auto button. The Operator menu that was displayed before Auto mode was selected is re-displayed, but with the Auto symbols blacked out and Manual Run symbols visible.

To disable Auto mode, press the Off button.

The generator set is now ready to receive a remote start signal that will initiate the Auto run mode.

⚠ WARNING

Should a remote start signal be received, the generator set starts automatically. Make sure there is no danger to personnel or equipment should the generator set start without warning.

NOTICE

Manual Run mode can also be selected FROM Auto mode. Switching to Manual Run mode results in the generator set starting up.




FIGURE 14. SELECTING AUTO MODE

Selecting Off Mode

⚠ WARNING

Electrical Generating Equipment

When changing modes, the generator set can start or stop without warning (for example, Auto Mode may have been selected with no mains (utility) power available).

Make sure there is no danger to personnel or equipment, if the generator set starts or stops when changing modes.

To switch to Off mode (see the figure below),

- 1. Make sure that it is safe to do so before proceeding to stop the set.
- 2. Press the Off button on any of the Operator menus or the "Establishing/Reestablishing communication with control" menus.
- 3. If the Mode Change Access Code is enabled, the Mode Change Access Code will be displayed. Enter the Mode Change Access Code.
- 4. On entering the last correct digit, the basic screen will re-appear, and the set will stop without a Time Delay to Stop.

NOTICE

Make sure that there is no danger to personnel or equipment if the generator set is stopped.




FIGURE 15. SELECTING OFF MODE

4 Operation

4.1 Safety Considerations

⚠ WARNING

Hazardous Voltage

Contact with high voltages can cause severe electrical shock, burns, or death.

Make sure that only personnel who are trained and qualified to work on this equipment are allowed to operate the generator set and perform maintenance on it.

⚠ WARNING

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death.

Make sure that the generator set cannot be started accidentally or remotely before starting work on the generator.

⚠ WARNING

Combustible Gases

Ignition of battery gases is a fire and explosion hazard which can cause severe personal injury or death.

Do not smoke, or switch the trouble light ON or OFF near a battery. Touch a grounded metal surface first before touching batteries to discharge static electricity. Stop the generator set and disconnect the battery charger before disconnecting battery cables. Using an insulated wrench, disconnect the negative (–) cable first and reconnect it last.

⚠ CAUTION

Hazardous Voltage

Contact with high voltages can cause severe electrical shock, burns, or death.

Isolate all external electrical supplies prior to access of the control panel. Internal components have live exposed terminations even when the generator set is not running.

NOTICE

Isolator switch only: Do not open the output box while the generator set is running as the isolator switch will cause the generator set to shut down. Keep the output box covers in place during troubleshooting.

4. Operation 3-2018

NOTICE

Always disconnect a battery charger from its AC source before disconnecting the battery cables. Failure to do so can result in voltage spikes high enough to damage the DC control circuits of the generator set.

NOTICE

Ventilate the battery area before working on or near the battery. Wear goggles. Stop the generator set and disconnect the battery charger before disconnecting the battery cables using an insulated wrench. Disconnect the negative (–) cable first and reconnect it last.

All maintenance tasks must be assessed for health and safety risks; the preventive measures identified must be performed. An additional person is required for any task where doing so significantly adds to the safety of the task.

The installation of a generator set can be designed for remote starting. When troubleshooting a generator set that is shut down, make sure that the generator set cannot be accidentally re-started. Refer to the Locking the Generator Set Out of Service section.

4.2 Introduction

This section describes the operation of the generator set. The text should be read in conjunction with the Control System section of this manual.

All indicators, control switches/buttons, and graphical display are located on the face of the Operator Panel.

4.3 Maintenance

To ensure maximum performance and reliability from your generator set, it is essential that certain components are inspected periodically and, where necessary, maintenance procedures are carried out, as detailed in the Maintenance chapter.

4.4 Operating Recommendations

Running-In

Refer to the Maintenance section of this manual. Special "running-in" oils are not recommended for new or rebuilt Cummins engines. Use the same type of oil during "running-in" as is used in normal operation.

The engine should be run at varying loads during the first few hours of operation to allow the components to "bed in." Avoid long periods of light load or full load running particularly during the early life of the engine.

3-2018 4. Operation

Exercise Period

Generator sets on continuous standby must be able to go from a cold start to being fully operational in a matter of seconds. This can impose a severe burden on engine parts.

Regular exercising keeps engine parts lubricated, prevents oxidation of electrical contacts, and in general helps provide reliable engine starting.

Exercise the set for a minimum of ten minutes off-load at least once a week and for a minimum of 30 minutes with load at least once each month so that the engine reaches normal operating temperatures.

Low Operating Temperatures

NOTICE

Operating engines at idle (650 to 1000 rpm) in cold ambient temperatures wastes fuel, accelerates wear, and can result in serious engine damage. Under low temperature conditions, incomplete combustion will occur, allowing deposits of unburned tars and carbon to buildup on the valve guide and valves, and eventually cause valve sticking.

In cold climates it is critical that the following items be appropriately maintained and selected based on ambient operating temperatures. Check to be sure:

- The battery is properly sized.
- An appropriate mixture of antifreeze is used in the cooling system.
- The proper grade of fuel is being used.
- The correct weight of engine oil is being used.

Use a coolant heater if a separate source of power is available. The optional heater available from Cummins will help provide reliable starting under adverse weather conditions. Make sure the voltage of the separate power source is correct for the heater element rating.

High Operating Temperatures

In high ambient temperatures, when operating at full load, it is normal for the high temperature warning to be given. This indicates that the engine is operating near to its maximum capacity and is normal. If operation in high temperature environments is anticipated, increase the frequency of checks for coolant level, obstructions of cooling air inlets and outlets, and debris at the radiator.

Refer to the generator set nameplate for the maximum operating temperature, if applicable.

General Operating Conditions

The area surrounding the generator set is critical for safety and its performance. Follow the guidelines below.

Do not stack anything on top of the generator set.

4. Operation 3-2018

- Do not store anything inside of the generator set.
- Keep areas clear in front of the cool air in and hot air out (free of obstructions, debris, plants, etc.).

NOTICE

All maintenance procedures must be performed or supervised by authorized and trained service personnel only.

4.5 Generator Set Operation

⚠ WARNING

Combustible Vapors

Do not operate an engine where there are or can be combustible vapors. These vapors can be sucked through the air intake system and cause engine acceleration and overspeeding, which can result in a fire, an explosion, personal injury and extensive property damage.

Correct care of your engine will result in longer life, better performance, and more economical operation.

Cummins Inc. does not know how you will use your generator set. The equipment owner and operator, therefore, is responsible for safe operation in the installation site environment. Consult your authorized Cummins dealer for further information.

NOTICE

Diesel engines only: Cummins Inc. recommends the installation of an air intake shutoff device or a similar safety device to minimize the risk of overspeeding where an engine will be operated in a combustible environment.

NOTICE

Long periods of idling (more than ten minutes) can damage an engine. Do not idle the engine for excessively long periods.

Sequence of Operation

NOTICE

The following sequences are based on an approximate time duration. Your generator set may vary slightly from the timing diagrams in this manual. All referenced times are based on default control settings. The following sequences are applicable to generator sets connected to an RA series transfer switch.

3-2018 4. Operation

Power Outage Sequence

The sequence of operation after a power outage (when the generator set is in Auto Mode) is as follows:

- 1. In normal operation, the utility power is running to the transfer switch and then to the building load, and the generator set is off.
- 2. The utility power turns off (power outage).
- 3. One second after the power outage, the transfer switch sends the command to the generator set to start.
- 4. The generator set starts and provides voltage to the transfer switch, but the transfer switch does not switch (allowing the voltage to go to the building) until after a delay.




FIGURE 16. TIME REMAINING UNTIL TRANSFER SCREEN

5. Five seconds after starting, the generator set provides a signal to the transfer switch to transfer the building load to the generator set.




FIGURE 17. BUILDING LOAD TRANSFER IN PROCESS

6. The transfer switch switches the generator set power to the building load. The building is now running on generator power.




FIGURE 18. GENERATOR SET POWERING BUILDING LOAD

55

7. When the utility power is back and providing voltage to the transfer switch, the transfer switch waits for utility power stability.

4. Operation 3-2018




FIGURE 19. TIME REMAINING UNTIL RE-TRANSFER

8. When the utility power is stable for 5 minutes, the transfer switch switches back to utility power.




FIGURE 20. BUILDING LOAD TRANSFER IN PROCESS




FIGURE 21. UTILITY POWERING BUILDING LOAD

9. The generator set runs for a 5-minute cooldown and shuts off.



FIGURE 22. TIME REMAINING UNTIL STOP

10. Normal operation resumes.

Exercise Sequence

The exercise sequence when the programmed exercise time is realized (the generator set is in Auto Mode) is as follows:

1. The generator set starts and runs.

3-2018 4. Operation

2. The Exerciser Scheduler On screen displays every 3 seconds and toggles between the existing Information screen that is displayed for 1 second.




FIGURE 23. EXERCISER SCHEDULER SCREEN AND INFORMATION SCREEN TOGGLE - EXAMPLE

3. The transfer switch is not commanded to switch the building load to the generator set.

NOTICE

The user may navigate to other screens from the Information screens during this duration. No functional keys are active on the Exerciser Scheduler On screen.

4. The generator set stops after programmed exercise run time.

Manually Starting the Generator Set Sequence

If the generator set is manually started with the standard operator panel, HMI211 (the generator set is in Man Mode), the sequence is as follows:

NOTICE

Open the generator set main line circuit breaker to prevent the transfer switch from transferring building load to the generator set.

- 1. In normal operation, the utility power is running to the transfer switch and then to the building load, and the generator set is off.
- 2. Manually start the generator set via the standard control (HMI211) mounted on the generator set.

4. Operation 3-2018




FIGURE 24. MANUAL START SCREEN, STANDARD OPERATOR PANEL

- 3. The generator set starts and provides voltage to the transfer switch.
- 4. The generator set provides a signal to the transfer switch to transfer the building load to the generator set.




FIGURE 25. BUILDING LOAD TRANSFER IN PROCESS

5. The transfer switch switches the generator set power to the building load. The building is now running on generator power.

3-2018 4. Operation




FIGURE 26. GENERATOR SET POWERING BUILDING LOAD

6. Press the Off button to switch the load back to the utility power.




FIGURE 27. BUILDING LOAD TRANSFER IN PROCESS




FIGURE 28. UTILITY POWERING BUILDING LOAD

7. Normal operation resumes.

Remote Starting the Generator Set Sequence

If the generator set is remote started with the in-home operator panel accessory, if equipped (the generator set is in Auto Mode), the sequence is as follows:

- 1. In a normal operation, the utility power is running to the transfer switch and then to the building load, and the generator set is off.
- 2. The generator set-mounted control (HMI211) is set in Auto Mode.

4. Operation 3-2018




FIGURE 29. HMI211 SET IN AUTO MODE

3. Manually start the generator set via the in-home operator panel.

3-2018 4. Operation




FIGURE 30. MANUAL START SCREEN, IN-HOME OPERATOR PANEL

4. The generator set starts and provides voltage to the transfer switch, but the transfer switch does not switch (allowing the voltage to go to the building) until after a delay.




FIGURE 31. TIME REMAINING UNTIL TRANSFER SCREEN

5. Five seconds after starting, the generator set provides a signal to the transfer switch to transfer the building load to the generator set.

4. Operation 3-2018




FIGURE 32. BUILDING LOAD TRANSFER IN PROCESS

6. The transfer switch switches the generator set power to the building load. The building is now running on generator power.




FIGURE 33. GENERATOR SET POWERING BUILDING LOAD

7. When the remote display Stop button is pressed, the transfer switch switches back to utility power after a 5 minute retransfer delay.




FIGURE 34. BUILDING LOAD TRANSFER IN PROCESS




FIGURE 35. UTILITY POWERING BUILDING LOAD

8. The generator set runs for a 5-minute cooldown and shuts off.

3-2018 4. Operation



FIGURE 36. TIME REMAINING UNTIL STOP

9. Normal operation resumes.

4. Operation 3-2018

This page is intentionally blank.

5 Maintenance

5.1 Maintenance Safety

⚠ WARNING

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death.

Isolate all auxiliary supplies and use an insulated wrench to disconnect the starting battery cables (negative [–] first).

Hydrogen Gas

Arcing can ignite explosive hydrogen gas given off by batteries, causing severe personal injury or death. Arcing can occur when cables are removed or replaced, or when the negative (–) battery cable is connected and a tool used to connect or disconnect the positive (+) battery cable touches the frame or other grounded metal part of the generator set.

Insulated tools must be used when working in the vicinity of the batteries. Always remove the negative (–) cable first and reconnect last.

⚠ WARNING

Explosive Fumes

Arcing can ignite explosive fumes causing severe personal injury or death. Make sure hydrogen from the battery, engine fuel and other explosive fumes are fully dissipated before working on the generator set.

⚠ WARNING

Working at Heights

Using the incorrect equipment when working at heights can result in severe personal injury or death.

Suitable equipment for performing these tasks must be used in accordance with the local guidelines and legislation. Failure to follow these instructions can result in severe personal injury or death.

5. Maintenance 3-2018

↑ WARNING

Access

Using the generator set or part of as a means of access when attaching lifting shackles, chains, or other lifting aids, may damage the generator set, causing severe personal injury or death.

Do not use the generator set as a means of access. Failure to follow these instructions can result in severe personal injury or death.

⚠ WARNING

Exposed Terminations

Some panel internal components may have live exposed terminations even if the generator set is not running. Voltages are present which can cause electrical shock, resulting in personal injury or damage to equipment. Isolate all external electrical supplies prior to access of the control panel

NOTICE

Only authorized and qualified maintenance technicians who are familiar with the equipment and its operation should carry out maintenance.

NOTICE

Dependent upon the control system fitted, this unit may operate automatically and could start without warning.

NOTICE

Always disconnect a battery charger from its AC source before disconnecting the battery cables. Failure to do so can result in voltage spikes high enough to damage the DC control circuits of the generator set.

All maintenance tasks must be performed, but be sure to assess them for health and safety risks before starting. For example, perform a task with someone present if doing so will add significantly to the safety of the task.

Read, understand, and comply with all Caution, Warning, and Danger notes in this section, the Important Safety Instructions section, and the documentation supplied with the generator set.

Make sure that adequate lighting is available.

3-2018 5. Maintenance

Locking the Generator Set Out of Service

NOTICE

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death.

Isolate all auxiliary supplies and use an insulated wrench to disconnect the starting battery cables, negative (–) cable first.

Before any work is carried out for maintenance, etc., the generator set must be immobilized. Even if the generator set is put out of service by pressing the Off switch on the Operator Panel (or the STOP button if applicable), the generator set cannot be considered safe to work on until the engine is properly immobilized, as detailed in the following procedure.

NOTICE

Refer also to the engine-specific Operator Manual, if applicable. This manual contains specific equipment instructions that may differ from the standard generator set.

To immobilize the generator set:

1. Press the Off switch from the display and then press the E-Stop button to shut down the engine. This will prevent the starting of the generator set regardless of the Start signal source and will therefore provide an additional safety step for immobilizing the generator set. Alternatively, make sure the generator set is in manual mode (which allows it to be started by manually pushing the buttons).

NOTICE

When the E-Stop button is pressed, the Operator Panel indicates the Shutdown condition by illuminating the red Shutdown status LED and displaying a message on the graphical LCD display.

- 2. Thoroughly ventilate the generator set before disconnecting any leads.
- 3. Turn off and disconnect the heater (where fitted) from the AC source before disconnecting the battery cables.
- 4. Turn off and disconnect the battery charger (where fitted) from the AC source before disconnecting the battery cables.
- 5. Turn off the fuel supply to the engine.
- 6. Disconnect the battery. Disconnect the negative (-) cable first, using an insulated wrench.
- 7. Place warning notices at each of the above locations that state, "Maintenance in Progress Immobilized for Safe Working."

5. Maintenance 3-2018

5.2 Periodic Maintenance

⚠ WARNING

Electrical Generating Equipment

Accidental or remote starting of the generator set can cause severe personal injury or death.

Before working on the generator set, make sure that the generator set is in Off mode, disable the battery charger, and remove the negative (–) battery cable from the battery to prevent starting.

The table(s) that follow show the recommended service intervals for a generator set on standby service. If the generator set will be subjected to extreme operating conditions, the service intervals should be reduced accordingly.

At each scheduled maintenance interval, perform all previous maintenance checks that are due for scheduled maintenance.

Some of the factors that can affect the maintenance schedule are:

- Extremes in ambient temperature
- Exposure to elements
- Exposure to salt water
- Exposure to windblown dust or sand

Consult with your authorized Cummins Inc. service provider if the generator set will be subjected to any extreme operating conditions, and determine if extra protection or a reduction in service intervals is needed. Use the engine hours shown on the system status screen to keep to keep an accurate log of all service performed for warranty support. Perform all service at the time period indicated, or after the number of operating hours indicated, whichever comes first.

Repair or replace worn, damaged, or improperly functioning components identified during periodic maintenance procedures.

Periodic Maintenance Guidelines

Regularly performing the following periodic maintenance tasks greatly reduces the chances of a generator set shutdown:

- Maintain an appropriate oil level.
- Keep battery connections clean and tight.
- Do not overload the generator set.
- Keep the air inlet and outlet openings clear.

Periodic Maintenance Schedule

NOTICE

Perform maintenance tasks as specified using the period of operation that occurs first.

TABLE 22. PERIODIC MAINTENANCE SCHEDULE

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours¹ | 2 Years ¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|----------------------------------|-------------------------|---------------|
| Check air cleaner restriction indicator (where fitted): If the service indicator shows red, replace air cleaner elements and reset the air cleaner service indicator. | • | | | | | |
| Check air intake system for leaks: Visually inspect the air intake system for signs of wear or damage. Check audibly when the generator set is running. Replace worn or damaged components. | • | | | | | |
| Check operation of operator panel: Check display (the system will perform a control panel test on initial activation). Replace component if not functioning properly. | | | | | | |

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours ¹ | 2 Years¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|--|-------------|---------------|
| Check coolant level of radiator(s) (water jacket & LTA): If low, top up to coolant system specifications level, with Cummins recommended coolant mix. | | | | | | |
| Check cooling fan blades: Visually inspect the fan blades through the guarding for signs of wear or damage. | | | | | | |
| Check drive belt, condition and tension: Visually check belt for evidence of wear or slippage. | | | | | | |
| Check coolant lines and radiator hoses for leaks, wear, and cracks: Visually check for leaks, worn or damaged hoses. | | | | • | | |
| Check radiator air flow: Visually inspect the radiator through the guarding for blockage, build-up of debris, signs of wear or damage. | • | | | | | |

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours¹ | 2 Years ¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|----------------------------------|-------------------------|---------------|
| Verify that the coolant heater has power and is running (where fitted). Check for evidence of leaks. Remove any corrosion from fittings. | • | | | | | |
| Check engine oil level: If low, top up to engine specifications level, with recommended oil. | • | | | | | |
| Check fuel lines and hoses: Visually check for leaks, worn or damaged hoses. | • | | | | | |
| Check charge alternator: Check visually and audibly when the generator set is running. | • | | | | | |
| Check all exhaust components, and hardware (fittings, clamps, fasteners, etc.): Visually inspect the exhaust system for signs of wear or damage. Check audibly when the generator set is running. | • | | | | | |

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours ¹ | 2 Years¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|--|-------------|---------------|
| Check generator set enclosure: Visually check enclosure, walk around inspection of generator set. Make sure no inlets/outlets are covered/restricted, service access doors are operational and safety systems are in place and operational. | | | | | | |
| Check operation of Emergency Stop Button (where fitted): With the generator set running, press the Emergency Stop button. Check all systems, before resetting the fault. | | • | | | | |
| Replace engine oil and filters. Refer to the procedure in the Engine Oil section. | | = ² | | = ² | | |
| Check battery: Check connections to verify that they are secure. | | • | | • | | |
| Replace air cleaner. | | | • | | | |
| Clean radiator core. | | | | 3 | | |
| Check charge air cooler for damage and debris (where fitted). | | | | • | | |

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours ¹ | 2 Years¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|--|-------------|---------------|
| Check water pump for leaks. Check weep holes for evidence of leaks. Replace if leaking. | | | | • | | |
| Check engine ground. Clean as necessary. | | | | • | | |
| Check engine mounts general condition and for signs of excessive wear. | | | | • | | |
| Check starting motor for general condition, wiring connections. | | | | • | | |
| Check turbocharger (where fitted) for signs of leakage. Listen for excessive noise when test running the generator set. | | | | • | | |
| Check timing belt condition. Visually inspect. | | | | • | | |
| Inspect spark plugs. Replace if showing signs of excessive wear, carbon deposits, oil accumulation or damaged. | | | | | | |
| Check battery condition. | | | | • | | |

| Maintenance Item | Daily or After 24 Hours | Weekly or After 50 Hours | 100 Hours | 1 Year or After 200 Hours¹ | 2 Years ¹ | 4000 Hours |
|---|-------------------------------|--------------------------------|--------------|----------------------------------|-------------------------|---------------|
| Check electrical connections (battery, starter motor, alternator connections). Check for tight connections, general condition and remove any corrosion. | | | | • | | |
| Check alternator heater (where fitted). Check general condition and wiring connections. | | | | • | | |
| Check battery heater (where fitted). Check general condition and wiring connections. | | | | • | | |
| Replace cooling system coolant. | | | | | | |
| Inspect all sealed bearings every 4000 to 4500 hours | | O T l. | | | | 4 |

¹ To be performed by a qualified Service Technician.

Maintenance Record

Record all periodic and unscheduled maintenance and service. See the Periodic Maintenance Schedule for a list of scheduled maintenance frequency.

² After the initial 50 hour interval and every 200 hours thereafter.

³ Cleaning schedule may be reduced depending on operating conditions/environment.

⁴ Replace all bearings every 30000 hours or 5 years (or if necessary after 10000 hours or 2 years).

| Date | Engine Hours Meter Reading | Maintenance or Service Performed |
|------|-------------------------------------|----------------------------------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Record the name, address, and phone number of your authorized Cummins Inc. service center:

| Name | Address | Phone |
|------|---------|-------|
| | | |

Exercising the Generator Set

NOTICE

Audible engine RPM variation may be heard when there is no load applied. This is normal and does not affect the generator set performance.

Exercising the generator set drives off moisture, relubricates the engine, and removes oxides from electrical contacts. The result is better starting, more reliable operation and longer engine life.

The generator set exerciser mode defaults are as follows.

Day: TuesdayTime: 2:00 pmPeriod: Monthly

Run Time: 5 minutes

Refer to the Exercise Settings section of this manual for more information on setting up the exerciser.

5.3 Engine Oil

Recommended Engine Oil

Check the oil level prior to starting the generator set to verify that the oil level is between the High and Low marks. The generator set is shipped with engine oil (5W30 API SM or newer engine oil is recommended).

Checking Engine Oil Level

NOTICE

Check the engine oil level when the engine is not running and is out of Auto mode.

⚠ WARNING

Crankcase pressure can blow out hot oil and cause severe burns. Do NOT check oil while the engine is operating.

⚠ CAUTION

Overfilling can cause foaming or aeration of the oil while operation below the low mark may cause loss of oil pressure. Do not operate the engine with the oil level below the low mark or above the high mark.

⚠ WARNING

State and federal agencies have determined that contact with used engine oil can cause cancer or reproductive toxicity. Avoid skin contact and breathing of vapors. Use rubber gloves and wash exposed skin. Accidental or remote starting of the generator set can cause severe personal injury or death. Disconnect the negative (-) battery cable and place the control switch in its OFF position (or press the STOP button if applicable) before starting work.




FIGURE 37. ENGINE OIL COMPONENTS

To check the engine oil level:

- 1. Make sure that the engine has not been running for approximately five minutes.
- 2. Clean off the area surrounding the dipstick port to prevent entry of debris into the oil pan.
- 3. Pull out the dipstick and wipe it clean.
- 4. Reinsert and fully seat the dipstick.
- 5. Remove the dipstick and check the oil level.

NOTICE

The engine oil level indicated on the dipstick should be between the High (4.3 L or 4.5 qt) and Low (3.8 L or 4.0 qt) marks.

6. Reinsert and fully seat the dipstick.




FIGURE 38. ENGINE OIL DIPSTICK

Adding or Draining Oil

⚠ WARNING

Hot Surfaces

Contact with hot surfaces can cause severe burns. Wear appropriate PPE when working on hot equipment and avoid physical contact with hot surfaces.

⚠ WARNING

Hot Engines

Contact with hot engines can cause severe burns. Ensure that the generator set engine has cooled down before adding or draining the oil.

NOTICE

Too much oil can cause high oil consumption. Too little oil can cause severe engine damage. Keep the oil level between the High and Low marks on the dipstick.

Adding Oil

If the oil level is found to be insufficient, oil must be added.

- 1. Ensure that the oil fill cap area is clean, and prevent debris from entering the engine.
- 2. Add the appropriate amount of oil, based on the engine oil level check. Refer to the Checking Engine Oil Level section and the Model Specifications section.
- 3. Recheck the engine oil level. Based on the results, add or drain oil.
- 4. Clean up and dispose of any oil in accordance with local/state regulations.

Draining Oil

If the oil level is found to be excessive, oil must be drained from the engine.

- 1. Detach the oil drain hose from the side of the engine.
- 2. Place the end of the drain hose into an appropriate container.

Refer to local regulations to determine the appropriate container for used oil.

- Open the oil drain valve to release oil from the engine into the appropriate container.
- Recheck the engine oil level. Based on the results, add or drain oil.
- When a sufficient amount of oil has been drained from the system:
 - 1. Close the oil drain valve.
 - 2. Wipe the oil drain valve clean.
 - 3. Re-attach the drain hose to the side of the engine.
 - 4. Dispose of the used oil in accordance with local/state regulations.

Changing Engine Oil and Oil Filter

⚠ WARNING

Toxic Hazard

State and federal agencies have determined that contact with used engine oil can cause cancer or reproductive toxicity.

Avoid skin contact and breathing of vapors. Use rubber gloves and wash exposed skin. Accidental or remote starting of the generator set can cause severe personal injury or death. Disconnect the negative (-) battery cable and place the control switch in its OFF position (or press the STOP button if applicable) before starting work.

79

NOTICE

If the oil and/or oil filter are not reused, dispose of them in accordance with local environmental regulations.

NOTICE

Change the engine oil and filter when the engine is not running and is out of Auto mode.

NOTICE

Change the oil more often in hot and dusty environments.

NOTICE

Cummins highly recommends that any service or maintenance work be performed by qualified technicians.

- 1. Before changing the oil, the generator set should be operated until the water temperature is approximately 140 °F (60 °C).
- Turn off the generator set.
- 3. Drain the oil.
- 4. Remove the oil filter, and clean the filter mounting surface on the engine block. Remove the old gasket if it remains.
- 5. Make sure the gasket is in place on the new filter and apply a thin film of clean oil to the gasket. Install the new filter until the gasket just touches the block. Turn it an additional 1/2 to 3/4 turn. Do not over-tighten.
- 6. Close the oil drain valve.
- Refill with oil until full.

NOTICE

Too much oil can cause high oil consumption. Too little oil can cause severe engine damage. Keep the oil level between the High and Low marks.

- Operate generator set with no load to inspect for leaks at the lubricating oil filter and the drain plug.
- 9. Confirm that the correct oil level is in the pan:
 - a. Shut the generator set off and wait 5 minutes.
 - b. Check the engine oil level.
- 10. Check and repair any leaks identified.
- 11. Dispose of the used oil and oil filter according to local environmental regulations.

5.4 Air Intake System

The direct flow air cleaner consists of a primary filter and a secondary filter within the air cleaner housing. The air cleaner has been designed for a maximum restriction, at which point the filter elements should be changed. Refer to the Model Specifications section.

Normal Duty Air Cleaner

Normal Duty Air Cleaner Element Replacement

NOTICE

Holes, loose-end seals, dented sealing surfaces, corrosion of pipes, and other forms of damage render the air cleaner inoperative and require immediate element replacement or engine damage can occur.

NOTICE

Cummins Inc. does not recommend cleaning paper-type air cleaner elements.

- 1. Remove the existing air cleaner:
 - a. Loosen the strap clamp (2).
 - b. Wipe away any debris accumulated around the air cleaner connection to the engine. Ensure that no debris is allowed to enter the body of the air cleaner or the connection on the engine.
 - c. Remove the dirty air cleaner (1).
 - d. Dispose of the dirty element in accordance with local environmental agency requirements.
- 2. Install the replacement air cleaner (1) as follows:
 - a. Install the air cleaner (1).
 - b. Tighten strap clamp (2). Torque to 2.5 3.3 ft-lb (4.3 4.65 Nm).




FIGURE 39. EXAMPLE OF NORMAL DUTY AIR CLEANER

Heavy Duty Air Cleaner

Heavy Duty Air Cleaner Maintenance

⚠ WARNING

Fall Hazard

Falls can result in severe personal injury or death.

Make sure that suitable equipment for performing tasks at height are used in accordance with local guidelines and legislation.

There is a dust ejector valve (DEV) on the bottom of each filter pre-cleaner that should be checked periodically to make sure it is free of dust and dirt.

When there is a filter pre-cleaner, it includes a primary and secondary element that is checked periodically to make sure they are clean. Refer to the *Periodic Maintenance Schedule* table for additional information.

Heavy Duty Air Cleaner Element Replacement

⚠ CAUTION

Holes, loose-end seals, dented sealing surfaces, corrosion of pipes, and other forms of damage render the air cleaner inoperative and require immediate element replacement or engine damage can occur.

NOTICE

Cummins Inc. does not recommend cleaning paper-type air cleaner elements.

- 1. To remove the existing air cleaner element:
 - a. Before disassembly, wipe dirt from the cover and the upper portion of the air cleaner.
 - b. Lift the latch (3) and turn the end cover (4) counterclockwise.
 - c. Pull the end cover (4) away from the housing (1).
 - d. Remove the air filter element (2) from the housing (1).
 - e. Dispose of the dirty element in accordance with local environmental agency requirements.
- 2. To install the replacement air cleaner element:
 - a. Ensure that no debris enters the filter element or connection point on the air cleaner housing.
 - b. Insert the air filter element (2) into the housing (1).
 - c. Install the end cover (4) onto the housing (1).
 - d. Turn the end cover (4) clockwise until the latch (3) snaps into place.




FIGURE 40. EXAMPLE OF HEAVY DUTY AIR CLEANER

5.5 Generator Set Output - AC Electric System Checks

1. Check the following while the generator set is operating.

TABLE 23. AC ELECTRIC SYSTEM CHECKS

| Check | Description |
|------------|--|
| Frequency | The generator set frequency should be stable and the reading should be the same as the generator set nameplate rating. See the Model Specifications section. |
| AC Voltage | At no load, the line-to-line voltage, or voltages, should be the same as the generator set nameplate rating. |

| Check | Description |
|-------------|--|
| AC Ammeter | At no load, the current readings should be zero. With a load applied, each line current should be similar. |
| Panel Lamps | When the operating panel is first connected to the DC supply, the system runs a check by illuminating each of the indicator lamps in turn. |

2. If all of the LEDs do not illuminate, replace the operator panel.

5.6 DC Electrical System

⚠ WARNING

Combustible Gases

Ignition of battery gases is a fire and explosion hazard which can cause severe personal injury or death.

Do not smoke, or switch the trouble light ON or OFF near a battery. Touch a grounded metal surface first before touching batteries to discharge static electricity. Stop the generator set and disconnect the battery charger before disconnecting battery cables. Using an insulated wrench, disconnect the negative (–) cable first and reconnect it last.

1. Check the harness connections. If any harness connections are damaged, contact your service representative.




FIGURE 41. CHECK HARNESS CONNECTIONS

- 2. Check the terminals on the batteries for clean and tight connections. Loose or corroded connections create resistance, which can hinder starting. Clean and reconnect the battery cables if loose, using an insulated wrench. Always disconnect both ends of the negative battery cable. Reconnect one end of the cable to the negative battery terminal and the other end to ground. This will make sure that any arcing will be away from the battery and least likely to ignite explosive battery gases.
- 3. Check connections at the battery charging alternator.
- 4. Visually inspect the alternator belt to make sure it is not loose or cracked.

5.7 Batteries

Batteries are an essential part of any standby generator set system. A significant amount of generator set failures are due to battery issues.

It is therefore vital that batteries are stored, commissioned, and maintained as detailed here. Reference should also be made to the battery manufacturer's instructions.

Maintenance free batteries (if supplied with the generator set) need no maintenance for commissioning.

Storage

Batteries must be stored in a cool, dry, well-ventilated place, in the upright position, and with the vent caps securely in place.

Batteries must never be stacked on top of each other and must be protected from the floor by a wooden pallet or suitably thick cardboard sheet.

Safety Precautions

Servicing of batteries are to be performed or supervised by personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries.

General Precautions for Maintenance-Free Batteries

Handling and proper use of batteries is not hazardous if the correct precautions are observed and personnel are trained in their use.

⚠ WARNING

Arcing Hazard

Laying tools or metal objects across the battery can cause arcing that may ignite battery gases causing explosions resulting in personal injury.

Never lay tools or metal objects across the top of the battery.

↑ WARNING

Electric Shock Hazard

Voltages and currents present an electrical shock hazard that can cause severe burns or death.

Use tools with insulated handles to prevent the risk of electric shock.

⚠ CAUTION

Toxic Hazard

Electrolyte is a dilute sulphuric acid that is harmful to the skin and eyes. It is electrically conductive and corrosive.

Wear full eye protection and protective clothing. If electrolyte contacts the skins, wash it off immediately with water. If electrolyte contacts the eyes, flush thoroughly and immediately with water and seek medical attention. Wash spilled electrolyte with an acid neutralizing agent.

NOTICE

Keep batteries upright to prevent spillage.

Fire Hazard

⚠ WARNING

Combustible Gases

Lead acid batteries present a risk of fire because they generate hydrogen gas.

Do not smoke near the batteries. Do not cause flame or spark in the battery area. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface.

⚠ WARNING

Before disconnecting a battery, always remove power from the AC powered battery charger.

⚠ WARNING

When putting a battery into service on a generator set, connect the negative lead LAST; when removing the battery, disconnect the negative lead FIRST.

Vented Batteries

⚠ WARNING

Toxic Hazard

The electrolyte in vented batteries is a dilute sulfuric acid that is harmful to the skin and eyes. It is also electrically conductive and corrosive.

Always:

- 1. Wear full eye protection and protective clothing;
- 2. If the electrolyte contacts the skin, wash it off immediately with water:
- 3. If the electrolyte contacts the eyes, flush them thoroughly and immediately with water and seek medical attention; and
- 4. Wash spilled electrolyte down with an acid neutralizing agent. A common practice is to use a solution of one pound (500 grams) bicarbonate of soda (also known as baking soda or sodium bicarbonate) to one gallon (4 liters) of water.
- 5. Continue to add the bicarbonate of soda solution until the evidence of reaction (that is, foaming) has stopped.
- 6. Flush the resulting liquid with water and dry the area.

Battery Maintenance

⚠ WARNING

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death. Arcing at battery terminals or in light switches or other equipment, and flames or sparks can ignite battery gas causing severe personal injury.

Always follow these procedures to avoid injury and/or damage:

- Ventilate the battery area before working on or near the battery.
- · Wear safety glasses.
- Do not smoke.
- Switch a work light on or off away from the battery.

Make sure the generator set is shut down and disabled:

- 1. Press the generator set's red STOP button on the local display to stop the generator set. Allow the generator set to thoroughly cool to the touch.
- 2. Turn off and disconnect the battery charger from the AC source before disconnecting the battery cables.
- 3. Disconnect the negative (–) cable from the battery and secure it from contacting the battery terminals to prevent accidental starting.
- 4. Once work is complete, reconnect the negative (-) battery cable last.

See Battery Charger Maintenance for troubleshooting the charger.

Always:

Keep the battery case and terminals clean and dry and the terminals tight.

- Remove battery cables with an insulated wrench or battery terminal puller.
- Make sure which terminal is positive (+) and which is negative (-) before making battery connections, always removing the negative (-) cable first and reconnecting it last to reduce arcing.

NOTICE

If the battery needs to be replaced, make sure that the replacement battery specifications match those found in the Model Specifications in this manual.

Charging

Where a consistent source of AC power is available, Cummins recommends the use of a battery charger to maintain battery condition and charge. Cummins offers several battery chargers.

Where generator sets are used infrequently and a consistent source of AC power is not available, battery recharging must be put on a recharge schedule to ensure that a fully charged condition is maintained.

NOTICE

NEVER allow a battery to become completely flat (fully discharged), or to stand in a discharged condition, or damage will result.

Follow the battery charger operating instructions for proper use.

5.8 Spark Plugs

NOTICE

Make sure service personnel are qualified to perform electrical and mechanical service.

The generator set has four spark plugs, all accessible from the top of the engine. The spark plugs must be in good condition for proper engine starting and performance. A spark plug that fouls frequently or has heavy soot deposits indicates the need for engine service.

- 1. Set the generator set control to the Off position before checking the spark plugs.
- 2. To prevent cross-threading a spark plug, always thread it in by hand until it seats. Torque the spark plug to 20 Nm (15 lb-ft).

3. Return the generator set control to the desired setting when finished performing maintenance.

5.9 Cleaning the Generator Set Housing

The housing of the generator set housing can be damaged by pressure washing or solvents and other cleaning agents. Only use soap and water or an "all citrus degreaser" to clean the housing.

5.10 Complete System Test

NOTICE

Only authorized and qualified maintenance technicians who are familiar with the equipment and its operation should carry out this test.

A complete system test is recommended to verify that the electrical system is working properly. Testing the system once every 200 hours or every 2 years is required to make sure the transfer switch will transfer the load to the generator set if there is a utility power failure. For more information, see the transfer switch owner manual.

To initiate a complete system test:

- 1. Before starting:
 - Check the oil level.
 - Make sure there is enough fuel.
 - See the Checklist section in the installation manual.
- Place the generator set in Standby mode.
- 3. Switch the main utility disconnect from the ON to the OFF position.
- 4. Make sure the following occurs:
 - The generator set starts.
 - b. After the generator set starts and stabilizes, the load is transferred from the utility to the generator set.
- 5. Switch the main utility disconnect from the OFF to the ON position.
- 6. Make sure the following occurs:
 - a. After approximately 5 minutes, the load is transferred back to the utility.
 - b. Once the transfer switch is connected to utility power, after approximately 5 minutes, the generator set stops.

NOTICE

If the test fails, call your authorized Cummins service provider to fix the problem.

6 Troubleshooting

6.1 Avoiding Generator Set Shutdowns

By regularly performing the following periodic maintenance and guidelines, you will greatly reduce the chances of a generator set shutdown:

- · Maintain an appropriate oil level.
- · Keep battery connections clean and tight.
- · Do not overload the generator set.
- Keep the air inlet and outlet openings clear.

Refer to the Maintenance section for more information.

6.2 Control System

The generator set control system continuously monitors engine sensors for abnormal conditions, such as low oil pressure and high coolant temperature. If any of these conditions occur, the control will light a yellow Warning lamp or a red Shutdown lamp and will display a message on the graphical display panel. In the event of an engine shutdown fault (red Shutdown LED), the control will stop the engine immediately.

6.3 Fault Finding

⚠ WARNING

Troubleshooting procedures.

Troubleshooting procedures present hazards that can result in severe personal injury or death.

Only qualified service personnel with knowledge of fuels, electricity, and machinery hazards should perform service procedures.

Review safety precautions listed in this manual together with the documentation supplied with the generator set.

For any symptom not listed, contact your authorized dealer for assistance.

Before starting any fault finding, ensure that the following basic checks are carried out:

- All switches and controls are in their correct positions
- · Fuel system is connected and fuel is available
- The lubricating oil level is correct
- The coolant level is correct
- The radiator cooling air flow is free from obstruction

6. Troubleshooting 3-2018

- The battery charge condition is satisfactory and the connections are secure
- The generator set electrics and alternator connections are secure
- The panel connections are secure
- The protection circuits have been reset
- · Blown fuses have been replaced
- Tripped contactors or circuit breakers have been reset

6.4 Fault/Status Codes - PowerCommand 1.1

Fault Code Introduction

Fault code information, together with warning and shutdown information, is provided in this section to assist in locating and identifying the possible causes of faults in the generator set system.

Refer also to the engine-specific operator manual, if it exists. The engine operator manual contains additional information regarding the running and care of the generator set as well as specific equipment instructions that may differ from the standard generator set.

For any fault codes that occur but are not listed, contact your Cummins service representative.

Fault/Status Codes Warnings

⚠ WARNING

Electrical Generating Equipment

Incorrect installation or servicing can result in severe personal injury or death.

Make sure that only suitably trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards perform electrical and/or mechanical service.

⚠ WARNING

Automated Machinery

Accidental or remote starting of the generator set can cause severe personal injury or death.

Prevent accidental starting by disconnecting the starting battery cables, negative (–) cable first.

Code 143 - Engine Oil Pressure Low (Warning)

Logic: Engine oil pressure is below the low oil pressure shutdown threshold.

Possible Cause:

1. Low lubricating oil level

3-2018 6. Troubleshooting

2. External leak

Diagnosis and Repair:

- 1. Low lubricating oil level
 - a. Check the oil level. Add or drain oil, if necessary.
- 2. External leak
 - a. Inspect the engine and surrounding area for external oil leaks.
 - b. Contact your local dealer if a leak is present.

Code 151 - Engine Coolant Temperature High (Shutdown)

Logic:

Engine coolant temperature has exceeded the alarm (shutdown) threshold for high coolant temperature.

Possible Cause:

- 1. High ambient temperature
- 2. Coolant level is below specification
- Cooling system components are damaged or obstructed

Diagnosis and Repair:

- 1. High ambient temperature
 - Reduce loads or recirculation of discharge air to generator in elevated ambient.
- 2. Coolant level is below specification
 - a. Inspect the engine, cooling system, and surrounding area for external coolant leaks.
 - i. Contact your local dealer if a leak is present.
 - b. Verify the coolant level is correct via the sight glass.
 - i. Add coolant as necessary.
- 3. Cooling system components are damaged or obstructed
 - a. Inspect the radiator, charge air cooler, and other cores (if used).
 - i. Inspect for damaged fins.
 - ii. Inspect for dirt, debris, or obstructions.
 - iii. Remove blockage.
 - b. Inspect the fan shroud and air recirculation baffles for damage and clearance.
 - i. Contact your local dealer if repair or replacement is required.
 - c. Inspect the fan belt(s) for damage, wear, and proper tension. Inspect pulleys and belt tensioner for damage or wear.
 - i. Contact your local dealer if repair or replacement is required.

93

6. Troubleshooting 3-2018

d. Inspect the radiator cap and gasket for damage and proper pressure operation.

- i. Contact your local dealer if repair or replacement is required.
- e. Inspect upper and lower radiator hoses for collapse, distortion, or fluid leaks.
 - i. Contact your local dealer if repair or replacement is required.
- f. Inspect cooling system components for external contaminates and clean as required.
 - i. Open the radiator cap and inspect for contaminated coolant and scale.
 - ii. Contact your local dealer if flushing of cooling system is required.

Code 155 - Intake Manifold Temperature High (Shutdown)

Logic: The engine intake manifold temperature has exceeded 95 °C (203 °F) for greater than 10 seconds.

Diagnosis and Repair:

For the troubleshooting procedure, refer to DTC 127 in the E-Controls Manual, which applies to several applications. See the drawings provided with the generator set or the wiring diagrams appendix for the appropriate pin numbers.

Code 197 - Coolant Level Low (Warning)

Logic: Coolant level sensor signal is showing a low coolant level for greater 10 seconds.

Possible Cause:

1. Low coolant

Diagnosis and Repair:

- 1. Low coolant
 - a. Remove radiator cap and check that coolant is up to the required level.

Code 415 - Engine Oil Pressure Low (Shutdown)

Logic: Engine oil pressure is below the low oil pressure shutdown threshold.

Possible Causes:

- 1. Lubricating oil level is low
- 2. External leak

Diagnosis and Repair:

- 1. Lubricating oil level is low
 - a. Check the oil level. Add oil, if necessary.
- External leak
 - a. Inspect the engine and surrounding area for external oil leaks.

3-2018 6. Troubleshooting

b. If a leak is present, contact your Cummins service representative.

Code 421 - Engine Oil Temperature High (Warning)

Logic: The control has detected the engine oil temperature has exceeded the warning threshold.

Possible Cause:

- 1. High ambient temperature
- Blocked enclosure air intake
- Coolant level below specification

Diagnosis and Repair:

- 1. High ambient temperature
 - a. Reduce loads or recirculation of discharge air to generator in elevated ambient.
- Blocked enclosure air intake
 - a. Inspect for dirt, debris, or obstructions.
 - b. Remove blockage or snow/ice buildup as applicable.
- 3. Coolant level is below specification
 - a. Check coolant level.
 - b. Add coolant as necessary.

Code 441 - Battery Voltage Low (Warning)

Logic: Battery voltage is low.

Possible Causes:

- 1. Loose or damaged battery cable connections
- Battery charger not connected (if equipped)
- Battery not completely charged
- 4. Battery is old and does not maintain a charge

Diagnosis and Repair:

- Loose or damaged battery cable connections
 - Inspect the battery cable connections for corrosion and loose connections.
 Adjust or repair if needed.
- Battery charger not connected (if equipped)
 - Make sure that the battery charger is connected to the AC power supply.
 - b. Make sure that the battery charger is connected correctly to the battery.
- Battery not completely charged
 - Using a voltmeter or multimeter, determine if the voltage is below 11 V. If so, recharge the battery.

6. Troubleshooting 3-2018

- 4. Battery is old and does not maintain a charge
 - · Replace the battery.

Code 488 - Intake Manifold Temperature High (Warning)

Logic:

Engine intake manifold temperature has exceeded 185 °F (85 °C) for more than 90 seconds.

Possible Cause:

- 1. High ambient temperature
- Enclosure air intake blocked
- 3. Coolant level is below specification
- 4. Radiator blocked
- Enclosure air discharge blocked
- 6. Fan belt is broken or loose

Diagnosis and Repair:

- 1. High ambient temperature
 - a. Reduce loads or recirculation of discharge air to generator in elevated ambient.
- Enclosure air intake blocked
 - a. Inspect for dirt, debris, or obstructions.
 - b. Remove blockage or snow/ice buildup as applicable.
- 3. Coolant level is below specification
 - Check coolant level.
 - b. Add coolant as necessary.
- Radiator blocked
 - a. Inspect for dirt, debris or obstructions.
 - b. Remove blockage or winterfront as applicable.
- 5. Enclosure air discharge blocked
 - a. Inspect for dirt, debris, or obstructions.
 - b. Remove blockage or snow/ice buildup as applicable.
- Fan belt is broken or loose
 - a. Inspect belt(s) for damage, wear, and proper tension.
 - b. Repair or replace if damaged or worn.

Code 1438 - Fail to Crank (Shutdown)

Logic:

3-2018 6. Troubleshooting

The engine failed to crank after the generator control received a start signal.

Possible Cause:

- 1. Dead or weak battery
- 2. Failed starter

Diagnosis and Repair:

- 1. Dead or weak battery
 - a. Verify battery voltage is at least 12 VDC (or 24 VDC if applicable).
 - b. Charge or replace the battery as necessary.
- 2. Failed starter
 - a. Press the Reset/Fault acknowledge button on the display.
 - b. Attempt to start the generator and test for B+ at the starter supply lug.
 - c. If B+ is present at the starter supply lug, the starter could be defective.

Code 1472 - High AC Current (Shutdown)

Logic:

The generator set output current has exceeded the shutdown limit threshold for greater than the fixed time delay.

Possible Causes:

1. Generator set overload

Diagnosis and Repair:

- 1. Generator set overload.
 - a. Reduce the generator set load by powering off unnecessary electrical loads.

Code 5134 - Unknown Shutdown at Idle

Logic:

Engine is not getting a proper fuel supply.

Possible Causes:

1. Fuel supply issue

Diagnosis and Repair:

- Fuel supply issue
 - a. Check that there is a proper supply of fuel to the engine.

6. Troubleshooting 3-2018

This page is intentionally blank.

power.cummins.com

Copyright © 2018 Cummins Inc. All rights reserved.

Cummins, the "C" logo, PowerCommand, AmpSentry, and InPower are trademarks of Cummins Inc.

Other company, product, or service names may be trademarks or service marks of others.

Specifications are subject to change without notice.

