

Alternators and Starter Motors

TECHNICAL MANUAL
Alternators and Starter Motors
CTM77 18JUL05 (ENGLISH)

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



CAUTION: This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

This Component Technical Manual (CTM) contains the latest available instructions necessary to repair engine alternators and starter motors. It includes theory of operation, and diagnostic and testing procedures to help troubleshoot and understand potential failure modes.

The information is organized in sections and groups by various suppliers. At the beginning of each repair group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Component Technical Manuals are concise service guides for specific components. They are written as stand-alone manuals covering multiple machine applications.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes.

This manual covers alternator and starter motor applications for all John Deere diesel engines—both older 300/400/500-Series and newer POWERTECH® and PowerTech Plus™ 2.4 L—13.5 L engines. This manual covers components for both Deere OEM engines and Deere machine engine applications.

NOTE: Remanufactured alternators and starter motors are available for replacement on most applications listed in this manual. Refer to John Deere's "Remanufactured Components" catalogs PC2344 (Ag), PC2345 (CE) and PC2346 (C&CE) to cross-reference your original equipment part number and obtain a suitable remanufactured replacement starter or alternator.

John Deere Dealers

IMPORTANT: Please copy this page listing changes and route it through your service department.

This CTM is a complete revision of CTM77, Alternators and Starter Motors, dated 25 Sep 02. **Discard CTM77 dated 25 Sep 02 and replace it with this new manual.**

This manual covers alternators and starter motors on all John Deere and OEM applications manufactured since 1972, except 40, 50 and 55 Series Utility Tractors.

Revised information includes:

1. Updated test specifications for all current alternators and starter motors, including those adopted since the 25 Sep 02 edition.
2. Added new applications for all current alternators and starter motors.
3. Added new Bosch alternator pulley removal procedure to Section 30, Group 10.
4. Updated torque charts in Section 05, Group 10.

OURGP11,0000053 -19-15JUL05-1/1

Contents

SECTION 05—Introduction and Safety Information

- Group 05—Safety
- Group 10—General Information
- Group 15—Electrical System Basic Information and Wiring Diagrams

SECTION 10—Delco-Remy Alternators

- Group 05—Delco-Remy Alternator Theory of Operation
- Group 10—Delco-Remy (Delcotron) 10SI, 12SI and 15SI Alternator Repair
- Group 15—Delco-Remy (Delcotron) 21SI Alternator Repair

SECTION 15—Motorola Alternators

- Group 05—Motorola Alternator Theory of Operation
- Group 10—Motorola 8E-Series Alternator Repair
- Group 15—Motorola HC-, MA-, MR-Series Alternator Repair
- Group 20—Motorola A-, RA-, 8AR-Series Alternator Repair
- Group 25—Motorola SA-Series Alternator Repair
- Group 30—Motorola TA-Series Alternator Repair

SECTION 20—Niehoff Alternators

- Group 05—Niehoff Alternator Theory of Operation
- Group 10—Niehoff 12-Volt, 110-Amp Alternator Repair
- Group 15—Niehoff 24-Volt, 50-Amp Alternator Repair

SECTION 25—Denso Alternators

- Group 05—Denso Alternator Theory of Operation
- Group 10—Denso Alternator with Add-On Regulator Repair
- Group 15—Denso Alternator with Built-In Regulator Repair

SECTION 30—Bosch Alternators

- Group 05—Bosch Alternator Theory of Operation
- Group 10—Bosch Alternator Repair

SECTION 35—Valeo Alternators

- Group 05—Valeo Alternator Theory of Operation
- Group 10—Valeo Alternator Repair
- Group 15—Valeo A13N-Series Alternator Repair

SECTION 40—Magneton Alternators

- Group 05—Magneton Alternator Theory of Operation
- Group 10—Magneton Alternator Repair

SECTION 45—Leece-Neville Alternators

- Group 05—Leece-Neville Alternator Theory of Operation
- Group 10—Leece-Neville Alternator Repair

SECTION 50—Prestolite Alternators

- Group 05—Prestolite Alternator Theory of Operation
- Group 10—Prestolite Alternator Repair

SECTION 55—Iskra Alternators

- Group 05—Iskra Alternator Theory of Operation
- Group 10—Iskra Alternator Repair

SECTION 60—Delco-Remy Starter Motors

- Group 05—Starting Circuit Theory of Operation
- Group 10—Delco-Remy 10/20/22/25/27/28MT Starter Motor Repair
- Group 15—Delco-Remy 30MT, 35MT, 37MT Starter Motor Repair
- Group 20—Delco-Remy 40MT, 41MT, 42MT, 50MT Starter Motor Repair

SECTION 65—John Deere/Denso Starter Motors

- Group 05—Starting Circuit Theory of Operation
- Group 10—John Deere/Denso Conventional Starter Motor Repair
- Group 15—John Deere/Denso Gear Reduction Starter Motor Repair
- Group 20—John Deere/Denso Planetary Starter Motor Repair

SECTION 70—Bosch Starter Motors

- Group 05—Starting Circuit Theory of Operation
- Group 10—Bosch Conventional Starter Motor Repair
- Group 15—Bosch Planetary Gear Starter Motor Repair

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2005
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 1994, 1997, 2000, 2002

05

SECTION 75—Iskra Starter Motors

Group 05—Starting Circuit Theory of Operation

Group 10—Iskra AZE/AZF/AZJ-Type Starter Motor
Repair

Group 15—Iskra AZE-Type Starter Motor Repair

10

SECTION 80—Valeo Starter Motors

Group 05—Starting Circuit Theory of Operation

Group 10—Valeo Starter Motor Repair

15

SECTION 85—Magnetron Starter Motors

Group 05—Starting Circuit Theory of Operation

Group 10—Magnetron Starter Motor Repair

20

25

30

35

40

45

50

Contents

55

60

65

70

75

80

85

INDX

Contents

55

60

65

70

75

80

85

INDX

Section 05

Introduction and Safety Information

Contents

	Page
Group 05—Safety	05-05-1
Group 10—General Information	
Unified Inch Bolt and Screw Torque Values . . .	05-10-1
Metric Bolt and Screw Torque Values	05-10-2
Group 15—Electrical System Basic Information and Wiring Diagrams	
Electrical Circuit Malfunctions	05-15-1
High Resistance Circuit	05-15-2
Open Circuit	05-15-3
Grounded Circuit	05-15-5
Shorted Circuit	05-15-7
Seven Step Electrical Test Procedure	05-15-8
Multimeter	05-15-10

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



TS227 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -UN-23AUG88


DX,SPARKS -19-03MAR93-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

Handling Batteries Safely

! **CAUTION:** Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (—) battery clamp first and replace it last.

! **CAUTION:** Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Using proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.


If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



TS204 -UN-23AUG88



TS203 -UN-23AUG88


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

Work in Clean Area

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




T6642EJ -UN-18OCT88

DX,CLEAN -19-04JUN90-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88


DX,LOOSE -19-04JUN90-1/1

05
05
4

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area



TS220 -UN-23AUG88

DX,AIR -19-17FEB99-1/1

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




TS223 -UN-23AUG88

DX,LIGHT -19-04JUN90-1/1

Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



TS226 -UN-23AUG88

DX,LIFT -19-04JUN90-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 76 mm (3 in.) from area to be affected by heating.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.



TSS20 -JUN-23AUG88

DX,PAINT -19-19JUL01-1/1

05
05
6

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



TS218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 -UN-08NOV89

DX,REPAIR -19-17FEB99-1/1

Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TSS1133 -UN-26NOV90


DX,DRAIN -19-03MAR93-1/1

Prevent Machine Runaway

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



TS177 -UN-11JAN89

DX,BYPAS1 -19-29SEP98-1/1

Live With Safety

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.




TS231 -19-07OCT88

DX,LIVE -19-25SEP92-1/1

Unified Inch Bolt and Screw Torque Values

TS1671 -UN-01MAY03



Bolt or Screw	SAE Grade 1				SAE Grade 2 ^a				SAE Grade 5, 5.1 or 5.2				SAE Grade 8 or 8.2			
	Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c	
Size	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in
1/4	3.7	33	4.7	42	6	53	7.5	66	9.5	84	12	106	13.5	120	17	150
													N•m	lb-ft	N•m	lb-ft
5/16	7.7	68	9.8	86	12	106	15.5	137	19.5	172	25	221	28	20.5	35	26
									N•m	lb-ft	N•m	lb-ft				
3/8	13.5	120	17.5	155	22	194	27	240	35	26	44	32.5	49	36	63	46
			N•m	lb-ft	N•m	lb-ft	N•m	lb-ft								
7/16	22	194	28	20.5	35	26	44	32.5	56	41	70	52	80	59	100	74
	N•m	lb-ft														
1/2	34	25	42	31	53	39	67	49	85	63	110	80	120	88	155	115
9/16	48	35.5	60	45	76	56	95	70	125	92	155	115	175	130	220	165
5/8	67	49	85	63	105	77	135	100	170	125	215	160	240	175	305	225
3/4	120	88	150	110	190	140	240	175	300	220	380	280	425	315	540	400
7/8	190	140	240	175	190	140	240	175	490	360	615	455	690	510	870	640
1	285	210	360	265	285	210	360	265	730	540	920	680	1030	760	1300	960
1-1/8	400	300	510	375	400	300	510	375	910	670	1150	850	1450	1075	1850	1350
1-1/4	570	420	725	535	570	420	725	535	1280	945	1630	1200	2050	1500	2600	1920
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2140	1580	2700	2000	3400	2500
1-1/2	990	730	1250	930	990	730	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For plastic insert or crimped steel type lock nuts, for stainless steel fasteners, or for nuts on U-bolts, see the tightening instructions for the specific application. Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.


Replace fasteners with the same or higher grade. If higher grade fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^aGrade 2 applies for hex cap screws (not hex bolts) up to 6. in (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

^b"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or 7/8 in. and larger fasteners with JDM F13C zinc flake coating.

^c"Dry" means plain or zinc plated without any lubrication, or 1/4 to 3/4 in. fasteners with JDM F13B zinc flake coating.

Metric Bolt and Screw Torque Values



TS1670 -UN-01MAY03

Bolt or Screw	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b	
Size	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in	N•m	lb-in
M6	4.7	42	6	53	8.9	79	11.3	100	13	115	16.5	146	15.5	137	19.5	172
									N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
M8	11.5	102	14.5	128	22	194	27.5	243	32	23.5	40	29.5	37	27.5	47	35
			N•m	lb-ft	N•m	lb-ft	N•m	lb-ft								
M10	23	204	29	21	43	32	55	40	63	46	80	59	75	55	95	70
	N•m	lb-ft														
M12	40	29.5	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	46	80	59	120	88	150	110	175	130	220	165	205	150	260	190
M16	100	74	125	92	190	140	240	175	275	200	350	255	320	235	400	300
M18	135	100	170	125	265	195	330	245	375	275	475	350	440	325	560	410
M20	190	140	245	180	375	275	475	350	530	390	675	500	625	460	790	580
M22	265	195	330	245	510	375	650	480	725	535	920	680	850	625	1080	800
M24	330	245	425	315	650	480	820	600	920	680	1150	850	1080	800	1350	1000
M27	490	360	625	460	950	700	1200	885	1350	1000	1700	1250	1580	1160	2000	1475
M30	660	490	850	625	1290	950	1630	1200	1850	1350	2300	1700	2140	1580	2700	2000
M33	900	665	1150	850	1750	1300	2200	1625	2500	1850	3150	2325	2900	2150	3700	2730
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2770	4750	3500


Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For stainless steel fasteners or for nuts on U-bolts, see the tightening instructions for the specific application. Tighten plastic insert or crimped steel type lock nuts by turning the nut to the dry torque shown in the chart, unless different instructions are given for the specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class. Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^a“Lubricated” means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or M20 and larger fasteners with JDM F13C zinc flake coating.

^b“Dry” means plain or zinc plated without any lubrication, or M6 to M18 fasteners with JDM F13B zinc flake coating.

Electrical Circuit Malfunctions



T7713AD (CV)

T7713AD -19-27FEB92

A—Battery
B—Fuse

C—Switch

D—Light

E—Ground

1. There are four common circuit malfunctions.

- High-Resistance Circuit
- Open Circuit
- Grounded Circuit
- Shorted Circuit

2. Three sections in a simple circuit where these malfunctions can occur:

- Before the controlling switch (C).
- Between the controlling switch and before the component, light (D).

- After the component.

Component malfunctions can easily be confused with circuit malfunctions. Therefore, care must be exercised when isolating the cause of a problem.


Example: Light does not operate or is dim when switch is turned ON, until switch connector is disconnected and reconnected.

Reason: High resistance caused by a dirty switch connector, caused a voltage drop which prevented the proper amount of current from flowing to the light.

DPSG.OU01004,785 -19-19APR99-1/1

05
15
2

High Resistance Circuit



T7713AG (CV)

T7713AG -19-26FEB92

A—Battery
B—Fuse
C—Switch

D—Switch Terminal
E—High Resistance

F—Harness Connector
G—Light Terminal

H—Light
I—Ground

A high resistance circuit can result in slow, dim or no component operation.

Examples: Loose, corroded, dirty or oily terminals.
Wire size too small. Strands broken inside the wire.
Poor ground connection to frame.

To locate the cause of high resistance:

With switch (C) ON, check for battery voltage between switch and ground (I) at an easily accessible location, like harness connector (F).


If less than battery voltage is indicated, check again closer to switch.

If battery voltage is indicated, check closer to ground to locate point of voltage drop. The example shows high resistance (E) between switch and harness connector.

Repair circuit as required. In the example, strands were broken inside the wire. Replace that section of wire.

Repeat check-out procedure after repair.

Open Circuit



T7713AF (CV)

A—Battery
B—Fuse
C—Switch

D—Switch Terminal
E—Harness Connector

F—Open Circuit
G—Light Terminal

H—Light
I—Ground

An open circuit will result in no components operating. Fuse may or may not be blown.

Example: Broken wire, disconnected component terminal, pins inside a connector not making contact, blown fuse, open circuit breaker, failed switch or component, or a disconnected ground wire.

To locate an open circuit:

Check fuse. If blown, replace and operate circuit. If fuse blows a second time, continue check.

With switch (C) ON, check for battery voltage at switch terminal (D).

If no voltage is indicated, check switch, fuse and wiring to battery.

If battery voltage is indicated, check for voltage closer to ground at harness connector (E).

If no voltage is indicated, wire may be broken between switch and connector.

If battery voltage is indicated, inspect connector pins. If pins are OK, check for voltage at light terminal (G).

In the example, zero voltage will be indicated at light terminal, indicating a broken wire between harness connector and light terminal.

If battery voltage had been indicated, the next check for voltage would be at ground connection (I).

Normal indicated voltage at a ground connection should be 0.0 to 0.5 volts.

Continued on next page

DPSG,UO01004,661 -19-15MAR99-1/2

T7713AF -19-27FEB92

Electrical System Basic Information and Wiring Diagrams


05
15
4

If battery voltage is indicated, poor connection to frame or broken wire is indicated.

When problem is located, repair as needed, then repeat last check.

DPSG,OUO1004,661 -19-15MAR99-2/2

Grounded Circuit



T7713AE (CV)

T7713AE -19-27FEB92

A—Battery
B—Fuse
C—Fuse Terminal

D—Switch
E—Switch Terminal
F—Harness Connector

G—Harness Connector
H—Grounded Circuit
I—Light (Component) Terminal

J—Light
K—Ground

If no component operates, the fuse is blown and replacement fuses blow immediately or the circuit breaker is open and reopens when reset, a grounded circuit exists. (Example: power wire contacting frame or other metal component). A wire may be pinched or insulation may be worn from a wire. To isolate the location of a grounded circuit:

If circuit is grounded between battery and fuse, wire will be burned and circuit will be open. Fuse will not be blown.

If fuse is blown, remove fuse from circuit, disconnect circuit near its center, such as harness connector (F). Turn switch (D) ON and check for continuity to ground at harness connector (F). This will check harness from harness connector to fuse.

If continuity to ground is indicated, there is a pinched or bare wire between fuse terminal (C) and harness connector (F).


If continuity to ground does not exist, disconnect ground (K) from frame. Measure continuity to ground at harness connector (G). This checks harness from harness connector to ground terminal. In the example, continuity to ground will exist because circuit is grounded (wire is pinched) at (H).

If continuity exists, disconnect circuit at light terminal (I) and measure continuity to ground on light terminal. This checks harness from light to ground terminal. In the example, continuity will not exist, indicating a grounded circuit between the light and harness connector (G).

05
15
6 Repeat check-out procedure after repair.

DPSG,OUO1004,662 -19-15MAR99-2/2

Shorted Circuit



T7713AH (CV)

T7713AH -19-27FEB92

A—Battery
B—Fuse
C—Fuse
D—Switch

E—Switch Terminal
F—Switch
G—Harness Connector
H—Shorted Circuit

I—Harness Connector
J—Light
K—Light Terminal

L—Light
M—Ground
N—Ground

A shorted circuit causes components in separate circuits to operate when a switch in either circuit is turned ON. (Example: two harnesses rubbing together until insulation is worn through, allowing bare wires to touch). Components can also become shorted. However, shorted components will usually blow the fuse.

To locate a shorted circuit:

Turn switch (F) ON then OFF. Turn switch (D) ON then OFF. Both lights (J and L) will be ON when either switch (D or F) is ON.

Turn switch (F) ON. Both lights (J and L) will be ON; only light (L) should be ON.

Disconnect wire from switch of component that should not be ON. In the example, disconnect wire from terminal (E) at switch (D). Light (J) remains ON.

Disconnect circuit at convenient places like harness connectors (G) and (I) and light terminal (K) until light (J) goes OFF.

The short circuit will be between the last two places the circuit was disconnected. In the example, it is between harness connectors (G and I). Light (J) will go OFF when harness connector (I) is disconnected. Inspect harness between connectors (G and I).

Continued on next page


DPSG,UOU1004,664 -19-15MAR99-1/2

05
15
8
Repair or replace wires and harnesses as needed.
Install tie bands and clamps on harnesses as required
to prevent future problems.

Repeat check-out procedure after repair.

DPSG.OUO1004,664 -19-15MAR99-2/2

Seven Step Electrical Test Procedure



T7719AA (CV)

- | | | | |
|---|---|--------------------------------------|-------------------------------------|
| A—Battery Ground | D—Fuse or Circuit Breaker | G—Battery Side of Component Terminal | I—Ground Side of Component Terminal |
| B—Battery | E—Component Side of Fuse or Circuit Breaker | H—Light (Component) | J—Component Ground |
| C—Battery Side of Fuse or Circuit Breaker | F—Switch | | |

Continued on next page

DPSG.OUO1004,666 -19-15MAR99-1/2

T7719AA -19-05MAR92

Step 1—Switch ON	
Check battery side of circuit breaker (C) for battery voltage.	Battery voltage normal, go to Step 2. Low voltage, repair high resistance. Open circuit from battery.
Step 2—Switch OFF	
Check component side of circuit breaker (E) for battery voltage.	Battery voltage normal, go to Step 4. Low voltage, repair high resistance. No voltage, go to Step 3.
Step 3—Switch OFF	
Check component side of circuit breaker (E) for continuity to ground.	Continuity to ground, repair grounded circuit at or before switch. No continuity to ground, replace circuit breaker.
Step 4—Switch ON	
Check component side of circuit breaker (E) for battery voltage.	Battery voltage normal, go to Step 6. Low voltage, repair high resistance. No voltage, go to Step 5.
Step 5 ^a	
Disconnect wire at battery side of component (G). Switch ON. Check wire at (G) for battery voltage.	Battery voltage, repair component. No voltage, repair grounded or open circuit at or after switch.
Step 6—Switch ON	
Check lead to component at (G) for battery voltage.	Battery voltage normal, go to Step 7. Low voltage, repair high resistance in circuit between fuse and component. No voltage, repair high resistance or open circuit between fuse and component.
Step 7—Switch ON	
Check ground wire of component at (I) for voltage.	No voltage, good continuity to ground, repair component. Voltage, poor continuity to ground, repair high resistance or open ground circuit.
^a A multimeter will not apply a load to the circuit at Step 5. The multimeter result is tested as a voltage condition in the result column.	


DPSG,OUO1004,666 -19-15MAR99-2/2

05
15
10

Multimeter

The multimeter is an autoranging digital display that allows very accurate readings to be taken.

- A—Display
- B—Voltage AC (Alternating Current)
- C—Voltage DC (Direct Current)
- D—Resistance
- E—Diode Test/Continuity
- F—Current AC (Alternating Current)
- G—Current DC (Direct Current)
- H—Voltage, Resistance, Diode/Continuity (Red Lead Input)
- I—Ground (Black Lead Input)
- J—Current/Amps (Red Lead Input)



T8074AA -19-03SEP93

DPSG.OUO1004,665 -19-15MAR99-1/1

Section 10

Delco-Remy Alternators

Contents

	Page		Page
Group 05—Delco-Remy Alternator Theory of Operation		Slip Ring End Housing Assembly	10-15-13
Delco-Remy (Delcotron) Alternator		Final Assembly	10-15-19
Operation	10-05-1		
Delco-Remy (Delcotron) Regulator			
Operation	10-05-1		
 Group 10—Delco-Remy (Delcotron) 10SI, 12SI and 15SI Alternator Repair			
Essential Tools	10-10-1		
Other Material	10-10-2		
Delco-Remy (Delcotron) 10SI, 12SI, and 15SI Charging Circuit Repair			
Specifications	10-10-2		
Delco-Remy (Delcotron) 10SI, 12SI, and 15SI Charging Circuit Test Specifications . . .	10-10-3		
Remove Pulley Nut	10-10-4		
Separate Housing	10-10-5		
Remove Front Bearing	10-10-6		
Install Front Bearing	10-10-7		
Remove and Install Rear Bearing	10-10-8		
Test Rotor for Grounds	10-10-8		
Test Rotor for Open Circuit	10-10-9		
Test Rotor for Short Circuit	10-10-9		
Repair Slip Rings	10-10-10		
Inspect Stator	10-10-10		
Test Stator for Grounds	10-10-11		
Test Stator for Short Circuit	10-10-11		
Test Brush Assembly for Grounds	10-10-12		
Test Diode Trio	10-10-12		
Test Rectifier Bridge	10-10-13		
Regulator Test	10-10-13		
Assemble the Alternator	10-10-14		
 Group 15—Delco-Remy (Delcotron) 21SI Alternator Repair			
Essential Tools	10-15-1		
Delco-Remy (Delcotron) 21SI Charging			
Circuit Repair Specifications	10-15-2		
Delco-Remy (Delcotron) 21SI Charging			
Circuit Test Specifications	10-15-3		
Disassemble Delco-Remy 21SI Alternator	10-15-4		
Disassemble Alternator	10-15-5		
Slip Ring End Housing and Components	10-15-6		
Drive End Frame and Components	10-15-11		
Assemble Alternator	10-15-13		

Delco-Remy (Delcotron) Alternator Operation

The drawing at right shows alternator circuitry. Schematic of regulator (E) has been simplified. The regulator is a non-adjustable, sealed, solid-state unit mounted inside the alternator.


NOTE: To prevent battery run-down, R3 resistor has extremely high resistance. It still allows a constant drain on battery but this is insignificantly small. R3 and R4 are needed to provide voltage differential for turning on transistors.

An alternator (unlike a generator) uses a rotating magnetic field with stationary windings. The magnetic field is externally excited. This means that it requires an outside current source. The rotor (F) consists of two interlocking soft iron sections and a wire coil wrapped around an iron core. When current is passed through the wire coil, the rotor becomes an electromagnet.

The rotating magnetic field induces an alternating current in the stator windings (G). This is converted to direct current by six diodes in the rectifier bridge (H).

A capacitor inside rear housing protects rectifier bridge and diode trio (D) from voltage surges. It also suppresses radio interference.

This alternator uses an "A" field circuit with regulator located after field. Full output is obtained by grounding field.



Delco-Remy (Delcotron) Alternator

- A—Diode
- B—Switch
- C—Battery
- D—Diode Trio
- E—Regulator
- F—Rotor (Field)
- G—Stator
- H—Rectifier Bridge

RG, RG34710, 2025 -19-15MAR97-1/1

Delco-Remy (Delcotron) Regulator Operation

The solid-state regulator is mounted inside the alternator. It controls output by controlling current through field. In operation, regulator has the following three phases.

Continued on next page


RG, RG34710, 2026 -19-18OCT00-1/4

Phase I—Alternator Stopped

(Phase 1 also applies when alternator is running but only if not running fast enough for output to exceed battery voltage.)

1. Current flows from battery through key switch (B) and diode (A) to terminal 1.
2. From there, current flows through resistor R1 to transistor TR1 and turns it on.
3. Transistor TR1 then provides a path to ground so current can flow through field, enabling alternator to generate electricity.
4. Zener diode D2 prevents flow of current from terminal 2 to transistor TR2. A Zener diode is a special type of diode which will not permit current to pass until voltage reaches a certain preset level. If voltage exceeds that level, current can pass through the Zener diode.

- A—Diode
- B—Key Switch
- C—Battery
- D—Diode Trio
- E—Regulator
- F—Rotor (Field)
- G—Stator
- H—Rectifier Bridge



Phase I—Alternator Stopped


RW10107L -UN-29NOV/89

Continued on next page

RG.RG34710,2026 -19-18OCT00-2/4

Phase II—Generating Electricity

1. The diode trio, key switch, rectifier bridge, and terminal 1 all have equal voltage. Therefore no current flows through diode.
2. Current, now coming from diode trio, still flows through resistor R1 to turn on transistor TR1.
3. Transistor TR1 still provides a path to ground so current can flow through field, enabling alternator to generate electricity.
4. Since the field is rotating, it does generate electricity. Alternating current is included in the stator windings. The rectifier bridge converts it to direct current, providing current to run electrical accessories and charge batteries.
5. Output voltage still has not reached critical voltage of Zener diode D2, so no current can flow from terminal 2 to transistor TR2.



Phase II—Generating Electricity

10
05
3


RW10108L -19-28NOV89

Continued on next page

RG, RG34710, 2026 -19-18OCT00-3/4

Phase III—Shut-Off

1. Output voltage reaches critical voltage of Zener diode D2.
2. Current can now pass through Zener diode D2 to turn on transistor TR2.
3. Transistor TR2 now provides a direct path to ground for any current coming through resistor R1.
4. This cuts off the current to transistor TR1, turning it off. There is now no path to ground for current through field.
5. Current through field is shut off instantly, and alternator stops generating electricity.
6. Phase II and III are repeated many times per second to maintain voltage at proper level.



Phase III—Shut-Off

RW10131L -19-28NOV89

RG, RG34710, 2026 -19-18OCT00-4/4

10
05
4

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B4E -19-25APR02-1/5

10
10
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -UN-12DEC88

OUO1004,0000B4E -19-25APR02-2/5

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B4E -19-25APR02-3/5

Alternator Pulley Tool Set JD306A

Remove and install alternator pulley retaining nut.

RG12198 -UN-17JUL02




JD306A

Continued on next page

OUO1004,0000B4E -19-25APR02-4/5

Bushing, Bearing and Seal Driver Set D01045AA

Remove front bearing.



RG11162 -UN-21SEP00

OUC1004,0000B4E -19-25APR02-5/5

Other Material

Number	Name	Use
	Delco-Remy Lubricant No. 1948791	Lubricate alternator bearings.
	400-Grit Silicon Carbide Paper or 00 Sandpaper	Polish slip rings.

OUC1004,0000B50 -19-21SEP00-1/1

Delco-Remy (Delcotron) 10SI, 12SI, and 15SI Charging Circuit Repair Specifications

Item	Measurement	Specification
Delco-Remy Model 12SI Alternator Pulley Nut	Torque	100 N•m (75 lb-ft)
Delco-Remy Model 10SI and 15SI Alternator Pulley Nut	Torque	80 N•m (60 lb-ft)

OUC1004,0000B51 -19-21SEP00-1/1

Delco-Remy (Delcotron) 10SI, 12SI, and 15SI Charging Circuit Test Specifications

John Deere Alternator Part No.	Delcotron Alternator Model No.	Series	Type	Field Current @27°C (80°F)		Cold Output				Rated (Hot) Output at Rated Speed
				Amps	Volts	Amps	RPM	Amps	RPM	Amps
AR54793	1100490	10SI	106	4.0—4.5	12	25	2500	65	5000	72
AR54796	1104901	10SI	106	4.0—4.5	12	25 30 22	2000	51	5000	55
AR56728	1102359	10SI	106	4.0—4.5	12	22	2000	33	5000	37
AR84305	1102926	10SI	116	4.0—5.0	12	30	2000	57	5000	61
AR84306	1102932	10SI	116	4.0—5.0	12	25	2000	65	5000	72
AR93445	1103124	10SI	116	4.0—5.0	12	30	2000	57	5000	61
AR93446	1103128	10SI	116	4.0—5.0	12	25	2000	65	5000	72
AT117390	1105539	15SI	116	4.0—5.0	12	56	2000	110	5000	105
AT130930	1101285	10SI	100	1.2—1.6	24	25	2600	41	7000	40
AT142267	10479850	12SI	100	4.0—5.0	12	51	2000	81	7000	78
AT157177	10480058	10SI	116	4.0—5.0	12	51	2000	81	7000	78
AT157178	10480060	10SI	116	1.2—1.6	24	25	2600	41	7000	40
AT58321	1102936	10SI	116	4.0—5.0	12	30	2000	57	5000	61
AT64718	1103131	10SI	116	4.0—5.0	12	28	2000	42	7000	42
RE13797	1105175	10SI	116	4.0—5.0	12	25	2000	65	5000	72
RE13966	1105068	10SI	116	4.0—5.0	12	30	2000	57	5000	61
RE17379	1105422	10SI	116	4.0—5.0	12	32	2000	60	5000	63
RE20034	1105510	10SI	116	4.0—5.0	24	25	2600	41	7000	40
RE27109	1101268	12SI	100	4.2—5.0	12	30	1600	75	6500	75
RE31694	1101345	12SI	100	4.2—5.0	12	30	1600	78	6500	78
RE501112	19009950	19SI	—	—	12	—	—	110	—	105

Regulator Temperature ^a	Voltage
29°C (85°F)	13.8—14.9 volts
41°C (105°F)	13.6—14.7 volts
52°C (125°F)	13.4—14.6 volts
63°C (145°F)	13.2—14.4 volts

^aMeasured 25.4 mm (1.0 in.) from regulator.

10
10
3

Stator Winding	Field Resistance
37-amp, 12-volt	0.23 ohm
40-amp, 24-volt	0.23 ohm
42-amp, 12-volt	0.28 ohm
55-amp, 12-volt	0.20 ohm
61-amp, 12-volt	0.20 ohm
63-amp, 12-volt	0.20 ohm
72-amp, 12-volt	0.10 ohm
75-amp, 12-volt	0.10 ohm
78-amp, 12-volt	0.10 ohm
105-amp, 12-volt	0.10 ohm
130-amp, 12-volt	0.04 ohm

RG, RG34710, 2031 -19-07JUL05-2/2

Remove Pulley Nut

NOTE: Pulley nut need not be removed if you are certain that front bearing is in good condition. Separate housing as described and leave rotor in front housing.

1. Install a 15/16 in. socket (A) on JD306A-1 Alternator Pulley Nut Tool (B) to hold nut.
2. Install JD306A-2 (C) on hex shaft of JD306A-1 to hold rotor shaft.
3. Hold rotor and remove nut.



Remove Pulley Nut

- A—15/16 in. Socket
- B—JD306A-1 Alternator Pulley Nut Tool
- C—JD306A-2 Alternator Pulley Nut Tool


RW6036 -JUN-15DEC88

RG, RG34710, 2032 -19-12SEP02-1/1

Separate Housing

1. Remove washer (A), pulley (B), fan (C), and collar (D).
2. Before separating, make a chalk mark (E) across separation between front and rear housings for alignment when reassembling. Housings can be indexed any one of four ways.

A—Washer
B—Pulley
C—Fan
D—Collar
E—Chalk mark
F—Nut
G—Through Bolts



Separate Housing


RW10657 -UN-16NOV89

10
10
5

RG,RG34710,2033 -19-15MAR97-1/3

3. Remove four through bolts (A).
4. Separate front and rear housings. If necessary, pry carefully with two screwdrivers on opposite sides to force housings apart.

A—Through Bolts (4 Used)



Separate Front and Rear Housing


RW6011 -UN-22FEB90

Continued on next page

RG,RG34710,2033 -19-15MAR97-2/3

5. Set alternator on rear housing (A) and slide front housing (B) off. Lift out rotor (C).
6. Place a piece of masking tape over rear bearing to keep trash out.

A—Alternator Rear Housing
B—Alternator Front Housing
C—Rotor



Lift Out Rotor

RW6012 -UN-22FEB90


RG, RG34710, 2033 -19-15MAR97-3/3

Remove Front Bearing

Remove bearing retainer (A) and bearing (B).

NOTE: If bearing must be pressed in or out of housing, carefully support housing near bearing diameter. A 1-3/4 in. socket makes a suitable support. Use disk No. 27494 from D01045AA Bushing Driver Set to press on inner diameter of bearing. Press from outside to inside.

A—Bearing Retainer
B—Bearing



Remove Bearing Retainer and Bearing

RW6013 -UN-22FEB90

RG, RG34710, 2034 -19-15MAR97-1/1

Install Front Bearing


Bearing may be reused if not damaged.

1. Clean bearing and fill it 1/4 full with Delco-Remy Lubricant No. 1948791 before assembly. Do not overfill.

NOTE: Lubrication is not required on sealed bearings.

2. Install bearing (B).

A—Bearing Retainer
B—Bearing



Install Front Bearing


RW6013 -UN-22FEB90

10
10
7

RG, RG34710, 2035 -19-12SEP02-1/2

3. Fill cavity between retainer plate (A) and bearing (B) with Delco-Remy No. 1948791 Lubricant.
4. If felt seal (C) is hardened or worn, replace seal and retainer.

A—Retainer Plate
B—Bearing
C—Felt Seal



Replace Retainer


RW6014 -UN-22FEB90

RG, RG34710, 2035 -19-12SEP02-2/2

Remove and Install Rear Bearing

1. Replace rear bearing (A) if defective or its grease supply is exhausted. Do not relubricate.
2. Support housing (B) near bearing diameter with a 1-1/4 in. socket and press bearing to inside.
3. Press new bearing in until flush with housing.

NOTE: If seal is separate from bearing, install a new seal whenever bearing is replaced. Install seal with lip of seal toward rotor when assembled. Coat seal lip with oil when installing rotor shaft.



Rear Bearing

A—Rear Bearing
B—Support Housing


RW6015 -UN-22FEB90

RG,RG34710,2036 -19-18OCT00-1/1

Test Rotor for Grounds

1. Use an ohmmeter (A) or test lamp to test for continuity.
2. Attach ohmmeter to rotor shaft (B) and each slip ring (C).
3. Replace rotor if test shows continuity.

A—Ohmmeter
B—Rotor Shaft
C—Slip Ring



Test Rotor for Grounds


RW6017 -UN-10NOV88

RG,RG34710,2038 -19-15MAR97-1/1

Test Rotor for Open Circuit

1. Use ohmmeter (A) (or test lamp) to test for continuity from one slip ring (B) to the other (C).
2. If test does not show continuity, replace rotor.

A—Ohmmeter
B—Slip Ring
C—Slip Ring



Test Rotor for Open Circuit


RW6018 -UN-10NOV88

10
10
9

RG, RG34710, 2039 -19-15MAR97-1/1

Test Rotor for Short Circuit

1. Connect slip ring (A) to one terminal of 12-volt battery (B).
2. Connect ammeter (C) to other terminal of battery and slip ring (D).
3. Current draw should be 4.0—4.5 amps at 12 volts. Excessive current draw indicates a short circuit. Replace rotor if current draw exceeds 5.0 amps.



Test Rotor for Short Circuit

A—Slip Ring
B—12-Volt Battery
C—Ammeter
D—Slip Ring

RW6019 -UN-25APR89

RG, RG34710, 2040 -19-18OCT00-1/1

Repair Slip Rings

NOTE: Rough or out-of-round slip rings can cause short brush life.

1. Mount rotor assembly on plate.
2. If slip rings are rough or scored, turn them just enough to eliminate roughness. If slip rings are out-of-round, turn them to within 0.005 mm (0.002 in.) of total indicator reading.
3. Polish slip rings sparingly with No. 00 sandpaper or 400-grit silicon carbide paper.


IMPORTANT: Clean rotor and stator with compressed air only. Cleaning solvent will damage insulation.

RG, RG34710, 2041 -19-15MAR97-1/1

Inspect Stator

1. Inspect stator (A) for defective insulation.
2. Check for discoloration or a burned odor indicating a short circuit.
3. Replace stator if you find any defect.

A—Stator



Inspect Stator

RW6020 -UN-10NOV88


RG, RG34710, 2042 -19-15MAR97-1/1

Test Stator for Grounds

Connect an ohmmeter (A) (or test lamp) between each stator (B) lead and stator frame (C). Replace stator if test indicates continuity.

NOTE: The stator cannot be tested for an open circuit unless terminals are disconnected from stator windings.

- A—Ohmmeter
- B—Stator
- C—Stator Frame



Test Stator for Grounds

RW10652 -UN-16NOV89

10
10
11

RG,RG34710,2043 -19-15MAR97-1/1


Test Stator for Short Circuit

A short-circuit in the stator can be difficult to identify. Use an ohmmeter that is sensitive to resistance of 0.0 to 1.0 ohm.

Connect ohmmeter (A) between each pair of terminals (B). Resistance should be approximately 0.1 ohm. (Ohmmeter needle should deflect to zero if leads are touched together.) If resistance is low, windings are shorted and must be replaced.

A stator will occasionally exhibit an open circuit or short circuit only when hot, making the defect even more difficult to diagnose.

If a stator defect cannot be confirmed, re-check all other components. If problem is not found elsewhere, replace stator.



Connect Ohmmeter Between Terminals

- A—Ohmmeter
- B—Terminals

RW6022 -UN-25APR89


RG,RG34710,2044 -19-15MAR97-1/1

Test Brush Assembly for Grounds

A grounded brush assembly results in either no output or uncontrolled output, depending on where the ground is located.

NOTE: A grounded brush assembly may also damage the diode trio. Before assembling alternator, check diode trio.

1. Check insulating washers on screws holding brush leads (A and B). Replace if necessary. If circuit is grounded elsewhere, replace regulator.
2. Connect ohmmeter (or test lamp) between points (B and C) and between points (A and D). Replace brush assembly if either check shows no continuity.



Test Brush Assembly for Grounds

- A—Brush Contact from Diode Trio
- B—Brush Contact from Regulator
- C—Test Point
- D—Test Point

RG, RG34710, 2045 -19-15MAR97-1/1

Test Diode Trio

1. Remove stator and diode trio attaching nuts (A). Note position of any insulating washers.
2. Remove diode trio, noting insulator position.

A—Stator and Diode Trio Attaching Nuts (4 Used)



Stator and Diode Trio

Continued on next page


RG, RG34710, 2046 -19-15MAR97-1/2

3. Connect ohmmeter (or test lamp) to points (A and D). Check for continuity. Reverse leads and test for continuity between same points. A good diode trio will have continuity only in one direction.

Repeat test between points (B and C) and (C and D).

Replace diode trio unless tests show continuity in only one direction in each case.

- A—Terminal
- B—Terminal
- C—Terminal
- B—Terminal



Connect Ohmmeter

RW6025 -UN-22FEB90

10
10
13

RG,RG34710,2046 -19-15MAR97-2/2


Test Rectifier Bridge

NOTE: Rectifier bridge has grounded heat sink (A) and insulated heat sink (E).

Connect ohmmeter (or test lamp) to points A and B. Then reverse leads between same two points. Continuity should be in only one direction.

NOTE: On models 10-SI and 12-SI, connect ohmmeter lead to threaded stud of test points (B), (C), and (D). On all other models, connect ohmmeter by pressing down very firmly onto flat metal connector, and not onto threaded stud.

- A—Grounded Heat Sink
- B—Terminal
- C—Terminal
- D—Terminal
- E—Insulated Heat Sink



Test Rectifier Bridge

RW6026 -UN-22FEB90

RG,RG34710,2047 -19-15MAR97-1/1

Regulator Test

Regulator cannot be effectively tested. Replace regulator if brush assembly tests indicate a failure.

RG,RG34710,2048 -19-15MAR97-1/1

Assemble the Alternator

1. Install rectifier bridge (A). Be sure insulating washers are in position.

A—Rectifier Bridge



Install Rectifier Bridge

RW6027 -UN-22FEB90


RG, RG34710, 2049 -19-15MAR97-1/4

2. Install brush assembly (A) and diode trio (B). Be sure brush assembly insulating screws (C) are in position.
3. Push brushes back to clear slip rings. Insert a wire through hole in rear housing only far enough to hold brushes back.

A—Brush Assembly

B—Diode Trio

C—Brush Assembly Insulating Screws (2 Used)



Install Brush Assembly and Diode Trio


RW6028 -UN-22FEB90

Continued on next page

RG, RG34710, 2049 -19-15MAR97-2/4

- Remove tape over rear bearing and carefully slip rotor (C) into rear housing (A).

A—Rear Housing
 B—Front Housing
 C—Rotor



Slip Rotor into Rear Housing

RW6012 -UN-22FEB90


10
10
15

RG, RG34710, 2049 -19-15MAR97-3/4

- Carefully slip front housing over rotor shaft. Align previously marked chalk mark (E).
- Install four through bolts (G). Alternately tighten bolts until secure.
- Remove wire from housing.
- Install collar (D), fan (C), pulley (B), washer (A) and nut (F). Tighten pulley nut with JD306A Alternator Pulley Tool to specifications.

Specification

Delco-Remy Model 12SI
 Alternator Pulley Nut—Torque 100 N•m (75 lb-ft)
 Delco-Remy Model 10SI and
 15SI Alternator Pulley Nut—
 Torque 80 N•m (60 lb-ft)



Slip Front Housing Over Rotor Shaft

A—Washer
 B—Pulley
 C—Fan
 D—Collar
 E—Chalk Mark
 F—Nut
 G—Bolts

RW10657 -UN-16NOV89

RG, RG34710, 2049 -19-15MAR97-4/4

10
10
16

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B52 -19-21SEP00-1/3

10
15
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B52 -19-21SEP00-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B52 -19-21SEP00-3/3

Delco-Remy (Delcotron) 21SI Charging Circuit Repair Specifications

Item	Measurement	Specification
Delco-Remy Model 21SI Alternator Pulley Nut	Torque	100 N•m (75 lb-ft)
Drive End Bearing Retainer Plate Cap Screws	Torque	3.0 N•m (26 lb-in.)
Slip Ring End Housing Components		
Inside Output Terminal Nut	Torque	5.5 N•m (50 lb-in.)
Rectifier Bridge Attaching Screws	Torque	3.0 N•m (25 lb-in.)
Capacitor Attaching Screw	Torque	2.5 N•m (22 lb-in.)
“R” Terminal Nut	Torque	2.5 N•m (22 lb-in.)
Regulator Mounting Screws	Torque	2 N•m (20 lb-in.)
Regulator Mounting Nut	Torque	2.5 N•m (22 lb-in.)
Brush Holder Pivot Attaching Screw	Torque	2 N•m (20 lb-in.)
Stator Debris Shield Mounting Stud Nut	Torque	5.5 N•m (50 lb-in.)
Rectifier Bridge Nuts	Torque	2.5 N•m (22 lb-in.)
Drive End-to-Slip Ring End Housing Through Bolts	Torque	5.5 N•m (50 lb-in.)

OUC1004,0000BB1 -19-28SEP00-1/1

Delco-Remy (Delcotron) 21SI Charging Circuit Test Specifications

				Field Current @ 27°C (80°F)		Cold Output				Rated (Hot) Output at Rated Speed
John Deere Alternator Model No.	Delcotron Alternator Model No.	Alternator Series	Type	Amps	Volts	Amps	RPM	Amps	RPM	Amps
AT142246	1117909	21SI	355	6.7—7.1	12	50	1600	130	5000	130


Regulator Temperature ^a	Voltage
29°C (85°F)	13.8—14.9 volts
41°C (105°F)	13.6—14.7 volts
52°C (125°F)	13.4—14.6 volts
63°C (145°F)	13.2—14.4 volts
^a Measured 25.4 mm (1.0 in.) from regulator.	

Stator Winding Field	Resistance
130-amp, 12-volt	0.04 ohm

RG, RG34710, 2052 -19-07JUL05-1/1

10
15
3

Disassemble Delco-Remy 21SI Alternator



Delco-Remy 21SI Alternator

- | | | | |
|-----------------------------|-----------------------------|---|---|
| 1—Slip Ring End Housing | 12—Regulator Stud Connector | 22—Pulley | 29—Regulator Attaching Screw (Insulated) |
| 2—Slip Ring End Bearing | 13—"I" Terminal Connector | 23—Regulator Nut | 30—Capacitor Attaching Screw |
| 3—Rotor Assembly | 14—Capacitor | 24—Rectifier Bridge Nut | 31—Bearing Retainer Plate Attaching Screw |
| 4—Stator Assembly | 15—Brush Holder Assembly | 25—Shaft Nut | 32—Slip Ring End Frame Ground Screw and Load Washer |
| 5—Drive End Frame | 16—Brush and Arm | 26—Rectifier Bridge Nut/Washer Assembly | 33—Shaft Nut Washer |
| 6—Drive End Bearing | 17—Drive End Retainer Plate | 27—Brush Holder Attaching Screw (Pivot) | 34—Through Bolt |
| 7—Rectifier Bridge Assembly | 18—Hinge Bushing | 28—Regulator Attaching Screw (Ground) | |
| 8—Diode Trio | 19—Regulator Terminal Cover | | |
| 9—Regulator | 20—Terminal Cap | | |
| 10—BAT Terminal Assembly | 21—Fan | | |
| 11—"I" Terminal Assembly | | | |


RG6894 -UN-30NOV83

RG, RG34710, 2053 -19-15MAR97-1/1

Disassemble Alternator

1. Place alignment mark across slip ring end housing (A), stator housing (B), and drive end frame (C) for assembly after repair.

A—Slip Ring End Housing
 B—Stator Housing
 C—Drive End Frame



Alignment Mark


RG, RG34710, 2054 -19-15MAR97-1/2

RG6971 -UN-30NOV93

10
15
5

2. Remove four through bolts (A).
3. Separate drive end frame (B) (with rotor) from slip ring end housing (C) (with stator). If necessary, carefully pry drive end frame from edge of stator with screwdriver (D). After separation, place tape over slip ring end housing bearing inside unit to prevent dirt from entering bearing.

A—Through Bolts
 B—Drive End Frame
 C—Slip Ring End Housing
 D—Screwdriver



Disassemble Alternator

RG, RG34710, 2054 -19-15MAR97-2/2


RG6972 -UN-30NOV93

Slip Ring End Housing and Components

1. Inspect slip ring end housing (A) for loose connections or other obvious conditions. Correct as necessary. If none are found, proceed with slip ring end housing checks which follow.
2. Remove three rectifier bridge nuts (B) to disconnect stator (C). If necessary, carefully pry stator (C) away from slip ring end housing (A) with a screwdriver (D).
3. Inspect stator windings for dark, burned appearance. View windings from inside of unit; black paint on outside of windings does not indicate burned windings.

If all windings are uniform in color and varnish covering is not flaking off, proceed with electrical check, step 4 below.

If some windings are dark and others are light, a shorted, open, or grounded condition is indicated. Replace the stator. The stator should also be replaced if the windings are uniformly dark and burned, with the varnish flaking off to expose bare wires.



Slip Ring End Housing and Components

- A—Slip Ring End Housing
- B—Rectifier Bridge Nuts
- C—Stator
- D—Screwdriver

RG6973 -JUN-30NOV93


Continued on next page

RG, RG34710, 2055 -19-18OCT00-17

4. Perform electrical check on stator. Use digital multimeter on ohms setting (or a 110-volt test lamp). There should be no continuity between any of the stator leads (A) and the stator laminations (B).

If continuity is present, windings are grounded. Replace stator.

If there is no continuity, stator is probably good. However, there is no service electrical check for shorted or open delta stator windings. If all other electrical checks are normal and the generator did not produce within 15 amps of the rated output, a shorted or open stator is indicated and the stator should be replaced.



Stator Leads and Laminations

- A—Stator Leads
- B—Stator Laminations

RG, RG34710, 2055 -19-18OCT00-27


10
15
7

RG6974 -UN-30NOV93

5. Remove insulated regulator attaching screw (A) to disconnect diode trio (B). Lift diode trio from slip ring end housing assembly.
6. Place the negative ohmmeter lead on regulator strap (C) and use positive ohmmeter lead to check for continuity to each of the three rectifier bridge straps. All three readings should indicate continuity. Reverse the ohmmeter leads and perform the checks again. Readings should all indicate open circuits.

If all readings are proper, diode trio is good.

If any reading is wrong, replace the diode trio.



Check Continuity

- A—Insulated Regulator Screws
- B—Diode Trio
- C—Regulator Strap
- D—Rectifier Bridge Straps

Continued on next page

RG, RG34710, 2055 -19-18OCT00-37

RG6975 -UN-30NOV93


7. Use the digital multimeter to check the rectifier bridge. Rectifier bridge may also be checked while installed in the slip ring end housing. Check rectifier bridge as follows:

Place negative ohmmeter lead on grounded heat sink (A). Touch positive ohmmeter lead firmly to metal diode clips (B) that surround each of the three threaded studs. All three readings should be the same and indicate open circuits. Reverse the ohmmeter leads and perform the checks again. All three readings should indicate continuity.

Repeat checks using insulated (positive) heat sink (C) in place of grounded heat sink. With negative ohmmeter lead on insulated heat sink (C), all three readings should indicate continuity. Reverse the ohmmeter leads and perform the checks again. Readings should all indicate open circuits.

If readings are good, the rectifier bridge is good.

If any reading is wrong, an open or shorted diode is indicated and the rectifier bridge should be replaced.



Check Rectifier Bridge

- A—Grounded Heat Sink
- B—Metal Diode Clips
- C—Insulated (Positive) Heat Sink


RG6976 -UN-30NOV93

Continued on next page

RG, RG34710, 2055 -19-18OCT00-4/7

8. To remove rectifier bridge, remove inside BAT terminal nut (A), regulator nut (B) and regulator stud connector (C) from regulator stud. Remove inside "R" (relay) terminal nut (D) and relay terminal connector (E) (if used), two bridge attaching screws (F), and insulated capacitor attaching screw (G). Lift capacitor (H) and rectifier bridge (I) from slip ring end housing.

- A—BAT Terminal Nut
- B—Regulator Nut
- C—Regulator Stud Connector
- D—Relay Terminal Nut
- E—Relay Terminal Connector
- F—Bridge Attaching Screws
- G—Capacitor Attaching Screw
- H—Capacitor
- I—Rectifier Bridge



Remove Rectifier Bridge

10
15
9

RG6977 -UN-30NOV93


Continued on next page

RG, RG34710, 2055 -19-18OCT00-5/7

9. Brush holder assembly must be removed to service brushes or regulator. Hold brushes (A) in retracted position and insert brush pin (B) to keep brushes in retracted position. Remove insulated regulator attaching screws (C). Remove regulator nut and stud connector (D) (if used). Loosen or remove inside "I" terminal nut (E) to move "I" terminal connector (F) (if used) as necessary for clearance. Finally, remove brush holder pivot screw (G). Lift brush holder assembly (H) from housing without bending regulator connector from diode trio or "I" terminal connector.

10. Check brushes and leads for excessive wear, breakage, etc. If necessary to replace, note routing of lead wires and position of brush lead clips (I) for later assembly. (Brushes are identical but leads and clips are positioned differently.) Carefully remove brush pin (B) to release brushes (A). Remove brushes and spacer (J) one at a time, placing fingers around springs (K) to prevent loss. It may be necessary to spread the brush lead clips slightly to disengage retaining tabs.

11. If previous checks lead to an instruction to replace the regulator (L), replace it. Remove remaining regulator attaching (ground) screw (M).



Brush Holder Assembly

- A—Brush
- B—Brush Pin
- C—Regulator Attaching Screws
- D—Regulator Stud Connector
- E—Inside "I" Terminal Nut
- F—"I" Terminal Connector
- G—Brush Holder Pivot
- H—Brush Holder Assembly
- I—Brush Lead Clip
- J—Spacer
- K—Brush Springs
- L—Regulator
- M—Regulator Attaching Screw

RG6978 -UN-30NOV93

Continued on next page

RG, RG34710, 2055 -19-18OCT00-6/7


- Remove protective tape and check bearing (B) in slip ring end housing (A). If bearing is dry or damaged, replace bearing.

NOTE: Bearings are permanently lubricated. Do not add grease.

To remove bearing, use tube (C) slightly smaller than opening in slip ring end housing and drive bearing through to inside of housing.

NOTE: If bearing is being replaced without removing brushes from slip ring end housing, use brush pin to hold brushes in retracted position while bearing is removed.

- Place tape over bearing until reassembly of alternator.



Check Bearing

- A—Slip Ring End Housing
- B—Slip Ring End Bearing
- C—Tube
- D—Hammer

RG, RG34710, 2055 -19-18OCT00-77

10
15
11

RG6979 -UN-30NOV93

Drive End Frame and Components


- Use digital multimeter to check rotor field resistance. Place ohmmeter leads on two slip rings (A) on the rotor shaft to make this check. Proper resistance is 0.04 ohm.

Also check for a grounded field by touching one lead to a slip ring and one lead to rotor frame (B) or shaft (C). Reading should be infinite (open) to show that field is not grounded.

If field resistance is outside specifications, or if field is grounded, replace rotor as described in the following steps.

- Hold drive end frame (D) and spin rotor by hand to see that it spins freely in ball bearing. If bearing movement is rough or loose, replace bearing in drive end frame as described in the following steps.

NOTE: Bearing is permanently lubricated. Do not add grease.



Drive End Frame and Components


- A—Slip Rings
- B—Rotor Frame
- C—Rotor Shaft
- D—Drive End Frame

Continued on next page

RG, RG34710, 2056 -19-15MAR97-1/2

3. Remove shaft nut (A) by placing a 5/16-in. hex wrench (B) in the end of the shaft to hold the shaft while removing nut with a common wrench (C). Remove shaft nut washer (D), pulley (E) and fan (F) from shaft.
4. Remove rotor (G) from drive end frame (H).
5. If rotor checked good electronically, inspect slip rings. If rough or out of round, turn in lathe (removing only enough material to make rings smooth and round). Maximum indicator reading for roundness is 0.05 mm (0.002 in.). Finish with 400 grain polishing cloth. Blow away all copper dust. Clean shaft of any accumulated grease or copper dust.
6. Remove three attaching screws (I) and bearing retainer plate (J) from drive end frame.
7. Inspect drive end bearing (K). If bearing appears dry, or if rotor did not turn smoothly when checked during alternator disassembly, replace the drive end bearing.

NOTE: Bearing is permanently lubricated. Do not add grease.



Inspect Bearing

- A—Shaft Nut
- B—Hex Wrench
- C—Common Wrench
- D—Shaft Nut Washer
- E—Pulley
- F—Fan
- G—Rotor
- H—Drive End Frame
- I—Attaching Screws
- J—Retainer Plate
- K—Drive End Bearing

RG6981 -UN-30NOV93

RG, RG34710, 2056 -19-15MAR97-2/2

Assemble Alternator

1. Install drive end bearing (K) and bearing retainer plate (J) on drive end frame (H) with three attaching screws (I). Tighten attaching screws to specifications.


Specification

Drive End Bearing Retainer Plate
 Cap Screws—Torque 3.0 N•m (26 lb-in.)

2. Install rotor shaft (G) into drive end bearing.
3. Install fan (F), pulley (E) and shaft nut washer (D) and shaft nut (A) onto rotor shaft. Hold rotor shaft with 5/16-inch hex wrench (B) and tighten shaft nut with common wrench (C). Tighten shaft nut to specifications.

Specification

Delco-Remy Model 21SI
 Alternator Pulley Nut—Torque 100 N•m (75 lb-ft)



Alternator Components

- A—Shaft Nut
- B—Hex Wrench
- C—Common Wrench
- D—Shaft Nut Washer
- E—Pulley
- F—Fan
- G—Rotor
- H—Drive End Frame
- I—Attaching Screws
- J—Retainer Plate
- K—Drive End Bearing


10
15
13
RG6981 -JUN-30NOV93

RG, RG34710, 2057 -19-15MAR97-1/1

Slip Ring End Housing Assembly

1. Install slip ring end bearing (A) into slip ring end housing (B) using appropriate size tube (C). Install bearing flush with outside lip of housing. Cover opening in bearing with tape to prevent entry of dirt.

- A—Slip Ring End Bearing
- B—Slip Ring End Housing
- C—Tube



Slip Ring End Housing Assembly


RG6982 -JUN-30NOV93

Continued on next page

RG, RG34710, 2058 -19-06MAY02-1/10

2. Install rectifier bridge assembly (A) in slip ring end housing (B). Install one rectifier bridge attaching screw (C) through grounded heat sink portion of rectifier bridge as shown. Tighten attaching screw finger-tight.

- A—Rectifier Bridge Assembly
 B—Slip Ring End Housing
 C—Rectifier Bridge Attaching Screw



Install Rectifier Bridge Assembly


RG6983 -UN-30NOV93

RG, RG34710, 2058 -19-06MAY02-2/10

NOTE: Shape of "R" terminal connector determines location of "R" terminal in slip ring end housing.

3. Install relay "R" terminal (A) in slip ring end housing (B). Place inside insulating washer (C) over "R" terminal stud. Place "R" terminal connector (D) over rectifier bridge stud (E) and "R" terminal stud.

NOTE: Be sure inside insulating washer is between connector and slip ring end housing at terminal end. Connector must not touch housing. Also be sure outside insulator is centered in hole to ensure that terminal stud cannot touch housing.



Install Terminal Connectors

RG6984 -UN-30NOV93

4. Install inside nut/washer assembly (F) on "R" terminal stud. Tighten inside nut/washer assembly to specifications.

Specification


"R" Terminal Stud Nut—Torque 2.5 N•m (22 lb-in.)

- A—"R" Terminal
 B—Slip Ring End Housing
 C—Insulating Washer
 D—"R" Terminal Connector
 E—Rectifier Bridge Stud
 F—Inside Nut/Washer Assembly

Continued on next page

RG, RG34710, 2058 -19-06MAY02-3/10

5. Install output (BAT) terminal (A) on slip ring end housing (B). Be sure to seat square insulator flange in hole.
6. Install inside (BAT) terminal nut/washer assembly (C) on terminal stud and tighten finger-tight.
7. Position capacitor over holes in rectifier bridge and install rectifier bridge attaching screw (E) through capacitor connector and grounded heat sink into slip ring end housing. Tighten screw finger-tight.
8. Install insulated capacitor attaching screw (F) through capacitor connector and insulated heat sink into slip ring end housing. Tighten screw finger-tight.



Slip Ring End Housing

- A—Output (BAT) Terminal
- B—Slip Ring End Housing
- C—Inside (BAT) Terminal Nut/Washer Assembly
- D—Capacitor
- E—Rectifier Bridge Attaching Screw (Ground)
- F—Capacitor Attaching Screw (Insulated)


RG.RG34710,2058 -19-06MAY02-4/10

10
15
15

RG6985 -UN-30NOV93

IMPORTANT: Do not immerse or wipe regulator with solvent. Internal damage to regulator could result.

9. Before installing voltage regulator, be sure regulator and regulator mounting bosses in slip ring end housing are free of all dirt and grease. Wipe all contact areas with a clean, dry cloth.
10. Install regulator (A) to slip ring end housing (B) with regulator attaching screw (C) (ground). Tighten screw finger-tight.



Install Regulator

- A—Voltage Regulator
- B—Slip Ring End Housing
- C—Voltage Regulator Attaching Screw

Continued on next page

RG.RG34710,2058 -19-06MAY02-5/10


RG6986 -UN-30NOV93

11. Install brushes (A), springs (B) and spacer (C) on brush holder (D).

NOTE: Brushes are identical, but brush leads and contact clips (E) are positioned differently.

12. Pin brushes in retracted position with brush pin (F).

- A—Brush (with Arm)
- B—Brush Spring
- C—Spacer
- D—Brush Holder
- E—Brush Contact Clip
- F—Brush Pin



Install Brushes, Springs and Spacer

RG6987 -UN-30NOV93

RG, RG34710, 2058 -19-06MAY02-6/10


13. With brushes pinned in retracted position, position brush holder assembly (B) over holes in regulator (C) and slip ring end housing (D). Install brush holder attaching (pivot) screw (E) and one insulated regulator attaching screw (F). Tighten both screws finger-tight.

NOTE: Brush pin (A) must remain in place until final assembly.

Ensure that contact surfaces of brushes are free of grease and dirt.

14. Install diode trio (G) onto three threaded studs on rectifier bridge assembly (H). Position long connector strap on diode trio over mounting hole in brush holder and regulator.

- A—Brush Pin
- B—Brush Holder Assembly
- C—Regulator
- D—Slip Ring End Housing
- E—Brush Holder Attaching (Pivot) Screw
- F—Regulator Attaching Screw (Insulated)
- G—Diode Trio
- H—Rectifier Bridge




Position Brush Holder Assembly

RG6988 -UN-30NOV93

Continued on next page

RG, RG34710, 2058 -19-06MAY02-7/10

15. Hold outside BAT terminal and temporarily remove the inside BAT terminal nut/washer assembly (A). Install regulator stud connector (B) to threaded regulator stud (C) and to inside BAT terminal stud (D). Reinstall inside BAT terminal nut/washer assembly (A) and install regulator nut/washer assembly (E) to regulator stud. Tighten two nuts finger-tight.
16. Install "I" terminal with outside insulator (F) (if used) to slip ring end housing and hold in place. Install inside insulator (G) and "I" terminal connector (H) over "I" terminal stud inside housing. Position other end of "I" terminal connector over mounting hole in brush holder. Install "I" terminal nut/washer assembly (I) onto "I" terminal stud. Tighten nut finger-tight.
17. Install insulated regulator attaching screw (K) to mounting hole in brush holder, passing through diode trio connector (J) and "I" terminal connector (if used). Tighten screw finger-tight.



BAT Terminal

- A—Inside BAT Terminal Nut/Washer Assembly
- B—Regulator Stud Connector
- C—Regulator Stud
- D—BAT Terminal Stud
- E—Regulator Stud Nut/Washer Assembly
- F—"I" Terminal with Outside Insulator
- G—Inside Insulator
- H—"I" Terminal Connector
- I—Inside "I" Terminal Nut/Washer Assembly
- J—Diode Trio Connector
- K—Regulator Attaching Screw (Insulated)

10
15
17


RG6989 -UN-30NOV93

Continued on next page

RG, RG34710, 2058 -19-06MAY02-8/10

18. Tighten the slip ring end housing components in the following order to specifications listed below:

- a. Inside output terminal nut (A).
- b. Rectifier bridge attaching screws (B).
- c. Insulated capacitor attaching screw (C).
- d. "R" terminal nut (D). It may be necessary to hold terminal on outside while tightening.
- e. Regulator mounting screw (E).
- f. Insulated regulator attaching screw.
- g. Regulator nut (G) (if used).
- h. Brush holder attaching (pivot) screw (H).



Slip Ring End Housing Components

- A—Inside Output Terminal Nut
- B—Rectifier Bridge Attaching Screws
- C—Insulated Capacitor Attaching Screw
- D—"R" Terminal Nut
- E—Regulator Mounting Screw
- F—Insulated Regulator Nut (If Used)
- G—Regulator Nut
- H—Brush Holder Attaching (Pivot) Screw

Slip Ring End Housing Components—Specification

Inside Output Terminal Nut (A)—	
Torque	5.5 N•m (50 lb-in.)
Rectifier Bridge Attaching Screws	
(B)—Torque	3.0 N•m (25 lb-in.)
Capacitor Attaching Screw (C)—	
Torque	2.5 N•m (22 lb-in.)
"R" Terminal Nut (D)—Torque.....	2.5 N•m (22 lb-in.)
Regulator Mounting Screws (E)—	
Torque	2 N•m (20 lb-in.)
Regulator Mounting Nut (G)—	
Torque	2.5 N•m (22 lb-in.)
Brush Holder Pivot Attaching	
Screw (H)—Torque.....	2 N•m (20 lb-in.)

RG6890 -UN-30NOV93

Continued on next page

RG, RG34710, 2058 -19-06MAY02-9/10

19. If used, install debris shield mounting stud in slip ring end housing with inside washer to "I" terminal hole in housing. Install outside washer, lock washer and mounting stud on outside of housing. Tighten nut to specifications.

Specification


Stator Debris Shield Mounting
 Stud Nut—Torque 5.5 N•m (50 lb-in.)

20. Install stator (A) in slip ring end housing (B), placing three phase leads (C) over threaded studs (D) on rectifier bridge. Be sure stator is seated in register around edge of slip ring end housing.

21. Install rectifier bridge nuts on threaded studs. Tighten nuts to specifications.

Specification

Rectifier Bridge Nuts—Torque 2.5 N•m (22 lb-in.)



Install Components on Housing

- A—Stator
- B—Slip Ring End Housing
- C—Phase Leads
- D—Threaded Studs on Rectifier Bridge
- E—Rectifier Bridge Nuts

10
15
19

RG6991 -JUN-30NOV93

RG, RG34710, 2058 -19-06MAY02-10/10


Final Assembly

1. Assemble drive end frame assembly (A) and slip ring end housing assembly (B) using alignment marks (C) to ensure proper alignment to parts. Install four through bolts (D) and tighten bolts to specifications.

Specification

Drive End-to-Slip Ring End
 Housing Through Bolts—Torque..... 5.5 N•m (50 lb-in.)

- A—Drive End Frame Assembly
- B—Slip Ring End Housing Assembly
- C—Alignment Marks
- D—Through Bolts



Final Assembly


RG6992 -JUN-30NOV93

Continued on next page

RG, RG34710, 2059 -19-15MAR97-1/2

2. Remove brush pin (A) from slip ring end housing (B) to release brushes onto slip rings inside unit.

A—Brush Pin
B—Slip Ring End Housing



Remove Brush Pin

RG6993 -UN-30NOV93

RG.RG34710.2059 -19-15MAR97-2/2

10
15
20

Section 15

Motorola Alternators

Contents

Page	Page
Group 05—Motorola Alternator Theory of Operation	
Motorola Alternator Operation	15-05-1
Motorola Regulator Operation	15-05-2
Group 10—Motorola 8E-Series Alternator Repair	
Essential Tools	15-10-1
Motorola 8E-Series Charging Circuit Repair	
Specifications	15-10-2
Motorola 8E-Series Charging Circuit Test	
Specifications	15-10-2
General Information	15-10-3
Remove Alternator for Repair	15-10-3
Disassemble and Test Motorola 8E-Series	
(12-Volt, 65 Amp) Alternator	15-10-4
Assemble Motorola 8E-Series	
(12-Volt, 65 Amp) Alternator	15-10-8
Group 15—Motorola HC-, MA-, MR-Series Alternator Repair	
Essential Tools	15-15-1
Service Equipment and Tools	15-15-2
Motorola HC-, MA-, MR-Series Charging	
Circuit Repair Specifications	15-15-2
Motorola HC-, MA-, MR-Series Charging	
Circuit Test Specifications	15-15-3
Disassemble and Test Motorola HC-, MA-,	
MR-Series Alternator	15-15-4
Assemble Motorola HC-, MA-, MR-Series	
Alternator	15-15-20
Group 20—Motorola A-, RA-, 8AR-Series Alternator Repair	
Essential Tools	15-20-1
Motorola A-, RA-, 8AR-Series Charging	
Circuit Repair Specifications	15-20-2
Motorola A-, RA-, 8AR-Series Charging	
Circuit Test Specifications	15-20-2
Disassemble and Test Motorola A-, RA-,	
8AR-Series Alternator	15-20-3
Assemble Motorola A-, RA-, 8AR-Series	
Alternator	15-20-11
Group 25—Motorola SA-Series Alternator Repair	
Essential Tools	15-25-1
Other Material	15-25-2
Motorola SA-Series Charging Circuit Repair	
Specifications	15-25-2
Motorola SA-Series Charging Circuit Test	
Specifications	15-25-3
Remove Alternator for Repair	15-25-3
Disassemble and Test Motorola SA-Series	
Alternator	15-25-4
Assemble Motorola SA-Series Alternator	15-25-14
Group 30—Motorola TA-Series Alternator Repair	
Essential Tools	15-30-1
Service Equipment and Tools	15-30-2
Motorola TA-Series Charging Circuit Repair	
Specifications	15-30-3
Motorola TA-Series Charging Circuit Test	
Specifications	15-30-3
Remove Alternator for Repair	15-30-4
Disassemble and Test Motorola TA-Series	
Alternator	15-30-4
Assemble Motorola TA-Series Alternator	15-30-14


Motorola Alternator Operation

In an alternator, the magnetic field of the rotor is moved across stationary conductors in the stator. This permits permanent connection between the stator windings and the output terminal. Slip rings are used to transmit the field current to the rotor field winding.

The alternator produces power in the form of three-phase alternating current and voltage. The alternating current is rectified to direct current by a three-phase full-wave rectifier circuit using six silicon rectifier diodes. Since the diode will pass current in only one direction (from alternator to battery or load), the alternator does not require the use of cutout relay.

The entire DC output of the system passes through the isolation diode. This provides the system with several distinct advantages. It prevents the battery from discharging through the regulator and alternator field without the use of relays or switches. Electrically, the indicator lamp is connected across the isolation diode. When the system is operating properly, the alternator output voltage is very nearly the same as the battery voltage. This means that the voltage potential across the isolation diode is low and the indicator lamp shows that the alternator is charging.

The alternator output current is controlled by the current flow through the field coil (rotor). The amount of current required is determined and controlled by the regulator. Since there is very little residual magnetism in the alternator, it is necessary to supply a small amount of excitation current to the field (rotor) to start the process of current generation. The excitation resistor supplies this starting current when the key switch is turned on. This resistor is enclosed in the sealed regulator case. Once the alternator is excited, a voltage is developed at the regulator terminal and the voltage regulator takes over control of the system voltage.



Motorola Alternator Operation

- 1—Stator
- 2—Rotor Winding (Field)
- 3—Rotor Slip Ring
- 4—Brushes
- 5—Regulator Terminal
- 6—Output Terminal
- 7—Isolation Diode
- 8—Regulator

T52184 -UN-31MAY89

15
05
1

Motorola Regulator Operation

The transistor regulator is an electronic switching device composed principally of transistors, resistors, and diodes to form a completely static unit containing no moving parts.

The transistors are used to switch the alternator field current on and off, and are controlled by the resistors and the Zener diode.


A Zener diode is a special diode that will break down and permit a reverse flow of current when the voltage reaches a certain value, without damaging the semiconductor material. This diode is the trigger which senses the maximum desired voltage and turns the transistor on or off to limit charging system voltage.

The field discharge diode provides an alternator current path to protect the transistors from induced high voltage from the alternator field windings. The sudden stopping of field current by the transistor and subsequent collapsing of the magnetic field causes an induced voltage in the rotor windings.

The thermistor (RT) is a temperature compensating resistor. Its resistance varies with temperature and controls the operating point of the Zener diode so that a high system voltage is produced in cold weather, when needed, and a lower system voltage in warm weather.

When the voltage appearing at the output terminal of the alternator rises to a predetermined value (14.4 volts), the voltage which appears across the Zener diode conducts. This conduction of the Zener diode permits current to flow in the base of transistor T-1. This causes transistor T-1 to turn on and reverse bias transistor T-2, thus turning off the current applied to the alternator field.

When the system voltage drops below the predetermined value, the Zener diode stops conducting, T-1 turns off and T-2 turns on. When transistor T-2 is switched on, field current again is supplied to the alternator.



Motorola Regulator Operation

- 1—Thermistor (RT)
- 2—Field Discharge Diode
- 3—Transistor (T-2)
- 4—Transistor (T-1)
- 5—Zener Diode
- 6—Excitation Resistor
- 7—To Alternator Indicator Light

T51537 -UN-02JUN89

The operation of transistor T-2 is in effect like a switch, turning the alternator field current on and off as the electrical supply varies due to the varying electrical load. This action occurs many times a second, so fast it cannot be detected in the alternator output.

The solid-state regulator is either mounted on rear of alternator or mounted internally. It controls output by controlling current through field. In operation, regulator has the following three phases.

Continued on next page

RG, RG34710.2061 -19-06MAY02-2/5


15
05
3

Phase 1—Alternator Stopped

(Phase 1 also applies when alternator is turning but only if not running fast enough for output to exceed battery voltage.)

1. Current flows from battery (B) through key switch (C) to regulator (A).
2. From there, current flows through resistors R8, R7, and R1 to transistor Q2, turning it on.
3. Transistor Q2 then provides a path so current can flow through field (E) to ground, enabling alternator to generate electricity.
4. Zener diode D1 prevents flow of current to transistor Q1. A Zener diode is a special type of diode which will not permit current to pass until voltage reaches a certain preset level. If voltage exceeds that level, current can pass through the Zener diode.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase 1—Alternator Stopped

N37761 -JUN-02MAY89


Continued on next page

RG, RG34710, 2061 -19-06MAY02-3/5

Phase II—Generating Electricity

1. The key switch (C) and rectifier bridge diodes (G) all have equal voltage. Therefore, no current flows from key switch to regulator.
2. Current, now coming from rectifier bridge diodes, flows through resistors R7 and R1 to turn on transistor Q2.
3. Transistor Q2 still provides path to ground through field (E), enabling alternator to generate electricity.
4. Since the field is rotating, it does generate electricity. Alternating current is included in the stator windings (F). The rectifier bridge converts it to direct current, providing current to run electrical accessories and charge the battery.
5. Output voltage still has not reached critical voltage of the Zener diode D1.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase II—Generating Electricity

N37762 -JUN-02MAY89

Continued on next page


RG, RG34710, 2061 -19-06MAY02-4/5

15
05
5

Phase III—Shut-Off

1. Output voltage reaches critical voltage of Zener diode D1.
2. Current can now pass through Zener diode D1 to turn on control transistor Q1
3. Current from transistor Q1 cuts off voltage to transistor Q2, turning it off. There is now no path to ground for current through field (E).
4. Current through field is shut off instantly, and alternator stops generating electricity.
5. With transistor Q2 off, system voltage starts to drop in unrestricted fashion until it falls below the Zener diode D1 critical voltage. When this occurs, Zener diode D1 and transistor Q1 switch off and Q2 turns on again.
6. Phase II and III are repeated many times per second to maintain voltage at proper level.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase III—Shut-Off

N37763 -JUN-02MAY89

RG, RG34710, 2061 -19-06MAY02-5/5

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B5A -19-25APR02-1/3

15
10
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JN-12DEC88

OUO1004,0000B5A -19-25APR02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B5A -19-25APR02-3/3

Motorola 8E-Series Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush (24-Volt, 42-Amp)	Minimum Exposed Length	6.4 mm (0.25 in.)
Brush (12-Volt, 65-Amp)	Minimum Exposed Length	4.8 mm (0.189 in.)
Motorola 8E-Series Alternator		
Pulley-to-Shaft Nut	Torque	60 N•m (45 lb-ft)
Rear Housing-to-Front Housing Cap Screws	Torque	7.0—8.3 N•m (50—60 lb-in.)
Bearing Retainer Cap Screws	Torque	3.5—4.8 N•m (25—35 lb-in.)
Output Terminal Nut	Torque	7 N•m (50 lb-in.)
Indicator Light Terminal	Torque	2.3 N•m (20 lb-in.)
Slip Ring-to-Shaft	Torque	40 N•m (30 lb-ft)

OUO1004,0000B59 -19-21SEP00-1/1

Motorola 8E-Series Charging Circuit Test Specifications

John Deere Part No.	Motorola Part No.	Volts	Rated Amps	Output Test Amps (Hot) ^a	Field Current ^b Amps	Winding Resistance ^c Ohms
AT103344	8EM2009NB	12	65	54—62	3.2—3.7	4.0—4.7
AT115049	8EM3002GB	24	42	37—42	1.8—2.3	12.0—13.0
AT125414	8EM2009ND	12	65	54—62	3.2—3.7	4.0—4.7
AT125430	8EM3002GC	24	42	37—42	1.8—2.3	12.0—13.0
RE28186	8EM3002GA	24	42	37—42	1.8—2.3	12.0—13.0

^aOutput test @ 3000—4000 RPM.

^bField current @ 20—27°C (70—80°F); @ 10V for 12V systems and 20V for 24V systems.

^cWinding resistance @ 20—27°C (70—80°F).

RG.RG34710,2066 -19-08SEP00-1/1

General Information

The Motorola 8E-Series charging systems are available in two basic versions on John Deere Engines. One version (12-volt, 65-amp) includes an integral, solid-state voltage regulator. The other version (24-volt, 42-amp) is equipped with a blade terminal for connection to a remote, externally-mounted voltage regulator.

Refer to the proper repair procedure for the charging system used on your John Deere Engine.

15
10
3

RG, RG34710, 2067 -19-15MAR97-1/1

Remove Alternator for Repair


Refer to your machine technical manual for removal of alternator.

IMPORTANT: Never immerse alternator in cleaning solvent. Remove dirt and grease by scraping and using a stiff brush with solvent. Dry with compressed air.

ONLY rosin core solder should be used for soldering operations. The use of acid core solder will result in rapid corrosion of the windings and eventual failure of the complete alternator unit.

RG, RG34710, 2068 -19-15MAR97-1/1

Disassemble and Test Motorola 8E-Series (12-Volt, 65 Amp) Alternator



Motorola 8E-Series Alternator

- | | | | |
|---------------------|-------------------------------|------------------------------------|------------------|
| 1—Nut (2 Used) | 10—Insulating Washer (2 Used) | 18—Rear Housing | 26—Front Bearing |
| 2—Screw (2 Used) | 11—AC Tap Strap | 19—O-Ring | 27—Front Housing |
| 3—Rear Cover | 12—B + Nut | 20—Stator Assembly | 28—Fan Spacer |
| 4—Felt Gasket | 13—Screw (4 Used) | 21—Slip Ring | 29—Fan |
| 5—Nut | 14—Diode Field | 22—Rear Bearing | 30—Pulley |
| 6—D + Strap | 15—Screw (3 Used) | 23—Rotor Assembly | 31—Lock Washer |
| 7—Brush Assembly | 16—Rectifier Diode Bridge | 24—Woodruff Key | 32—Nut |
| 8—Screw (2 Used) | 17—Through Bolt (4 Used) | 25—Bearing Retainer Screw (3 Used) | |
| 9—Voltage Regulator | | | |

T6478AB -UN-02NOV88

Continued on next page

RG.RG34710.2069 -19-15MAR97-17

1. Inspect and test brush assembly. Brush set may be reused if brush length is within specification.

Brush (12-Volt, 65-Amp)—
Minimum Exposed Length 4.8 mm (0.189 in.)

Specification

Brush (24-Volt, 42-Amp)—
Minimum Exposed Length 6.4 mm (0.25 in.)

Brushes must not be oil soaked, cracked or grooved on the sides. Replace defective brush assembly.


RG, RG34710, 2069 -19-15MAR97-2/7

15
10
5

2. Inspect and test diode trio. Test diode for continuity from each of three terminals (A) to D+ stud (B). Continuity must be observed in one direction only.

Replace entire diode trio if any one diode fails test.

A—Diode Terminals
B—D+ Stud



Diode Trio


T6478AD -UN-02NOV88

RG, RG34710, 2069 -19-15MAR97-3/7

3. Inspect and test rectifier bridge. Test for continuity between plate (B) and each of three diode terminals (A). Then test for continuity between terminal (C) and each of the three diode terminals. Continuity should be observed in one direction only, and all diodes should check alike.

Replace entire rectifier bridge if any diode fails test.

A—Terminals
B—Plate
C—Terminal



Test Continuity

T6478AE -UN-02NOV88


Continued on next page

RG, RG34710, 2069 -19-15MAR97-4/7

4. Inspect and test stator. Test for continuity between terminals (A, B and C). There should be no continuity from any terminals (A, B, or C) and laminations (D).

Replace stator if windings show any signs of discoloration.

- A—Terminal
- B—Terminal
- C—Terminal
- D—Laminations




Inspect and Test Stator

RG, RG34710, 2069 -19-15MAR97-5/7

5. Inspect and test rotor assembly. Test resistance between each slip ring (A). Then test for no continuity between each slip ring and pole finger (B).

Slip ring resistance should be 4.0—4.7 ohms @ 20—27°C (70—80°F) for 12-volt systems and 12.0—13.0 ohm for 24-volt system.

- A—Slip Ring
- B—Pole Finger



Inspect and Test Rotor Assembly

Continued on next page


RG, RG34710, 2069 -19-15MAR97-6/7

6. If necessary to replace slip rings, unsolder rotor leads (A) from slip ring terminals. Straighten rotor leads (A) and insert a No. 10 x 1 in. cap screw (B) into center of slip ring assembly. Remove slip ring assembly using a bearing puller.

7. If necessary, remove rear bearing using a bearing puller.

NOTE: Replace bearing if removed.

A—Rotor Leads
B—No. 10 x 1 in. Cap Screw



Unsolder Rotor Leads

T6486AH -UN-02NOV88

15
10
7

RG, RG34710, 2069 -19-15MAR97-7/7

Assemble Motorola 8E-Series (12-Volt, 65 Amp) Alternator

For alternator assembly, the following is a list of special reassembly requirements:

Replace bearings if removed.

Guide rotor leads through one of the oval passages in the slip ring assembly. The oval passages must line up with the groove in the rotor shaft. Solder rotor leads to terminals on slip ring.

Tighten front bearing retainer screws (B) to specifications.

Press front housing down until inner bearing (D) race contacts shoulder on the shaft.

Apply a thin film of heat sink compound to back of diode rectifier bridge (A) and mating surface of rear housing.


Check to be sure felt gasket is installed.

Tighten shaft nut (C) to specifications.

Tighten through bolts (4 used) to specifications.

Motorola 8E-Series—Specification

Pulley-to-Shaft Nut—Torque	60 N•m (45 lb-ft)
Rear Housing-to-Front Housing	
Cap Screws—Torque	7.0—8.3 N•m (50—60 lb-in.)
Bearing Retainer Cap Screws—	
Torque	3.5—4.8 N•m (25—35 lb-in.)
Output Terminal Nut—Torque.....	7 N•m (50 lb-in.)
Indicator Light Terminal—Torque.....	2.3 N•m (20 lb-in.)
Slip Ring-to-Shaft—Torque	40 N•m (30 lb-ft)



Assemble Motorola 8E-Series Alternator

- A—Diode Rectifier Bridge
- B—Front Bearing Retainer
- C—Shaft Nut
- D—Inner Bearing

T6493BC -UN-09DEC88

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B5C -19-25APR02-1/3

15
15
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B5C -19-25APR02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B5C -19-25APR02-3/3

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000BBE -19-18OCT00-1/2

Battery Load Tester JT28001

Test rotor windings.

OUO1004,0000BBE -19-18OCT00-2/2

Motorola HC-, MA-, MR-Series Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush	Minimum Exposed Length	6.4 mm (0.25 in.)
Slip Ring Retainer Cap Screw	Torque	5.1 N•m (45 lb-in.)
Fan Pulley-to-Shaft Nut	Torque	47—68 N•m (35—50 lb-ft)
Stator Stud Lock Nuts	Torque	3.5—4.5 N•m (33—40 lb-in.)
Housing Through Bolts	Torque	5.5—7.0 N•m (50—60 lb-in.)
Brush Assembly Mounting Screws	Torque	2.5—3.5 N•m (20—30 lb-in.)
Regulator Mounting Cap Screws	Torque	4.5—5.0 N•m (40—45 lb-in.)
Isolation Diode Nuts	Torque	2.5—3.5 N•m (20—30 lb-in.)
Alternator Terminal Nuts	Torque	2.5—3.5 N•m (20—30 lb-in.)

OUO1004,0000BB2 -19-28SEP00-1/1

Motorola HC-, MA-, MR-Series Charging Circuit Test Specifications

John Deere Part No.	Motorola Part No.	Volts	Rated Amps	Output Test ^a Amps (Hot)	Field Current ^b Amps	Winding Resistance ^c Ohms
AH112211	8MR2030T	12	90	79—82	4.10—4.40	2.3—2.4
AR40420	70D44110C01	12	55	—	—	—
AR43989	8MA2003PA	12	72	—	1.8—2.0	5.0—5.4
AR50909	8MR2012P	12	72	—	1.8—2.0	5.0—5.4
AR52077	8MR2012PS,MA12JD602	12	70	—	1.8—2.0	5.0—5.4
AR52078	8HC2003PS	12	72	—	1.8—2.0	5.0—5.4
AR53261	70D44086B05	12	35	—	—	—
AT21618	A12NJD454	12	35	—	1.95—2.55	4.2—5.5
AT28453	MA12NJD603	12	55	43—46	1.65—2.25	4.0—5.2
AT31668	70D44160B	12	22	—	—	—
AT31670	8MA2002KS	12	51	43—46	1.65—2.55	4.0—5.2
AT41951	70D44725C03	12	37	—	—	—
AT44644	8HC3010G	24	42	30	1.28—1.88	11.0—14.0
AT49446	8HC3010G	24	42	30	1.28—1.88	11.0—14.0
AT55539	8HC2015L, 8HC2012F	12	62	51—54	2.10—2.50	4.1—4.7
RE50811	8MR2069T	12	90	79—82	4.10—4.40	2.3—2.4


^aOutput test @ 3000—4000 RPM.

^bField current @ 20—27°C (70—80°F); @ 10V for 12V systems and 20V for 24V systems.

^cWinding resistance @ 20—27°C (70—80°F).

15
15
3

Disassemble and Test Motorola HC-, MA-, MR-Series Alternator




HC-, MA-, MR-Series with Isolation Diode

- | | | | |
|---------------------------|-------------------------|---------------------|-----------------|
| 1—Cover | 11—Nut (6 Used) | 21—Positive Ring | 30—Rotor |
| 2—Tie Strap | 12—Lock Washer (5 Used) | 22—Negative Ring | 31—Key |
| 3—Screw (2 Used) | 13—Washer (4 Used) | 23—Insulator | 32—Retainer |
| 4—Lock Washer | 14—Diode, Isolation | 24—Bolt | 33—Housing |
| 5—Regulator | 15—Sleeve | 25—Stator | 34—Nut (4 Used) |
| 6—Gasket | 16—Washer (2 Used) | 26—O-Ring | 35—Spacer |
| 7—Screws (2 Used) | 17—Housing | 27—Screw | 36—Fan |
| 8—Brush Holder | 18—Capacitor | 28—Ring | 37—Lock Washer |
| 9—Isolator | 19—Bushing (2 Used) | 29—Bearing (2 Used) | 38—Nut |
| 10—Through Bolts (4 Used) | 20—Wiring Lead | | |

N38152 -UN-22SEP88

Continued on next page

RG, RG34710, 2073 -19-06MAY02-1/30



HC-, MA-, MR-Series With Diode Trio

- | | | | |
|--------------------------|------------------------------|---------------------|------------------|
| 1—Screen | 10—Lock Washer (6 Used) | 19—Rectifier Diode | 28—Retainer |
| 2—Tie Strap | 11—Isolation Washer (7 Used) | 20—Isolation Diode | 29—Front Housing |
| 3—Screw (4 Used) | 12—Rear Housing | 21—Bolt | 30—Square Nuts |
| 4—Regulator | 13—Capacitor | 22—Stator | 31—Spacer |
| 5—Gasket | 14—Washer | 23—Screw | 32—Fan |
| 6—Screws (2 Used) | 15—Spacer | 24—Slip Rings | 33—Washer |
| 7—Brush Holder | 16—Nuts (2 Used) | 25—Bearing (2 Used) | 34—Nut |
| 8—Through Bolts (4 Used) | 17—Diode Plate | 26—Rotor Assembly | 35—O-Ring |
| 9—Nuts (5 Used) | 18—Diode Trio | 27—Key | |

N38456 -JUN-22SEP88


Continued on next page

RG.RG34710.2073 -19-06MAY02-2/30

IMPORTANT: Voltage regulator wires must be disconnected before testing diodes to obtain accurate results.

1. Disconnect voltage regulator wires on regulator (A), negative output (B) and positive output (C) terminals.

A—Voltage Regulator
B—Negative Output Wire
C—Positive Output Wire



Output Terminals


T6558A1 -UN-02NOV88

RG,RG34710,2073 -19-06MAY02-3/30

IMPORTANT: The diode test position must be used on meters to get accurate results. Follow manufacturer's instructions for your meter to test diodes.

2. Test positive and negative diodes in both directions using an ohmmeter. Put one probe on a diode lead (B) and the other probe on diode plate (A) to get a reading.

A diode with a high reading in one direction and a low reading in the other direction is good. A diode with the same reading in both directions is bad and should be replaced.



Test Diodes

A—Diode Plate
B—Diode Lead

T84666 -UN-07NOV88

Continued on next page

RG,RG34710,2073 -19-06MAY02-4/30

NOTE: Illustration shows alternator equipped with an isolation diode plate. Some applications do not use this plate.

3. Check isolation diode using volt-ohm-amp meter with selector indicator in diode test position.

The meter must register OL in one direction and approximately 0.50 volts in the other. If it does not, replace diode.




Alternator with Isolation Diode Plate

RG, RG34710, 2073 -19-06MAY02-5/30

4. Loosen regulator cap screws (A). Remove two nuts to remove isolation diode plate, if equipped.

A—Regulator Cap Screws (4 Used)




Regulator Cap Screws

Continued on next page

RG, RG34710, 2073 -19-06MAY02-6/30

5. Remove sleeve (C), insulator washer (B) and regulator wires (A) from alternator terminals.

A—Regulator Wires
B—Insulator Washer
C—Sleeve



T6015AT -UN-06APR90

Remove Sleeve, Washer, and Wires

RG, RG34710, 2073 -19-06MAY02-7/30

6. Test the three negative diodes with selector in diode test position.

Touch one probe to a diode and the other probe to the ground terminal. Take reading. Reverse probes (A) and take another reading.

The meter must register OL in one direction and approximately 0.50 volts in the other on all three diodes. If it does not, replace the negative diode plate.

A—Meter Probes



T6015AL -UN-06APR90

Test Negative Diodes

Continued on next page

RG, RG34710, 2073 -19-06MAY02-8/30

7. Test the three positive diodes (A) with selector in diode test position.

Touch one probe to a diode (A) and the other probe to diode plate post. Take reading. Reverse probes and take another reading.

The meter must register OL in one direction and approximately 0.50 volts in the other on all three diodes. If it does not, replace the positive diode plate.

A—Three Positive Diodes



Test Positive Diodes

T6015AM -UN-06APR90

15
15
9


RG,RG34710,2073 -19-06MAY02-9/30

8. Check the stator windings for continuity.

Touch one probe to a diode (A) and the other probe to each of the other two diodes (B) attached to the same diode plate. Repeat step for other diode plate.

If there is no continuity in any of the connections, there is an open circuit in the stator windings and the stator must be replaced.

A—Diode
B—Two Diodes



Check Stator Windings

T6015AD -UN-06APR90

Continued on next page

RG,RG34710,2073 -19-06MAY02-10/30

9. Check stator for a grounded winding.

Touch one probe to a diode (A) and the other probe to the rear alternator housing (B). Take reading. Reverse probes and take another reading.

The meter must register continuity in one direction only. If continuity is registered in both directions, a stator winding is grounded and the stator must be replaced.

- A—Diode
- B—Rear Alternator Housing



Check Stator for Grounded Winding


T6015BA -UN-06APR90

RG, RG34710, 2073 -19-06MAY02-11/30

10. Remove screws and disconnect wire (A) to remove regulator.

11. Remove cap screws (B) to remove brushes.

- A—Wire
- B—Cap Screws (2 Used)



Remove Regulator and Brushes


T6015AY -UN-06APR90

RG, RG34710, 2073 -19-06MAY02-12/30

12. Check the condition of the springs, connections, and for free movement of the brushes. If either brush is worn to less than specified length, or is cracked or oil soaked, replace the brush assembly.

Specification

Brush—Minimum Exposed Length..... 6.4 mm (0.25 in.)



Check Movement of Brushes


T84656 -UN-07NOV88

Continued on next page

RG, RG34710, 2073 -19-06MAY02-13/30

13. Check for continuity between terminal (A) and brush (B) and bracket (C) and brush (D). If there is no continuity at either brush, replace the brush assembly.
14. Check for continuity between terminal (A) and bracket (C). If there is continuity, replace the brush assembly.
15. Check for continuity between terminal (A) and brush (D). If there is continuity, replace the brush assembly.

A—Terminal
B—Brush
C—Bracket
D—Brush



Check for Continuity

T87568 -UN-23FEB90

15
15
11


RG,RG34710,2073 -19-06MAY02-14/30

16. Check rotor windings for continuity (a low resistance reading will be seen) using an ohmmeter.

If there is no continuity (open circuit), check soldered connections (A). If connections are good, replace rotor.

NOTE: Place meter probes on edges of slip rings to prevent scratching brush contact area.

A—Soldered Connections




Check Soldered Connections

T84674 -UN-07NOV88

Continued on next page

RG,RG34710,2073 -19-06MAY02-15/30

17. Check for grounded rotor windings. If there is continuity (short circuit), replace rotor.



T6015AE -UN-06APR90

Check for Grounded Rotor Windings

RG, RG34710, 2073 -19-06MAY02-16/30

18. Remove nut and isolation washer. Disconnect wiring lead (A).

19. Remove four cap screws to remove rear housing cover.

NOTE: Some units use square nuts with the through bolts; others have threaded holes in the front housing.

A—Wiring Lead



T6015AP -UN-06APR90

Disconnect Wiring Lead

RG, RG34710, 2073 -19-06MAY02-17/30

IMPORTANT: Inserting screwdriver blades farther than 1.6 mm (1/16 in.) may damage stator windings.

20. Carefully insert two screwdriver blades (A) in opposite openings between the stator and front housing and separate the front housing from the rear.

A—Two Screwdriver Blades



T87572 -UN-23FEB90

Insert Screwdriver Blades

Continued on next page

RG, RG34710, 2073 -19-06MAY02-18/30

21. Put identification tags on wiring leads to aid assembly.
22. Unsolder wiring leads from diode leads, as necessary, to replace diode assemblies, diode trio or stator. Use needle-nose pliers as a heat sink on the leads of good diodes to protect them from too much heat.

Remove nut and insulating washers from regulator terminal stud to remove diode trio from positive diode assembly plate. Note location of insulating washers for reassembly.




Unsolder Wiring Leads

23. When soldering wiring leads to diodes, use needle nose pliers as a heat sink to protect diodes from too much heat. Use rosin core solder only.
24. Be sure to install insulating washer under nut when diode trio is installed.

RG, RG34710, 2073 -19-06MAY02-19/30

For alternators equipped with a diode trio:

25. Using a commercial diode tester, volt-ohm-amp meter with diode test position, or 12-volt DC test lamp, check for continuity from each lead separately to center contact stud. Continuity should be observed in one direction only. All three diodes should check alike.
26. If any diode is defective, replace entire diode trio assembly.



Commercial Diode Tester

Continued on next page

RG, RG34710, 2073 -19-06MAY02-20/30


T89073 -UN-21FEB90

15
15
13

N38452 -UN-22SEP88

27. Clamp pulley in vise using an over-sized belt to protect pulley. Remove nut to remove pulley and fan.

Inspect parts for wear or damage.




T89074 -UN-21FEB90

Remove Pulley and Fan

RG, RG34710, 2073 -19-06MAY02-21/30

28. Remove the front bearing retainer (A) by compressing ears of bearing retainer with a long-nosed pliers and lifting retainer free of recess. On HC and MR units, remove three front bearing retainer screws and lock washers.

A—Front Bearing Retainer



T87605 -UN-23FEB90

Remove Front Bearing Retainer

RG, RG34710, 2073 -19-06MAY02-22/30

29. Use a plastic hammer to remove rotor and bearing from front housing. If front housing has felt dust seals pressed in casting, replace with new seals.




T87606 -UN-23FEB90

Remove Rotor and Bearing

Continued on next page

RG, RG34710, 2073 -19-06MAY02-23/30

30. Use a suitable bearing puller to remove front bearing.



T87607 -UN-23FEB90

Remove Front Bearing

Continued on next page

RG, RG34710, 2073 -19-06MAY02-24/30


15
15
15

31. Connect a voltmeter (A) to slip rings. (Make sure slip rings are clean.)
32. Connect an ammeter (D), a variable resistor (B), and 12-volt power source (C) in series. Attach to slip rings.

NOTE: Use a second volt-ohm-amp meter for the ammeter, and JT28001 Battery Load Tester as the variable resistor.

33. Set battery load tester to maximum resistance.
34. Connect other slip ring to the power source.
35. Adjust battery load tester to obtain full battery voltage.

IMPORTANT: Do not remove rotor leads from slip rings at this time. It will cause an arc, damaging slip ring surface.



Voltmeter and Ammeter

- A—Voltmeter
- B—Variable Resistor
- C—12-Volt Power Source
- D—Ammeter

N37053 -UN-22SEP88

ROTOR WINDING TEST SPECIFICATIONS [Measured at 21—27°C (70—80°F)]

System Voltage	Rated Amps	Current Draw (Amps) ^a	Winding Resistance (Ohms)
12	37	1.95—2.55	4.2—5.5
12	51/55	1.65—2.55	4.0—5.2
12	62	2.1—2.5	4.1—4.7
12	72	1.8—2.0	5.0—5.4
12	90	4.1—4.4	2.3—2.4
24	42	1.28—1.88	11.0—14.0

^aCurrent draw at 10V for 12-Volt systems and 20V for 24-Volt systems.

Shorted windings are indicated by excessive current draw, and open windings by no current draw.


Continued on next page

RG, RG34710, 2073 -19-06MAY02-25/30

36. Check rotor for grounds between each slip ring and rotor shaft, using ohmmeter (A) or test lamp.

Ohmmeter resistance reading should be high (infinite) or test lamp should not light. If resistance is low or test lamp lights, short exists between field coil and rotor. Replace rotor.

A—Ohmmeter



Ohmmeter or Test Lamp

N35990 -UN-22SEP88

15
15
17

RG,RG34710,2073 -19-06MAY02-26/30

37. Inspect rotor shaft and body for stripped threads on shaft, worn key slot, worn bearing surface, scuffed pole fingers, or worn or dry bearing.

Replace rotor assembly if any of the above faults are found.

NOTE: New rotors include new rear bearings and slip rings.

38. Unsolder rotor leads from slip ring terminals.

IMPORTANT: Do not overheat slip ring terminals.

39. Carefully unwind ends of rotor coil leads from slip ring terminals.



Inspect Rotor Shaft and Body

N8516201 -UN-22SEP88


Continued on next page

RG,RG34710,2073 -19-06MAY02-27/30

40. Remove hex countersunk head screw (A) from end of shaft.

41. Thread a 1/4 x 1 in. cap screw into slip ring hub. This will back slip ring assembly (B) off shaft.

A—Hex Countersunk Head Screw
B—Slip Ring Assembly



N85162P1 -UN-22SEP88

Remove Screw and Slip Ring Assembly


RG,RG34710,2073 -19-06MAY02-28/30

42. Place rotor leads (B) away from bearing puller contact area.

43. Using bearing puller (C), remove rear bearing (A).

NOTE: Remove bearing only if it will be replaced.

A—Rear Bearing
B—Rotor Leads
C—Bearing Puller



N29582NY -UN-03MAR89

Remove Rear Bearing


Continued on next page

RG,RG34710,2073 -19-06MAY02-29/30

44. Examine stator for discoloration or a burned odor indicating overheating from shorted windings. Stator should be checked further with low resistance (0—1 ohm) ohmmeter before it is replaced.
45. Disconnect stator leads from diode assemblies and check resistance from each lead to stator frame. If reading is not infinite, a winding is grounded.
46. Carefully zero the ohmmeter and connect the leads between A and B.

The meter reading should be 0.6 ohms. An infinite or high reading indicates an open-circuited winding.


47. While measuring the resistance between A and B, touch AA and BB leads together. If ohmmeter pointer does not drop to 0, the windings are shorted.
48. Repeat steps 3 and 4 with leads connected to A and C, then to B and C.
49. When replacing stator, connect leads A to B, AA to C, and BB to CC. Connect to diode assemblies.



Stator Leads

- A—Stator Lead
- B—Stator Lead
- C—Stator Lead
- AA—Stator lead
- BB—Stator Lead
- CC—Stator Lead

Assemble Motorola HC-, MA-, MR-Series Alternator




HC-, MA-, MR-Series with Isolation Diode

- | | | | |
|---------------------------|-------------------------|---------------------|-----------------|
| 1—Cover | 11—Nut (6 Used) | 21—Positive Ring | 30—Rotor |
| 2—Tie Strap | 12—Lock Washer (5 Used) | 22—Negative Ring | 31—Key |
| 3—Screw (2 Used) | 13—Washer (4 Used) | 23—Insulator | 32—Retainer |
| 4—Lock Washer (2 Used) | 14—Diode, Isolation | 24—Bolt | 33—Housing |
| 5—Regulator | 15—Sleeve | 25—Stator | 34—Nut (4 Used) |
| 6—Gasket | 16—Washer (2 Used) | 26—O-Ring | 35—Spacer |
| 7—Screws (2 Used) | 17—Housing | 27—Screw | 36—Fan |
| 8—Brush Holder | 18—Capacitor | 28—Ring | 37—Lock Washer |
| 9—Isolator | 19—Bushing (2 Used) | 29—Bearing (2 Used) | 38—Nut |
| 10—Through Bolts (4 Used) | 20—Wiring Lead | | |

N38152 -UN-22SEP88

Continued on next page

RG, RG34710, 2074 -19-15MAR97-1/21



HC-, MA-, MR-Series with Diode Trio

- | | | | |
|--------------------------|------------------------------|---------------------|------------------|
| 1—Screen | 10—Lock Washer (6 Used) | 19—Rectifier Diode | 28—Retainer |
| 2—Tie Strap | 11—Isolation Washer (7 Used) | 20—Isolation Diode | 29—Front Housing |
| 3—Screw (4 Used) | 12—Rear Housing | 21—Bolt | 30—Square Nuts |
| 4—Regulator | 13—Capacitor | 22—Stator | 31—Spacer |
| 5—Gasket | 14—Washer | 23—Screw | 32—Fan |
| 6—Screws (2 Used) | 15—Spacer | 24—Slip Rings | 33—Washer |
| 7—Brush Holder | 16—Nuts (2 Used) | 25—Bearing (2 Used) | 34—Nut |
| 8—Through Bolts (4 Used) | 17—Diode Plate | 26—Rotor Assembly | 35—O-Ring |
| 9—Nuts (5 Used) | 18—Diode Trio | 27—Key | |

N38456 -JUN-22SEP88


Continued on next page

RG, RG34710, 2074 -19-15MAR97-2/21

1. Support pulley end of rotor on base of press assembly.

NOTE: Use new front and rear bearings for reassembly of alternator.

2. Using push-puller, leg extensions, and bearing puller attachment, and pressing only on inner bearing race, press bearing on shaft until inner race contacts the shaft shoulder.




N38455 -UN-22SEP88

Install Bearing

RG, RG34710, 2074 -19-15MAR97-3/21

3. Guide rotor windings through one passage in slip ring hub.
4. Hand press slip rings (B) on shaft while maintaining alignment of winding leads and passage.
5. Tighten hex countersunk head screw (A) to specifications.



N85162P1 -UN-22SEP88

Slip Rings and Head Screw

Specification

Slip Ring Retainer Cap Screw—	
Torque	5.1 N•m (45 lb-in.)

- A—Hex Countersunk Head Screw
- B—Slip Rings

Continued on next page

RG, RG34710, 2074 -19-15MAR97-4/21

6. Install a fiber washer on the non-soldered terminal of slip rings. This is to prevent the inner slip ring from touching the outer slip ring, causing a short.
7. Wrap leads (A) around slip ring terminals, and solder with rosin core solder. Do not overheat.

IMPORTANT: ONLY rosin core solder should be used for soldering operations. The use of acid core solder will result in rapid corrosion of the windings and eventual failure of the complete alternator unit.

8. Secure wires to end of rotor with a synthetic sealer.
9. Retest rotor assembly to ensure that a ground or short circuit did not develop during repair.

A—Wire Leads



Wrap Leads around Slip Ring Terminals

RG.RG34710,2074 -19-15MAR97-5/21

10. For MA and MR units, install sleeve (A) into either side of front ball bearing using a 32 mm disk. Push flange of sleeve tight against bearing race.

A—Sleeve




Install Sleeve

Continued on next page

RG.RG34710,2074 -19-15MAR97-6/21

11. Install felt seal (A) and washer (B) (if used) into front housing.

A—Felt Seal
B—Washer



T84587 -UN-07NOV88

Install Felt Seal and Washer

RG, RG34710, 2074 -19-15MAR97-7/21

12. Install front ball bearing (A) into front housing so sleeve flange is toward rotor. Push bearing to the bottom of bore.

A—Front Ball Bearing




T84588 -UN-07NOV88

Install Front Ball Bearing

RG, RG34710, 2074 -19-15MAR97-8/21

13. Place bearing retainer in housing recess, with ears upward and aligning them with opening in housing. Use a wooden dowel to exert pressure on retainer while locking retainer in recess.



T87609 -UN-23FEB90

Bearing Retainer in Housing Recess

Continued on next page

RG, RG34710, 2074 -19-15MAR97-9/21

14. For HC and MR units, assemble front bearing and sleeve as follows:


NOTE: There are two variations of assembly depending on the dimension (A).

If the dimension of bore (A) is 35.6 mm (1.40 in.), install the front bearing and sleeve assembly (B) in the housing and secure with bearing retainer (C), three retainer screws (D) and lock washers (E).


If the dimension of bore (A) is 46.9 mm (1.847 in.), the felt seal (F) must be installed flush with outer surface of housing. Remove outer bearing seal (G) from bearing before installing bearing and sleeve assembly in housing. Place felt seal (H) against bearing retainer (C). Secure bearing retainer (C) with three retainer screws (D) and lock washers (E).

NOTE: Extra grease may be placed between the outer felt seal and the bearing.

- A—Housing Bore Dimension
- B—Bearing and Sleeve Assembly
- C—Bearing Retainer
- D—Retainer Screws
- E—Lock Washers
- F—Felt Seal
- G—Outer Bearing Seal
- H—Felt Seal



35.6 mm (1.40 in.)



46.9 mm (1.847 in.)

RG, RG34710, 2074 -19-15MAR97-10/21

15. Using a hollow drive that contacts inner bearing race only, press front housing onto rotor shaft until bearing race contacts shaft shoulder.




Press Front Housing onto Rotor Shaft

Continued on next page

RG, RG34710, 2074 -19-15MAR97-11/21

16. Install spacer (A) and woodruff key (B).

A—Spacer
B—Woodruff Key



T89075 -UN-21FEB90


Install Spacer and Woodruff Key

RG, RG34710, 2074 -19-15MAR97-12/21

17. Install fan, pulley, lock washer, and hex nut. Clamp pulley in vise using an old over-sized belt to protect pulley and tighten nut to specifications.

Specification

Fan Pulley-to-Shaft Nut—Torque 47—68 N•m (35—50 lb-ft)



T89076 -UN-21FEB90

Tighten Nut

Continued on next page

RG, RG34710, 2074 -19-15MAR97-13/21

18. Install O-ring. Lubricate the exposed area of the O-ring with hydraulic brake fluid only.

DO NOT use oil.



Install O-Ring

T6015AJ -UN-06APR90

15
15
27

RG, RG34710, 2074 -19-15MAR97-14/21

19. Install insulator washer (A) and cap screw.

A—Insulator Washer



Install Insulator Washer and Cap Screw

T89077 -UN-21FEB90


Continued on next page

RG, RG34710, 2074 -19-15MAR97-15/21

20. Install insulator washers (A) and sleeves (B).

IMPORTANT: To prevent shorting or grounding, position stator leads away from through bolts and sharp corners of diode assemblies. Squeeze rear housing and stator together to check wire positions.

A—Insulator Washers
B—Sleeves



Insulator Washers and Sleeves

T89089 -UN-21FEB90

RG, RG34710, 2074 -19-15MAR97-16/21

21. Install rear housing on stator.

22. Install capacitor, if equipped.

23. Install insulating washers (B), wire lead (A) and four nuts (C). Tighten nuts to specifications.

Specification

Stator Stud Lock Nuts—Torque 3.5—4.5 N•m (33—40 lb-in.)


24. Install rear housing and stator on the front housing. Line up screw holes.

25. Install four through bolts (D) and square nuts, if used. Tighten bolts evenly to specifications.

Specification

Housing Through Bolts—Torque..... 5.5—7.0 N•m (50—60 lb-in.)

NOTE: Spin rotor shaft by hand to ensure bearings are not binding.



Rear Housing

A—Wire Lead
B—Insulating Washers
C—Nuts (4 Used)
D—Through Bolts (4 Used)

T6015AR -UN-06APR90

Continued on next page

RG, RG34710, 2074 -19-15MAR97-17/21

- 26. Install brush assembly (HC/MR unit shown).
- 27. Install and tighten screws (B) to specifications.


Specification

Brush Assembly Mounting

Screws—Torque..... 2.5—3.5 N•m (20—30 lb-in.)

- 28. Connect regulator wire (A) to brush terminal.

- A—Regulator Wire
- B—Screws (2 Used)



HC/MR Unit Shown


T6015AC -UN-06APR90

15
15
29

RG,RG34710,2074 -19-15MAR97-18/21

- 29. Install regulator wires (A). Install insulator washer (B) and sleeve (C).

- A—Regulator Wires
- B—Insulator Washer
- C—Sleeve



Install Wires, Washer, and Sleeve

T6015AT -UN-06APR90

Continued on next page

RG,RG34710,2074 -19-15MAR97-19/21

30. Install isolation diode plate and insulation washer (B) at negative terminal, if equipped.


IMPORTANT: The negative terminal post must be isolated from diode plate.

31. Install and tighten regulator cap screws (A) to specifications.

Specification

Regulator Mounting Cap
Screws—Torque 4.5—5.0 N•m (40—45 lb-in.)

A—Regulator Cap Screws (4 Used)
B—Insulated Washer



Isolation Diode Plate/Insulation Washer

T6015AK -UN-06APR90

RG, RG34710, 2074 -19-15MAR97-20/21

32. Install and tighten two isolation diode nuts to specifications.

Specification

Isolation Diode Nuts—Torque 2.5—3.5 N•m (20—30 lb-in.)

33. Tighten alternator terminal nuts to specifications.

Specification

Alternator Terminal Nuts—Torque 2.5—3.5 N•m (20—30 lb-in.)



Tighten Nuts

T6015BI -UN-06APR90

RG, RG34710, 2074 -19-15MAR97-21/21

15
15
30

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B60 -19-08MAY02-1/3

15
20
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B60 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B60 -19-08MAY02-3/3

Motorola A-, RA-, 8AR-Series Charging Circuit Repair Specifications

Item	Measurement	Specification
Used Brush	Minimum Exposed Length	6.4 mm (0.25 in.)
Housing Through Bolts	Torque	3.5—4.0 N•m (30—35 lb-in.)
Pulley Shaft Nut	Torque	68 N•m (50 lb-ft)

OUO1004.0000B63 -19-21SEP00-1/1

Motorola A-, RA-, 8AR-Series Charging Circuit Test Specifications

John Deere Part No.	Motorola Part No.	Volts	Rated Amps	Output Test ^a Amps (Hot)	Field Current ^b Amps	Winding Resistance ^c Ohms
A221618	A12NJD454	12	35	—	—	—
AR38458	RA12NJD453, 70D44120C01	12	35	33	1.90—2.55	4.2—5.5
AR40419	RA2AJD9025, A24JD900	24	35	—	1.28—1.88	—
AR40420	RA12NJD604	12	55	52	1.65—2.25	4.0—5.2


^aOutput test @ 3000—5000 RPM.

^bField current @ 20—27°C (70—80°F); @ 10V for 12V systems and 20V for 24V systems.

^cWinding resistance @ 20—27°C (70—80°F).

RG.RG34710,2076 -19-08SEP00-1/1

Disassemble and Test Motorola A-, RA-, 8AR-Series Alternator



Motorola A-, RA-, 8AR-Series Alternator

- | | | | |
|-----------------------------|-----------------------------|--------------------------|--------------------|
| 1—Isolation Diode Plate | 7—3/4 in. Insulating Washer | 13—Slip Ring End Frame | 18—Drive End Frame |
| 2—1/2 in. Insulating Washer | 8—Long Insulating Bushing | 14—Slip Ring End Bearing | 19—Spacer |
| 3—Short Insulating Bushing | 9—O-Ring Bearing Retainer | 15—Rotor | 20—Fan |
| 4—Brush Return Wire | 10—Positive Diode | 16—Bearing Retainer | 21—Pulley |
| 5—Brush Holder | 11—Stator | 17—Drive End Bearing | 22—Pulley Nut |
| 6—Through Bolt | 12—Negative Diode | | |

The regulator (not shown) may be mounted directly to end frame (13) or remotely mounted elsewhere on the vehicle.

Continued on next page

RG.RG34710,2077 -19-15MAR97-1/15

15
20
3

RG5477 -UN-02FEB89

1. Check isolation diode plate using digital multimeter with selector indicator in the diode test position.

The meter must register "OL" in one direction and approximately 0.50 volts in the other. If it does not, replace diode.



Check Isolation Diode Plate

RG,RG34710,2077 -19-15MAR97-2/15

2. Test the three negative diodes (A) with selector in diode test position.

Touch one probe to a diode (A) and the other probe to the ground terminal. Take reading. Reverse probes and take another reading.

The meter must register "OL" in one direction and approximately 0.50 volts in the other on all three diodes. If it does not, replace the negative diode plate.

A—Three Negative Diodes



Test Negative Diodes

Continued on next page

RG,RG34710,2077 -19-15MAR97-3/15

3. Test the three positive diodes (A) with selector in diode test position.

Touch one probe to a diode (A) and the other probe to diode plate post. Take reading. Reverse probe and take another reading.

The meter must register "OL" in one direction and approximately 0.50 volt in the other on all three diodes. If it does not, replace the positive diode plate.

A—Three Positive Diodes



Test Positive Diodes

T6015AM -UN-06APR90

15
20
5


RG,RG34710,2077 -19-15MAR97-4/15

4. Check the stator windings for continuity.

Touch one probe to a diode (A) and the other probe to each of the other two diodes (B) attached to the same diode plate. Repeat step for other diode plate.

If there is no continuity in any of the connections, there is an open circuit in the stator windings and the stator must be replaced.

A—Diode
B—Two Diodes



Check Stator Windings for Continuity

T6015AD -UN-06APR90


Continued on next page

RG,RG34710,2077 -19-15MAR97-5/15

5. Check stator for a grounded winding.

Touch one probe to diode lead (A) and the other probe to the rear alternator housing (B). Take reading. Reverse the probes and take another reading.

The meter must register in one direction only. If continuity is registered in both directions, a stator winding is grounded and the stator must be replaced.



T6015BA -JUN-06APR90

Check Stator for Grounded Winding


- A—Diode Lead
- B—Rear Alternator Housing

RG, RG34710, 2077 -19-15MAR97-6/15

6. Remove regulator from end frame, if so equipped. Remove brush cover.

7. Remove two cap screws to remove brushes.

8. Check the condition of the springs and connections, and for freedom of movement of brushes. If either brush is worn beyond specification, or is cracked or oil soaked, replace the brush assembly.



T84656 -JUN-07NOV88

Brush Assembly

Specification


Used Brush—Minimum Exposed
Length..... 6.4 mm (0.25 in.)

Continued on next page

RG, RG34710, 2077 -19-15MAR97-7/15

9. Check for continuity between terminal (A) and brush (B). Next check for continuity between bracket (C) and brush (D). If there is no continuity at either brush, replace the brush assembly.
10. Check for continuity between terminal (A) and bracket (C). If there is continuity, replace the brush assembly.

A—Terminal
B—Brush
C—Bracket
D—Brush



Check for Continuity

T87568 -UN-23FEB90

15
20
7

RG,RG34710,2077 -19-15MAR97-8/15

11. Remove four through bolts and nuts.

IMPORTANT: Inserting screwdriver blades deeper than 1.6 mm (1/16 in.) may damage stator windings.

12. Carefully insert two screwdriver blades (A) in opposite openings between the stator and front housing to separate the front housing from the rear.

A—Two Screwdriver Blades



Insert Screwdriver Blades


T87572 -UN-23FEB90

Continued on next page

RG,RG34710,2077 -19-15MAR97-9/15

13. Remove stator and diode assembly from the slip ring end frame.
14. If necessary to remove diodes from stator, carefully note locations of insulators and washers for proper reassembly. Do not unsolder stator-to-diode wire junctions. Avoid bending stator wires at junction.

IMPORTANT: Do not use an acid-core solder when soldering diode leads. Use rosin-core solder only.



T89073 -UN-21FEB90

Soldering and Unscrewing Leads

15. Use needle-nose pliers as a heat sink when soldering and unscrewing leads to and from diodes. Do not exert excessive stress on diode leads.
16. Note diode assembly-to-stator connections. Be sure replacement diode assembly connections are the same as removed. The positive diode assembly has red printing and the negative has black printing. **DO NOT INTERCHANGE.**

RG, RG34710, 2077 -19-15MAR97-10/15

17. Use a bearing puller to remove slip ring end bearing. If bearing is to be reused, puller must contact inner race only.



T87602 -UN-23FEB90

Remove Slip Ring End Bearing


Continued on next page

RG, RG34710, 2077 -19-15MAR97-11/15

18. Remove nut to remove pulley and fan. Clamp pulley in vise using an old over-sized belt to protect pulley. Remove woodruff key from shaft.

Inspect parts for wear or damage.

NOTE: Pulley nut need not be removed if front bearing will not be replaced.



Remove Pulley and Fan


T89074 -UN-21FEB90

15
20
9

RG, RG34710, 2077 -19-15MAR97-12/15

19. Remove the front bearing retainer (A) by prying it out of its groove with an awl.

A—Front Bearing Retainer



Remove Front Bearing Retainer

T87605 -UN-23FEB90

RG, RG34710, 2077 -19-15MAR97-13/15

20. Use a plastic hammer to remove rotor and bearing from front housing.




Use Plastic Hammer

T87606 -UN-23FEB90

Continued on next page

RG, RG34710, 2077 -19-15MAR97-14/15

21. Use a suitable bearing puller to remove front bearing.




T87607 -UN-23FEB90

Remove Front Bearing

RG.RG34710,2077 -19-15MAR97-15/15

15
20
10

Assemble Motorola A-, RA-, 8AR-Series Alternator



Motorola A-, RA-, 8AR-Series Alternator

- | | | | |
|-----------------------------|-----------------------------|--------------------------|--------------------|
| 1—Isolation Diode Plate | 7—3/4 in. Insulating Washer | 13—Slip Ring End Frame | 18—Drive End Frame |
| 2—1/2 in. Insulating Washer | 8—Long Insulating Bushing | 14—Slip Ring End Bearing | 19—Spacer |
| 3—Short Insulating Bushing | 9—O-Ring Bearing Retainer | 15—Rotor | 20—Fan |
| 4—Brush Return Wire | 10—Positive Diode | 16—Bearing Retainer | 21—Pulley |
| 5—Brush Holder | 11—Stator | 17—Drive End Bearing | 22—Pulley Nut |
| 6—Through Bolt | 12—Negative Diode | | |

For alternator assembly, the following is a list of special requirements:

Replace bearings, if removed.

Guide rotor leads through one of the oval passages in the slip ring assembly. The oval passage must line up with the groove in the rotor shaft.

Press front housing down until inner bearing race contacts shoulder on shaft.

Be sure front bearing retainer is firmly seated in housing bore.

Tighten housing through bolts to specifications.

Specification

Housing Through Bolts—
Torque..... 3.5—4.0 N•m (30—35 lb-in.)

15
20
11

RG5477 -UN-02FEB89

Tighten pulley shaft nut to specifications.

Specification

Pulley Shaft Nut—Torque..... 68 N•m (50 lb-ft)

RG, RG34710, 2078 -19-15MAR97-2/2

15
20
12

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B64 -19-08MAY02-1/3

15
25
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B64 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B64 -19-08MAY02-3/3

Other Material

Number	Name	Use
T43512 (U.S.) TY9473 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to front and rear bearing retainer cap screws.

15
25
2

LOCTITE is a registered trademark of Loctite Corp.

OUC1004.0000B66 -19-21SEP00-1/1

Motorola SA-Series Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush	Minimum Exposed Length	4.8 mm (0.189 in.)
Slip Ring Retainer Screw	Torque	5.1 N•m (45 lb-in.)
Pulley Retaining Nut	Torque	68 N•m (50 lb-ft)
Housing Through Bolts	Torque	5.7—6.8 N•m (50—60 lb-in.)

OUC1004.0000B67 -19-21SEP00-1/1

Motorola SA-Series Charging Circuit Test Specifications

John Deere Part No.	Motorola Part No.	Volts	Rated Amps	Output Test ^a Amps (Hot)	Field Current ^b Amps	Winding Resistance ^c Ohms
AT51042	8SA2016R	12	84	77—80	1.74—2.10	5.25
RE20486	8SA2035V	12	130	100—110	3.90—4.70	2.30

^aOutput test @ 3000—4000 RPM.

^bField current @ 20—27°C (70—80°F); @ 10V for 12V systems and 20V for 24V systems.

^cWinding resistance @ 20—27°C (70—80°F).

Item	Specification
Stator Resistance	0.1—0.4 ohms
130 Amp Rotor Winding Resistance	2.0—3.0 ohms
84 Amp Rotor Winding Resistance	4.7—5.8 ohms

RG, RG34710, 2080 -19-08SEP00-1/1

15
25
3

Remove Alternator for Repair

Refer to your machine technical manual for removal of alternator.

IMPORTANT: Never immerse alternator in cleaning solvent. Remove dirt and grease by scraping and using a stiff brush with solvent. Dry with compressed air.


ONLY rosin core solder should be used for soldering operations. The use of acid core solder will result in rapid corrosion of the windings and eventual failure of the complete alternator unit.

RG, RG34710, 2081 -19-15MAR97-1/1

Disassemble and Test Motorola SA-Series Alternator

1. Remove alternator ground wire (A), regulator ground lead (B) and regulator positive lead (C).
2. Remove regulator retaining cap screws (D).
3. Remove yellow wire leads from stator terminals and green wire leads from brush terminals.

A—Alternator Ground Wire
B—Regulator Ground Lead
C—Regulator Positive Lead
D—Cap Screws




Disassemble Motorola SA Alternator

RW10855 -UN-17NOV89

RG, RG34710, 2082 -19-09MAY02-1/22

4. Remove brush assembly retaining cap screws (A), then remove brush assembly.

A—Brush Assembly Retaining Cap Screws (2 Used)



Brush Assembly Retaining Cap Screws

RW10856 -UN-17NOV89


Continued on next page

RG, RG34710, 2082 -19-09MAY02-2/22

5. Examine brushes for roughness, cracks or oil contamination. If damaged, replace assembly.
6. Measure unused brush length. If brush length is not within specification, replace brushes.

Specification


Brush—Minimum Exposed Length..... 4.8 mm (0.189 in.)



Measure Brush Length

RG, RG34710, 2082 -19-09MAY02-3/22

7. Use ohmmeter to test continuity between each terminal and attached brush.
8. Test continuity between the two brushes and between each brush and ground. There should be no continuity.
9. If malfunction was indicated in regulator or brush assembly, replace parts as necessary and reassemble. If not, continue disassembly.




Use Ohmmeter to Test Continuity

Continued on next page

RG, RG34710, 2082 -19-09MAY02-4/22

10. Remove four through bolts (A).

A—Through Bolts (4 Used)



Remove Through Bolts


RG, RG34710, 2082 -19-09MAY02-5/22

IMPORTANT: Avoid inserting sharp tools between stator and housing. Damage to stator windings or laminations could occur.

11. Separate front housing from rear housing by supporting rear housing at through bolt ears (A) with wood or steel blocks. Use 25.4 mm (1.0 in.) ID soft steel conduit (B) as a driver.

NOTE: Stator will stay with rear housing, rotor will stay with front housing.

A—Through Bolt Ears
B—Soft Steel Conduit Driver



Separate Front Housing from Rear Housing

Continued on next page

RG, RG34710, 2082 -19-09MAY02-6/22

12. Remove stator leads from the three stator tap terminals (A).
13. Remove the "R" terminal stud (B).
14. Remove stator (C) from rear housing.

A—Stator Tap Terminals (3 Used)
B—"R" Terminal Stud
C—Stator



Remove Stator Leads

RG, RG34710, 2082 -19-09MAY02-7/22


15
25
7

15. Inspect stator for physical damage. Look for broken insulation, rotor striking laminations or foreign material that may restrict circulation of cooling air.

Discoloration or burned odor may indicate overheating, which may cause short circuits. Replace stator if either condition exists.

16. Connect ohmmeter to each stator lead (A) and stator frame (B). Replace stator if test indicated continuity.

A—Stator Leads
B—Stator Frame



Inspect Stator Lead and Frame

Continued on next page


RG, RG34710, 2082 -19-09MAY02-8/22

17. A short-circuit in the stator can be difficult to identify. Use an ohmmeter that is sensitive to resistance of 0 to 1 ohm.

Connect ohmmeter between each pair of terminals (A). Resistance should be approximately 0.1 ohm. (Ohmmeter needle should deflect to zero if leads are touched together.) If resistance is above 0.4 ohm, replace stator.

A stator will occasionally exhibit an open circuit or short circuit only when hot, making the defect even more difficult to diagnose.

A—Stator Terminals



Ohmmeter

RW10864 -UN-17NOV89

RG, RG34710, 2082 -19-09MAY02-9/22

18. Remove positive stud (A) and negative stud (B) nuts, and leads to stator taps. Remove diode heat sink assembly from rear housing.

A—Positive Stud
B—Negative Stud



Remove Diode Heat Sink Assembly

RW10865 -UN-17NOV89

Continued on next page


RG, RG34710, 2082 -19-09MAY02-10/22

- Disconnect capacitor lead (A) from heat sink.

NOTE: Make sure that heat sink halves are insulated from each other.

- Connect ohmmeter to each lead (B) and heat sink. Reverse leads and test for continuity between same points. Perform this check on both (+) and (—) heat sink assemblies. Good diodes will have continuity in only one direction. Replace assembly if there is no continuity in either direction or continuity in both directions.

A—Capacitor Lead
B—Leads



Capacitor Leads

RW10866 —UN-17NOV89

15
25
9

RG,RG34710,2082 —19-09MAY02-11/22

- Set multimeter for highest resistance (ohms) scale of diode test position to test capacitor.
- Connect meter test leads to condenser lead (A) and body (B) as shown. Charge condenser for 15 seconds before disconnecting one test lead.

If the multimeter indicates continuity through the condenser, it is leaking current and needs to be replaced.

- Reset multimeter for a low voltage scale.

- Observe voltmeter needle (digital read-out) for a voltage increase as you reconnect the test lead.

If there was no voltage reading, the condenser was not charged and needs to be replaced.

- Repeat the last four steps several times to verify condenser performance.



Condenser Lead and Body

A—Condenser Lead
B—Condenser Body


RW10867 —UN-17NOV89

Continued on next page

RG,RG34710,2082 —19-09MAY02-12/22

26. Use an ohmmeter to test rotor for continuity.
27. Attach ohmmeter to rotor frame (A) and each slip ring (B).
28. Replace rotor if test shows continuity.

A—Rotor Frame
B—Slip Ring



Rotor Frame and Slip Ring

RW10871 -UN-16NOV89


RG,RG34710,2082 -19-09MAY02-13/22

29. Use ohmmeter to test for continuity from one slip ring to the other or at soldered connections at end of rotor.

If test does not show continuity, replace rotor.

30. Measure rotor winding resistance.

Rotor winding resistance should be 2.0—3.0 ohms for 130-amp circuits and 4.7—5.8 ohms for 84-amp circuits.



Ohmmeter


RW10872 -UN-16NOV89

Continued on next page

RG,RG34710,2082 -19-09MAY02-14/22

31. Inspect rotor slip rings (A) for excessive wear or roughness. Use fine crocus cloth to remove minor roughness.
32. Check front and rear bearings (B) for roughness.
33. Check fan (C) for loose or bent blades.
34. Check pulley (D) for excessive wear.

If bearings, slip rings or pulley are rough or worn or fan is damaged, continue with disassembly.



RW10873

Inspect Components

- A—Rotor Slip Ring
- B—Rear Bearing
- C—Fan
- D—Pulley

RW10873 -UN-16NOV89

15
25
11

RG,RG34710,2082 -19-09MAY02-15/22

35. Unsolder rotor leads from slip ring terminals.
- IMPORTANT: Do not overheat slip ring terminals.**
36. Carefully unwind ends of rotor coil leads from slip ring terminals.



Unsolder Rotor Leads

N8516201 -UN-22SEP88


Continued on next page

RG,RG34710,2082 -19-09MAY02-16/22

37. Remove hex countersunk head screw (A) from end of shaft.

38. Thread a 1/4 x 1 in. cap screw into slip ring hub. This will back slip ring assembly (B) off shaft.

A—Hex Countersunk Head Screw
B—Slip Ring Assembly




Shaft

N85162P1 -UN-22SEP88

RG, RG34710, 2082 -19-09MAY02-17/22

IMPORTANT: Do not press on porcelain center of slip rings.

39. Use three-jaw puller and slide hammer to remove rear bearing from rotor.



RW10874


RW10874 -UN-16NOV89

RG, RG34710, 2082 -19-09MAY02-18/22

40. Place pulley in vise using soft jaws to protect pulley. Remove pulley nut and lock washer.

41. Remove pulley (A) and fan (B).

A—Pulley
B—Fan



RW10875

RW10875 -UN-16NOV89


Remove Pulley and Fan

Continued on next page

RG, RG34710, 2082 -19-09MAY02-19/22

42. Remove spacer (A) and woodruff key (B).
43. Remove three bearing retainer screws (C).

A—Spacer
B—Woodruff Key
C—Retainer Screws



Remove Spacer and Woodruff Key

RW10876 -UN-16NOV89

15
25
13

RG,RG34710,2082 -19-09MAY02-20/22

IMPORTANT: To prevent damage to front housing DO NOT support housing at outer circumference when removing rotor and front bearing.

44. Using three-jaw puller, push rotor and front bearing from front housing.




Three-Jaw Puller

RW10877 -UN-16NOV89

Continued on next page

RG,RG34710,2082 -19-09MAY02-21/22

45. Remove front bearing only if bearing replacement is necessary. Use a knife-edge, bearing pulling attachment to remove front bearing from rotor shaft.
46. Inspect rotor shaft, body, and rear bearing for stripped threads on shaft, worn key slot, worn bearing surface, or scuffed pole finger. Replace rotor assembly if any of the above defects are found.




Inspect Rotor Shaft, Body and Bearing

RG,RG34710,2082 -19-09MAY02-22/22

Assemble Motorola SA-Series Alternator

1. Install rear bearing spacer (A), sealing felt, rear bearing (B), front bearing retainer (C), sealing felt and front bearing (D).
2. Place assembly in small press. Using a 25.4 mm (1.0 in.) ID soft steel conduit, push assembly together until spacers and bearings are seated against rotor frame.

- A—Rear Bearing Spacer
- B—Rear Bearing
- C—Front Bearing Retainer
- D—Front Bearing



Motorola SA Alternator

Continued on next page


RG,RG34710,2083 -19-09MAY02-1/13

3. Guide rotor windings through one passage in slip ring hub.
4. Hand press slip rings (B) on shaft while maintaining alignment of winding leads and passage.
5. Tighten hex countersunk head screw (A) to specifications.

Specification

Slip Ring Retainer Screw—
Torque 5.1 N•m (45 lb-in.)

- A—Hex Countersunk Head Screw
- B—Slip Rings



Slip Rings and Head Screw

N85162P1 -UN-22SEP88

15
25
15

RG, RG34710, 2083 -19-09MAY02-2/13

6. Install a fiber washer on the non-soldered terminal of slip rings. This is to prevent the inner slip ring from touching the outer slip ring, causing a short.
7. Wrap leads (A) around slip ring terminals and solder with rosin-core solder. Do not overheat.
8. Secure wires to end of rotor with a synthetic sealer.
9. Retest rotor assembly to ensure that a ground or short circuit did not develop during repair.

- A—Leads



Wrap Leads Around Terminals


N85162Q1 -UN-22SEP88

Continued on next page

RG, RG34710, 2083 -19-09MAY02-3/13

IMPORTANT: Support front housing on bearing quill.

10. Press rotor with front bearing into front housing.




Press Rotor Into Front Housing

RG,RG34710,2083 -19-09MAY02-4/13

11. Apply LOCTITE® 242 Thread Lock and Sealer to front bearing screws (A) and reinstall.

12. Reinstall spacer (B) and woodruff key (C).

- A—Front Bearing Screws (3 Used)
- B—Spacer
- C—Woodruff Key



Reinstall Spacer and Woodruff Key

LOCTITE is a registered trademark of Loctite Corp.

Continued on next page

RG,RG34710,2083 -19-09MAY02-5/13


13. Install fan (B), pulley (A), lock washer and nut.

14. Tighten pulley nut to specifications.

Specification

Pulley Retaining Nut—Torque..... 68 N•m (50 lb-ft)

A—Pulley
B—Fan



Install Fan and Pulley


RG, RG34710, 2083 -19-09MAY02-6/13

15
25
17

15. Inspect rear housing bearing bore (A) for scuffs or cracks. Replace as necessary.

16. Check and install all inside insulators (B).

A—Rear Housing Bearing Bore
B—Inside Insulators



Inspect Rear Housing


Continued on next page

RG, RG34710, 2083 -19-09MAY02-7/13

17. Check and install outside insulators (C).

NOTE: Do not attempt to remove rear bearing, nylon retaining ring. Retaining ring does not normally need to be replaced. Replace only if cracked or gouged or if there is evidence of bearing spin.

C—Outside Insulators



Outside Insulator


RW10869 -UN-17NOV89

RG, RG34710, 2083 -19-09MAY02-8/13

18. Install "R" terminal bolt (A) through stator lead and diode lead eyelets with three insulators (B).

19. Install diode heat sink into rear housing.

A—"R" Terminal Bolt
B—Insulators (3 Used)



RW10870

Terminal Bolt and Insulators

RW10870 -UN-17NOV89

Continued on next page

RG, RG34710, 2083 -19-09MAY02-9/13

20. Install stator assembly into rear housing.
21. Install the "R" terminal stud (B).
22. Install leads on three stator terminals (A).

A—Stator Terminals (3 Used)
 B—"R" Terminal Stud
 C—Stator



RW10862

Install Terminal Stud and Leads

RW10862 -UN-17NOV89

15
25
19


RG, RG34710, 2083 -19-09MAY02-10/13

23. Install rear housing assembly to front housing.
24. Apply LOCTITE® 242 Thread Lock and Sealer to through bolts (A) and install. Tighten evenly so rear rotor bearing is pressed into rear housing. Tighten until stator and housings are securely fastened together.
25. Tighten through bolts to specifications.

Specification

Housing Through Bolts—Torque..... 5.7—6.8 N•m (50—60 lb-in.)

NOTE: Lubricate rear retaining ring (in rear housing bearing bore) with liquid soap.



RW10859

Through Bolts

A—Through Bolts (4 Used)

RW10859 -UN-17NOV89


LOCTITE is a registered trademark of Loctite Corp.

Continued on next page

RG, RG34710, 2083 -19-09MAY02-11/13

26. Install brush assembly. Install and tighten brush assembly retaining cap screws (A) securely.


A—Brush Assembly Retaining Cap Screws (2 Used)



Brush Assembly Retaining Cap Screws

RG,RG34710,2083 -19-09MAY02-12/13

27. Install gasket on voltage regulator.
28. Connect two regulator brush leads to brush assembly.
29. Install regulator and tighten retaining cap screws (D) securely.
30. Install alternator ground wire (A) and regulator ground lead (B). Install washer and tighten nut securely.
31. Install regulator positive lead (C) with washer and tighten nut securely.
32. Refer to your machine technical manual for installation of alternator and proper adjustment of V-belts.



Install Gasket

**A—Alternator Ground Wire
B—Regulator Ground Lead
C—Regulator Positive Lead
D—Retaining Cap Screws**

RG,RG34710,2083 -19-09MAY02-13/13

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B68 -19-08MAY02-1/4

15
30
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B68 -19-08MAY02-2/4

Alternator, Generator, Starter and Battery Bench Tester JT01760


Test alternators and starters for voltage, resistance, or current flow.

Continued on next page

OUO1004,0000B68 -19-08MAY02-3/4

Bushing, Bearing and Seal Driver Set D01045AA

Install seal in front housing of alternator.



D01045AA

RG11162 -UN-21SEP00

OOU1004,0000B68 -19-08MAY02-4/4

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OOU1004,0000B69 -19-21SEP00-1/2

17-1/2 Ton Puller Set. D01047AA

Remove alternator pulley.

OOU1004,0000B69 -19-21SEP00-2/2

15
30
2

Motorola TA-Series Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush	Minimum Exposed Length	6.4 mm (0.25 in.)
Alternator Pulley Retaining Nut	Torque	47—68 N•m (35—50 lb-ft)
Front-to-Rear Alternator Housing Cap Screws	Torque	2.8—3.4 N•m (20—30 lb-in.)
Brush Holder Retaining Screws	Torque	2.8—3.4 N•m (20—30 lb-in.)

OUC1004,0000B6B -19-21SEP00-1/1

15
30
3

Motorola TA-Series Charging Circuit Test Specifications

John Deere Part No.	Motorola Part No.	Volts	Rated Amps	Output Test ^a Amps (Hot)	Field Current ^b Amps	Winding Resistance ^c Ohms
AN114058	8TA2009E	12	30	28—30	0.55—1.50	11.0—12.5
AT22870	TA12NJD400	12	30	28—30	0.55—1.50	11.0—12.5
AT31669	8TA2009EB	12	30	28—30	0.55—1.50	11.0—12.5
AT36220	8TA2003D	12	22	18—20	0.55—1.50	11.0—12.5
AT41070	8TA2006D	12	22	18—20	0.55—1.50	11.0—12.5
AT45618	8TA2017D	12	22	18—20	0.55—1.50	11.0—12.5
AT56246	8TA3025CS	24	16	10—14	0.08—1.20	27.0—29.0
AT56247	8TA3025C	24	16	10—14	0.08—1.20	27.0—29.0

^aOutput test @ 3000—4000 RPM.

^bField current @ 10V for 12V system and 20V for 24V systems; @ 20—27°C (70—80°F).

^cWinding resistance @ 20—27°C (70—80°F).

Item	Specification
Rotor Current Draw @ 20—27°C (70—80°F)	0.55—1.56 amps

RG, RG34710, 2085 -19-08SEP00-1/1

Remove Alternator for Repair

Refer to your machine technical manual for removal of alternator.

IMPORTANT: Never immerse alternator in cleaning solvent. Remove dirt and grease by scraping and using a stiff brush with solvent. Dry with compressed air.


ONLY rosin core solder should be used for soldering operations. The use of acid core solder will result in rapid corrosion of the windings and eventual failure of the complete alternator unit.

RG,RG34710,2086 -19-15MAR97-1/1

Disassemble and Test Motorola TA-Series Alternator

1. Remove voltage regulator (A) and capacitor (B) from alternator.

A—Voltage Regulator
B—Capacitor



Remove Voltage Regulator and Capacitor

T91362 -UN-14FEB90

Continued on next page

RG,RG34710,2087 -19-15MAR97-1/20

2. Remove brush cover (A) and gasket.

A—Brush Cover and Gasket



Remove Brush Cover and Gasket

T5916AG -UN-12APR90

15
30
5


RG, RG34710, 2087 -19-15MAR97-2/20

3. Remove isolator (A) and brush assembly (B). Inspect brushes. If either one is worn beyond specification, cracked or oil soaked, replace the brush assembly.

Specification

Brush—Minimum Exposed Length..... 6.4 mm (0.25 in.)

A—Isolator
B—Brush Assembly




Remove Isolator and Brush Assembly

T91364 -UN-14FEB90

Continued on next page

RG, RG34710, 2087 -19-15MAR97-3/20

4. Check for continuity between terminal (A) and brush (B) and bracket (C) and brush (D). If there is no continuity at either brush, replace the brush assembly.
5. Check for continuity between terminal (A) and bracket (C). If there is continuity, replace the brush assembly.
6. Check for continuity between terminal (A) and brush (D). If there is continuity, replace the brush assembly.



Check for Continuity

T87568 -UN-23FEB90

- A—Terminal
- B—Brush
- C—Bracket
- D—Brush


RG,RG34710,2087 -19-15MAR97-4/20

7. Remove cap screws (A) to separate the housings. Note horseshoe clip (B) at lower cap screw.

IMPORTANT: Inserting screwdriver blades farther than 1.6 mm (1/16 in.) may damage stator windings.

8. Carefully insert two screwdriver blades in opposite openings between the stator and front housing and separate the front housing from the rear.

- A—Cap Screws (4 Used)
- B—Horseshoe Clip



Separate Front Housing

T91366 -UN-14FEB90


Continued on next page

RG,RG34710,2087 -19-15MAR97-5/20

9. Remove nuts and washers (A) to disconnect stator leads (B).

NOTE: Remove diode leads from stud terminal.

A—Nuts and Washers (3 Used)
B—Stator Leads



T91367 -UN-14FEB90

Disconnect Stator Leads

15
30
7

RG,RG34710,2087 -19-15MAR97-6/20

10. Use ohmmeter to check rotor windings by placing a probe on each slip ring. If there is no continuity, replace the rotor.



T91373 -UN-14FEB90

Check Rotor Windings

Continued on next page

RG,RG34710,2087 -19-15MAR97-7/20

11. Use ohmmeter to check for grounded rotor windings. If there is continuity, replace the rotor.



T91374 -UN-14FEB90

Check for Grounded Rotor Windings

RG,RG34710,2087 -19-15MAR97-8/20

12. Use ohmmeter to check the stator for an open winding. Check all the leads. If there is no continuity in any of the connections, there is an open circuit in the stator windings and the stator must be replaced.



T91375 -UN-14FEB90

Check Stator and Leads

Continued on next page

RG,RG34710,2087 -19-15MAR97-9/20

13. Use ohmmeter to check the stator for a grounded winding. Touch one probe to any of the leads and one to the ground. The meter must not register continuity. If it registers continuity, a stator winding is grounded and the stator must be replaced.



Check Stator

T91376 -UN-14FEB90

15
30
9

RG,RG34710,2087 -19-15MAR97-10/20

IMPORTANT: The diode test position must be used on meters with test position to get accurate results. Follow the manufacturer's instructions for your meter to test diodes.

14. Test positive and negative diodes in both directions using a volt-ohm-amp meter. Put one probe on a diode lead and the other probe on the diode plate to get a reading.

A diode with a high reading in one direction and a low reading in the other direction is good. A diode with the same reading in both directions is defective and should be replaced.

Test diode trio in both directions using a volt-ohm-amp meter. Put probes on each end of diode to get a reading.

A diode trio with a high reading in one direction and a low reading in the other direction is good. A diode trio with the same reading in both directions is defective and should be replaced.



Test Diodes

T91377 -UN-14FEB90



Test Diodes


T5916AH -UN-12APR90

Continued on next page

RG,RG34710,2087 -19-15MAR97-11/20

15. To separate the diode plate from the alternator half, remove the nut and insulator on the stator terminal (A) and the nut on the ground terminal (B).

A—Stator Terminal
B—Ground Terminal



T91378 -UN-14FEB90


Stator and Ground Terminals

RG, RG34710, 2087 -19-15MAR97-12/20

16. Remove diodes if defective. Use a standard punch.

IMPORTANT: Support underside of casting to prevent damage when removing diodes.

The rectifying diode in TA-Series alternators have their leads welded, not soldered, to the stems. Do not attempt to substitute diode and solder the lead to the diode stem.



T91379 -UN-14FEB90


Remove Defective Diodes

Continued on next page

RG, RG34710, 2087 -19-15MAR97-13/20

17. To replace the diodes, use a piece of pipe to press diodes into diode plate.

IMPORTANT: Before installing diode plate, make certain that it is properly insulated from housing. (See ASSEMBLE MOTOROLA TA-SERIES ALTERNATOR in this group.)




T91380 -UN-14FEB90

Replacing Diodes

15
30
11

RG,RG34710,2087 -19-15MAR97-14/20

18. Remove the front housing from the stator.




T91381 -UN-14FEB90

Remove Front Housing

Continued on next page

RG,RG34710,2087 -19-15MAR97-15/20

19. Remove nut and lock washer. Remove the pulley with a gear puller from D01047AA 17-1/2 Ton Puller Set.



T91382 -UN-14FEB90

Remove Pulley

RG, RG34710, 2087 -19-15MAR97-16/20

20. To remove rotor, remove the key from the shaft and tap on the shaft with a plastic hammer.



T91383 -UN-14FEB90

Remove Rotor

Continued on next page

RG, RG34710, 2087 -19-15MAR97-17/20

21. Remove three screws and lock washers to remove bearing retainer.




T91384 -UN-14FEB90

Remove Bearing Retainer

15
30
13

RG,RG34710,2087 -19-15MAR97-18/20

22. Remove the front seal and bearing using a 3/32 in. punch.




T91385 -UN-14FEB90

Remove Front Seal and Bearing

Continued on next page

RG,RG34710,2087 -19-15MAR97-19/20

23. Remove the rear bearing if bearing replacement is necessary.



T91386 -UN-14FEB90

Remove Rear Bearing if Necessary

RG, RG34710, 2087 -19-15MAR97-20/20

Assemble Motorola TA-Series Alternator

1. Install seal open face to driver from the D01045AA Bushing, Bearing and Seal Driver Set. Install seal in housing bore.



T91387 -UN-14FEB90

Install Seal in Housing Bore

Continued on next page

RG, RG34710, 2088 -19-15MAR97-1/15

2. Install bearing using a driver that contacts the outer race.



Install Bearing

T91388 -UN-14FEB90

15
30
15

RG, RG34710, 2088 -19-15MAR97-2/15

3. Install bearing retainer using three screws and washers.



Install Bearing Retainer


T91389 -UN-14FEB90

Continued on next page

RG, RG34710, 2088 -19-15MAR97-3/15

4. Install seals (B) and bearing (A).

A—Bearing
B—Seals



Install Seals and Bearing

T5916A1 -UN-12APR90

RG, RG34710, 2088 -19-15MAR97-4/15

5. Install rotor to housing. Install the spacer and shaft key. Install the pulley, lock washer and hex nut. Tighten hex nut to specifications.

Specification

Alternator Pulley Retaining Nut—
Torque 47—68 N•m (35—50 lb-ft)

IMPORTANT: Clamp pulley in a soft-jawed vise or use an old oversize belt to prevent damage to pulley.



Install Rotor to Housing


T91390 -UN-14FEB90

Continued on next page

RG, RG34710, 2088 -19-15MAR97-5/15

6. Install O-ring (A). Lubricate the exposed area of the O-ring with hydraulic brake fluid only. Do not use oil.

A—O-Ring



Install O-ring


T91391 -UN-14FEB90

15
30
17

RG, RG34710, 2088 -19-15MAR97-6/15

7. Install diode plate mounting terminals, diode trio, and insulators (A—H) on diode plate.

A—Insulator
B—Insulator, Square (2 Used)
C—Insulator
D—Insulator
E—Diode Trio
F—Nut (3 Used)
G—Insulator (3 Used)
H—Bolt



Install Diode Plate Mounting Terminals


T5919AD -UN-16APR90

Continued on next page

RG, RG34710, 2088 -19-15MAR97-7/15

8. Install diode plate into rear housing. Install insulators, washers, and nuts (A—J).

- A—Insulator Sleeve
- B—Insulator
- C—Washer
- D—Nut
- E—Insulator
- F—Flat Washer
- G—Lock Washer
- H—Nut
- I—Insulator
- J—Nut




Install Diode Plate

T6106AG -UN-02APR90

RG,RG34710,2088 -19-15MAR97-8/15

9. Install stator into front housing. Install gasket.



Install Stator and Gasket


T91381 -UN-14FEB90

Continued on next page

RG,RG34710,2088 -19-15MAR97-9/15

10. Connect each diode lead to the terminal (B) adjacent to it. Also connect stator leads (A) leads to terminals (B). Fasten with nuts and lock washers.

A—Stator Leads
B—Terminals



Connect Leads

T5916AJ -UN-12APR90

15
30
19

RG, RG34710, 2088 -19-15MAR97-10/15

11. After stator leads are fastened to diode terminals, fasten the stator leads together using a tie band along the rear housing shell. Place stator leads as far as possible from rotor.



Attach Leads

T92062 -UN-12FEB90

Continued on next page


RG, RG34710, 2088 -19-15MAR97-11/15

12. Install rear housing and stator into the front housing. Make sure grooves in stator line up with cap screw holes. Install four screws (A) and tighten to specifications. Horseshoe clip (B) must be installed on lower screw.

Specification

Front-to-Rear Alternator Housing
 Cap Screws—Torque 2.8—3.4 N•m (20—30 lb-in.)

After assembly, rotate the alternator pulley. The pulley must rotate without any rough spots. Rough spots could be caused by the stator leads rubbing the rotor or a rough bearing. If rough spots are felt, disassemble rear housing and correct the problem.



T91366 -UN-14FEB90

Screws and Horseshoe Clip

A—Cap Screws (4 Used)
 B—Horseshoe Clip


RG, RG34710, 2088 -19-15MAR97-12/15

13. Install the brush assembly (B). Isolator (A) must be installed with tab over the brush leads to prevent brush leads from touching housing. Tighten brush holder retaining cap screws to specifications.

Specification

Brush Holder Retaining Screws—
 Torque 2.8—3.4 N•m (20—30 lb-in.)

A—Isolator
 B—Brush Assembly



T91364 -UN-14FEB90

Install Brush Assembly and Isolator

Continued on next page

RG, RG34710, 2088 -19-15MAR97-13/15

15
 30
 20

14. Install brush holder cover (A) and dust shield.

A—Brush Holder Cover and Dust Shield



Brush Holder Cover and Shield


T5916AG -UN-12APR90

15
30
21

RG,RG34710,2088 -19-15MAR97-14/15

15. Install voltage regulator (A) and wiring leads.
16. Refer to your machine technical manual for installation of alternator.

A—Voltage Regulator



Voltage Regulator

T6106AF -UN-02APR90

RG,RG34710,2088 -19-15MAR97-15/15

Section 20

Niehoff Alternators

Contents

Page

Group 05—Niehoff Alternator Theory of Operation

- Starting the Niehoff Alternator20-05-1
- Niehoff Alternator Operation20-05-1
- Niehoff Alternator Load Dump Circuit20-05-4

Group 10—Niehoff 12-Volt, 110-Amp Alternator Repair

- Essential Tools20-10-1
- Other Material20-10-3
- Niehoff 12-Volt Charging Circuit Repair
 - Specifications.20-10-3
- Niehoff 12-Volt Charging Circuit Test
 - Specifications.20-10-4
- Disassemble Niehoff 12-Volt, 110-Amp Alternator.20-10-4
- Test Niehoff 12-Volt, 110-Amp Alternator Components20-10-17
- Assemble Niehoff 12-Volt, 110-Amp Alternator.20-10-22
- Establish Magnetic Field20-10-27

Group 15—Niehoff 24-Volt, 50-Amp Alternator Repair


- Essential Tools20-15-1
- Other Material20-15-3
- Niehoff 24-Volt Charging Circuit Repair
 - Specifications.20-15-3
- Niehoff 24-Volt Charging Circuit Test
 - Specifications.20-15-4
- Disassemble Niehoff 24-Volt, 50-Amp Alternator and Test Components20-15-5
- Assemble Niehoff 24-Volt, 50-Amp Alternator.20-15-12
- Re-Establish Magnetic Field20-15-18

20

Starting the Niehoff Alternator

As the engine is cranking to start, the alternator rotor will turn. The residual magnetism in the rotor and stationary forging creates a magnetic field. The turning rotor causes the magnetic field to alternately increase and decrease in strength. This induces current into the stator (A). This current is sufficient to turn on the power transistor (B). The alternator and regulator are now operating.

- A—Stator
- B—Power Transistor



Starting Niehoff Alternator

RW5112 -JUN-06APR89


20
05
1

RG, RG34710, 2089 -19-15MAR97-1/1

Niehoff Alternator Operation

With the power transistor (A) on, field current is permitted to flow through the alternator field winding (B) from the battery (C). The field coil current will produce a magnetic field.

- A—Power Transistor
- B—Alternator Field Winding
- C—Battery



Niehoff Alternator Operation

RW5113 -JUN-06APR89


Continued on next page

RG, RG34710, 2090 -19-15MAR97-1/3

This magnetic field flows through a small air gap to the rotor and to the stator windings. As the rotor turns, the magnetic field is alternately increased and decreased in strength. This induces an alternating three-phase voltage and current in the stator coil windings (A). The alternating current output from the stator is applied to a three-phase full wave bridge rectifier (B), which provides direct current to the battery (C).

The compound winding produces a magnetic field which adds to the magnetic field created by the field coil. This helps the alternator produce output at the high end of the output range.

- A—Stator Coil Windings
- B—Bridge Rectifier
- C—Battery
- D—Rotor Winding
- E—Field Winding



RW5114 -UN-06APR89

Continued on next page

RG, RG34710, 2090 -19-15MAR97-2/3


20
05
2

The voltage regulator senses the voltage of the charging system through the diode trio (A). If the alternator loading demand is high, the power transistor (B) becomes conductive for longer periods of time and supplies a greater amount of current to the field winding (C). An increase in current flow through the field winding causes an increase in alternator output voltage.

As the charging system builds up to the predetermined setting of the regulator, the Zener diode (D) in the regulator causes the power transistor (B) to turn off. With the power transistor (B) turned off, little or no current is applied to the field winding, thereby decreasing the alternator output voltage.

This on/off field switching action is repeated as often as necessary so that the average voltage output of the alternator is maintained at the regulator setting.

- A—Diode Trio
- B—Power Transistor
- C—Field Winding
- D—Zener Diode



Voltage Regulator

RW5115 -JUN-06APR89


20
05
3

Niehoff Alternator Load Dump Circuit

The load dump circuit protects the alternator and the vehicle's electrical system when the battery connection is broken.

When the battery connection is broken, a high voltage appears at the alternator output (A). This high voltage causes the Zener diode (B) and the transistor (C) to conduct. This will turn on three SCR's (D)

- A—Alternator Output
- B—Zener Diode
- C—Transistor
- D—SCR's (3 Used)



Load Dump Circuit

RW5164 -UN-24MAY89


RG,RG34710,2091 -19-15MAR97-1/2

All the alternator output will flow through the three SCR's (A) to ground (B).

After a short time, the high voltage is gone and the regulator will take control of the alternator. The alternator output will remain at a level necessary to operate the vehicle's electrical system.

Repeated operation of the load dump circuit will result in regulator failure.

- A—SCR's (3 Used)
- B—Ground



SCR to Ground

RW5165 -UN-04MAY89

RG,RG34710,2091 -19-15MAR97-2/2

Group 10 Niehoff 12-Volt, 110-Amp Alternator Repair

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000B6C -19-08MAY02-1/6

Stator Support JDG255

Support shell while pressing out stator.



JDG255

RW10306 -JUN-10NOV89

20
10
1

OUO1004.0000B6C -19-08MAY02-2/6

Blind Hole Puller Set D01061AA

Remove bearings from front housing assembly.



D01061AA


RG11161 -JUN-21SEP00

Continued on next page

OUO1004.0000B6C -19-08MAY02-3/6

Bushing, Bearing and Seal Driver Set D01045AA

Install bearings in front housing assembly.



D01045AA

RG11162 -UN-21SEP00

OQO1004,0000B6C -19-08MAY02-4/6

20
10
2

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -UN-12DEC88

OQO1004,0000B6C -19-08MAY02-5/6

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OQO1004,0000B6C -19-08MAY02-6/6

Other Material

Number	Name	Use
TY16285 (U.S.) CXTY24311 (Canadian) 222 (LOCTITE®)	Thread Lock and Sealer (Low Strength)	Apply to all cap screws and nuts when assembling alternator.
	High Temperature, Silicone Base Grease	Fill front and rear grease reservoir in alternator housing.
	Silicone Rubber Compound	Apply to all internal wiring lead cap screws.

LOCTITE is a registered trademark of Loctite Corp.

OOU1004,0000B6E -19-21SEP00-1/1

20
10
3

Niehoff 12-Volt Charging Circuit Repair Specifications

Item	Measurement	Specification
Fan Pulley Lock Nut	Torque	95 N•m (70 lb-ft)
Front Housing-to-Stator Shell Nuts	Torque	3.4 N•m (30 lb-in.)
Rotor Nut	Torque	68 N•m (50 lb-ft)
Regulator Field Lead-to-Standoff Screw and Y-Lead-to-Load Dump Screw	Torque	0.9—1.1 N•m (8—10 lb-in.)
Output and Relay Leads-to-Standoff Screw	Torque	2.3 N•m (20 lb-in.)
Ground Lead-to-Load Dump Screw	Torque	1.1—1.7 N•m (10—15 lb-in.)
Flanged Nuts	Torque	5.1 N•m (45 lb-in.)


OOU1004,0000B6F -19-21SEP00-1/1

Niehoff 12-Volt Charging Circuit Test Specifications

John Deere Alternator Part No.	Niehoff Alternator Model No.	Ground	Voltage	Rated Output (Amps)	Winding Resistance @ 21—27°C (70—80°F) (Ohms)
AR94100	N1114-1	N	12	110	2.9—3.1

RG, RG34710, 2094 -19-07JUL05-1/1

Disassemble Niehoff 12-Volt, 110-Amp Alternator



Niehoff 12-Volt, 110-Amp Alternator

RW3289 -UN-02MAR90

- | | | | |
|-----------------------------|----------------------|----------------------|--------------------------|
| A—Screw (3 Used) | I—Screw (4 Used) | Q—Insulator (6 Used) | Y—Front Housing Assembly |
| B—Dust Cover | J—Washer (4 Used) | R—Nut (6 Used) | Z—Shaft |
| C—Ground Bolt with Washer | K—Screw (7 Used) | S—Spacer (6 Used) | AA—Woodruff Key |
| D—Battery Stud with Washers | L—Regulator Assembly | T—Stator Assembly | BB—Bearing Cover |
| E—Lock Nut | M—Insulator | U—Lock Nut | CC—Fan |
| F—Insulator | N—Nut (6 Used) | V—Washer | DD—Pulley |
| G—Nut (6 Used) | O—Insulator (6 Used) | W—Rotor | EE—Washer |
| H—Rear Housing | P—Rectifier Assembly | X—Washer | FF—Nut |

Refer to your machine technical manual for removal of alternator.

Continued on next page

RG, RG34710, 2096 -19-15MAR97-1/26


IMPORTANT: Never immerse alternator in cleaning solution. Remove dirt and grease by scraping and using a stiff brush with solvent. Dry with compressed air.

NOTE: Because of the manufacturer's design of the rotor and the field flux noise, this alternator is noisier than others.

Unnecessary disassembly may be prevented by first checking alternator output, shell temperature and pulley nut tension before the decision to disassemble is made. (Refer to your machine Operation and Test manual for complete charging circuit diagnosis.

1. Remove dust cover (A).

NOTE: If alternator is being disassembled for testing, follow Steps 1 through 8 only. Refer to TEST NIEHOFF 12-VOLT, 110-AMP ALTERNATOR COMPONENTS, later in this group.



Remove Dust Cover

A—Dust Cover


RW3274 -UN-02MAR90

20
10
5

RG.RG34710,2096 -19-15MAR97-2/26

2. Remove battery positive bolt (A), negative bolt (B), and lock nut and insulator from terminal (C).

A—Battery Positive Bolt
B—Negative Bolt
C—Terminal



Remove Bolts from Terminal


RW3275 -UN-02MAR90

Continued on next page

RG.RG34710,2096 -19-15MAR97-3/26

3. Remove six lock nuts (A) from studs and pry with screwdriver in detent (B) to lift off rear housing (C).

A—Lock Nuts (6 Used)
B—Detent
C—Rear Housing




Lift Off Rear Housing

RW3276 -UN-02MAR90

RG, RG34710, 2096 -19-15MAR97-4/26

4. Remove two screws (A) to detach compound winding leads.

A—Screws (2 Used)



Detach Compound Winding Leads


RW3277 -UN-02MAR90

Continued on next page

RG, RG34710, 2096 -19-15MAR97-5/26

5. Remove two screws (A) to detach field leads.

A—Screws (2 Used)



Detach Field Leads


RW3278 -UN-02MAR90

20
10
7

RG, RG34710, 2096 -19-15MAR97-6/26

6. Remove three screws (A) with washers at stand-offs.

A—Screws (3 Used)



Remove Screws at Stand-Offs


RW3279 -UN-02MAR90

Continued on next page

RG, RG34710, 2096 -19-15MAR97-7/26

7. Remove three screws with washers (A) to detach regulator (B).

A—Screws with Washers
B—Regulator



Remove Screws to Detach Regulator


RW3280 -UN-02MAR90

RG,RG34710,2096 -19-15MAR97-8/26

8. Loosen three terminal locks (A) and detach stator leads (B).

NOTE: The alternator has now been disassembled for testing. Refer to TEST NIEHOFF 12-VOLT, 110-AMP ALTERNATOR COMPONENTS, later in this group.

A—Terminal Locks (3 Used)
B—Stator Leads



Detach Stator Leads


RW3281 -UN-02MAR90

Continued on next page

RG,RG34710,2096 -19-15MAR97-9/26

9. Remove six nuts (A) and six insulators (B) to detach rectifier assembly.

A—Nuts (6 Used)
B—Insulators (6 Used)



Detach Rectifier Assembly

RW3290 -UN-02MAR90

20
10
9

RG,RG34710,2096 -19-15MAR97-10/26

IMPORTANT: Use soft-jawed vise when clamping pulley.

10. Remove lock nut (A) and hardened washer (B).

A—Lock Nut
B—Hardened Washer



Remove Lock Nut and Washer


RW3291 -UN-02MAR90

Continued on next page

RG,RG34710,2096 -19-15MAR97-11/26

11. Lift rotor (A) from shaft (B).

A—Rotor
B—Shaft




Lift Rotor from Shaft

RW3292 -UN-02MAR90

RG, RG34710, 2096 -19-15MAR97-12/26

12. Remove six insulators (A), six washer nuts (B), and six spacers (C) from studs (D).

A—Insulator
B—Washer Nut
C—Spacer
D—Stud



Remove Insulators, Nuts and Spacers

RW3293 -UN-02MAR90


Continued on next page

RG, RG34710, 2096 -19-15MAR97-13/26

13. Identify wires for reassembly.

IMPORTANT: Note and mark position of compound winding leads (A) and field winding leads (B) to stator (C). All must be in original position for correct assembly.

- A—Compound Winding Leads
- B—Field Winding Leads (White)
- C—Stator



Leads and Stator


RWG3294 -JUN-02MAR90

20
10
11

RG,RG34710,2096 -19-15MAR97-14/26

14. Tap shell (A) lightly with soft hammer to loosen it from front housing assembly (B).

- A—Shell
- B—Housing Assembly



Front Housing Assembly


RWG3295 -JUN-02MAR90

Continued on next page

RG,RG34710,2096 -19-15MAR97-15/26

15. Pry shell (A) from front housing assembly (B).

A—Shell
B—Housing Assembly



Front Housing Assembly

RW3296 -UN-02MAR90

20
10
12

RG, RG34710, 2096 -19-15MAR97-16/26

IMPORTANT: Note and mark the relationship of stator-to-shell before disassembly.

16. Press stator from shell. Use JDG255 Stator Support (A) to support shell (B). Using a punch, tap stator out evenly.

A—JDG255 Stator Support Tool
B—Alternator Shell



Tap Stator Out


RW10426 -UN-10NOV89

Continued on next page

RG, RG34710, 2096 -19-15MAR97-17/26

17. Remove nut and washer to detach pulley (A) and fan (B) from shaft (C).

A—Pulley
B—Fan
C—Shaft



RW3297 -UN-02MAR90

Detach Pulley and Fan

RG, RG34710, 2096 -19-15MAR97-18/26

20
10
13

18. Remove Woodruff key (A) to detach bearing seal cover (B) from shaft (C).

A—Woodruff Key
B—Bearing Seal Cover
C—Shaft



RW3298 -UN-02MAR90

Remove Woodruff Key


Continued on next page

RG, RG34710, 2096 -19-15MAR97-19/26

NOTE: Remove bearings for replacement only, and replace both ball and roller bearings. Bearings are prelubricated by supplier. Use D01061AA Blind Hole Puller Set and ensure full ID contact when removing bearings.

19. Remove snap ring (A).

A—Snap Ring
B—Bearing
C—Shaft




Remove Snap Ring

RW5120 -UN-23FEB90

RG, RG34710, 2096 -19-15MAR97-20/26

20. Remove ball bearing (A). Use 16 mm (5/8 in.) collet (No. 33860).¹

A—Ball Bearing



Remove Ball Bearing

RW3283 -UN-02MAR90


¹From the D01061AA Blind Hole Puller Set.

Continued on next page

RG, RG34710, 2096 -19-15MAR97-21/26

21. Remove roller bearing and seal (A). Use 26—32 mm (1—1-1/4 in.) collet (No. 33863).¹

A—Roller Bearing and Seal



RW3284 -UN-02MAR90

Remove Roller Bearing and Seal

¹From the D01061AA Blind Hole Puller Set.


RG, RG34710, 2096 -19-15MAR97-22/26

20
10
15

To install new alternator bearings:

22. Press roller bearing (A) into front housing assembly. Use 27 mm (1-1/16 in.) pilot disk (B) and 46 mm (1-13/16 in.) driver disk (C) (No. 27500 and 27512).¹

A—Roller Bearing
B—27 mm (1-1/16 in.) Pilot Disk
C—46 mm (1-13/16 in.) Driver Disk (No. 24500 and 27512.) *



RW3286 -UN-02MAR90

New Alternator Bearings

¹ From the D01045AA Bushing, Bearing and Seal Driver Set.


Continued on next page

RG, RG34710, 2096 -19-15MAR97-23/26

IMPORTANT: Seal spring and lip must be visible when seal is properly installed for maximum protection against dust penetration into bearing.

23. Press roller bearing seal (A) into front housing assembly (B) using 54 mm (2-1/8 in.) driver disk (C), (No. 27517).¹

A—Roller Bearing Seal
B—Front Housing Assembly
C—Driver Disk



Roller Bearing Seal


RW3287 -UN-02MAR90

¹ From the D01045AA Bushing, Bearing and Seal Driver Set.

RG, RG34710, 2096 -19-15MAR97-24/26

24. Press ball bearing (A) into front housing using 16 mm (5/8 in.) disk (B) and 40 mm (1-9/16 in.) driver disk (C) (No. 27493 and 27508).¹

A—Ball Bearing
B—16 mm (5/8 in.) Disk
C—40 mm (1-9/16 in.) Driver Disk (No. 27493 and 27508)



Ball Bearing

RW3285 -UN-02MAR90

¹ From the D01045AA Bushing, Bearing and Seal Driver Set.


Continued on next page

RG, RG34710, 2096 -19-15MAR97-25/26

NOTE: Snap ring (A) must be seated completely with flat side against the bearing (B) (bevel is away from bearing).

25. Assemble snap ring (A) to front housing assembly (C).

- A—Snap Ring
- B—Bearing
- C—Front Housing Assembly



RG,RG34710,2096 -19-15MAR97-26/26


20
10
17

Test Niehoff 12-Volt, 110-Amp Alternator Components

1. Test stator windings by measuring resistance in each successive pair of stator phase leads (A) (three pair). Use JT05791 Digital Multimeter to measure resistance.

Less than 0.5 ohm of resistance should be indicated in each pair.

- A—Stator Phase Leads




Continued on next page

RG,RG34710,2097 -19-12SEP02-1/9

2. Test for shorted stator windings by measuring resistance between each stator lead (A) and stator frame (B).

Infinite resistance or "open" should be indicated.

A—Stator Lead
B—Stator Frame



Measure Resistance


RW3266 -UN-02MAR90

RG,RG34710,2097 -19-12SEP02-2/9

NOTE: A resistance reading above or below specification indicates a defective field winding. Front housing and field coil assembly should be replaced.

3. Test field windings (A) for a resistance of 2.9—3.1 ohms and compound windings (B) for less than 0.5 ohms.

A—Field Windings
B—Compound Windings



Test Field Windings

RW11292 -UN-17APR90


Continued on next page

RG,RG34710,2097 -19-12SEP02-3/9

4. Test for shorted field windings to compound windings by measuring resistance between field leads (A) and compound winding leads (B).

Infinite resistance or “open” should be indicated. If a short is indicated, the front housing assembly must be replaced.

A—Field Leads
B—Compound Winding Leads



Measure Resistance

RW3268 -JUN-02MAR90


20
10
19

RG, RG34710, 2097 -19-12SEP02-4/9

5. Test for shorted field windings to front housing assembly by checking resistance between field leads (A) and front housing/shell assembly (B).

Infinite resistance or “open” should be indicated. If a short is indicated, the front housing assembly must be replaced.

A—Field Leads
B—Front Housing/Shell Assembly



Field Leads and Housing/Shell Assembly

RW3269 -JUN-02MAR90


Continued on next page

RG, RG34710, 2097 -19-12SEP02-5/9

NOTE: Evidence of defective diodes require replacement of rectifier diode and rectifier assembly. When checking diodes with a digital meter, use the diode position.

6. Test top plate (A) diodes of rectifier assembly by checking resistance between output terminal (B) and each stator phase terminal (C).

All readings should be of low resistance or infinite resistance, depending on direction of current flow through the diodes.



RW3270 -JUN-02MAR90

Test Top Plate Diodes


- A—Top Plate
- B—Output Terminal
- C—Stator Phase Terminal

RG.RG34710,2097 -19-12SEP02-6/9

7. Test top plate (A) diodes for reverse current flow by reversing test probes at output terminal. Measure resistance between output terminal (B) and stator phase terminals (C).

All readings should be the reverse of those in the preceding step.

- A—Top Plate
- B—Output Terminal
- C—Stator Phase Terminal



RW3271 -JUN-02MAR90

Test Top Plate Diodes


Continued on next page

RG.RG34710,2097 -19-12SEP02-7/9

8. Test the lower plate (A) diodes of the rectifier assembly by checking the resistance between output terminal (B) and stator phase terminals (C).

All readings should be infinite or low depending on direction of current flow through the diodes.

A—Lower Plate
B—Output Terminal
C—Stator Phase Terminals



Test Lower Plates Diodes

RW3272 -UN-02MAR90


20
10
21

RG, RG34710, 2097 -19-12SEP02-8/9

9. Test lower plate (A) diodes for reverse current flow by reversing probes at output terminal (B) and stator phase terminals (C).

All readings should be the reverse of those in the preceding step.

Example: An infinite reading in this step should have been a low resistance reading in step 8. If the same reading is indicated in steps 6 and 7 or 8 and 9, defective diodes are evident and the rectifier assembly must be replaced.



Test Lower Plate Diodes

A—Lower Plate
B—Output Terminal
C—Stator Phase Terminal

RW3273 -UN-02MAR90

RG, RG34710, 2097 -19-12SEP02-9/9

Assemble Niehoff 12-Volt, 110-Amp Alternator

NOTE: Apply **LOCTITE® 222 Thread Lock and Sealer** (low strength) on all cap screws and nuts when assembling alternator.

1. Assemble roller bearing cover (B) to shaft (C) and insert Woodruff key (A) in slot.

A—Woodruff Key
B—Roller Bearing Cover
C—Shaft



Assemble Roller Bearing Cover

RW3298 -UN-02MAR90

LOCTITE is a registered trademark of Loctite Corp.


RG, RG34710, 2098 -19-15MAR97-1/10

2. Assemble fan (B) and pulley (A) to shaft (C). Tighten lock nut to specifications.

Specification

Fan Pulley Lock Nut—Torque..... 95 N•m (70 lb-ft)

A—Pulley
B—Fan
C—Shaft



Assemble Fan and Pulley

RW3297 -UN-02MAR90


Continued on next page

RG, RG34710, 2098 -19-15MAR97-2/10

IMPORTANT: Note your marked position of shell to stator as in disassembly.

3. Assemble stator (A) to shell (B), by tapping evenly around outside edge.

A—Stator
B—Shell



RW10427

Assemble Stator to Shell

RW10427 -UN-10NOV89

RG, RG34710, 2098 -19-15MAR97-3/10


20
10
23

IMPORTANT: Note your marked position of shell (A) to front housing (B) as in disassembly. Also note the way compound winding leads (C) and field winding leads (D) are threaded through stator (E). All must be in the original position before shell is seated onto front housing assembly.

4. Fill front and rear grease reservoir two-thirds full of high temperature, silicone-base grease.

Assemble shell (A) to front housing (B).

A—Shell
B—Front Housing
C—Compound Winding Lead
D—Field Winding Lead
E—Stator



Assemble Shell


RW3301 -UN-02MAR90

Continued on next page

RG, RG34710, 2098 -19-15MAR97-4/10

IMPORTANT: Be sure to assemble spacer, nuts, insulators and rectifier assembly to alternator, in the order shown.

- A—Spacer
- B—Nut
- C—Insulator
- D—Rectifier Assembly
- E—Insulator
- F—Nut
- G—Stud



Assemble Hardware

RW3299 -UN-12MAY89


RG, RG34710, 2098 -19-15MAR97-5/10

5. Assemble six spacers and six washer nuts. Tighten washer nuts (A) to specifications.

Specification

Front Housing-to-Stator Shell
Nuts—Torque 3.4 N•m (30 lb-in.)

A—Washer Nuts (6 Used)



Tighten Washer Nuts


RW3303 -UN-02MAR90

Continued on next page

RG, RG34710, 2098 -19-15MAR97-6/10

6. Assemble six insulators (A) to studs (D).

- A—Insulators
- B—Washer Nuts
- C—Spacer
- D—Studs



Assemble Insulators


RW3293 -UN-02MAR90

20
10
25

RG, RG34710, 2098 -19-15MAR97-7/10

7. Assemble rotor (A) and washer (B) to shaft (C).

- A—Rotor
- B—Washer
- C—Shaft



Assemble Rotor and Washer to Shaft

RW3288 -UN-02MAR90


Continued on next page

RG, RG34710, 2098 -19-15MAR97-8/10

8. Assemble hardened washer (B) and nut (A). Tighten to specifications.

Specification
Rotor Nut—Torque 68 N•m (50 lb-ft)

A—Nut
B—Hardened Washer



Hardened Washer and Nut


RW3291 -UN-02MAR90

RG,RG34710,2098 -19-15MAR97-9/10

IMPORTANT: Coat all screw heads on regulator and rectifier assembly with silicone rubber compound.

9. Assemble remaining alternator parts in reverse order of disassembly, starting with step 9 back to step 1.

Specification
Regulator Field Lead-to-Standoff
Screw and Y-Lead-to-Load Dump
Screw—Torque..... 0.9—1.1 N•m (8—10 lb-in.)
Output and Relay
Leads-to-Standoff Screw—Torque 2.3 N•m (20 lb-in.)
Ground Lead-to-Load Dump
Screw—Torque..... 1.1—1.7 N•m (10—15 lb-in.)
Flanged Nuts—Torque 5.1 N•m (45 lb-in.)



Assemble Remaining Parts

A—Nuts (6 Used)
B—Insulators (6 Used)

RW3290 -UN-02MAR90

10. Refer to your machine technical manual for alternator installation.

RG,RG34710,2098 -19-15MAR97-10/10


20
10
26

Establish Magnetic Field

NOTE: This action will take only a few seconds.

Connect alternator ground stud (A) to field coil through inspection hole (B) while alternator output is connected to battery positive post and alternator ground is connected to battery negative post.

A—Alternator Ground Stud
B—Inspection Hole



Establish Magnetic Field

RW3305 -UN-12MAY89

RG, RG34710, 2099 -19-15MAR97-1/1

20
10
27

20
10
28

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B70 -19-08MAY02-1/5

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

20
15
1

OUO1004,0000B70 -19-08MAY02-2/5

Alternator, Generator, Starter and Battery Bench Tester JT01760


Test alternators and starters for voltage, resistance, or current flow.

Continued on next page

OUO1004,0000B70 -19-08MAY02-3/5

Blind Hole Puller Set D01061AA

Remove bearings from front housing assembly.



RG11161 -UN-21SEP00

OUC1004,0000B70 -19-08MAY02-4/5

20
15
2

Bushing, Bearing and Seal Driver Set D01045AA

Install bearings in front housing assembly.



RG11162 -UN-21SEP00

OUC1004,0000B70 -19-08MAY02-5/5

Other Material

Number	Name	Use
TY16285 (U.S.) CXTY24311 (Canadian) 222 (LOCTITE®)	Thread Lock and Sealer (Low Strength)	Apply to all cap screws and nuts when assembling alternator.
	High Temperature, Silicone Base Grease	Fill front and rear grease reservoir in alternator housing.
	Silicone Rubber Compound	Apply to all internal wiring lead cap screws.

LOCTITE is a registered trademark of Loctite Corp.

OOU1004,0000B72 -19-21SEP00-1/1

20
15
3

Niehoff 24-Volt Charging Circuit Repair Specifications

Item	Measurement	Specification
Pulley Nut	Torque	95 N•m (70 lb-ft)
Rotor Nut	Torque	75 N•m (55 lb-ft)
Front Housing-to-Stator Nuts	Torque	3.4 N•m (30 lb-in.)
Rotor-to-Stator Poles	Minimum Air Gap	0.13 mm (0.005 in.)
Rotor Housing Stud Ground Lead Nut	Torque	2.8—3.4 N•m (25—30 lb-in.)
Field Lead-to-Regulator Stand-Off Cap Screw	Torque	0.91—1.1 N•m (8—10 lb-in.)
Output and Relay Lead Cap Screws	Torque	2.3 N•m (20 lb-in.)
Ground Lead-to-Load Dump Screw	Torque	1.1—1.7 N•m (10—15 lb-in.)
Y-Lead-to-Load Dump Screw	Torque	0.9—1.1 N•m (8—10 lb-in.)
Load Dump Assembly Mounting Cap Screws	Torque	0.9—1.1 N•m (8—10 lb-in.)
Rear Housing Flange Nuts	Torque	5.1 N•m (45 lb-in.)

OOU1004,0000B73 -19-21SEP00-1/1



Niehoff 24-Volt Charging Circuit Test Specifications

John Deere Alternator Part No.	Niehoff Alternator Model No.	Ground	Voltage	Rated Output (Amps)	Winding Resistance @ 21—27°C (70—80°F) (Ohms)
AT56873	N-1031	N	24	50	9.0—11.0
AT53676	N-1108	N	24	70—80 ^a	11.0—13.0

^aAlternator output is adjustable on this model.

RG, RG34710, 2102 -19-07JUL05-1/1

Disassemble Niehoff 24-Volt, 50-Amp Alternator and Test Components



Niehoff 24-Volt, 50-Amp Alternator

- | | | | |
|---|------------------------------|--------------------------------------|------------------------------|
| 1—Pulley Nut | 14—Shorter Stud | 28—Regulator Assembly | 38—No. 6 Cap Screw |
| 2—Hardened Washer | 15—Longer Stud (2 Used) | 29—Spring Washer (4 Used) | 39—Gasket |
| 3—Pulley | 16—Rear Bearing | 30—Double Chamfered Hex Nut (3 Used) | 40—Voltage Adjust Cover |
| 4—Fan | 17—Retaining Ring | 31—No. 6 Cap Screw (2 Used) | 41—Red Insulator |
| 5—Shaft Key | 18—Flat Washer (2 Used) | 32—No. 10 Cap Screw (2 Used) | 42—Output Stud |
| 6—Shaft | 19—Lock Nut | 33—No. 8 Cap Screw | 43—Rear Housing |
| 7—Shaft Seal | 20—Flanged Hex Nut (3 Used) | 34—Spring Washer (8 Used) | 44—No. 6 Cap Screw |
| 8—Front Bearing | 21—Spacer (3 Used) | 35—No. 6 Cap Screw (3 Used) | 45—Nameplate Cover |
| 9—Cap Screw (4 Used) | 22—Hardened Washer | 36—Insulator | 46—White Insulator |
| 10—Terminal Lock (7 Used) | 23—Stator and Shell Assembly | 37—Single Flanged Hex Nut (3 Used) | 47—Flat Washer |
| 11—Cap Screw (7 Used) | 24—Rotor | | 48—Lock Nut |
| 12—Heat Sink Assembly | 25—Hardened Washer | | 49—Rubber Relay Terminal Cap |
| 13—Front Housing and Field Winding Assembly | 26—Ground Lead | | |
| | 27—Lock Nut | | |

Continued on next page

RG.RG34710,2103 -19-15MAR97-1/13


20
15
5

T6090AX -UN-25MAY89

NOTE: The alternator does not have to be completely disassembled to test components.

1. Remove parts (1—7) to remove cover.

- 1—Cover
- 2—Lock Nut (3 Used)
- 3—Voltage Adjusting Screw
- 4—Output Terminal
- 5—Name Plate Cover Cap Screw
- 6—Regulator Support Screw
- 7—Relay Terminal




Remove Alternator Parts

T6090AP -UN-29MAR90

RG, RG34710, 2103 -19-15MAR97-2/13

2. Remove insulation from screw heads.
3. Remove screws (1) and spring washers.
4. Turn load dump (2) over and remove insulation from wire connections.

- 1—Screws (3 Used)
- 2—Load Dump



Load Dump

T6090AT -UN-29MAR90


Continued on next page

RG, RG34710, 2103 -19-15MAR97-3/13

5. Disconnect wiring leads (4 and 6) to remove load dump (5).

6. Disconnect wiring leads (1, 2, and 3).

- 1—Relay Lead (Brown)
- 2—Field Lead (White)
- 3—Output Lead (Red)
- 4—Ground Lead (White)
- 5—Load Dump
- 6—Y-Lead (Brown)



T6090A02 -JUN-29MAR90

Remove Load Dump


20
15
7

RG, RG34710, 2103 -19-15MAR97-4/13

7. Put alternator pulley in a vise. Use an oversize belt on pulley for protection or use a soft-jawed vise.

8. Remove parts (1—4).

- 1—Nut
- 2—Hardened Washer
- 3—Pulley
- 4—Fan



T6104AB -JUN-25MAY89


Remove Parts

Continued on next page

RG, RG34710, 2103 -19-15MAR97-5/13

9. Disconnect wire leads (1—3).
10. Adjust ohmmeter to zero and check for continuity between each of the black phase leads (1). If there is no continuity, the stator is open and must be replaced.
11. Check for continuity between each phase lead (1—3) and alternator housing. If there is continuity, the stator is grounded and must be replaced.

- 1—Black Phase Leads
- 2—Phase Lead
- 3—Phase Lead




Check for Continuity

T6103AH -UN-02APR90

RG,RG34710,2103 -19-15MAR97-6/13

12. Adjust ohmmeter to zero. Check for 9—13 ohms resistance between white field lead (1) and thinner red field lead (2). If resistance is not within specification, the coil or assembly must be replaced.
13. Check for continuity between either field lead and alternator housing. If there is continuity, replace the forging and coil assembly and field coil.

- 1—White Field Lead
- 2—Red Field Lead



Field Leads


T6103BK -UN-02APR90

Continued on next page

RG,RG34710,2103 -19-15MAR97-7/13

14. Make sure all leads are disconnected from, and are not touching, the heat sink assembly.
15. Check continuity between output terminal (1) and each phase lead terminal (2). All readings should be the same.
16. Reverse leads and repeat step 15. All readings must be opposite of those recorded in step 15. If any reading is the same as in step 15, one or more diodes are defective and heat sink must be replaced.

1—Output Terminal
2—Phase Lead Terminal



Check Continuity


T6103BJ -UN-02APR90

RG,RG34710,2103 -19-15MAR97-8/13

20
15
9

17. Check continuity between phase terminals (1) and alternator housing. All readings must be the same.
18. Reverse probes and repeat step 17. If any reading is the same as in step 17, a diode is defective and the heat sink must be replaced.
19. Remove heat sink (2).

1—Phase Terminals
2—Heat Sink



Check Continuity


T6103BH -UN-02APR90

Continued on next page

RG,RG34710,2103 -19-15MAR97-9/13

20. Remove nuts (1) to remove regulator (2).

- 1—Nuts
- 2—Regulator




T6090A01 -JUN-29MAR90

Remove Nuts to Remove Regulator

RG, RG34710, 2103 -19-15MAR97-10/13

21. Remove parts (1—5).

- 1—Nut
- 2—Special Washer (2 Used)
- 3—Rotor
- 4—Alternator
- 5—Shaft Assembly



T6090AU -JUN-29MAR90

Remove Parts


Continued on next page

RG, RG34710, 2103 -19-15MAR97-11/13

NOTE: Remove bearings and seal only for replacement.

22. Remove shaft seal (1) and front bearing (2) using a D01061AA Blind Hole Puller Set.
23. Remove snap ring (4) and rear bearing (3).

- 1—Shaft Seal
- 2—Front Bearing
- 3—Rear Bearing
- 4—Snap Ring



T6090AY -UN-25MAY89

RG, RG34710, 2103 -19-15MAR97-12/13


20
15
11

24. Remove nuts from studs (3).
25. Hold front housing (1) upward and lightly tap housing using a soft-faced hammer to remove shell (2).

NOTE: DO NOT soak front housing in solvent; wipe with clean cloth.

26. Clean and inspect all parts for damage. Replace parts as necessary.

- 1—Front Housing
- 2—Shell
- 3—Studs



T6090AL1 -UN-29MAR90


RG, RG34710, 2103 -19-15MAR97-13/13

Assemble Niehoff 24-Volt, 50-Amp Alternator

NOTE: Apply **LOCTITE® 222 Thread Lock and Sealer (low strength)** on all cap screws and nuts when assembling alternator.

1. Install short threaded end of studs (1 and 2) into housing (3). Install shorter stud (1) in hole below mounting ear.

- 1—Shorter Stud
- 2—Longer Stud
- 3—Housing



Assemble Alternator

T6099AP -UN-29MAR90

LOCTITE is a registered trademark of Loctite Corp.

RG.RG34710,2104 -19-15MAR97-1/9

2. Align ground terminal (4) with shorter stud (2) and phase and output leads (3) toward front housing (1).

3. Put shell assembly on stud.


4. Put phase and output leads (3) through opening in front housing (1).

5. Push shell assembly against housing.

6. Tap shell with a soft-faced hammer until shell seats in front housing.

IMPORTANT: If the thicker stud nuts are not used, the regulator support screw and threads will engage when installing cover.

7. Loosely install three thicker flange head nuts.



Shell Assembly

- 1—Front Housing and Field Winding Assembly
- 2—Shorter Stud
- 3—Phase and Output Leads
- 4—Ground Terminal
- 5—Longer Stud (2 Used)

T6099AQ -UN-25MAY89

Continued on next page

RG.RG34710,2104 -19-15MAR97-2/9

8.

Fill front and rear grease reservoir two-thirds full of high-temperature, silicone-base grease.

9. Press front bearing (3) into housing (4) using a 44 mm disk (1) (from D01045AA Bushing, Bearing and Seal Driver Set) and press.


10. Put high-temperature, silicone-base grease on seal lip and fill space between front bearing and seal.

11. Position seal (2) with open side toward front bearing and press seal into housing using a 44 mm disk (1).


12. Position rear bearing (5) with open side toward housing.

13. Press rear bearing into alternator using a 38 mm disk and press.

- 1—44 mm Disk
- 2—Seal
- 3—Front Bearing
- 4—Alternator Housing
- 5—Rear Bearing



Press Seal into Housing




Position Rear Bearing

RG, RG34710, 2104 -19-15MAR97-3/9

14. Install snap ring (2) with flat side against bearing (1) in housing core (3).

- 1—Bearing
- 2—Snap Ring
- 3—Housing Core



Install Snap Ring

Continued on next page

RG, RG34710, 2104 -19-15MAR97-4/9

15. Install key (5) in shaft (6).


16. Assemble parts (1—6) and tighten nut (1) to specifications.

Specification

Pulley Nut—Torque 95 N•m (70 lb-ft)

17. Put high-temperature, silicone-base grease on shaft large area.

- 1—Pulley Nut
- 2—Special Washer
- 3—Pulley
- 4—Fan
- 5—Shaft Key
- 6—Shaft



Assemble Parts

T6099AO -UN-25MAY89

RG, RG34710, 2104 -19-15MAR97-5/9

18. Carefully put shaft assembly (5) in front housing (4).

19. Assemble parts (1—3) and tighten rotor nut to specifications.

Specification


Rotor Nut—Torque 75 N•m (55 lb-ft)

IMPORTANT: Correct rotor-to-stator clearance is essential to operation of alternator.

20. Put a 25 x 76 mm (1 x 3 in.) piece of 0.2 mm (0.008 in.) shim stock between each pole of the rotor and adjacent poles of stator.

IMPORTANT: Shims must not overlap.

21. Move stator in shell for best free movement of shims.



Assemble Parts

- 1—Rotor Nut
- 2—Special Washer (2 Used)
- 3—Rotor
- 4—Front Housing and Field Winding Assembly
- 5—Shaft Assembly

T6090AU -UN-29MAR90

Continued on next page

RG, RG34710, 2104 -19-15MAR97-6/9

22. Tighten the three thicker flange hex nuts (2) to specifications.

Specification

Front Housing-to-Stator Nuts—
Torque 3.4 N•m (30 lb-in.)

23. Remove shims and check air gap between rotor and stator poles.

Specification

Rotor-to-Stator Poles—Minimum
Air Gap 0.13 mm (0.005 in.)

24. Install spacers (3).


25. Put white ground lead (4) on longer stud on alternator right side.

26. Install regulator assembly (5) on studs with the four voltage adjustment stand-offs toward ground terminal.

27. Install spring washers (6) and nuts (7). Tighten to specifications.

Specification

Rotor Housing Stud Ground Lead
Nut—Torque 2.8—3.4 N•m (25—30 lb-in.)



Assemble Parts

- 1—Stud
- 2—Flange Hex Nut (3 Used)
- 3—Spacer (3 Used)
- 4—Ground Lead (White)
- 5—Regulator
- 6—Spring Washer (3 Used)
- 7—Double Chamfered Nut (3 Used)

20
15
15

T6090AW -UN-25MAY89

Continued on next page

RG, RG34710, 2104 -19-15MAR97-7/9

28. Attach field lead (2) to regulator stand-off. Tighten screws to specifications.

Specification

Field Lead-to-Regulator Stand-Off
Cap Screw—Torque..... 0.91—1.1 N•m (8—10 lb-in.)

29. Install output leads (3), relay lead (1), spring washers, and screws. Tighten screws to specifications.

Specification

Output and Relay Lead Cap
Screws—Torque..... 2.3 N•m (20 lb-in.)

30. Install ground lead (4), spring washer, and screw. Tighten screw to specifications.

Specification

Ground Lead-to-Load Dump
Screw—Torque..... 1.1—1.7 N•m (10—15 lb-in.)

31. Install Y-lead (6), spring washer, and screw. Tighten screw to specifications.

Specification

Y-Lead-to-Load Dump Screw—
Torque 0.9—1.1 N•m (8—10 lb-in.)


32. Put silicone rubber compound on all connections.

33. Install load dump, spring washers, and screws. Tighten screws to specifications.

Specification

Load Dump Assembly Mounting
Cap Screws—Torque 0.9—1.1 N•m (8—10 lb-in.)

34. Put silicone rubber compound on load dump screws.



Leads

- 1—Relay Lead (Brown)
- 2—Field Lead (White)
- 3—Output Lead (Red)
- 4—Ground Lead (White)
- 5—Load Dump Assembly
- 6—Y- Lead (Brown)
- 7—Regulator
- 8—Nut (3 Used)

T6090AO -UN-29MAR90

20
15
16

Continued on next page

RG, RG34710, 2104 -19-15MAR97-8/9

35. Install housing and tighten nuts (2) to specifications.

Specification

Rear Housing Flange Nuts—
Torque 5.1 N•m (45 lb-in.)

36. Install voltage adjusting screw (3), spring washer, and cover (1).

37. Install regulator support screw (6) and spring washer.

38. Install plate cover and screws (5).


39. Install flat washer, nut and cover on relay terminal (7).

40. Install output stud (4).

41. If rotor and stator were removed from alternator during repair, the magnetic field must be re-established. (See REESTABLISHING MAGNETIC FIELD, later in this group.)

42. Install alternator. (See your machine technical manual.)

- 1—Cover
- 2—Lock Nut (3 Used)
- 3—Voltage Adjusting Screw
- 4—Output Terminal
- 5—Name Plate Cover Cap Screw
- 6—Regulator Support Screw
- 7—Relay Terminal



Components


T6090AP -UN-29MAR90

20
15
17


Re-Establish Magnetic Field

1. Remove voltage adjustment cover.
2. Connect battery positive terminal to alternator output and battery negative terminal to alternator ground.
3. Make a jumper wire (1) with an alligator clamp. Remove 1.5 mm (1/16 in.) of insulation (2) from end of wiring lead.
4. Connect clamp to ground stud (3) and put the other end of wiring lead momentarily into hole (4) in end of housing.
5. Remove jumper wire. Disconnect cables and install cover.
6. After alternator is installed, check that magnetic field has been established. Turn key switch on, then check voltage reading (battery voltage) on voltmeter.

Start engine, then check voltage reading (charging voltage) on the voltmeter. Charging voltage must be higher than battery voltage to indicate magnetic field has been established.



Jumper Wire and Insulation



Ground Stud

- 1—Jumper Wire
- 2—1.5 mm (1/16 in.)
- 3—Ground Stud
- 4—Hole In Housing

T6100AV -UN-25MAY89

T6100AU -UN-29MAR90

RG, RG34710, 2105 -19-15MAR97-1/1

Section 25

Denso Alternators

Contents

	Page		Page
Group 05—Denso Alternator Theory of Operation			
Denso Alternator Operation	25-05-1		
Denso Regulator Operation	25-05-2		
Group 10—Denso Alternator with Add-On Regulator Repair			
Essential Tools	25-10-1		
Other Material	25-10-2		
Denso Charging Circuit Repair			
Specifications (Alternators with Add-On Regulator)	25-10-2		
Denso Charging Circuit Test			
Specifications (Alternators with Add-On Regulator)	25-10-2		
Disassemble Denso Alternator with Add-On Regulator and Test Components	25-10-3		
Separate Housing	25-10-4		
Separate Housing and Remove Rear Bearing	25-10-5		
Inspect Rear Bearing	25-10-8		
Install Rear Bearing	25-10-8		
Remove Stator, Rectifier Bridge and Brush Assembly	25-10-8		
Test Brush Assembly	25-10-9		
Install New Brushes	25-10-11		
Inspect Stator	25-10-11		
Test Stator for Grounds	25-10-12		
Test Stator for Open or Short	25-10-12		
Test Diodes in Rectifier Bridge	25-10-13		
Test Diodes for Open or Short Circuit	25-10-13		
Test Diode/Resistor Trio	25-10-14		
Connect Stator Windings	25-10-15		
Test Regulator	25-10-15		
Assemble Rear Frame	25-10-16		
Remove Pulley Nut	25-10-17		
Remove and Inspect Front Bearing	25-10-17		
Install Front Bearing Assembly	25-10-18		
Test Rotor for Grounds	25-10-18		
Test Rotor for Open or Shorted Circuits	25-10-19		
Recondition Slip Rings	25-10-19		
Install Rotor and Front Housing	25-10-20		
Install Pulley Assembly	25-10-21		
Install Regulator	25-10-21		
Group 15—Denso Alternator with Built-In Regulator Repair			
Essential Tools	25-15-1		
Other Material	25-15-2		
Denso Charging Circuit Repair			
Specifications (Alternators with Built-In Regulator)	25-15-3		
Denso Charging Circuit Test			
Specifications (Alternators with Built-In Regulator)	25-15-4		
Disassemble and Test Denso Alternator with Built-In Regulator	25-15-5		
Disassemble Alternator	25-15-6		
Assemble Denso Alternator	25-15-12		

25

Denso Alternator Operation


The drawing at right shows alternator circuitry. Schematic of regulator (E) has been simplified.

An alternator (unlike generator) uses a rotating magnetic field with stationary windings. The magnetic field is externally excited. This means that it requires an outside current source. The rotor (F) consists of two interlocking soft iron sections and a wire coil wrapped around an iron core. When current is passed through the wire coil, the rotor becomes an electromagnet.

The rotating magnetic field induces an alternating current in the stator windings (G). This is converted to direct current by six diodes in the rectifier bridge (H).

A capacitor inside rear housing protects rectifier bridge and diode trio (D) from voltage surges. It also suppresses radio interference.

This alternator uses an "A" field circuit with regulator located after field. Full output is obtained by grounding field.



Denso Alternator Operation

- A—Diode
- B—Switch
- C—Battery
- D—Diode Trio
- E—Regulator
- F—Rotor (Field)
- G—Stator
- H—Rectifier Bridge

RW10118L -JUN-29NOV89

25
05
1


Denso Regulator Operation

The solid-state regulator is mounted inside the alternator. It controls output by controlling the current through the field. In operation, the regulator has the following three phases.

Phase I—Alternator Stopped

(Phase I also applies when alternator is running but only if not running fast enough for output to exceed battery voltage.)

1. Current flows from battery through key switch and diode to terminal IG.
2. From there, current flows through resistor R1 to transistor TR1 and turns it on.
3. Transistor TR1 then provides a path to ground so current can flow through field, enabling alternator to generate electricity.
4. Zener diode Z prevents flow of current from terminal IG to transistor TR2. A Zener diode is a special type of diode which will not permit current to pass until voltage reaches a certain preset level. If voltage exceeds that level, current can pass through the Zener diode.



Phase I—Alternator Stopped

RW10119L -UN-29NOV/89


Continued on next page

RG, RG34710, 2107 -19-18OCT00-1/3

25
05
2

Phase II—Generating Electricity

1. The diode trio, key switch, rectifier bridge, and terminal 1 all have equal voltage. Therefore, no current flows through diodes.
2. Current, now coming from diode/resistor trio, still flows through resistor R1 to turn on transistor TR1.
3. Transistor TR1 still provides a path to ground so current can flow through field, enabling alternator to generate electricity.
4. Since the field is rotating, it does generate electricity. Alternating current is induced in the stator windings. The rectifier bridge converts it to direction current, providing current to run electrical accessories and charge batteries.
5. Output voltage still has not reached critical voltage of Zener diode Z, so no current can flow from terminal 2 to transistor TR2.




Phase II—Generating Electricity

RG, RG34710, 2107 -19-18OCT00-2/3

25
05
3

Phase III—Shut-Off

1. Output voltage reaches critical voltage of Zener diode Z.
2. Current can now pass through Zener diode Z to turn on transistor TR2.
3. Transistor TR2 now provides a direct path to ground for any current coming through resistor R1.
4. This cuts off the current to transistor TR1, turning it off. There is now no path to ground for current through field.
5. Current through field is shut off instantly, and alternator stops generating electricity.
6. Phases II and III are repeated many times per second to maintain voltage at proper level.



Phase III—Shut-Off

RG, RG34710, 2107 -19-18OCT00-3/3

Denso Alternator with Add-On Regulator Repair

Group 10

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B74 -19-08MAY02-1/4

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -UN-12DEC88

25
10
1

OUO1004,0000B74 -19-08MAY02-2/4

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B74 -19-08MAY02-3/4

Alternator Pulley Tool Set JD306A

Remove and install alternator pulley retaining nut.

RG12198 -UN-17JUL02



JD306A

OUO1004,0000B74 -19-08MAY02-4/4

Denso Alternator with Add-On Regulator Repair

Other Material

Number	Name	Use
	Chevron SR1-2 Grease	Lubricate alternator bearings.
	400-Grit Silicon Carbide Paper or 00 Sandpaper	Polish slip rings.

OUO1004,0000B76 -19-21SEP00-1/1

**Denso Charging Circuit Repair Specifications
(Alternators with Add-On Regulator)**

Item	Measurement	Specification
Used Brushes	Minimum Exposed Length	6 mm (0.25 in.)
New Brushes	Exposed Length	16 mm (0.625 in.)
Pulley Nut	Torque	66—87 N•m (50—65 lb-ft)

OUO1004,0000B77 -19-21SEP00-1/1

**Denso Charging Circuit Test Specifications
(Alternators with Add-On Regulator)**


John Deere Alternator Part No.	Denso Alternator Part No.	Voltage	Rated Output (Amps)
AN193461	100211—5800	12	90
AR87205	100211—0081	12	90
AR93448	100211—0290, 100211—0291	12	90
AT103789	100211—0292	12	90

Item	Specification
Regulator Output Voltage	13.8—14.8 volts

NOTE: Earlier Denso alternators may have the original Nippondenso label.

RG, RG34710, 2110 -19-07JUL05-1/1

Disassemble Denso Alternator with Add-On Regulator and Test Components



Denso Alternator

- | | | | |
|------------------------|----------------------|-------------------------|------------------|
| A—Fan | G—Bearing Retainer | M—Regulator Cover | S—Insulator |
| B—Front Housing | H—Condenser | N—Through Bolt (4 Used) | T—Brush (2 Used) |
| C—Felt Washer (2 Used) | I—Insulating Bushing | O—Rear Housing | U—Stator |
| D—Collar (2 Used) | J—Insulating Bushing | P—Felt Washer | V—Rear Bearing |
| E—Front Bearing | K—Rear Cover | Q—Insulating Bushings | W—Felt Washer |
| F—O-Ring | L—Voltage Regulator | R—Rectifier Bridge | X—Rotor |

Disassemble alternator only after making an external examination and performing alternator tests outlined in your machine technical manual.

Refer to your machine technical manual for removal of alternator from engine.

IMPORTANT: Never immerse alternator in cleaning solvent. Remove dirt and grease by scraping and using a stiff brush with solvent. Dry with compressed air.

R31563 -JUN-13APR89

25
10
3

RG, RG34710, 2111 -19-15MAR97-1/1


Separate Housing

1. Remove four through bolts (A).

NOTE: Pulley need not be removed at this time. See REMOVE PULLEY NUT in this group if only pulley service is required.

IMPORTANT: Inserting screwdriver blade farther than 1.6 mm (1/16 in.) may damage stator windings.

2. Separate front and rear housings. Carefully pry between the two end frames with a screwdriver on each side.
3. If housings separate, set alternator on rear housing and slide off from housing; go to INSPECT REAR BEARING, later in this group.
4. In some cases, removing the rotor and rear bearing may be difficult. A vacuum may be created in the bearing cavity as the bearing and rotor are removed. If this happens, see SEPARATE HOUSING AND REMOVE REAR BEARING, later in this group.



Remove Through Bolts

A—Through Bolts (4 Used)


RG, RG34710, 2112 -19-15MAR97-1/1

Separate Housing and Remove Rear Bearing

IMPORTANT: Mark must be centered to prevent off-center drilling of rotor shaft if tapping is later required. (See step 3 below.)

1. Carefully center punch and drill a 2 mm (1/16 in.) hole (A) in the center of the rear housing. This will allow air into the bearing bore as bearing is removed.

A—Center Punch On Center
B—19 mm (0.741 in.)
C—28 mm (1.092 in.)



Center Punch

RW12623 -JUN-10NOV88


25
10
5

Continued on next page

RG, RG34710, 2113 -19-15MAR97-1/4

Again try to remove rotor and bearing. If rotor and bearing still cannot be removed, go to step 2. If bearing remains in end frame, do the following;

- a. Install a pin (A) to hold brushes fully retracted.
 - b. Fill cavity behind bearing with grease through bearing bore. Place end frame on a hard, flat surface. Place a 12 mm (0.47 in.) screw or rod into bearing bore.
 - c. Strike end of screw or rod sharply with a hammer to hydraulically remove the bearing. Filling the cavity four to six times may be required to completely remove the bearing. Continue repairing alternator as detailed under INSPECT REAR BEARING later in this group.
2. Enlarge drilled hole with a 1/4 in. drill, 13 mm (1/2 in.) deep.
 3. Measure length of a 1/16-27 NPT tap (JDG417, or equivalent) . Turn tap in hole until exposed end is 10—11 mm (0.390—0.430 in.) less than total length of tap.



A—Pin
B—Alternator

RW6054 -UN-10NOV88

Continued on next page

RG, RG34710, 2113 -19-15MAR97-2/4

4. Install a 1/16-27 NPT grease zerk (A) firmly in tapped hole.
5. Attach a grease gun to zerk and fill bearing cavity with grease. Extend handle of grease gun and apply several quick, pumping strokes until alternator frame and stator separate approximately 3—6 mm (1/8—1/4 in.)

IMPORTANT: Inserting screwdriver blade farther than 1.6 mm (1/16 in.) may damage stator windings.

6. Using two screwdrivers, complete alternator separation by prying between stator and front end frame.
7. Set alternator on rear housing and lift front housing.



1/16-27 NPT Grease Zerk

A—Grease Zerk


RW12628 -UN-18APR90

RG, RG34710, 2113 -19-15MAR97-3/4

25
10
7

8. Remove grease zerk and install a 15H560 Allen plug (A) in drilled hole. If plug extends into bearing cavity more than 2 mm (1/6 in.), grind a taper on end of plug and reinstall. Continue repairing alternator at INSPECT REAR BEARING, later in this group.

A—15H560 Allen Plug



15H560 Allen Plug

RW12627 -UN-18APR90

RG, RG34710, 2113 -19-15MAR97-4/4

Inspect Rear Bearing

1. Check bearing ID and OD for damage.
2. Make sure bearing turns freely.


Replace bearing as required.

RG.RG34710.2114 -19-15MAR97-1/1

Install Rear Bearing

IMPORTANT: Do not clean bearing in solvent.

1. Install a pin to hold brushes fully retracted. Clean grease and chips from bearing cavity.
2. Wipe bearing (A), bearing cavity and felt washers (B) with a clean cloth.
3. Coat bearing with a thin coat of grease to aid in installation of bearing in rear housing.
4. If a small hole 2 mm (1/16 in.) was drilled during disassembly, seal with a silicone sealer to prevent contaminant entry.



Install Rear Bearing

A—Bearing
B—Felt Washers


RW12629 -UN-10NOV88

RG.RG34710.2115 -19-15MAR97-1/1

Remove Stator, Rectifier Bridge and Brush Assembly

1. Remove screws (A), regulator cover (B) and regulator (C).
2. Disconnect condenser wire (D) and remove condenser.

A—Screws
B—Regulator Cover
C—Regulator
D—Condenser Wire



Regulator Components


RW10654 -UN-10NOV88

Continued on next page

RG.RG34710.2116 -19-15MAR97-1/2

3. Remove four nuts (A), insulators (B), condenser (C) and rear cover (D).
4. Lift out stator, rectifier bridge and brush assembly.

A—Nuts
B—Insulators
C—Condenser
D—Rear Cover



Lift Out Parts

RW6043 -UN-10NOV88

RG, RG34710, 2116 -19-15MAR97-2/2

Test Brush Assembly

1. Inspect assembly for damage. Be sure brushes slide freely. Be sure springs hold brushes firmly against slip rings.



Inspect Brush Assembly

25
10
9

R7811K1 -UN-31JAN89

Continued on next page

RG, RG34710, 2117 -19-15MAR97-1/3

2. Measure brushes for wear. If exposed length is not within specification, replace brushes.

Specification

Used Brushes—Minimum
Exposed Length..... 6 mm (0.25 in.)




Measure Brushes for Wear

R78111L1 -JUN-31JAN89

RG.RG34710,2117 -19-15MAR97-2/3

3. Connect ohmmeter (or test light) to check continuity between the two brushes and between each brush and ground. There should be no continuity.

If brush holder is defective, rectifier bridge must be replaced.



Check Continuity

R31565 -JUN-31JAN89

RG.RG34710,2117 -19-15MAR97-3/3

25
10
10

Install New Brushes


1. Install new brushes, blocking them in position so that exposed length (A) is within specification.

Specification

New Brushes—Exposed Length 16 mm (0.625 in.)

2. Solder brush leads firmly in this position. Cut off excess length of leads.

A—Brush Exposed Length 16 mm (5/8 in.)



Exposed Brush Length


RW12624 -JUN-10NOV88

RG, RG34710, 2118 -19-15MAR97-1/1

Inspect Stator

1. Inspect stator (A) for defective insulation.
2. Check for discoloration or a burned odor indicating a short circuit.
3. Replace stator if you find any defect.

A—Stator



Inspect Stator

25
10
11


RW6020 -JUN-10NOV88

RG, RG34710, 2119 -19-15MAR97-1/1

Test Stator for Grounds

1. Connect ohmmeter (A) (or test lamp) to stator lead (B) and stator frame (C).
2. Repeat test for each stator lead.
3. If test shows continuity, replace stator.

A—Ohmmeter
B—Stator Lead
C—Stator Frame



Test Stator for Grounds

RG,RG34710,2120 -19-15MAR97-1/1

25
10
12

Test Stator for Open or Short

NOTE: Stator cannot be tested for open circuit unless windings are disconnected.

A stator will occasionally exhibit an open or short circuit only when hot, making the defect even more difficult to diagnose.


If a defective stator is suspected, but cannot be confirmed, recheck all other electrical components. If a problem is not found elsewhere, replace stator.

RG,RG34710,2121 -19-15MAR97-1/1

Test Diodes in Rectifier Bridge

NOTE: Stator must be disconnected from rectifier bridge to test diodes. Test diodes only if diagnostic tests indicate defective diodes.

1. Use a soldering iron (A) of at least 120-watt capacity.
2. Grasp diode connector (B) with needle-nose pliers to serve as heat sink and to protect diode from overheating.
3. Work quickly to disconnect.



Test Diodes in Rectifier Bridge


A—Soldering Iron
B—Diode Connector

RG, RG34710, 2122 -19-15MAR97-1/1

Test Diodes for Open or Short Circuit

1. Connect one ohmmeter probe (A) to metal base.
2. With other ohmmeter probe (B), touch each of three diodes (C). Note ohmmeter readings.

A—Ohmmeter Probe
B—Ohmmeter Probe
C—Diodes



Test Diodes for Open or Short Circuit

Continued on next page


RG, RG34710, 2123 -19-15MAR97-1/2

25
10
13

- Reverse ohmmeter probes (A and B) and make the same checks. Note ohmmeter readings.
- Perform steps 1 through 3 on diodes (C) on the opposite side of rectifier bridge.

Ohmmeter readings should indicate that each diode has continuity in only one direction. A shorted diode would have continuity in both directions. An open diode would not have continuity in either direction.

A—Ohmmeter Probe
B—Ohmmeter Probe
C—Diodes



Reverse Check

RW6048 -UN-10NOV88

RG, RG34710, 2123 -19-15MAR97-2/2


25
10
14

Test Diode/Resistor Trio

- Touch one ohmmeter probe (A) against terminal "G". Touch other ohmmeter probe (B) to the NEARER terminal (C) (the terminal that would be connected to stator windings) of each of the two diodes (D). Note ohmmeter readings.
- Reverse ohmmeter probe.

Each diode should have continuity in only one direction. If either diode is defective, rectifier bridge must be replaced.

A—Ohmmeter Probe
B—Ohmmeter Probe
C—Stator Winding Terminal
D—Diodes



Test Diode/Resistor Trio


RW6049 -UN-10NOV88

Continued on next page

RG, RG34710, 2124 -19-15MAR97-1/2

- Place one ohmmeter probe (A) against terminal "G". Touch probe (B) to NEARER terminal of resistor (C).
- Resistance should be about 100 ohms. If resistor is defective, replace rectifier bridge.

A—Ohmmeter Probe
B—Ohmmeter Probe
C—Resistor Terminal




Check Resistor

RW6050 -JUN-10NOV88

RG,RG34710,2124 -19-15MAR97-2/2

Connect Stator Windings

- Use a soldering iron (A) with 120-watt capacity.
- Grasp diode connector (B) with needle-nose pliers to act as heat sink.
- Connect triple leads of stator winding to side of rectifier bridge. Connect each triple lead to both a rectifier diode and the diode/resistor trio.
- Solder all nine connections quickly to prevent overheating. Use rosin-core solder only.



Connect Stator Windings

A—Soldering Iron
B—Diode Connector

25
10
15

RW6046 -JUN-10NOV88

RG,RG34710,2125 -19-15MAR97-1/1

Test Regulator


The only suitable way to test a regulator is to install it on an alternator known to be good and measure regulator output voltage. Normal regulator voltage is 13.8—14.8 volts. Replace regulator if voltage is too high or too low.

RG,RG34710,2126 -19-15MAR97-1/1

Assemble Rear Frame

1. Place insulating bushings (A) on two screws on output side of rectifier bridge.

A—Insulating Bushings




Insulating Bushings

RW6051 -UN-10NOV88

RG,RG34710,2127 -19-15MAR97-1/2

2. Install rectifier bridge/stator in rear housing.
3. Install rear cover (A).
4. Install insulator bushings (B).
5. Install condenser (C) and attach condenser wire (D).

A—Rear Cover
B—Insulator Bushings
C—Condenser
D—Condenser Wire



Install Parts

RW6052 -UN-10NOV88


RG,RG34710,2127 -19-15MAR97-2/2

25
10
16

Remove Pulley Nut

NOTE: Pulley nut need not be removed if you are certain that front bearing is in good condition. Separate housing as described earlier in this group and leave rotor in front housing.

1. Install a 22 mm socket (A) on JD306A-1 Tool (B) (from JD306A Alternator Pulley Nut Tool Set) to hold nut.
2. Install JD306A-2 (C) on hex shaft of JD306A-1 to hold rotor shaft.
3. Hold rotor and remove nut, pulley and fan.



Remove Pulley Nut

A—22 mm Socket
B—JD306A-1 Tool
C—JD306A-2 Tool


RW6038 -JUN-15DEC88

RG,RG34710,2128 -19-15MAR97-1/1

Remove and Inspect Front Bearing

1. Remove three screws (A) holding bearing retainer to front housing.

A—Screws (3 Used)



Remove Screws

25
10
17


RW6038 -JUN-10NOV88

Continued on next page

RG,RG34710,2129 -19-15MAR97-1/2

2. Remove bearing retainer (A), collars (B) and bearing (C).
3. Inspect bearing and bearing bore (D) for damage. Bearing may be reused, if not damaged.
4. Inspect collars (B) and felt washers on collars. Also inspect O-ring on bearing retainer.

A—Bearing Retainer
 B—Collars
 C—Bearing
 D—Bearing Bore



Inspect Parts for Damage

RW6039 -UN-10NOV88

RG, RG34710, 2129 -19-15MAR97-2/2

25
10
18

Install Front Bearing Assembly

1. Wipe bearing, bearing cavity, collars and felt washers with a clean cloth.
2. Coat bearing with a thin film of grease to aid installation of bearing in housing.
3. Install bearing assembly.

RG, RG34710, 2130 -19-15MAR97-1/1

Test Rotor for Grounds

1. Use an ohmmeter (A) or test lamp to test for continuity.
2. Attach ohmmeter to rotor shaft (B) and each slip ring (C).
3. Replace rotor if test shows continuity.

A—Ohmmeter
 B—Rotor Shaft
 C—Slip Rings



Test Rotor for Grounds

RW6017 -UN-10NOV88

RG, RG34710, 2131 -19-15MAR97-1/1

Test Rotor for Open or Shorted Circuits

1. Connect ohmmeter (A) to each slip ring (B and C) to measure resistance.
2. Resistance should be 3—5 ohms. Replace rotor if resistance is too high or too low.

A—Ohmmeter
B—Slip Ring
C—Slip Ring



Measure Resistance

RG,RG34710,2132 -19-15MAR97-1/1

Recondition Slip Rings

NOTE: Rough or out-of-round slip rings can cause short brush life.

1. Mount rotor assembly on lathe.
2. If slip rings are rough or scored, turn them just enough to eliminate roughness. If slip rings are out-of-round, turn them to within 0.05 mm (0.002 in.) of total indicator reading.
3. Polish slip rings sparingly with No. 00 sandpaper or 400-grit silicon carbide paper.


IMPORTANT: Clean rotor and stator with compressed air only. Cleaning solvent will damage insulation.

RG,RG34710,2133 -19-15MAR97-1/1

Install Rotor and Front Housing

1. Push back brushes to clear rear bearing.
2. Insert pin (A) through hole in rear housing to hold brushes fully retracted.
3. Place felt washer on rear bearing end of rotor shaft, install rotor in rear housing (B) and remove wire. Be sure brushes have good contact with rotor slip rings.

A—Pin
B—Rear Housing




Install Rotor and Front Housing

RW6054 -UN-10NOV88

RG, RG34710, 2134 -19-15MAR97-1/2

4. Slide front housing (A) onto rotor shaft and secure with four through bolts (B). Rotate rotor to ensure that it is free from any interferences.

A—Front Housing
B—Through Bolts (4 Used)



Secure Front Housing

RW6055 -UN-10NOV88

RG, RG34710, 2134 -19-15MAR97-2/2


Install Pulley Assembly

Install fan, pulley, washer and pulley nut. Tighten pulley nut to specifications using JD306A Alternator Pulley Nut Tool.

Specification

Pulley Nut—Torque 66—87 N•m (50—65 lb-ft)

1. Install a 22 mm socket (A) on JD306A-1 (B) to hold nut.
2. Install JD306A-2 (C) on hex shaft of JD306A-1 to hold rotor shaft.
3. Hold rotor shaft and tighten nut to torque above.



Install Pulley Assembly

A—22 mm Socket
B—JD306A-1 Tool
C—JD306A-2 Tool

RW6036 -JUN-15DEC88


RG,RG34710,2135 -19-15MAR97-1/1

Install Regulator

1. Slip insulator (A) over regulator terminals. Slip it back into notches at base of terminals.
2. Attach regulator (B) and cover (C).

Refer to your machine technical manual for alternator installation and correct V-belt adjustments.

A—Insulator
B—Regulator
C—Cover



Install Regulator

25
10
21

RW6053 -JUN-10NOV88

RG,RG34710,2136 -19-15MAR97-1/1

25
10
22

Group 15 Denso Alternator with Built-In Regulator Repair

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B78 -19-08MAY02-1/5

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -UN-12DEC88

25
15
1

OUO1004,0000B78 -19-08MAY02-2/5

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B78 -19-08MAY02-3/5

Alternator Pulley Tool Set JD306A

Remove and install alternator pulley retaining nut.

RG12198 -UN-17JUL02



JD306A

Continued on next page

OUO1004,0000B78 -19-08MAY02-4/5

Denso Alternator with Built-In Regulator Repair

Alternator Pulley Tool Set JDG672

Remove and install alternator pulley retaining nut on 12-volt, 120-amp Denso alternator.



JDG672

RG5495 -UN-09JAN90

OUC1004,0000B78 -19-08MAY02-5/5

25
15
2

Other Material

Number	Name	Use
	400-Grit Silicon Carbide Paper or 00 Sandpaper	Polish slip rings.
	Chevron SR1-2 Grease	Lubricate alternator bearing

OUC1004,0000B7A -19-21SEP00-1/1

**Denso Charging Circuit Repair Specifications
(Alternators with Built-In Regulator)**

Item	Measurement	Specification
New Brush	Exposed Length	10.5 mm (0.40 in.)
Used Brush	Minimum Exposed Length	4.5 mm (0.18 in.)
Rotor Slip Ring	OD	14.0—14.4 mm (0.55—0.57 in.)
Rear End Cover	Torque	4.5 N•m (40 lb-in.)
Drive End-to-Rear End Frame	Torque	4.5 N•m (40 lb-in.)
IC Regulator	Torque	2.0 N•m (18 lb-in.)
Brush Assembly	Torque	2.0 N•m (18 lb-in.)
Rectifier Terminal	Torque	6.5 N•m (57 lb-in.)
Pulley Nut	Torque	94—127 N•m (70—95 lb-ft)

25
15
3

OUO1004,0000BB3 -19-28SEP00-1/1


**Denso Charging Circuit Test Specifications
(Alternators with Built-In Regulator)**

John Deere Alternator Part No.	Denso Alternator Part No.	Voltage	Rated Output (Amps)
CH10493	021000—7281	12	25
RE34888	100211—5030	12	90
RE34890	100211—7130	12	120
RE37201	100211—6031	12	120
RE42123	100211—6030	12	120
RE42778	100211—4200	12	40
RE44140	100311—6050	12	120
RE46043	100211—2470	12	60
RE46608	100211—6420	12	140
RE500226	101211—7780	12	140
RE500227	102211—1180	12	90
RE506145	101211—8620	12	60
RE51921	101211—6050	12	120
RE51922	100211—6040	12	120
RE60745	101211—7130	12	120
RE65414	102211—0040	24	60
RE70268	101211—133	12	40
RE71763	5—101211—148	12	65
RE72915		12	40
RE72916	101211—1131	12	40
RE72917	101211—2471	12	60
RE72918	102211—5121	12	65

Item	Specification
Regulator Output Voltage	13.9—15.1 volts

NOTE: Earlier Denso alternators may have the original Nippondenso label.

Disassemble and Test Denso Alternator with Built-In Regulator



Test Denso Alternator with Regulator

A—V-Ribbed Pulley
 B—Spacer Collar
 C—Drive End Frame
 D—Stator
 E—Stud Bolt

F—Bearing (2 Used)
 G—Bushing
 H—Retainer Plate
 I—Rotor
 J—Rear End Frame

K—“S” Terminal Insulator
 L—Rectifier
 M—IC Regulator
 N—Bearing Cover

O—Brush Holder
 P—Spring
 Q—Brush
 R—Rear End Cover

RG5480 -UN-02FEB89

RG, RG34710, 2140 -19-15MAR97-1/1

25
 15
 5

Disassemble Alternator

NOTE: Pulley nut need not be removed if you are sure that front bearing is in good condition. Separate housing as described and leave rotor in front housing.

Remove alternator pulley using JD306A Alternator Pulley Tool Set.

For 12-volt, 120-amp alternator, use JDG672 Alternator Pulley Tool Set as follows:

1. Install JDG672 Socket (A) on shaft nut. Hold socket using a 24 mm wrench as shown.
2. Install Snap-On SIMM100, 10 mm Impact Socket (B) onto rotor shaft hex.
3. Hold rotor shaft and remove nut and pulley.




Install Sockets

A—JDG672 Socket
B—Snap-On SIMM100, 10 mm Impact Socket

RG5481 -UN-09JAN90

4. Remove nut and insulator from rectifier terminal (A).
5. Remove three nuts holding rear end cover to alternator assembly and remove cover.

A—Rectifier Terminal



Remove Nut from Rectifier Terminal


RG5482 -UN-09JAN90

Continued on next page

RG, RG34710, 2141 -19-15MAR97-2/13

- 6. Remove rubber boot (A) from brush assembly.
- 7. Remove two screws securing brush holder assembly to rectifier and remove brush holder assembly. Remove gasket from below brushes.

A—Rubber Boot



Remove Rubber Boot

RG5483 -UN-09JAN90


RG, RG34710, 2141 -19-15MAR97-3/13

- 8. Measure length of brush protruding from the brush holder.

Replace brush assembly if length is not within minimum serviceable length.

Specification

New Brush—Exposed Length	10.5 mm (0.40 in.)
Used Brush—Minimum Exposed Length.....	4.5 mm (0.18 in.)



Measure Length of Brush

25
15
7


RG5484 -UN-02MAR89

Continued on next page

RG, RG34710, 2141 -19-15MAR97-4/13

9. Remove three screws securing IC regulator (A) to end frame and remove regulator.

A—IC Regulator



RG5485 -UN-09JAN90


Remove IC Regulator Screws

RG, RG34710, 2141 -19-15MAR97-5/13

10. Disconnect four stator lead wires. Remove rectifier from alternator end frame.
11. Connect red lead of multimeter to output terminal (A) of rectifier. Connect stator attaching points (B) with the black lead of meter.
There should not be continuity.
12. Reverse polarity of multimeter leads and repeat test outlined in step 11.
There should be continuity.

If there is continuity in both directions, diode is shorted. If no continuity in either direction, diode is open.

If either diode is defective, rectifier bridge must be replaced.



RG5487 -UN-02MAR89

Check Continuity

A—Rectifier Output Terminal
B—Stator Attaching Points


Continued on next page

RG, RG34710, 2141 -19-15MAR97-6/13

25
15
8

13. Remove four rubber bushings (A) from stator leads. Do not stretch stator leads.
14. Remove four nuts (B) from stud bolts that hold drive and rear end frames together.

A—Rubber Bushings (4 Used)
B—Nuts (4 Used)



Remove Nuts and Bushings

RG5488 -JUN-09JAN90


RG, RG34710, 2141 -19-15MAR97-7/13

15. Carefully insert two flat screwdrivers in opposite openings between front and rear end housing.

IMPORTANT: DO NOT insert screwdriver blade more than 1.6 mm (1/16 in.). Damage to stator windings may result.

16. Apply prying pressure at several points to separate housings.

NOTE: If housings are difficult to separate, use a jaw-type puller to bear on rotor shaft and pull on rear end frame.



RG5489 -JUN-09JAN90

RG, RG34710, 2141 -19-15MAR97-8/13

17. Remove rotor from housing by lightly tapping shaft (as shown) with a soft-faced hammer. Be careful not to drop rotor.



RG5490 -JUN-09JAN90

Continued on next page

RG, RG34710, 2141 -19-15MAR97-9/13

18. Remove screws holding bearing retainer plate and remove plate. Drive bearing from housing. Remove bearing cover.
19. Install new bearing and bearing cover in housing bore. Install bearing retainer plate and tighten screws securely.



RG5491 -UN-09JAN90

RG, RG34710, 2141 -19-15MAR97-10/13

20. Connect ohmmeter leads to each slip ring (as shown) to measure resistance.

Resistance should be 2.0—4.0 ohms. Replace rotor if resistance is not within specification.

21. Connect black (—) lead of ohmmeter to end of shaft and the red (+) lead to each slip ring.

There should be no continuity (0.1 ohm or less). Replace rotor if test shows continuity.



RG5492 -UN-09JAN90

RG, RG34710, 2141 -19-15MAR97-11/13

22. Measure slip ring OD. Replace rotor if slip ring OD is below the acceptable limit.

Specification

Rotor Slip Ring—OD 14.0—14.4 mm (0.55—0.57 in.)

23. If slip rings are rough or scored, turn them just enough to eliminate roughness. Polish sparingly with No. 00 sandpaper or 400-grit silicon carbide paper.



RG5493 -UN-09JAN90

Continued on next page

RG, RG34710, 2141 -19-15MAR97-12/13

IMPORTANT: Clean rotor and stator with compressed air only. Cleaning solvent will damage insulation.

NOTE: Remove bearing only if replacement is necessary.

24. If necessary, remove bearing from rotor shaft using a puller as shown. If desired, rotor may be clamped in a soft-jawed vise.




RG5494 -UN-09JAN90

RG, RG34710, 2141 -19-15MAR97-13/13

25
15
11

Assemble Denso Alternator



RG5479 -UN-02FEB89

Assemble Denso Alternator

- | | | | |
|--------------------|----------------|------------------|--------------------|
| A—Driver End Frame | E—Connector | I—Slip Ring | L—Rotor |
| B—Rear End Frame | F—IC Regulator | J—Rectifier | M—Bearing (2 Used) |
| C—Stator Windings | G—Spring | K—Rear End Cover | N—Pulley |
| D—“S” Terminal | H—Brush | | |

Assemble alternator in the reverse sequence of disassembly procedure while paying close attention to the following details:

1. If one bearing needs replacing, replace both bearings as a set. Lubricate bearings with grease.
2. Be sure screws securing IC regulator are in the correct position, so that too long of a screw will not touch rear end frame and cause battery overcharging.
3. Compress brush springs during assembly for clearance past slip rings.

4. Torque all hardware to specifications.

Specification

Rear End Cover—Torque.....	4.5 N•m (40 lb-in.)
Drive End-to-Rear End	
Frame—Torque.....	4.5 N•m (40 lb-in.)
IC Regulator—Torque.....	2.0 N•m (18 lb-in.)
Brush Assembly—Torque.....	2.0 N•m (18 lb-in.)
Rectifier Terminal—Torque.....	6.5 N•m (57 lb-in.)
Pulley Nut—Torque	94—127 N•m (70—95 lb-ft)


Section 30

Bosch Alternators

Contents

	Page
Group 05—Bosch Alternator Theory of Operation	
Function of Alternator	30-05-1
Group 10—Bosch Alternator Repair	
Essential Tools	30-10-1
Other Material	30-10-2
Bosch Charging Circuit Repair	
Specifications	30-10-3
Bosch Charging Circuit Test Specifications	30-10-4
Alternator, Section View	30-10-6
Alternator Removal	30-10-7
Removing Brush Holder with Regulator	30-10-7
Alternator Disassembly	30-10-8
Stator Removal	30-10-8
Diode Plate Removal	30-10-9
Alternator Exploded View	30-10-10
Testing Rotor for Short Circuit	30-10-11
Testing Rotor for Ground	30-10-11
Testing Slip Rings and Rotor Shaft for Radial	
Runout	30-10-12
Turning Down Slip Rings	30-10-12
Testing Stator Coil for Short Circuit	30-10-13
Testing Stator Coil for Grounds	30-10-13
Replacing Carbon Brushes	30-10-14
Replacing Ball Bearings	30-10-14
Checking Positive Diodes	30-10-15
Checking Negative Diodes	30-10-16
Testing Exciting Diodes	30-10-17
Diode Plate Installation	30-10-18
Soldering Stator Coils	30-10-18
Pressing Ball Bearing onto Rotor Shaft	30-10-19
Pressing Rotor into Drive End Frame	30-10-19
Assemble Alternator	30-10-20
Installing Brush Holder with Regulator	30-10-20
Fan and Belt Pulley Removal and	
Installation	30-10-21

Function of Alternator



L110749

L110749 -UN-01FEB89

Bosch 14-Volt Alternator

- | | | | |
|-------------------------|-------------------------|------------------------------|------------------------|
| A—Alternator | C—Exciting Coil (Rotor) | E—Battery | G—Starter Motor Switch |
| B—Current Coil (Stator) | D—Regulator | F—Alternator Indicator Light | |

The Bosch 14-volt alternator is a 12-pole, self-induced synchronous generator. The current coil is located in the stator, and the exciting coil in the rotor. The exciting current is supplied by the rectifier (terminal D+) through the regulator, two carbon brushes and slip rings to the exciting coil in the rotor.

The alternator is normally driven by a fan belt from the engine crankshaft. The rotor is supported by two permanently lubricated bearings.

The alternator generates alternating current which is then transformed into direct current by the rectifier diodes.

The alternator windings are Y-connected. The coil ends U, V and W (see illustration) are connected to the rectifier diodes. The current flows through the

diode and terminal B+ directly to the positive pole of the battery.

Alternator current is generated in each stator coil (B) of the alternator. During one revolution of the rotor (C), the voltage in the stator coil rises from 0 to the positive maximum, drops to 0, rises to the negative maximum and again drops to 0. Then the process is repeated.

As the stator coils are Y-connected, a three-phase or alternating current is generated. The individual phases are shifted 120°.

A sealed electronic regulator is used to regulate the alternator voltage. This regulator, which cannot be adjusted, limits the alternator voltage to approximately 14 volts.

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B7C -19-07JUL05-1/4

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

30
10
1

OUO1004,0000B7C -19-07JUL05-2/4

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

Continued on next page


OUO1004,0000B7C -19-07JUL05-3/4

Bosch Alternator Repair


Alternator Pulley R & I Kit JDG1747

Used to remove and reinstall the Bosch alternator pulley on 6015, 6020, 7720, 7320, 7420 and 7520 Row Crop tractors. (Bosch 14V/90A, 14V/115A & 14V/150A). Individual tools in kit are: KJD10227 - Alternator Pulley Holding Adapter, KJD10278 - Alternator Pulley Tool and JDG1939 - Socket.

KJD10227 -UN-2900102



KJD10227
KJD10227



KJD10278
KJD10278

OUC1004,0000B7C -19-07JUL05-4/4

Other Material

Number	Name	Use
194891 (U.S.)	Delco-Remy High Temperature Bearing Grease	Apply to end frame bearing seat.

OUC1004,0000BBF -19-19OCT00-1/1

30
10
2

Bosch Charging Circuit Repair Specifications

Item	Measurement	Specification
Slip Rings	Maximum Radial Runout	0.03 mm (0.0012 in.)
Rotor Shaft	Maximum Radial Runout	0.05 mm (0.002 in.)
Slip Rings	Minimum Length	20 mm (0.79 in.)
Slip Rings	Minimum OD	26.8 mm (1.055 in.)
Used Brushes	Minimum Exposed Length	5 mm (0.2 in.)
New Brushes	Exposed Length	10 mm (0.4 in.)
Alternator Housing Cap Screws	Torque	4.0—5.5 N•m (33—48 lb-in.)
Armature	End Play	0.1—0.3 mm (0.004—0.012 in.)
Alternator Pulley Nut	Torque	35—45 N•m (25—32 lb-ft)

OUO1004,0000B7F -19-21SEP00-1/1

30
10
3

Bosch Charging Circuit Test Specifications

John Deere Alternator Part No.	Bosch Alternator Part No.	Model/Series	Rating	
			Volts	Amps
AE52707	9 120 060 042	K1	12(14)	120
AE53101	9 120 060 042, 0 120 484 017, 0 120 484 019	K1	12 (14)	120
AH137883	0 120 484 011	K1	12 (14)	95
AH165975	A 120 402 555	K1	12	120
AL111675	0 123 315 501	KC(R)	12 (14)	90
AL111676	0 123 512 500	NC(R)	12 (14)	115
AL119537	0 123 515 501	NC(R)	12 (14)	150
AL28516	0 120 489 704	K1	12 (14)	55
AL32141	0 120 339 512	G1	12 (14)	33
AL35998	0 120 489 704	K1	12	55
AL36100	0 120 339 545	G1	(14)	33
AL60033	0 120 484 003	K1	12	85
AL67175	0 120 488 218	K1	12 (14)	55
AL67176	0 120 402 425	K1	12	85
AL78689	0 120 488 267	K1	12 (14)	55
AL78690	0 120 484 016	K1	12 (14)	85
AL78692	0 120 484 017	K1	12 (14)	120
AL81436	0 120 488 290	K1	12 (14)	55
AL81437	0 120 484 020	K1	12 (14)	85
AL81438	0 120 488 019	K1	12 (14)	120
AR62401	0 120 300 535	G1	(14)	28
AT161324	0 120 488 206	K1	24 (28)	45
AT168711	0 120 468 136	N1	24 (28)	80
AT173624	0 120 488 205, 9 120 060 040	K1	12 (14)	65
AT175194	9 120 060 041	K1	12 (14)	95
AT175195	9 120 060 039	K1	24 (28)	45
AT175839	0 120 468 055	N1R	12 (14)	135
AT185696	F 005 A00022	K1	24	45
AT185951	F 005 A00025	K1	12	120
AT207608	F 005 A00003	K1	24	55
AT208541	0 120 468 136	N1	24	80
AT220393	F 005 A0 0023	K1	12	65
AT220394	F 005 A0 0024	K1	12	95
AT221116	F 005 A0 0003	K1	24 (28)	55
AT85458	0 122 469 004	N1	24 (28)	50

30
10
4

Continued on next page

RG, RG34710, 2145 -19-07JUL05-1/2

Bosch Alternator Repair


John Deere Alternator Part No.	Bosch Alternator Part No.	Model/Series	Rating	
			Volts	Amps
AZ23575	0 120 339 512	G1	12 (14)	35
AZ31316	0 120 489 156	K1	12	65
AZ38462	0 120 484 012	K1	12 (14)	95
RE185213	0 123 515 5002		12 (14)	150
RE36267	0 120 484 011	K1	12 (14)	90
RE36268	0 120 468 055	N1	12 (14)	135
RE509648	0 124 0AB 5PB	K1	12 (14)	70

Item	Specification
Stator winding resistance	0.40—0.44 ohms
Rotor winding resistance	4.0—4.40 ohms

RG,RG34710,2145 -19-07JUL05-2/2

30
10
5

Alternator, Section View



Alternator, Section View

- | | | | |
|-------------------|-------------------------|-------------------------------|---------|
| A—Stator Assembly | D—Bearing and End Frame | G—Regulator | I—Rotor |
| B—Stator Winding | E—Slip Ring | H—Bearing and Drive End Frame | |
| C—Heat Sink | F—Carbon Brush | | |

L106767A -UN-06APR89

RG,RG34710,2146 -19-15MAR97-1/1

30
10
6

Alternator Removal

Disconnect ground straps of battery.

Disconnect cables from alternator.

Remove alternator per instructions in machine technical manual.




Alternator Removal

RG, RG34710, 2147 -19-15MAR97-1/1

Removing Brush Holder with Regulator

NOTE: Before dismantling alternator, first remove brush holder with regulator so carbon brushes will not break during disassembly.



Remove Brush Holder with Regulator

RG, RG34710, 2148 -19-15MAR97-1/1


30
10
7

Alternator Disassembly

Mark position of both bearing end frames and stator for later assembly (A).

Press rotor out of drive end frame.

A—Position Marks



Mark End Frames and Stator

L106770 -UN-11JUL89

RG, RG34710, 2149 -19-15MAR97-1/1

Stator Removal

Unsolder stator windings from diode leads of diode plate.



Unsolder Stator Windings

L106771 -UN-11JUL89

RG, RG34710, 2150 -19-15MAR97-1/1

Diode Plate Removal

Remove screws from connections "D+" and "B+".


Lift out diode plate.



Diode Plate Removal

RG, RG34710, 2151 -19-15MAR97-1/1

Alternator Exploded View



L106773

L106773 -UN-06APR89

Alterator—Exploded View

- | | | | |
|--|---|-------------------------------|---|
| 1—Retaining Plate | 8—Fan | 15—Carbon Brush (2 Used) | 24—Ball Bearing |
| 2—Ball Bearing | 9—Belt Pulley Repair Set | 16—Gasket | 25—Slip Ring |
| 3—Washer | 10—Snap Ring ¹ | 17—Suppression Capacitor | 26—Rotor |
| 4—Stator Coil | 11—Hex Nut ¹ | 18—Cylinder Screw | 27—Woodruff Key ¹ |
| 5—Drive End Frame | 12—Screw with Spring Washer
(2 Used) | 19—Gasket | 28—Screw with Spring Washer
(3 Used) |
| 6—Cylinder Screw (4 Used) | 13—Regulator with Brush
Holder | 20—End Frame | 29—Protective Cap |
| 7—Countersunk Screw (4
Used) ¹ | 14—Compression Spring (2
Used) | 21—Diode Plate | 30—Repair Kit for Terminals
W, D+ and B+ |
| | | 22—Spring Washer ¹ | |
| | | 23—O-Ring | |

¹ Rotor Repair Kit.

Testing Rotor for Short Circuit

With a test lamp:

Test lamp must light brightly.

With an ohmmeter:

Ohmmeter indication must be between 4.0 and 4.4 ohms.

If test fails, replace rotor.



Test Rotor for Short Circuit

L106774 -JUN-11JUL89

RG, RG34710, 2153 -19-15MAR97-1/1

Testing Rotor for Ground

Use an ohmmeter to test for continuity.

Attach ohmmeter to rotor and each slip ring.

Replace rotor if test shows continuity.



Test Rotor for Ground

L106775 -JUN-11JUL89

RG, RG34710, 2154 -19-21SEP00-1/1

30
10
11


Testing Slip Rings and Rotor Shaft for Radial Runout

Check maximum radial runout of slip rings and rotor shaft.

Specification

Slip Rings—Maximum Radial Runout	0.03 mm (0.0012 in.)
Rotor Shaft—Maximum Radial Runout	0.05 mm (0.002 in.)

A—Rotor Shaft Test Point



Rotor Shaft Test Point

L106777 -UN-11JUL89

RG, RG34710, 2155 -19-15MAR97-1/1

Turning Down Slip Rings

Turn down slip rings to length of only (A).

Specification


Slip Rings—Minimum Length	20 mm (0.79 in.)
---------------------------------	------------------

Check diameter of slip rings.

Specification

Slip Rings—Minimum OD	26.8 mm (1.055 in.)
-----------------------------	---------------------

A—Slip Ring Length



Turning Down Slip Rings

L106776 -UN-11JUL89

RG, RG34710, 2156 -19-15MAR97-1/1

30
10
12

Testing Stator Coil for Short Circuit

Test phase outlets with respect to each other as follows:
A and B; B and C; A and C.


With test lamp:

Test lamp must light up brightly

With ohmmeter:

Indications between 0.40 and 0.44 ohms.

If test fails, replace stator coil.



Test Phase Outlets

A—Phase Outlet
B—Phase Outlet
C—Phase Outlet

RG, RG34710, 2157 -19-15MAR97-1/1

L106778 -JUN-11JUL89

Testing Stator Coil for Grounds

Connect ohmmeter (or test lamp) to stator lead and stator frame.

Repeat test for each stator lead.

If test shows continuity, replace stator.



Test Stator Coil for Grounds

RG, RG34710, 2158 -19-15MAR97-1/1

L106779 -JUN-11JUL89

30
10
13

Replacing Carbon Brushes

Replace carbon brushes if dimension (A) is less than specified.

Specification

Used Brushes—Minimum
Exposed Length..... 5 mm (0.2 in.)

NOTE: When soldering copper lead, make sure solder (rosin-core solder only) does not seep into the copper leads.

Solder new carbon brushes in such a way that dimension (A) does not exceed specifications.

Specification

New Brushes—Exposed Length 10 mm (0.4 in.)

IMPORTANT: The service life of carbon brushes and ball bearings are matched to each other. Therefore, always replace ball bearings when renewing carbon brushes. Before installing new carbon brushes, slip rings must be checked and turned down if necessary.



Dimension

A—Carbon Brush Dimension

L106780 -UN-11JUL89

RG, RG34710, 2159 -19-19OCT00-1/1

Replacing Ball Bearings

Remove attaching screws (A) of drive end frame retaining plate and force rotor out of drive end frame.

Pull off rotor ball bearing.

Removed ball bearings must be replaced.

A—Screws (4 Used)



Remove Attaching Screws

L106781 -UN-11JUL89


RG, RG34710, 2160 -19-15MAR97-1/1

Checking Positive Diodes

Consecutively place positive test probe of ohmmeter to positive heat sink (A) and negative test probe to leads (B) of diodes.

Meter must not show continuity.

- A—Positive Heat Sink
- B—Diode Leads



Check Positive Diodes


L106782 -JUN-11JUL89

RG, RG34710, 2161 -19-15MAR97-1/2

If no fault is found in the above described test, carry out this test with reversed polarity (see illustration).

Meter must show continuity.

NOTE: Test voltage 6—12 volts DC.



Reversed Polarity

L106783 -JUN-11JUL89

RG, RG34710, 2161 -19-15MAR97-2/2


30
10
15

Checking Negative Diodes

Consecutively place positive test probe of ohmmeter to positive heat sink (B) and negative test probe to leads (A) of diodes.

Meter must not show continuity.

- A—Diode Leads
- B—Positive Heat Sink



Check Negative Diodes

L106784 -UN-11JUL89


RG,RG34710,2162 -19-15MAR97-1/2

If no fault is found in the above described test, carry out this test with reversed polarity (see illustration).

Meter must show continuity.

NOTE: Test voltage 6—12 volts DC.

- A—Diode Leads
- B—Positive Heat Sink



Reverse Polarity

L106785 -UN-11JUL89


RG,RG34710,2162 -19-15MAR97-2/2

Testing Exciting Diodes

Place positive test probe of an ohmmeter on connection "D+" (B) and negative probe onto diode lead (A).

Meter must not show continuity.

- A—Diode Leads
- B—"D+" Connection



Test Exciting Diodes

L106786 -JUN-11JUL89


RG, RG34710, 2163 -19-15MAR97-1/2

If no fault is found in the above described test, carry out this test with reversed polarity (see illustration).

Meter must show continuity.

NOTE: Test voltage 6—12 volts DC.

- A—Diode Leads
- B—"D+" Connection



Reverse Polarity

L106787 -JUN-11JUL89

30
10
17

RG, RG34710, 2163 -19-15MAR97-2/2

Diode Plate Installation

Pay attention to perfect insulation connections "B+", "D+" and the positive diode heat sink in respect to end frame.

Install diode plate as shown and tighten screws.



Install Diode Plate

RG,RG34710,2164 -19-15MAR97-1/1

Soldering Stator Coils

IMPORTANT: Use only rosin-core solder.

Make sure that no solder seeps inside diode plate.

Avoid overheating diodes.



Solder Stator Coils

RG,RG34710,2165 -19-15MAR97-1/1

Pressing Ball Bearing onto Rotor Shaft

For pressing on, use a sleeve which presses against the ball bearing inner race.

IMPORTANT: Never press onto drive end frame; damage may result.



Pressing Ball Bearing Onto Rotor Shaft

RG, RG34710, 2166 -19-15MAR97-1/1

Pressing Rotor into Drive End Frame

Use a new retaining plate (A) when installing new ball bearing.

A—Retaining Plate



Retaining Plate

RG, RG34710, 2167 -19-15MAR97-1/1

30
10
19

Assemble Alternator

Apply high temperature bearing grease such as Bosch FT70V1 or Delco Remy No. 194891 to end frame bearing seat. Place spring washer end in frame and carefully join both alternator halves, paying attention to markings.

Tighten screws (A) to specifications.


Specification

Alternator Housing Cap Screws—
Torque 4.0—5.5 N•m (33—48 lb-in.)

Check armature end play.

Specification

Armature—End Play 0.1—0.3 mm (0.004—0.012 in.)



Alternator Assembly

A—Screws (4 Used)


L106790 -UN-11JUL89

RG, RG34710, 2168 -19-21SEP00-1/1

Installing Brush Holder with Regulator

Carefully insert brush holder with regulator. Make sure that gasket (A) fits correctly. Tighten screws securely.

A—Gasket



Install Brush Holder with Regulator


L106791 -UN-11JUL89

RG, RG34710, 2169 -19-15MAR97-1/1

30
10
20

Fan and Belt Pulley Removal and Installation

A—Pulley



Pulley

LX1030018 -UN-26JUL02


RG.RG34710,2170 -19-07JUL05-1/3

1. Open the hood or panels for access to pulley.

CAUTION: Disconnect negative (-) cable from battery.

IMPORTANT: Always relieve tension on drive belt before removing the pulley.

2. Take the drive belt off the pulley.
3. Remove the pulley by installing KJD10227 adapter (A) in alternator pulley.
4. Using extension (C) with ratchet (D) and insert KJD10278 special socket (B) through KJD10227 adapter holding alternator shaft.
5. Use a 17 mm wrench or crows foot (F) with torque wrench (E) to loosen pulley from alternator.




Pulley Tools

30
10
21

RXA0066043 -UN-05MAR03

Continued on next page


RG.RG34710,2170 -19-07JUL05-2/3



RXA0061214 -UN-19JUN02

$$Tw = Ta \times \frac{L}{L+A}$$

Torque Wrench



RXA0061213 -UN-19JUN02

Torque Wrench

Tw—Torque setting on wrench **Ta**—Torque actually being applied to nut or cap screw **L**—Length from point of force (center of wrench handle) to center of wrench head **A**—Application distance from center of torque wrench head to center of adapter

6. Using formula with torque wrench tighten alternator pulley to specification.

Item	Measurement	Specification
Alternator Pulley	Torque	80 N•m (60 lb-ft)

NOTE: To install alternator and adjust belt tension, refer to machine technical manual.

RG, RG34710, 2170 -19-07JUL05-3/3

30
10
22

Section 35

Valeo Alternators

Contents

Page

Group 05—Valeo Alternator Theory of Operation

Valeo Alternator Operation35-05-1
Valeo Regulator Operation35-05-2

Group 10—Valeo Alternator Repair

Essential Tools35-10-1
Other Material35-10-2
Valeo Charging Circuit Repair Specifications . . .35-10-2
Valeo Charging Circuit Test Specifications . . .35-10-3
Disassemble Alternator and Test
 Components35-10-3
Assemble Alternator35-10-9

Group 15—Valeo A13N-Series Alternator Repair

Essential Tools35-15-1
Valeo A13N-Series Repair Specifications35-15-2
Valeo A13N-Series Test Specifications35-15-2
Disassemble and Test Valeo A13N-Series
 Alternator35-15-3
Assemble Valeo A13N-Series Alternator35-15-10

Contents


Valeo Alternator Operation

In an alternator, the magnetic field of the rotor is moved across stationary conductors in the stator. This permits a permanent connection between the stator windings and the output terminal. Slip rings are used to transmit the field current to the rotor field winding.

The alternator produces power in the form of a three-phase alternating current and voltage. The alternating current is rectified to direct current by a three-phase full-wave rectifier circuit using six silicon rectifier diodes. Since the diode will pass current in only one direction (from alternator to battery or load), the alternator does not require the use of a cutout relay.

The entire DC output of the system passes through the isolation diode. This provides the system with several distinct advantages. It prevents the battery from discharging through the regulator and alternator field without the use of relays or switches. Electrically, the indicator lamp is connected across the isolation diode. When the system is operating properly, the alternator output voltage is very nearly the same as the battery voltage. This means that the voltage potential across the isolation diode is low and the indicator lamp shows that the alternator is charging.

The alternator output current is controlled by the current flow through the field coil (rotor). The amount of current required is determined and controlled by the regulator. Since there is very little residual magnetism in the alternator, it is necessary to supply a small amount of excitation current to the field (rotor) to start the process of current generation. The excitation resistor supplies this starting current when the key switch is turned on. This resistor is enclosed in the sealed regulator case. Once the alternator is excited, a voltage is developed at the regulator terminal and the voltage regulator takes over control of the system voltage.



Valeo Alternator Operation

- 1—Stator
- 2—Rotor Winding (Field)
- 3—Rotor Slip Ring
- 4—Brushes
- 5—Regulator Terminal
- 6—Output Terminal
- 7—Isolation Diode
- 8—Regulator

T52184 -UN-31MAY89

35
05
1

Valeo Regulator Operation

The transistor regulator is an electronic switching device composed principally of transistors, resistor, and diodes to form a completely static unit containing no moving parts.

The transistors are used to switch the alternator field current on and off and are controlled by the resistors and the Zener diode.

A Zener diode is a special diode that will break down and permit a reverse flow of current when the voltage reaches a certain value, without damaging the semiconductor material. This diode is the trigger which senses the maximum desired voltage and turns the transistor on or off to limit charging system voltage.


The field discharge diode provides an alternator current path to protect the transistors from induced high voltage from the alternator field windings. The sudden stopping of field current by the transistor and subsequent collapsing of the magnetic field cause an induced voltage in the rotor windings.

The thermistor (RT) is a temperature compensating resistor. Its resistance varies with temperature and controls the operating point of the Zener diode so that a high system voltage is produced in cold weather when needed, and a lower system voltage in warm weather.

When the voltage appearing at the output terminal of the alternator rises to a predetermined value (1.44 volts), the voltage which appears across the Zener diode permits current to flow in the base of transistor T-1. This causes transistor T-1 to turn on and reverse bias transistor T-2, thus turning off the current applied to the alternator field.

When the system voltage drops below the predetermined value, the Zener diode stops conducting, T-1 turns off and T-2 turns on. When transistor T-2 is switched on, field current again is supplied to the alternator.

The operation of transistor T-2 is in effect like a switch, turning the alternator field current on and off as the electrical supply varies due to the varying electrical load. This action occurs many times a second, so fast it cannot be detected in the alternator output.



Valeo Regulator Operation

- 1—Thermistor (RT)
- 2—Field Discharge Diode
- 3—Transistor (T-2)
- 4—Transistor (T-1)
- 5—Zener Diode
- 6—Excitation Resistor
- 7—To Alternator Indicator Light

T51537 -UN-02JUN89

35
05
2

The solid-state regulator is either mounted on rear of alternator or mounted internally. It controls output by controlling current through the field. In operation, the regulator has the following three phases.


RG, RG34710, 2172 -19-06MAY02-2/5

Phase I—Alternator Stopped

(Phase I also applies when alternator is running but only if not running fast enough for output to exceed battery voltage.)

1. Current flows from battery (B) through key switch (C) to regulator (A).
2. From there, current flows through resistors R8, R7, and R1 to transistor Q2, turning it on.
3. Transistor Q2 then provides a path so current can flow through field (E) to ground, enabling alternator to generate electricity.
4. Zener diode D1 prevents flow of current to transistor Q1. A Zener diode is a special type of diode which will not permit current to pass until voltage reaches a certain preset level. If voltage exceeds that level, current can pass through the Zener diode.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase I—Alternator Stopped


35
05
3

N37761 -JUN-02MAY89

Phase II—Generating Electricity

1. The key switch (C) and rectifier bridge diodes (G) all have equal voltage. Therefore, no current flows from key switch to regulator.
2. Current, now coming from rectifier bridge diodes, flows through resistors R7 and R1 to turn on transistor Q2.
3. Transistor Q2 still provides a path to ground through field (E), enabling alternator to generate electricity.
4. Since the field is rotating, it does generate electricity. Alternating current is induced in the stator windings (F). The rectifier bridge converts it to direct current, providing current to run electrical accessories and charge the battery.
5. Output voltage still has not reached critical voltage of the Zener diode D1.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase II—Generating Electricity

N37762 -JUN-02MAY89


Continued on next page

RG, RG34710, 2172 -19-06MAY02-4/5

Phase III—Shut-Off

1. Output voltage reaches critical voltage of Zener diode D1.
2. Current can now pass through Zener diode D1 to turn on control transistor Q1.
3. Current from transistor Q1 cuts off voltage to transistor Q2, turning it off. There is now no path to ground for current through field (E).
4. Current through field is shut off instantly, and alternator stops generating electricity.
5. With transistor Q2 off, system voltage starts to drop in unrestricted fashion until it falls below the Zener diode D1 critical voltage. When this occurs, Zener diode D1 and transistor Q1 switch off and Q2 turns on again.
6. Phases II and III are repeated many times per second to maintain voltage at proper level.

- A—Regulator
- B—Battery
- C—Key Switch
- D—Rotor
- E—Field Windings
- F—Delta Stator
- G—Rectifier Diodes
- H—Diode Trio
- I—Suppression Capacitor



Phase III—Shut-Off

NS7763 -JUN-02MAY89

35
05
5

RG, RG34710, 2172 -19-06MAY02-5/5

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B80 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B80 -19-08MAY02-2/3

35
10
1

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B80 -19-08MAY02-3/3

Other Material

Number	Name	Use
TY16285 (U.S.) CXTY24311 (Canadian) 222 (LOCTITE®)	Thread Lock and Sealer (Low Strength)	Apply to front bearing plate and housing through bolts.

LOCTITE is a registered trademark of Loctite Corp.

OOU1004,0000B82 -19-21SEP00-1/1

Valeo Charging Circuit Repair Specifications

Item	Measurement	Specification
Alternator Housing Through Bolts	Torque	5 N•m (44 lb-in.)
Pulley Nut	Torque	61 N•m (45 lb-ft)
Ground (—) Terminal Nut	Torque	4 N•m (35 lb-in.)
Optional Terminal Nut	Torque	4 N•m (35 lb-in.)
Battery Positive (+) Terminal Nut	Torque	5 N•m (44 lb-in.)

OOU1004,0000B83 -19-21SEP00-1/1

Valeo Charging Circuit Test Specifications

NOTE: Formerly Motorola alternators made in France.

John Deere Alternator Part No.	Valeo Alternator Part No.	Pulley Grooves	Rated Amps	Field Current (Volts)	Min. Output @ 25°C (77°F)	
					Amps	RPM
RE20600	2940090 ^a	W/O	35	14	26—30	3000—4000
RE30838	2518033 ^b	Dual	35	14	26—30	3000—4000
RE40575	2518032 ^b	Single	35	14	26—30	3000—4000
RE40576	2518073 ^b	Single	80	14	68—78	3000—4000

^aWith additional resistor.

^bWith included regulator (Packard connector).

Item	Specification
Maximum Continuous Speed	12000 rpm
Maximum Intermittent Speed	16000 rpm
Maximum Recommended Working Temperature	80°C (176°F)


RG, RG34710, 2174 -19-07JUL05-1/1

35
10
3

Disassemble Alternator and Test Components

1. Remove regulator after having identified the color coding of the wires.
2. Unscrew the three cover attaching screws (1) and remove cover.

1—Screws (3 Used)



Unscrew Cover Attaching Screws

CD5712 -UN-26JUL89

Continued on next page

RG, RG34710, 2175 -19-15MAR97-1/19

3. Remove the brush assembly with caution and turn it toward the outside in order to protect the brushes.
4. Inspect brushes. If either one is worn, cracked or oil soaked, replace the brush assembly.




CD5713 -UN-26JUL89

Remove Brush Assembly

RG,RG34710,2175 -19-15MAR97-2/19

5. Touch each brush with test leads using JT05791 Digital Multimeter. No continuity should be found, even if either brush has slid up or down in its channel. If there is continuity, replace the brush assembly.




CD5714 -UN-26JUL89

JT05791 Digital Multimeter

RG,RG34710,2175 -19-15MAR97-3/19

6. Connect the test leads of JT05791 Digital Multimeter on the field terminal and on its corresponding brush. Continuity should be found even when moving brushes. If there is no continuity, replace the brush assembly.




CD5715 -UN-26JUL89

Connect Test Leads

RG,RG34710,2175 -19-15MAR97-4/19

7. Connect the test leads of JT05791 Digital Multimeter on the second terminal and on its corresponding brush. Continuity should be found even when moving brushes. If there is no continuity, replace the brush assembly.



CD5716 -UN-26JUL89

Test for Continuity

RG,RG34710,2175 -19-15MAR97-5/19

Continued on next page

35
10
4

8. Connect the test leads to each slip ring. The resistance must be between 3.8 and 5.2 ohms.
9. Connect an ohmmeter between a slip ring and the alternator housing. The resistance should be infinity.




Test Resistance

RG,RG34710,2175 -19-15MAR97-6/19

CD5717 -UN-26JUL89

10. Check if the winding has been damaged by overheating.
11. Check the stator insulation by connecting an ohmmeter between the alternator housing and in succession with each stator phase winding. The resistance should be infinity.




Check the Stator Insulation

RG,RG34710,2175 -19-15MAR97-7/19

CD5718 -UN-26JUL89

12. Unsolder the leads of phase winding (1), and D+ terminal (2).
13. Take out link diode bridge after removing the screws (3).

- 1—Phase Winding
- 2—D+ Terminal
- 3—Screws



Remove Link Diode Bridge

Continued on next page

RG,RG34710,2175 -19-15MAR97-8/19

CD5719 -UN-26JUL89


35
10
5

14. Using a power supply not exceeding 12 volts and an indicator lamp in series, check the current flow through each diode.
15. Test positive diodes by connecting the indicator lamp between each phase terminal and the B+ terminal. Just touch the lamp probes briefly.

If the indicator lamp lights only in one direction, the diode is good. Continue testing diode as outlined in step 16.

If the indicator lamp lights in both directions, the diode is shorted. Replace diode.

If the indicator lamp does not light in either direction, the diode circuit is open. Replace diode.



Test Diode

RG,RG34710,2175 -19-15MAR97-9/19


16. Test negative diodes by connecting the lamp between each phase terminal and the heat sink.

If the indicator lamp lights only in one direction, the diode is good. Continue with step 17.

If the indicator lamp lights in both directions, the diode is shorted. Replace diode.

If the indicator lamp does not light in either direction, the diode is open circuit. Replace diode.

17. Test the trio by connecting the test leads on the D+ terminal and on each phase terminal in sequence. Then reverse the polarity.




Test Diodes

Continued on next page

RG,RG34710,2175 -19-15MAR97-10/19

18. Note the orientation of the housing and take out the four through bolts.




CD5722 -UN-26JUL89

Remove Through Bolts

RG, RG34710, 2175 -19-15MAR97-11/19

19. Remove the rear housing. If it is glued to the stator, take care not to damage the winding.



CD5723 -UN-26JUL89

Remove Rear Housing

RG, RG34710, 2175 -19-15MAR97-12/19

20. Remove O-ring from rear bearing bore.



CD5724 -UN-26JUL89

Remove O-Ring

RG, RG34710, 2175 -19-15MAR97-13/19

21. Remove stator from front housing.



CD5725 -UN-26JUL89

Remove Stator

Continued on next page

RG, RG34710, 2175 -19-15MAR97-14/19

- 22. Remove pulley nut and lock washer.
- 23. Pull alternator from pulley. Remove fan.




CD5726 -UN-26JUL89

Remove Pulley Nut and Lock Washer

RG, RG34710, 2175 -19-15MAR97-15/19

- 24. Press rotor out of front housing.



CD5727 -UN-26JUL89

Press Rotor Out

RG, RG34710, 2175 -19-15MAR97-16/19

- 25. Remove rear bearing using a suitable puller.




CD5728 -UN-26JUL89

Remove Rear Bearing

RG, RG34710, 2175 -19-15MAR97-17/19

- 26. Unscrew the three screws securing the bearing plate.




CD5729 -UN-26JUL89

Unscrew Screws

RG, RG34710, 2175 -19-15MAR97-18/19

Continued on next page

27. Extract the front bearing.



CD5730 -UN-26JUL89

Extract the Front Bearing

RG,RG34710,2175 -19-15MAR97-19/19

Assemble Alternator

1. Fit the front bearing to its housing by pressing on the outer ring as shown.
2. Install the bearing plate. Apply LOCTITE® 222 Thread Lock and Sealer (low strength) on the threads of the three screws and tighten.



CD5731 -UN-26JUL89

Assemble Alternator

RG,RG34710,2176 -19-15MAR97-11/11

LOCTITE is a registered trademark of Loctite Corp.

3. Press rear bearing onto rotor using a suitable driver.




CD5732 -UN-26JUL89

Press Rear Bearing onto Rotor

RG,RG34710,2176 -19-15MAR97-2/11

4. Install rotor into front housing.




CD5733 -UN-26JUL89

Install Rotor

Continued on next page

RG,RG34710,2176 -19-15MAR97-3/11

5. Install stator.




CD5725 -UN-26JUL89

Install Stator

RG, RG34710, 2176 -19-15MAR97-4/11

6. Install rear housing, taking care that marks made when disassembling are in line. Use a new O-ring in rear bearing bore.



CD5734 -UN-26JUL89


Install Rear Housing

RG, RG34710, 2176 -19-15MAR97-5/11

7. Install the four through bolts. Apply LOCTITE® 222 Thread Lock and Sealer (low strength) on the threads of the through bolts and tighten to specifications.

Specification

Alternator Housing Through Bolts—Torque..... 5 N•m (44 lb-in.)



CD5722 -UN-26JUL89

Install Through Bolts

RG, RG34710, 2176 -19-15MAR97-6/11

LOCTITE is a registered trademark of Loctite Corp.

8. Install fan.



CD5735 -UN-26JUL89

Install Fan

Continued on next page

RG, RG34710, 2176 -19-15MAR97-7/11

35
10
10

9. Install pulley, nut and lock washer. Tighten the pulley nut to specifications.

Specification

Pulley Nut—Torque 61 N•m (45 lb-ft)



CD5726 -UN-26JUL89


Tighten Pulley Nut

RG,RG34710,2176 -19-15MAR97-8/11

10. Install the diode bridge and tighten screws (3).

11. Solder the leads of phase winding (1) and D+ terminal (2). DO NOT use acid-core solder.

- 1—Phase Winding
- 2—D+ Terminal
- 3—Screws




CD5719 -UN-26JUL89

Install Diode Bridge

RG,RG34710,2176 -19-15MAR97-9/11

12. Install the brush assembly.




CD5713 -UN-26JUL89

Install Brush Assembly

Continued on next page

RG,RG34710,2176 -19-15MAR97-10/11

- 13. Install the rear cover. Tighten the three screws (1).
- 14. Install regulator. It is essential that connections be made correctly; reversals will cause damage.
- 15. Refer to your machine technical manual for alternator installation and proper V-belt adjustments.
- 16. Tighten terminal nuts to specifications.



CD5712 -UN-26JUL89

Installation and Adjustments

1—Screws (3 Used)

Specification

Ground (—) Terminal Nut—	
Torque	4 N•m (35 lb-in.)
Optional Terminal Nut—Torque	4 N•m (35 lb-in.)
Battery Positive (+) Terminal	
Nut—Torque	5 N•m (44 lb-in.)

RG, RG34710, 2176 -19-15MAR97-11/11

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B84 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JN-12DEC88

OUO1004,0000B84 -19-08MAY02-2/3

35
15
1

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B84 -19-08MAY02-3/3

Valeo A13N-Series Repair Specifications

Item	Measurement	Specification
Ground (B—) Terminal Nut	Torque	4 N•m (35 lb-in.)
Output (B+) Terminal Nut	Torque	5 N•m (44 lb-in.)
Front-to-Rear Housing Through Bolts	Torque	5 N•m (44 lb-in.)
Pulley-to-Shaft Nut	Torque	55 N•m (41 lb-ft)

OUO1004.0000B87 -19-21SEP00-1/1

Valeo A13N-Series Test Specifications


John Deere Alternator Part No.	Valeo Alternator Model No.	Pulley Grooves	Ground	Rated (Amps)	Min. Output @ 25°C (77°F)	
					Amps	Alt. RPM
RE53906	2541673	Single	N	50	39—43	3000—4000

Item	Specification
Rotor winding resistance	3.6 ohms
Stator resistance	0.000 ohms
Alternator output voltage	13.7—14.7 volts
Maximum recommended working temperature	80°C (176°F)
Maximum continuous alternator speed	9000 rpm

RG.RG34710,2177 -19-07JUL05-1/1

35
15
2

Disassemble and Test Valeo A13N-Series Alternator



Valeo A13N-Series Alternator

- | | | | |
|----------|-------------------------|---|---------------------------------|
| 1—Nut | 6—Fan Spacer | 11—Rotor | 16—Regulator and Brush Assembly |
| 2—Washer | 7—Front Housing | 12—Rear Ball Bearing | 17—Rear Cover |
| 3—Pulley | 8—Through-Bolt (4 Used) | 13—Plastic Ball Bearing Cage | |
| 4—Spacer | 9—Front Ball Bearing | 14—Rear Housing | |
| 5—Fan | 10—Stator | 15—Rectifier Diode Bridge and Diode-Trio Assembly | |


CD30363 -JUN-14APR94

DPSG,RG34710,102 -19-13SEP99-1/15

35
15
3

1. Pull out the rear cover (A).
2. Remove regulator/brush assembly (B).

- A—Rear Cover
B—Regulator/Brush Assembly



Remove Regulator/Brush Assembly

CD30364 -JUN-14APR94

Continued on next page

DPSG,RG34710,102 -19-13SEP99-2/15

3. Inspect brushes. If either one is worn, cracked or oil soaked, replace the regulator/brushes assembly.
4. Touch each brush with test leads. No continuity should be found even if either brush has slid up or down in its channel. If there is continuity, replace the brush assembly.




CD30365 -UN-14APR94

Inspect Brushes

DPSG,RG34710,102 -19-13SEP99-3/15

5. Check for continuity between terminal (A) and brush (B) and between metallic box of regulator (C) and brush (D). If there is no continuity at either brush, replace the brush assembly.

- A—Terminal
- B—Brush
- C—Metallic Regulator Box
- D—Brush



CD30366 -UN-14APR94


Check for Continuity

Continued on next page

DPSG,RG34710,102 -19-13SEP99-4/15

35
15
4

6. Connect the test leads to each slip ring of the rotor. The ohmmeter should read a resistance of 3.60 ohms.
7. Connect the ohmmeter between a slip ring and the alternator housing. The resistance should be infinity.




CD30367 -UN-14APR94

Check Resistance

DPSG,RG34710,102 -19-13SEP99-5/15

8. Check if the winding has been damaged by overheating.
9. Check the stator insulation by connecting an ohmmeter between the alternator housing and in succession with each stator phase winding. The resistance should be infinity.



CD30368 -UN-14APR94

Check Winding for Damage


35
15
5

Continued on next page

DPSG,RG34710,102 -19-13SEP99-6/15

10. Unsolder the leads of phase winding (A).
11. Take out the rectifier diode bridge/diode trio assembly after removing the screw and nuts (B).

A—Phase Winding
B—Screw and Nuts



CD30369 -UN-14APR94


Remove Rectifier Diode Bridge/Diode Trio

DPSG.RG34710,102 -19-13SEP99-7/15

12. Test positive diodes. Test for continuity between the positive plate (A) and each of three terminals (B). Continuity should be observed in one direction only.

Replace entire rectifier diode bridge if any diode fails test.

A—Positive Plate
B—Three Terminals



CD30370 -UN-14APR94

Test Positive Diodes


Continued on next page

DPSG.RG34710,102 -19-13SEP99-8/15

13. Test negative diodes. Test for continuity between the negative plate (A) and each of three phases (B).
14. Test the diode trio by connecting the test leads on each phase (B) with the corresponding diode trio terminal (C).

Continuity should be observed in one direction only. Replace entire rectifier diode bridge if any diode fails test.

A—Negative Plate
B—Three Phases
C—Diode Trio Terminal




Test Negative Diodes

CD30371 -UN-14APR94

DPSG, RG34710, 102 -19-13SEP99-9/15

15. Note the orientation of the housing and take out the four through bolts.



Remove Through Bolts


CD30372 -UN-14APR94

35
15
7

Continued on next page

DPSG, RG34710, 102 -19-13SEP99-10/15

16. Remove the rear housing. If it is glued to the stator, take care not to damage the winding.



CD30373 -UN-14APR94

Remove Rear Housing

DPSG,RG34710,102 -19-13SEP99-11/15

17. Remove stator from housing.




CD5725 -UN-26JUL89

Remove Stator

DPSG,RG34710,102 -19-13SEP99-12/15

18. Remove pulley and fan. Note the order of washers and spacers to ensure a proper reinstallation.




CD30374 -UN-14APR94

Remove Pulley and Fan

Continued on next page

DPSG,RG34710,102 -19-13SEP99-13/15

19. Press rotor out of front housing.



CD5727 -UN-26JUL89

Press Rotor Out of Front Housing

DPSG,RG34710,102 -19-13SEP99-14/15

20. Remove rear ball bearing using a suitable puller.

NOTE: Since the front ball bearing is set in front housing, it cannot be removed. If required, replace the front housing/ball bearing assembly.




CD5728 -UN-26JUL89

Remove Rear Ball Bearing

DPSG,RG34710,102 -19-13SEP99-15/15

Assemble Valeo A13N-Series Alternator



Valeo A13N-Series Alternator

1—Through Bolt (4 Used)

2—Pulley Nut

Assemble alternator in the reverse sequence of disassembly procedure using the following torque specifications.

Item	Measurement	Specification
Ground (B—) Terminal Nut	Torque	4 N•m (35 lb-in.)
Output (B+) Terminal Nut	Torque	5 N•m (44 lb-in.)
Front-to-Rear Housing Through Bolts	Torque	5 N•m (44 lb-in.)
Pulley-to-Shaft Nut	Torque	55 N•m (41 lb-ft)

CD30375 -UN-08DEC94


RG, RG34710, 2178 -19-15MAR97-1/1

Section 40 Magnetron Alternators

Contents

	Page
Group 05—Magnetron Alternator Theory of Operation	
Operation of Alternator	40-05-1
Group 10—Magnetron Alternator Repair	
Essential Tools	40-10-1
Magnetron Charging Circuit Repair	
Specifications.	40-10-2
Magnetron Charging Circuit Test	
Specifications.	40-10-3
Exploded View of Alternator	40-10-4
Identification	40-10-5
Troubleshooting.	40-10-6
Disassembly of Alternator	40-10-7
Testing Brush/Regulator Assembly	40-10-9
Testing Rotor	40-10-10
Testing Stator/Rectifier Bridge Assembly.	40-10-11
Rectifier Bridge Replacement	40-10-12
Reassembly of Alternator	40-10-12
Installation of Alternator.	40-10-14

Operation of Alternator



Magneton Alternator

- | | | | |
|-------------------------|-------------------|---------------------|--------------------------|
| A—Alternator | D—Regulator | G—Ignition | J—Diode Trio |
| B—Current Coil (Stator) | E—Battery | H—Protection Device | K—Rectifier Diode Bridge |
| C—Exciting Coil (Rotor) | F—Indicator Light | | |

The Magneton alternator is a synchronous three-phase generator. The current coil is located in the stator, and the exciting current is supplied by the diode trio (J) through the regulator (D+ circuit), two carbon brushes and slip rings to the exciting coil in the rotor.

The alternator is normally driven by the fan belt from the engine crankshaft. The rotor is supported by two permanently lubricated bearings.

The alternator generates alternating current which is then transformed into direct current by the rectifier diode bridge (K).

The alternating windings are delta-connected. The coil ends X, Y, and Z are connected to the rectifier diode

as shown. Alternating current is generated in each stator coil (B) of the alternator. During one revolution of the rotor (C), the voltage in the stator coil rises from 0 to the positive maximum, drops to 0, rises to the negative maximum and again drops to 0. The current then flows through the diode and terminal B+ directly to the positive pole of the battery.

A sealed electronic regulator is used to regulate alternator voltage. This regulator, which cannot be adjusted, limits the alternator voltage to approximately 14 volts.

A protection device (H), including a Zener diode and a capacitor, protects diode from voltage surges and suppresses radio interference.

CD30489 -JUN-07JAN97

40
05
1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B88 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B88 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B88 -19-08MAY02-3/3

40
10
1

Magneton Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush	Minimum Exposed Length	7 mm (0.27 in.)
Rectifier Bridge-to-Rear Housing Nuts	Torque	3 N•m (27 lb-in.)
Capacitor Mounting Nut	Torque	3 N•m (27 lb-in.)
B+ Terminal Nut	Torque	4 N•m (35 lb-in.)
“W” Terminal Nut	Torque	3 N•m (27 lb-in.)
Front-to-Rear Housing Bolts	Torque	3 N•m (27 lb-in.)
Alternator Pulley Nut	Torque	40 N•m (29 lb-ft)

OUC1004,0000B8B -19-21SEP00-1/1

Magneton Charging Circuit Test Specifications


John Deere Alternator Part No.	Magneton Alternator Model No. ^a	Rated Amps	Nominal Voltage	Nominal Alternator rpm	Pulley Grooves
RE500502	9516-763	55	14	6000	Single
RE501634	443 113 516 241	55	12	6000	Poly-Vee
RE503543	443 113 516 971	40	24	6000	Poly-Vee
RE506196	9515-241	55	14	6000	Poly-Vee
RE506197	9515-765	55	12	6000	Single
RE57960	443 113 516 765	55	14	6000	Single
RE57961 ^b	443 113 516 762	55	14	6000	Dual
RE70779	443 113 516 875	40	24	6000	Single
RE70780	443 113 516 872	40	24	6000	Dual

^aMagneton Alternators are now manufactured by Pal-Mag Company (since 1988).

^bNot a service part. Order RE57960.

Item	Specification
Rotor winding resistance	2.95 ohms
Stator resistance	0.00 ohms
Alternator output voltage	13.5—14.2 volts
Working temperature range	-40°C—+90°C
Maximum D+ terminal current load	0.5 amp
Maximum continuous alternator speed	13000 rpm

Exploded View of Alternator



Alternator—Exploded View

- 1—Pulley Nut, M14 x 1.5
- 2—Lock Washer
- 3—Pulley¹
- 4—Fan

- 5—Rotor
- 6—Rear Bearing
- 7—Spring Collar
- 8—Stator

- 9—Front Bearing
- 10—Front Housing
- 11—Regulator and Brush Assembly¹

- 12—Rectifier Bridge Assembly¹
- 13—Capacitor¹
- 14—Rear Housing

¹ Available as service parts.

CD30488 -JUN-13DEC96

40
10
4

Identification

The information for parts identification is stamped on the body of the alternator.



CD30470 -JUN-13DEC96

Parts Identification

RG, RG34710, 2183 -19-15MAR97-1/1

Troubleshooting


Symptom	Problem	Solution
Alternator indicator light stays off with ignition on and engine not running.	Loose connection	Check
	Regulator failure	Replace brush/regulator assembly
	Stator failure (short-circuit)	Replace complete alternator.
Alternator indicator light stays on with engine running (alternator is not charging) at any speed.	Drive belt loose or broken	Adjust tension or replace
	Loose connection	Check
	Brush/regulator or capacitor failure	Replace
	Diode failure	Replace complete rectifier bridge
	Stator failure	Replace complete alternator
	Rotor failure	Replace complete alternator
Alternator indicator light stays on with engine running (alternator is not charging) at low speed.	Alternator speed too low	Use smaller alternator pulley
Battery overcharging.	Low electrical consumption	Use regulator with narrower regulation range (RE69380)
	Regulator failure	Replace

RG, RG34710, 2184 -19-19OCT00-1/1

Disassembly of Alternator

1. Remove pulley nut (A), lock washer, pulley and fan from shaft.

A—Pulley Nut




Remove Pulley Nut

ZT0613 -UN-01FEB94

RG, RG34710, 2185 -19-12SEP02-1/7

2. Remove shaft key (B) and spacer (C) from shaft.

B—Shaft Key
C—Spacer



Remove Shaft Key and Spacer

ZT0614 -UN-01FEB94


Continued on next page

RG, RG34710, 2185 -19-12SEP02-2/7

40
10
7

3. Disconnect wire (D) from terminal. Remove screws and washers (E). Remove brush/regulator assembly by tilting top of regulator up and away from alternator.

D—Wire
E—Screws and Washers




CD30471 -UN-13DEC96

Remove Brush/Regulator Assembly

RG,RG34710,2185 -19-12SEP02-3/7

4. Remove the three bolts (A) from front housing side.

A—Bolts (3 Used)




ZT0616 -UN-01FEB94

Remove Bolts

RG,RG34710,2185 -19-12SEP02-4/7

5. Place alignment marks along the alternator to note the orientation of housings. Split alternator by carefully prying at slot (B) using a screwdriver against housing.

B—Slot



CD30472 -UN-13DEC96


Split Alternator

Continued on next page

RG,RG34710,2185 -19-12SEP02-5/7

- Remove rotor/front housing assembly (C) from stator/rear housing assembly (D).

C—Rotor/Front Housing Assembly
D—Stator/Rear Housing Assembly




Housing Assemblies
RG, RG34710, 2185 -19-12SEP02-6/7

CD30473 -JUN-13DEC96

- Remove capacitor (E). Remove nuts and washers (F) from rear housing. Remove "B+" terminal nut and washers (G). Remove "W" terminal nut and washers (H). Remove stator/rectifier bridge assembly (J) from rear housing.

E—Capacitor
F—Nuts and Washers (2 Used)
G—"B+" Terminal Nut and Washers
H—"W" Terminal Nut and Washers
J—Stator/Rectifier Bridge Assembly



Remove Capacitor

CD30474 -JUN-13DEC96

RG, RG34710, 2185 -19-12SEP02-7/7


Testing Brush/Regulator Assembly

- Check brushes (A) for free movement against spring tension. If either brush is worn beyond specification, replace the brush/regulator assembly. Also replace if the brushes are cracked or oil-soaked.

Specification

Brush—Minimum Exposed Length..... 7 mm (0.27 in.)

- Touch each brush with meter test leads. No continuity should be found, even if either brush can slip up or down in its channel. If there is continuity, replace the brush/regulator assembly.



Check Brushes

A—Brushes

CD30475 -JUN-13DEC96

40
10
9


Continued on next page

RG, RG34710, 2186 -19-15MAR97-1/2

3. Check for continuity between brush (B) and wire (C).
4. Connect regulator to an electrical source corresponding to the nominal voltage, the "+" at the wire (C) and the "-" (ground) on the body (E). Continuity between brush (D) and body should be observed in one direction only.

If defective, replace the brush/regulator assembly.

- B—Brush
- C—Wire
- D—Brush
- E—"—" Body Ground



Check for Continuity


CD30476 -UN-13DEC96

RG,RG34710,2186 -19-15MAR97-2/2

Testing Rotor

1. Inspect slip rings (A) of rotor for scoring or rough surface. Polish slip rings sparingly with No. 00 sandpaper.

- A—Slip Rings



Inspect Slip Rings

CD30477 -UN-13DEC96

RG,RG34710,2187 -19-15MAR97-1/2

2. Connect ohmmeter between both slip rings of the rotor. Resistance should be 2.95 ohms.
3. Check the rotor for insulation by connecting an ohmmeter between each slip ring and shaft (B). Resistance should be infinity.

If insulation, resistance or slip ring are defective, replace complete alternator.

- B—Shaft



Slip Ring and Shaft

CD30478 -UN-13DEC96


RG,RG34710,2187 -19-15MAR97-2/2

Testing Stator/Rectifier Bridge Assembly

1. Inspect stator winding (A) for discoloration or a burned odor indicating a short circuit.
2. Check stator for grounds by connecting an ohmmeter between each stator lead (B) and stator frame (C). Resistance should be infinity.

Replace complete alternator if any defect is noted.

- A—Stator Winding
- B—Stator Lead
- C—Stator Frame




Test Stator/Rectifier Bridge Assembly

CD30479 -UN-13DEC96

RG, RG34710, 2188 -19-15MAR97-1/2

3. Check positive diodes by connecting an ohmmeter between each phase terminal (D) and the "B+" plate (E), then reverse the polarity.
4. Check negative diodes by connecting an ohmmeter between each phase terminal (D) and the "B—" plate (F) or ground, then reverse the polarity.
5. Check the diode trio by connecting an ohmmeter between each phase terminal (D) and the "D+" terminal (G), then reverse the polarity.

A diode with a high reading in one direction and a low reading in the other direction is good. A diode with the same reading in both directions is bad. If any diode fails the test, replace the entire rectifier bridge.



Check Positive Diodes

- D—Phase Terminal
- E—"B+" Plate
- F—"B—" Plate
- G—"D+" Terminal


CD30480 -UN-13DEC96

RG, RG34710, 2188 -19-15MAR97-2/2

Rectifier Bridge Replacement

1. To replace the rectifier bridge, unsolder the leads of phase winding (A) and "W" terminal (B) using a soldering iron.
2. Position the replacement rectifier bridge and solder phase winding leads. Solder "W" terminal at the proper location.

A—Phase Winding
B—"W" Terminal



Rectifier Bridge Replacement


CD30481 -UN-13DEC96

RG.RG34710,2189 -19-15MAR97-1/1

Reassembly of Alternator

NOTE: Refer to exploded view earlier in this group.

1. Install stator and rectifier bridge into rear housing using alignment mark.



Reassembly of Alternator

CD30482 -UN-13DEC96

Continued on next page

RG.RG34710,2190 -19-15MAR97-1/6

- Secure rectifier bridge to rear housing by the two nuts and washers (A). Install capacitor (B) with nut and washer (C). Tighten nuts (A) and (C) to specifications.

Specification

Rectifier Bridge-to-Rear Housing	
Nuts—Torque	3 N•m (27 lb-in.)
Capacitor Mounting Nut—Torque	3 N•m (27 lb-in.)

- Install insulated washer, flat washer, capacitor wire, lock washer and nut on “B+” terminal (D). Tighten to specification.


Specification

B+ Terminal Nut—Torque	4 N•m (35 lb-in.)
------------------------------	-------------------

- Install insulated washer, flat washer, spade terminal, lock washer and nut on “W” terminal (E). Tighten to specifications.

Specification

“W” Terminal Nut—Torque	3 N•m (27 lb-in.)
-------------------------------	-------------------



Install Parts

- A—Nuts and Washers (2 Used)
- B—Capacitor
- C—Nut and Washer
- D—“B+” Terminal
- E—“W” Terminal

CD30483 -UN-13DEC96

RG, RG34710, 2190 -19-15MAR97-2/6


- Place rotor/front housing assembly into rear housing using alignment marks. Press by hand for final installation.

- Install the three mounting bolts (F) with washers. Tighten to specifications.

Specification

Front-to-Rear Housing Bolts—	
Torque	3 N•m (27 lb-in.)

- F—Mounting Bolts (3 Used)



Install Mounting Bolts

CD30484 -UN-13DEC96


Continued on next page

RG, RG34710, 2190 -19-15MAR97-3/6

40
10
13

7. Install brush/regulator assembly with caution. Tilt it so that the brushes contact the rotor slip rings. Secure brush/regulator with the two screws and washers (G). Attach wire to terminal (H).

G—Screws and Washers (2 Used)
H—Terminal




CD30485 -UN-13DEC96

Install Brush/Regulator Assembly

RG,RG34710,2190 -19-15MAR97-4/6

8. Install shaft key (J), spacer (K) and fan (L).

J—Shaft Key
K—Spacer
L—Fan



CD30486 -UN-13DEC96

Install Shaft Key, Spacer, and Fan


RG,RG34710,2190 -19-15MAR97-5/6

9. Install pulley (M) with lock washer and nut (N). Tighten to specifications.

Specification

Alternator Pulley Nut—Torque 40 N•m (29 lb-ft)

M—Pulley
N—Lock Washer and Nut



CD30487 -UN-16DEC96

Install Pulley

RG,RG34710,2190 -19-15MAR97-6/6

Installation of Alternator

Refer to machine technical manual to install alternator and to adjust belt tension.

RG,RG34710,2191 -19-15MAR97-1/1

Section 45

Leece-Neville Alternators

Contents

Page

Group 05—Leece-Neville Alternator Theory of Operation

Alternator Operation45-05-1

Group 10—Leece-Neville Alternator Repair

Essential Tools45-10-1

Leece-Neville Repair Specifications.45-10-1

Leece-Neville Charging Circuit Test
Specifications.45-10-2

Repair Alternator45-10-2

Charging System Failure.45-10-2

Alternator Troubleshooting45-10-3

Alternator Output Test.45-10-3

Diode Trio Test45-10-4

Full Field Test45-10-5

Adjust Regulator45-10-6


Alternator Operation

Vehicle battery power is applied to the ignition terminal (A), to supply excitation to the field coil (rotor coil) through the regulator and brushes. This creates a magnetic field around the rotor and through the stator.

When the rotor is set in motion, the moving magnetic field induces an alternating current (AC) in the stator windings. This output current increases with the speed of the rotor.

The AC produced in the stator is converted to direct current (DC) by the positive and negative rectifier assemblies. The rectifier assemblies are connected to the alternator output terminals to provide DC output for charging the batteries and to satisfy the vehicle electrical loads.

The adjustable regulator monitors the output voltage through sensing leads which are connected to the positive and negative rectifier assemblies. When the output voltage deviates from the set voltage, the regulator takes corrective action to maintain the output voltage at the proper level.



Alternator Operation

A—Ignition Terminal
B—Battery

RG11155 -UN-12SEP00

OOU1004,0000B34 -19-11SEP00-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000B8C -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



RW11274 -JUN-12DEC88

OUO1004.0000B8C -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester. JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000B8C -19-08MAY02-3/3

Leece-Neville Repair Specifications

Item	Measurement	Specification
Alternator Pulley Nut	Torque	95—108 N•m (70—80 lb-ft)

45
10
1

OUO1004.0000B3B -19-13SEP00-1/1

Leece-Neville Charging Circuit Test Specifications

John Deere Alternator Part No.	Leece-Neville Alternator Part No.	Volts	Rated Amps
RE500920	A0014860JB	12	200
RE522329	A0014730LC	24 (28)	140

OUO1022,0000002 -19-07JUL05-1/1

Repair Alternator

There are no serviceable parts for the alternator available from John Deere. Replace alternator as required. (Refer to machine technical manual for removal and installation.) If alternator pulley is removed, reinstall and torque pulley nut to specifications.

Specification

Alternator Pulley Nut—Torque 95—108 N•m (70—80 lb-ft)

OUO1004,0000B35 -19-11SEP00-1/1

Charging System Failure

Causes of Charging System Failure:

- Charging system malfunction is identified by battery condition.

Undercharged batteries caused by one or a combination of the following:

- Loose belts; corroded, broken, loose, or dirty terminals; broken wiring; undersize wiring; defective batteries.
- Alternator field circuit malfunction caused by one or a combination of the following:
 - Poor contacts between regulator and brushes.
 - Defective diode trio.
 - No residual magnetism in rotor.
 - Defective or improperly adjusted regulator.
 - Damaged or worn brushes.

- Damaged or worn slip rings.
- Poor connection between slip ring assembly and field coil leads.
- Rotor coil shorted, open, or grounded.
- Alternator generating section malfunction caused by one or a combination of the following:
 - Stator phase(s) shorted, open, or grounded.
 - Rectifier assembly grounded.
 - Rectifier(s) shorted or open.

Overcharged batteries caused by one or a combination of the following:

- Defective battery.
- Defective diode trio.
- Defective or improperly adjusted regulator.
- Poor sensing lead contact to regulator or rectifier assembly.

OUO1004,0000B3D -19-13SEP00-1/1

Alternator Troubleshooting

NOTE: For fast and accurate troubleshooting, ensure that belts are properly tensioned, and that wiring and terminals are in good working condition. Check batteries per manufacturer's specifications to establish if they are defective. Ensure that batteries are 95—100% charged.

OUO1004,0000B3E -19-13SEP00-1/1

Alternator Output Test

1. Shut off all electrical accessories and run engine at approximately 1000—1200 rpm.

IMPORTANT: Use an accurate voltmeter to measure output voltage. DO NOT rely on dashboard gauges.

2. Connect a DC voltmeter to the battery terminals and measure voltage. Make a note of the readings, Compare to the values specified by the vehicle manufacturer. If reading is above specified voltage, an OVERCHARGE condition is present.
3. If the reading is below specified voltage, an UNDERCHARGE condition is present.

If either condition is observed, perform DIODE TRIO TEST in this group.

NOTE: The following tests are designed to identify the source of alternator failure. Refer to the manufacturer's service manual for detailed descriptions on how to disassemble, test, and properly assemble the alternator. No repair parts are available from John Deere. Only replacement alternators are available.

OUO1004,0000B3F -19-13SEP00-1/1

Diode Trio Test

1. Remove the diode trio from the alternator.
2. Connect the negative (—) ohmmeter test lead to the diode trio lead terminal. Connect the positive (+) test lead to each of the three copper contact pads, one at a time. Observe the resistance at each contact pad and write down the resistance for each contact for later reference.
3. Reverse the leads so the positive (+) lead is connected to the diode trio lead terminal and the negative (—) test lead connects to the contact pads. Again observe the resistance at each of the contact pads and record the results for each contact.

NOTE: The diode trio is OK when a LOW resistance reading is observed in one direction and a HIGH resistance is observed in the other direction. Occasionally the diode trio malfunctions under operating conditions only.

4. If the diode trio is malfunctioning, replace alternator. Otherwise, reinstall the diode trio on the alternator.

NOTE: There are no serviceable parts available from John Deere. Replacement of entire alternator is necessary if failure is detected.

OUO1004,0000B40 -19-13SEP00-1/1

Full Field Test


1. Run engine at approximately 1000 rpm with all electrical accessories OFF. Measure the output voltage across the alternator terminals (C and D) and write it down for later reference.

NOTE: Use a digital voltmeter with 0.01-volt reading capabilities.

2. Attach a short jumper to a 51 mm (2 in.) piece of stiff wire (a paper clip is suitable).
3. Connect the other end of the jumper to the negative (—) alternator output terminal (D) and insert the wire in the full field access hole (B). Hold the wire firmly against the brush terminal inside the housing.
4. With the jumper in place, connect a voltmeter across the alternator terminals (C and D) and run the engine at approximately 1000 rpm. Compare this voltage reading with the voltage reading obtained in Step 1.
5. With the jumper still hooked up and the wire in the FULL FIELD ACCESS HOLE, connect an AC voltmeter across terminals 1 and 2 (G and F), 1 and 3 (G and E), and 2 and 3 (F and E), and note the voltages. If all of the voltages are approximately the same, they are considered "balanced."
6. Remove the jumper and wire from the alternator. If the voltage in step 4 is higher than the voltage in step 1, and the voltages measured in step 5 are balanced, the stator and alternator are OK.

If the voltage in step 4 is higher than the voltage in step 1, and the voltages measured in step 5 are not balanced, the alternator stator or rectifier(s) are defective. Replace alternator.

If the voltage in step 4 is lower or equal to the voltage in step 1, and the voltages measured in step 5 are balanced, the alternator is defective. Replace alternator.



Test Alternator

- A—Ignition Terminal
- B—Full Field Access Hole
- C—Positive Battery Terminal
- D—Negative Output Terminal
- E—Terminal 3
- F—Terminal 2
- G—Terminal 1

RG11157A -JUN-13SEP00

45
10
5

If the voltage in step 4 is lower or equal to the voltage in step 1, and the voltages measured in step 5 are not balanced, alternator stator or rectifier(s) are defective. Replace alternator.

OUC1004,0000B38 -19-12SEP00-2/2


Adjust Regulator

NOTE: Battery must be at least 95% charged prior to performing this procedure. Also, make sure wire connections and belt tension are OK.

1. Shut off all electrical accessories and run the engine at approximately 1000 rpm.
2. Connect a voltmeter across alternator terminals.
3. Remove plastic screw (A) from regulator and insert a small screwdriver through hole to engage in slotted adjustment screw inside regulator.

IMPORTANT: The adjustment potentiometer screw has high and low stops. DO NOT exert excessive pressure and force the screwdriver past the stops.

4. Turn the adjustment screw clockwise to raise the voltage or counterclockwise to lower the voltage. Set alternator voltage to vehicle specifications.
5. Reinstall plastic screw (A) in regulator.



Adjust Regulator

A—Plastic Screw

RG11156A -UN-13SEP00

OUC1004,0000B37 -19-11SEP00-1/1

Section 50 Prestolite Alternators

Contents

	Page
Group 05—Prestolite Alternator Theory of Operation	
Alternator Operation	50-05-1
Group 10—Prestolite Alternator Repair	
Essential Tools	50-10-1
Prestolite Charging Circuit Test	
Specifications	50-10-2
Repair Alternator	50-10-2
Charging System Failure	50-10-3
Alternator Troubleshooting	50-10-3
Test Alternator	50-10-4

Contents

Alternator Operation


The alternator converts mechanical and magnetic energy to AC current and voltage by the rotation of an electromagnetic field/rotor (C) inside a three-phase stator assembly (B). The AC current and voltage are changed to DC by a three-phase, full-wave rectifier assembly using negative and positive diodes (A and H).

Since diodes pass current in only one direction, their arrangement in the alternator eliminates the need for a cut-out relay in the voltage regulator. The individual rectifier diodes, three positive (H) and three negative (A), are assembled in two temperature dissipating heat sinks. The heat sinks are placed in the alternator with threaded studs that also serve as circuit terminals.

Maximum charging current is limited by the design and connections in the stator assembly, eliminating the need for a current regulating relay in the voltage regulator.

The diode trio (E) is a low-current version of the rectifier assembly and must be of the same polarity. The diode trio allows for the use of a charging lamp and prevents battery drain when the charging system is not in operation.

The voltage regulator is an electronic switching device which senses the system voltage level at regulator terminal (F) and switches the voltage applied to the field in order to maintain proper system voltage.



Alternator Operation

- A—Negative Diode Assembly
- B—Stator
- C—Rotor
- D—Negative Output
- E—Diode Trio
- F—Regulator Terminal
- G—Positive Output
- H—Positive Diode Assembly

RG11160 -UN-18SEP00

OUO1004,0000B43 -19-14SEP00-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000B8D -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



RW11274 -JUN-12DEC88

OUO1004.0000B8D -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester. JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000B8D -19-08MAY02-3/3

Prestolite Charging Circuit Test Specifications

John Deere alternator Part No.	Prestolite Alternator Part No.	Volts	Rated Amps
AH148633	8SC2020Z	12	185
AH211398		12	185
AT103344	8EM2009NB	12	65
AT178902	8MR2084KS	12	51
RE20486	70D43198S, 85AZ2035V	12	130
RE50811	8MR2069T, 70D43841T, 70D43841T02	12	90
RE522329	A0014730LC	24 (28)	140

OUC1022,0000001 -19-07JUL05-1/1

Repair Alternator

There are no serviceable parts from John Deere available for this alternator. Replace alternator as required.

Tighten pulley nut to specifications.

Specification

Alternator Pulley Nut—Torque 80 N•m
(59 lb-ft)

OUC1004,0000B42 -19-07JUL05-1/1

Charging System Failure

Causes of Charging System Failure:

- Charging system malfunction is identified by battery condition.

Undercharged batteries caused by one or a combination of the following:

- Loose belts; corroded, broken, loose, or dirty terminals; broken wiring; undersize wiring; defective batteries.
- Alternator field circuit malfunction caused by one or a combination of the following:
 - Poor contacts between regulator and brushes.
 - Defective diode trio.
 - No residual magnetism in rotor.
 - Defective or improperly adjusted regulator.
 - Damaged or worn brushes.

- Damaged or worn slip rings.
- Poor connection between slip ring assembly and field coil leads.
- Rotor coil shorted, open, or grounded.
- Alternator generating section malfunction caused by one or a combination of the following:
 - Stator phase(s) shorted, open, or grounded.
 - Rectifier assembly grounded.
 - Rectifier(s) shorted or open.

Overcharged batteries caused by one or a combination of the following:

- Defective battery.
- Defective diode trio.
- Defective or improperly adjusted regulator.
- Poor sensing lead contact to regulator or rectifier assembly.

OUO1004,0000B3D -19-13SEP00-1/1

Alternator Troubleshooting

NOTE: For fast and accurate troubleshooting, ensure that belts are properly tensioned, and that wiring and terminals are in good working condition. Check batteries per manufacturer's specifications to establish if they are defective. Ensure that batteries are 95—100% charged.

OUO1004,0000B3E -19-13SEP00-1/1

Test Alternator

Alternator Output Test

NOTE: Ensure that belts are properly tensioned, and that wiring and terminals are in good working condition. Check batteries per manufacturer's specifications to establish if they are defective. Ensure that batteries are 95—100% charged.

IMPORTANT: Use an accurate voltmeter to measure output voltage. **DO NOT** rely on dashboard gauges.


1. Start and run engine at approximately 1000 rpm. Turn on vehicle headlights and blower fan (low speed). Check system voltage by connecting voltmeter to output terminal (G) and negative battery post. Compare reading to the values specified by the vehicle manufacturer.
2. If alternator voltage does not fall within the specified range, replace alternator.

Diode Trio Test (MR Series Alternator)

1. Check for battery voltage at output terminal (G) and for 1.5—3 volts at regulator terminal (C).
2. Install jumper wire (H) between terminals (C and G).
3. Operate engine at low idle with all electrical accessories OFF.
4. If charging lamp (B) is off and charging voltage is present at output terminal (G), the diode trio is probably open (defective). Replace alternator.

Field Diode Test (SC Series Alternators)

1. Check for battery voltage at output terminal.
2. Install jumper wire between alternator positive output terminal and indicator lamp terminal.
3. Operate engine at low idle with all electrical accessories OFF.



Typical Alternator Configuration

- A—Ignition Switch
- B—Charging Lamp
- C—Regulator Terminal
- D—Negative Terminals
- E—Ground
- F—Battery
- G—Positive Output Terminal
- H—Jumper Wire (Use Only for Diode Trio Test)

RG11158 -UN-15SEP00

Prestolite Alternator Repair

4. Connect voltmeter to positive and negative output terminals on alternator.
5. If alternator output is 13.5—14.1 volts, the field diode assembly is defective. Replace alternator.

OUO1004,0000B46 -19-12SEP02-2/2

Section 55 Iskra Alternators

55

Contents

Page

Group 05—Iskra Alternator Theory of Operation

Operation of Alternator55-05-1

Group 10—Iskra Alternator Repair

Essential Tools55-10-1

Iskra Charging Circuit Repair Specifications . . .55-10-2

Iskra Charging Circuit Test Specifications55-10-3

Exploded View of Alternator55-10-4

Identification55-10-5

Troubleshooting.55-10-6


Remove and Install Pulley.55-10-7

Testing Brush/Regulator Assembly55-10-8

Install Brush/Regulator Assembly55-10-10

Installation of Alternator.55-10-10

Operation of Alternator



Iskra Alternator

- | | | | |
|-------------------------|-------------------|--------------------------|--------------------------|
| A—Alternator | D—Regulator | G—Ignition | J—Diode Trio |
| B—Current Coil (Stator) | E—Battery | H—RFI Suppression Device | K—Rectifier Diode Bridge |
| C—Exciting Coil (Rotor) | F—Indicator Light | | |

The Iskra alternator is a synchronous three-phase generator. The current coils are located in the stator. Alternator is self-excited through diode trio (J), brushes and slip rings, to the exciting coil in the rotor, regulator, negative pole of the alternator (ground), and back to the stator (current) coils (B).

The alternator is normally driven by the fan belt from the engine crankshaft. The rotor is supported by two permanently lubricated bearings.

The alternator generates alternating current which is then transformed into direct current by the rectifier diode bridge (K).

The stator windings are delta-connected. The coil ends U, V and W are connected to the rectifier diode bridge

as shown. Alternating current is generated in each stator coil (B) of the alternator. During one revolution of the rotor (C), the voltage in the stator coil rises from 0 to the positive maximum, drops to 0, rises to the negative maximum and again drops to 0 per one rotor pole pair. The current then flows through the diode and terminal B+ directly to the positive pole of the battery.

A sealed electronic regulator is used to regulate alternator voltage. This regulator, which cannot be adjusted, regulates the alternator voltage to approximately 14.5 volts.

A capacitor (H), suppresses radio interference.

RG12225 -UN-29JUL02

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B88 -19-19JUN02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B88 -19-19JUN02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B88 -19-19JUN02-3/3

Iskra Charging Circuit Repair Specifications

Item	Measurement	Specification
Brush	Minimum Exposed Length	1 mm (0.04 in.)
Rectifier Bridge-to-Rear Housing Bolts	Torque	2.9—4.1 N•m (26—36 lb-in.)
Capacitor Mounting Stud	Torque	2.9—4.1 N•m (26—36 lb-in.)
B+ Terminal Nut (65 amp)	Torque	4.2—6.0 N•m (37—53 lb-in.)
B+ Terminal Nut (75 amp)	Torque	9.8—14.0 N•m (87—124 lb-in.)
“W” Terminal Nut	Torque	2.7—4.1 N•m (24—36 lb-in.)
Front-to-Rear Housing Bolts	Torque	4.2—6.0 N•m (37—53 lb-in.)
Alternator Pulley Nut	Torque	60—70 N•m (44—52 lb-ft)

OUOD006.000003A -19-19JUN02-1/1


Iskra Charging Circuit Test Specifications

John Deere Alternator Part No.	Iskra Alternator Model No.	Iskra Alternator Part No.	Rated Amps	Nominal Voltage	Nominal Alternator rpm	Pulley Grooves
RE505690	AAK4335	11.203.369	50	28	6000	8
RE505895	AAK3307	11.201.869	75	14	6000	8
RE505896	AAK5378	11.203.159	95	14	6000	8
RE509106	AAK3359	11.201.998	65	14	6000	1
RE525689	AAK4334	11.203.368	75	14	6000	8
RE505896A	AAK5123	11.201.727	95	14	6000	
69X56702A	AAK3360	11.203.002	65	14	6000	
RE204426	AAK5382	11.203.167	95	14	6000	
—	AAK3394	11.203.202	95	14	6000	
RE523953A	AAK3395	11.203.203	120	14	6000	
RE522401	AAK5532	11.203.278	50	28	6000	

Item	Specification
Rotor winding resistance	2.70—2.97 ohms
Stator resistance (Phase resistance)	160—180 milliohms (65 amp); 101—111 milliohms (75 amp)
Alternator output voltage	14.3—14.6 volts (20°C), 0.5 I max, 0.5 n max)
Working temperature range	-40°C—+110°C
Maximum D+ terminal current load	0.5 amp
Maximum continuous alternator speed	13000 rpm

OUOD006,000003B -19-07JUL05-1/1

Exploded View of Alternator



Alternator—Exploded View

Continued on next page

OUD006.000003C -19-19JUN02-1/2

RG12474 -UN-18JUL02

Iskra Alternator Repair

1—Fan	5—Through Bolt	10—Rectifier	14—Gasket
2—Drive End Housing	6—Rotor	11—Rear End Housing	15—Protective Cover
3—Bearing With Cover	7—Pulley	12—Fixing Lug	16—Regulator/Brush Holder ¹
4—Stator	8—Pulley Kit ¹	13—Capacitor	17—Brush ¹
	9—Ball Bearing		

55
10
5

¹ Available as service parts.

OUOD006,000003C -19-19JUN02-2/2

Identification

The information for parts identification is provided on the label attached to the body of the alternator.



Parts Identification

RG12226 -UN-26JUN02

OUOD006,000003D -19-19JUN02-1/1

Troubleshooting

Symptom	Problem	Solution
Alternator indicator light stays off with ignition on and engine not running.	Loose/bad connection	Check
	Bad indicator light	Replace indicator light
	Discharged/defective battery	Charge/replace battery
	Regulator failure	Replace brush/regulator assembly
	Open rotor (exciting) circuit	Replace alternator
	Rectifier failure (breakdown of power diode)	Replace alternator
Alternator indicator light stays on with engine running at high speed (alternator is not charging).	Drive belt loose or broken	Adjust tension or replace
	Loose connection	Check
	Brush/regulator failure	Replace brush/regulator assembly
	Grounded conductor D+	Replace alternator
	Defective rectifier bridge/short circuited conductor DF or rotor winding	Replace alternator
Alternator indicator light glows brightly with engine not running, and glows dimly with engine running.	Excessive resistance in power circuit or conductors	Check conductors and power circuit
	Regulator failure	Replace regulator/brush assembly
	Alternator failure	Replace alternator

Continued on next page

OUOD006,000003E -19-19JUN02-1/2

Symptom	Problem	Solution
Discharged battery	Loose drive belt	Tension belt properly
	Open or high resistance in power circuit	Check circuit
	Defective battery	Replace battery
	Defective regulator	Replace regulator/brush assembly
	Defective alternator	Replace alternator

OUOD006,000003E -19-19JUN02-2/2


Remove and Install Pulley

1. Remove pulley nut (A), washer(s) and pulley from shaft.
2. Install pulley, washer(s) and pulley nut. Tighten to specification.

Specification

Alternator Pulley Nut—Torque 60—70 N•m (44—52 lb-ft)

A—Pulley Nut



Remove Pulley Nut


RG-12227 -JUN-26JUN02

OUOD006,000003F -19-19JUN02-1/1

Testing Brush/Regulator Assembly

1. Remove screws (A). Remove brush/regulator assembly from rear end housing.

A—Screws (2 used)




Remove Brush/Regulator Assembly

RG12228 -UN-26JUN02

OUOD006,0000040 -19-19JUN02-1/4

2. Remove wire from terminal (B).

B—Terminal



Remove Wire

RG12229 -UN-26JUN02

Continued on next page


OUOD006,0000040 -19-19JUN02-2/4

3. Check brushes (C) mounted on brush holder (D) for free movement against spring tension. If either brush is worn beyond specification, replace the brush/regulator assembly. Also replace if the brushes are cracked or oil-soaked.

Specification

Brush—Minimum Exposed Length..... 1 mm (0.04 in.)

- C—Brushes
- D—Brush Holder



Check Brushes

RG12230 -JUN-26JUN02


OQOD006,0000040 -19-19JUN02-3/4

4. To test voltage regulation of regulator, identify terminals using top diagram on right, and make connections as shown in bottom diagram.

5. Increase rectifier voltage.


Lamp in circuit should glow when rectifier voltage is below 14.3V +/- 0.5V, and go out when rectifier voltage is 14.3V +/- 0.5V.

If lamp does not glow at all, or does not go out when voltage is 14.3V +/- 0.5V, regulator is defective and must be replaced.



Terminal Identification

RG12494 -JUN-29JUL02



Connections


RG12495 -19-18JUL02

OQOD006,0000040 -19-19JUN02-4/4

Install Brush/Regulator Assembly

1. Attach wire to terminal. Install brush/regulator assembly with caution. Fasten brush/regulator with the two screws (A) and washers.

A—Screws (2 Used)



Install Brush/Regulator Assembly

RG12228 -JUN-26JUN02

OUOD006,0000041 -19-19JUN02-1/1

Installation of Alternator

Refer to machine technical manual to install alternator and to adjust belt tension.

RG,RG34710,2191 -19-15MAR97-1/1

Section 60

Delco-Remy Starter Motors

Contents

	Page	Page
Group 05—Starting Circuit Theory of Operation		
General Information	60-05-1	
Typical Starting Circuit Operation	60-05-1	
Typical Starter Motor Operation	60-05-2	
 Group 10—Delco-Remy 10/20/22/25/27/28MT Starter Motor Repair		
Essential Tools	60-10-1	
Service Equipment and Tools	60-10-2	
Other Material	60-10-2	
Delco-Remy 10MT, 20MT, 22MT, 25MT, 27MT, 28MT Starter Motor Repair Specifications	60-10-3	
Delco-Remy 10MT, 20MT, 22MT, 25MT, 27MT, 28MT Starter Motor Test Specifications	60-10-4	
Diagnosing Starter Motor Malfunctions	60-10-6	
Delco-Remy Starter Motor Cutaway View—Series 10MT, 20MT, 22MT, 25MT, 27MT, 28MT	60-10-7	
Check Operation of Motor Drive	60-10-7	
Make Solenoid Pull-In Test	60-10-8	
Make Solenoid Hold-In Test	60-10-9	
Make Solenoid No-Load Test	60-10-9	
Disassemble Starter Motor and Test Components	60-10-10	
Clean Starter Motor Components	60-10-13	
Inspect Armature	60-10-14	
Make Short Circuit Test	60-10-14	
Make Armature Ground Test	60-10-15	
Make Open Circuit Test	60-10-15	
Make Ground Circuit Test for Field Windings	60-10-15	
Make Open Circuit Test for Field Windings	60-10-16	
Remove Field Coils (If Necessary)	60-10-16	
Install Field Windings	60-10-17	
Disassemble Solenoid	60-10-17	
Inspect and Clean Solenoid Parts	60-10-18	
Assemble Solenoid	60-10-19	
Remove Drive End Bushing and Wick	60-10-19	
Install Drive End Bushing and Wick	60-10-20	
Inspect Drive Motor ID	60-10-20	
Inspect Center Bushing ID	60-10-21	
Inspect Commutator End Frame Bushing	60-10-21	
Assemble Starter Motor	60-10-22	
Check Pinion Clearance	60-10-24	
Make Solenoid No-Load Test	60-10-25	
 Group 15—Delco-Remy 30MT, 35MT, 37MT Starter Motor Repair		
Essential Tools	60-15-1	
Service Equipment and Tools	60-15-2	
Other Material	60-15-2	
Delco-Remy 30MT, 35MT, and 37MT Starter Motor Repair Specifications	60-15-3	
Delco-Remy 30MT, 35MT, and 37MT Starter Motor Test Specifications	60-15-4	
Diagnosing Starter Motor Malfunctions	60-15-6	
Delco-Remy Starter Motor Cutaway View—Series 30MT, 35MT, and 37MT	60-15-7	
Test Starter Motor Before Disassembly	60-15-8	
Make No-Load Test for Solenoid	60-15-10	
Disassemble Delco-Remy Starter Motor (Series 35MT Illustrated)	60-15-12	
Install New Bushings During Disassembly	60-15-17	
Clean Starter Motor Components	60-15-18	
Inspect Armature	60-15-19	
Make Short Circuit Test	60-15-19	
Make Armature Ground Test	60-15-20	
Make Open Circuit Test	60-15-20	
Make Ground Circuit Test for Field Windings	60-15-21	
Make Open Circuit Test for Shunt Windings	60-15-21	
Make Open Circuit Test for Field Windings	60-15-22	
Remove Field Windings	60-15-22	
Inspect Brushes	60-15-23	
Test Brush Holder for Ground	60-15-23	
Inspect Brush Springs	60-15-24	
Inspect and Clean Solenoid	60-15-24	
Assemble Solenoid	60-15-24	
Inspect Plunger, Shift Lever, and Overrunning Clutch Assembly	60-15-25	
Assemble Starter Motor	60-15-25	
Check Armature End Play	60-15-28	
Check for Proper Pinion Clearance	60-15-29	
Make No-Load Test (After Assembly)	60-15-30	
 Group 20—Delco-Remy 40MT, 41MT, 42MT, 50MT Starter Motor Repair		
Essential Tools	60-20-1	

Continued on next page

Page

Other Material 60-20-2

Delco-Remy 40MT, 41MT, 42MT, and
50MT Starter Motor Repair Specifications . . . 60-20-3

Delco-Remy 40MT, 41MT, 42MT, and
50MT Starter Motor Test Specifications 60-20-4

Diagnosing Starter Motor Malfunctions 60-20-5

Delco-Remy Starter Motor Cutaway
View—Series 40MT, 41MT, 42MT, and
50MT 60-20-6

Test Starter Motor Before Disassembly 60-20-6

Test Pull-In and Hold-In Windings 60-20-9

Make No-Load Test 60-20-10

Disassemble Delco-Remy Starter Motor (
Series 50MT Illustrated) 60-20-12

Make Ground Circuit Test for Field
Windings 60-20-17

Make Open Circuit Test for Shunt
Windings 60-20-17

Make Open Circuit Test for Field Windings . . . 60-20-18

Remove Field Windings 60-20-18

Inspect Brushes 60-20-19

Test Brush Holder for Ground 60-20-20

Inspect Brush Springs 60-20-20

Install New Bushings—40MT, 41MT, and
42MT 60-20-21

Install New Bushings—50MT 60-20-23

Clean Starter Motor Components 60-20-24

Inspect Armature 60-20-25

Make Short Circuit Test 60-20-25

Make Armature Ground Test 60-20-26

Make Open Circuit Test 60-20-26

Inspect Solenoid Plunger and Shift Lever
Assembly 60-20-27

Inspect Overrunning Clutch and Pinion 60-20-27

Inspect and Clean Solenoid 60-20-28

Assemble Solenoid 60-20-28

Assemble Starter Motor 60-20-29

Check for Proper Pinion Clearance 60-20-32

60

General Information

IMPORTANT: Never operate starter motor longer than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

Typical Starting Circuit Operation

When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) to ground.


Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

Light shunt windings (J) are wrapped together with two of the heavy field windings. Shunt windings are connected to solenoid switch terminal and directly to ground. They provide additional low speed torque to assist engine rotation and prevent overheating of motor.

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).


Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Typical Starting Circuit Operation

- A—Wire from Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

Typical Starter Motor Operation



Typical Starter Motor Operation

R25228 -UN-14NOV88

- | | | | |
|------------------------|-------------------|-------------------|-----------------------|
| 1—Snap Ring | 7—Field Connector | 13—Field Windings | 19—Brake Washer |
| 2—Drive End Housing | 8—End Frame Cover | 14—Armature | 20—Wear Pads |
| 3—Shift Lever | 9—Brush | 15—Pole Shoe | 21—Overrunning Clutch |
| 4—Plunger | 10—Bushing | 16—Oil Seal | 22—Pinion Stop |
| 5—Shunt Field Terminal | 11—Thrust Washers | 17—Bushing | 23—Bushing |
| 6—Solenoid Assembly | 12—Commutator | 18—Felt | |

When solenoid (6) engages, it pulls shift lever (3). Shift lever pushes overrunning clutch drive (21) to engage pinion in starter gear on flywheel. As armature (14) turns, it cranks engine.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts,

but direction of current is reversed in pull-in winding. The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel. Brake washer (19) slows armature to a stop.

RG, RG34710, 2194 -19-15MAR97-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B8F -19-08MAY02-1/3

60
10
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B8F -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B8F -19-08MAY02-3/3

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B90 -19-25SEP00-1/2

Bushing, Bearing, and Seal Driver Set. D01045AA

Remove and install all commutator, drive end, and center bushings and/or bearings.

OUO1004,0000B90 -19-25SEP00-2/2

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.

OUO1004,0000B91 -19-25SEP00-1/1

Delco-Remy 10MT, 20MT, 22MT, 25MT, 27MT, 28MT Starter Motor Repair Specifications

Item	Measurement	Specification
Brush Spring	Minimum Tension	990 gram force (35 ounce-force)
Brushes	Minimum Length Beyond Holder	7.9 mm (0.31 in.)
Field Pole Shoe Screws	Torque	41 N•m (30 lb-ft)
Solenoid "R" Terminal Contact	Height	1.59—2.38 mm (0.062—0.093 in.)
New Drive End Housing Bushing	ID	11.709—11.811 mm (0.4610—0.4650 in.)
	Wear Limit	12.065 mm (0.475 in.)
	Oil Clearance	0.051—0.127 mm (0.0020—0.0050 in.)
	Wear Limit	0.432 mm (0.0170 in.)
Motor Drive	ID	14.275—14.300 mm (0.5620—0.5630 in.)
	Wear Limit	14.579 mm (0.5740 in.)
New Center Bearing Plate Bushing	ID	19.304—19.354 mm (0.7600—0.7620 in.)
	Wear Limit	19.608 mm (0.7720 in.)
	Oil Clearance	0.254—0.381 mm (0.0100—0.0150 in.)
	Wear Limit	0.635 mm (0.0250 in.)
New Commutator End Frame Bushing	ID	14.313—14.338 mm (0.5635—0.5645 in.)
	Wear Limit	14.554 mm (0.5730 in.)
	Oil Clearance	0.051—0.127 mm (0.0020—0.0050 in.)
	Wear Limit	0.406 mm (0.0160 in.)
Housing Attaching Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Commutator End Frame Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Pinion-to-Pinion Stop	Clearance	0.25—3.56 mm (0.010—0.140 in.)

60
10
3

Delco-Remy 10MT, 20MT, 22MT, 25MT, 27MT, 28MT Starter Motor Test Specifications

NOTE: Specification data for starters marked with an asterisk (*) was not available from Delco. Data provided for these asterisked starters in the following table was obtained from the John Deere Alternator, Generator, Starter and Battery Bench Tester Operator's Manual (OMTY25323, 14Dec01). This data is for remanufactured starters, provided by suppliers other than Delco, which can be used as replacements for the Delco starters. Specifications for the remanufactured starters may not correspond exactly with the original Delco starter specifications, and should be used for reference only. Delco does not either approve nor disapprove the use of these specifications.

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
* AA6004R	1108989	12	10	85 Max	3500—5500
* AH76330	1108360-10MT	12	9 (10)	90 Max	3500—6000
* AP22652	1107972	12	9	155 Max	8000—13000
* AR11150	1103004	12	10	85 Max	3500—5500
AR11160	1109434	12	10	65—110	6500—10700
AR11161	1107547	24	23.5	60—130	4900—8500
AR60085	1109147-20MT	12	9	50—80	5500—9000
AR69750	1998364-22MT	12	10	75—175	6900—14900
AR91813	1109576-SD300	12	10	65—110	6500—10700
AT10806	1107736	12	9	50	3500—6000
AT10958	1113104	12	9	50—75	3500—5500
AT11324	1107175	6	5.6	70	5500
AT12283	1107879	12	9	55—80	3500—6000
AT12458	1108672	12	11.8	55—85	6300—8700
AT15335	1107547	24	23.5	60—130	4900—8500
AT16883	1107176	6	5.6	70	5500
AT17411	1107573	12	11.8	55—85	6300—8700
AT18025	1109421-SD300	12	10	60—90	6500—10500
AT18150	1107577-20MT	12	9	40—140	8000—13000
AT18150	1107599-20MT	12	9	40—140	8000—13000
AT18150	1107863-20MT	12	9	40—140	8000—13000

Continued on next page

RG, RG34710, 2198 -19-07JUL05-1/2

Delco-Remy 10/20/22/25/27/28MT Starter Motor Repair

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
AT18150	1107871-20MT	12	9	40—140	8000—13000
AT19196	1998364-20MT	12	10	75—175	6900—14900
AT25619	1107863-20MT	12	9	40—140	8000—13000
AT25619	1107871-20MT	12	10	75—175	8000—13000
AT418T	1107685	12	9	50—75	3500—6000
AT452T	1107713	12	9	50—75	3500—6000
RE19187	1998367-20MT	12	9	40—140	6900—14900
RE19737	1998519-20MT	24	20	40—80	8000—13700
* RE49033	1113271-28MT	12	9	180 Max	2800 (Output Gear)
RE50095	1113271-28MT	12	10	125—190	3000—5600
RE51723	1113283-28 MT	12	10	125—190	3000—5600
RE51725	1113272-28MT	24	20	75—100	3600—6300
RE52119	1113272-28MT	24	20	75—100	3600—6300
RE60654	10479628-28MT	12	10.6	135—190	3600—5600
RE62916	1113271-28MT	12	10	125—190	3000—5600
RE64647	10479630-28MT	12	10.6	135—190	3600—5600

60
10
5

RG, RG34710, 2198 -19-07JUL05-2/2

Diagnosing Starter Motor Malfunctions

Fails to Operate, No Current Draw

Open field circuit (all field windings)

Open armature windings

Defective brush contact with commutator

Open solenoid windings

Defective solenoid contacts

Fails to Operate, High Current Draw

Grounded field windings or armature windings

Seized bearings

Low Speed, Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed, High Current Draw

Excessive friction

Shorted armature

Grounded armature or field windings

High Speed, High Current Draw

Shorted field windings


NOTE: This test will not detect individual open-circuited field coils—the stator would have a slow cranking speed but would pass this test.

RG, RG34710, 2199 -19-15MAR97-1/1

Delco-Remy Starter Motor Cutaway View— Series 10MT, 20MT, 22MT, 25MT, 27MT, 28MT

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

- A—Grommet
- B—Field Connectors
- C—Plunger
- D—Solenoid
- E—Return Spring
- F—Shift Lever
- G—Brake Washer
- H—Bushing
- I—Pinion Stop
- J—Overrunning Clutch
- K—Spiral Splines
- L—Center Bearing
- M—Field Coil
- N—Armature
- O—Bushing



Series 20MT Shown

60
10
7

RG, RG34710, 2200 -19-06MAY02-1/1

Check Operation of Motor Drive

1. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.



Turn Overrunning Clutch Pinion

Continued on next page

RG, RG34710, 2201 -19-15MAR97-1/2

- Turn armature by prying against pinion with screwdriver. Check for dragging armature, seized bushings or bent shaft.

If there is any interference, disassemble and repair starter motor.

NOTE: DO NOT conduct the no-load test unless armature turns freely.




Turn Armature

T81531 -UN-01NOV88

RG, RG34710, 2201 -19-15MAR97-2/2

Make Solenoid Pull-In Test

- To prevent damage, solenoid must be on starter motor when testing the windings.
- Disconnect field connector from solenoid "M" terminal as shown.




Disconnect Field Connector

T81532 -UN-01NOV88

RG, RG34710, 2202 -19-15MAR97-1/2

- Make connections as shown. Quickly adjust the carbon pile resistor to obtain 5 volts. The ammeter reading must be 13—15.5 amps.

- 1—Voltmeter
- 2—Carbon Pile Resistor
- 3—Battery
- 4—Ammeter



Make Connections

T81519 -UN-25MAY89

RG, RG34710, 2202 -19-15MAR97-2/2

Make Solenoid Hold-In Test

Make connections as shown. Adjust the carbon pile resistor to obtain 10 volts. The ammeter reading should be 14.5—16.5 amps.


A high ammeter reading indicates windings are grounded or short circuited.

A low ammeter reading indicates excessive resistance (usually in a connection).

No ammeter reading indicates windings are open circuited.

To prevent overheating, do not energize the pull-in winding longer than 15 seconds. Current draw will decrease as the winding temperature increases.

If the fault cannot be repaired and the solenoid performance is questionable, replace the windings.



Make Solenoid Hold-In Test

- 1—Voltmeter
- 2—Carbon Pile Resistor
- 3—Battery
- 4—Ammeter

T81520 -UN-25MAY89


60
10
9

RG, RG34710, 2203 -19-15MAR97-1/1

Make Solenoid No-Load Test

1. Clamp starter motor drive housing in vise.
2. Make connections as shown.
3. Close switch to operate starter motor and adjust carbon pile resistor to obtain 9.0 volts.

Current draw must be to specifications given at beginning of this group.




Make Solenoid No-Load Test

- 1—Carbon Pile Resistor
- 2—Battery
- 3—Ammeter
- 4—Voltmeter
- 5—Jumper Lead with Switch
- 6—Tachometer

T81521 -UN-25MAY89

DPSG, OUOE003, 27 -19-17DEC98-1/1

Disassemble Starter Motor and Test Components



Delco-Remy No. 1998367 Shown

- | | | | |
|--------------------------|--------------------------------|------------------------------------|-------------------------------|
| 1—Bushing | 13—Armature | 23—Snap Ring | 33—Brush Pivot Pin (2 Used) |
| 2—Lubricating Wick | 14—Thrust Washer | 24—Thrust Collar | 34—Brush Holder Kit |
| 3—Plug | 15—Center Bearing Assembly | 25—Dowel Pin | 35—Bushing |
| 4—Drive End Housing | 16—Brake Washer | 26—Field Frame | 36—Lubricating Wick |
| 5—Shifter Pivot Screw | 17—Lock Wire | 27—Insulating Bushing | 37—Commutator End Frame |
| 6—Spring Pin | 18—Collar | 28—Field Winding Coil | 38—Bolt (2 Used) |
| 7—Shifter | 19—Overrunning Clutch Spring | 29—Brush Spring (2 Used) | 39—Brush Ground Lead (2 Used) |
| 8—Solenoid Plunger | 20—Bushing | 30—Grounded Brush Holder (2 Used) | 40—Brush (4 Used) |
| 9—Solenoid Return Spring | 21—Overrunning Clutch Assembly | 31—Insulated Brush Holder (2 Used) | 41—Field Pole Shoe |
| 10—Gasket | 22—Pinion Stop | 32—Brush Mounting Screws (4 Used) | 42—Pole Shoe Screw (8 Used) |

N38155 -UN-20APR89

RG.RG34710,2204 -19-15MAR97-1/11

1. Remove commutator end frame cap screws and commutator end frame.



T81535 -UN-22MAR90

Remove Commutator End Frame

Continued on next page RG.RG34710,2204 -19-15MAR97-2/11

2. Disconnect field coil connector and remove field frame.



Remove Field Frame

RG,RG34710,2204 -19-15MAR97-3/11

T81536 -UN-22MAR90

60
10
11

- 3. Make sure brushes are not binding holders. The full brush surface must ride on commutator.
- 4. Check by hand to make certain brush springs are giving firm contact between brushes and commutator. If springs are distorted or discolored, replace them.



Check Brushes and Brush Springs

RG,RG34710,2204 -19-15MAR97-4/11

T5983AV -UN-12APR90

5. Remove brush pins, brush holders and brush springs. Check brush spring tension.

Specification

Brush Spring—Minimum Tension..... 990 gram force (35 ounce-force)



Remove Pins, Holders, and Springs

Continued on next page

RG,RG34710,2204 -19-15MAR97-5/11

T81537 -UN-22MAR90

6. Check brushes for being oil soaked or worn beyond specifications.

Specification

Brushes—Minimum Length
Beyond Holder..... 7.9 mm (0.31 in.)



T81523 -UN-22MAR90

Measure Brushes

RG, RG34710, 2204 -19-15MAR97-6/11

7. Tighten screws securely when installing new brushes.



T81538 -UN-22MAR90

Tighten Screws Securely

RG, RG34710, 2204 -19-15MAR97-7/11

8. Remove screws, solenoid switch assembly, solenoid gasket and plunger return spring.



T81539 -UN-22MAR90


Remove Parts

RG, RG34710, 2204 -19-15MAR97-8/11

9. Remove the shift lever cap screw and center bearing screws (A).

10. Remove armature.

A—Bearing Screws



T88855 -UN-21FEB90

Remove Armature

Continued on next page

RG, RG34710, 2204 -19-15MAR97-9/11

11. Use a 1/2-in. pipe nipple or other suitable metal cylinder to drive pinion stop toward pinion.



Drive Pinion Stop

RG, RG34710, 2204 -19-15MAR97-10/11

T81541 -JUN-22MAR90

60
10
13

12. Remove retaining ring (A), pinion stop, and overrunning clutch drive.
13. Remove brake washer and center bearing plate (B).

A—Retaining Ring
B—Bearing Plate



Center Bearing Plate

RG, RG34710, 2204 -19-15MAR97-11/11

T88866 -JUN-21FEB90

Clean Starter Motor Components

IMPORTANT: Never clean armature, field windings, or overrunning clutch drive in solvent. All parts except overrunning clutch drive may be cleaned with mineral spirits and a brush.


1. Clean components using mineral spirits and a brush.
2. Dry with compressed air or a clean cloth.

DPSG, OJUE003, 28 -19-17DEC98-1/1

Inspect Armature

1. Place armature in V-blocks and check for a bent shaft. Replace armature if shaft is bent.
2. Inspect armature for signs of dragging against pole shoes or scoring under bushings.
3. Carefully check commutator for roughness, burned commutator bars or any material that might cause short circuits between bars.
4. Clean and touch up commutator, if necessary, with 00 sandpaper. NEVER use emery cloth.

NOTE: *If commutator is out of round, badly burned or rough, it can be turned down slightly on a lathe. Remove only enough metal to eliminate problem. Do not undercut commutator after turning, as this will cause shorts between commutator bars.*



Inspect Armature

X1451 -UN-25JAN89


RG, RG34710, 2205 -19-15MAR97-1/1

Make Short Circuit Test

Place armature in a growler and hold hacksaw blade above each slot while slowly rotating the armature.

If coil is shorted, the blade will be attracted to and repelled from the slot.

Short circuit most often occurs because of copper dust or filings between two commutator segments. Clean commutator segments to correct this short.



Make Short Circuit Test


T81543 -UN-07DEC88

RG, RG34710, 2206 -19-15MAR97-1/1

Make Armature Ground Test

1. Set ohmmeter to read on highest scale.
2. Place one test lead on the armature core or shaft. Place other lead on commutator.

If the test meter indicator swings toward zero, the armature is grounded. Replace armature.



Make Armature Ground Test

T90253 -UN-20NOV89

60
10
15

RG, RG34710, 2207 -19-15MAR97-1/1

Make Open Circuit Test

1. Set ohmmeter to read on lowest scale.
2. Place one test lead on commutator segment. Place other test lead on an adjacent segment.
3. Repeat this operation for all segments by moving one lead at a time.

If the test meter indicator does not swing to zero and remain stationary, the armature coil between these two segment is open. Replace armature.



Make Open Circuit Test

T90254 -UN-19OCT88

RG, RG34710, 2208 -19-06MAY02-1/1

Make Ground Circuit Test for Field Windings

1. Set ohmmeter to read on highest scale.
2. Connect one test lead to the field frame and the other test lead to the field connector.

If the test meter indicator swings toward zero, the field coils are grounded. Replace the field windings.



Make Ground Circuit Test

T81546 -UN-22MAR90

RG, RG34710, 2209 -19-15MAR97-1/1

Make Open Circuit Test for Field Windings

1. Set ohmmeter on its lowest scale.
2. Connect one test lead to a field coil lead. Connect the other test lead to the field connector.

If the test meter indicator does not swing to zero and remains stationary, the field coils have an open circuit. Replace field coils.



T81547 -UN-22MAR90

Make Open Circuit Test

RG.RG34710,2210 -19-15MAR97-1/1

Remove Field Coils (If Necessary)

1. The field connector must be removed before the field coils can be removed from frame.



T81548 -UN-22MAR90

Remove Field Connector

RG.RG34710,2211 -19-15MAR97-1/2

2. Place field frame in a soft-jawed vise.

IMPORTANT: Do not squeeze sides of field frame in vise or strike with a hammer. If an impact screwdriver is used to remove pole shoe screws, support each pole shoe individually using a pole shoe spreader or nose of anvil.

3. Make a scribe mark on pole shoe and field frame for proper assembly.
4. Use a large screwdriver bit and socket wrench to remove pole shoe screws.
5. Remove pole shoes. Then carefully remove field windings as an assembly.

IMPORTANT: Handle windings very carefully. Windings are easily damaged, causing shorts, opens, or grounds.



T81549 -UN-22MAR90

Remove Field Windings

RG.RG34710,2211 -19-15MAR97-2/2

Install Field Windings

1. Carefully insert field windings.
2. Align scribe marks on pole shoes and field frame. Assemble shoe so the long lip points in direction of armature rotation.
3. Tighten pole shoe screws to specifications. Use a center punch to lightly stake one edge of each screw.

Specification


Field Pole Shoe Screws—Torque..... 41 N•m (30 lb-ft)

RG, RG34710, 2212 -19-15MAR97-1/1

Disassemble Solenoid

1. Remove hex nuts from “M” and “S” terminals (A) and (B).
2. Remove the two screws (C) and cover.

A—“M” Terminal
B—“S” Terminal
C—Cover Screws



Disassemble Solenoid

T5966AB -UN-02APR90

RG, RG34710, 2213 -19-15MAR97-1/1

Inspect and Clean Solenoid Parts

Inspect all solenoid parts for wear, dirt, and corrosion.

Wipe all parts and connections with mineral spirits and a clean cloth or brush. Dry with a clean cloth.

Firm pressure should be felt on the plunger when fully depressed. If plunger is weak, replace solenoid winding and plunger assembly.



T5966AA -UN-11APR90

Inspect and Clean Solenoid Parts


RG.RG34710,2214 -19-15MAR97-1/3

The "R" terminal contact finger (B) height above the surface of the main contact (A) must be 1.59—2.38 mm (1/16—3/32 in.). Bend contact finger if adjustment is necessary.

Specification

Solenoid "R" Terminal Contact—
Height 1.59—2.38 mm (0.062—0.093 in.)

- A—Main Contact
- B—"R" Terminal Contact Finger



T88858 -UN-21FEB90

"R" Terminal Contact Finger

RG.RG34710,2214 -19-15MAR97-2/3

Replacement "S" terminal and "M" terminal stud clips must be crimped to winding leads.



T81553 -UN-22MAR90

Replacement Stud Clips

RG.RG34710,2214 -19-15MAR97-3/3

Assemble Solenoid

1. Place gasket on winding terminal.
2. Align main contact vertically.
3. Place packing on switch cover.
4. Tighten switch cover screws to solenoid winding and plunger assembly securely.

NOTE: Solenoid contacts and plunger will be damaged if current is applied to solenoid when removed from starter motor.


RG, RG34710, 2215 -19-15MAR97-1/1

Remove Drive End Bushing and Wick

1. Measure drive end bushing.

Specification

New Drive End Housing	
Bushing—ID.....	11.709—11.811 mm (0.4610—0.4650 in.)
Wear Limit	12.065 mm (0.475 in.)
Oil Clearance.....	0.051—0.127 mm (0.0020—0.0050 in.)
Wear Limit	0.432 mm (0.0170 in.)



Measure Drive End Bushing

T81524 -UN-22MAR90

RG, RG34710, 2216 -19-15MAR97-1/3

2. Remove plug and drive end wick.



Remove Plug and Drive End Wick


T81556 -UN-22MAR90

Continued on next page

RG, RG34710, 2216 -19-15MAR97-2/3

- Use 27493 Disk (1) and 27491 Disk (2) from D01045AA Bushing, Bearing and Seal Driver Set to remove the drive end bushing.

- 1—27493 Disk
- 2—27491 Disk




T81557 -UN-22MAR90

27493 Disk and 27491 Disk

RG, RG34710, 2216 -19-15MAR97-3/3

Install Drive End Bushing and Wick

- Install drive end bushing by pressing it from the outside in. Press it even with the end of the drive housing.



T81558 -UN-22MAR90

Drive End Bushing and Wick

RG, RG34710, 2217 -19-15MAR97-1/2

- Drill bushing through oil wick hole using same size drill as oil wick hole.
- After drilling, ream bushing to maintain proper oil clearance between shaft and bushing.
- Soak new wicks in SAE 10 engine oil. Install drive end wick and pipe plug.



T81559 -UN-22MAR90

Drive End Wick and Pipe Plug

RG, RG34710, 2217 -19-15MAR97-2/2


Inspect Drive Motor ID

Measure the motor drive ID.

Specification

Motor Drive—ID.....	14.275—14.300 mm (0.5620—0.5630 in.)
Wear Limit	14.579 mm (0.5740 in.)

The motor drive cannot be repaired and must be replaced if defective.



T81525 -UN-22MAR90

Inspect Drive Motor ID

RG, RG34710, 2218 -19-15MAR97-1/1


Inspect Center Bushing ID

Measure the center bushing ID and oil clearance.

Specification

New Center Bearing Plate	
Bushing—ID.....	19.304—19.354 mm (0.7600—0.7620 in.)
Wear Limit	19.608 mm (0.7720 in.)
Oil Clearance.....	0.254—0.381 mm (0.0100—0.0150 in.)
Wear Limit	0.635 mm (0.0250 in.)

Burnish bushing to size if necessary.



Inspect Center Bushing ID

T81526 -UN-22MAR90

60
10
21

RG, RG34710, 2219 -19-15MAR97-1/1


Inspect Commutator End Frame Bushing

Measure commutator end frame bushing ID and oil clearance.

Specification

New Commutator End Frame	
Bushing—ID.....	14.313—14.338 mm (0.5635—0.5645 in.)
Wear Limit	14.554 mm (0.5730 in.)
Oil Clearance.....	0.051—0.127 mm (0.0020—0.0050 in.)
Wear Limit	0.406 mm (0.0160 in.)

Burnish bushing to size if necessary.



Inspect Commutator End Frame Bushing

T81527 -UN-22MAR90

RG, RG34710, 2220 -19-18OCT00-1/1

Assemble Starter Motor

1. Lubricate splines and drive end of armature shaft with SAE 10 engine oil.
2. Install center bearing plate and brake washer.




Lubricate Splines and Armature Shaft

T81560 -UN-22MAR90

RG.RG34710,2221 -19-15MAR97-1/7

3. With motor drive in place on armature shaft, install pinion stop (A) with cupped side toward drive end of armature shaft.
4. Use the drive end thrust collar (B) and a 1/2-in. pipe nipple, or other suitable metal cylinder, to drive the retaining ring (C) into its groove on the armature shaft.

A—Pinion Stop
B—Drive End Thrust Collar
C—Retaining Ring




Armature Shaft

T88860 -UN-21FEB90

RG.RG34710,2221 -19-15MAR97-2/7

5. Use pliers and the drive end thrust collar (A) to force the pinion stop into place over the retaining ring.
6. Hold thrust collar (A) in place while installing armature.

A—Drive End Thrust Collar



Hold Thrust Collar


T88861 -UN-21FEB90

Continued on next page

RG.RG34710,2221 -19-15MAR97-3/7

7. With shift lever fork in motor drive collar, install armature, shift lever and solenoid switch plunger in drive housing.
8. Install the shift lever cap screw and the center bearing plate screws (A).

A—Center Bearing Plate Screws



Center Bearing Plate Screws

T88855 -UN-21FEB90

60
10
23

RG, RG34710, 2221 -19-15MAR97-4/7

9. Install solenoid gasket and plunger return spring.



Solenoid Gasket/Plunger Return Spring

T81563 -UN-22MAR90

RG, RG34710, 2221 -19-15MAR97-5/7

10. Install solenoid switch assembly and screws.
11. Install commutator end spacer washer (A).

A—Commutator End Spacer Washer



Commutator End Spacer Washer

T88862 -UN-21FEB90

Continued on next page

RG, RG34710, 2221 -19-15MAR97-6/7

12. Install frame, with field coil assembly and brushes, onto rotor.

Specification

Housing Attaching Cap Screws—
Torque 18—23 N•m (159—204 lb-in.)

13. Attach field connector to the solenoid switch “M” terminal.

14. Install commutator end frame and cap screws and tighten to specifications.

Specification

Commutator End Frame Cap
Screws—Torque 18—23 N•m (159—204 lb-in.)



Install Commutator End Frame

T81535 -UN-22MAR90


RG,RG34710,2221 -19-15MAR97-7/7

Check Pinion Clearance

Pinion clearance cannot be adjusted, but must be checked after reassembly of the starter motor. Improper clearance is an indication of worn parts.

1. Disconnect motor field coil connector from the solenoid motor terminal and insulate it carefully.
2. Make connections as shown using a 12-volt battery.

- A—Battery
- B—Solenoid
- C—Starter Motor
- D—Jumper Wire



Check Pinion Clearance

T88952 -UN-25MAY89


Continued on next page

RG,RG34710,2222 -19-15MAR97-1/2

3. Momentarily touch a jumper lead from the solenoid motor terminal to solenoid frame. The pinion will shift into cranking position and remain until the battery is disconnected.
4. Push pinion toward armature.
5. Measure the distance between pinion and pinion stop.

Specification

Pinion-to-Pinion Stop—Clearance..... 0.25—3.56 mm (0.010—0.140 in.)



Push Pinion Toward Armature

RG, RG34710, 2222 -19-15MAR97-2/2


T81528 -UN-22MAR90

60
10
25

Make Solenoid No-Load Test

1. Clamp starter motor drive housing in vise.
2. Make connections as shown.
3. Close switch to operate starter motor and adjust carbon pile resistor to obtain 9.0 volts.

Current draw must be to specifications given at beginning of this group.



Make Solenoid No-Load Test

T81521 -UN-25MAY89

- 1—Carbon Pile Resistor
- 2—Battery
- 3—Ammeter
- 4—Voltmeter
- 5—Jumper Lead with Switch
- 6—Tachometer

RG, RG34710, 2223 -19-15MAR97-1/1

60
10
26

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B93 -19-08MAY02-1/3

60
15
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B93 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B93 -19-08MAY02-3/3

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1004,0000B94 -19-25SEP00-1/2

Bushing, Bearing, and Seal Driver Set. D01045AA

Remove and install all commutator, drive end, and center bushings and/or bearings.

OUC1004,0000B94 -19-25SEP00-2/2

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.
	ESSO Beacon 325 or Delco-Remy No. 1960954 Lubricant	Lubricate various stator components.

OUC1004,0000B95 -19-25SEP00-1/1

Delco-Remy 30MT, 35MT, and 37MT Starter Motor Repair Specifications

Item	Measurement	Specification
Drive Housing Bushing	ID	14.28—14.33 mm (0.562—0.564 in.)
	Wear Tolerance	14.58 mm (0.574 in.)
	Oil Clearance	0.05—0.13 mm (0.002—0.005 in.)
	Wear Tolerance	0.43 mm (0.017 in.)
Lever Housing Bushing	ID	19.23—19.25 mm (0.757—0.758 in.)
	Wear Tolerance	19.61 mm (0.772 in.)
	Oil Clearance	0.25—0.33 mm (0.010—0.013 in.)
	Wear Tolerance	0.69 mm (0.027 in.)
Commutator End Frame Bushing	ID	14.28—14.33 mm (0.562—0.564 in.)
	Wear Tolerance	14.55 mm (0.573 in.)
	Oil Clearance	0.05—0.13 mm (0.002—0.005 in.)
	Wear Tolerance	0.41 mm (0.016 in.)
Brush	Minimum Length	12 mm (0.50 in.)
Brush	Minimum Tension	22 N (80 ounce-force)
Shift Lever Housing-to-Field Housing Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Drive Housing-to-Shift Lever Housing Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Commutator End-to-Field Frame Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Armature	End Play	0.13—1.27 mm (0.005—0.050 in.)
	Wear Limit	1.52 mm (0.060 in.)
Pinion-to-Pinion Stop	Clearance	0.25—3.56 mm (0.010—0.140 in.)

60
15
3

OUO1004,0000B96 -19-25SEP00-1/1

Delco-Remy 30MT, 35MT, and 37MT Starter Motor Test Specifications

NOTE: Specification data for starters marked with an asterisk () was not available from Delco. Data provided for these asterisked starters in the following table was obtained from the John Deere Alternator, Generator, Starter and Battery Bench Tester Operator's Manual (OMTY25323, 14Dec01). This data is for remanufactured starters, provided by suppliers other than Delco, which can be used as replacements for the Delco starters. Specifications for the remanufactured starters may not correspond exactly with the original Delco starter specifications, and should be used for reference only. Delco does not either approve nor disapprove the use of these specifications.*

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
* AB2937R	1107445	6	5 Min	70 Max	6000
* AB4093R	1107445	6	5 Min	70 Max	6000
AB4094R	1107193	6	5	30—60	2900—5300
* AB4649R	1108144	12	10	90 Max	3500—6000
* AB4860R	1108155	12	10	90 Max	3500—6000
* AF1392R	1108990-30MT	12	10	60 Max	3500—5500
* AF1578R	110981	12	10	60 Max	3500—5500
AF2673R	1113304	12	—	—	—
AF3758R	1113079	12	—	—	—
* AM1802T	1107127	6	5 Min	140 Max	4500—6400
AM3397T	1107165	6	5.6	70	5500
AR11010	1107725	12	9	50—75	4500—6400
* AR11011	1113092-30MT	12	10	80 Max	7000 Min
AR11138	1107555	24	20	52—90	7000—13000
AR11141	1113135	24	20	50—70	7000—9500
* AR11151	1107193	6	5	65 Max	2900—5300
AR11152	1108180	12	9	50—75	3500—6000
* AR11159	1113005	12	10	60 Max	3500—5500
AR11300	1107785	12	9	55—80	3500—6000
AR28053	1113148	24	20	50—70	7000—9500
AR34406	1113656-35MT	12	9	75—105	5000—7000

Continued on next page

RG, RG34710, 2227 -19-07JUL05-1/2

Delco-Remy 30MT, 35MT, 37MT Starter Motor Repair

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
* AR40134	1113190-30MT	24	20	80 Max	7000 Min
AR41627	1113402-35MT	12	9	124—185	4700—7600
AR55638	1113672-35MT	12	9	124—185	4700—7600
AR62267	1113402-35MT	12	9	124—185	4700—7600
AR72308	1113093-35MT	12	9	50—70	3500—5500
AR77254	1113391-35MT	12	9	124—185	4700—7600
AR78538	1113391-35MT	12	9	124—185	4700—7600
AR91813	1109576-SD300	12	10	65—110	6500—10700
AT10224	1108072	6	5.7	53—91	3650—6350
AT15334	1107523	12	9	50—80	5500—9000
AT16209	1107556	12	9	40—140	8000—13000
AT16880	1108099	6	5	90—125	2900—5300
AT16881	1107200	6	5.7	90—125	4500—6400
AT91813	1109421-SD300	12	10	60—90	6500—10500
RE27462	1993799-37MT	12	10	140—175	6600—8200
RE29400	1993829-37MT	24	20	115—175	3000—4800
RE36646	1993930-37MT	24	20	50—75	3300—4400
RE37961	1993894-37MT	12	10	120—160	6000—8700
RE38632	1993917-37MT	24	20	50—75	3300—4400
RE41755	1993894-37MT	12	10	120—160	6000—8700
RE43300	1993917-37MT	24	20	50—75	3300—4400
RE48077	10478819-37MT	24	20	50—75	3300—4400
RE48134	1993917-37MT	24	20	50—75	3300—4400
RE52955	10478957-37MT	12	10	120—160	6000—8700
RE53217	10478957-37MT	12	11	130—175	6100—8700
RE53404	10478814-37MT	24	20	50—75	3300—4400
RE53575	10478814-37MT	24	20	—	3300—4400
RE59586	10478819-37MT, 10479180	24	20	50—75	3300—4400
RE59593	10478957-37MT	12	11	130—175	6100—8700
RE59594	10478814-37MT, 10479181	24	20	50—75	3300—4400
RE65189	10478814-37MT	24	20	50—75	3300—4400

60
15
5

Diagnosing Starter Motor Malfunctions

Fails to Operate, No Current Draw

Open field circuit (all field windings)

Open armature windings

Defective brush contact with commutator

Open solenoid windings

Defective solenoid contacts

Fails to Operate, High Current Draw

Grounded field windings or armature windings

Seized bearings

Low Speed, Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed, High Current Draw

Excessive friction

Shorted armature

Grounded armature or field windings

High Speed, High Current Draw

Shorted field windings


NOTE: This test will not detect individual open-circuited field coils—the stator would have a slow cranking speed but would pass this test.

RG, RG34710, 2228 -19-15MAR97-1/1

Delco-Remy Starter Motor Cutaway View— Series 30MT, 35MT, and 37MT

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

NOTE: Series 37MT starter motors use TORX® screws for all external fasteners. Two different size TORX® drivers are required to service the 37MT motor—T40 and E8. These drives can be procured from a local tool source.



Series 37MT Shown

- A—Grommet
- B—Field Connectors
- C—Gaskets
- D—Plunger
- E—Solenoid
- F—O-Ring
- G—Oil Wick
- H—Boot
- I—Shift Lever
- J—Bushing
- K—Overrunning Clutch
- L—Seal
- M—Field Coil
- N—Armature
- O—Brushes
- P—End Cap

TORX is a registered trademark of Camcar/Textron.

RG, RG34710, 2229 -19-15MAR97-1/1

60
15
7

RG4993 -UN-19JAN90

Test Starter Motor Before Disassembly

1. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.



Turn Overrunning Clutch Pinion

R26549N -UN-16SEP99

RG, RG34710, 2230 -19-15MAR97-1/4

2. Turn armature by prying against pinion with screwdriver. Check for dragging armature, seized bushings or bent shaft.

If you discover any interference, disassemble and repair starter motor. Do not conduct no-load test unless armature turns freely.



Turn Armature

R26550 -UN-09FEB90

Continued on next page


RG, RG34710, 2230 -19-15MAR97-2/4

3. Connect a 12-volt battery to solenoid (A) with heavy-duty jumper cables. Connect battery terminal (B) on solenoid to positive battery terminal and motor terminal (C) to negative battery terminal.

IMPORTANT: Do not engage solenoid longer than one to two seconds, because closing solenoid switch provides a dead short across battery.

4. Use a screwdriver blade to short across from battery terminal to switch terminal (D). Solenoid should engage, pushing overrunning clutch drive to engage position.

When screwdriver is removed, solenoid should return sharply to the disengage position. If solenoid engages but then chatters instead of staying firmly engaged, hold-in winding is defective and solenoid must be replaced. Be sure solenoid is connected securely to start frame. If shift lever or overrunning clutch drive appears to bind, disassemble and repair starter.




Terminals

- A—Solenoid
- B—Battery Terminal
- C—Motor Terminal
- D—Switch Terminal

RG, RG34710, 2230 -19-15MAR97-3/4

5. If solenoid does not engage, remove solenoid and manually move shift lever back and forth. If lever moves smoothly, pull-in winding is defective and solenoid must be replaced. If there is pressure felt when moving the shift lever, but solenoid does not engage when tested, disassemble and repair starter.



Check for Defects

RG, RG34710, 2230 -19-15MAR97-4/4


RG4686 -UN-06APR89

60
15
9

R78220P1 -UN-23JAN90

Make No-Load Test for Solenoid

1. If armature turns freely, make connections as shown. Use an ammeter capable of measuring several hundred amps. Make sure the battery is fully charged.
2. Close switch to operate starter motor and adjust carbon pile resistor to obtain specified voltage. Compare rpm and current draw with values given in specifications at the beginning of this group.
3. If speed and current draw are slightly low, connect a voltmeter between motor terminal and field frame. Voltage during test may be reduced because of high current draw on battery.
4. If speed or current draw is significantly different than specified, use the diagnostic list earlier in this group.




Make No-Load Test for Solenoid

- A—Battery
- B—Ammeter
- C—Shunt
- D—Switch
- E—Voltmeter
- F—Starter Motor
- G—Tachometer
- H—Carbon Pile Resistor

RG4660 -UN-06APR89

RG, RG34710, 2231 -19-15MAR97-1/1

Disassemble Delco-Remy Starter Motor (Series 35MT Illustrated)



Series 35MT

RG4661 -JUN-06/JAN94

Continued on next page

RG, RG34710, 2232 -19-12SEP02-1/8

Delco-Remy 30MT, 35MT, 37MT Starter Motor Repair


1—Solenoid Case and Coil	17—Shift Lever	34—Washer	50—Field Winding Connector
2—Switch Terminal Stud (2 Used)	18—O-Ring	35—Armature	51—Brush Support (2 Used)
3—Motor Terminal Stud	19—Plug	36—Spacer	52—Brush Holder Support Pin (2 Used)
4—Contact Disk and Push Rod	20—Brake Washer	37—Oil Seal	53—Brush Holder Pin (2 Used)
5—Return	21—Gasket	38—O-Ring	54—Brush Spring (2 Used)
6—Battery Terminal Stud	22—O-Ring	39—Center Bushing	55—Brush Spring Lead (2 Used)
7—Cover Gasket	23—Shift Lever Shaft	40—Pipe Plug	56—Brush Holder (2 Used)
8—Cover	24—O-Ring	41—Wick	57—Brush Holder (2 Used)
9—Sealing Washer	25—Shift Lever Housing	42—Retaining Ring	58—Brush (4 Used)
10—Rear Bushing	26—Special Nut	43—Field Winding Assembly	59—Tapping Screw (4 Used)
11—Drive Housing	27—Retaining Ring	44—Pole Shoe (4 Used)	60—Front Bushing
12—Wick	28—Spring Retainer	45—Insulator (2 Used)	61—Commutator End Frame
13—Pipe Plug	29—Shift Lever Spring	46—Field Terminal Stud	62—Pipe Plug
14—Retaining Ring	30—Spring Retainer	47—Insulator Bushing	63—Wick
15—Pinion Stop	31—Boot	48—Main Frame	
16—Overrunning Clutch Drive	32—Washer	49—Machine Screw (8 Used)	
	33—Plunger		

60
15
13

RG, RG34710, 2232 -19-12SEP02-2/8

1. Clean exterior of starter motor with compressed air before disassembling.
2. Remove field winding connector (A).
3. Remove solenoid mounting cap screws (B).
4. Remove nuts and sealing washers (9) from solenoid motor and "S" terminals. (See exploded view.)
5. Remove switch cover (8) and cover gasket (7).

A—Field Winding Connector
B—Solenoid Mounting Cap Screws



Field Winding Connector and Cap Screws


RG4662 -UN-06APR89

Continued on next page

RG, RG34710, 2232 -19-12SEP02-3/8

6. Push boot (1) back, and slide solenoid away (shown removed) from boot and plunger (2).

1—Boot
2—Plunger




Solenoid Removed

RG, RG34710, 2232 -19-12SEP02-4/8

7. IF NECESSARY, remove cover plug and disconnect solenoid plunger from shift lever. Grasp plunger and remove self-locking nut.

NOTE: Pinion clearance is controlled by self-locking nut. Do not change adjustment unless complete disassembly is required. Check pinion clearance, covered later in this group.

8. Scribe a mark across main frame (48) and end frame (61) as reassembly reference. (See exploded view.)
9. Remove four cap screws attaching commutator end frame to main frame.
10. Remove commutator end frame.




Remove Commutator End Frame

Continued on next page

RG, RG34710, 2232 -19-12SEP02-5/8

- Slide brush holder pin (F) out of support (E) to remove brushes (A). Remove tapping screws (D) which attach brushes to grounded brush holders (B) and insulated brush holders (C).
- Scribe a mark across drive housing and shift lever housing for proper assembly.
- Remove drive end housing cap screws and remove drive housing.

A—Brushes
B—Grounded Brush Holders
C—Insulated Brush Holders
D—Tapping Screws
E—Support
F—Pin



Remove Drive Housing


RG4663 -UN-19JAN90

60
15
15

RG, RG34710, 2232 -19-12SEP02-6/8

- Remove pinion stop (B). Use a pipe coupling (A) or other metal cylinder to drive pinion stop toward pinion as shown. Remove retaining ring and slide pinion stop off shaft.
- Slide shift lever housing and overrunning clutch drive off shaft.

A—Pipe Coupling
B—Pinion Stop



Pinion Stop and Pipe Coupling


R26556 -UN-09FEB90

Continued on next page

RG, RG34710, 2232 -19-12SEP02-7/8

16. Carefully slide armature (1) out of field frame. If spacer washer remains in housing, pull it out and install on shaft.

1—Armature



Slide Armature

RG.RG34710,2232 -19-12SEP02-8/8

RG2992 -UN-17JUL89

60
15
16

Install New Bushings During Disassembly

NOTE: Refer to exploded view earlier in this group.

1. Remove plugs (13 and 62) and lubricating wicks (12 and 63).
2. Replace bushings (10, 39, and 60) if worn longer than wear tolerances given.

Specification

Drive Housing Bushing—ID..... 14.28—14.33 mm (0.562—0.564 in.)
 Wear Tolerance..... 14.58 mm (0.574 in.)
 Oil Clearance..... 0.05—0.13 mm (0.002—0.005 in.)
 Wear Tolerance..... 0.43 mm (0.017 in.)

Specification

Lever Housing Bushing—ID..... 19.23—19.25 mm (0.757—0.758 in.)
 Wear Tolerance..... 19.61 mm (0.772 in.)
 Oil Clearance..... 0.25—0.33 mm (0.010—0.013 in.)
 Wear Tolerance..... 0.69 mm (0.027 in.)

Specification

Commutator End Frame Bushing—ID..... 14.28—14.33 mm (0.562—0.564 in.)
 Wear Tolerance..... 14.55 mm (0.573 in.)
 Oil Clearance..... 0.05—0.13 mm (0.002—0.005 in.)
 Wear Tolerance..... 0.41 mm (0.016 in.)

3. Remove the commutator end frame housing (61) using a blind hole puller. Remove other bushings using drivers from tool set listed below.

Use the following disks from D01045AA Bushing, Bearing and Seal Driver Set when replacing bushing.

Bushing	Pilot Disk	Drive Disk
Drive Housing Bushing	27491	27495
Commutator Bushing	27491	27494
Lever Housing Bushing	27494	27497


4. Drive new bushings into end frame to same depth as old bushing.

5. Use a drill the same size as the oil wick hole and drill bushing (1).

Only if necessary, carefully ream bushing to size.

6. Saturate new wicks (3) with SAE 10W clean engine oil and install.

7. Install plug (2) and tighten securely.



- 1—Drill Bushing
- 2—Plug
- 3—Oil Wick

RG, RG34710, 2233 -19-15MAR97-2/2

Clean Starter Motor Components

IMPORTANT: Never clean armature, field windings, or overrunning clutch drive in solvent. All parts except overrunning clutch drive may be cleaned with mineral spirits and a brush.


1. Clean components using mineral spirits and a brush.
2. Dry with compressed air or a clean cloth.

RG, RG34710, 2234 -19-15MAR97-1/1

Inspect Armature

1. Place armature in V-blocks and check for a bent shaft. Replace armature if shaft is bent.
2. Inspect armature for signs of dragging against pole shoes or scoring under bushings.
3. Carefully check commutator for roughness, burned commutator bars or any material that might cause short circuits between bars.
4. Clean and touch up commutator, if necessary, with 00 sandpaper. NEVER use emery cloth.

NOTE: If commutator is out of round, badly burned or rough, it can be turned down slightly on a lathe. Remove only enough metal to eliminate problem. Do not undercut commutator after turning, as this will cause shorts between commutator bars.



Inspect Armature

X1451 -UN-25JAN89

60
15
19


RG, RG34710, 2235 -19-15MAR97-1/1

Make Short Circuit Test

Place armature in a growler and hold hacksaw blade above each slot while slowly rotating the armature.

If coil is shorted, the blade will be attracted to and repelled from the slot.

Short circuit most often occurs because of copper dust or filings between segments. Clean commutator segments to correct this short.



Make Short Circuit Test


RG78074C1 -UN-08JAN90

RG, RG34710, 2236 -19-15MAR97-1/1

Make Armature Ground Test

1. Set ohmmeter to read on highest scale.
2. Place one test lead on the armature core or shaft. Place other lead on commutator.

If the test meter indicator swings toward zero, the armature is grounded. Replace armature.



Make Armature Ground Test

T90253 -UN-20NOV89

RG, RG34710, 2237 -19-15MAR97-1/1

Make Open Circuit Test

1. Set ohmmeter to read on lowest scale.
2. Place one test lead on ohmmeter segment. Place other test lead on an adjacent segment.
3. Repeat this operation for all segments by moving one lead at a time.

If the test meter indicator does not swing to zero and remains stationary, the armature coil between these two segments is open. Replace armature.



Make Open Circuit Test

T31426 -UN-27JUL89

RG, RG34710, 2238 -19-15MAR97-1/1

Make Ground Circuit Test for Field Windings

1. Set the D09001TT Volt-Ohm-Amp Meter to read on highest scale.
2. Place one test lead on a clean spot on field frame. Place other lead on the copper terminal bolt.

If the ohmmeter indicator swings toward zero, a grounded circuit is indicated. Replace the field windings.



Make Ground Circuit Test

RG7807601 -UN-09JAN90

60
15
21

RG,RG34710,2239 -19-06MAY02-1/1

Make Open Circuit Test for Shunt Windings

1. Set ohmmeter on its lowest scale.
2. Place one test lead on the eyelet terminal. Place other lead on the terminal bolt.

If the ohmmeter does not swing to zero, it is open circuited. Replace the field winding assembly.

RG,RG34710,2240 -19-15MAR97-1/1


Make Open Circuit Test for Field Windings

All four windings are connected in parallel. Test each winding for an open circuit.

1. Connect a test battery (B) to field terminal (C) and either insulated brush lead (D) using a resistor (A) to limit current draw.
2. Use a hacksaw blade (E) to test windings for magnetism. If any winding is not magnetic, the winding is open circuited. Repair or replace windings.

NOTE: Because 1/4 ohm resistors capable of carrying several hundred watts are not widely available, a suggested alternative is to connect four 1-ohm resistors in parallel. Each resistor should be rated for at least 150 watts. A carbon pile resistor can also be used. Limit current to 40—70 amps.

There is no suitable way to check field windings for short circuits. Winding resistance is too low to permit detection of a short circuit.



Make Open Circuit Test

- A—1/4-Ohm Resistor
- B—12-Volt Battery
- C—Field Terminal
- D—Insulated Brush Lead
- E—Hacksaw Blade

R26554N -UN-11APR89

RG,RG34710,2241 -19-09OCT00-1/1

Remove Field Windings

1. If field windings are suspected of being damaged, place field frame in a soft-jawed vise.

NOTE: Do not squeeze sides of field frame in vise or strike with a hammer. If an impact screwdriver is used to remove pole shoe screws, support each pole shoe individually using a pole shoe spreader or the nose of an anvil.

2. Use a large screwdriver or bit and socket wrench on pole shoe screws.



Remove Field Windings

R782211 -UN-23JAN90

Continued on next page


RG,RG34710,2242 -19-15MAR97-1/2

3. Remove pole shoes (2). Then carefully remove field windings as an assembly.

IMPORTANT: Handle windings very carefully. Windings are easily damaged, causing shorts, opens, or grounds.

4. Install new field windings and tighten pole shoe screws as tight as possible. Use a center punch to lightly stake one edge of each screw.

IMPORTANT: Make sure the notched end (3) on pole shoe is facing the brush end of the field frame starter (1).



New Field Windings

- 1—Starter Field Frame
- 2—Pole Shoe
- 3—Notched End

RG2995 -JUN-17JUL89

60
15
23

RG, RG34710, 2242 -19-15MAR97-2/2

Inspect Brushes

1. Inspect brushes (58) closely. (See exploded view this group.) Make sure brush holders (56 and 57) are clean and are not binding. Full width of brush should contact commutator.
2. Replace brushes if they are oil soaked or are worn beyond specifications.

Specification

Brush—Minimum Length..... 12 mm (0.50 in.)

RG, RG34710, 2243 -19-09OCT00-1/1

Test Brush Holder for Ground

1. Set ohmmeter on its highest scale.
2. Place one test lead on commutator end frame. Place other lead on brush holder.

If dial indicator swings toward zero, the positive brush holder is grounded and should be replaced.

RG, RG34710, 2244 -19-15MAR97-1/1

Inspect Brush Springs

1. Inspect and replace brush springs if they are distorted or discolored.
2. Measure brush spring tension with a spring scale.

Specification

Brush—Minimum Tension 22 N (80 ounce-force)

RG, RG34710, 2245 -19-15MAR97-1/1

Inspect and Clean Solenoid

1. Replace contact disk (4, see exploded view in this group), if it is badly corroded.
2. Be sure all connections are clean and tight. Wipe parts with mineral spirits and brush. Dry clean with a cloth.

IMPORTANT: Solenoid contacts and plunger will be damaged if current is applied to solenoid when removed from starter motor.

RG, RG34710, 2246 -19-15MAR97-1/1

Assemble Solenoid

NOTE: Replacement "S" terminal clips and motor terminal studs are soldered to wiring leads.

1. Assemble solenoid parts using a new gasket (7, see exploded view in this group) and sealing washers (9).
2. Tighten cover (8) screws securely.

RG, RG34710, 2247 -19-15MAR97-1/1

Inspect Plunger, Shift Lever, and Overrunning Clutch Assembly

1. Remove plug (19, see exploded view in this group) and inspect shift lever spring (33) and shift lever assembly for wear or damage.
2. Press plunger inward and check tension on plunger spring (29). Spring should not compress easily. Replace plunger assembly if spring is weak.
3. Inspect overrunning clutch drive (16) for wear or damage. Rotate the pinion. Pinion gear should rotate smoothly (but not easily) in one direction. The pinion gear should not rotate in the opposite direction.
4. If pinion gear does not rotate smoothly or if it is worn, chipped, or burred, replace clutch drive assembly.

IMPORTANT: Do not clean overrunning clutch drive with solvent. Solvent would dissolve lubricant in clutch mechanism. Clean only by wiping with a clean cloth. Do not lubricate drive.


RG, RG34710, 2248 -19-09OCT00-1/1

Assemble Starter Motor

1. Carefully install armature (1) into field frame. Be sure spacer is installed on end of armature shaft before installing into main frame.

IMPORTANT: To avoid possible damage to brush holders, it is best to install brush assembly dismantled.

1—Armature



Install Armature

RG2992 -JUN-17JUL89

Continued on next page

RG, RG34710, 2249 -19-12SEP02-1/4

NOTE: Always use new O-rings, packing, and gaskets when assembling starter motor.

2. Lubricate bearing surface with Delco-Remy No. 1960954 Lubricant or its equivalent.
3. Install seal plug (3), gasket (1) and brake washer (5) into shift lever housing.
4. Place overrunning clutch drive in shift lever housing, making certain that shift lever is engaged in slot.
5. Slide shift lever housing and overrunning clutch drive into armature shaft.



Shift Lever Housing

T33145NY -UN-27JUL89

- 1—Gasket
- 2—Shift Lever
- 3—Seal Plug
- 4—Shift Lever Shaft
- 5—Brake Washer

Continued on next page

RG.RG34710,2249 -19-12SEP02-2/4

60
15
26

- Slide pinion stop (A) onto shaft, with open side toward end of shaft. Install retaining ring (B) in groove. Force pinion stop over ring, using a washer (C) and two pairs of pliers as shown. Remove washer.

NOTE: Series 37MT starter motors have TORX® screws for all external fasteners. Tighten screws to same torque values as given for conventional screws.

- Install shift lever housing on field using five cap screws and lock washers. Tighten screws to specifications.

Specification


Shift Lever Housing-to-Field
Housing Cap Screws—Torque..... 18—23 N•m (159—204 lb-in.)

- Align scribe marks on drive housing and shift lever housing (made during disassembly). Install the six special screws in drive housing. Tighten screws to specifications.

Specification

Drive Housing-to-Shift Lever
Housing Cap Screws—Torque..... 18—23 N•m (159—204 lb-in.)

- If pinion clearance has not been changed, install hole plug (19, see exploded view in this group) in shift lever housing. Otherwise, it should be left out until clearance is adjusted at conclusion of assembly.



Pinion Stop

A—Pinion Stop
B—Retaining Ring
C—Washer


TORX is a registered trademark of Camcar/Textron.

Continued on next page

RG, RG34710, 2249 -19-12SEP02-3/4

10. Install brush holders (B and C), brushes (A) and springs (D). When installing brushes, turn longer side toward armature windings. Make sure full width of each brush contacts commutator and brush holders are not binding.

11. Install commutator end frame on field frame (position so scribe marks made during disassembly are aligned). Tighten cap screws securely and evenly to specifications.



RG-4664 -JUN-19/JAN90

Brushes, Holders, and Springs

- A—Brushes
- B—Grounded Brush Holders
- C—Installed Brush Holders
- D—Brush Springs

Specification

Commutator End-to-Field Frame
 Cap Screws—Torque 18—23 N•m (159—204 lb-in.)

12. Install solenoid on field frame. Be sure that plunger (33, see exploded view) and boot (31) are installed correctly. Tighten solenoid-to-field frame cap screws securely.

NOTE: Do not install field winding connector (50) until pinion clearance has been checked.

13. Check armature end play and pinion clearance before installing starter motor.

RG, RG34710, 2249 -19-12SEP02-4/4

Check Armature End Play

1. Attach a dial indicator on drive housing and position indicator plunger on end of armature shaft to measure end play.

Specification

Armature—End Play 0.13—1.27 mm (0.005—0.050 in.)
 Wear Limit 1.52 mm (0.060 in.)

2. If end play is not within specifications, recheck installation to determine cause.

RG, RG34710, 2250 -19-15MAR97-1/1

60
 15
 28


Check for Proper Pinion Clearance

1. Connect a 12-volt battery to the solenoid frame and "S" terminal.
2. Momentarily connect a jumper wire between solenoid frame and motor terminal to pull solenoid plunger in.
3. Press overrunning clutch (D) toward commutator and measure pinion clearance (E) with a feeler gauge (C).
4. Clearance between pinion (A) and pinion stop (B) should be as follows:

Specification

Pinion-to-Pinion Stop—Clearance..... 0.25—3.56 mm (0.010—0.140 in.)

5. If pinion clearance is not within specifications, turn self-locking nut (26, see exploded view in this group) to adjust clearance.
6. After adjusting to correct pinion clearance, install adjusting hole plug (19) and tighten securely.
7. Install field winding connector (50). Tighten nuts securely.



Check for Proper Pinion Clearance

A—Pinion
B—Pinion Stop
C—Feeler Gauge
D—Press on Clutch to Take Up Movement
E—0.25—3.56 mm (0.010—0.140 in.) Clearance


R25224 -UN-09FEB90

60
15
29

RG, RG34710, 2251 -19-12SEP02-1/1

Make No-Load Test (After Assembly)

1. Clamp starter in vise.
2. Connect a fully charged 12-volt battery (A), ammeter (B), shunt (C), control switch (D), voltmeter (E) carbon pile resistor (H), and tachometer (G) to starter motor (F).
3. Close switch to operate starter motor and adjust carbon pile resistor to obtain specified voltage.
4. Starter motor should rotate smoothly at the specified speed, voltage, and current draw given at the beginning of this group.



Make No-Load Test

- A—Battery
- B—Ammeter
- C—Shunt
- D—Switch
- E—Voltmeter
- F—Starter Motor
- G—Tachometer
- H—Carbon Pile Resistor

RG4660 -UN-06APR89

RG, RG34710, 2252 -19-15MAR97-1/1

Delco-Remy 40MT, 41MT, 42MT, 50MT Starter Motor Repair

Group 20

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B97 -19-08MAY02-1/5

60
20
1

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

OUO1004,0000B97 -19-08MAY02-2/5

Alternator, Generator, Starter and Battery Bench Tester JT01760


Test alternators and starters for voltage, resistance, or current flow.

Continued on next page

OUO1004,0000B97 -19-08MAY02-3/5

Bushing, Bearing and Seal Driver Set D01045AA

Install commutator end frame bushing.



D01045AA

RG11162 -UN-21SEP00

OUC1004,0000B97 -19-08MAY02-4/5

Blind Hole Puller Set D01061AA

Remove commutator end frame bushing.



D01061AA

RG11161 -UN-21SEP00

OUC1004,0000B97 -19-08MAY02-5/5

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.
	ESSO Beacon 325 or Delco-Remy No. 1960954 Lubricant	Lubricate various stator components.

OUC1004,0000B97 -19-25SEP00-1/1

Delco-Remy 40MT, 41MT, 42MT, and 50MT Starter Motor Repair Specifications

Item	Measurement	Specification
Field Pole Shoe Cap Screws	Torque	41 N•m (30 lb-ft)
New Brush	Length	19 mm (0.75 in.)
Used Brush	Minimum Length	16 mm (0.63 in.)
Brush Spring	Minimum Tension	22 N (80 ounce-force)
Starter Motor Drive Housing Bushing (40MT, 41MT, 42MT)	ID	15.88—15.93 mm (0.625—0.627 in.)
	Maximum Serviceable ID	16.18 mm (0.637 in.)
Starter Motor Lever Housing Bushing (40MT, 41MT, 42MT)	ID	24.46—24.51 mm (0.963—0.965 in.)
	Maximum Serviceable ID	24.69 mm (0.972 in.)
Starter Motor Commutator End Frame Bushing (40MT, 41MT, 42MT)	ID	16.87—16.97 mm (0.664—0.668 in.)
	Maximum Serviceable ID	17.22 mm (0.678 in.)
Starter Motor Drive Housing Bushing (50MT)	ID	15.88—15.90 mm (0.6250—0.6260 in.)
	Wear Tolerance	16.15 mm (0.636 in.)
	Oil Clearance	0.05—0.10 mm (0.0020—0.0040 in.)
	Wear Tolerance	0.38 mm (0.0150 in.)
Starter Motor Lever Housing Bushing (50MT)	ID	21.41—21.44 mm (0.8430—0.8440 in.)
	Wear Tolerance	21.59 mm (0.850 in.)
	Oil Clearance	0.48—0.53 mm (0.0190—0.0210 in.)
	Wear Tolerance	0.69 mm (0.0270 in.)
Starter Motor Commutator End Frame Bushing (50MT)	ID	14.27—14.30 mm (0.5620—0.5630 in.)
	Wear Tolerance	14.55 mm (0.5730 in.)
	Oil Clearance	0.05—0.10mm (0.0020—0.0040 in.)
	Wear Tolerance	0.38 mm (0.0150 in.)
Shift Lever Housing Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Drive End Housing Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Commutator End Frame Cap Screws	Torque	18—23 N•m (159—204 lb-in.)
Pinion-to-Drive Housing	Clearance	8.33—9.92 mm (0.328—0.391 in.)

60
20
3

**Delco-Remy 40MT, 41MT, 42MT, and 50MT
Starter Motor Test Specifications**

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
AM3397T	1107165	6	5.6	70	5500
AR102188	1114831-40MT	12	10	140—215	4000—7000
AR102190	1109841-50MT	24	20	80—125	5500—8500
AR102770	1114869-40MT	24	20	95—120	5500—7500
AR102771	1114843-40MT	24	20	70—110	5500—9000
AR46886	1114191-40MT	12	9	140—215	4000—7000
AR55313	1114735-40MT	24	20	70—110	5500—9000
AR55314	1113827-40MT	24	20	75—95	5500—7500
AR62153	1114166-40MT	12	11	160—230	4900—8300
AR72308	1113093	12	9	50—70	3500—5500
AR78235	1109978-50MT	24	20	95—120	5500—7500
AT16311	1107326	12	9	55—80	3500—6000
AT16882	1108093	6	5.7	90—125	4500—6400
AT409T	1107166	12	10	115—170	6600—9000
RE10321	1114819-40MT	12	10	140—215	4000—7000
RE10464	1990269-50MT	24	20	95—120	5500—7500
RE12101	1990270-50MT	24	20	95—120	5500—7500
RE13942	1990325-40MT	12	10	140—215	4000—7000
RE24305	1990354-42MT	12	10	115—170	6600—9000
RE28781	1990356-42MT	12	10	100—170	5500—7800
RE28782	1990357-42MT	24	20	60—75	6500—7700
RE28783	1990358-42MT	12	10	100—170	5500—7800
RE38632	1993917-37MT, 10479178-37MT	24	20		
RE38633	1993935-42MT	12	10	115—170	6600—9000
RE38634	1993936-42MT	24	20	50—90	6300—8400
RE41756	1190325-42MT	12	10	140—215	4000—8300
RE51792	1993934-42MT	12	10	115—170	6600—9000
RE59593	10478957-41MT	12	11		
RE61547	10479052-42MT	12	11	100—170	5500—7800
RE62911	1049071-41MT	12	11	130—175	6100—8700
RE63094	10479053-42MT	24	23	60—75	6300—8400
RE64474	10479071-41MT	12	11	130—175	6100—8700
RE65103	10479628	12	10.6	135—190	3600—5600

Continued on next page

RG, RG34710, 2256 -19-07JUL05-1/2

John Deere Starter Motor Part No.	Delco-Remy Starter Motor Model No. -Series	System Voltage	Motor Voltage	No Load Test (Includes Solenoid Current)	
				Current Draw (Amps)	Armature RPM
RE67432	10479098-41MT	12	11	130—175	6100—8700
RE69590	1193935-42MT	12	10	115—170	6600—9000

RG, RG34710, 2256 -19-07JUL05-2/2

60
20
5

Diagnosing Starter Motor Malfunctions

Fails to Operate, No Current Draw

Open field circuit (all field windings)

Open armature windings

Defective brush contact with commutator

Open solenoid windings

Defective solenoid contacts

Fails to Operate, High Current Draw

Grounded field windings or armature windings

Seized bearings

Low Speed, Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed, High Current Draw

Excessive friction

Shorted armature

Grounded armature or field windings

High Speed, High Current Draw

Shorted field windings


NOTE: This test will not detect individual open-circuited field coils—the stator would have a slow cranking speed but would pass this test.

RG, RG34710, 2258 -19-15MAR97-1/1

Delco-Remy Starter Motor Cutaway View— Series 40MT, 41MT, 42MT, and 50MT

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

NOTE: Series 42MT starter motors use TORX® screws for all external fasteners. Two different size TORX® drivers are required to service the motor—T40 and E8. These drivers can be procured from a local tool source.



Series 42MT Shown

- A—Field Connectors
- B—Gasket
- C—Bushing
- D—Solenoid
- E—O-Ring
- F—Boot
- G—Shift Lever
- H—Bushing
- I—Overrunning Clutch
- J—Seal
- K—Field Coil
- L—Armature
- M—Brushes
- N—End Cap
- O—Oil Wick

RG4994 -UN-19JAN90

TORX is a registered trademark of Camcar/Textron.

RG, RG34710, 2259 -19-12SEP02-1/1

Test Starter Motor Before Disassembly

1. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.



R78220Q1 -UN-23JAN90

Turn Overrunning Clutch Pinion

Continued on next page RG, RG34710, 2260 -19-15MAR97-1/5

2. Turn armature by prying against pinion with screwdriver. Check for dragging armature, seized bushings or bent shaft.

If you discover any interference, disassemble and repair starter motor.

NOTE: Do not conduct the no-load test unless armature turns freely.



Turn Armature


R7820R1 -UN-23JAN90

60
20
7

RG, RG34710, 2260 -19-15MAR97-2/5

3. Be sure solenoid ground wire (A) is connected securely to starter end frame.

A—Solenoid Ground Wire



Solenoid Ground Wire

RG, RG34710, 2260 -19-15MAR97-3/5

RG3422 -UN-26SEP89

4. Connect a 12-volt battery to solenoid with heavy-duty jumper cables. Connect battery terminal on solenoid to positive (+) battery terminal. Connect motor terminal to negative (-) battery terminal.



Connect 12-Volt Battery

RG3423 -UN-31JUL89

Continued on next page

RG, RG34710, 2260 -19-15MAR97-4/5

IMPORTANT: DO NOT engage solenoid longer than one or two seconds, because closing solenoid switch provides a dead short across battery.

5. Use a screwdriver to short across from battery terminal to switch terminal. Solenoid should engage, pushing overrunning clutch drive to engaged position.

When screwdriver is removed, solenoid should return sharply to the disengaged position. If solenoid engages, but then chatters instead of staying firmly engaged, hold-in winding is defective and solenoid must be replaced. Be sure solenoid and ground wire are connected securely to starter frame. If shift lever or overrunning clutch drive appears to bind, disassemble and repair starter.




Use Screwdriver

RG3424 -UN-31JUL89

RG, RG34710, 2260 -19-15MAR97-5/5

Test Pull-In and Hold-In Windings



A—Ground Terminal
B—Motor Terminal

C—Battery Terminal
D—Switch Terminal

E—Ammeter
F—Switch

G—24-Volt Battery

1. (See exploded view in this group.) Remove field coil connector (42) and return wire (31).

2. Make connections shown by dashed lines for testing pull-in windings.

IMPORTANT: DO NOT energize pull-in windings longer than 15 seconds. Current draw will decrease as winding temperature increases, which could damage windings.

3. Close switch (F) and observe ammeter (E). Ammeter should read 24—28 amps for 24-volt motors and 55—63 amps for 12-volt motors.

4. Make connections shown by solid lines for testing hold-in windings.

5. Close switch and observe ammeter. Ammeter should read 4.1 amps maximum for 24-volt motors and 6—9 amps for 12-volt motors.

6. Interpret test results as follows:

High Ammeter Reading

Windings are grounded or short circuited.

Low Ammeter Reading

Excessive resistance is present (usually in a connection).

No Ammeter Reading

Windings are open circuited.

NOTE: If the fault cannot be repaired and the solenoid performance is questionable, replace the windings.

Make No-Load Test

1. Install field connector and connect solenoid return lead.
2. Make connections as shown. Use an ammeter capable of measuring at least 300 amps.
3. Close switch to operate starter. Compare rpm and current draw with specifications given at beginning of this group.

Battery voltage will drop due to high current draw. If speed and current draw are slightly low, repeat test, observing voltmeter. Voltage may be reduced due to high current draw.

Interpret test results as follows:

Fails to Operate, No Current Draw

Open field circuit (all field windings)

Open armature windings

Defective brush contact with commutator

Fails to Operate, High Current Draw

Grounded terminal or field windings

Seized bearings

Low Speed, Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed, High Current Draw


Excessive friction

Shorted armature

Grounded armature or field windings

High Speed, High Current Draw

Shorted field windings




Make No-Load Test

- A—Batteries
- B—Tachometer
- C—Switch
- D—Ammeter
- E—Voltmeter
- F—To Voltmeter
- G—To Ammeter
- H—To Switch

RG3419 -UN-06APR89

60
20
11

Disassemble Delco-Remy Starter Motor (Series 50MT Illustrated)



Delco-Remy Starter Motor (50MT)

RG4278 -JUN-03SEP91

Continued on next page

RG.RG34710,2263 -19-12SEP02-1/9


1—Terminal Plate Gasket	27—Wiring Lead	48—Insulator Bushing	72—Small O-Ring
2—Terminal Stud (2 Used)	28—Bushing	49—O-Ring (2 Used)	73—Shift Lever Housing
3—Machine Screw (2 Used)	29—Disk	50—Commutator End Frame Bushing	74—Lever Housing Bushing
4—Solenoid Winding Terminal	30—Spring	51—Commutator End Frame	75—Oil Seal
5—Strip Insulator	31—Solenoid Return Wire	52—Lubrication Wick (3 Used)	76—Spacer Washer
6—Insulator	32—Field Frame	53—Plug (3 Used)	77—Armature
7—Screw (4 Used)	33—Brush Plug Gasket (2 Used)	54—Lock Washer (9 Used)	78—Thrust Washer
8—Terminal	34—Plug (3 Used)	55—Special Hex Screw (9 Used)	79—Drive End Housing Bushing
9—Plate	35—Field Lead Insulator (2 Used)	56—Insulator	80—Special Screw 38 mm (1-1/2 in.) Long (5 Used)
9A—Solenoid Cover	36—Field Coil and Brush Lead Insulator	57—Brushes (4 Used)	81—Special Screw 22 mm (7/8 in.) Long (2 Used)
10—Nut (4 Used)	37—Field Terminal Stud	58—Machine Screw (4 Used)	82—Drive End Housing
11—Washer (2 Used)	38—Insulator	59—Spring (4 Used)	83—Split Washer (2 Used)
12—Lock Washer Insulator (2 Used)	39—Special Packing	60—Plain Washer (3 Used)	84—Pinion Stop Cup
13—Washer (2 Used)	40—Insulating Washers 25 mm (1 in.) OD (2 Used)	61—Lock Washers (3 Used)	85—Pinion
14—Lock Washer (2 Used)	41—Solenoid Mounting (4 Used)	62—Machine Screw (3 Used)	86—Small Washer
15—Nut (2 Used)	42—Field Coil Connector	63—Field Pole Shoe (4 Used)	87—Spring
16—Nut (2 Used)	43—Jam Nut (3 Used)	64—Field Coil Assembly	88—Spring Cup
17—Lock Nut	44—Washer (2 Used)	65—Gasket	89—Large Washer
18—Snap Ring	45—Brush Holder Assembly	66—Brake Washer	90—Spacer
19—Retainer	46—Insulating Washers 2 mm (7/8 in.) OD (2 Used)	67—Adjusting Hole Plug Gasket	91—Overrunning Clutch Bushing
20—Spring	47—Packing	68—Seal Plug	92—Overrunning Clutch
21—Retainer		69—Pole Shoe Screw (8 Used)	93—Shift Lever
22—Boot		70—Shift Lever Shaft	
23—Washer		71—O-Ring	
24—Plunger			
25—Screw (4 Used)			
26—Solenoid Winding and Case Assembly			

60
20
13

RG, RG34710, 2263 -19-12SEP02-2/9

1. Disconnect solenoid ground wire (A).
2. Remove field winding connector (B).
3. Remove solenoid mounting cap screws (C).

A—Solenoid Ground Wire
B—Field Winding Connector
C—Solenoid Mounting Cap Screws



Disassemble Starter Motor


RG3427 -UN-31JUL89

Continued on next page

RG, RG34710, 2263 -19-12SEP02-3/9

4. Push boot (A) back, and slide solenoid away (shown removed) from boot and plunger (B).

A—Boot
B—Plunger



Push Boot Back

RG3428 -UN-31JUL89

RG, RG34710, 2263 -19-12SEP02-4/9

5. IF NECESSARY, remove cover plug and disconnect solenoid plunger from shift lever. Grasp plunger and remove self-locking nut as shown.

NOTE: Pinion clearance is controlled by self-locking nut. Do not change adjustment unless complete disassembly is required. Check pinion clearance as covered later in this group.



Remove Self-Locking Nut

R76220T1 -UN-23JAN90

Continued on next page


RG, RG34710, 2263 -19-12SEP02-5/9

6. Remove field brush cover plugs (shown removed) and O-rings (A). Remove screws (B) from field winding leads.

NOTE: Scribe reference marks (C) across end frame and field frame for reassembly.

7. Remove end frame cap screws (D).

- A—O-Ring (2 Used)
- B—Cap Screw (2 Used)
- C—Reference Marks
- D—Cap Screw (4 Used)



Brush Cover Plugs Shown Removed

RG3429 -UN-31JUL89


60
20
15

RG, RG34710, 2263 -19-12SEP02-6/9

8. Carefully slide brush holder assembly away from armature. Remove brush strap machine screws (A). Inspect brush leads (B) for fraying or discoloration.

NOTE: If only brushes are going to be installed, it is not necessary to remove brush holder assembly.

- A—Brush Strap Machine Screws
- B—Brush Leads



Slide Brush Holder Assembly


RG3420 -UN-31JUL89

Continued on next page

RG, RG34710, 2263 -19-12SEP02-7/9

9. Scribe a reference mark (A) across drive housing (B) and shift lever housing (C) for proper assembly.
10. Remove drive end housing cap screws and remove drive housing.
11. Remove shift lever housing with overrunning clutch (D).

A—Reference Mark
B—Drive End Housing
C—Shift Lever Housing
D—Overrunning Clutch




Remove Shift Lever Housing

RG3431 -UN-31JUL89

RG, RG34710, 2263 -19-12SEP02-8/9

12. Carefully slide armature (A) out. If spacer washer remains in housing, pull it out and install on shaft.

A—Armature



Armature

RG3432 -UN-31JUL89

RG, RG34710, 2263 -19-12SEP02-9/9

Make Ground Circuit Test for Field Windings

1. Set the D09001TT Volt-Ohm-Amp Meter to read on highest scale.
2. Place one test lead on a clean spot on field frame. Place other lead on the copper terminal bolt.

If the ohmmeter indicator swings toward zero, a grounded circuit is indicated. Replace the field windings.



Volt-Ohm-Amp Meter

RG7807601 -UN-09JAN90

60
20
17

RG, RG34710, 2264 -19-15MAR97-1/1

Make Open Circuit Test for Shunt Windings

1. Set ohmmeter on its lowest scale.
2. Place one test lead on the eyelet terminal. Place other lead on the terminal bolt.
3. If the ohmmeter does not swing to zero, it is open circuited. Replace the field winding assembly.

RG, RG34710, 2265 -19-15MAR97-1/1


Make Open Circuit Test for Field Windings

All four field windings are connected in parallel. Test each winding for an open circuit.

1. Connect a test battery (B) to field terminal (C) and to either insulated brush lead (D) using a resistor (A) to limit current draw.
2. Use a hacksaw blade (E) to test windings for magnetism. If any winding is not magnetic, the winding is open circuited. Repair or replace windings.

NOTE: Because 1/4 ohm resistors capable of carrying several hundred watts are not widely available, a suggested alternative is to connect four 1-ohm resistors in parallel. Each resistor should be rated for at least 150 watts. A carbon pile resistor can also be used. Limit current to 40—70 amps.

There is no suitable way to check field windings for short circuits. Winding resistance is too low to permit detection of a short circuit.



Make Open Circuit Test

- A—1/4-Ohm Resistor
- B—12-Volt Battery
- C—Field Terminal
- D—Insulated Brush Lead
- E—Hacksaw Blade

R26554N -UN-11APR89

RG, RG34710, 2266 -19-09OCT00-1/1

Remove Field Windings

1. If field windings are suspected of being damaged, place field frame in a soft-jawed vise.

NOTE: Do not squeeze sides of field frame in vise or strike with a hammer. If an impact screwdriver is used to remove pole shoe screws, support each pole shoe individually using a pole shoe spreader or the nose of an anvil.

2. Use a large screwdriver or bit and socket wrench on pole shoe screws.



Field Frame in Vise

R782111 -UN-23JAN90

Continued on next page

RG, RG34710, 2267 -19-15MAR97-1/2

- Remove pole shoes. Then carefully remove field windings as an assembly.

IMPORTANT: Handle windings very carefully. Windings are easily damaged, causing shorts, opens, or grounds.


- Install new field windings and tighten pole shoe screws to specifications. Use a center punch to lightly stake one edge of each screw.

Specification

Field Pole Shoe Cap Screws—

Torque 41 N•m (30 lb-ft)

IMPORTANT: Make sure the notched end (B) on pole shoe is facing the brush end of the field frame (A).



Notched End Facing Brush End

A—Field Frame
B—Notched End on Pole Shoes

R78221H1 -UN-23JAN90

60
20
19

RG, RG34710, 2267 -19-15MAR97-2/2

Inspect Brushes

- Remove brushes (B) by lifting brush up and away from brush spring (A).
- Replace brushes if they are oil soaked, worn, pitted, or damaged. If brushes are worn beyond specification, replace them.


Specification

New Brush—Length 19 mm (0.75 in.)

Used Brush—Minimum Length 16 mm (0.63 in.)

- Make sure brush holders (C) are clean and brushes are not binding in holders. The full brush surface should ride on the commutator.

A—Brush Spring
B—Brushes
C—Brush Holders



Inspect Brushes

RG3421 -UN-31JUL89

RG, RG34710, 2268 -19-15MAR97-1/1

Test Brush Holder for Ground

1. Set ohmmeter on its highest scale.
2. Place one test lead on commutator end frame. Place other lead on brush holder.

If dial indicator swings toward zero, the positive brush holder is grounded and should be replaced.

RG, RG34710, 2269 -19-15MAR97-1/1

Inspect Brush Springs

1. Inspect and replace brush springs if they are distorted or discolored.
2. Measure brush spring tension with a spring scale.

Specification

Brush Spring—Minimum Tension..... 22 N (80 ounce-force)

RG, RG34710, 2270 -19-15MAR97-1/1

60
20
20

Install New Bushings—40MT, 41MT, and 42MT

NOTE: See exploded view earlier in this group.

1. Remove all plugs (53) and lubricating wick (52).
2. Replace bushings if worn beyond specification.

Specification

Starter Motor Drive Housing	
Bushing (40MT, 41MT, 42MT)—	
ID	15.88—15.93 mm (0.625—0.627 in.)
Maximum Serviceable ID	16.18 mm (0.637 in.)
Starter Motor Lever Housing	
Bushing (40MT, 41MT, 42MT)—	
ID	24.46—24.51 mm (0.963—0.965 in.)
Maximum Serviceable ID	24.69 mm (0.972 in.)
Starter Motor Commutator End	
Frame Bushing (40MT, 41MT, 42MT)—ID	
	16.87—16.97 mm (0.664—0.668 in.)
Maximum Serviceable ID	17.22 mm (0.678 in.)

NOTE: The overrunning clutch drive bushing (91) is not replaceable. Entire drive must be replaced if bushing is worn.

NOTE: When replacing lever housing bushing, seal plug (68, refer to exploded view) must be removed. Install new seal plug after replacing bushing.

3. Remove commutator end frame bushing using the D01061AA Blind Hole Puller Set.
4. Drive old bushing out and drive new bushing in to same depth as old bushing. Use the following disks from D01045AA Bushing, Bearing and Seal Driver Set.


Bushing Location	Pilot Disk	Disk Driver
Drive Housing	27492	27494
Lever Housing	27496	27498
Commutator	27491	27495

5. Use a drill the same size as the oil wick hole and drill bushing (A).

Only if necessary, carefully ream bushing to size.

6. Saturate new wicks (C) with SAE 10W clean engine oil and install.

7. Install plug (B) and tighten securely.



Install Plug

A—Drill Bushing
B—Plug
C—Oil Wick

R25221 -UN-17APR89

RG, RG34710, 2271 -19-09OCT00-2/2

Install New Bushings—50MT

NOTE: See exploded view earlier in this group.

1. Remove plugs (53) and lubricating wicks (52).
2. Replace bushings if worn more than wear tolerance given.

Specification

Starter Motor Drive Housing	
Bushing (50MT)—ID.....	15.88—15.90 mm (0.6250—0.6260 in.)
Wear Tolerance.....	16.15 mm (0.636 in.)
Oil Clearance.....	0.05—0.10 mm (0.0020—0.0040 in.)
Wear Tolerance.....	0.38 mm (0.0150 in.)
Starter Motor Lever Housing	
Bushing (50MT)—ID.....	21.41—21.44 mm (0.8430—0.8440 in.)
Wear Tolerance.....	21.59 mm (0.850 in.)
Oil Clearance.....	0.48—0.53 mm (0.0190—0.0210 in.)
Wear Tolerance.....	0.69 mm (0.0270 in.)
Starter Motor Commutator End	
Frame Bushing (50MT)—ID.....	14.27—14.30 mm (0.5620—0.5630 in.)
Wear Tolerance.....	14.55 mm (0.5730 in.)
Oil Clearance.....	0.05—0.10mm (0.0020—0.0040 in.)
Wear Tolerance.....	0.38 mm (0.0150 in.)

NOTE: The overrunning clutch drive bushing (91) is not replaceable. Entire drive must be replaced if bushing is worn.

NOTE: When replacing lever housing bushing, seal plug (68, refer to exploded view) must be removed. Install new seal plug after replacing bushing.

3. Remove commutator end frame bushing using the D01061AA Blind Hole Puller Set.
4. Drive old bushing out and drive new bushing in to same depth as old bushing. Use the following disks from D01045AA Bushing, Bearing and Seal Driver Set.

Bushing Location	Pilot Disk	Disk Driver
Drive Housing	27492	27494
Lever Housing	27496	27498
Commutator	27491	27495


RG, RG34710, 2272 -19-09OCT00-2/3

- Use a drill the same size as the oil wick hole and drill bushing (A).

Only if necessary, carefully ream bushing to size.

- Saturate new wicks (C) with SAE 10W clean engine oil and install.
- Install plug (B) and tighten securely.

A—Drill Bushing
 B—Plug
 C—Oil Wick



R25221 -UN-17APR89

RG, RG34710, 2272 -19-09OCT00-3/3

Clean Starter Motor Components

IMPORTANT: Never clean armature, field windings, or overrunning clutch drive in solvent. All parts except overrunning clutch drive may be cleaned with mineral spirits and a brush.


- Clean components using mineral spirits and a brush.
- Dry with compressed air or a clean cloth.

RG, RG34710, 2273 -19-15MAR97-1/1

Inspect Armature

1. Place armature in V-blocks and check for a bent shaft. Replace armature if shaft is bent.
2. Inspect armature for signs of dragging against pole shoes or scoring under bushings.
3. Carefully check commutator for roughness, burned commutator bars or any material that might cause short circuits between bars.
4. Clean and touch up commutator, if necessary, with 00 sandpaper. NEVER use emery cloth.

NOTE: *If commutator is out of round, badly burned or rough, it can be turned down slightly on a lathe. Remove only enough metal to eliminate problem. Do not undercut commutator after turning, as this will cause shorts between commutator bars.*



X1451 -UN-25JAN89

60
20
25


RG, RG34710, 2274 -19-15MAR97-1/1

Make Short Circuit Test

Place armature in a growler and hold hacksaw blade above each slot while slowly rotating the armature.

If coil is shorted, the blade will be attracted to and repelled from the slot.

A short circuit most often occurs because of copper dust or filings between segments. Clean commutator segments to correct this short.



Make Short Circuit Test


RG78074C1 -UN-08JAN90

RG, RG34710, 2275 -19-15MAR97-1/1

Make Armature Ground Test

1. Set ohmmeter to read on highest scale.
2. Place one test lead on the armature core or shaft. Place other lead on commutator.

If the test meter indicator swings toward zero, the armature is grounded. Replace armature.



Make Armature Ground Test

T90253 -UN-20NOV89

RG, RG34710, 2276 -19-15MAR97-1/1

Make Open Circuit Test

1. Set ohmmeter to read on lowest scale.
2. Place one test lead on ohmmeter segment. Place other test lead on an adjacent segment.
3. Repeat this operation for all segments by moving one lead at a time.

If the test meter indicator does not swing to zero and remains stationary, the armature coil between these two segments is open. Replace armature.



Make Open Circuit Test


T31426 -UN-27JUL89

RG, RG34710, 2277 -19-15MAR97-1/1

Inspect Solenoid Plunger and Shift Lever Assembly

1. Remove plug (A) and inspect plunger and shift lever assembly for wear or damage.
2. Press plunger (B) inward and check tension on plunger spring. Spring should not compress easily. Replace plunger assembly if spring is weak.
3. Inspect shift lever wear pads (C) for wear or damage. If damaged, replace both wear pads.
4. Inspect overrunning clutch (D) for wear or damage. Replace as necessary.

A—Plug
B—Plunger
C—Wear Pads
D—Overrunning Clutch



Solenoid Plunger/Shift Lever Assembly

RG, RG34710, 2278 -19-15MAR97-1/1

60
20
27

RG3435 -JUN-31-JUL89

Inspect Overrunning Clutch and Pinion

Rotate the pinion. Pinion gear should rotate smoothly (but not easily) in one direction. The pinion gear should not rotate in the opposite direction.

If pinion gear does not rotate smoothly or if it is worn, chipped, or burred, it should be replaced.

RG, RG34710, 2279 -19-15MAR97-1/1


Inspect and Clean Solenoid

1. Remove terminal plate (A) and inspect all parts. Replace contact disk (B) and terminal studs (C), if they are badly corroded.

Be sure all connections are clean and tight.

2. Replace gasket (D), if corroded or damaged.
3. Wipe parts with mineral spirits and brush. Dry with a clean cloth.

IMPORTANT: Solenoid contacts and plunger will be damaged if current is applied to solenoid when removed from starter motor.



Inspect and Clean Solenoid

A—Terminal Plate
B—Contact Disk
C—Terminal Studs
D—Gasket


RG3436 -UN-31JUL89

RG, RG34710, 2280 -19-15MAR97-1/1

Assemble Solenoid

1. Place new gasket (D) on solenoid housing.
2. Align terminal studs (C) and contact disk (B).
3. Tighten terminal plate (A) cap screws securely.

A—Terminal Plate
B—Contact Disk
C—Terminal Studs
D—Gasket



Assemble Solenoid

RG3436 -UN-31JUL89


RG, RG34710, 2281 -19-15MAR97-1/1

Assemble Starter Motor

NOTE: Always use new O-rings, packing, and gaskets when assembling starter motor.

1. Lubricate bearing surfaces with Delco-Remy No. 1960954 Lubricant or its equivalent.
2. Install seal plug (C), gasket (A), and brake washer (E) into shift lever housing.

A—Gasket
B—Shift Lever
C—Seal plug
D—Shift Lever Shaft
E—Brake Washer



Shift Lever Housing

RG3437 -UN-31JUL89


60
20
29

RG, RG34710, 2282 -19-12SEP02-1/8

3. Install wear pads (C) and overrunning clutch (D).
4. Make sure plunger (B) moves shift lever back and forth easily.

NOTE: Do not install adjusting hole plug (A) until pinion clearance has been checked.

A—Adjusting Hole Plug
B—Plunger
C—Wear Pads
D—Overrunning Clutch



Shift Lever


RG3435 -UN-31JUL89

Continued on next page

RG, RG34710, 2282 -19-12SEP02-2/8

- Carefully install armature (A) into field frame. Be sure spacer is installed on end of armature shaft before installing into main frame.

A—Armature



Install Armature

RG3432 -UN-31JUL89

RG, RG34710, 2282 -19-12SEP02-3/8

NOTE: Series 42MT starter motors have TORX® screws for all external fasteners. Tighten screws to same torque values as given for conventional screws.

- Install shift lever housing (C), making sure armature shaft goes through overrunning clutch (D). Tighten cap screws to specifications.


Specification

Shift Lever Housing Cap
Screws—Torque 18—23 N•m (159—204 lb-in.)

- Align reference marks (A) (made prior to disassembly) and install drive end housing (B). Make sure armature shaft fits through drive housing bushing. Tighten special screws to specifications.

Specification

Drive End Housing Cap Screws—
Torque 18—23 N•m (159—204 lb-in.)



Install Shift Lever Housing

A—Reference Mark
B—Drive End Housing
C—Shift Lever Housing
D—Overrunning Clutch

RG3431 -UN-31JUL89


TORX is a registered trademark of Camcar/Textron.

Continued on next page

RG, RG34710, 2282 -19-12SEP02-4/8

- Pull brushes (B) up against brush holder (C) and spring (A). Pull brushes up far enough to allow installation of the commutator.

A—Spring
B—Brushes
C—Brush Holder



Pull Brushes


RG3421 -UN-31JUL89

60
20
31

RG, RG34710, 2282 -19-12SEP02-5/8

- Install bush assembly onto commutator. Press brushes down until spring clips over brush.
- Press brush leads (B) down onto brush holder. Be sure that the leads DO NOT touch each other.
- Install brush strap machine screws (A), and tighten brush strap securely to brush holder.

A—Brush Strap Machine Screws
B—Brush Leads




Install Bush Assembly

RG3420 -UN-31JUL89

Continued on next page

RG, RG34710, 2282 -19-12SEP02-6/8

12. Carefully press brush assembly and end frame into main frame and align reference mark (C) (made prior to disassembly).
13. Install O-ring (A) and install field winding lead-to-brush holder machine screws (B). Tighten cap screws securely. Install field brush cover plugs (shown removed).
14. Install commutator end frame cap screws and tighten to specifications.



Bush Assembly and End Frame


- A—O-Ring (2 Used)
- B—Machine Screw (2 Used)
- C—Reference Marks
- D—Cap Screw (4 Used)

Specification

Commutator End Frame Cap
Screws—Torque..... 18—23 N•m (159—204 lb-in.)

RG, RG34710, 2282 -19-12SEP02-7/8

15. Install solenoid. Be sure plunger and boot are installed correctly. Tighten solenoid-to-field frame cap screws (C) securely.
16. Install solenoid ground wire (A) and field winding connector (B). Tighten all connections securely.



Install Solenoid

- A—Solenoid Ground Wire
- B—Field Winding Connector
- C—Solenoid-to-Field Frame Cap Screws

RG, RG34710, 2282 -19-12SEP02-8/8

Check for Proper Pinion Clearance

1. Disconnect solenoid ground wire and connect a 12-volt battery to solenoid “SW” and ground terminals.
2. Briefly touch a screwdriver blade across motor and ground terminals to pull solenoid plunger in.



Screwdriver Blade

Continued on next page

RG, RG34710, 2283 -19-15MAR97-1/2

3. Push pinion back toward armature (arrow).
4. Measure distance between pinion (C) and drive housing.


Correct pinion clearance (E) is as follows:

Specification

Pinion-to-Drive Housing—
 Clearance 8.33—9.92 mm (0.328—0.391 in.)

5. If pinion clearance is not within specifications, turn self-locking nut (B) to adjust clearance.
6. After adjusting to correct pinion clearance, install adjusting hole plug and tighten securely.

- A—Plug Removed
- B—Self-Locking Nut (Turn to Adjust Clearance)
- C—Pinion
- D—Press on Clutch to Take Up Movement
- E—8.33 to 9.92 mm (0.328—0.391 in.) Clearance



Pinion Clearance

R32571 -UN-09JAN90

60
20
33

RG, RG34710, 2283 -19-15MAR97-2/2

Section 65

John Deere/Denso Starter Motors

Contents

	Page	Page
Group 05—Starting Circuit Theory of Operation		
General Information	65-05-1	
Typical Starting Circuit Operation	65-05-1	
Starter Motor Operation (Conventional Type)	65-05-2	
Starter Motor Operation (Gear Reduction Type)	65-05-3	
Starter Motor Operation (Planetary Type)	65-05-5	
Group 10—John Deere/Denso Conventional Starter Motor Repair		
Essential Tools	65-10-1	
Service Equipment and Tools	65-10-2	
Dealer Fabricated Tools	65-10-3	
Other Material	65-10-4	
John Deere/Denso Conventional Starter Motor Repair Specifications	65-10-5	
John Deere/Denso Conventional Starter Motor Test Specifications	65-10-6	
Test Starter Motor Before Disassembly	65-10-8	
Make Solenoid Pull-In Test	65-10-8	
Make Solenoid Return Test	65-10-10	
Make No-Load Test	65-10-10	
Diagnose No-Load Test	65-10-11	
Disassemble Starter Motor	65-10-11	
John Deere/Denso Conventional Starter Motor Exploded View	65-10-15	
Install New Bushings/Needle Bearings	65-10-16	
Clean Starter Motor Components	65-10-16	
Inspect Armature	65-10-17	
Make Short Circuit Test	65-10-17	
Make Armature Ground Test	65-10-18	
Make Open Circuit Test	65-10-18	
Repair Armature	65-10-19	
Inspect Overrunning Clutch and Pinion	65-10-19	
Make Grounded Circuit Test for Field Windings	65-10-20	
Make Open Circuit Test for Shunt Windings	65-10-20	
Make Open Circuit Test for Field Windings	65-10-21	
Remove Field Windings (If Necessary)	65-10-21	
Install Field Windings	65-10-22	
Inspect and Repair Brushes	65-10-22	
Test Brush Holder for Grounds	65-10-23	
Measure Brush Spring Tension	65-10-23	
Disassemble Solenoid	65-10-24	
Assemble Starter Motor	65-10-25	
Install Solenoid	65-10-28	
Make No-Load Test	65-10-30	
Group 15—John Deere/Denso Gear Reduction Starter Motor Repair		
Essential Tools	65-15-1	
Service Equipment and Tools	65-15-2	
Other Material	65-15-2	
John Deere/Denso Gear Reduction Starter Motor Repair Specifications	65-15-3	
John Deere/Denso Gear Reduction Starter Motor Test Specifications	65-15-4	
Bench Test Starter Motor	65-15-5	
No-Load Test	65-15-6	
John Deere/Denso Gear Reduction Starter Motor Exploded View	65-15-7	
Disassemble Field Frame, Armature, and Brush Holder	65-15-7	
Inspect and Repair Armature	65-15-9	
Inspect Brushes and Brush Holder	65-15-13	
Inspect Field Coils	65-15-15	
Assemble Field Frame, Armature, and Brush Holder	65-15-16	
Disassemble Gear Train and Overrunning Clutch	65-15-19	
Assemble Gear Train and Overrunning Clutch	65-15-22	
Disassemble, Inspect, and Repair Starter Solenoid	65-15-25	
Assemble Solenoid Assembly	65-15-27	
Group 20—John Deere/Denso Planetary Starter Motor Repair		
Essential Tools	65-20-1	
Other Material	65-20-2	
John Deere/Denso Planetary Starter Motor Repair Specifications	65-20-2	
John Deere/Denso Planetary Starter Motor Test Specifications	65-20-3	
Test Starter Motor Before Disassembly	65-20-3	
Make Solenoid Pull-In Test	65-20-4	
Make Solenoid Hold-In Test	65-20-5	
Make Return Test	65-20-6	

Continued on next page

Contents

Page

Make No-Load Test65-20-6
Diagnose No-Load Test65-20-7
Disassemble Starter Motor65-20-7
John Deere/Denso Planetary Starter Motor
 Exploded View65-20-14
Clean Starter Motor Components65-20-15
Inspect and Repair Brushes65-20-16
Test Brush Holder for Grounds65-20-16
Measure Brush Spring Tension65-20-17
Assemble Starter Motor65-20-17
Install Solenoid65-20-21
Make No-Load Test65-20-23

65

General Information

IMPORTANT: Never operate starter motor longer than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

RG, RG34710, 2284 -19-15MAR97-1/1

Typical Starting Circuit Operation

When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) of starter motor to ground.


Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

Light shunt windings (J) are wrapped together with two of the heavy field windings. Shunt windings are connected to solenoid switch terminal and directly to ground. They provide additional low speed torque to assist engine rotation and prevent overspeeding of motor.

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).

Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Starting Circuit Operation


- A—Wire from Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

65
05
1

RG1313 -UN-20APR89

RG, RG34710, 2285 -19-15MAR97-1/1

Starter Motor Operation (Conventional Type)



Starter Motor (Conventional Type)

- | | | | |
|------------------------|-------------------|-------------------|-----------------------|
| 1—Snap Ring | 7—Field Connector | 13—Field Windings | 19—Brake Washer |
| 2—Drive End Housing | 8—End Frame Cover | 14—Armature | 20—Wear Pads |
| 3—Shift Lever | 9—Brush | 15—Pole Shoe | 21—Overrunning Clutch |
| 4—Plunger | 10—Bushing | 16—Oil Seal | 22—Pinion Stop |
| 5—Shunt Field Terminal | 11—Thrust Washer | 17—Bushing | 23—Bushing |
| 6—Solenoid Assembly | 12—Commutator | 18—Felt | |

When solenoid (6) engages, it pulls shift lever (3). Shift lever pushes overrunning clutch drive (21) to engage pinion in starter gear on flywheel. As armature (14) turns, it cranks engine.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.


The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel. Brake washer (19) slows armature to a stop.

R25228 -UN-14NOV88

Starter Motor Operation (Gear Reduction Type)



Starter Motor (Gear Reduction Type)

RG8614 -UN-03DEC97

- | | | | |
|------------------------|----------------|--------------------|-----------------------|
| 1—Pinion Gear | 4—Brush | 7—Field Windings | 10—Solenoid Assembly |
| 2—Idle (Reducing) Gear | 5—Brush Spring | 8—Armature | 11—Overrunning Clutch |
| 3—Drive Gear | 6—Field Frame | 9—Solenoid Plunger | |

The reduction or “R” type starter motor is a positive shift type and consists of the motor, reduction gear, overrunning clutch, and solenoid switch. The solenoid switch and overrunning clutch mechanism are on the same axis as shown.

In a conventional starter motor the armature and overrunning pinion rotate at the same speed. In a reduction-type starter motor, the armature rotation is reduced by one-fourth to one-third by the reduction gears, and is transmitted to the pinion through the clutch mechanism.

Operation is as follows:

When solenoid (10) engages, it pushes overrunning clutch drive (11) to engage pinion gear (1) in starter gear on flywheel. As armature (8) turns, it cranks engine.

When engine starts, overrunning clutch (11) spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.

Continued on next page

RG, RG34710, 2287 -19-09OCT00-1/2

Starting Circuit Theory of Operation

The two windings cancel each other, and solenoid is released.


Overrunning clutch (11) retracts, disengaging pinion gear (1) from flywheel.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings (7) and armature (8).

RG, RG34710, 2287 -19-09OCT00-2/2

65
05
4

Starter Motor Operation (Planetary Type)



Starter Motor (Planetary Type)

1—Drive End Housing
2—Overrunning Clutch
3—Shift Lever
4—Sealing Boot

5—Solenoid
6—Brush
7—Motor

8—Ball Bearing
9—Field Coil
10—Shunt Coil

11—Planetary Reduction Gear
12—Grease Reservoir
13—Needle Bearing

RG12496 -UN-25JUL02

65
05
5

When solenoid (5) engages, it pulls shift lever (3). Shift lever pushes overrunning clutch drive (2) to engage pinion in starter gear on flywheel. As motor (7) turns, it cranks engine through planetary reduction gears (11) which provide a speed reduction, with proportional torque increase, for the pinion gear.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through

both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.

The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel.

OUOD006,0000064 -19-28AUG02-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000B9B -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JN-12DEC88

OUO1004.0000B9B -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000B9B -19-08MAY02-3/3

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1004,0000B9C -19-25SEP00-1/2

65
10
2

Bushing, Bearing, and Seal Driver Set. D01045AA

Remove and install all commutator, drive end, and center bushings and/or bearings.


OUC1004,0000B9C -19-25SEP00-2/2

Dealer Fabricated Tools

Starter Motor Commutator, Center Bearing and Drive End Bushing Tool

Commutator and Drive End Bushing Tool		
Dimension	Removal	Installation
A	25.4 mm (1 in.)	25.4 mm (1 in.)
B	18.6—18.7 mm (0.731—0.736 in.)	18.6—18.7 mm (0.731— 0.736 in.)
C	16.8—16.9 mm (0.661—0.665 in.)	16.8—16.9 mm (0.661— 0.665 in.)
D	50.8 mm (2 in.)	100.08 mm (3.94 in.)
E	22.9—23.1 mm (0.901—0.909 in.)	0.46—0.56 mm (0.018— 0.022 in.)
F	19.9—20.1 mm (0.783—0.791 in.)	19.9—20.1 mm (0.783— 0.791 in.)

Center Bearing Bushing Tool		
Dimension	Removal	Installation
A	39.9 mm (1.57 in.)	39.9 mm (1.57 in.)
B	34.5—34.8 mm (1.36—1.37 in.)	34.5—34.8 mm (1.36— 1.37 in.)
C	29.7—30.0 mm (1.17—1.18 in.)	29.7—30.0 mm (1.17— 1.18 in.)
D	50.8 mm (2 in.)	50.8 mm (2 in.)
E	24.1—25.9 mm (0.95—1.02 in.)	0.46—0.51 mm (0.018— 0.02 in.)
F	22.0—24.0 mm (0.866—0.945 in.)	25.3—25.4 mm (0.996— 1.000 in.)



Dealer Fabricated Tools

R18972 -UN-11APR89

65
10
3

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.
	ESSO Beacon 325 or Delco-Remy No. 1960954 Lubricant	Lubricate various stator components.

OUC1004,0000B9D -19-25SEP00-1/1

65
10
4

John Deere/Denso Conventional Starter Motor Repair Specifications

Item	Measurement	Specification
Commutator and Drive End Bushing	ID	17.000—17.028 mm (0.6693—0.6704 in.)
	Wear Limit	17.120 mm (0.674 in.)
	Oil Clearance	0.091—0.178 mm (0.0036—0.0070 in.)
	Wear Limit Bushing Depth	0.41 mm (0.016 in.) 0.20—0.56 mm (0.008—0.022 in.)
Center Housing Bushing	ID	30.023—30.074 mm (1.182—1.84 in.)
	Maximum Oil Clearance	0.599 mm (0.0236 in.)
	Bushing Depth	0.43—0.81 mm (0.017—0.032 in.)
Standard Commutator	Runout	0.05 mm (0.002 in.)
	Wear Limit	0.38 mm (0.016 in.)
Armature	Undercut Depth	0.79 mm (0.0312 in.)
	Wear Limit	0.20 mm (0.008 in.)
Commutator	OD	48 mm (1.89 in.)
	Minimum OD	46 mm (1.81 in.)
Armature	End Play	0.05—0.50 mm (0.002—0.020 in.)
Pole Shoe Cap Screws	Torque	41 N•m (30 lb-ft)
New Brush	Length	26 mm (1.02 in.)
Used Brush	Minimum Length	16 mm (0.68 in.)
Brush Spring	Minimum Tension	11 N (40 ounce-force)
Shift Lever Pivot Cap Screw	Torque	41 N•m (30 lb-ft)
Center Housing-to-Field Frame Cap Screw	Torque	8 N•m (71 lb-in.)
Armature End Play	Torque	0.05—0.50 mm (0.002—0.020 in.)
Drive End Housing-to-Center Housing Cap Screws	Torque	14 N•m (124 lb-in.)
Commutator End Frame Cap Screws	Torque	14 N•m (124 lb-in.)

John Deere/Denso Conventional Starter Motor Test Specifications

John Deere Starter Motor Part No.	Denso Starter Motor Part No.	System Voltage	Rating Type	kW	Motor Voltage	No Load Test Current Draw Amps (Max.)	RPM (Min.)
AR41627	028000-3290	12	F	4.0	11.7	130	3100
AR46886	028000-3811	12	F	5.0	11.7	130	3100
AR55639	028000-3290	12	F	4.0	11.7	130	3100
AR62154	028000-3810, 028000-3811	12	F	5.0	11.7	130	3100
AR63341	028000-3970	12	F	4.0	11.7	130	3100
AR63341	028000-3971	12	F	4.0	11.7	130	3100
AR77254	028000-3291	12	F	4.0	11.7	130	3100
AR77254	028000-3291	12	F	4.0	11.7	130	3100
AR84333	028000-5250	24	F	7.5	23.5	75	4200
CH12084	028000-7640	12	R	1.0	11.5	90	3000
CH12096	028000-5660	12	R	2.5	11.0	180	3500
CH15586	028000-7640	12	R	1.0	11.5	90	3000
CH19282	128000-0740	12	R	1.0	11.5	90	3000
CH19284	128000-0710	12	R	1.4	11.5	90	3500
CH19285	128000-0790	12	R	2.5	11.0	180	3500
RE13722	028000-3292	12	F	4.0	11.7	130	3100
RE15663	028000-5251	24	F	7.5	23.5	75	4200
RE15718	128000-0480	24	F	7.5	23.5	75	4800
RE23900	128000-3690	12	F	4.0	11.7	130	3100
RE38336	128000-5970, 128000-5971	12	IIF	4.0	11.7	130	3300
RE38369	128000-7170	24	IIF	7.5	23.5	80	3500
RE39832	128000-7230	12	IIF	4.0	11.7	130	3300
RE39833	128000-7240	24	IIF	7.5	23.5	80	3500
RE40595	128000-8303	24	R	4.5	23.0	90	3500
RE41799	028000-8400	12	R	2.5	11.0	180	3500
RE42670	128000-7250	12	IIF	4.0	11.7	130	3300
RE43266	128000-5972, 228000-2360	12	IIF	4.0	11.7	130	3300
RE43421	128000-7230	12	IIF	4.0	11.7	130	3300
RE43422	128000-0480	24	F	7.5	23.5	75	4800
RE44151	128000-7172	24	IIF	7.5	23.5	80	3500
RE44511	228000-2390	24	IIF	7.5	23.5	80	3500
RE44515	128000-7172	24	IIF	7.5	23.5	80	3500
RE45328	128000-7172, 228000-2390	24	IIF	7.5	23.5	80	3500
RE48827	128000-8301	24	R	4.5	23.0	90	3500
RE500199	228000-7011	24	R	7.8	23	120	3800
RE500345	228000-6570, 22800-7011A	24	R	7.5	23	120	3800

Continued on next page

RG, RG34710, 2292 -19-07JUL05-1/2

John Deere/Denso Conventional Starter Motor Repair

John Deere Starter Motor Part No.	Denso Starter Motor Part No.	System Voltage	Rating Type	kW	Motor Voltage	No Load Test Current Draw Amps (Max.)	RPM (Min.)
RE501060	228000-7411	24	R	7.8	23	120	3800
RE501150	228000-7410	24	R	7.8	23	120	3800
RE501294	228000-7871	12	R	4.8	11	220	4200
RE502811	228000-8470	12	R	4.8	11	220	4200
RE504244	228000-9140	12	R	4.8	11	220	4200
RE504245	228000-9150	24	R	7.8	23	120	3800
RE505465	228000-9630	24	R	7.8	23	120	3800
RE506825	42800-0120	12	R	4.8	11.5	200	2000
RE506826	42800-0130	24	R	7.8	23.5	120	2000
RE522851	42800-121	12	R	4.8	11.5	200	2000
RE522852	42800-131	24	R	7.8	23.5	120	2000
RE54416	128000-5973, 228000-2360	12	IIF	4.0	11.7	130	3300
RE54874	228000-2370	12	IIF	4.0	11.7	130	3300
RE54909	228002-2380	12	IIF	4.0	11.7	130	3300
RE55378	228000-2370	12	IIF	4.0	11.7	130	3300
RE55641	228000-2390	24	IIF	7.5	23.5	80	3500
RE57078	228000-2390	24	IIF	7.5	23.5	80	3500
RE59583	228000-4690	12	IIF	4.0	11.7	130	3300
RE59584	228000-4730	24	IIF	7.5	23.5	80	3500
RE59585	228000-4611	24	IIF	7.5	23.5	80	3500
RE59596	228000-4700	12	IIF	4.0	11.7	130	3300
RE59589	228000-4601	12	IIF	4.0	11.7	130	3300
RE61517	228000-4610	24	IIF	7.5	23.5	80	3500
RE65100	228000-4630	12	IIF	4.0	11.7	130	3300
RE65173	228000-4730	24	IIF	7.5	23.5	80	3500
RE65174	228000-4611	24	IIF	7.5	23.5	80	3500
RE65176	228000-4601	12	IIF	4.0	11.7	130	3300
RE65191	228000-4700	12	IIF	4.0	11.7	130	3300
RE70958	228000-6560	24	R	7.8	23	120	3800
RE70961	228000-7010	24	R	7.8	23	120	3800
RE79474	228000-6550	12	R	4.8	11	220	4200

NOTE: Earlier Denso starter motors may have the original Nippondenso label.


RG.RG34710,2292 -19-07JUL05-2/2

65
10
7

Test Starter Motor Before Disassembly

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

1. Turn overrunning clutch drive by hand. Clutch drive should turn freely on shaft in overrunning direction only.




Turn Overrunning Clutch Drive

RG, RG34710, 2294 -19-15MAR97-1/2

2. Turn armature by prying against pinion with screwdriver. Check for dragging armature, seized bushings, or bent shaft.

If you discover any interference, disassemble and repair starter motor.

IMPORTANT: Do not conduct the no-load test unless armature turns freely. Damage to the starter motor may result.




Turn Armature

RG, RG34710, 2294 -19-15MAR97-2/2

Make Solenoid Pull-In Test

1. To prevent damage, solenoid must be on starter motor when testing the windings.
2. Remove shunt field winding lead (A) from terminal on field frame.
3. Remove terminal cover (B).

A—Shunt Field Winding Lead
B—Terminal Cover



Shunt Field Winding Lead and Cover

Continued on next page

RG, RG34710, 2295 -19-15MAR97-1/4

4. Remove field coil connector (A).

A—Field Coil Connector



Remove Field Coil Connector


RG3893 -UN-09NOV89

RG, RG34710, 2295 -19-15MAR97-2/4

5. Make connections as shown.

With 8 volts applied, the solenoid should push the pinion out to the pinion stop when the jumper wire (D) is connected. The drive gear should remain out at the pinion stop. Current through jumper wire will be approximately 90 amps. Use a heavy jumper wire and remove as soon as the pinion is at stop.

- A—12-Volt Battery
- B—Voltmeter
- C—Carbon Pile Resistor
- D—Jumper Wire



Make Connections

RG4636 -UN-06APR89

RG, RG34710, 2295 -19-15MAR97-3/4

If solenoid does not engage, remove solenoid and manually move shift lever (A) back and forth. If lever moves smoothly, pull-in winding is defective and solenoid must be replaced. If not, disassemble and repair starter.

If solenoid engages but then chatters instead of staying firmly engaged, the hold-in winding is defective and solenoid must be replaced. Be sure solenoid ground wire is connected to starter frame.

A—Shift Lever



Move Shift Lever


RG3895 -UN-09NOV89

RG, RG34710, 2295 -19-15MAR97-4/4

Make Solenoid Return Test

1. Make connections as shown.
2. Close the switch (A).
3. Pull the drive out until the pinion contacts the pinion stop. When released, the drive should return without hesitation.

A—Switch



RG3896

Make Solenoid Return Test


RG3896 -UN-05DEC97

RG.RG34710,2296 -19-15MAR97-1/1

65
10
10

Make No-Load Test

1. Make connections as shown, and use an ammeter (A) capable of measuring several hundred amps.
2. Measure current draw and compare with specifications given earlier in this group.
3. If speed and current draw are slightly low, connect a voltmeter between motor terminal and frame. Observe voltage during test. Voltage may be reduced because of high current draw on battery.
4. If speed or current draw is significantly different than specified, diagnose problem as follows:



Make Connections

- A—Ammeter
- B—Battery
- C—Starter Frame
- D—Tachometer
- E—Battery Terminal
- F—Switch
- G—Field Coil Connector

RG11163 -UN-28SEP00

RG.RG34710,2297 -19-15MAR97-1/1

Diagnose No-Load Test

Fails to Operate-Low Current Draw (Approx. 25 Amps)

Open series field circuit.

Open armature coils.

Defective brush contact with commutator.

Fails to Operate-High Current Draw

Grounded terminal or fields.

Seized bearings.

Low Speed-Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed-High Current Draw

Excessive friction

Shorted armature

Grounded armature or fields.

High Speed-Low Current Draw

Open shunt field circuit.

High Speed-High Current Draw

Shorted series field coils.

RG, RG34710, 2298 -19-15MAR97-1/1


65
10
11

Disassemble Starter Motor

NOTE: Starter motor has metric bolts and nuts except for those on switch cover.

1. Remove solenoid cap screws (A) and lock washers.

IMPORTANT: Whenever starter motor is disassembled, for any reason, lubricate as follows: Apply a coat of ESSO Beacon 325 or Delco-Remy Lubricant No. 1960954 to both end bearings. Grease reservoirs for both end bearings, armature shaft except center bearing area, brake washer, solenoid plunger, both ends of shift lever, wear pads, and shift lever pivot shaft.



Solenoid Cap Screws

A—Solenoid Cap Screws

RG3888 -JUN-09NOV89

Continued on next page

RG, RG34710, 2299 -19-06MAY02-1/10

2. Remove solenoid from center bearing housing by lifting plunger shaft (A) up and away from shift lever.

A—Plunger Shaft



Lift Plunger Shaft

RG, RG34710, 2299 -19-06MAY02-2/10

RG3899 -UN-09NOV89

3. Remove end frame cover and gasket.



Remove End Frame Cover and Gasket

RG, RG34710, 2299 -19-06MAY02-3/10


RG2705 -UN-17JUL89

4. Inspect brush leads (A) for fraying or corrosion.

NOTE: If only new brushes are going to be installed, it isn't necessary to remove the commutator end frame.

5. Remove commutator end frame cap screws (B) with washers. Inspect O-ring (C) for wear.

A—Brush Leads
B—Commutator End Frame Cap Screws
C—O-Ring



Inspect Brush Leads and O-Ring


RG3900 -UN-09NOV89

Continued on next page

RG, RG34710, 2299 -19-06MAY02-4/10

6. Remove brush lead cap screws (A).
7. Remove brush ground straps (B).

A—Brush Lead Cap Screws
B—Brush Ground Straps




Remove Cap Screws and Ground Straps

RG.RG34710,2299 -19-06MAY02-5/10

RG3901 -UN-09NOV89

8. Use an O-ring pick (A) or other suitable tool to pull brush spring (B) back and remove brush (C).

A—O-Ring Pick
B—Brush Spring
C—Brush



Remove Brush

RG.RG34710,2299 -19-06MAY02-6/10


RG3902 -UN-09NOV89

9. Remove shift lever pivot (A).

NOTE: Before removal of drive end housing, place alignment marks on drive end housing and center bearing housing for aid in reassembly.

10. Remove drive end housing Allen screws (B) and center bearing housing cap screws (D).
11. Remove drive end housing (C).

A—Shift Lever Pivot
B—Allen Screw (6 used)
C—Drive End Housing
D—Cap Screw (2 Used)



Remove Drive End Housing


Continued on next page

RG.RG34710,2299 -19-06MAY02-7/10

RG3903 -UN-09NOV89

12. Use a pipe coupling (A) or other metal cylinder to drive pinion stop (B) toward pinion.
13. Remove retaining ring and slide pinion stop off shaft.

A—Pipe Coupling
B—Pinion Stop




Slide Pinion Stop

R26558 -UN-09FEB90

RG, RG34710, 2299 -19-06MAY02-8/10

14. Carefully remove overrunning clutch (A), brake washer (B), shift lever (C), and wear pads (D) from center bearing housing and armature shaft. Inspect wear pads for excessive wear or damage. Replace wear pads if necessary.

A—Overrunning Clutch
B—Brake Washer
C—Shift Lever
D—Wear Pads




Inspect for Damage

RG3904 -UN-09NOV89

RG, RG34710, 2299 -19-06MAY02-9/10

15. Remove center bearing housing (C).
16. Carefully remove armature (B) from field frame (A).

A—Field Frame
B—Armature
C—Center Bearing Housing




Remove Armature

RG3905 -UN-09NOV89

RG, RG34710, 2299 -19-06MAY02-10/10

John Deere/Denso Conventional Starter Motor Exploded View



Starter Motor Components

- | | | | |
|--------------------------|-------------------------------|-------------------------|---------------------------------|
| 1—Drive End Bushing | 11—Shunt Winding Lead | 21—Field Winding | 31—Gasket |
| 2—Drive End Housing | 12—Armature | 22—Pole Shoe (4 Used) | 32—Commutator End Frame Bushing |
| 3—O-Ring | 13—Bakelite Washer | 23—Square Washer | 33—Brush (4 Used) |
| 4—Overrunning Clutch | 14—Oil Seal | 24—Insulating Bushing | 34—Brush Spring (4 Used) |
| 5—Shift Lever Pivot | 15—Center Bearing Bushing | 25—Square Insulator | 35—Commutator End Frame Bushing |
| 6—O-Ring | 16—Oil Felt | 26—Special Bolt | 36—Field Frame |
| 7—Shift Lever | 17—Brake Washer | 27—Field Coil Connector | 37—Shims (as required) |
| 8—Center Bearing Housing | 18—Pinion Stop | 28—Terminal Cover | |
| 9—Solenoid Winding | 19—Snap Ring | 29—Brush Ground Strap | |
| 10—Solenoid Switch Cover | 20—Shunt Winding Ground Screw | 30—End Frame Cover | |

65
10
15

RG4541 -UN-15DEC88

OUC1004,0000B48 -19-15SEP00-1/1

Install New Bushings/Needle Bearings

NOTE: Refer to exploded view on previous page.

1. If needed, install new bushings (1, 15, and 32).
2. Install a new oil seal (14) and oil felt (16) saturated with clean engine oil.
3. Make a bushing tool as shown earlier in Dealer Fabricated Tools or use the following components from the D01045AA Bushing, Bearing, and Seal Driver Set.

Commutator and Drive End Bushing Tools		
Component	Bushing Removal	Bushing Installation
Handle	27487	27487
Disk (Spacers)	27491	27492
Disk (Pilot)	27493	27493
Disk	27494	27495

4. Install commutator and drive end bushing and determine depth. Compare to specification below.
5. Ream bushing, if necessary, so following specifications are maintained.

Specification

Commutator and Drive End	
Bushing—ID	17.000—17.028 mm (0.6693—0.6704 in.)
Wear Limit.....	17.120 mm (0.674 in.)
Oil Clearance	0.091—0.178 mm (0.0036—0.0070 in.)
Wear Limit.....	0.41 mm (0.016 in.)
Bushing Depth	0.20—0.56 mm (0.008—0.022 in.)

6. Install center bushing and oil seal using tools and specifications listed below.

Center Bushing Tools		
Component	Bushing	Oil Seal
Handle	27487	27487
Disk	27505	27512
Disk (pilot)	27501	27501

Specification

Center Housing Bushing—ID	30.023—30.074 mm (1.182—1.84 in.)
Maximum Oil Clearance	0.599 mm (0.0236 in.)
Bushing Depth	0.43—0.81 mm (0.017—0.032 in.)

RG, RG34710, 2300 -19-09OCT00-1/1

Clean Starter Motor Components

IMPORTANT: Do not immerse the solenoid, field windings, or armature in cleaning solvent because it may damage the insulation.

1. Clean parts by wiping with a cloth or brush, moistened with mineral spirits.
2. Dry with compressed air.

3. Clean the drive end housing, overrunning clutch, center bearing housing, and commutator end frame the same way.

All other parts which are not made of rubber or mentioned previously, can be dipped in cleaning solvent to remove all oil and dirt.

RG, RG34710, 2301 -19-15MAR97-1/1

Inspect Armature


1. Place armature in V-blocks and check for bent shaft. If shaft is bent, replace armature.

Inspect armature using the following specifications:

Specification

Standard Commutator—Runout.....	0.05 mm (0.002 in.)
Wear Limit	0.38 mm (0.016 in.)
Armature—Undercut Depth.....	0.79 mm (0.0312 in.)
Wear Limit	0.20 mm (0.008 in.)
Commutator—OD.....	48 mm (1.89 in.)
Minimum OD.....	46 mm (1.81 in.)
Armature—End Play.....	0.05—0.50 mm (0.002—0.020 in.)

2. Check armature for opens, shorts and grounds. Burned edge of commutator bar indicates an open circuit.



Inspect Armature

X1451 -UN-25JAN89


RG, RG34710, 2302 -19-15MAR97-1/1

65
10
17

Make Short Circuit Test

1. Place armature in a growler and hold hacksaw blade above each slot while slowly rotating the armature.
2. If coil is shorted, the blade will be attracted to and repelled from the slot.

A short circuit most often occurs because of copper dust or filings between two commutator segments. Clean commutator segments to correct this short.



Place Armature in Growler


RG78074C1 -UN-09JAN90

DPSG, OUOE003, 29 -19-18DEC98-1/1

Make Armature Ground Test

1. Set ohmmeter to read on highest scale.
2. Place one test lead on the armature core or shaft. Place other lead on commutator.

If the test meter indicator swings toward zero, the armature is grounded. Replace armature.



T90253 -UN-20NOV89

Make Armature Ground Test


RG, RG34710, 2303 -19-15MAR97-1/1

65
10
18

Make Open Circuit Test

1. Set ohmmeter to read on lowest scale.
2. Place one test lead on ohmmeter segment. Place other test lead on an adjacent segment.
3. Repeat this operation for all segments by moving one lead at a time.

If the test meter indicator does not swing to zero and remains stationary, the armature coil between these two segment is open. Replace armature.



T31426NY -UN-27JUL89

Make Open Circuit Test

RG, RG34710, 2304 -19-15MAR97-1/1

Repair Armature

1. If commutator bars are rough or burned, clean with 00 sandpaper. Never use emery cloth.
2. Clean all dust from armature.

IMPORTANT: Do not clean armature with solvent. Solvent could damage insulation on windings. Use only mineral spirits and a clean cloth or brush. Wipe dry with a clean cloth.

65
10
19

RG, RG34710, 2305 -19-15MAR97-1/1

Inspect Overrunning Clutch and Pinion

1. Rotate the pinion. Pinion gear should rotate smoothly (but not easily) in one direction. The pinion gear should not rotate in the opposite direction.

If pinion gear does not rotate smoothly or if it is worn, chipped, or burred, it should be replaced.

RG, RG34710, 2306 -19-15MAR97-1/1

Make Grounded Circuit Test for Field Windings

1. Remove screw and hang eyelet terminal in the air.
2. Set ohmmeter to read on highest scale.
3. Place one test lead on a clean spot on the field frame. Place other leads on the copper terminal bolt as shown.

If the ohmmeter indicator swings toward zero, a grounded circuit is indicated. Replace the field windings.



Make Grounded Circuit Test

T35198 -UN-28JUL89

RG, RG34710, 2307 -19-15MAR97-1/1

Make Open Circuit Test for Shunt Windings

1. Set the ohmmeter on its lowest scale.
2. Place one test lead on the eyelet terminal. Place other lead on the terminal bolt.

If the ohmmeter does not swing to zero, it is open circuited. Replace the field winding assembly.



Make Open Circuit Test for Shunt Windings

T31428NY -UN-27JUL89

RG, RG34710, 2308 -19-15MAR97-1/1

Make Open Circuit Test for Field Windings

1. Set ohmmeter on its lowest scale.
2. Place one test lead on the naked field end. Place other lead on the copper terminal bolt.

If ohmmeter dial indicator does not swing to zero, the field windings are open circuited. Replace field windings.



Make Open Circuit Test for Field Windings

RG, RG34710, 2309 -19-15MAR97-1/1

65
10
21

Remove Field Windings (If Necessary)

1. Use a large screwdriver bit and socket wrench on pole shoe cap screws.
2. Scribe mark on pole shoe and field frame for proper assembly.

IMPORTANT: Do not tightly squeeze side of main frame in a vise or strike with a hammer. Damage may result.

If an impact screwdriver is used to loosen screws, support each pole shoe individually using a pole shoe spreader or the nose of an anvil.

Remove windings very carefully. Windings are easily damaged, causing shorts, opens, or grounds.





Remove Field Windings

RG, RG34710, 2310 -19-15MAR97-1/1

Install Field Windings

NOTE: Two different field winding assemblies are available. Starter motors with date code 9U0001 and lower have shunt wire lead (A), while those with date code 10U001 and higher have shunt wire lead (B). Shunt wire lead (A) will be too short for the later starter motors.

1. Carefully insert field windings.
2. Align scribe marks on pole shoes and field frame.
3. Tighten pole shoe screws to specifications.



Install Field Windings

Specification

Pole Shoe Cap Screws—Torque 41 N•m (30 lb-ft)

- A—Earlier Field Winding Shunt Lead
- B—Later Field Winding Shunt Lead

RG4958 -UN-06APR89

RG, RG34710, 2311 -19-15MAR97-1/1

Inspect and Repair Brushes

Replace brushes if they are oil soaked, worn, damaged, or worn beyond specification.

Specification

New Brush—Length 26 mm (1.02 in.)
 Used Brush—Minimum Length 16 mm (0.68 in.)


If brushes are burned or rough, use 00 sandpaper to clean commutator contact area of brushes. Never use emery cloth. Clean all dust from brush before reassembly.

RG, RG34710, 2312 -19-15MAR97-1/1

Test Brush Holder for Grounds

1. Set ohmmeter on its highest scale.
2. Place one test lead on commutator end frame. Place other lead on brush holder.

If needle swings toward zero, the positive brush holder is grounded and should be replaced.



Test Brush Holder for Grounds

RG, RG34710, 2313 -19-15MAR97-1/1

65
10
23

Measure Brush Spring Tension


Measure spring tension with a spring scale.

Brush spring tension should be as specified, just as the spring leaves the brush holder.

Specification

Brush Spring—Minimum Tension..... 11 N (40 ounce-force)

When measuring tension, scale should be parallel with edge of brush holder.



Measure Brush Spring Tension

RG, RG34710, 2314 -19-15MAR97-1/1


Disassemble Solenoid

1. Remove nut, washer and gasket from solenoid "S" terminal (C).
2. Remove nut, washer and gasket from pull-in terminal (F).
3. Remove switch cover (A).
4. Inspect all solenoid parts for wear, dirt, and corrosion.
5. Wipe all parts and connections with mineral spirits and a clean cloth or brush. Dry with a clean cloth.

Firm pressure should be felt on the plunger when fully depressed. If plunger is weak, replace solenoid winding and plunger assembly.

6. Place gaskets on pull-in terminal and "S" terminal.
7. Align main contact vertically.
8. Place packing on switch cover.
9. Tighten switch cover screws to solenoid winding and plunger assembly securely.

IMPORTANT: Solenoid contacts and plunger will be damaged if current is applied to solenoid when removed from starter motor.



Disassemble Solenoid

- A—Switch Cover
- B—Shunt Winding Lead
- C—"S" Terminal
- D—Solenoid Winding and Plunger Assembly
- E—Plunger Cover
- F—Pull-In Winding Terminal
- G—Gaskets
- H—Packing

RG3906 -JUN-09NOV89


RG, RG34710, 2315 -19-15MAR97-1/1

Assemble Starter Motor

1. Lubricate both ends of shift lever (C) and wear pads (D) on overrunning clutch (A), with a multi-purpose lubricant.
2. Lubricate brake washer (B) and place on end of overrunning clutch.

NOTE: Avoid excessive lubrication.

- A—Overrunning Clutch
- B—Brake Washer
- C—Shift Lever
- D—Wear Pads



Assemble Starter Motor

RG3904 -UN-09NOV/89

65
10
25


RG, RG34710, 2316 -19-15MAR97-1/9

3. Place shift lever and overrunning clutch (A) up into center bearing housing (B).
4. Install shift lever pivot (C) through shift lever and tighten to specifications.

Specification

Shift Lever Pivot Cap Screw—
Torque 41 N•m (30 lb-ft)

5. Bend washered edge of shift lever pivot down to prevent loosening.
6. Lubricate bearing in center bearing housing generously, but not excessively with either Esso Beacon 325 or Delco-Remy Lubricant No. 1960954.
7. Inspect O-ring (D) for wear and damage. Replace if necessary.



Install and Inspect

- A—Overrunning Clutch
- B—Center Bearing Housing
- C—Shift Lever Pivot
- D—O-Ring

RG3907 -UN-09NOV/89


Continued on next page

RG, RG34710, 2316 -19-15MAR97-2/9

8. Carefully install armature into field frame (A).
9. Place center bearing housing with overrunning clutch assembly (B) onto armature shaft (C) and against field frame.

Make sure O-ring in center bearing housing is not twisted or crimped when placed against field frame.

10. Slide pinion stop over ring using a washer (F) and two pair of pliers.
11. Remove washer.
12. Tighten all center bearing housing cap screws (G) in field frame to specifications.



Install Center Bearing Housing

- A—Field Frame
- B—Overrunning Clutch Assembly
- C—Armature Shaft
- D—Pinion Stop
- E—Retaining Ring
- F—Washer (remove after using)
- G—Cap Screws

RG3908 -UN-09NOV89

Specification

Center Housing-to-Field Frame
Cap Screw—Torque..... 8 N•m (71 lb-in.)

NOTE: Before installing drive end housing, check armature end play. Using a dial indicator, place a tip against end of armature shaft on drive end. If end play is not within specifications, add or remove shims (37, see exploded view) to obtain correct end play.

Specification

Armature End Play—Torque..... 0.05—0.50 mm (0.002—0.020 in.)


RG, RG34710, 2316 -19-15MAR97-3/9

13. Install drive end housing (A) against center bearing housing. Armature shaft must come through drive end bushing (B).
14. Tighten drive end Allen-head bolts (C) to specifications.

Specification

Drive End Housing-to-Center
Housing Cap Screws—Torque..... 14 N•m (124 lb-in.)

- A—Drive End Housing
- B—Drive End Bushing
- C—Drive End Allen-Head Bolts



Install Drive End Housing

RG4205 -UN-08SEP89

Continued on next page


RG, RG34710, 2316 -19-15MAR97-4/9

15. Place commutator end frame over armature.

NOTE: Be sure commutator end frame notches fit correctly in field frame.

16. Using O-ring pick (A) or other suitable tool, raise brush springs (B) and install brushes (C).

- A—O-Ring Pick
- B—Brush Springs
- C—Brushes



Install Brushes

RG3902 -UN-09NOV/89


65
10
27

RG, RG34710, 2316 -19-15MAR97-5/9

17. Twist brush leads (B) 180 degrees.

18. Press leads of insulated brush (A) down against brush. Make sure spring (C) is fully seated on top of brush.

- A—Insulated Brush
- B—Brush Leads
- C—Spring



Twist Brush Leads

RG3909 -UN-09NOV/89


RG, RG34710, 2316 -19-15MAR97-6/9

19. Install brush ground straps (B).

20. Screw brush cap screws (A) down securely.

NOTE: Make sure field winding lead and shunt winding leads are tightened down with the brush cap screws.

- A—Brush Cap Screws
- B—Brush Ground Straps



Install Brush Ground Straps

RG3901 -UN-09NOV/89

Continued on next page

RG, RG34710, 2316 -19-15MAR97-7/9

21. Install washers and cap screws (B) through commutator end frame.


22. Tighten screws to specifications.

Specification

Commutator End Frame Cap
Screws—Torque..... 14 N•m (124 lb-in.)

Make sure brush leads (A) are properly positioned.

NOTE: Replace O-ring (C) if cracked or worn.



Position Brush Leads

RG3900 -UN-09NOV89

- A—Brush Leads
- B—Washers and Cap Screws
- C—O-Ring

RG, RG34710, 2316 -19-15MAR97-8/9

23. Place end frame cover onto field frame.

24. Install end frame cover washers, lock washers and cap screws. Tighten securely.



End Frame Cover

RG2705 -UN-17JUL89

RG, RG34710, 2316 -19-15MAR97-9/9

Install Solenoid

1. Install solenoid plunger shaft (A) up onto shift lever.

- A—Solenoid Plunger Shaft



Solenoid Plunger Shaft


RG3899 -UN-09NOV89

Continued on next page

RG, RG34710, 2317 -19-15MAR97-1/4

2. Push solenoid assembly forward up against center bearing housing.
3. Screw solenoid cap screws with lock washers (A) into solenoid and tighten securely.

A—Solenoid Cap Screws and Lock Washers



Lock Washers

RG, RG34710, 2317 -19-15MAR97-2/4

RG3898 -UN-09NOV89

4. Install field coil connector (A), washers and nuts. Tighten nuts securely.

A—Field Coil Connector




Install Field Coil Connector

RG, RG34710, 2317 -19-15MAR97-3/4

RG3893 -UN-09NOV89

5. Install shunt lead wire (A), lock washer, and nut. Tighten nut securely.
6. Install terminal cover (B) on solenoid securely.

**A—Shunt Lead Wire
B—Terminal Cover**




Install Terminal Cover

RG, RG34710, 2317 -19-15MAR97-4/4

RG3892 -UN-09NOV89

Make No-Load Test

1. Make connections as shown, and use an ammeter (A) capable of measuring several hundred amps.
2. Measure current draw and compare with specifications given earlier in this group.
3. If speed and current draw are slightly low, connect a voltmeter between motor terminal and frame. Observe voltage during test. Voltage may be reduced because of high current draw on battery.
4. If speed or current draw is significantly different than specified, diagnose problem by referring to Diagnose No-Load Test chart earlier in this group.



Make No-Load Test

- A—Ammeter
- B—Battery
- C—Start Frame
- D—Tachometer
- E—Battery Terminal
- F—Switch
- G—Field Coil Connector

RG11163 -JUN-28SEP00

RG, RG34710, 2318 -19-15MAR97-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004,0000B9F -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

65
15
1

OUO1004,0000B9F -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004,0000B9F -19-08MAY02-3/3

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1004,0000BA0 -19-25SEP00-1/5

65
15
2

Armature Growler

Test windings for shorts.

OUC1004,0000BA0 -19-25SEP00-2/5

Bearing Puller. D01203AA

Remove bearings.

OUC1004,0000BA0 -19-25SEP00-3/5

Bearing Puller. D01217AA

Remove bearings.

OUC1004,0000BA0 -19-25SEP00-4/5

Bushing, Bearing and Seal Drive Set. D01045AA

Remove and install all commutator, drive end, and center bushings.

OUC1004,0000BA0 -19-25SEP00-5/5

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.
	ESSO Beacon 325 or Delco-Remy No. 1960954 Lubricant	Lubricate various stator components.

OUC1004,0000BA1 -19-25SEP00-1/1

John Deere/Denso Gear Reduction Starter Motor Repair Specifications

Item	Measurement	Specification
Armature	Undercut Depth	0.08 mm (0.031 in.)
	Service Minimum	0.20 mm (0.008 in.)
Commutator	OD (New Part)	36 mm (1.41 in.)
	Wear Limit	35 mm (1.38 in.)
Commutator	Runout (New Part)	0.02 mm (0.0008 in.)
	Wear Limit	0.05 mm (0.002 in.)
Negative Brushes	Minimum Length	9.0 mm (0.35 in.)
Field Coil Brushes	Minimum Length	12.7 mm (0.500 in.)

OUC1004,0000BA2 -19-25SEP00-1/1

65
15
3

John Deere/Denso Gear Reduction Starter Motor Test Specifications

John Deere Starter Motor Part No.	Denso Starter Motor Part No.	System Voltage	Rating Type	kW	Motor Voltage	No Load Test Current Draw Amps (Max.)	RPM (Min.)
AM879743	22800-7111	12	R	2.0	11		
AM877284	22800-	12	R	2.0	11		
RE19275	028000-8400	12	R	2.5	11	180	3500
RE40092	028000-8290	12	R	2.5	11	200	3000
RE500199	228000-7010	24	R	7.5	23	120	3800
RE501060	228000-7410, 228000-7411	24	R	7.8	23 Min	120	3800
RE501294	228000-7873	12	R	4.0	11	220	4200
RE50165	228000-0840	12	R	2.5	11	200	3000
RE51447	028000-8401	12	R	2.5	11	200	3000
RE54090	128000-8291	12	R	2.5	11	200	3000
RE54091	228000-0841	12	R	2.5	11	200	3000
RE54092	028000-8402	12	R	2.5	11	200	3000
RE59588	228000-0844	12	R	2.5	11	200	3000
RE59595	128000-8294	12	R	2.5	11	200	3000
RE68470	228000-6471	12	R	2.7	11	200	3000
RE69704	228000-6530, 228000-6531	12	R	4.0	11	220	4200
RE69705	228000-6560	24	R	7.5	23	120	3800
RE70473	228000-6540	12	R	4.8	11	220	4200
RE70474	228000-6550, 228000-6551	12	R	4.8	11	220	4200
RE70475	228000-6570	24	R	7.5	23	120	3800
RE70957	228000-6530	12	R	4.8	11	220	4200
RE70959	228000-6540	12	R	4.8	11	220	4200
RE70960	228000-6550	12	R	4.8	11	220	4200

NOTE: Earlier Denso starter motors may have the original Nippondenso label.

RG, RG34710, 2322 -19-07JUL05-1/1


Bench Test Starter Motor

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

NOTE: Perform bench tests before disassembling the starter motor to determine the cause of the problem.

1. Turn overrunning clutch drive clockwise by hand. Pinion should turn freely.
2. Turn pinion counterclockwise. A definite resistance should be felt. If clutch assembly is defective, disassemble the starter clutch.
3. If armature turns freely and the clutch is not defective, test starter under no-load conditions as follows.

NOTE: Starter motors illustrated in this group are equipped with a four-hole mounting flange instead of one that has two holes. In addition, later R 4.0 kW and R 7.5 kW starter motors have the brush assemblies at the opposite end of the armature. Service procedures are not affected.



Turn Overrunning Clutch

65
15
5

RW2:158 -UN-06MAR90


RG, RG34710, 2323 -19-15MAR97-1/1

No-Load Test

NOTE: Do not conduct the no-load test unless the armature turns freely.

1. Connect a 12-volt battery (A) to starter battery terminal (B) and starter frame (C) as shown. Use heavy-duty cables.
2. Connect a remote start switch (D) between switch terminal (E) and battery terminal (B).
3. When switch is activated, starter should engage and run.
4. If solenoid only chatters, hold-in winding is open-circuited. If nothing happens, either the pull-in winding is open-circuited or mechanical parts are sticking. To check for sticking, remove solenoid end cover and push plunger by hand.
5. If solenoid engages properly, but motor does not run, check main contact points, bearings, brushes, reduction gears, armature, and field windings.

NOTE: The solenoid cannot be repaired, although mechanical parts may be replaced. Disassemble solenoid to determine cause of problem.




No-Load Test

- A—12-Volt Battery
- B—Battery Terminal
- C—Starter Frame
- D—Remote Start Switch
- E—Switch Terminal

RW2159 -UN-01DEC88

RG, RG34710, 2324 -19-15MAR97-1/1

John Deere/Denso Gear Reduction Starter Motor Exploded View



Gear-Reduction Starter Motor

- | | | | |
|----------------|------------------|----------------------|-----------------------|
| 1—End Frame | 6—Armature | 11—Idler Gear | 15—Return Spring |
| 2—O-Ring | 7—Front Bearing | 12—Retainer | 16—Steel Ball |
| 3—Field Frame | 8—Brush (4 Used) | 13—Roller (5 Used) | 17—Overrunning Clutch |
| 4—O-Ring | 9—Brush Holder | 14—Solenoid Assembly | 18—Motor Frame |
| 5—Rear Bearing | 10—Drive Gear | | |


RG, RG34710, 2334 -19-15MAR97-1/1

Disassemble Field Frame, Armature, and Brush Holder

NOTE: Bench test the starter motor before disassembly.

1. Disconnect field lead (A) from solenoid.
2. Remove two through bolts (B) and separate field frame assembly from motor frame.

- A—Field Lead
B—Through Bolts (2 Used)



Disconnect Field Lead

Continued on next page

RG, RG34710, 2325 -19-15MAR97-1/4

3. Remove two screws from brush end cap and remove cap from frame assembly.



RW10059 -UN-10NOV89

Remove Cap from Frame Assembly

RG,RG34710,2325 -19-15MAR97-2/4

4. Lift two field coil brush springs away and pull field coil brushes (A) away from brush holder assembly.

A—Field Coil Brushes



RW10067 -UN-10NOV89

Field Coil Brushes

Continued on next page

RG,RG34710,2325 -19-15MAR97-3/4

5. Lift two negative brush springs away and pull brushes back about 6 mm (0.250 in.). Release springs to hold brushes in place in brush holder (A).
6. Remove brush holder from frame assembly and armature.
7. Remove armature from frame assembly.

A—Brush Holder



Brush Holder

RW10068 -UN-10NOV89

65
15
9

RG, RG34710, 2325 -19-15MAR97-4/4

Inspect and Repair Armature

1. Remove armature from field frame assembly. See Disassemble Field Frame, Armature and Brush Holder earlier in this group.

IMPORTANT: Do not clean armature with solvent. Solvent could damage insulation on windings. Use only mineral spirits and a brush.

2. Visually inspect armature. Look for signs of dragging against pole shoes.

Specification

Armature—Undercut Depth.....	0.08 mm (0.031 in.)
Service Minimum.....	0.20 mm (0.008 in.)



Inspect and Repair Armature


RW2166 -UN-06MAR90

Continued on next page

RG, RG34710, 2326 -19-15MAR97-1/8

3. Check for grounded windings using an ohmmeter as shown, or a test lamp. Place ohmmeter probes on commutator bar and armature shaft. If test shows continuity (needle movement) a winding is grounded and the armature must be replaced.

NOTE: Operating symptoms of grounded windings would be that the starter motor cranks engine slowly or not at all. On no-load test, the starter motor would have low armature speed and high current draw, or fail to operate and have high current draw.



Ohmmeter

RW2167 -JUN-26FEB93


RG, RG34710, 2326 -19-15MAR97-2/8

NOTE: Operating symptoms of short-circuited windings would be that the starter motor cranks engine slowly. On no-load test, motor has low armature speed and high current draw.

4. Check for short-circuited windings using a growler such as shown.
5. Place armature in growler and hold a hacksaw blade above each slot while slowly rotating the armature. The blade will be attracted to and repelled (vibrating motion) from the slot.

NOTE: A short circuit most often occurs because of copper dust or fillings between two commutator segments.

6. If test indicates short-circuited windings, clean the commutator of dust and filings and recheck the armature. If test still indicates a short circuit, replace the armature.



Growler


RW2168 -JUN-01DEC88

Continued on next page

RG, RG34710, 2326 -19-15MAR97-3/8

7. Check for open-circuited windings using an ohmmeter as shown, or a test lamp. Place ohmmeter probes on two different commutator bars. If test shows no continuity (no needle movement), there is an open circuit and the armature must be replaced.

NOTE: Operating symptoms of open-circuited windings would be that the starter motor cranks engine slowly. On no-load test, motor has low armature speed and high current draw.




Ohmmeter Probes

RW10060 -UN-10NOV89

65
15
11

RG,RG34710,2326 -19-15MAR97-4/8

8. Check commutator (A), looking for roughness or burned commutator bars.
9. If necessary, clean and touch up with 00 sandpaper. NEVER use emery cloth. Clean all dust from armature when finished.
10. Turn down slightly on a lathe if commutator is out of round, badly burned, or rough. Remove only enough metal to eliminate the problem. After turning down, undercut the insulation between bars to 0.5—0.8 mm (0.019—0.031 in.) deep. Touch up commutator with sandpaper and clean metal chips and dust from armature when finished.



Check Commutator

RW10061 -UN-10NOV89

A—Commutator

Specification

Commutator—OD (New Part)	36 mm (1.41 in.)
Wear Limit	35 mm (1.38 in.)
Commutator—Runout (New Part)	0.02 mm (0.0008 in.)
Wear Limit	0.05 mm (0.002 in.)

Continued on next page

RG,RG34710,2326 -19-15MAR97-5/8

11. Inspect front and rear armature bearings for smooth, quiet operation. Replace as necessary.
12. Remove bearings by using D01217AA Bearing Puller and D01203AA Bearing Puller as shown.



Front and Rear Armature Bearings

RW10069 -UN-10NOV89

RG, RG34710, 2326 -19-15MAR97-6/8

IMPORTANT: Install both bearings with the sealed side toward the middle of the armature.

13. Install new bearing on the rear of armature using a piece of 15.88 mm (0.625 in.) ID pipe (A) drilled out to 17.45 mm (0.687 in.) ID. Be sure to drive only on the inner race. Make sure bearing is tight against shoulder of shaft.

NOTE: Pipe must be drilled out to the larger size to allow it to pass over the splined end of the armature.

A—15.88 mm (0.625 in.) ID Pipe



15.88 mm (0.625 in.) ID Pipe


RW10070 -UN-10NOV89

Continued on next page

RG, RG34710, 2326 -19-15MAR97-7/8

14. Install bearing (A) with sealed side of bearing toward middle of armature on commutator end of armature using 27491 1/2 in. driver disk from D01045AA Bushing, Bearing and Seal Drive Set. Drive only on the inner race. Install bearing until tight against shoulder of shaft.

A—Bearing



Install Bearing

RW10071 -UN-10NOV89

65
15
13

RG,RG34710,2326 -19-15MAR97-8/8

Inspect Brushes and Brush Holder

1. Measure negative brushes mounted on brush holder. If worn below specification, replace the brush holder assembly.

Specification

Negative Brushes—Minimum
Length..... 9.0 mm (0.35 in.)



Measure Negative Brushes

RW10072 -UN-10NOV89

Continued on next page

RG,RG34710,2327 -19-15MAR97-1/4

2. Measure the field coil brushes attached to the field frame assembly. If worn below specified length, replace the entire field frame assembly.

Specification

Field Coil Brushes—Minimum
Length..... 12.7 mm (0.500 in.)



RW10073 -UN-10NOV89

Measure Field Coil Brushes

RG,RG34710,2327 -19-15MAR97-2/4

3. Test the brush holder using an ohmmeter as shown, or a test light. Place one lead of tester to the negative brush holder and the other lead to field brush holder. If there is continuity (needle movement), replace the brush holder.



RW10074 -UN-10NOV89

Test Brush Holder with Ohmmeter

Continued on next page

RG,RG34710,2327 -19-15MAR97-3/4

4. Check the brush springs to be sure they are not weak or distorted. Replace as necessary.
5. Remove spring using a pair of needle nose pliers. Raise brush end of spring from holder and pry spring upward from lug on holder with a screwdriver.
6. To install, start spring on lug and wind spring so brush end of spring fits in brush holder, while at the same time pushing the spring on the lug.



Check Brush Springs

RW10075 -UN-10NOV89

65
15
15

RG, RG34710, 2327 -19-15MAR97-4/4

Inspect Field Coils

1. Check for grounded field winding using an ohmmeter as shown, or a test light. Touch one lead to a field coil brush and the other lead to the field frame. Be sure the brush lead is not touching the frame. If there is continuity (needle movement), the coil is grounded and the field frame assembly must be replaced.



Check for Grounded Field Winding

RW10076 -UN-10NOV89

Continued on next page

RG, RG34710, 2328 -19-12SEP02-1/2

2. Check for open field coil using an ohmmeter as shown, or a test light. Touch a lead to each field coil brush. If there is no continuity (no needle movement), the field coil is open and the field frame assembly must be replaced.



RW10077 -UN-10NOV89

Check for Open Field Coil

RG,RG34710,2328 -19-12SEP02-2/2

Assemble Field Frame, Armature, and Brush Holder

1. Place armature in field frame assembly and place in vise.
2. Lift the two negative brush springs away and pull brushes back about 6 mm (0.250 in.). Release the spring to lock the brushes in the outward position.
3. Place brush holder on armature and frame assembly.



RW10095 -UN-10NOV89

Field Frame, Armature and Brush Holder

Continued on next page

RG,RG34710,2329 -19-15MAR97-1/5

4. Lift two field coil brush springs away from holder and place brushes (A) in holders. Allow springs to hold brushes against commutator.
5. Push negative brushes inward to allow springs to hold brushes against commutator.

A—Brushes



Place Brushes in Holders

RW10067 -UN-10NOV89

65
15
17

RG, RG34710, 2329 -19-15MAR97-2/5

6. Apply a small amount of Delco-Remy Lubricant No. 1960954, or equivalent, to the open side of the brush end bearing.
7. Install brush end cap in place and install and tighten two screws from brush end cap to field frame assembly.



Install Brush End Cap


RW10059 -UN-10NOV89

Continued on next page

RG, RG34710, 2329 -19-15MAR97-3/5

8. Apply a small amount of Delco-Remy Lubricant No. 1960954, or equivalent, to the open side of the drive end bearing.
9. Install felt washer (A) in place on armature shaft.
10. Align indexing slot in solenoid frame (B) with flange on lip of field frame assembly (C).

NOTE: Some starter motors may have a small-square shaped locking key which fits into the cast slot (B) in solenoid frame.




RW10078 -UN-10NOV89

Install Felt Washer

- A—Felt Washer
- B—Indexing Slot
- C—Field Frame Assembly

RG, RG34710, 2329 -19-15MAR97-4/5

11. Install field frame assembly to motor frame.
12. Install and tighten two through bolts (B).
13. Connect field lead (A) to solenoid.
14. Bench test the repaired starter motor as instructed earlier in this group.
15. If bench tests indicate that the starter motor is working, install starter motor on engine as instructed in machine technical manual.



RW10058 -UN-10NOV89

Connect Field Lead to Solenoid


- A—Field Lead
- B—Through Bolts (2 Used)

RG, RG34710, 2329 -19-15MAR97-5/5

Disassemble Gear Train and Overrunning Clutch

1. Disassemble the field frame assembly from the housing as previously instructed in this group.
2. Remove three screws (A) and separate gear train assembly from motor frame.

A—Screws (3 Used)




Remove Screws

RW10062 -UN-10NOV89

65
15
19

RG,RG34710,2330 -19-15MAR97-1/6

3. Place gear assembly in a soft-jaw vise as shown. Be sure rear vise jaw is against shaft and front jaw is against pinion.
4. Slowly tighten vise until pinion compresses.



Compress Pinion

R30383 -UN-12FEB90


Continued on next page

RG,RG34710,2330 -19-15MAR97-2/6

5. Drive back retainer (B) until snap ring is exposed, using a short length of 5/8 in. ID pipe (A).
6. Remove snap ring and retainer from pinion shaft.

! **CAUTION: Shaft could be propelled from clutch unit with considerable force, if spring is not allowed to extend fully while in vise.**

7. Slowly open vise until all spring tension is relieved and remove gear assembly from vise.




Remove Snap Ring and Retainer

A—5/8 in. ID Pipe
B—Retainer

RG, RG34710, 2330 -19-15MAR97-3/6

8. Remove drive pinion from shaft.
9. Remove shaft with springs (A) and clutch unit (B) from housing.

A—Shaft with Springs
B—Clutch Unit




Remove Shaft

Continued on next page

RG, RG34710, 2330 -19-15MAR97-4/6

10. Inspect all parts for wear or damage. Replace as necessary.
11. If clutch unit (E) is defective, the entire unit must be replaced.

- A—Shaft
- B—Spring
- C—Spring
- D—Retainer
- E—Clutch Unit



Inspect Parts for Wear or Damage


RW10081 -UN-10NOV89

65
15
21

RG, RG34710, 2330 -19-15MAR97-5/6

12. Remove the starter pinion (B), needle roller retainer (D) with six needle rollers (C), and thrust washer (A) from housing.
13. Remove the spring (E) from the solenoid plunger.
14. Inspect all parts for wear or damage. Replace as necessary.

- A—Thrust Washer
- B—Pinion
- C—Needle Rollers (6 used)
- D—Needle Roller Retainer
- E—Solenoid Plunger Spring
- F—Solenoid Housing



Inspect Parts

RW10082 -UN-10NOV89


RG, RG34710, 2330 -19-15MAR97-6/6

Assemble Gear Train and Overrunning Clutch

NOTE: Use Delco-Remy No. 1960954 Lubricant or a similar lubricant when assembling starter motor.

1. Make sure the solenoid plunger ball (A) is in place in the shaft bore (B). Apply a light coat of grease to the ball to hold in place.

A—Solenoid Plunger Ball
B—Shaft Bore



Solenoid Plunger Ball in Shaft Bore


RW10079 -UN-10NOV89

RG, RG34710, 2331 -19-15MAR97-1/7

NOTE: Lubricate the shaft lightly with lubricant before installing springs.

2. First place the long spring (B) on the pinion shaft, then the short spring (C), and spring retainer (D).
3. Install pinion shaft assembly into clutch unit (E), as shown.

A—Pinion Shaft
B—Spring
C—Spring
D—Spring Retainer
E—Clutch Unit



Install Pinion Shaft Assembly into Clutch Unit


RW10081 -UN-10NOV89

Continued on next page

RG, RG34710, 2331 -19-15MAR97-2/7

4. Install clutch unit (B) with pinion shaft assembly (A) into housing.

A—Pinion Shaft Assembly
B—Clutch Unit



Clutch Unit with Pinion Shaft Assembly


RW10080 -UN-10NOV89

65
15
23

RG, RG34710, 2331 -19-15MAR97-3/7

5. Make sure retaining ring (A) is in drive pinion and is not worn or damaged.

A—Retaining Ring




Retaining Ring

RW10083 -UN-10NOV89

Continued on next page

RG, RG34710, 2331 -19-15MAR97-4/7

6. Lightly lubricate the pinon shaft and install drive pinion (A) onto pinion shaft, as shown, with large flange to the outside of clutch.
7. Place gear assembly in a soft jaw vise, as shown. Be sure rear vise jaw is against shaft and front jaw is against pinion.
8. Slowly tighten vise until pinion compresses enough to allow installation of retainer and retaining ring.
9. Install retainer (B) and snap ring (C) and remove from vise. Make sure snap ring is seated in retainer.




RW10084 -UN-10NOV89

Install Retainer and Snap Ring

- A—Drive Pinion
- B—Retainer
- C—Snap Ring

RG, RG34710, 2331 -19-15MAR97-5/7

10. Apply a thin coating of lubricant to the thrust washer (A) and install on shaft.
11. Apply a thin coating of lubricant to the needle rollers (C) and install them into retainer (D).
12. Install the needle roller retainer with needle rollers into the starter pinion (B).
13. Place the pinion assembly onto the shaft with the open side of the retainer facing the thrust washer.
14. Install spring (E) on solenoid plunger.



RW10082 -UN-10NOV89

Components


- A—Thrust Washer
- B—Pinion
- C—Needle Rollers (6 used)
- D—Needle Roller Retainer
- E—Solenoid Plunger Spring
- F—Solenoid Housing

Continued on next page

RG, RG34710, 2331 -19-15MAR97-6/7

15. Assemble gear train assembly to frame and install and tighten three screws (A).
16. Assemble field frame assembly to housing and bench test the starter as previously instructed in this group.

A—Screws (3 Used)



Screws

RW10062 -UN-10NOV89


65
15
25

RG, RG34710, 2331 -19-15MAR97-7/7

Disassemble, Inspect, and Repair Starter Solenoid

1. Remove starter motor from engine.
2. Disconnect field frame lead (A).
3. Remove three screws (B) and remove solenoid cover and gasket.

A—Field Frame Lead
B—Screws (3 Used)



Remove Solenoid Cover and Gasket


RW10086 -UN-10NOV89

Continued on next page

RG, RG34710, 2332 -19-15MAR97-1/3

4. Remove plunger (A).

A—Plunger



RW10087 -UN-10NOV89

Remove Plunger

65
15
26

RG, RG34710, 2332 -19-15MAR97-2/3

5. Remove plunger spring (A).

A—Plunger Spring




RW10088 -UN-10NOV89

Remove Plunger Spring

RG, RG34710, 2332 -19-15MAR97-3/3

Assemble Solenoid Assembly



Exploded View of Solenoid Assembly

A—Screw (3 Used)	E—Bolt	H—Nut (2 Used)	K—Solenoid Housing
B—Solenoid Cover	F—Plate (2 Used)	I—Special Washer (2 Used)	L—Bolt
C—Gasket	G—Bushing (2 Used)	J—Bushing	M—Plunger Spring
D—Plunger			

1. Inspect all solenoid components shown and replace as necessary if broken or worn.
2. The complete solenoid housing must be replaced if there is a solenoid problem other than the loose parts shown.

Continued on next page


RG, RG34710, 2333 -19-15MAR97-1/4

65
15
27

RW10085L -UN-29NOV89

3. Place plunger spring (A) in housing.

A—Plunger Spring




Plunger Spring

RW10088 -UN-10NOV89

RG, RG34710, 2333 -19-15MAR97-2/4

4. Place solenoid plunger (A) into spring in housing.

A—Plunger



Solenoid Plunger


RW10087 -UN-10NOV89

Continued on next page

RG, RG34710, 2333 -19-15MAR97-3/4

5. Carefully inspect gasket and replace if hard and brittle or torn.
6. Install solenoid cover and gasket onto solenoid housing and install and tighten three screws (B).
7. Connect field frame lead (A).

A—Field Frame Lead
B—Screws (3 Used)



Connect Field Frame Lead

RW10086 -JN-10NOV89

65
15
29

RG, RG34710, 2333 -19-15MAR97-4/4

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000B9B -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JN-12DEC88

65
20
1

OUO1004.0000B9B -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000B9B -19-08MAY02-3/3

Other Material

Number	Name	Use
	Mineral Spirits	Clean armature, solenoid and brushes.
	00 Sandpaper	Clean commutator.
	Moribten Grease 7129 or equivalent	Lubricate various components.

OUO1004,0000B9D -19-25SEP00-1/1

John Deere/Denso Planetary Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	26 mm (1.02 in.)
Used Brush	Minimum Length	18 mm (0.71 in.)
Brush Spring	Minimum Tension	26.5 N (6.0 lb-force)
Brush Lead Screws	Torque	2.2—3.4 N•m (19.4—30.1 lb-in.)
Drive End Housing-to-Center Housing Cap Screws	Torque	17.6—25.4 N•m (13.0—18.7 lb-ft)
Rear End Cover to Field Frame Bolts (M8)	Torque	26.5—29.4 N•m (19.5—21.7 lb-ft)
Brush Holder Assy to Rear Cover Nut (Ground Terminal) (1/2 in.)	Torque	27.5—33.3 N•m (20.3—24.5 lb-ft)
Brush Holder Assy to Rear Cover Nut (1/4 in.)	Torque	3.2—4.4 N•m (28.3—38.9 lb-in.)
Solenoid to Center Housing Cap Screws (M6)	Torque	10.5—14.5 N•m (7.7—10.7 lb-ft)
"M" Terminal Nut (1/2 in.)	Torque	19.6—29.4 N•m (14.4—21.7 lb-ft)
Shunt Field Terminal Nut (Yoke) (M5)	Torque	2.94—4.71 N•m (26.0—41.6 lb-in.)

OUOD006,000004B -19-08JUL02-1/1

John Deere/Denso Planetary Starter Motor Test Specifications

John Deere Starter Motor Part No.	Denso Starter Motor Part No.	System Voltage	Rating Type	kW	Motor Voltage	No Load Test Current Draw Amps (Max.)	RPM (Min.)
RE506825	428000-0120	12	P	5.0	11.5	200	2000
RE506826	428000-0130	24	P	8.0	23.5	120	2000

OUOD006,000004C -19-07JUL05-1/1

Test Starter Motor Before Disassembly

IMPORTANT: Never operate starter motor more than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating, caused by excessive operation, will seriously damage starter motor.

1. Turn overrunning clutch drive by hand. Clutch drive should turn freely on shaft in overrunning direction only.



Turn Overrunning Clutch Drive

RG12475 -UN-05JUL02

OUOD006,0000043 -19-05JUL02-1/2

2. Turn armature by prying against pinion with screwdriver. Check for dragging armature, seized bushings, or bent shaft.

If you discover any interference, disassemble and repair starter motor.

IMPORTANT: Do not conduct the no-load test unless armature turns freely. Damage to the starter motor may result.



Turn Armature

RG12476 -UN-05JUL02

OUOD006,0000043 -19-05JUL02-2/2

Make Solenoid Pull-In Test


IMPORTANT: To prevent damage, solenoid must be on starter motor when testing the windings.

IMPORTANT: To prevent solenoid switch winding from burning, disconnect leads as soon as pinion is at stop. Do not test for more than 3 to 5 seconds.

Make connections as shown, using heavy wire. (Current through wire will be approximately 90 amps.)

NOTE: "50" terminal is terminal for lead from the starting switch.

With 8 volts applied to a 12 volt starter, or 16 volts applied to a 24 volt starter, solenoid should pull the pinion in to the pinion stop and slowly rotate.



Make Connections


A—Ground Terminal
B—"50" Terminal

RG12548 -UN-06AUG02

OUOD006.0000044 -19-05JUL02-1/2

If solenoid does not engage, remove solenoid (See Steps 1 through 4 of "Disassemble Starter Motor" on following pages), and manually move shift lever (A) back and forth. If lever moves smoothly, pull-in winding is defective and solenoid must be replaced. If not, disassemble and repair starter.

A—Shift Lever



Move Shift Lever


RG12481 -UN-05JUL02

OUOD006.0000044 -19-05JUL02-2/2

Make Solenoid Hold-In Test

After pull-in test, remove the field connector (A). With connections as shown on the previous page for the solenoid pull-in test, and the pinion in the extended position, the pinion should remain in the jumped out (extended) position with a minimum of 3 volts applied for a 12 volt system, or 6 volts for a 24 volt system. If the pinion does not remain in the jumped out position, the hold-in winding or the shunt field winding is defective.

A—Field Coil Connector



Remove Field Coil Connector

RG12478 -JUN-05JUL02

OUOD006,0000061 -19-20AUG02-1/2

65
20
5


Perform continuity check on hold-in winding and on shunt field winding to determine which is defective (open).

Disconnect power source.

Disconnect shunt field winding lead (A).

Hold-in Winding Check: Connect ohmmeter between "50" terminal (B) and shunt field winding terminal (C) on solenoid. If check indicates hold-in winding is open, replace solenoid.

Shunt Field Winding Check: Connect ohmmeter between shunt field winding terminal (D) at yoke and ground terminal (E). If check indicates shunt field winding is open, the field coils are defective and the starter must be replaced .



Perform Continuity Checks

- A—Shunt Field Winding Lead
- B—"50" Terminal
- C—Shunt Field Winding Terminal (Solenoid)
- D—Shunt Field Winding Terminal (Yoke)
- E—Ground Terminal


RG12563 -JUN-22AUG02

OUOD006,0000061 -19-20AUG02-2/2

Make Return Test

After hold-in test, connect jumper wire from battery to motor ("M") terminal (C), and disconnect the "50" terminal (B) jumper wire. The pinion should return immediately.

- A—Ground Terminal
- B—"50" Terminal
- C—Motor ("M") Terminal



RG12562 -UN-22AUG02

Return Test Connections


OUOD006.0000062 -19-20AUG02-1/1

65
20
6

Make No-Load Test

1. Fasten starter in a vise and, using ammeter (A) (capable of measuring several hundred amps), connect the positive lead of battery (B) to plus (+) terminal of ammeter.
2. Connect ammeter negative (-) terminal to solenoid's "B" (battery) terminal (D). Also connect "50" terminal (F) through switch (E) to positive lead of battery.
3. Connect battery negative (-) lead to ground terminal (C).

Starter should show smooth and steady rotation immediately after pinion jumps out, and should draw less than specified current. (Refer to "Test Specifications" at beginning of this group.)



RG12549 -UN-20AUG02

Make Connections

- A—Ammeter
- B—Battery
- C—Ground Terminal
- D—"B" (Battery) Terminal
- E—Switch
- F—"50" Terminal

RG, RG34710, 2297 -19-20AUG02-1/1

Diagnose No-Load Test

Fails to Operate-Low Current Draw (Approx. 25 Amps)

Open series field circuit.

Open armature coils.

Defective brush contact with commutator.

Fails to Operate-High Current Draw

Grounded terminal or fields.

Seized bearings.

Low Speed-Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed-High Current Draw

Excessive friction

Shorted armature

Grounded armature or fields.

High Speed-Low Current Draw

Open shunt field circuit.

High Speed-High Current Draw

Shorted series field coils.

RG, RG34710, 2298 -19-15MAR97-1/1


65
20
7

Disassemble Starter Motor

NOTE: Starter motor has metric bolts and nuts except for those on switch cover.

1. Remove shunt field winding lead (A) from terminal on field frame (if not previously removed).

A—Shunt Field Winding Lead




Remove Shunt Field Winding Lead

Continued on next page

OUOD006,0000045 -19-05JUL02-1/11

2. Remove field coil connector (A) (if not previously removed).

A—Field Coil Connector



RG12478 -UN-05JUL02


Remove Field Coil Connector

OUOD006,0000045 -19-05JUL02-2/11

3. Remove solenoid cap screws (A).

IMPORTANT: Whenever starter motor is disassembled, for any reason, lubricate as follows: Apply a coat of Moribten Grease 7129 or equivalent to both end bearings. Grease overrunning clutch, planetary shaft, planetary gears, solenoid plunger, both ends of shift lever, wear pads and shift lever pivot shaft.

A—Solenoid Cap Screw (2 used)



RG12479 -UN-05JUL02


Solenoid Cap Screws

Continued on next page

OUOD006,0000045 -19-05JUL02-3/11

4. Remove solenoid from center bearing housing by lifting plunger shaft (A) up and away from shift lever.

A—Plunger Shaft



Lift Plunger Shaft


RG12480 -JUN-05JUL02

65
20
9

OUOD006,0000045 -19-05JUL02-4/11

5. Remove nuts (A), lock washers (B), flat washers (C) and fiber washers (D) from small and large studs in rear end frame cover.
6. Remove two bolts (E).
7. Remove rear end frame cover.

A—Nut
B—Lock Washer
C—Flat Washer
D—Fiber Washer
E—Bolt (2 used)



Remove End Frame Cover

RG12482 -JUN-05JUL02

Continued on next page

OUOD006,0000045 -19-05JUL02-5/11


8. Inspect brush leads (A) for fraying or corrosion.

NOTE: If only new brushes are going to be installed, it isn't necessary to remove the commutator end frame.

9. Inspect rear cover O-ring (B) for wear.

10. Inspect O-rings (C) and bushings (D) on small and large studs.

- A—Brush Leads (8 used)
- B—O-Ring
- C—O-Rings
- D—Bushings




RG12483 -UN-05JUL02

Inspect Brush Leads, O-Rings and Bushings

OUOD006,0000045 -19-05JUL02-6/11

11. Remove brush lead screws (A).

- A—Brush Lead Screw (4 used)



RG12484 -UN-05JUL02


Remove Brush Lead Screws

Continued on next page

OUOD006,0000045 -19-05JUL02-7/11

12. Pull brush spring (A) back and remove brush (B).

- A—Brush Spring (4 used)
- B—Brush (4 used)



Remove Brushes

RG12485 -UN-05JUL02

65
20
11

OUOD006,0000045 -19-05JUL02-8/11


13. Remove snap ring and shift lever pivot (A).

NOTE: Before removal of drive end housing, place alignment marks on drive end housing and center bearing housing for aid in reassembly.

14. Remove drive end housing hex head bolts (B).

15. Remove drive end housing (C).

- A—Shift Lever Pivot
- B—Hex Head Bolt (6 used)
- C—Drive End Housing



Remove Drive End Housing


RG12486 -UN-05JUL02

Continued on next page

OUOD006,0000045 -19-05JUL02-9/11

16. Use a pipe coupling (A) or other metal cylinder to drive pinion stop (B) toward pinion.
17. Remove retaining ring and slide pinion stop off shaft.

A—Pipe Coupling
B—Pinion Stop




Slide Pinion Stop

R26558 -UN-09FEB90

OUOD006.0000045 -19-05JUL02-10/11

18. Carefully remove overrunning clutch (A), shift lever (B), and wear pads (C) from center bearing housing and armature shaft. Inspect wear pads for excessive wear or damage. Replace wear pads if necessary.

A—Overrunning Clutch
B—Shift Lever
C—Wear Pads




Inspect for Damage

RG12550 -UN-06AUG02

OUOD006.0000045 -19-05JUL02-11/11

65
20
13

John Deere/Denso Planetary Starter Motor Exploded View



Starter Motor Components (12 Volt Model Illustrated)

RG12492 -UN-20AUG02

Continued on next page

OUOD006.000004D -19-08JUL02-1/2

1—Yoke Assembly	9—Solenoid Switch Assembly	15—O-Ring	31—Washer
1-1—Terminal	9-1—Plunger Cover	16—O-Ring	32—Washer
2—Armature Assembly	9-2—Connecting Wire	17—Snap Ring	33—Washer
2-1—Bearing	9-3—Lock Washer, M5 (4 used)	18—Bolt, M6x40.5 (2 used)	34—Brush Screw (4 used)
3—Overrunning Clutch	9-4—Nut, M5 (3 used)	19—Bolt, M7x26.5 (6 used)	35—Fiber Washer
4—Drive End Housing Assembly	9-5—Bolt	20—Planetary Gear (3 used)	36—Nonferrous Metal Bushing
4-1—Needle Bearing	9-6—Nut, U4.83	21—Seal	37—O-Ring (ID12.3)
5—Center Bearing Assembly	9-7—Terminal	22—Internal Gear	38—Washer (4 used)
5-1—Bearing (Not shown)	9-8—Lock Washer (2 used)	23—O-Ring (ID 105) (2 used)	39—Flat Washer
5-2—Seal	9-9—Nut (2 used)	24—Ball	40—Nut, U12.7 (2 Used)
5-3—Gasket	10—Pinion Stop Collar	25—Bolt (2 used)	41—Lock Washer
5-4—Bolt (2 used)	11—Snap Ring	26—Fiber Washer	42—Lock Washer
5-5—Washer (2 used)	12—Planetary Shaft	27—Nonferrous Metal Bushing	43—Flat Washer
6—Frame Assembly	13—Shift Lever Assembly	28—Nut	44—Wave Washer
7—Brush Holder Assembly	13-1—Shift Lever Ring (2 used)	29—Washer (Thrust)	45—Seal
8—Brush (4 used)	14—Shift Lever Pin	30—Nut, M5	46—Terminal Insulation Cover

OUOD006,000004D -19-08JUL02-2/2

65
20
15

Clean Starter Motor Components

IMPORTANT: Do not immerse the solenoid, field windings, or armature in cleaning solvent because it may damage the insulation.

1. Clean parts by wiping with a cloth or brush, moistened with mineral spirits.
2. Dry with compressed air.

3. Clean the drive end housing, overrunning clutch, center bearing housing, and commutator end frame the same way.

All other parts which are not made of rubber or mentioned previously, can be dipped in cleaning solvent to remove all oil and dirt.

RG, RG34710, 2301 -19-15MAR97-1/1

Inspect and Repair Brushes

Replace brushes if they are oil soaked, worn, damaged, or worn beyond specification.

Specification

New Brush—Length 26 mm (1.02 in.)
Used Brush—Minimum Length 18 mm (0.71 in.)

If brushes are burned or rough, use 00 sandpaper to clean commutator contact area of brushes. Never use emery cloth. Clean all dust from brush before reassembly.

65
20
16


OUOD006.000004E -19-08JUL02-1/1

Test Brush Holder for Grounds

1. Set ohmmeter on its highest scale.
2. Place one test lead on commutator end frame (A).
Place other lead on positive brush holder (B).

If needle swings toward zero, the positive brush holder is grounded and should be replaced.

A—Commutator End Frame
B—Brush Holder



Test Brush Holder for Grounds

RG12487 -UN-05JUL02

OUOD006.0000046 -19-08JUL02-1/1

Measure Brush Spring Tension

Measure spring tension at end of brush spring (A) with a spring scale.

Brush spring tension should be specified just as the spring leaves the brush holder.

Specification

Brush Spring—Minimum Tension..... 26.5 N (6.0 lb-force)

When measuring tension, scale should be parallel with edge of brush holder.

A—Brush Spring



Measure Brush Spring Tension

RG12488 -JUN-05JUL02

65
20
17


OUOD006,0000047 -19-08JUL02-1/1

Assemble Starter Motor

1. Lubricate both ends of shift lever (B), wear pads (C) on overrunning clutch (A), with a multi-purpose lubricant.

NOTE: Avoid excessive lubrication.

A—Overrunning Clutch
B—Shift Lever
C—Wear Pads



Assemble Starter Motor


RG12550 -JUN-06AUG02

OUOD006,0000048 -19-08JUL02-1/9

2. Place shift lever and overrunning clutch (A) up into center bearing housing (B).

NOTE: Do not expand snap ring more than 8 mm (0.3 in.) during shift lever pivot installation.

3. Install shift lever pivot (C) with snap ring.
4. Lubricate bearing in center bearing housing generously, but not excessively, with Moribten Grease 7129 or equivalent.
5. Inspect black dust seal (D) around clutch barrel.



Install and Inspect

A—Overrunning Clutch
B—Center Bearing Housing
C—Shift Lever Pivot
D—Dust Seal

RG12489 -JUN-05JUL02


Continued on next page

OUOD006,0000048 -19-08JUL02-2/9

6. Carefully install armature into center housing.
7. Place center bearing housing with overrunning clutch assembly (A) onto armature shaft (B) and field frame.

Make sure O-ring in center bearing housing is not twisted or crimped when placed against field frame.

8. Slide pinion stop (C) over retaining ring (D) using a washer (E) and two pair of pliers.
9. Remove washer.



Install Center Housing

- A—Overrunning Clutch Assembly
- B—Armature Shaft
- C—Pinion Stop
- D—Retaining Ring
- E—Washer (remove after using)

RG12551 -UN-06AUG02


OUOD006.0000048 -19-08JUL02-3/9

10. Align marks made during disassembly and install drive end housing (A) against center bearing housing using hex head bolts (B).
11. Tighten drive end hex head bolts (B) to specifications.

Specification

Drive End Housing-to-Center
Housing Cap Screws—Torque..... 17.6—25.4 N•m (13.0—18.7 lb-ft)

- A—Drive End Housing
- B—Hex Head Bolts



Install Drive End Housing

RG12491 -UN-08JUL02

Continued on next page


OUOD006.0000048 -19-08JUL02-4/9

12. Place commutator end frame over armature.

NOTE: Be sure commutator end frame notches fit correctly in field frame.

13. Raise brush springs (A) and install brushes (B).

- A—Brush Springs (4 used)
- B—Brushes (4 used)



Install Brushes

RG12485 -JUN-05JUL02

65
20
19

OUOD006,0000048 -19-08JUL02-5/9

14. Twist brush screws 180 degrees so they cross as shown.


15. Press brush into brush holder so brush spring is fully seated on top of brush.

16. Install brush lead screws (A) and tighten to specifications.

NOTE: Make sure field winding lead and shunt winding leads are tightened down with the brush lead screws.

Specification

Brush Lead Screws—Torque 2.2—3.4 N•m (19.4—30.1 lb-in.)



Install Brush Lead Screws

RG12484 -JUN-05JUL02


A—Brush Lead Screw (4 used)

Continued on next page

OUOD006,0000048 -19-08JUL02-6/9

17. Before rear cover installation, verify brush leads (A) are installed as illustrated.
18. Check that rear cover O-ring (B), and stud O-rings (C) and bushings (D) are in good condition and are properly installed.

A—Brush Leads
B—Rear Cover O-Ring
C—Stud O-Rings
D—Stud Bushings



Before Cover Installation

RG12490 -JUN-06AUG02

OUOD006.0000048 -19-08JUL02-7/9

19. Install thrust washer (A) in rear end frame.

A—Thrust Washer



Thrust Washer

RG12552 -JUN-07AUG02

Continued on next page

OUOD006.0000048 -19-08JUL02-8/9

20. Place rear end frame cover onto field frame.
21. Fasten end frame cover with two bolts (E). Tighten to specifications.


Specification

Rear End Frame Cover to Field
 Frame Bolts (M8)—Torque..... 26.5—29.4 N•m (19.5—21.7 lb-ft)

22. Install fiber washers (D) on brush holder assembly studs, followed by flat washers (C) and lock washers (B). Tighten nuts (A) to specifications.

Specification

Brush Holder Assy to Rear Cover
 Nut (Ground Terminal) (1/2 in.)—
 Torque 27.5—33.3 N•m (20.3—24.5 lb-ft)
 Brush Holder Assy to Rear Cover
 Nut (1/4 in.)—Torque..... 3.2—4.4 N•m (28.3—38.9 lb-in.)



Rear End Frame Cover

- A—Nuts
- B—Lock Washers
- C—Flat Washers
- D—Fiber Washers
- E—Bolt (2 used)

RG12482 -JUN-05JUL02

65
20
21

OUID006,0000048 -19-08JUL02-9/9

Install Solenoid

1. Install solenoid plunger shaft (A) up onto shift lever.

A—Solenoid Plunger Shaft



Solenoid Plunger Shaft

RG12480 -JUN-05JUL02

Continued on next page


OUID006,0000049 -19-08JUL02-1/4

2. Push solenoid assembly forward up against center bearing housing.
3. Attach solenoid with solenoid cap screws (A). Tighten to specifications.

Specification

Solenoid Cap Screws—Torque 10.5—14.5 N•m (7.7—10.7 lb-ft)

A—Solenoid Cap Screws



Solenoid Cap Screws

RG12479 -UN-05JUL02


OUOD006.0000049 -19-08JUL02-2/4

4. Install field coil connector (A). Tighten motor ("M") terminal nut to specifications.

Specification

Motor ("M") Terminal Nut—
Torque 19.6—29.4 N•m (14.4—21.7 lb-ft)

A—Field Coil Connector



Install Field Coil Connector

RG12478 -UN-05JUL02

Continued on next page

OUOD006.0000049 -19-08JUL02-3/4


5. Install shunt lead (A). Tighten nut to specifications.

Specification

Shunt Field Lead Nut (Yoke)
 (M5)—Torque 2.94—4.71 N•m (26.0—41.6 lb-in.)

6. Install terminal cover on solenoid. (Not shown).

A—Shunt Lead



Install Shunt Lead

RG12477 -UN-05JUL02


65
20
23

OUID006,0000049 -19-08JUL02-4/4

Make No-Load Test

1. Fasten starter in a vise and, using ammeter (A) (capable of measuring several hundred amps), connect the positive lead of battery (B) to plus (+) terminal of ammeter.
2. Connect ammeter negative (-) terminal to solenoid's "B" (battery) terminal (D). Also connect "50" terminal (F) through switch (E) to positive lead of battery.
3. Connect battery negative (-) lead to ground terminal (C).

Starter should show smooth and steady rotation immediately after pinion jumps out, and should draw less than specified current. (Refer to "Test Specifications" at beginning of this group.)



Make Connections

- A—Ammeter
- B—Battery
- C—Ground Terminal
- D—"B" (Battery) Terminal
- E—Switch
- F—"50" Terminal

RG12549 -UN-20AUG02

RG, RG34710, 2297 -19-20AUG02-1/1

Section 70

Bosch Starter Motors

Contents

	Page	Page
Group 05—Starting Circuit Theory of Operation		
General Information	70-05-1	
Typical Starting Circuit Operation	70-05-1	
Typical Starter Motor Operation	70-05-2	
Group 10—Bosch Conventional Starter Motor Repair		
Essential Tools	70-10-1	
Bosch Conventional Starter Motor Repair		
Specifications	70-10-2	
Bosch Conventional Starter Motor Test		
Specifications	70-10-3	
Make No-Load Test	70-10-4	
Diagnosing Starter Motor Malfunctions	70-10-5	
Bosch Conventional Starter Motor		
Cutaway View	70-10-6	
Bosch Conventional Starter Motor		
Exploded View	70-10-7	
Disassembly	70-10-8	
Solenoid Switch—Removal	70-10-8	
Carbon Brush Plate—Removal	70-10-9	
Armature—Removal	70-10-9	
Snap Ring—Removal	70-10-10	
Cleaning Parts	70-10-10	
Testing Armature for Grounds	70-10-10	
Testing Armature for Short Circuit	70-10-11	
Testing Armature for Open Circuit	70-10-11	
Turning Commutator Down	70-10-12	
Testing Commutator for Out-of-Roundness	70-10-12	
Testing Field Winding for Grounded Circuit	70-10-13	
Field Winding—Removal	70-10-13	
Make Open Circuit Test for Field Windings	70-10-14	
Lubrication of Starter Motor (Before and		
During Assembly)	70-10-14	
Field Winding—Installation	70-10-15	
Checking Carbon Brush Plate for Grounds	70-10-15	
Testing Carbon Brushes	70-10-16	
Replace Carbon Brushes	70-10-16	
Engaging Lever—Installation	70-10-17	
Checking Armature End Play and Torque	70-10-17	
Installing Starter Motor	70-10-17	
Group 15—Bosch Planetary Gear Starter Motor Repair		
Essential Tools	70-15-1	
		70-15-2
		70-15-2
		70-15-3
		70-15-4
		70-15-5
		70-15-6
		70-15-7

70

General Information

IMPORTANT: Never operate starter motor longer than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

RG, RG34710, 2335 -19-15MAR97-1/1

Typical Starting Circuit Operation

When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) to ground.


Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

Light shunt windings (J) are wrapped together with two of the heavy field windings. Shunt windings are connected to solenoid switch terminal and directly to ground. They provide additional low-speed torque to assist engine rotation and prevent overspeeding of motor.

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).

Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Typical Starting Circuit


- A—Wire From Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

RG1313 -UN-20APR89

70
05
1

RG, RG34710, 2336 -19-15MAR97-1/1

Typical Starter Motor Operation



Typical Starter Motor Operation

- | | | | |
|------------------------|-------------------|-------------------|-----------------------|
| 1—Snap Ring | 7—Field Connector | 13—Field Windings | 19—Brake Washer |
| 2—Drive End Housing | 8—End Frame Cover | 14—Armature | 20—Wear Pads |
| 3—Shift Lever | 9—Brush | 15—Pole Shoe | 21—Overrunning Clutch |
| 4—Plunger | 10—Bushing | 16—Oil Seal | 22—Pinion Stop |
| 5—Shunt Field Terminal | 11—Thrust Washer | 17—Bushing | 23—Bushing |
| 6—Solenoid Assembly | 12—Commutator | 18—Felt | |

When solenoid (6) engages, it pulls shift lever (3). Shift lever pushes overrunning clutch drive (21) to engage pinion in starter gear on flywheel. As armature (14) turns, it cranks engine.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.

The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel. Brake washer (19) slows armature to a stop.

The main difference between a conventional starter (illustrated above) and a planetary gear reduction starter is the addition of a planetary gear system between the field frame and the drive end housing. The planetary gear system reduces motor speed while proportionally increasing its torque.

R25228 -UN-14NOV88

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000BA3 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

70
10
1

OUO1004.0000BA3 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000BA3 -19-08MAY02-3/3

Bosch Conventional Starter Motor Repair Specifications

Item	Measurement	Specification
Commutator (3.0 and 3.1 kW)	Minimum OD	42.5 mm (1.67 in.)
Commutator (2.7 kW)	Minimum OD	39.5 mm (1.555 in.)
Commutator	Insulation Undercut after Turning Down	0.5—0.8 mm (0.02—0.03 in.)
Commutator	Maximum Out-of-Round	0.03 mm (0.0012 in.)
Armature Plate Stacks	Maximum Out-of-Round	0.05 mm (0.002 in.)
Brushes	Minimum Length	7.5 mm (0.30 in.)
70 10 2 Armature	End Play	0.1—0.3 mm (0.004—0.012 in.)
Armature (2.7 kW)	Braking Torque	0.45—0.75 N•m (4.0—6.6 lb-in.)
	Overrunning Torque	0.40—0.55 N•m (3.5—4.8 lb-in.)
Armature (3.0 and 3.1 kW)	Braking Torque	0.5—1.2 N•m (4.42—10.62 lb-in.)
	Overrunning Torque	0.35—0.65 N•m (3.10—5.75 lb-in.)

OUO1004.0000BA6 -19-23JUL02-1/1

Bosch Conventional Starter Motor Test Specifications

John Deere Starter Motor Part No.	Bosch Starter Motor Model No.	System Voltage	Rating kW	No Load Test		
				Motor Voltage	Amps (Max.)	RPM
AL110503	0 001 367 078	12	3.0	11.5	130	7000
AL110504	0 001 369 022	12	3.1	11.5	170	8000
AL39700	0 001 369 001	12	3.1	9.0 Min	205	9400
AL41247	0 001 362 312	12	2.7	11.5	125	7000
AL62690	0 001 362 316	12	2.7	11.5	125	7000
AL62772	0 001 369 005	12	3.1	11.5	170	8000
AL78760	0 001 367 075	12	3.0	11.5	130	7000
AL81154	0 001 367 077	12	3.0	11.5	130	7000
AR70436	0 001 359 090	12	3.0	9.0 Min	190	7000
RE30493	0 001 362 324	12	2.7	11.5	125	7000
RE508922	6 004 AK3 014	12	2.2	10.5		
RE526375	0 001 B00 039	12	3.8	11.5	220	9000
RE527400	0 001 B00 039	12	3.8	11.5	220	9000
RE62448	0 001 369 012	12	3.1	11.5	170	8000
RE65169	0 001 369 021	12	3.1	11.5	170	8000


70
10
3

Item	Specification
Minimum voltage of solenoid	8 volts
Testing armature for grounded circuit, voltage	40 volts AC
Testing field coils for grounded circuit, voltage	40 volts AC
Testing field coils for open windings, voltage	6—12 volts DC
Testing brush holder insulation for grounded circuit, voltage	40 volts AC

RG, RG34710, 2339 -19-07JUL05-1/1

Make No-Load Test

1. Make connections as shown, and use an ammeter (A) capable of measuring several hundred amps.
2. Measure current draw in amps and compare with specifications given earlier in this group.
3. If speed and current draw are slightly low, connect a voltmeter between motor terminal and frame. Observe voltage during test. Voltage may be reduced because of high current draw on battery.
4. If speed or current draw is significantly different than specified, diagnose problem per chart which follows.



Make Connections

- A—Ammeter
- B—Battery
- C—Starter Frame
- D—Tachometer
- E—Battery Terminal
- F—Switch
- G—Field Coil Connector

RG11163 -JUN-28SEP00

RG, RG34710, 2340 -19-15MAR97-1/1

70
10
4

Diagnosing Starter Motor Malfunctions

Fails to Operate, No Current Draw

- Open field circuit (all field windings)
- Open armature windings
- Defective brush contact with commutator
- Open solenoid windings
- Defective solenoid contacts

Fails to Operate, High Current Draw

- Grounded field windings or armature windings
- Seized bearings

Low Speed, Low Current Draw

- High internal resistance
- Defective brush contact with commutator

Low Speed, High Current Draw

- Excessive friction
- Shorted armature
- Grounded armature or field windings


High Speed, High Current Draw

- Shorted field windings

NOTE: This test will not detect individual open-circuited field coils—the stator would have a slow cranking speed but would pass this test.

70
10
5

Bosch Conventional Starter Motor Cutaway View



Bosch Conventional Starter Motor

- | | | | |
|------------------------|-----------------|---------------------------------------|-------------------|
| A—Solenoid Switch | E—Commutator | I—Overrunning Clutch
(Roller-Type) | K—Drive Hub |
| B—Commutator End Frame | F—Field Winding | J—Pinion | L—Engaging Spring |
| C—Compression Spring | G—Field Frame | | M—Engaging Lever |
| D—Carbon Brush | H—Guide Ring | | |


L107 007

L107007 -UN-06APR89

RG.RG34710,2342 -19-23JUL02-1/1

70
10
6

Bosch Conventional Starter Motor Exploded View



L117559

Conventional Starter Motor—Exploded View

- | | | | |
|--------------------------|-------------------------------|---------------------------------|--------------------------------|
| 1—Starter Motor Assembly | 11—Pivot Screw | 19—Center Bearing | 28—Commutator End Frame |
| 2—Hex Nut | 12—Countersunk Screw (3 Used) | 20—Bushing | 29—Bushing |
| 3—Stud | 13—Drive End Frame Assembly | 21—Washer (2 Used) | 30—Carbon Brushes (Kit) |
| 4—Cap Screw | 14—Bushing | 22—Hex Nut (2 Used) | 31—Compression Spring (4 Used) |
| 5—Solenoid Switch | 15—Snap Ring | 23—Cylinder Head Screw (2 Used) | 32—Carbon Brush Plate |
| 6—Securing Clip | 16—Stop Ring | 24—Cover Cap | 33—Winding |
| 7—Cylinder Head Screw | 17—Bushing | 25—Rubber Ring | 34—Armature |
| 8—Hex Nuts (4 Used) | 18—Drive with Pinion | 26—Fixing Washer | 35—Stud (2 Used) |
| 9—Hex Nut | | 27—Shims | 36—Field Frame |
| 10—Engaging Lever | | | |

70
10
7

L117559 -JUN-02FEB89


Disassembly

NOTE: Not all parts for Bosch conventional and gear reduction starters are available through John Deere for service. Repair and test procedures provided in the following pages for other components are for reference only.

Unscrew cover cap (A) and remove fixing washer and shims. Be careful with rubber ring.

Remove hex nuts (B).

A—Cover Cap
B—Hex Nuts (2 Used)



Unscrew Cover Cap and Remove Hex Nuts


RG, RG34710, 2344 -19-26JUN02-1/1

Solenoid Switch—Removal

Disconnect wiring connection from solenoid switch.

Remove attaching screws (A) and pull out solenoid switch with pinion head.

A—Screws (3 Used)



Remove Attaching Screws


RG, RG34710, 2345 -19-15MAR97-1/1

Carbon Brush Plate—Removal

Carefully remove commutator end frame as shown.

NOTE: When removing commutator end frame, the brush compression springs may spring out of the brush holders.

Pull carbon brushes out of carbon brush plate and remove carbon brush plate from armature shaft.



Remove Commutator End Frame

L107010 -JUN-17JUL89


RG, RG34710, 2346 -19-15MAR97-1/1

70
10
9

Armature—Removal

Carefully pull armature with drive end frame assembly from field frame (do not damage windings).

Remove engaging lever and armature jointly out of drive end frame assembly.



Armature Removal

L107011 -JUN-17JUL89


RG, RG34710, 2347 -19-15MAR97-1/1

Snap Ring—Removal

Drive back stop ring (A) and bend open snap ring (B).

Remove drive with pinion and center bearing from armature shaft.

A—Stop Ring
B—Snap Ring



Snap Ring Removal

RG, RG34710, 2348 -19-15MAR97-1/1

Cleaning Parts

Wash parts in solvent and dry with compressed air.

NOTE: Armature, windings and drive with pinion must not be placed in cleaning fluid.

Inspect all parts for wear and mechanical damage.


RG, RG34710, 2349 -19-15MAR97-1/1

Testing Armature for Grounds

Set ohmmeter to read on highest scale.

Place one test lead on the armature core or shaft. Place other lead on commutator.

If the test meter indicator swings toward zero, the armature is grounded. Replace armature.



Test Armature for Grounds


RG, RG34710, 2350 -19-15MAR97-1/1

Testing Armature for Short Circuit

Place armature in a growler and hold hacksaw blade above each slot while slowly rotating the armature.

If coil is shorted, the blade will be attracted to and repelled from the slot.

Short circuit most often occurs because of copper dust or filings between two commutator segments. Clean commutator segments to correct this short.



RG78074C1 -JUN-09JAN90

Test Armature for Short Circuit

RG, RG34710, 2351 -19-15MAR97-1/1

70
10
11

Testing Armature for Open Circuit

Set ohmmeter to read on lowest scale.

Place one test lead on commutator segment. Place other test lead on an adjacent segment. Repeat this operation for all segments by moving one lead at a time.

If the test meter indicator does not swing to zero and remains stationary, the armature coil between these two segments is open. Replace armature.

RG, RG34710, 2352 -19-15MAR97-1/1

Turning Commutator Down


Check commutator OD and compare to specifications.

After turning the commutator down, undercut its insulation to specification with a commutator saw and then finish-turn.

Specification

Commutator (3.0 and 3.1 kW)—	
Minimum OD.....	42.5 mm (1.67 in.)
Commutator (2.7 kW)—Minimum	
OD.....	39.5 mm (1.555 in.)
Commutator—Insulation Undercut	
after Turning Down.....	0.5—0.8 mm (0.02—0.03 in.)

- A—Solenoid Lug
- B—Claw
- C—Turn Down Only to Here



Turning Commutator Down

L107016 -JUN-06APR89

RG, RG34710, 2353 -19-15MAR97-1/1


Testing Commutator for Out-of-Roundness

Check commutator out-of-round.

Specification

Commutator—Maximum	
Out-of-Round.....	0.03 mm (0.0012 in.)
Armature Plate Stacks—	
Maximum Out-of-Round.....	0.05 mm (0.002 in.)

Check armature once again for grounds and short circuits.



Test Commutator for Out-of-Roundness

L107017 -JUN-17JUL89

RG, RG34710, 2354 -19-15MAR97-1/1

Testing Field Winding for Grounded Circuit

Set ohmmeter to read on highest scale.

Place one test lead on a clean spot on field frame. Place other lead on brush lead.

If the ohmmeter indicator swings toward zero, a grounded circuit is indicated. Replace the field windings.



Test Field Winding for Grounded Circuits

L107018 -JUN-17JUL89


RG,RG34710,2355 -19-15MAR97-1/1

70
10
13

Field Winding—Removal

Mark position of pole shoes and winding ends and unscrew pole shoe screws (A).

A—Pole Shoe Screws



Unscrew Pole Shoe Screws

L107019 -JUN-17JUL89

RG,RG34710,2356 -19-15MAR97-1/1

Make Open Circuit Test for Field Windings


All four field windings are connected in parallel. Test each winding for an open circuit.

Connect a test battery (B) to field terminal (C) and either insulated brush lead (D), using a resistor (A) to limit current draw.

Use a hacksaw blade (E) to test winding for magnetism. If any winding is not magnetic, the winding is open circuited. Repair or replace windings.

NOTE: Because 1/4-ohm resistors capable of carrying several hundred watts are not widely available, a suggested alternative is to connect four 1-ohm resistors in parallel. Each resistor should be rated for at least 150 watts. A carbon pile resistor can also be used. Limit current to 40—70 amps.

There is no suitable way to check field windings for short circuits. Winding resistance is too low to permit detection of a short circuit.



L113431

L113431 -UN-02FEB89

Make Open Circuit Test for Field Windings

- A—1/4-Ohm Resistor
- B—12-Volt Battery
- C—Field Terminal
- D—Insulated Brush Lead
- E—Hacksaw Blade

RG, RG34710, 2357 -19-15MAR97-1/1

Lubrication of Starter Motor (Before and During Assembly)

Lubrication Point	Lubrication Instructions
Bushings	Soak new bushings for at least 1/2 hour before installation.
Armature shaft	Coat drive and commutator end journals of shaft, splines and bearing surfaces of clutch drive with a light film of grease.
Shift Lever	Lubricate bearing surfaces and pivot bolts liberally with grease.
Solenoid switch	Coat inside of yoke and bolt threads with a light film of grease.

NOTE: Keep contacts free from grease.

RG, RG34710, 2358 -19-15MAR97-1/1

Field Winding—Installation


Slightly warm windings and insert together with pole shoes into field frame. Insert pole shoe screws.

Press suitable mandrel (see illustration) between pole shoes.

Firmly tighten pole shoe screws and press out mandrel.

Check installed windings for shorted or open circuits.

- a—85 mm (3.35 in.)
- b—5° Chamfer
- c—12—14 mm (0.47—0.55 in.)
- d—75.80—75.85 mm (2.984—2.986 in.)
- e—Wall Thickness 12—15 mm (0.47—0.59 in.)



Field Winding Installation

RG, RG34710, 2359 -19-15MAR97-1/1


70
10
15

Checking Carbon Brush Plate for Grounds

Set ohmmeter on its highest scale.

Place one test lead on commutator end frame. Place other lead on brush holder.

If needle swings toward zero, the positive brush holder is grounded and should be replaced.



Check Carbon Brush Plate for Grounds

RG, RG34710, 2360 -19-15MAR97-1/1

L107020 -UN-17JUL89

Testing Carbon Brushes


The carbon brushes must move freely in their guides.

Check brush length and compare to specifications.

Brushes—Minimum Length 7.5 mm (0.30 in.)

Specification

a—Brush Length



Test Carbon Brushes

L107021 -UN-17JUL89

RG,RG34710,2361 -19-15MAR97-1/1

70
10
16

Replace Carbon Brushes


Cut off old brushes at end of brush strands.

Secure new brushes in bores (A).

Check for easy movement of carbon brushes in brush holders.

NOTE: Screws and hex nuts are included in the repair kit.

A—Brush Bores



Secure Brushes in Bores

L117234 -UN-17JUL89


RG,RG34710,2362 -19-15MAR97-1/1

Engaging Lever—Installation

Driving hub pins (B) of engaging lever (A) must engage in guide (C) of drive pinion.

Screw in studs and slide field frame over armature.

- A—Engaging Lever
- B—Pins
- C—Guide



Engaging Lever Installation

RG, RG34710, 2363 -19-15MAR97-1/1

70
10
17

Checking Armature End Play and Torque

Check end play of armature using a dial indicator.


Specification

Armature—End Play..... 0.1—0.3 mm (0.004—0.012 in.)

Check armature torque.

Specification

Armature (2.7 kW)—Braking
 Torque 0.45—0.75 N•m (4.0—6.6 lb-in.)
 Overrunning Torque 0.40—0.55 N•m (3.5—4.8 lb-in.)
 Armature (3.0 and 3.1 kW)—
 Braking Torque 0.5—1.2 N•m (4.42—10.62 lb-in.)
 Overrunning Torque 0.35—0.65 N•m (3.10—5.75 lb-in.)



Test Armature End Play

RG, RG34710, 2364 -19-25SEP00-1/1

Installing Starter Motor

Refer to machine technical manual for installing starter motor and adjusting belt tension.

RG, RG34710, 2365 -19-15MAR97-1/1

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUOD006,000004F -19-23JUL02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

70
15
1

OUOD006,000004F -19-23JUL02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUOD006,000004F -19-23JUL02-3/3


Bosch Planetary Gear Starter Motor Test Specifications

John Deere Starter Motor Part No.	Bosch Starter Motor Model No.	System Voltage	Rating kW	No Load Test		
				Motor Voltage	Amps (Max.)	RPM
RE500819	0 001 230 005	12	3.0	11.4	204	4735—6500
RE501347	0 001 223 502	12	2.6	11.4	142	5300
RE501551	0 001 230 008	12	3.0	11.4	204	4735—6500
RE503226	0 001 230 002	12	3.0	11.4	204	4735—6500
RE506589	0 001 230 003	12	3.0	11.4	204	4735—6500
RE507943	0 001 230 018	12	3.0	11.4	204	4735—6500

OUOD006,0000050 -19-07JUL05-1/1

Make No-Load Test

1. Make connections as shown, and use an ammeter (A) capable of measuring several hundred amps.
2. Measure current draw in amps and compare with specifications given earlier in this group.
3. If speed and current draw are slightly low, connect a voltmeter between motor terminal and frame. Observe voltage during test. Voltage may be reduced because of high current draw on battery.
4. If speed or current draw is significantly different than specified, diagnose problem per chart which follows.



Make Connections

- A—Ammeter
- B—Battery
- C—Starter Frame
- D—Tachometer
- E—Battery Terminal
- F—Switch
- G—Field Coil Connector

RG11163 -UN-28SEP00

RG, RG34710, 2340 -19-15MAR97-1/1

Diagnosing Starter Motor Malfunctions

Fails to Operate, No Current Draw

Open field circuit (all field windings)

Open armature windings

Defective brush contact with commutator

Open solenoid windings

Defective solenoid contacts

Fails to Operate, High Current Draw

Grounded field windings or armature windings

Seized bearings

Low Speed, Low Current Draw

High internal resistance

Defective brush contact with commutator

Low Speed, High Current Draw

Excessive friction

Shorted armature


Grounded armature or field windings

High Speed, High Current Draw

Shorted field windings

NOTE: This test will not detect individual open-circuited field coils—the stator would have a slow cranking speed but would pass this test.

Bosch Planetary Gear Starter Motor Cutaway View



Bosch Planetary Gear Starter Motor

- | | | | |
|---------------------|-----------------------------------|---------------|-------------------------|
| A—Drive End Housing | E—Commutator End Frame | H—Field Frame | K—Planetary Gear |
| B—Pinion | F—Brush Plate with Carbon Brushes | I—Armature | L—Shift Lever |
| C—Solenoid Switch | G—Excitation Winding | J—Pole Shoe | M—Pinion-engaging Drive |
| D—Terminal | | | |

RG12493 -UN-24JUL02

OUOD006.0000051 -19-23JUL02-1/1


70
15
4

Disassemble Solenoid Switch

Clamp starting motor in fixture.

Remove excitation winding connection (A) from solenoid.

A—Excitation Winding Connection



Remove Excitation Winding

OUOD006,0000052 -19-23JUL02-1/3

RG12497 -JUN-24JUL02


70
15
5

Mark position of solenoid switch.

⚠ CAUTION: Return spring is pretensioned, and can cause injury when released.

Remove solenoid switch screws.

Remove solenoid switch from solenoid plunger as illustrated.



Remove Solenoid Switch

Continued on next page


OUOD006,0000052 -19-23JUL02-2/3

RG12498 -JUN-24JUL02

Disengage solenoid plunger (A) at shift lever.

NOTE: Pay attention not to lose or misplace return spring (B) in solenoid plunger.

- A—Solenoid Plunger
- B—Return Spring



Disengage Solenoid Plunger

RG12499 -UN-24JUL02

OUOD006.0000052 -19-23JUL02-3/3

70
15
6

Test Solenoid Switch


Connect tester leads to Terminal 50 (A) and Terminal 30-f (B).

Check resistance of pull-in winding against specification.

Specification

Pull-in winding—Resistance..... 0.25—0.30 ohms

- A—Terminal 50
- B—Terminal 30-f



Check Pull-in Winding

RG12546 -UN-25JUL02

Continued on next page

OUOD006.0000053 -19-24JUL02-1/2


Connect tester leads to Terminal 50 (A) and Ground.

Check resistance of hold-in winding against specification.

Specification

Hold-in winding—Resistance..... 1.1—1.3 ohms

A—Terminal 50



Check Hold-in Winding

OUID006,0000053 -19-24JUL02-2/2

RG12547 -JUN-25JUL02


70
15
7

Assemble Solenoid Switch

Press pinion against stop ring, hook solenoid plunger (A) into engaging lever, and grease lightly around periphery.

NOTE: Pay attention not to lose or misplace return spring (B) in solenoid plunger.

A—Solenoid Plunger
B—Return Spring



Assemble Solenoid Switch

Continued on next page

OUID006,0000054 -19-24JUL02-1/2


RG12499 -JUN-24JUL02

Using solenoid position mark made previously, align solenoid switch with drive end bearing housing and fasten with screws.

Torque to specification.

Specification

Solenoid Switch Screws—Torque..... 4.5—5.5 N•m (40—49 lb-in.)



Attach Solenoid Switch

OUOD006.0000054 -19-24JUL02-2/2

RG12498 -UN-24JUL02

70
15
8

Section 75

Iskra Starter Motors

Contents

	Page	Page
Group 05—Starting Circuit Theory of Operation		
General Information	75-05-1	
Typical Starting Circuit Operation	75-05-1	
Starter Motor Operation	75-05-2	
Group 10—Iskra AZE/AZF/AZJ-Type Starter Motor Repair		
Essential Tools	75-10-1	
Dealer Fabricated Tools	75-10-2	
Iskra AZF-Type Starter Motor Repair		
Specifications	75-10-5	
Iskra AZJ-Type Starter Motor Repair		
Specifications	75-10-5	
Iskra AZE, AZF-Type Starter Motor Test		
Specifications	75-10-6	
Iskra AZJ-Type Starter Motor Test		
Specifications	75-10-7	
Exploded View of Iskra Starter Motor (AZF-Type)	75-10-8	
Exploded View of Iskra Starter Motor (AZJ-Type)	75-10-9	
Troubleshooting	75-10-10	
Identification	75-10-11	
Disassembly of Starter Motor	75-10-11	
Testing Solenoid Switch	75-10-15	
Testing Brushes	75-10-15	
Brush Replacement	75-10-16	
Testing Armature	75-10-16	
Testing Field Windings	75-10-17	
Checking Engaging Lever	75-10-17	
Checking Overrunning Clutch Pinion	75-10-18	
Reassembly of Starter Motor	75-10-18	
Group 15—Iskra AZE-Type Starter Motor Repair		
Essential Tools	75-15-1	
Dealer Fabricated Tools	75-15-2	
Iskra AZE-Type Starter Motor Repair		
Specifications	75-15-3	
Iskra AZE-Type Starter Motor Test		
Specifications	75-15-3	
Exploded View of AZE (Noseless)-Type Starter Motor	75-15-4	
Troubleshooting	75-15-5	
Identification	75-15-6	
Removing Solenoid Switch	75-15-6	
Testing Solenoid Switch	75-15-7	
Installing Solenoid Switch	75-15-8	

General Information

IMPORTANT: Never operate starter motor longer than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

RG, RG34710, 2366 -19-15MAR97-1/1

Typical Starting Circuit Operation


When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) to ground.

Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).

Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Typical Starting Circuit Operation


- A—Wire from Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

RG1313 -UN-20APR89

75
05
1

RG, RG34710, 2367 -19-15MAR97-1/1

Starter Motor Operation



RG12553 -UN-13AUG02

Starter Motor Operation

- | | | | |
|--------------------------|----------------|----------------------------|--------------------------------------|
| 1—Engaging Lever | 5—Bearing | 9—Field Coil | 12—Drive End Bracket |
| 2—Plunger | 6—Brush Holder | 10—Armature | 13—Overrunning Clutch Drive Assembly |
| 3—Solenoid | 7—Brush Kit | 11—Reduction Gear Assembly | |
| 4—Commutator End Bracket | 8—Commutator | | |

When solenoid (3) engages, it pulls engaging lever (1). Engaging lever pushes overrunning clutch drive (13) to engage pinion in starter gear on flywheel. As armature (10) turns, it cranks engine.

both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding. The two windings cancel each other, and solenoid is released.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through

Engaging lever retracts overrunning clutch drive, disengaging pinion from flywheel.

Group 10 Iskra AZE/AZF/AZJ-Type Starter Motor Repair

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000BA7 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

75
10
1

OUO1004.0000BA7 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench
Tester JT01760


Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000BA7 -19-08MAY02-3/3

Dealer Fabricated Tools

Pilot for Retaining Ring Installation- AZF Type

- a—Dia. 15.4 mm (0.606 in.)
- b—Dia. 14.4 mm (0.567 in.)
- c—50 mm (1.97 in.)
- d—18.5 mm (0.728 in.)
- e—5 mm (0.20 in.)
- f—30°
- g—R10 mm (0.39 in.)




Pilot for Retaining Ring

OUOD006,000005F -19-14AUG02-1/6

CD30492 -JUN-31JAN97

Pilot for Retaining Ring Installation- AZJ Type

- a—Dia. 15.4—15.5 mm (0.606—0.610 in.)
- b—Dia. 14.4—14.5 mm (0.567—0.571 in.)
- c—50 mm (1.97 in.)
- d—25 mm (0.98 in.)
- e—5 mm (0.20 in.)
- f—30°
- g—R10 mm (0.39 in.)



Pilot for Retaining Ring

Continued on next page


OUOD006,000005F -19-14AUG02-2/6

CD30492 -JUN-31JAN97

75
10
2

Driver for Retaining Ring Installation and for Pinion Stop Removal- AZF Type

- a—Dia. 18.5 mm (0.728 in.)
- b—Dia. 15.4 mm (0.606 in.)
- c—75 mm (2.95 in.)
- d—60 mm (2.36 in.)
- e—Chamfer 45° x 2 mm (0.08 in.)
- f—Chamfer 45° x 0.5 mm (0.02 in.)




Driver for Retaining Ring and Pinion Stop

CD300493 -UN-03FEB97

OUOD006,000005F -19-14AUG02-3/6

Driver for Retaining Ring Installation and for Pinion Stop Removal- AZJ Type

- a—Dia. 25 mm (0.98 in.)
- b—Dia. 15.5—15.6 mm (0.610—0.614 in.)
- c—75 mm (2.95 in.)
- d—60 mm (2.36 in.)
- e—Chamfer 45° x 2 mm (0.08 in.)
- f—Chamfer 45° x 0.5 mm (0.02 in.)



Driver for Retaining Ring and Pinion Stop

CD300493 -UN-03FEB97

75
10
3


Continued on next page

OUOD006,000005F -19-14AUG02-4/6

Dummy Commutator for Brush Holder Removal and Installation- AZF Type

Material: Plastic

- a—Dia. 36 mm (1.42 in.)
- b—Dia. 16 mm (0.63 in.)
- c—Dia. 40 mm (1.57 in.)
- d—35 mm (1.38 in.)
- e—2.5 mm (0.10 in.)
- f—Chamfer 15°
- g—2 mm (0.08 in.)



Dummy Commutator for Brush Holder


CD30494 -JUN-31JAN97

OUOD006,000005F -19-14AUG02-5/6

Dummy Commutator for Brush Holder Removal and Installation-AZJ Type

Material: Plastic

- a—Dia. 44.9—45.1 mm (1.768—1.775 in.)
- b—Dia. 20 mm (0.79 in.)
- c—Dia. 50 mm (1.97 in.)
- d—35 mm (1.38 in.)
- e—2.5 mm (0.10 in.)
- f—Chamfer 15°
- g—2.5 mm (0.10 in.)



Dummy Commutator for Brush Holder

CD30494 -JUN-31JAN97

OUOD006,000005F -19-14AUG02-6/6

Iskra AZF-Type Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	19.5 mm (0.77 in.)
Used Brush	Minimum Length	7 mm (0.27 in.)
Commutator End Frame Nuts	Torque	6 N•m (53 lb-in.)
Field Winding Terminal Nut	Torque	15 N•m (132 lb-in.)

OUOD006,000059 -19-13AUG02-1/1

Iskra AZJ-Type Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	23 mm (0.91 in.)
Used Brush	Minimum Length	13 mm (0.51 in.)
Engaging Lever Pivot Pin	Torque	12 N•m (106 lb-in.)
Commutator End Frame Nuts	Torque	6 N•m (53 lb-in.)
Field Winding Terminal Nut	Torque	15 N•m (132 lb-in.)

OUO1004,0000BAA -19-25SEP00-1/1

75
10
5

Iskra AZE, AZF-Type Starter Motor Test Specifications

John Deere Starter Motor Part Number	Iskra Starter Motor Part Number	Starter Motor Model	System Voltage	Rating (kW)	Solenoid Current		Pinion	
					Pull-In Winding (Amps)	Hold-In Winding (Amps)	No. of Teeth	Tooth Spacing (Modul)
RE505744	11.130.794	AZF4522	12	4.2	62	14	10	3.175
RE505745	11.130.793	AZF4521	12	3.4	62	14	10	2.54
RE505746	11.131.063	AZE4603	12	2.8	62	14	10	2.54
RE508322	11.131.060	AZF4541	12	4.2	62	14	10	3.175
RE509025	11.131.145	AZF4553	12	4.2	62	14	10	3.175
RE509903	11.131.092	AZF4550	12	4.2	62	14	10	3.175
RE516455	11.920.209	AZE4534	12	2.8	62	14	10	2.54
RE519568	11.920.209	AZE4534	12	2.8	62	14	10	2.54
RE521488	11.131.294	AZE4625	12	2.8	62	14	10	2.54
RE522334	11.131.266	AZF4575	24	4.0	30	6	10	3.175
RE522738	11.131.274	AZF4573	24	4.0	30	6	10	2.54
RE528532	11.131.254	AZF4571	24	4.0	30	630	10	3.175

75
10
6

OUOD006.000005A -19-07JUL05-1/1


Iskra AZJ-Type Starter Motor Test Specifications

John Deere Starter Motor Part Number	Iskra Starter motor Part Number	Motor Model	Starter System Voltage	Rating (kW)	Solenoid Current		Pinion	
					Pull-In Winding (Amps)	Hold-In Winding (Amps)	No. of Teeth	Tooth Spacing (Modul)
RE500733	11.130.819	AZJ3283	12	3.1	62	14	10	2.54
RE501002 ^a	11.130.762	AZJ3274	12	3.1	62	14	10	2.54
RE501766 ^a	11.130.679	AZJ3326	12	3.1	62	14	10	3.175
RE501767								
RE501769 ^a	11.130.745	AZJ3265	24	4.0	30	6	10	3.175
RE503093	11.130.796	AZJ3325	12	3.0	62	12	10	3.175
RE503118	11.130.797	AZJ3326	24	4.0	30	6	10	2.54
RE503119	11.130.798	AZJ3327	24	4.0	30	6	10	3.175
RE503120	11.130.799	AZJ3328	12	3.1	62	14	10	3.175
RE503632	11.130.936	AZJ3338	24	4.0	30	6	10	3.175
RE504009	11.130.940	AZJ3342	12	3.0	62	12	10	3.175
RE504915	11.130.977	AZJ3350	24	4.0	30	6	10	3.175
RE509100	11.131.072	AZJ3370	12	3.0	62	12	10	3.175
RE59010	11.130.605	AZJ3190	12	3.0	62	14	10	3.175
RE60239 ^a	11.130.679	AZJ3226	12	3.1	62	14	10	3.175
RE60384	11.130.569	AZJ3181	12	3.1	62	14	10	2.54
RE67086	11.130.662	AZJ3214	24	4.0	30	6	10	2.54
RE67087	11.130.678	AZJ3225	24	4.0	30	6	10	3.175
RE68783	11.130.703	AZJ3241	12	3.1	62	14	10	3.175
RE71007 ^a	111.307.45	AZJ3265	24	4.0	30	6	10	3.175

^aNot a service part. For service, consult parts catalog.

75
10
7

Exploded View of Iskra Starter Motor (AZF-Type)



Iskra Starter Motor (AZF-Type)


- | | | | |
|------------------------------|-------------------------------|--------------------------|---------------------------|
| 1—Drive End Housing | 4—Drive Assembly | 8—Bearing | 11—Brush Holder |
| 2—Bushing, Drive End Bearing | 5—Engaging Lever ¹ | 9—Parts Kit ¹ | 12—Brush Kit ¹ |
| 3—Solenoid ¹ | 6—Gear Reduction Assembly | 10—Field Coil | 13—Commutator End Frame |
| | 7—Armature | | |

¹ Available as service parts.

RG12554 -UN-13AUG02

OUOD006,000005B -19-13AUG02-1/1

Exploded View of Iskra Starter Motor (AZJ-Type)



Iskra Starter Motor (AZJ-Type)

1—Drive End Housing
2—Solenoid¹
3—Engaging Lever¹
4—Bushing

5—Field Winding
6—Brush Holder
7—Brushes¹ (4 Used)
8—Commutator End Frame

9—Bushing
10—Armature
11—Overrunning Clutch
Pinion¹

12—Center Bearing
13—Service Parts Kit¹

¹ Available as service parts.

75
10
9

RG12559 -UN-13AUG02

Troubleshooting

Symptom	Problem	Solution
Fails to operate, no current draw	Open field circuit	Replace starter motor
	Open armature windings	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
	Open solenoid windings	Replace solenoid
	Defective solenoid contact	Replace solenoid
Fails to operate, high current draw	Grounded field windings or armature windings	Replace starter motor
	Seized bearings	Replace starter motor
Low speed, low current draw	High internal resistance	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
Low speed, high current draw	Shorted armature	Replace starter motor
	Grounded armature or field windings	Replace starter motor
High speed, high current draw	Shorted field windings	Replace starter motor
Solenoid switch operates but armature does not rotate	Worn or broken brushes	Clean brush holder and commutator and replace brushes
	Shorted field windings	Replace starter motor
Solenoid quickly engages and disengages	Shorted hold-in windings	Replace solenoid
Starter motor spins, but does not crank the engine	Overrunning clutch slipping	Replace overrunning clutch
	Pinion does not move into mesh with the gear ring	Replace engaging lever or clutch

Identification

The information for parts identification is stamped on the body of the starter motor as shown.



Parts Identification

CD30490 -JUN-03FEB97


RG,RG34710,2374 -19-15MAR97-1/1

Disassembly of Starter Motor

NOTE: Before separating, mark parts so that they can be reinstalled in their original positions.

1. Disconnect field winding cable (A).
2. Remove the three screws holding the solenoid switch (B).

A—Field Winding Cable
B—Solenoid switch



Field Winding Cable and Solenoid Switch

75
10
11


CD30495 -JUN-03FEB97

Continued on next page

RG,RG34710,2375 -19-15AUG02-1/7

3. Remove solenoid switch.
4. Extract spring (C) and plunger (D).

C—Spring
D—Plunger




Remove Solenoid Switch

CD30496 -UN-03FEB97

RG,RG34710,2375 -19-15AUG02-2/7

5. **AZJ Only:** Remove cover (E).
6. **AZJ Only:** Remove clip and washers (F).
7. Remove screws (G) fixing the brush holder.
8. Unscrew nuts (H) and remove commutator end frame (J).

E—Cover
F—Clip and Washer
G—Brush Holder Fixing Screws
H—Nuts
J—Commutator End Frame



Remove Components

CD30497 -UN-03FEB97

Continued on next page

RG,RG34710,2375 -19-15AUG02-3/7

9. Remove insulation washer (K).


NOTE: Brushes are installed from the inside on AZF-type starters, and from the outside on AZJ-type starters.

10. **AZJ Only:** Extract positive brushes (L).

11. Install a dummy commutator as shown in Dealer Fabricated Tools earlier in this group.

AZJ Only: Remove brush holder.

AZF Only: Remove field coil together with brush holder away from armature. Remove dummy commutator from brush holder and pull brushes away from brush holder assembly, then remove brush holder.



Remove Brush Holder

K—Insulation Washer
L—Brushes

CD30498 -UN-03FEB97


RG, RG34710, 2375 -19-15AUG02-4/7

75
10
13

12. Remove pivot pin (M) from engaging lever.

13. Separate field winding frame (N) from armature/drive end housing assembly (P).

M—Pivot Pin
N—Field Winding Frame
P—Armature/Drive End Housing Assembly



Separate Field Winding Frame

CD30499 -UN-03FEB97

Continued on next page


RG, RG34710, 2375 -19-15AUG02-5/7

14. Remove studs.

15. **AZJ Only:** Extract armature with clutch and engaging lever from drive end housing (Q).

AZF Only: Extract planetary gear assembly with clutch and engaging lever from drive end housing.

Q—Drive End Housing



Drive End Housing


CD30500 -UN-03FEB97

RG, RG34710, 2375 -19-15AUG02-6/7

16. Using appropriate tool or self-made driver, as shown in Dealer Fabricated Tools earlier in this group, push in pinion stop (R) to have access to retaining ring (S).

17. Remove retaining ring and slide out of armature shaft the overrunning clutch (T), the center bearing (U) and, if equipped, the armature brake component.

R—Pinion Stop
S—Retaining Ring
T—Overrunning Clutch
U—Center Bearing



Remove Components


CD30501 -UN-03FEB97

RG, RG34710, 2375 -19-15AUG02-7/7

75
10
14

Testing Solenoid Switch

1. Check for continuity between solenoid terminal (A) and motor terminal (C). If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.3 ohms.)
2. Check for continuity between solenoid terminal (A) and the steel casing. If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.9 ohms.)
3. Perform this test with the plunger and spring in the solenoid body. Prevent the plunger from falling out after disconnecting power. Apply appropriate voltage (12 volts or 24 volts) between solenoid terminal (A) and the steel casing. Connect a ground wire capable of 60 amps between motor terminal (C) and the steel casing. The plunger should pull in. Disconnect the ground wire, and the plunger should remain held in. Connect the ohmmeter between terminals (B) and (C). There should be continuity only when the plunger is held in. Disconnect power, and the pinion plunger should extend. If any test above fails, replace the solenoid switch.



Testing Solenoid Switch

- A—Solenoid Terminal
- B—Battery Terminal
- C—Motor Terminal

CD30502 -UN-03FEB97

75
10
15


RG, RG34710, 2376 -19-20SEP02-1/1

Testing Brushes

1. Check positive brush holder (A) by connecting an ohmmeter between brushes and plate. If the resistance is not infinity, replace starter motor.
2. Inspect brushes. Brushes must move freely in their guides. Check brush overall length. Replace brushes if frozen or too worn.

Specification

New Brush (AZF)—Length	19.5 mm (0.77 in.)
New Brush (AZJ)—Length	23 mm (0.91 in.)
Used Brush (AZF)—Minimum Length	7 mm (0.27 in.)
Used Brush (AZJ)—Minimum Length	13 mm (0.51 in.)



Test Brushes

- A—Brush Holder

CD30503 -UN-03FEB97


RG, RG34710, 2377 -19-16AUG02-1/1

Brush Replacement

1. Cut off old brush at end of brush strand (A).
2. Solder new brush using a 40—60% tin-lead mix. Heat to 230°C (446°F).

NOTE: This operation needs a specialized tooling. Eventually, have the brushes replaced by a local electrical repair station.

A—Brush Strand



Cut off Brush at End of Strand

CD30504 -UN-03FEB97

DPSG,OUOE003,30 -19-18DEC98-1/1

Testing Armature

1. Check the armature insulation by connecting an ohmmeter between the commutator (A) and the shaft (B). If test shows continuity (needle movement), the armature is grounded.
2. Check for armature condition. Space between bars must be clean and regular. Small defects can be eliminated using sandpaper and lathe.
3. If insulation is defective or armature is quite worn, replace the complete starter motor.



Test Armature

A—Commutator
B—Shaft


CD30505 -UN-03FEB97

RG, RG34710, 2378 -19-15MAR97-1/1

Testing Field Windings

Check insulation by connecting an ohmmeter between brush (A) and field frame (B). If ohmmeter swings toward zero, a grounded circuit is indicated. If defective, replace the complete starter motor.

A—Brush
B—Field Frame



Test Field Windings

CD30506 -UN-03FEB97


RG, RG34710, 2379 -19-15MAR97-1/1

Checking Engaging Lever

NOTE: Engaging lever on AZF-type starters looks different than on AZJ-type starters, but the inspection is the same.

Inspect wear pads (A) for excessive wear or damage. Replace engaging lever if necessary.

A—Wear Pads



Inspect Wear Pads

CD30607 -UN-03FEB97

RG, RG34710, 2380 -19-16AUG02-1/1


75
10
17

Checking Overrunning Clutch Pinion

1. Check for pinion tooth condition. Slight damage to teeth can be eliminated by grinding.

NOTE: Damage to teeth can be caused by a malfunction of electrical system. Also check electrical circuit for proper operation (switch, relay etc.).

2. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.
3. If defective, replace overrunning clutch pinion.



Check Overrunning Clutch Pinion

CD30508 -UN-03FEB97

RG, RG34710, 2381 -19-15MAR97-1/1

Reassembly of Starter Motor

NOTE: Use petrolatum-base grease to lubricate mechanical parts such as shaft in nose bushing, overrunning clutch pinion on shaft, and shaft in rear bearing.

Use service parts kit when reassembling the starter motor. (See (N) in exploded view earlier in this group.)

1. Install pinion stop (A) with cupped side toward shaft end.
2. Install retaining ring (B) using suitable tools or self-made tools as shown in Dealer Fabricated Tools earlier in this group.
3. Force pinion stop over retaining ring.



Reassemble Starter Motor

A—Pinion Stop
B—Retaining Ring


CD30509 -UN-03FEB97

Continued on next page

RG, RG34710, 2382 -19-16AUG02-1/8

- Install armature and engaging lever into drive end housing. Engaging lever pads (C) must engage in groove (D) of drive pinion.

C—Engaging Lever Pads
D—Drive Pinion Groove



Armature and Engaging Lever

CD30510 -UN-03FEB97

RG, RG34710, 2382 -19-16AUG02-2/8


NOTE: Tightening specification applies to AZJ-type starters only. AZF-type starters use a pin and snap ring.

- Install pivot pin (E). Tighten to specifications. (AZJ-type starters only.)

Specification

Engaging Lever Pivot Pin—
Torque 12 N•m (106 lb-in.)

- Screw in studs (F) with insulation sleeve.
- Slide field winding frame (G) over armature.



Field Winding Frame

E—Pivot Pin
F—Studs
G—Field Winding Frame

CD30511 -UN-03FEB97


75
10
19

Continued on next page

RG, RG34710, 2382 -19-16AUG02-3/8

8. Slide brush holder (H) onto commutator. Remove the dummy commutator.
9. Install positive brushes (J).
10. Install insulation washer (K).

H—Brush Holder
 J—Brushes
 K—Insulation Washer



Install Parts

CD30512 -JUN-03FEB97

RG, RG34710, 2382 -19-16AUG02-4/8


11. Install commutator end frame.
12. Screw in screws (L) for the brush holder and secure.
13. Install washers and nuts (M). Tighten to specifications.

Specification

Commutator End Frame Nuts—
 Torque 6 N•m (53 lb-in.)

14. Install thrust washers and clip (N).

L—Screws
 M—Washers and Nuts
 N—Thrust Washers and Clip



Install Commutator End Frame

CD30513 -JUN-03FEB97


Continued on next page

RG, RG34710, 2382 -19-16AUG02-5/8

75
10
20

15. Install O-ring into groove (P).
16. Put grease into cover (Q) and install cover. Tighten screws (R).

P—Groove
Q—Cover
R—Screws (2 Used)




CD30514 -UN-03FEB97

RG,RG34710,2382 -19-16AUG02-6/8

17. Install plunger end (S) onto engaging lever.
18. Slide spring (T) into solenoid body.
19. Install O-ring (U) into groove of body pilot (V).

S—Plunger
T—Spring
U—O-Ring
V—Solenoid Body Pilot Groove



CD30515 -UN-03FEB97

75
10
21

Continued on next page

RG,RG34710,2382 -19-16AUG02-7/8

20. Install solenoid body onto starter motor. Tighten screws (W).

21. Connect field winding cable. Tighten nut (X) to specifications.

Specification

Field Winding Terminal Nut—
Torque 15 N•m (132 lb-in.)

W—Solenoid Body Screws
X—Field Winding Cable Nut



CD30516 -JUN-08FEB97

Tighten Screw and Nut

RG, RG34710, 2382 -19-16AUG02-8/8

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000BA7 -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

75
15
1

OUO1004.0000BA7 -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760


Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000BA7 -19-08MAY02-3/3

Dealer Fabricated Tools

Pilot for Retaining Ring Installation

- a—Dia. 11.40 mm (0.449 in.)
- b—Dia. 10.24 mm (0.403 in.)
- c—50 mm (1.97 in.)
- d—18.50 mm (0.728 in.)
- e—5 mm (0.20 in.)
- f—30°
- g—R10 mm (0.39 in.)




Pilot for Retaining Ring

CD30492 -JUN-31JAN97

OUOD006,0000060 -19-14AUG02-1/3

Driver for Retaining Ring Installation and for Pinion Stop Removal

- a—Dia. 16 mm (0.63 in.)
- b—Dia. 11.5 mm (0.453 in.)
- c—75 mm (2.95 in.)
- d—60 mm (2.36 in.)
- e—Chamfer 45° x 2 mm (0.08 in.)
- f—Chamfer 45° x 2 mm (0.08 in.)



Driver for Retaining Ring and Pinion Stop

CD30493 -JUN-03FEB97


Continued on next page

OUOD006,0000060 -19-14AUG02-2/3

Dummy Commutator for Brush Holder Removal and Installation

Material: Plastic

- a—Dia. 31 mm (1.22 in.)
- b—Dia. 11 mm (0.43 in.)
- c—Dia. 35 mm (1.38 in.)
- d—35 mm (1.38 in.)
- e—2.5 mm (0.10 in.)
- f—Chamfer 15°
- g—2 mm (0.08 in.)



Dummy Commutator for Brush Holder

CD30494 -JUN-31-JAN97

OUD006,000060 -19-14AUG02-3/3

Iskra AZE-Type Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	14.5 mm (0.57 in.)
Used Brush	Minimum Length	7 mm (0.27 in.)
Commutator End Frame Nuts	Torque	5.8 N•m (51 lb-in.)
Field Winding Terminal Nut	Torque	15 N•m (132 lb-in.)

75
15
3


OUD1004,0000BAA -19-07MAY02-1/1

Iskra AZE-Type Starter Motor Test Specifications

John Deere Part Number	Iskra Part Number	Motor Model	System Voltage	Rating (kW)	Solenoid Current		Pinion	
					Pull-In Winding (Amps)	Hold-In Winding (Amps)	No. of Teeth	Tooth Spacing (Modul)
RE505746	11.131.063	AZE4603	12	2.8	62	14	10	2.54

RG, RG34710, 2371 -19-07MAY02-1/1

Exploded View of AZE (Noseless)-Type Starter Motor



Iskra Starter Motor (AZE-Type)

- | | | | |
|------------------------------|---------------------------|---------------|-------------------------|
| 1—Drive End Housing | 4—Drive Assembly | 8—Bearing | 11—Brush Holder |
| 2—Bushing, Drive End Bearing | 5—Engaging Lever | 9—Parts Kit | 12—Brush Kit |
| 3—Solenoid ¹ | 6—Gear Reduction Assembly | 10—Field Coil | 13—Commutator End Frame |
| | 7—Armature | | |

¹ Available as service parts.

RG12555 -UN-13AUG02

OUID006,0000012 -19-07MAY02-1/1

Troubleshooting

Symptom	Problem	Solution
Fails to operate, no current draw	Open field circuit	Replace starter motor
	Open armature windings	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
	Open solenoid windings	Replace solenoid
	Defective solenoid contact	Replace solenoid
Fails to operate, high current draw	Grounded field windings or armature windings	Replace starter motor
	Seized bearings	Replace starter motor
Low speed, low current draw	High internal resistance	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
Low speed, high current draw	Shorted armature	Replace starter motor
	Grounded armature or field windings	Replace starter motor
High speed, high current draw	Shorted field windings	Replace starter motor
Solenoid switch operates but armature does not rotate	Worn or broken brushes	Clean brush holder and commutator and replace brushes
	Shorted field windings	Replace starter motor
Solenoid quickly engages and disengages	Shorted hold-in windings	Replace solenoid
Starter motor spins, but does not crank the engine	Overrunning clutch slipping	Replace overrunning clutch
	Pinion does not move into mesh with the gear ring	Replace engaging lever or clutch

Identification

The information for parts identification is stamped on the body of the starter motor as shown.



RG12556 -UN-27AUG02

Parts Identification


OUID006,0000014 -19-07MAY02-1/1

Removing Solenoid Switch

NOTE: Before separating, mark parts for reinstallation in original position.

1. Disconnect nut (A) and field lead from solenoid.
2. Remove three cap screws (B) holding solenoid switch to housing.
3. Remove solenoid switch.

A—Nut (Field Lead)
B—Cap Screw (3 used)




RG12557 -UN-27AUG02

Remove Solenoid Switch

OUID006,000005C -19-13AUG02-1/1

Testing Solenoid Switch

1. Check for continuity between solenoid terminal (A) and motor terminal (C). If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.3 ohms.)
2. Check for continuity between solenoid terminal (A) and the steel casing. If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.9 ohms.)
3. Perform this test with the plunger and spring in the solenoid body. Prevent the plunger from falling out after disconnecting power. Apply appropriate voltage (12 volts or 24 volts) between solenoid terminal (A) and the steel casing. Connect a ground wire capable of 60 amps between motor terminal (C) and the steel casing. The plunger should pull in. Disconnect the ground wire, and the plunger should remain held in. Connect the ohmmeter between terminals (B) and (C). There should be continuity only when the plunger is held in. Disconnect power, and the pinion plunger should extend. If any test above fails, replace the solenoid switch.



Testing Solenoid Switch

A—Solenoid Terminal
B—Battery Terminal
C—Motor Terminal

CD30502 -UN-03FEB97

75
15
7


RG, RG34710, 2376 -19-20SEP02-1/1

RG12558 -UN-27AUG02

Installing Solenoid Switch

IMPORTANT: Handle (A) of plunger (B) must be connected to engaging lever.

1. Install three cap screws (C).
2. Install field lead onto terminal with nut (D). Tighten to specifications.




Check Plunger Handle Connection

Specification

Field Lead Terminal Nut—Torque..... 15 N•m (132 lb-in.)

- A—Handle
- B—Plunger
- C—Cap Screw (3 used)
- D—Nut (Field Lead)



Install Solenoid Switch

RG12561 -UN-27AUG02

Section 80

Valeo Starter Motors

Contents

Page

Group 05—Starting Circuit Theory of Operation

General Information.80-05-1
Typical Starting Circuit Operation80-05-1
Typical Starter Motor Operation.80-05-2

Group 10—Valeo Starter Motor Repair

Essential Tools80-10-1
Valeo Starter Motor Repair Specifications80-10-2
Valeo Starter Motor Test Specifications.80-10-2
Exploded View of Starter Motor.80-10-3
Disassembly of Starter Motor80-10-4
Testing Solenoid Switch80-10-9
Testing Brushes80-10-10
Positive Brush Replacement80-10-10
Testing Armature.80-10-11
Testing Field Winding80-10-11
Checking Overrunning Clutch Pinion.80-10-12
Reassembly of Starter Motor.80-10-13

General Information

IMPORTANT: Never operate starter motor longer than 30 seconds. Allow at least 2 minutes for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

RG, RG34710, 2383 -19-15MAR97-1/1

Typical Starting Circuit Operation

When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) to ground.


Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

Light shunt windings (J) are wrapped together with two of the heavy field windings. Shunt windings are connected to solenoid switch terminal and directly to ground. They provide additional low speed torque to assist engine rotation and prevent overspeeding of motor.

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).

Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Typical Starting Circuit Operation


- A—Wire From Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

RG1313 -UN-20APR89

80
05
1

RG, RG34710, 2384 -19-15MAR97-1/1

Typical Starter Motor Operation



Typical Starter Motor Operation

A—Solenoid Switch
B—Field Winding
C—Rear Bearing

D—Brush
E—Commutator

F—Gear Reduction Assembly
G—Overrunning Clutch

H—Pinion
J—Engaging Lever

When solenoid (A) engages, it pulls engaging lever (J). Lever pushes overrunning clutch drive (G) to engage pinion in starter gear on flywheel. As armature turns, it cranks engine.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.

The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel.

In this reduction-type starter, the speed of armature rotation is reduced by the gear reduction assembly (F).

CD30450 -UN-17,JUL96

80
05
2

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000BAB -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JUN-12DEC88

80
10
1

OUO1004.0000BAB -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000BAB -19-08MAY02-3/3

Valeo Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	14 mm (0.55 in.)
Used Brush	Minimum Length	8.5 mm (0.22 in.)
Starter Solenoid Mounting Cap Screws	Torque	3 N•m (27 lb-in.)
Housing Through Bolts	Torque	7 N•m (62 lb-in.)
Field Winding Terminal Screw	Torque	10 N•m (88 lb-in.)

OUC1004,0000BAE -19-25SEP00-1/1

Valeo Starter Motor Test Specifications


John Deere Starter Motor Part No.	Valeo Starter Motor Part No.	Valeo Model	System Voltage	Rating (kW)	Solenoid Current Hold-In Windings (Amps)
RE501680	187031	D7R14	12	2.5	32
RE502156	187031	D7R14	12	2.5	32
RE60641 ^a	187031	D7R14	12	2.5	32

^aNot a service part. For service, consult parts catalog.

RG, RG34710, 2387 -19-07JUL05-1/1

80
10
2

Exploded View of Starter Motor



Starter Motor


- | | | | |
|-----------------------------------|--|---------------------------------------|--------------------------------------|
| 1—Pivot Pin ¹ | 7—Overrunning Clutch Pinion ¹ | 14—Shim ¹ | 21—Clip ¹ |
| 2—Engaging Lever/Plunger Assembly | 8—Pinion Stop ¹ | 15—Rear Bearing | 22—Field Winding |
| 3—Solenoid Spring | 9—Retaining Ring ¹ | 16—Clip ¹ | 23—Pole Shoe Screw |
| 4—Gear Reduction Assembly | 10—Bushing ¹ | 17—Plastic Cap ¹ | 24—Field Winding Terminal Nut |
| 5—Solenoid Body ¹ | 11—Armature | 18—Through Bolt ¹ (2 used) | 25—Solenoid Attaching Screw (3 Used) |
| 6—Cover | 12—Field Frame | 19—Brush ¹ (4 used) | |
| | 13—Brush Plate ¹ | 20—Brush Spring ¹ | |

¹ Available as service parts.

Disassembly of Starter Motor

1. Disconnect field winding cable (A).
2. Unscrew the two through bolts (B).

A—Field Winding Cable
B—Through Bolts (2 Used)



CD30452 -UN-22JUL96


Starter Motor Disassembly

RG, RG34710, 2388 -19-12SEP02-1/11

3. Separate electric motor (A) from complete front assembly (B).
4. Unscrew the screw (C) holding the contactor using a TORX® screwdriver.

NOTE: Do not unscrew the pole shoe screws (D) as it is difficult to perform the tightening procedure.

A—Electric Motor
B—Front Assembly
C—Contactor Screw
D—Pole Shoe Screws



CD30453 -UN-22JUL96

Separate Electric Motor


TORX is a registered trademark of Camcar/Textron.

Continued on next page

RG, RG34710, 2388 -19-12SEP02-2/11

5. Separate gear reduction/solenoid/overrunning clutch assembly (A) from drive end housing (B).
6. Push pinion stop (C) toward pinion to have access to the retaining ring (D).
7. Remove retaining ring and slide pinion stop off shaft.

- A—Gear Reduction/Solenoid/Overrunning Clutch Assembly
- B—Drive End Housing
- C—Pinion Stop
- D—Retaining Ring



Slide Pinion Stop Off Shaft

CD30454 -UN-22JUL96

RG,RG34710,2388 -19-12SEP02-3/11

8. Remove pivot pin (A).

- A—Pivot Pin



Remove Pivot Pin

CD30455 -UN-22JUL96

80
10
5


Continued on next page

RG,RG34710,2388 -19-12SEP02-4/11

9. Separate overrunning clutch/engaging lever/mobile core assembly (A) from gear reduction/solenoid body assembly (B).

A—Overrunning Clutch/Engaging Lever/Mobile Core Assembly

B—Gear Reduction/Solenoid Body Assembly




Separate Assemblies

CD30456 -UN-22JUL96

RG, RG34710, 2388 -19-12SEP02-5/11

10. Unscrew the two screws holding the contactor (A) using TORX® screwdriver.

A—Screws (2 used)



Contactor

CD30457 -UN-22JUL96

TORX is a registered trademark of Camcar/Textron.


Continued on next page

RG, RG34710, 2388 -19-12SEP02-6/11

11. Before disassembly, mark both the rear bearing (A) and the field frame (B).

12. Remove rear plastic cap (C) and clip (D).

- A—Rear Bearing
- B—Field Frame
- C—Rear Plastic Cap
- D—Clip




CD30458 -UN-22JUL96

RG, RG34710, 2388 -19-12SEP02-7/11

13. Remove the rear bearing (A).

NOTE: Two shims (B) are located on each side of rear bearing.

- A—Rear Bearing
- B—Shims (4 Used)



CD30459 -UN-22JUL96

Continued on next page


RG, RG34710, 2388 -19-12SEP02-8/11

80
10
7

14. Position and push the disassembly sleeve (A) on the shaft to hold brushes in their housing and remove the armature.

NOTE: The disassembly sleeve (A) is provided with the brush repair kit available through John Deere.

A—Disassembly Sleeve



Disassembly Sleeve

CD30460 -UN-22JUL96

RG, RG34710, 2388 -19-12SEP02-9/11

15. Slide carbon brush plate away from the field frame.
16. Loosen and remove the four brush clips from the plate. Take care to avoid losing the four springs.
17. Remove the disassembly sleeve.



Remove the Disassembly Sleeve

CD30461 -UN-22JUL96

Continued on next page

RG, RG34710, 2388 -19-12SEP02-10/11

18. Push the two positive brushes inwards and remove the brush plate from the field frame.




Remove Brush Plate

CD30462 -UN-22JUL96

RG, RG34710, 2388 -19-12SEP02-11/11

Testing Solenoid Switch

1. Check for continuity between solenoid terminal (A) and motor terminal (C). If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.3 ohms.)
2. Check for continuity between solenoid terminal (A) and the steel casing. If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.9 ohms.)
3. Perform this test with the plunger and spring in the solenoid body. Prevent the plunger from falling out after disconnecting power. Apply appropriate voltage (12 volts or 24 volts) between solenoid terminal (A) and the steel casing. Connect a ground wire capable of 60 amps between motor terminal (C) and the steel casing. The plunger should pull in. Disconnect the ground wire, and the plunger should remain held in. Connect the ohmmeter between terminals (B) and (C). There should be continuity only when the plunger is held in. Disconnect power, and the pinion plunger should extend. If any test above fails, replace the solenoid switch.



Testing Solenoid Switch

- A—Solenoid Terminal
- B—Battery Terminal
- C—Motor Terminal

CD30463 -UN-22JUL96

80
10
9

RG, RG34710, 2389 -19-20SEP02-1/1

Testing Brushes


1. Check positive brushes (A) by connecting an ohmmeter between brushes and plate. The resistance should be infinity.
2. Inspect brushes. Brushes must move freely in their guides. Check brush overall length.

Specification

New Brush—Length 14 mm (0.55 in.)
 Used Brush—Minimum Length 8.5 mm (0.22 in.)

3. If defective, replace the brush plate assembly.

NOTE: Brush plate assembly is available as a John Deere Service part.



CD30464 -JUN-22JUL96

Test Brushes

A—Brushes


RG, RG34710, 2390 -19-15MAR97-1/1

Positive Brush Replacement

1. Cut off old brush at end of brush strand (A).
2. Solder new brush using a 40—60% tin-lead mix. Heat to 230°C (446°F).

NOTE: This operation requires specialized soldering tools. If not available, have the brushes replaced by a local electrical repair station.

A—Brush Strand



CD30465 -JUN-22JUL96


Positive Brush Replacement

RG, RG34710, 2391 -19-15MAR97-1/1

80
10
10

Testing Armature

1. Check the armature insulation by connecting an ohmmeter between the commutator (A) and the shaft (B). If test shows continuity (needle movement), the armature is grounded.
2. Check for armature condition. Space between bars must be clean and of even depth. Small defects can be eliminated using sandpaper and a lathe.
3. If insulation is defective or armature is quite worn, replace the complete starter motor.



Test Armature

A—Commutator
B—Shaft


CD30466 -UN-22JUL96

RG, RG34710, 2392 -19-15MAR97-1/1

Testing Field Winding

1. Check insulation by connecting an ohmmeter between brush (A) and field frame (B). If ohmmeter indicator swings toward zero, a grounded circuit is indicated.
2. Connect ohmmeter between brush (A) and terminal (C). Resistance should be below 1 ohm.
3. If defective, replace the complete starter motor.

A—Brush
B—Field Frame
C—Field Frame Terminal



Test Field Winding

CD30467 -UN-22JUL96

RG, RG34710, 2393 -19-15MAR97-1/1

80
10
11

Checking Overrunning Clutch Pinion

1. Check for pinion tooth condition. Slight damage on teeth can be eliminated by grinding.

NOTE: Damage on teeth can be caused by a malfunction of electrical system. Also check electrical circuit for proper operation (switch, relay etc.).

2. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.

3. If defective, replace overrunning clutch pinion.

NOTE: Overrunning clutch pinion is available as a John Deere service part.




Check Overrunning Clutch Pinion

CD30468 -UN-22JUL96

RG, RG34710, 2394 -19-12SEP02-1/1

Reassembly of Starter Motor



Reassemble Starter Motor

Reassemble starter motor in the reverse sequence of disassembly procedure.

Use petroleum-base grease to lightly coat mechanical part assemblies such as shaft in nose bushing, gear

reduction train, overrunning clutch pinion on shaft, and shaft rear bearing.

Refer to machine technical manual to install starter motor and adjust belt tension.

Item	Measurement	Specification
Starter Solenoid Mounting Cap Screws	Torque	3 N•m (27 lb-in.)
Housing Through Bolts	Torque	7 N•m (62 lb-in.)
Field Winding Terminal Screw	Torque	10 N•m (88 lb-in.)

CD30469 -UN-17JUL96

80
10
13

80
10
14

Section 85 Magnetron Starter Motors

Contents

Page

Group 05—Starting Circuit Theory of Operation

General Information	85-05-1
Typical Starting Circuit Operation	85-05-1
Starter Motor Operation	85-05-2

Group 10—Magnetron Starter Motor Repair

Essential Tools	85-10-1
Dealer Fabricated Tools	85-10-2
Magnetron Starter Motor Repair	
Specifications	85-10-2
Magnetron Starter Motor Test Specifications	85-10-3
Exploded View of Starter Motor	85-10-4
Identification	85-10-5
Troubleshooting	85-10-6
Disassembly of Starter Motor	85-10-7
Testing Solenoid Switch	85-10-11
Testing Brushes	85-10-12
Brush Holder Replacement	85-10-12
Testing Armature	85-10-13
Testing Field Winding	85-10-13
Checking Overrunning Clutch Pinion	85-10-14
Reassembly of Starter Motor	85-10-15

Contents

General Information

IMPORTANT: Never operate starter motor longer than 5 seconds. Allow at least 20 seconds for cooling and battery recovery before operating again. Overheating caused by excessive operation will seriously damage starter motor.

CD03523.00000D5 -19-30JUL02-1/1

Typical Starting Circuit Operation

When wire from relay (A) is energized, current flows through both pull-in winding (C) and hold-in winding (D) to ground.


Current through windings engages solenoid plunger (E), which closes main contacts (F). When main contacts close, current through pull-in windings stops. Current continues through hold-in winding, keeping solenoid engaged and main contacts closed.

With main contacts closed, current flows from battery cable (B) to starter motor at a very high rate. Four heavy field windings (G) carry current to commutator brushes (H).

Light shunt windings (J) are wrapped together with two of the heavy field windings. Shunt windings are connected to solenoid switch terminal and directly to ground. They provide additional low speed torque to assist engine rotation and prevent overspeeding of motor.

From field windings, current flows through armature windings (I) to ground, making contact through commutator brushes (H).

Strong magnetic fields are set up by current flow through field windings and armature windings. Windings are arranged so that magnetic fields constantly repel each other, rotating armature.



Typical Starting Circuit Operation


- A—Wire From Relay
- B—Cable from Battery
- C—Pull-In Winding
- D—Hold-In Winding
- E—Solenoid Plunger
- F—Main Contacts
- G—Field Windings
- H—Commutator Brushes
- I—Armature
- J—Shunt Windings

RG1313 -UN-20APR89

85
05
1

CD03523.00000D6 -19-17JUL02-1/1

Starter Motor Operation



CD30821

Magnetron Starter Operation

CD30821 -UN-26JUL02

- | | | | |
|----------------------------|-----------------------------------|-------------------------------------|------------------|
| A—Solenoid assembly | C—Overrunning clutch drive | E—Clutch drive external gear | F—Brushes |
| B—Shift lever | D—Armature | | |

When solenoid (A) engages, it pulls shift lever (B). Lever pushes overrunning clutch drive (C) to engage pinion in starter gear on flywheel. As armature (D) turns, it cranks engine.

When engine starts, overrunning clutch spins freely on shaft. This prevents overspeeding of armature by flywheel.

When key switch is released, current to solenoid hold-in winding is shut off. Current can feed through both pull-in and hold-in windings from main contacts, but direction of current is reversed in pull-in winding.

The two windings cancel each other, and solenoid is released.

A spring pushes solenoid back to disengaged position. This opens main contacts and shuts off current to field windings and armature.

Shift lever retracts overrunning clutch drive, disengaging pinion from flywheel.

In this reduction-type starter, the speed of armature rotation is reduced by the external gear (E) of the clutch drive.

85
05
2

Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1004.0000BAB -19-08MAY02-1/3

Digital Multimeter JT05791

Test electrical components for voltage, resistance, or current flow. It is especially good for measuring low voltage or high resistance circuits.



JT05791

RW11274 -JN-12DEC88

OUO1004.0000BAB -19-08MAY02-2/3

Alternator, Generator, Starter and Battery Bench Tester JT01760

Test alternators and starters for voltage, resistance, or current flow.

OUO1004.0000BAB -19-08MAY02-3/3


85
10
1

Dealer Fabricated Tools

Dummy Commutator for Brush Holder Removal and Installation

Material: Plastic

- a—Dia. 36.4—36.6 mm (1.433—1.441 in.)
- b—Dia. 24.5 mm (0.96 in.)
- c—Dia. 42 mm (1.65 in.)
- d—35 mm (1.38 in.)
- e—2.5 mm (0.10 in.)
- f—Chamfer 15°
- g—2.5 mm (0.10 in.)



Dummy Commutator for Brush Holder

CD30494 -UN-31JAN97

CD03523,00000D4 -19-17JUL02-1/1

Magneton Starter Motor Repair Specifications

Item	Measurement	Specification
New Brush	Length	18 mm (0.71 in.)
Used Brush	Minimum Length	7.5 mm (0.30 in.)
Solenoid Switch Screws	Torque	4 N•m (35 lb-in.)
Rear Cover Nut	Torque	6 N•m (53 lb-in.)
Field Winding Terminal Nut	Torque	7 N•m (62 lb-in.)
Front Flange Screw	Torque	7 N•m (62 lb-in.)
Terminal nut (from battery)	Torque	15 N•m (11 lb-ft)
Terminal nut (from relay)	Torque	2 N•m (17 lb-in.)

CD03523,00000D8 -19-17JUL02-1/1

85
10
2


Magneton Starter Motor Test Specifications

John Deere Starter Motor Part Number	Magneton Starter Motor Part Number	System Voltage	Rating (kW)	Solenoid Current		Pinion	
				Pull-In Winding (Amps)	Hold-In Winding (Amps)	No. of Teeth	Tooth Spacing (Modul)
RE507236	9142 740	12	2.7	65	20	10	3.175

CD03523.00000D9 -19-07JUL05-1/1

85
10
3

Exploded View of Starter Motor



Exploded view

- | | | | |
|--|------------------------|-------------------------------|------------------------------|
| 1—M6x25 Screw | 7—Transmission Housing | 15—Solenoid Body ¹ | 23—Lock Washer |
| 2—Lock Washer | 8—Vent Pipe | 16—Lock Washer | 24—Rear Cover |
| 3—Front Flange/Ball Bearing Housing | 9—Shift Lever | 17—M10 Nut | 25—Stator |
| 4—Overrunning Clutch Pinion ¹ | 10—Pivot | 18—Field Winding Cable | 26—Brush Holder ¹ |
| 5—M5x35 Screw | 11—Pivot Spring | 19—Washer | 27—Ball Bearing |
| 6—Lock Washer | 12—Plunger | 20—Lock Washer | 28—Armature |
| | 13—Plunger Spring | 21—M8 Nut | 29—Housing Through Stud |
| | 14—Sealing | 22—M6 Nut | 30—Roller Bearing |

¹Available as service parts.

CD03523,00000DA -19-29JUL02-1/1

CD030822 -LIN-26.JUL02

85
10
4

Identification

The information for part identification is located on the body of the starter motor as shown.



CD03523,00000DB -19-29JUL02-1/1

Troubleshooting


Symptom	Problem	Solution
Fails to operate, no current draw	Open field circuit	Replace starter motor
	Open armature windings	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
	Open solenoid windings	Replace solenoid
	Defective solenoid contact	Replace solenoid
Fails to operate, high current draw	Grounded field windings or armature windings	Replace starter motor
	Seized bearings	Replace starter motor
Low speed, low current draw	High internal resistance	Replace starter motor
	Defective brush contact with commutator	Clean brush holder or replace brushes
Low speed, high current draw	Shorted armature	Replace starter motor
	Grounded armature or field windings	Replace starter motor
High speed, high current draw	Shorted field windings	Replace starter motor
Solenoid switch operates but armature does not rotate	Worn or broken brushes	Clean brush holder and commutator and replace brushes
	Shorted field windings	Replace starter motor
Solenoid quickly engages and disengages	Shorted hold-in windings	Replace solenoid
Starter motor spins, but does not crank the engine	Overrunning clutch slipping	Replace overrunning clutch
	Pinion does not move into mesh with the gear ring	Replace engaging lever or clutch

Disassembly of Starter Motor

NOTE: Before separating, mark parts so that they can be reinstalled in their original positions.

1. Disconnect field winding cable (A).
2. Remove the three screws (B) holding the solenoid switch.

A—Field Winding Cable
B—Screw (3 used)



CD30824


Unfasten Solenoid Switch

CD30824 -UN-26JUL02

CD03523.00000DC -19-27AUG02-1/9

3. Remove solenoid switch (A).

A—Solenoid Switch



CD30825

Remove Solenoid Switch


CD30825 -UN-26JUL02

Continued on next page

CD03523.00000DC -19-27AUG02-2/9


4. Unscrew the four screws (A) holding the front flange (B)

A—Screw
B—Front Flange




5. Separate front flange (A) and overrunning clutch assembly (B) from transmission housing.

A—Front Flange
B—Overrunning Clutch Assembly




6. Unscrew nuts (A).

A—Nut (2 used)



7. Separate transmission cover (A) from stator/armature (B).

A—Transmission Cover
B—Stator/Armature Assembly



CD30829


Remove Transmission Cover

CD30829 -UN-26JUL02

CD03523.00000DC -19-27AUG02-6/9

8. Remove the rear cover (A).

A—Rear Cover



CD30830

Remove Rear Cover


CD30830 -UN-26JUL02

Continued on next page

CD03523.00000DC -19-27AUG02-7/9

9. Install a dummy commutator (A) as shown in Dealer Fabricated Tools earlier in this group.

A—Dummy Commutator




Install Dummy Commutator

CD03523,00000DC -19-27AUG02-8/9

10. Separate armature (A) from stator (B).

A—Armature
B—Stator




Remove Armature

CD03523,00000DC -19-27AUG02-9/9

Testing Solenoid Switch

1. Check for continuity between solenoid terminal (A) and motor terminal (B). If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.3 ohms.)
2. Check for continuity between solenoid terminal (A) and the steel casing. If there is no continuity, replace the solenoid switch. (Resistance should be approximately 0.9 ohms.)
3. Perform this test with the plunger and spring in the solenoid body. Prevent the plunger from falling out after disconnecting power. Apply appropriate voltage (12 volts or 24 volts) between solenoid terminal (A) and the steel casing. Connect a ground wire capable of 60 amps between motor terminal (B) and the steel casing. The plunger should pull in. Disconnect the ground wire, and the plunger should remain held in. Connect the ohmmeter between terminals (B) and (C). There should be continuity only when the plunger is held in. Disconnect power, and the pinion plunger should extend. If any test above fails, replace the solenoid switch.



A—Solenoid Terminal
 B—Motor Terminal
 C—Battery Terminal

CD03523,00000DD -19-29JUL02-1/1

85
 10
 11


Testing Brushes

1. Check positive brush holder by connecting an ohmmeter between brush lead (A) and ground plate (B). If the resistance is not infinity, replace brush holder.
2. Inspect brushes. Brushes must move freely in their guides. Check brush overall length. Replace brush holder if brushes are frozen or too worn.

Specification

New Brush—Length 18 mm (0.71 in.)
 Used Brush—Minimum Length 7.5 mm (0.30 in.)

A—Positive Brush Lead
B—Ground Plate



Testing Brushes

CD30834

UN-26JUL02


CD03523,00000DE -19-29JUL02-1/1

Brush Holder Replacement

1. Cut off old brushes at end of brush stranded wire (A).
2. Solder new brush wire using a 40—60% tin-lead mix. Heat to 230°C (446°F).

NOTE: This operation needs a specialized tooling. Eventually, have the brush holder replaced by a local electrical repair station.

A—Brush Stranded Wire
B—Old Brush Holder
C—New Brush Holder



CD30835

Brush Holder Replacement


UN-26JUL02

CD03523,00000DF -19-27AUG02-1/1

85
10
12

Testing Armature

1. Check the armature insulation by connecting an ohmmeter between the commutator (A) and the shaft (B). If test shows continuity (needle movement), the armature is grounded.
2. Check for armature condition. Space between bars must be clean and of even depth. Small defects can be eliminated using sandpaper and a lathe.
3. If insulation is defective or armature is quite worn, replace the complete starter motor.



CD30836

Testing Armature

A—Commutator
B—Shaft


CD30836 -UN-26JUL02

RG,RG34710,2392 -19-29JUL02-1/1

Testing Field Winding

Connect ohmmeter between positive brush (A) and field winding cable (C). Resistance should be below 1 Ohm. If defective, replace complete starter motor.

A—Brush
B—Brush Holder
C—Field Frame Cable



CD30837

Testing Field Winding

CD30837 -UN-26JUL02

85
10
13

CD03523,00000E0 -19-29JUL02-1/1

Checking Overrunning Clutch Pinion

1. Check for pinion tooth condition. Slight damage to teeth can be eliminated by grinding.

NOTE: Damage to teeth can be caused by a malfunction of electrical system. Also check electrical circuit for proper operation (switch, relay etc.).

2. Turn overrunning clutch pinion by hand. Clutch pinion should turn freely on shaft in overrunning direction only.
3. If defective, replace the overrunning clutch pinion assembly.




CD30838

Checking Overrunning Clutch Pinion

CD30838 -UN-29JUL02

CD03523.00000E1 -19-29JUL02-1/1

Reassembly of Starter Motor



Reassembly of Starter Motor

A—Solenoid Switch
B—Solenoid Switch Screw

C—Rear Cover Nut
D—Field Winding Terminal Nut

E—Front Flange Screw

F—Terminal (from battery) Nut

Reassemble starter motor in the reverse sequence of disassembly procedure. It is recommended to assemble solenoid switch (A) with transmission housing first.

Apply sealing compound on contact surface and on threads of cap screws.

Use petroleum-base grease to lightly coat mechanical part assemblies such as shaft in front bearing, gear reduction train, overrunning clutch pinion on shaft, and shaft rear bearing.

Refer to machine technical manual to install starter motor on engine.

Item	Measurement	Specification
Solenoid Switch Screws (B)	Torque	4 N•m (35 lb-in.)
Rear Cover Nuts (C)	Torque	6 N•m (53 lb-in.)
Field Winding Terminal Nut (D)	Torque	7 N•m (62 lb-in.)
Front Flange Screws (E)	Torque	7 N•m (62 lb-in.)

Continued on next page

CD03523,00000E2 -19-30JUL02-1/2

Magneton Starter Motor Repair

Item	Measurement	Specification
Terminal (from battery) Nut (F)	Torque	15 N•m (11 lb-ft)
Terminal (from relay) Nut	Torque	2 N•m (17 lb-in.)

CD03523.00000E2 -19-30JUL02-2/2

Index

	Page		Page
B			
Bosch alternator		Specifications, repair60-20-3
Alternator operation30-05-1	Specifications, test60-20-4
Exploded view30-10-10	Troubleshooting60-20-5
Repair and test30-10-7	Delco-Remy 10SI, 12SI, and 15SI alternator	
Sectional view30-10-6	Repair and test10-10-4, 10-15-4
Specifications, repair30-10-3	Specifications, repair10-10-2, 10-15-2
Specifications, test30-10-4	Specifications, test10-10-3, 10-15-3
Bosch conventional starter motor		Denso alternator	
Cutaway view70-10-6	Alternator operation25-05-1
Exploded view70-10-7	Regulator operation25-05-2
Repair and test70-10-4	Denso alternator (with add-on regulator)	
Specifications, repair70-10-2	Repair and test25-10-3
Specifications, test70-10-3	Specifications, repair25-10-2
Bosch planetary gear starter motor		Specifications, test25-10-2
Cutaway view70-15-4	Denso alternator (with built-in regulator)	
Repair and test70-15-2	Repair and test25-15-5
Specifications, test70-15-2	Specifications, repair25-15-3
Bosch starter motor		Specifications, test25-15-4
General information70-05-1	Denso/John Deere starter motor	
Starter motor operation70-05-2	Starting circuit operation65-05-1
Starting circuit operation70-05-1	Denso/John Deere starter motor (conventional type)	
Troubleshooting70-10-5, 70-15-3	Exploded view65-10-15
D			
Delco-Remy alternator		Repair and test65-10-8
Alternator operation10-05-1	Specifications, test65-10-6
Regulator operation10-05-1	Starter operation65-05-2
Delco-Remy starter motor		Denso/John Deere starter motor (gear reduction type)	
General information60-05-1	Exploded view65-15-7
Starter motor operation60-05-2	Repair and test65-15-5
Starting circuit operation60-05-1	Specifications, test65-15-4
Delco-Remy starter motor (10MT, 20MT, 22MT, 25MT, 27MT, 28MT)		Starter operation65-05-3
Cutaway view60-10-7	Denso/John Deere starter motor (planetary type)	
Repair and test60-10-7	Exploded view65-20-14
Specifications, repair60-10-3	Repair and test65-20-3
Specifications, test60-10-4	Specifications, test65-20-3
Troubleshooting60-10-6	Starter operation65-05-5
Delco-Remy starter motor (30MT, 35MT, 37MT)		E	
Cutaway view60-15-7	Electrical system	
Repair and test60-15-8	Circuit malfunctions05-15-1
Specifications, repair60-15-3	Grounded circuit05-15-5
Specifications, test60-15-4	High resistance circuit05-15-2
Troubleshooting60-15-6	Open circuit05-15-3
Delco-Remy starter motor (40MT, 41MT, 42MT, 50MT)		Seven step test procedure05-15-8
Cutaway view60-20-6	Shorted circuit05-15-7
Repair and test60-20-6	Test equipment05-15-10
I			
		Iskra alternator	
		Alternator operation55-05-1

Indx
1

Page	Page		
Exploded view	55-10-4	L	
Identification	55-10-5		
Repair and test	55-10-7		
Specifications, repair	55-10-2		Leece-Neville alternator
Specifications, test	55-10-3		Alternator operation
Troubleshooting	55-10-6		Repair and test
Iskra AZE-type starter motor			Specifications, repair
Exploded view	75-15-4		Specifications, test
Identification	75-15-6		
Specifications, repair	75-15-3		M
Specifications, test	75-15-3		
Troubleshooting	75-15-5		Magneton alternator
Iskra AZF-type starter motor			Alternator operation
Exploded view	75-10-8		Exploded view
Specifications, repair	75-10-5		Identification
Specifications, test	75-10-6		Repair and test
Iskra AZF/AZJ-type starter motor			Specifications, repair
Identification	75-10-11		Specifications, test
Repair and test	75-10-11		Troubleshooting
Troubleshooting	75-10-10		Magneton starter motor
Iskra AZJ-type starter motor			Brush holder replacement
Exploded view	75-10-9		Checking overrunning clutch pinion
Specifications, repair	75-10-5		Exploded view
Specifications, test	75-10-7		General information
Iskra starter motor			Identification
General information	75-05-1		Reassembly of starter motor
Starter motor operation	75-05-2		Repair and test
Starting circuit operation	75-05-1		Specifications, repair
			Specifications, test
J			Starter motor operation
John Deere/Denso starter motor			Starting circuit operation
General information	65-05-1		Testing armature
Starting circuit operation	65-05-1		Testing brushes
John Deere/Denso starter motor (conventional type)			Testing field winding
Exploded view	65-10-15		Testing solenoid switch
Repair and test	65-10-8		Troubleshooting
Specifications, test	65-10-6		Motorola A-, RA-, 8AR-Series alternator
Starter operation	65-05-2		Repair and test
John Deere/Denso starter motor (gear reduction type)			Specifications, repair
Exploded view	65-15-7		Specifications, test
Repair and test	65-15-5		Motorola alternator
Specifications, test	65-15-4		Alternator operation
Starter operation	65-05-3		Regulator operation
John Deere/Denso starter motor (planetary type)			Motorola HC-, MA-, MR-Series alternator
Exploded view	65-20-14		Repair and test
Repair and test	65-20-3		Specifications, repair
Specifications, test	65-20-3		Specifications, test
Starter operation	65-05-5		Motorola SA-Series alternator
			Repair and test
			Specifications, repair
			Specifications, test

	Page		Page
Motorola TA-Series alternator		Specifications, repair80-10-2
Repair and test15-30-4	Specifications, test80-10-2
Specifications, repair15-30-3	Starter motor operation80-05-2
Specifications, test15-30-3	Starting circuit operation80-05-1
Motorola 8E-Series alternator			
General information15-10-3		
Repair and test15-10-3		
Specifications, repair15-10-2		
Specifications, test15-10-2		
 N 			
Niehoff alternator			
Alternator operation20-05-1		
Load dump circuit20-05-4		
Starting alternator20-05-1		
Niehoff 12-volt, 110-amp alternator			
Repair and test20-10-4		
Specifications, repair20-10-3		
Specifications, test20-10-4		
Niehoff 24-volt, 50-amp alternator			
Repair and test20-15-5		
Specifications, repair20-15-3		
Specifications, test20-15-4		
 P 			
Prestolite alternator			
Alternator operation50-05-1		
Repair and test50-10-2		
Specifications, test50-10-2		
 V 			
Valeo alternator			
Alternator operation35-05-1		
Regulator operation35-05-2		
Repair and test35-10-3		
Specifications, repair35-10-2		
Specifications, test35-10-3		
Valeo A13N-Series alternator			
Repair and test35-15-3		
Specifications, repair35-15-2		
Specifications, test35-15-2		
Valeo starter motor			
Exploded view80-10-3		
General information80-05-1		
Repair and test80-10-4		

Indx
3

