



White
Operator's Manual

HD 800A-6A
Power Unit or Engine
S/N 34900001 & Up

JENSALES.COM

or Call 800-443-0625



THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
WHITE OR IT'S SUCCESSORS. **WHITE** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

WH-O-HD800A-6A

Operator's Manual

NOTES

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

WHITE

**HD 800A-6A
Power Unit**

JENSALES®

**OPERATION AND
MAINTENANCE MANUAL**

FORM NO. 432 441

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at


JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW



JENSALES[®]

purchase full manual at

9666

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

LUBRICATION

If an in-line lubricator is not used in air supply line, check lubricant in end cover periodically and maintain oil level at hex plug (Fig. 10). Use SAE 20, high quality motor oil for refilling oil chamber.




Fig. 10. Air Starting Motor

DISTRIBUTOR

Apply a trace of high-quality ball bearing lubricant to breaker cam every 250 hours of operation. Also, place two drops of light engine oil on felt wick under rotor.

Bendix breakerless distributor requires no lubrication.

FAN HUB

At initial engine servicing and after each 1000 hours of operation, turn fan hub so that vent plug and grease fitting are straight to either side (Fig. 11). Remove slotted vent plug and inject lithium base grease through grease fitting until grease is visible at vent plug opening. DO NOT OVERFILL — some air space must remain. Reinstall vent plug, tightening it securely.

Once annually, remove, disassemble, clean, and repack spindle bearings, using lithium base grease. Refer to Maintenance Section for disassembly and reassembly procedure.




Fig. 11. Fan Hub Lube Fitting

CLUTCH AND POWER SHAFT

Lubricate clutch throwout collar, power shaft bearing and pilot bearing every 150 hours of operation, using an automotive lithium base grease. DO NOT apply excess grease to throwout collar.

Bump crankshaft rearward after lubricating pilot bearing. Do not over-lubricate and avoid using heavy viscosity grease. These procedures will relieve forward thrust on crankshaft which could result in premature rear main or thrust bearing failure.

If fitting for pilot bearing in end of shaft is inaccessible, move fitting to alternate location as shown in Fig. 12. Install plug in end of shaft.




Fig. 12. Clutch & Power Shaft

MAINTENANCE

block is on high point of the cam lobe. Set point gap to .018 to .024 inch (Fig. 25). Gap should be set to wider opening to compensate for wear on rubbing block.

Check alignment of points to be sure they are centered. Apply a dab of ball bearing lubricant to breaker cam and reinstall dust shield, rotor, and cap. After completing service work on points, check ignition timing as explained on page 23.

If distributor is to be removed from engine for service, turn engine over until No. 1 piston is at top of its compression stroke. Remove distributor cap and mark position of rotor in relation to distributor body. Also mark position of distributor housing in relation to adapter housing. Use these marks to install distributor in its proper position at reassembly.




Fig. 25. Point Gap

DISTRIBUTOR (BREAKERLESS)

Breakerless distributor requires no maintenance or service except an occasional cleaning of rotor contact point and contacts inside distributor cap. Keep wire connections and terminals between transmitter and distributor clean and free of corrosion or oil.

If distributor is removed from engine for any reason, turn engine over in direction of rotation, until No. 1 piston is at top of its compression stroke.

Remove distributor cap and note position of rotor in relation to vertical timing marks inside body. There are two vertical marks for determining rotor position, depending on direction of distributor rotation. Distributor rotor turns in a clockwise direction when looking down

into body, so with No. 1 piston at top of its compression stroke, trigger vane nearest rotor should be pointing to vertical mark indicated in Fig. 26.

NOTE: FIG. 26 SHOWS ROTOR OUT OF POSITION TO FIRE NO. 1 CYLINDER TO ILLUSTRATE TIMING MARK IN HOUSING.



Fig. 26. Timing Distributor

MAGNETO

Field service of magnetos used on HD800A-6A power units is limited to cleaning or replacing breaker points and replacing condenser. Whenever major service becomes necessary, take magneto to an authorized magneto service station that has proper facilities and specialized equipment for overhauling and testing magneto.

IMPORTANT: IF DIFFICULTY IS EXPERIENCED WITH A MAG-TRONIC BREAKERLESS MAGNETO, TAKE IT TO AN AUTHORIZED AMERICAN-BOSCH MAGNETO SERVICE STATION FOR INSPECTION AND TESTING.

To clean or replace contact points, remove distributor cover. Figs. 27, 28, and 29 show contact points and condensers of three magnetos available for HD800A-6A power unit. The Mag-tronic magneto does not have contact points.

Check condition of points and clean them with a fine cut point file if they are severely burned, pitted or corroded. Replace points if they cannot be cleaned up satisfactorily. Replace condenser when new points are installed.

Adjust contact points to obtain a .015" gap with points wide open (cam follower on high part of cam lobe).

Pistons are available for unit in standard, .020", .040", and .060" oversize. To obtain correct fit for oversize pistons, cylinders must be bored to 5.3385-5.3395", 5.3585-5.3595" or 5.3785-5.3795", as applicable.

When reinstalling blocks, use new gaskets. Tighten place bolts inside crankcase evenly to 170-175 ft-lbs.

CAMSHAFT

To remove camshaft, remove rocker arm assemblies and push rods, keeping push rods in their original order. Use a piece of wire inserted down through each push rod hole to hold tappets up so that they will clear camshaft lobes and bearing journals when camshaft is removed.

Two front bearing surfaces of camshaft turn in bushings in crankcase. Nominal inside diameter of front bushing is 3.344-3.342", and second 3.3135-3.3115". Bearing clearance for No. 1 and 2 is .002 to .007"; for No. 3 and 4, .003 to .005". If wear on bushings exceeds .005-.008", there will be excessive play on camshaft and possible damage to timing gears. To replace bushings, press out old ones and press in new (Fig. 54).




Fig. 54. Camshaft Bushings

Replacement bushings are precision reamed during manufacture and require no further machining after assembly, provided they are not damaged during installation.

When reinstalling camshaft, remember to time camshaft gear with crankshaft gear (No. 1 tooth in No. 1 tooth space).

CAMSHAFT END PLAY

Camshaft should have .010-.025" end play. To adjust, loosen lock nut shown in Fig. 55, turn adjusting screw all the way in, then back screw out to obtain proper end play. Tighten lock nut.




Fig. 55. Camshaft End Play Adjustment

PTO CLUTCH

If satisfactory clutch adjustments can no longer be obtained, it indicates that driving plates are badly worn and must be replaced.

To gain access to clutch plates, it will be necessary to remove complete clutch assembly from engine. Remove bolts securing clutch housing to flywheel housing. Install a fairly long 1/2"-13 bolt in tapped hole in each side of bell housing. Turn bolts in evenly to force clutch housing away from flywheel housing.

Pull pilot bearing from shaft. Straighten bent over portion of lock washer and remove nut and washer.

Disconnect grease tube from shifter collar. Install a 5/8"-11 bolt in each tapped hole in clutch backing plate and attach a suitable puller. Remove clutch assembly from shaft.

Before removing floating plate and sliding sleeve assembly, check fit of shifting collar on sleeve. Collar should fit snug on sleeve with no evidence of drag.

If collar is loose on sleeve and shims are installed between collar halves, remove shims to obtain proper fit. If collar is worn so that it is loose with shims removed, replace collar.

INDEX

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

INDEX

A		C	
Accessory Shaft Bushings	29	Camshaft	45
Adjustments		Carburetion, Dual Fuel ((LP & Natural Gas)	16
Governor	18	Carburetor	33
PTO Clutch	18	Chart, Lube	15
Valve Clearances	19, 37	Checks, Pre-Starting	13
Air Cleaner	6, 7	Cleaner, Air	6, 7
American Bosch Magneto		Clearances, Valve	19, 37
High Tension	27	Clutch And Power Shaft	9
Breakerless	27	Clutch	45
Low Tension	27	Adjustment	18
Ammeter	11	Lever	11
Arm Assembly, Rocker	40	Connecting Rods	44
Automatic Oil Level Control	12	Bearings	41
		Controls	10
		Automatic Oil Lever	12
		Converter, LP Gas	34
		Cooling Coils, Irrigation Unit	19
		Cooling System	13
		Crankcase	
		Breather	8
		Ventilator Valve	23
		Crankshaft And Main Bearings	42
		Cylinder Blocks	44
		Cylinder Heads	41

B

Bearings			
Connecting Rod	41		
Main	42		
Belt Fan	24		
Blocks, Cylinder	44		
Breather, Crankcase	8		
Bushings, Accessory Shaft	29		
Button, Start	11		

purchase full manual at
JENSALES.COM
or call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

INDEX

D		H	
Distributor		Hourmeter	11
Breakerless	25	Hub, Fan	30
Lubrication	9	Lubrication	9
Regular	24		
Dual Fuel Carburetion - (LP & Natural Gas)	16		

E		I	
Electric Starting Receptacle	11	Ignition Switch	11
Electric Tachometer	11	Instrument Panel	10
End Play, Camshaft	45	Irrigation Unit Cooling Coils	19
Engine			
Oil	4		
Oil Pressure	13		
Oil Seal, Replacing (Rear)	41		
Starting			
LP Gas	17		
Natural Gas	15		
Stopping	18		
Timing	23		
Timing Magneto To	26		
Exchangers, Heat			
Fabricating	21		
Selecting Commercial	21		

F		L	
Fabricating Heat Exchangers	21	Lever	
Fairbanks Morse Low Tension Magneto	27	Clutch	11
Fan Belt	24	Throttle	11
Fan Hub	30	Low Oil Level Shutoff	12
Lubrication	9	LP Gas	
Filters	5, 6	Converter	34
LP Gas	34	Fuel	15
Fuel		Filter	34
LP Gas	15	Lubrication	4
Natural Gas	13	Chart	5

G		M	
Gauge		Magneto	25
Oil Pressure	11	American Bosch High Tension	27
Sight Oil	12	Breakerless	27
Temperature	10	Low Tension	27
Vacuum	12	Fairbanks Morse Low Tension	27
Generator	8	To - Transformer Wiring	28
Governor	30	Main Bearings	42
Adjustments	18	Maintenance	23
Guides, Valve	39	Mechanical Tachometer	12
		Motor, Starting	8
		Murphy Vacuum Panel	12

N	
Natural Gas Fuel	13

INDEX

O		S	
Oil		Seals, Valve Stem	40
Engine	4	Selecting Commercial Heat Exchangers	21
Pressure, Engine	13	Shutoff	
Pressure Gauge And Safety Cutout	11	Low Oil Level	12
Pump	36	Overspeed	12
Operation	13	Sight Oil Gauge	12
Overspeed Shutoff	12	Spark Plugs	23
		Specifications	2
		Springs, Valve	39
		Start Button	11
		Starting	
		LP Gas Engine	17
		Motor	8
		Natural Gas Engine	15
		Stopping Engine	18
		Storage	47
		Switch, Ignition	11
P		T	
Panel		Tachometer	
Instrument	10	Electric	11
Murphy-Vacuum	12	Mechanical	12
Piston Pins	44	Temperature Gauge And Safety Cut-Out	10
Pistons And Rings	43, 44	Throttle Lever	11
Plugs, Spark	23	Timing	
Preparing Unit For Storage	47	Engine	23
Pre-Starting Checks	13	Magneto-To-Engine	26
Pressure, Engine Oil	13		
Pressure Reducing Valve	34		
PTO Clutch	45		
Adjustment	18		
Pump			
Oil	36		
Water	28		
Push Rods	40		
		V	
		Vacuum Gauge	12
		Valve	
		Clearances, Adjusting	19, 37
		Guides	39
		Pressure Reducing	34
		Reconditioning	38
		Seat Inserts	38
		Springs	39
		Stem Seals	40
		Ventilator, Crankcase	23
		Ventilation	13
R		W	
Receptacle, Electric Starting	11	Water Pump	28
Reinstalling Cylinder Heads	40		
Replacing Rear Engine Seal	41		
Resistance of Bends To Flow	22		
Returning Unit To Service After Storage	48		
Rings, Piston	44		
Rocker Arm Assembly	40		
Rods, Connecting	44		
Rods, Push	40		