

OPERATION & MAINTENANCE MANUAL

**MITSUBISHI
DIESEL ENGINES**

S6R, S6R2

625 KW


APPLICATIONS

- Generator drive
- General mechanical drive
- Locomotive drive
- Construction machinery drive
- Marine generator drive
- Marine general mechanical drive



**WE WELCOME YOU TO THE
GROWING LIST OF PEOPLE
WHO OWN AND USE OUR
DIESEL ENGINE**

S6R, S6R2



500001

This manual is written to familiarize you with the operation and maintenance of your S6R/S6R2 diesel engines, and provide important safety information. We suggest that you carefully read this manual to learn about your new engines.

After reading this manual, be sure to keep it near your engine as a ready reference when you need it. See your Mitsubishi dealer for any further information you feel you need. He will be glad to help you and answer any questions you may have about handling of your new engines.

The engines described in this manual are for industrial drive and marine auxiliary drive (such as generator drive).

The descriptions, illustrations and specifications contained in this manual were in effect at the time it was approved for printing. Mitsubishi reserves the right to change specifications or design without notice and without incurring obligation.





TABLE OF CONTENTS

	Page
Your engine and Mitsubishi	1
Safety – it's up to you	3
Operation instructions	8
Major components	8
New engine initial service	9
Operating the engine	14
Operation under extreme weathers	17
Cold weather precautions	17
Hot weather precautions	19
Maintenance instructions	20
Maintenance schedule	21
Every 10 hours or daily	24
Every 50 hours or monthly	26
Every 250 hours or 1 year	29
Every 500 hours or 2 years	31
Every 1000 hours or 3 years	33
Every 2000 hours or 5 years	36
Storage	37
Diesel fuels, cooling water and lubricants	39
Troubleshooting	43
Specifications	50
Tightening torque	51
Circuit diagrams	54





YOUR ENGINE AND MITSUBISHI

SERVICE ASSISTANCE

Your Mitsubishi dealer is vitally interested in your complete satisfaction with the Mitsubishi engine you purchased from him. He is anxious to know that all of your service needs are quickly and courteously filled.

Mitsubishi has established district and regional offices throughout the world to help each dealer make himself more helpful to you. Should you feel that you require service assistance beyond that which your dealer is providing, the Mitsubishi office in your area will be pleased to work with you and your dealer.

If your engine is transferred to elsewhere from the original place of use registered with Mitsubishi, be sure to have the registration changed. Consult your Mitsubishi dealer for the necessary procedure.




LOCATION OF ENGINE SERIAL NUMBER

The engine serial number is stamped on the nameplate attached to the right front side of the engine.

Example


Model	Serial number
S6R	20012

On the nameplate are also stamped the output and rated speed. The numbers in the illustration show cylinder numbers.




ENGINE MODEL AND APPLICATION CODES


- S□□ - □ T Turbocharged unit
- S□□ - □ TA Turbocharged, aftercooled unit
- S□□ - □ TK Turbocharged, intercooled unit



SAFETY - IT'S UP TO YOU

WARNINGS, CAUTIONS and NOTES are used in this manual to emphasize important and critical instructions. They are used for the following conditions:

 **WARNING** Operating procedures, practices, etc., which if not correctly followed, will result in personal injury or loss of life.

 **CAUTION** Operating procedures, practices, etc., which if not strictly observed, will result in damage to or destruction of engine.

NOTE An operating procedure, condition, etc., which is essential to highlight.


✓ Right or normal

✗ Wrong or abnormal (service needed)

Recommendation of daily operation record

It is obvious to every engine user and operator that an engine should not be run to destruction. Daily recording is a preventive maintenance program and will serve as a guide for:


- Effective troubleshooting (to help a serviceman of your Mitsubishi pin-point the trouble)
- Quick servicing and less downtime (to help him save time for servicing)
- Grasp of operating conditions (to help you recognize conditions, signs or indications of approaching trouble)




Items to be recorded

The following items are recommended to be recorded as "daily readings":


1. Operating hours (service meter reading)
2. Quantities of engine oil, fuel oil and water (coolant) used for refilling.
3. Engine oil and coolant change periods
4. Engine oil pressure, exhaust temperature, supply air pressure and fresh water temperature
5. Parts serviced, kinds of service (adjustment, repair or replacement) and results of service
6. Changes in operating conditions (for example, "Exhaust smoke turned black")



- ⚠ Study OPERATION & MAINTENANCE MANUAL to become thoroughly familiar with all engine controls and instruments – and service procedures.




- ⚠ Wear hard hat and safety shoes – and, if job conditions require, safety goggles, heavy gloves, ear protectors, respirators, etc.




Before operation

Before starting and during warm up period, check under and around engine for visual defects – leaks of fuel, oil and coolant, loose or missing part.




- ⚠ When starting engine, walk around it once more – open eyes and be alert to people and obstacles that may be within operating range.




During operation


⚠ Do not touch any moving part of a running engine, or clothing or hair can be caught in moving parts, resulting in personal injury or loss of life.



⚠ Keep hands off hot parts – turbocharger, exhaust pipe, etc. – during operation or immediately after shutting off engine.




⚠ If necessary to operate engine within an enclosed area, provide adequate ventilation – and pay attention to exhaust piping and exhaust gas leaks.




Idling operation for engine cooling

After the load is removed, allow the engine to run at low idle speed for about 5 to 6 minutes. During this period, check around the engine for visual defects. Shutting off the engine immediately after removing the load is very hard on the engine parts.




After operation

At end of operating period, walk around engine to check for any defects, and make repairs to prepare for the next day.




Maintenance


⚠ Be sure to shut off engine, and turn off battery main switch (or close air tank valve) before servicing engine. If necessary to crank engine for inspection, signal to other man before cranking. After cranking, be sure to remove cranking bar.




⚠ Use right tools correctly. Thoughtless use of tools including use of a wrong tool can cause personal injury and damage to engine.




⚠ When removing radiator filler cap immediately after shutting off engine, be sure to release pressure to avoid having scalding by hot water or steam spouted out from radiator.



⚠ Do not smoke while handling highly flammable materials. Do not use open cans of gasoline or diesel fuel for cleaning parts near any open flame. Good commercial, nonflammable solvents are preferred.




⚠ Do not attempt to "climb up" engine for access to upper parts. Use a safe footstool for maintenance without accidents.



⚠ When lifting engine, use slings free of broken strands. Be sure that the crane has enough capacity for engine to be lifted. Make use of hangers provided on engine, and lift it carefully.


Attach each sling to engine at an angle of less than 60°. Put wads to sling contacting surfaces of engine to protect both slings and engine.



OPERATION INSTRUCTIONS


MAJOR COMPONENTS

External views



301211

Left-side view



301212

Right-side view


NOTE: Direction of rotation of this engine is counterclockwise as viewed from flywheel side.

NEW ENGINE INITIAL SERVICE

Before operation

Anyone charged with the care and operation of the engine is responsible for "new engine initial service" – service for a new or reconditioned engine or an engine which has been

stored for a long period of time. Check the following points before starting the engine for the first time. For the second and subsequent services, refer to Maintenance Schedule.



After initial 50 service hours, perform the following services:

Change of engine oil

Change of oil filter

Adjustment of valve clearance


Retightening of bolts and nuts




During break-in period of a new or reconditioned engine, avoid sudden application of load and high-speed operation for engine life.

• **Fuel injection pump**

1. Loosen air vent plug (3) about 1-1/2 turns on the injection pump.
2. Operate priming pump (2) until the flow of fuel at the plug is free of air bubbles. Lock the priming pump by twisting it clockwise while depressing it, and then tighten vent plug (3).



- 1) If all vent plugs are tightened before priming pump is locked, pressure acts on feed pump, making it difficult to lock the priming pump.
- 2) Wipe off fuel spilled out of each vent plug hole with wiping rag.




301214

LUBRICATION SYSTEM

Filling the oil pan

1. Use a clean jug to pour oil into the oil pan. Use engine oil of API service classification "CD."
2. After filling, check the oil level with the level gauge. The level should be within the operating range on the gauge.
3. Remove the rocker cover, and apply oil to the valve mechanism.
4. Check the oil pan and other parts for oil leaks.
5. Start and run the engine for a while. Stop the engine and, after waiting for about 10 minutes, add oil up to the level specified in 2 above.




300080

COOLING SYSTEM

Filling the cooling system

1. Tighten the drain cocks on the left front and rear sides of the engine (or the radiator drain plug on a radiator-cooled engine). The engine is shipped from the factory with its cooling system drained.
2. Use clean water that is low in scale forming mineral. Remember, some waters pumped out of ground in a mining or hot-spring area contain active impurities harmful to the metal of cylinder liners.



301242

NOTE

Use rust inhibitor in the cooling system at all times. It retards, and in some cases, completely eliminates mineral deposits within the cooling system. Use anti-freeze solution when the temperature is below freezing.

OPERATION INSTRUCTIONS

3. To fill the cooling system of a radiator-cooled engine for the first time, or to change the coolant in such an engine, proceed as follows:

- a) Remove the radiator filler cap, and slowly fill the radiator until it is full. Pour water at a rate of 10 liters (2.6 U.S. gal) per minute.

NOTE

To bleed air out of the cooling system, loosen the valve at the top of thermostat.

- b) When the radiator is full, leave the radiator filler cap removed and crank the engine with the starter three times, for 5 to 6 seconds each time, at intervals of about 20 seconds, in order to bleed air out of the water pump.





CAUTION

To crank the engine for air bleeding, keep the stop lever in STOP (returned) position. (See page 14.)

- c) Check the coolant level in the radiator, and add water if necessary.
- d) Crank the engine with the fuel supply shut off for 30 seconds to make sure that the oil pressure rises normally. If the pressure does not rise in 30 seconds, wait for about 1 minute, and crank it again.
- e) Start the engine, and run it at 600 to 700 rpm for 3 to 5 minutes.


- f) Stop the engine, and check the coolant level in the radiator again. If the level is low, refill the radiator fully, and install the cap.

- g) Check the hose joints for coolant leaks.



ELECTRICAL SYSTEM**Battery electrolyte level and specific gravity**

1. Remove the filler caps, and check the electrolyte level in each cell. It should be 1 cm (3/8 in.) above the cell plates.
2. When filling the cells of the battery for the first time, slowly pour dilute sulfuric acid (electrolyte) in the cells.
3. If the battery is already filled with electrolyte, check its level and, if the level is low, add distilled water.
4. Check the specific gravity of electrolyte. If the SG is below 1.22 at 20°C (68°F), recharge the battery.

**WARNING**

- 1) Electrolyte, sulfuric acid, is very corrosive. If you drip it on your skin or clothing, flush it off at once with water.
- 2) Do not allow sparks or open flame near the battery.

Circuits

Check each circuit for loose terminals.

OTHERS

Check the following valves and cocks to make sure they are opened or closed properly:

- Fuel supply valve Opened
- Coolant drain cock (radiator) Closed
- Coolant drain cock (engine) Closed
- Oil drain valve Closed
- Air supply valve (air tank) Opened

OPERATING THE ENGINE

Controls and instruments

Water temperature gauge
Indicates temperature of engine coolant.
Normal range:
70 – 90°C
(158 – 194°F)

Oil filter alarm lamp (pilot lamp)
Glows when paper-element type oil filter is clogged.

Tachometer
Indicates engine speed in rpm (revolutions per minute).

Oil temperature gauge
Indicates temperature of engine lubricating oil.
Normal range:
70 – 110°C
(158 – 230°F)

Oil pressure gauge
Indicates pressure of lubricating oil.
Normal range:
5 – 6.5 kgf/cm²
(71 – 92 psi)
[0.5 – 0.6 MPa]

Ammeter
Indicates battery charging current.
Normal indication: (+) side

Starter switch
HEAT: Operates air heater to start engine easily in cold weather. (air-heater model)
OFF: Insert and pull out key. All electrical circuits are OFF.
ON: Keep engine running. Charging and lamp circuits are ON.
START: Start engine. Key will return to ON when released.

300921

Service meter

301158

Rely on this meter to check, service or lubricate engine.

NOTE: Dial advances one number when engine is operated for 1 hour at 1500 rpm.

Speed control lever

300082

Use the lever to control engine speed. Pull it to stop engine.

Stop lever


301159

Pull the lever to stop engine in case of emergency.

After performing daily (10-hour) servicing, operate the engine as follows:

STARTING

There are three methods available for starting the engine – electric starting, air motor starting and direct air starting. Disengage the clutch (if equipped) or remove any load from the engine.



NOTE

Keep the tank air supply valve always opened for automatic starting.

CAUTION

- Give particular attention to the following rules when using the electric starting:
 - 1) Do not run the starter for more than 30 seconds at a time. Then allow 2 minutes for cooling before using it again.
 - 2) When cranking the engine again, wait

- until the starter stops rotating and the engine stops “rocking” to prevent it from turning in reverse direction.
- 3) Keep the starter switch in ON position during operation. Never move it to START or OFF position.
- Air-motor or direct-air starting engine:
 - Open the air tank drain valve and drain water every 50 hours or monthly.


OPERATION INSTRUCTIONS

WARMING UP

After starting up, allow the engine to idle at about 1000 rpm for 5 minutes to warm it up. During this warm-up period, check to be sure that oil pressure rises properly. The pressure will be 2 to 3 kgf/cm² (28 to 43 psi) [0.2 to 0.3 MPa] during low idling.



It is not necessary to warm up a stand-by engine. Instead, be sure to perform periodical testing items described in "Maintenance Instructions."



STARTING THE LOAD

After warming up the engine, apply the load. During the operation, check to be sure –

1. The engine makes no abnormal sound and vibration.
2. Exhaust smoke color is normal.
3. Meters and gauges are indicating normally.

- Tachometer
- Engine oil pressure gauge
5 – 6.5 kgf/cm² (71 – 92 psi)
[0.5 – 0.6 MPa]
- Water temperature gauge
70 – 90°C (158 – 194°F)
- Ammeter
(+) side
- Engine oil temperature gauge
70 – 110°C (158 – 230°F)
- Oil filter alarm lamp (pilot lamp) – OFF

STOPPING

After the load is removed, allow the engine to idle for about 5 minutes. Shutting off the engine immediately after removing the load is very hard on the engine parts.



Keep on pulling the stop lever until the engine comes to a complete stop. Do not release the lever before the engine stops to prevent it from turning in reverse direction.

Engine equipped with speed control lever Engine equipped with stop lever

Move speed control lever to STOP position.

Pull stop lever on governor to STOP position.

Turn starter switch to OFF position, pull out the key, and turn OFF battery switch (electric starting).

OPERATION UNDER EXTREME WEATHERS

COLD WEATHER PRECAUTIONS

Engine oil and fuel

1. Use engine oil of lower S.A.E. viscosity grade in cold weather. (See page 42.)
2. Use fuel oil of lower pour point. (See page 39.)

Battery




1. Add distilled water to the battery before starting the engine to prevent electrolyte from freezing.
2. The specific gravity of electrolyte rises as the battery becomes increasingly charged. An electrolyte with S.G. of 1.20 or under freezes at -20°C (-4°F) or so. To avoid such a freeze-up, be sure to keep the battery fully charged at all times, so that the electrolyte S.G. will be 1.28 or over.
3. The lower the temperature, the smaller the capacity of the battery. Try to keep the battery as warm as possible, and make necessary provisions for protecting the battery from the deadly chill of the night.

Cooling water

1. When the temperature is below freezing, use an anti-freeze solution in the cooling system.
2. The larger the proportion of the solution, the lower is the freezing point of the mixture.
3. A commercial anti-freeze solution comes with printed directions. Read them carefully and prepare the mixture in proportions (water and solution) necessary for the lowest freezing temperature expected. This chart will serve as a rough guide for determining the percent proportion of the solution for the mixture:

• Anti-freeze solution

- a. Use a permanent-type anti-freeze solution.
- b. When using anti-freeze solution, mix fresh water, anti-freeze solution and rust inhibitor in a container, and pour the mixture into radiator.



Percent of solution and coolant freezing point (reference)

Freezing point $^{\circ}\text{C}$ ($^{\circ}\text{F}$)	-45 (-49.0)	-36 (-32.8)	-24 (-11.2)	-16 (3.2)	-9 to 0 (15.8 to 32)
Anti-freeze solution %	60	50	40	30	20



The anti-freeze solution is inflammable.
Be sure to handle it carefully.

OPERATION UNDER EXTREME WEATHERS

- c. Before filling up the cooling system with the anti-freeze coolant, flush the system clean.
- d. After the cold season, drain and flush the cooling system and fill it with soft water.

Operating in cold weather

1. During cold weather, the battery is weak, often resulting in hard starting. If the engine fails to start within 30 seconds, wait for about 2 minutes to allow the battery to recover strength, before cranking the engine again.
2. When starting the engine equipped with an air heater in temperatures below -5°C (23°F), or when the engine is hard to start, turn the starter switch to HEAT position for the length of time indicated below to preheat the engine. (See page 14.)

Starting temperature	$-5 - -15^{\circ}\text{C}$ ($23 - 5^{\circ}\text{F}$)	$-15 - -30^{\circ}\text{C}$ ($5 - -22^{\circ}\text{F}$)
Heating time	20 - 40 seconds	40 - 60 seconds

NOTE

Cold starting aids are available from your Mitsubishi dealer.


3. After starting the engine, warm it up thoroughly before applying the load.

NOTE

The oil pressure gauge will indicate high pressure when the oil temperature is low immediately after the engine is started. In such a case, keep on idling the engine without increasing engine speed. The oil pressure will drop to the normal level as the oil temperature rises.

At end of operating period

1. Drain out water and sediment that have accumulated in fuel system to prevent freezing.
2. Fill the fuel tank fully to drive out moisture-laden air for preventing condensation.
3. In case of the TK type engine, drain coolant from the air cooler to prevent freezing.



HOT WEATHER PRECAUTIONS

Engine oil

Use engine oil of higher S.A.E. viscosity grade in hot weather. (See page 42.)

Battery



At higher temperatures, the battery is likely to lose its energy by "self-discharging." Remove the battery from the engine, and store it in a cool place.

Cooling water

Keep the cooling system filled up at all times. Repair any leaking point upon discovery of such a point. Maintain the water pump, fresh-water cooler and thermostat in the best operable condition.

Operating in hot weather

Give particular attention to overheating of the engine by observing the water temperature gauge and oil pressure gauge. When the engine is overheated, remove the load rather slowly, and allow the engine to idle for gradual cooling.



⚠ WARNING

Dangerous is an attempt to pour cold water into the overheated radiator: you will have scalding hot coolant or steam spouted out from the radiator.

MAINTENANCE INSTRUCTIONS

1. Use service-meter or calendar intervals whichever occur first.
2. The maintenance schedule, which follows, is for a fully equipped engine.
3. The established intervals in the schedule are for an average job application. Service the engine earlier than scheduled intervals if necessary. (Service intervals depends on application, operating conditions, fuel oil and lubricating oil used in the engine. Adjust the service intervals to meet the actual operating conditions.)

4. Perform previous interval items at multiples of the original requirement.

Example: At 250 hours or 1 year, also perform those items listed in "10 hours or daily" and "50 hours or monthly."

Where the engine is used for stand-by duty, it must be thoroughly checked and kept in perfectly operable condition at all times. This is because it has to be started and run under severe conditions and is expected to give full performance no matter when it is put in operation. Test the engine periodically by running it in no-load condition, as follows:

Periodical testing

Test run	Once-a-week no-load test run for 5 to 10 minutes	Check for: Ease of starting Lube oil pressure Color of exhaust smoke Abnormal vibration and others
	Once-a-month load test run for 15 to 30 minutes (Operate at half the full load, min.)	

- Check, clean, wash, adjust.
- Change.
- ⊗ Rely on your Mitsubishi dealer if necessary.
- * Item to be performed after initial 50 hours of operation of a new, reconditioned or long-stored engine.

MAINTENANCE SCHEDULE

Group	Service		Service intervals						Remarks
			Every 10 hours or daily	Every 50 hours or monthly	Every 250 hours or 1 year	Every 500 hours or 2 years	Every 1000 hours or 3 years	Every 2000 hours or 5 years	
Engine	Valve clearance	Check		*			○		Ⓢ
	Bolts and nuts	Retighten		*			○		Ⓢ
	Walk-around checks		○						
Lubrication system	Oil pan	Check oil level	○						
		Check for water or fuel in oil		○					
		Change oil		*	●				Ⓢ
	Oil filter	Change		*	●				Also change when oil filter alarm lamp glows.
	Bypass oil filter	Change			●				Ⓢ
Fuel system	Fuel tank	Check fuel level	○						
		Drain water		○					
	Fuel filter	Drain water		○					
		Change					●		Ⓢ
	Injection nozzles	Check and adjust					○		Ⓢ
	Injection timing	Check and adjust					○		Ⓢ
Cooling system	Coolant	Check level	○						
		Change	Change coolant twice a year. Use rust inhibitor. Use anti-freeze solution in autumn if freezing temperatures are expected in winter. In spring, drain anti-freeze coolant and refill with soft water.						
	Radiator fins	Clean			○				Ⓢ
	Water pump/alternator drive belts	Check tension			○				

MAINTENANCE INSTRUCTIONS

Group	Service		Service intervals						Remarks	
			Every 10 hours or daily	Every 50 hours or monthly	Every 250 hours or 1 year	Every 500 hours or 2 years	Every 1000 hours or 3 years	Every 2000 hours or 5 years		
Cooling system (cont'd)	Fan friction rubber	Check			○					
	Heat exchanger	Wash						○	Ⓢ	
	Zinc rods	Change				●			Ⓢ	
Air inlet and exhaust systems	Air cleaner (paper-element type)	Check indicator	○							
		Clean element			○				Ⓢ	
		Change element					●			
	Air cleaner (silencer type)	Clean			○				Ⓢ	
	Exhaust muffler	Drain water			○					
	Air cooler	Clean						○	Ⓢ	
	Turbo-charger	Check						○	Ⓢ	
Starting system	Electric starting	Batteries	○						Check specific gravity from time to time	
		Alternator						○	Ⓢ	
		Starter						○	Ⓢ	
	Air starting	Oiler	Check oil level	○						
		Air filter (air-motor starting)	Drain water		○					
			Wash element				○			Ⓢ
		Air filter (direct-air starting)	Drain water		○					
			Wash element				○			Ⓢ
		Air tank	Check air pressure		○					
	Drain water				○					
Check safety valve for operation					○				Ⓢ	


MAINTENANCE INSTRUCTIONS

Group	Service	Service intervals						Remarks
		Every 10 hours or daily	Every 50 hours or monthly	Every 250 hours or 1 year	Every 500 hours or 2 years	Every 1000 hours or 3 years	Every 2000 hours or 5 years	
Protective devices operation	Water temperature rise $95 \pm 2^{\circ}\text{C}$ ($203 \pm 3.6^{\circ}\text{F}$)							Ⓢ Check when malfunction is suspected (Check engine for stand-by every year.)
	Engine oil pressure drop $1.5 \pm 0.15 \text{ kgf/cm}^2$ ($21 \pm 2.1 \text{ psi}$) [$0.1 \pm 0.01 \text{ MPa}$]					○		
	Overspeed (112 - 115%)							
Others	Vibration damper	Check					○	Leaks, cracks in rubber or flaws
		Change						Every 8000 hours
	Coupling (rubber-bushing type)	Check			○			Ⓢ Cracks or other defects
	Valves in pipeline	Check for setting	○					
	Speed control lever	Check	○					

MAINTENANCE INSTRUCTIONS

EVERY 10 HOURS OR DAILY

Walk-around checks




300085

Check for:


- Loose or missing bolts and nuts
- Abnormal vibration, noise and exhaust color
- Water, oil and air leaks
- Broken electric wire and loose terminals
- Loose pipe joints
- Excessive mist from breather

Radiator – Check coolant level




300160

Remove radiator filler cap and check.
Coolant should be visible in filler neck.
Check level in sight gauge on expansion tank.



301216


Oil pan – Check oil level



300084

Maintain oil level in operating range.


Speed control lever – Check




300082

Check to be sure linkage moves smoothly without any sign of interference.



Fuel tank – Check fuel level




Air cleaner indicator (paper-element type) – Check




Batteries – Check electrolyte level/specific gravity




Valves in pipeline – Check for setting



Oiler (air-motor starting) – Check oil level




Air tank (air-motor/direct-air starting) – Check air pressure




EVERY 50 HOURS OR MONTHLY



Fuel tank – Drain water





Fuel filter – Drain water




Oil pan – Check for water or fuel in oil




Air filter (air-motor starting) – Drain water



Air tank (air-motor/direct-air starting) – Drain water




Air filter (direct-air starting) – Drain water




Priming the fuel system

• **Fuel filter**



1. Loosen air vent plugs (1) on fuel filter.
2. Unlock priming pump handle (2) by twisting it to left, and operate it.
3. Tighten air vent plugs when flow of fuel at vent plug holes is free of air bubbles.

• **Fuel injection pump**





1. Loosen air vent plug (3) about 1.5 turns.
2. Unlock priming pump handle (2) by twisting it to left, and operate it. Stop priming when flow of fuel at vent plug hole is free of air bubbles. Lock priming pump handle by twisting it to right.
3. Tighten air vent plug (3).

CAUTION

- Priming pump handle might be unable to restore to its locked position if all air vent plugs are tightened in advance.
- Wipe off fuel spilled out of each vent plug hole.

MAINTENANCE INSTRUCTIONS

Changing the coolant (spring and autumn)



1. Normally, change coolant twice a year.
2. Use clean water that is low in scale forming mineral – such as “city” water.
3. Use anti-freeze solution with rust inhibitor before cold season (in autumn, for example) in an area where freezing temperatures are expected in winter. After cold season (in spring, for example), change coolant with clean water (described in 2 above) containing rust inhibitor.
4. In an area where freezing temperatures are not expected, change coolant once a year.

Procedure




1. Start engine, and run it until water temperature is 70 – 90°C. (158 – 194°F).
2. Raise lever at radiator filler cap (1) to relieve pressure, and remove cap.
3. Open radiator drain plug (2) and engine drain cocks (3) and (4), and allow coolant to drain.
4. Close drain cocks, and fill cooling system with flushing solvent (which does not attack rubber and metal). Run engine at 800 – 900 rpm for about 15 minutes. Stop engine, and drain flushing solvent.
5. Close drain cocks, fill cooling system with clean water and run engine at 800 – 900 rpm for about 10 minutes.
6. Stop engine, and open drain cocks. Rinse cooling system with clean water until water flowing out of system is clean.
7. Close drain cocks, and fill system with soft water up to specified level.

NOTE

When using anti-freeze solution, mix fresh water, anti-freeze solution and rust inhibitor thoroughly in a container, and pour the mixture into radiator.


Recommended rust inhibitor:

Use SANKO-YUSHI-make “Radipet [9]” in mixing proportion of 5% and 95% water.




EVERY 250 HOURS OR 1 YEAR

Air cleaner (silencer type) – Clean




Remove precleaner, and wash it with non-sudsing household detergent.

Air cleaner (paper-element type) – Clean element



Use pressure air – 7 kgf/cm² (99.5 psi) [0.7 MPa] maximum. Insert light inside clean, dry element and check. Replace element if pinholes or tears are found. Clean air cleaner case. If red signal appears soon after cleaning and resetting, replace element.




Oil filter and bypass oil filter – Change



Disassemble filter to check for metal particles trapped in its element. If such particles are found, consult your Mitsubishi dealer.


NOTE: Change filter when oil filter alarm lamp glows, regardless of recommended service interval.

Coupling (rubber-bushing type) – Check



Check bushings for cracks or other defects.


Air tank (air-motor/direct-air starting) – Check safety valve operation




Make sure that safety valve opens when air pressure rises higher than limit.

Air motor: 9.9 kgf/cm² (141 psi) [1 MPa]
 Direct air starting: 32 kgf/cm² (455 psi) [3 MPa]


Exhaust muffler – Drain water




Radiator fins – Clean





Fan friction rubber – Check



Water pump/alternator drive belt – Check tension




Oil pan – Change oil




EVERY 500 HOURS OR 2 YEARS


Zinc rods (sea-water cooling) – Change




Governor oil filter (Woodward type) – Change element



Air filter (air-motor starting) – Wash element



Air filter (direct-air starting) – Wash element



Valve clearance – Check (EVERY 1000 HOURS OR 3 YEARS)

300516

Check valve clearance in the firing order shown below. Turn crankshaft by fitting turning bar to crankshaft pulley or rotating turning gear (optional) with a wrench.


Firing order

Cylinder No.	1-5-3-6-2-4
--------------	-------------

Unit: mm (in.)

	Valve clearance (A) [Cold]
Inlet	0.6 (0.024)
Exhaust	0.8 (0.031)

Adjust clearance if it is out of specification.



MAINTENANCE INSTRUCTIONS

Valve clearance — Adjust (EVERY 1000 HOURS OR 3 YEARS)

Adjusting valve heights by means of valve bridge

1. Before adjusting valve clearance, adjust and equalize heights of two valves by bringing valve bridge into contact with tops of their stems.
If seat for one valve is more worn than that for the other, for example, valve heights become unequal to produce some clearance between bridge and stem of a less worn valve, resulting in difference in height (clearance) between two valves.
2. To adjust, loosen lock nut (2), and back off adjusting screw (1).
3. Hold rocker arm with finger, and slowly turn in adjusting screw (1) until it touches valve stem top. From this position, further turn it in about 10 degrees, and tighten lock nut to secure adjusting screw.

NOTE


Be sure to adjust clearance (B) between valve bridge (3) and valve rotator (4). If it reaches less than 0.5 mm (0.020 in.), valve cotter may come off.

Adjusting valve clearance

1. Loosen lock nut (6) of adjusting screw (5) on pushrod side of each rocker.
2. While measuring clearance with a feeler gauge, turn adjusting screw (5) in either direction to adjust

valve clearance.

3. After adjusting, tighten lock nut (6) to secure adjusting screw (5).




Using turning gear

1. Loosen bolts (1) and (2), and remove plate (3) from the groove of shaft (4). Then, push in shaft (4) all the way.
2. Turn shaft (4) with socket (5) and ratchet handle (6) to crank engine.
3. After cranking engine, pull out shaft (4), restore plate (3) into the groove of shaft (4), and tighten bolts (1) and (2). Make sure plate (3) is fitted in groove of shaft (4) properly.


CAUTION

Be sure to return the turning gear to RUN position when starting the engine.



EVERY 1000 HOURS OR 3 YEARS

Bolts and nuts – Retighten




301172

Retighten bolts and nuts on:

- Timing gear case
- Crankshaft pulley
- Fuel injection pump coupling and shaft
- Mounting brackets
- Exhaust manifolds
- Turbocharger

Check cylinder head bolts for tightness and retighten them if necessary. Tighten the bolts in sequence shown above.


Air cleaner – Change element



300121

Be sure to stop engine before removing element.

Fuel injection nozzles – Check and adjust




300150


Standard injection pressure: 350 kgf/cm² (4977 psi)
 Make sure spray occurs from all ten orifices at the same time.

NOTE

If exhaust smoke is abnormal, check nozzles for spray pattern. See Fuel Injection Nozzles – Check and adjust, pages 34, 35.



Fuel filter – Change



New filter

Old filter


301174

Apply oil to gasket of a new cartridge. Bring gasket into contact with sealing face of bracket, and tighten cartridge 1/2 to 3/4 rotation by hands.

Injection timing – Check and adjust

To adjust injection timing, proceed as follows:

1. Injection timing is indicated on caution plate attached to rocker cover.



301230

2. Engage turning gear with ring gear, and turn crankshaft in normal direction (clockwise as viewed from front side), bringing timing pointer into alignment with 1.6 index number mark punched on damper.

This crank position corresponds to top dead center on compression stroke in No. 1 cylinder. Its inlet and exhaust valves are fully seated, presenting clearance.


NOTE

Be careful not to confuse No. 1 cylinder with No. 6.


3. Turn back crankshaft about 60°, and turn it forward slowly to align timing mark (2) on pump coupling with pointer (1) on end face of pump case. In this position of crankshaft, read degrees of angle (injection timing) on scale (4) provided on damper, indicated by pointer (3). Minus (-) mark on scale and "BTDC" on caution plate mean before top dead center.

4. To adjust injection timing, proceed as follows:

Make sure that pointer is aligned with injection timing mark for No. 1 cylinder on damper, displace injection pump by loosening two coupling bolts (5) to align pointer (1) on pump case with timing mark (2) on pump coupling. Then, tighten one bolt and, after turning crankshaft, tighten the other. Again check injection timing by cranking engine.



300716




300811

Fuel injection nozzles – Check and adjust


● Removal

1. Disconnect nozzle connector (1) and injection pipe (2) inside the rocker cover from nozzle by loosening securing nut.
2. Unscrew gland nut (3) and, after taking off gland, remove nozzle from cylinder head.



301231


3. To remove nozzle, use nozzle remover (33591-10101).



301176

Injection pressure adjustment

1. Mount injection nozzle in a tester. Push down tester lever gently to pressurize. See if fuel spray begins at 350 kgf/cm² (4977 psi) [34.3 MPa].
2. Remove cap nut (4) on nozzle holder, and tighten or loosen adjusting screw (5) with a screwdriver. Tightening screw will increase pressure, and vice versa.



300212


3. After adjusting, put back on cap nut (4) and tighten it to 4 ~ 5 kgf-m (28.9 ~ 36.2 lbf-ft) [39.5 ~ 49.3 N-m].

Fuel spray pattern


1. Push down tester lever forcefully to let nozzle spray fuel. Spray should occur from all of the ten orifices at the same time, taking a cone shape with an angle of 155 degrees and consisting of finely and uniformly atomized fuel particles. Nozzle should terminate each spray without any after-dribble.
2. If spray pattern is poor, remove nozzle tip. To remove the tip, remove cap nut, loosen adjusting screw with a screwdriver, and loosen retaining nut (6). Be sure to follow these steps in order because the tip is spring-loaded.
3. Wash needle valve (7) and body (8).



When removing nozzle tip, be careful not to tap part (A) of the tip.



300123



400229

4. For cleaning fluid, use clean gasoline. After cleaning, assemble needle valve (7) and body (8) in clean diesel fuel.




Needle valve and body are selectively fitted: never change this combination by replacing either part.

5. Tighten cap nut (6) to 18 ~ 20 kgf-m (130 ~ 145 lbf-ft) [177 ~ 196 N-m].
6. If the foregoing adjustment and cleaning do not improve spray pattern, replace nozzle tip.

Installation

1. To install, use reverse of removal procedure. To install nozzle, tighten nut to 10 kgf-m (72 lbf-ft) [98 N-m] while keeping the gap between body and spring equally. After installing nozzle, check each fuel pipe joints for fuel leaks.
2. Remove rocker cover, and run engine at about 600 rpm Under this condition, check to be sure that no fuel leaks at points (A), (B) and (C). Then, stop engine, and install rocker cover.




301231

MAINTENANCE INSTRUCTIONS

EVERY 2000 HOURS OR 5 YEARS

Air cooler – Clean




301178

Remove air cooler, and direct pressure air in direction opposite to air flow.

- Remove scale from inside of fresh-water or sea-water pipes by inserting a bar.


Turbocharger – Check



300124

Turn compressor wheel by hand to listen for abnormal noise. If wheel is noisy, replace bearings.


Alternator – Check



301232

Visually check for any defects. Remove V-belt and check for abnormal rotation.


Vibration damper – Check



301179

Check for cracks in rubber and leaks of fluid.

Heat exchanger – Wash




300125

Wash outside surfaces of pipes with a brush by dashing fresh water over them.

Remove scale from inside of pipes by inserting a bar.

Starter – Check




301234

Visually check for any defects. Check pinion for operation.

STORAGE


Preparation for long-time storage (3 months or more)

Drain out engine oil, and fill in anticorrosive oil such as "P-10."



300127

Use a mixture of "P-9" anticorrosive oil and fuel oil in 50-to-50 ratio.




300128

Run engine at 800 ~ 1000 rpm for 5 ~ 10 minutes under no-load condition.



300129

Lubricate fitting or linkage of tension pulley, etc.




300132

Put volatile anticorrosive compound in air inlet and exhaust system in amount of 3 - 5 g (0.1 - 0.2 oz) of the compound per volume of 28 liters (7.4 U.S. gal).




300131

After stopping engine, drain out fuel and coolant.



300130

Cover up air cleaner, air inlet pipe, exhaust pipe, breather and turbocharger with adhesive tapes.




300133

Loosen V-belts.



300134

Cover up starter and alternator with polyethylene sheet.



300135

CAUTION

- When storing engine, keep it indoors whenever possible.
- Attach caution tags reading "Anticorrosive oil in engine," and "Before placing engine in service, fill in coolant and fuel."

NOTE


It is not necessary to change engine oil if storage period is shorter than 6 months.

Recommended anticorrosive oils

Specification	Brand name
P - 9	US Horton Rustbet Cosmolin
P - 10	US Horton Rustbet Cosmolin 1051, 1049

Add distilled water and recharge batteries. Remove batteries, clean terminals and keep batteries in a dry, cool place.

Cover engine with an awning sheet.




300136

STORAGE


Service during storage

Recharge batteries at least once a month.



300137

Preparing a stored engine for service



DIESEL FUELS, COOLING WATER AND LUBRICANTS

DIESEL FUEL





Mitsubishi diesel engines are designed to use diesel fuel oil meeting the requirements of JIS (Japanese Industrial Standard K2204). JIS K2204 diesel fuel oil nearly corresponds to Class 2-D fuel oil specified by ASTM (American Society for Testing and Materials) D975. For pour point, refer to the following chart:

Ambient temp. °C (°F)	-30 (-22)	-20 (4)	-10 (14)	0 (32)	10 (50)	20 (68)	30 (86)	40 (104)
Gas oil (JIS K2204)	No. 3, special		No. 3	No. 2	No. 1	No. 1, special		

Too much emphasis cannot be placed on the importance of using only clean diesel fuel. The clearance between the plunger and barrel of fuel injection pump and that between needle valve and body of injection nozzle are very small. This makes it evident that invisible particles of dirt which might pass through the filter can damage these finely finished parts.


Care of the fuel supply

1. Use a storage tank, and allow fuel to stand at least 24 hours in this tank before pumping it to the diesel fuel tank. Be sure to drain all water and sediment that has settled to the bottom of the storage tank before the diesel fuel tank is refilled.
2. Fill the diesel fuel tank at the end of the day. This will drive out moisture-laden air and prevent condensation.
3. When refilling the diesel fuel tank, use clean tools, such as a hand pump, funnels, containers, hoses, etc. Wipe filler cap clean before removing it. When operating the hand pump, keep in mind that there could be water and sediment that has settled to the bottom of storage tank; tap the needed amount of fuel from clean top portion.



DIESEL FUELS, COOLING WATER AND LUBRICANTS


4. Be sure to pour fuel through strainer in the filler opening. Use of a lint-free cheese cloth is a good practice for keeping dirt out.



5. Occasionally, open the drain cock of the storage and diesel fuel tank to drain off any water or sediment that may have accumulated.





Even clean top portion of fuel oil contains more or less dirt and water. Such dirt and water should be removed before they get inside the engine. This method of cleaning fuel oil is called "draining."



COOLING WATER



1. Water used in the cooling system must be soft, or as free from scale forming minerals as possible. Water, such as is available from the city water supply, is generally soft enough for the engine.
2. River water and well water are most likely to contain large amount of scale forming minerals and should not be used. Remember, some waters, particularly those pumped from ground in a mining or hot-spring area, contain active impurities harmful to cylinder liners of your engine.
3. Be sure to service the zinc rods installed in the sea-water circuits at regular intervals.




LUBRICANTS**Engine oil**

Careful attention to the following information on engine oil and its proper selection will add much to performance, economy and long life of your engine — a high-speed, high-load diesel engine.

1. Be sure to use engine oil of the API (American Petroleum Institute) service classification "CD."
2. Avoid mixing engine oils of different brands. In some cases, different brands are not compatible with each other and, when mixed, can seize parts such as piston rings, cylinder liners, etc. or abnormally wear moving parts. It is best to stick with one and the same brand of engine oil at successive service intervals.

**3. Draining and refilling**

To change the oil, drain it out while the engine is still hot after a duty operation: the oil is hot and will rush out, washing out the sludge. After draining, allow the engine to idle for about 5 minutes with a flushing oil in the oil pan and refill with fresh oil upon draining the flushing oil.

**Grease**

Use clean multi-purpose grease for your engine.



Cleanliness is important for handling the engine oil and grease. Use clean handling tools; wipe the filler cap, grease fittings and plugs clean; and handle them in a dust-free condition.


DIESEL FUELS, COOLING WATER AND LUBRICANTS

Selection

Refer to the following charts in selecting engine oil and grease:

Starting temperatures and grades of lubricants

Ambient temp. °C (°F)	-30 (-22)	-20 (4)	-10 (14)	0 (32)	10 (50)	20 (68)	30 (86)	40 (104)
Engine oil	SAE 10W		SAE 10W-30			SAE 30		SAE 40
Grease	NLGI No. 0, No. 1			NLGI No. 2				



Recommended engine oils

Manufacturer	Brand name
Mitsubishi	Diamond HDS-3-Engine oil
Esso	Essolube D-3
General	General Gemico Super S-3
Idemitsu	Apollo Oil Diesel Motive Custom
Kygnus	Mighty Oil S-3
Kyodo	Kyoseki Delmate D
Cosmo	Cosmo Multi Diesel, Cosmo Diesel CD
Mobil	Mobil Delvac 1300 series
Nippon	High Diesel S-3
Showa-Shell	Shell Rimula Z Oil White Parrot Super S-3


When using oils other than these recommended ones, they should be of API service classification "CD" and meet the requirements of MIL-L-2104C.

TROUBLESHOOTING

General instructions


(1) Think before acting

Upon noting an abnormal symptom, recall what you did the last time when you ran across the same symptom. If what you did was correct and successful, do the same. If the symptom noted is new to you, think of possible causes in accordance with the troubleshooting procedure which follows.




(2) Dust and dirt are often the ultimate causes.

“Wear” is usually a result of abrasive particles. When disconnecting or disassembling a part or component, be sure to keep off dust and dirt.




(3) Use genuine Mitsubishi parts.

Use only genuine parts to replace those that have failed or reached the service limit. When ordering, specify the needed replacement parts by referring to the Mitsubishi Parts Catalogues.



(4) Perform servicing work safely.


Use the right kind of hand tool to carry on each working step in repair work. Avoid injury to yourself and damage to the parts by using improper tool. When lifting or carrying a part too heavy for one person to handle, get another person's help and, if necessary, use a jack or a chain block to avoid personal injury.



TROUBLESHOOTING




- Never attempt to break the seals of the governor for maximum speed setting and maximum injection quantity setting.
- The maximum injection quantity of injection pumps has been set on the basis of the output horsepower of each engine verified in the bench test. Never attempt to vary this injection quantity in field.




Electric-starting engine




Starter will not crank engine or cranks slowly, resulting in a failure of engine to start








300060

Starter will crank engine, but engine will not start




Air-starting engine

• **Air-motor starting**










• **Direct-air starting**



TROUBLESHOOTING

Others

Complaint	Possible causes	Remedy
<p>Engine lacks power</p>  <p>500040</p>	<ul style="list-style-type: none"> • Incorrect grade of oil • Wrong type of fuel • Insufficient air (air cleaner clogged) • Engine overcooled • Fuel feed pump gauze filter clogged • Engine overheating • Valve clearance incorrect • Injection pump defective • Injection nozzles defective • Injection timing incorrect • Compression pressure low (cylinders and pistons worn) 	<ul style="list-style-type: none"> • Use recommended type and SAE number of oil. • Change. • Clean or change element. • Use radiator cover, replace parts. • Clean gauze filter. • Flush cooling system or replace parts. • Readjust. * Readjust or replace. * Readjust or replace. * Readjust. * Disassemble and replace parts.
<p>White or blue exhaust smoke</p>  <p>500041</p>	<ul style="list-style-type: none"> • Too much oil in crankcase • Oil viscosity too low • Engine overcooled • Thermostat defective (no water temperature rise) • Injection timing incorrect • Compression pressure low • Wrong type of fuel (low cetane number) 	<ul style="list-style-type: none"> • Fill only to correct level on gauge. • Refill with correct viscosity of oil. • Use radiator cover, or clean, test and replace thermostat. * Replace. * Readjust. * Disassemble and replace parts. * Change.
<p>Black or gray exhaust smoke</p>  <p>500042</p>	<ul style="list-style-type: none"> • Wrong type of fuel • Valve clearance incorrect • Injection pump defective • Compression pressure low • Insufficient air (air cleaner clogged) 	<ul style="list-style-type: none"> • Refill with correct type of fuel • Readjust. * Readjust or replace. * Disassemble and replace parts. • Clean or change element.
<p>High fuel consumption</p>  <p>500043</p>	<ul style="list-style-type: none"> • Injection pump defective • Injection nozzles defective • Injection timing incorrect • Wrong type of fuel • Compression pressure low • Insufficient air 	<ul style="list-style-type: none"> * Readjust or replace. * Readjust or replace. * Readjust. • Refill with correct type of fuel. * Disassemble and replace parts. • Clean or change air cleaner element. Check turbocharger.

Complaint	Possible causes	Remedy
High oil consumption  500044	<ul style="list-style-type: none"> • Too high oil level in crankcase • Incorrect grade of oil • Oil leaks • Cylinders and piston rings worn 	<ul style="list-style-type: none"> • Maintain oil level in operating range on gauge. • Use recommended type and SAE number of oil. • Retighten or replace. * Disassemble and replace parts.
Engine overheats  500047	<ul style="list-style-type: none"> • Radiator or heat exchanger dirty • Fan belt loose • Lack of coolant • Water pump defective • Thermostat defective 	<ul style="list-style-type: none"> • Wash. • Readjust. • Refill. * Replace. * Replace.
Low oil pressure  500045	<ul style="list-style-type: none"> • Lack of oil • Oil viscosity too low • Oil filter clogged • Oil pump defective • Oil pressure regulating valve defective • Oil pressure sensor circuit defective 	<ul style="list-style-type: none"> • Refill up to level. • Refill with correct viscosity of oil. • Replace element. * Readjust or replace. * Readjust or replace. * Replace.

NOTE

1. Consult your Mitsubishi dealer for items marked with asterisk (*).
2. Consult your Mitsubishi dealer for any item other than those listed above.
3. When communicating with your Mitsubishi dealer, give model designation, serial number and service meter reading of your engine.

SPECIFICATIONS

Model designation		S6R			S6R2		
		T	TA	TK	T	TA	TK
Type		Water-cooled, 4-stroke cycle, turbocharged					
			Aftercooled	Intercooled		Aftercooled	Intercooled
Number of cylinders		6					
Bore x stroke		170 x 180 mm (6.693 x 7.087 in.)			170 x 220 mm (6.693 x 8.661 in.)		
Piston displacement		24.5 liters (1495.1 cu in.)			30.0 liters (1830.8 cu in.)		
Fuel injection system		Direct					
Compression ratio		14.0 : 1					
Firing order		1-5-3-6-2-4					
Rotation		Counterclockwise as viewed from flywheel side					
Dimensions	Length	1722 mm (67.8 in.)					
	Width	1050 mm (41.3 in.)					
	Height	1498 mm (60 in.)			1578 mm (62.1 in.)		
Dry weight		2250 kg (4960 lb)	2300 kg (5070 lb)	2350 kg (5180 lb)	2400 kg (5290 lb)		
Fuel system	Fuel	Diesel fuel oil ASTM No. 2-D					
	Injection pump	Mitsubishi PS6 type					
	Governor	RHD6 (hydraulic all-speed type)					
	Fuel filter	Paper-element (spin-on type)					
	Injection nozzles	Hole type					
	Injection pressure	350 $^{+5}_0$ kgf/cm ² (4977 $^{+71}_0$ psi) [34.3 $^{+0.5}_0$ MPa]					
Lubrication system	Type	Pressure feed (by oil pump)					
	Oil	API CD class					
	Capacity	100 liters (26.4 U.S. gal) approx.					
	Oil filter	Paper-element type (with bypass filter, spin-on type)					
	Oil cooler	Water-cooled multi-disc type (built in crankcase)					
Cooling system	Type	Forced circulation by centrifugal pump					
	Capacity (engine)	50 liters (13.2 U.S. gal) approx.			55 liters (14.5 U.S. gal) approx.		
	Fresh-water pump	Centrifugal type					
Starting system		Electric or air (air motor or direct air)					
Starter		24 V – 7.5 kW x 1					
Alternator		24 V – 30 A					
Turbocharger		Mitsubishi TD type					

TIGHTENING TORQUE

Important bolts and nuts

Parts attached	Thread Diam. — Pitch mm (in.)	Width across flats mm (in.)	Standard torque			Remarks
			kgf-m	lbf-ft	N-m	
Cylinder heads	22 — 2.5 (0.87 — 0.098)	27 (1.06)	55	398	539	[Wet]
Rocker shaft	14 — 2 (0.55 — 0.079)	17 (0.67)	15	108	147	
Main bearing caps	22 — 2.5 (0.87 — 0.098)	27 (1.06)	50	362	490	[Wet]
Timing gear case	16 — 1.5 (0.63 — 0.059)	24 (0.94)	22	159	216	
Oil pan	12 — 1.25 (0.47 — 0.049)	17 (0.67)	6	43	59	
Mounting brackets (rear)	16 — 1.5 (0.63 — 0.059)	24 (0.94)	22	159	216	
Mounting brackets (front)	12 — 1.25 (0.47 — 0.049)	17 (0.67)	11	80	108	
Connecting rod bearing caps	22 — 1.5 (0.87 — 0.059)	27 (1.06)	55	398	539	[Wet]
Crankshaft pulley, damper	22 — 1.5 (0.87 — 0.059)	32 (1.26)	50	362	490	
Flywheel	22 — 1.5 (0.87 — 0.059)	32 (1.26)	55	398	539	[Wet]
Idler gear	10 — 1.25 (0.39 — 0.049)	14 (0.55)	3	22	29	
Injection pump drive gear	30 — 1.5 (1.18 — 0.059)	46 (1.81)	40	289	392	
Idler shaft	12 — 1.25 (0.47 — 0.049)	17 (0.67)	11	80	108	
Injection pump drive shaft case	12 — 1.25 (0.47 — 0.049)	17 (0.67)	11	80	108	
Oil pump idler gear	12 — 1.25 (0.47 — 0.049)	17 (0.67)	7	51	69	Apply locktite 262
Water pump pulley nut	24 — 1.5 (0.94 — 0.059)	36 (1.42)	25	181	245	
Injection pump coupling	12 — 1.25 (0.47 — 0.049)	17 (0.67)	11	80	108	
Laminated plate	12 — 1.25 (0.47 — 0.049)	17 (0.67)	8.5 — 9.5	61 — 69	83 — 93	
Nozzle inlet connectors	16 — 1.5 (0.63 — 0.059)	19 (0.75)	6.5 — 7.5	47 — 54	64 — 74	
Nozzle gland studs	14 — 1.5 (0.55 — 0.059)	22 (0.87)	10	72	98	
Nozzle holder set screw cap nuts	14 — 1.5 (0.55 — 0.059)	22 (0.87)	4 — 5	29 — 36	39 — 49	
Nozzle tip nuts	28 — 1.5 (1.10 — 0.059)	27 (1.06)	18 — 20	130 — 145	177 — 196	

Remarks: Apply a coat of engine oil to the threads of parts indicated as [Wet].

TIGHTENING TORQUE


Parts attached	Thread Diam.—Pitch mm (in.)	Width across flats mm (in.)	Standard torque			Remarks
			kgf-m	lbf-ft	N-m	
Rocker case	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Camshaft	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Thrust plate	12 – 1.25 (0.47 – 0.049)	17 (0.67)	6	43	59	
Hanger	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Oil jet check valve	12 – 1.75 (0.47 – 0.069)	17 (0.67)	3.5	25	34	
Rear plate	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Oil pump	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Water pump	12 – 1.25 (0.47 – 0.49)	17 (0.67)	6	43	59	
Fan drive camshaft gear	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Fan drive shaft gear	30 – 1.5 (1.18 – 0.059)	46 (1.81)	40	289	392	
Fan plate	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Injection pump bracket	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Injection pump flywheel	24 – 1.5 (0.94 – 0.059)	36 (1.42)	24 – 26	174 – 188	235 – 255	
Plunger assembly	12 – 1.25 (0.47 – 0.049)	19 (0.75)	8 – 8.5	58 – 61	78 – 83	
Delivery valve holder	30 – 1.5 (1.18 – 0.059)	32 (1.26)	24 – 26	174 – 188	235 – 255	
Injection pump coupling shaft	14 – 1.5 (0.55 – 0.059)	22 (0.87)	17 – 18	123 – 130	167 – 177	At slit
Governor drive case	12 – 1.25 (0.47 – 0.049)	17 (0.67)	11	80	108	
Starter	12 – 1.25 (0.47 – 0.049)	17 (0.67)	6	43	59	

General bolts and nuts

Screw thread mm (in.)		Standard torque					
Diameter	Pitch	w/spring washer			w/o spring washer		
		kgf-m	lbf-ft	N·m	kgf-m	lbf-ft	N·m
8 (0.31)	1.0 (0.039)	1.8	13	18	2.2	16	22
	1.25 (0.049)	1.8	13	18	2.1	15	21
10 (0.39)	1.25 (0.049)	3.6	26	35	4.2	30	41
	1.5 (0.059)	3.4	25	33	4.0	29	39
12 (0.47)	1.25 (0.049)	6.5	47	64	7.6	55	75
	1.75 (0.069)	6.0	43	59	7.1	51	70
14 (0.55)	1.5 (0.059)	10.4	75	102	12.2	88	120
	2.0 (0.079)	9.8	71	96	11.5	83	113
16 (0.63)	1.5 (0.059)	15.8	114	155	18.6	135	182
	2.0 (0.079)	15.0	108	147	17.6	127	173
18 (0.71)	1.5 (0.059)	22.9	166	225	26.9	195	264
	2.5 (0.098)	20.7	150	203	24.4	176	239


CIRCUIT DIAGRAMS

FUEL SYSTEM



301235


LUBRICATION SYSTEM



301236


COOLING SYSTEM

With radiator (PTA)



301237


Single cooling system (fresh water series piping) (PTK)



301238


CIRCUIT DIAGRAMS

Dual cooling system (parallel piping) (PTK)



301243

ELECTRICAL SYSTEM




- Remarks: 1. The circuit shown above is standard and varies from one specification or application to another.
2. The circuit and its components are to be prepared in field.
3. Asterisk (*) indicates the parts mounted on the engine. Parts having no asterisk are to be prepared as a single item.

301239


AIR-STARTING SYSTEM

Air-motor starting



301240

Direct-air starting



301241