


# Operating Instructions

# MODEL "WM"

## WASHING MACHINE MOTOR

### Adjustment and Repair Information

### Parts List



### INDEX

	Page
Starting the "WM" Motor.....	3
Servicing Reference Chart.....	4
Instructions for Adjustment and Repair.....	4
Repair Parts .....	10
Parts List.....	11-13
Guarantee .....	13
Illustrated Parts .....	14
Nation-Wide Service Organization .....	15
Authorized Central Service Distributors.....	15


**Read these instructions carefully before operating this Motor for the first time.**

Guessing how to run it may cause you unnecessary inconvenience, aggravation or failure to receive the fine service that is built into it.

**There is a right way to operate the "WM" Motor. This book tells you how.**

Each Briggs & Stratton Motor is carefully tested and adjusted at the factory before packing for shipment, and if correctly operated will perform beyond your expectations.

**DO NOT START THIS MOTOR UNTIL YOU HAVE READ CAREFULLY "STARTING AND OPERATING THE MODEL "WM" MOTOR" ON PAGE 3**



# Starting the Model "WM" Motor

Before Starting the Motor.....	Paragraph 1
How to Start.....	2
Failure of Motor to Start.....	3

How to Stop.....	Paragraph 4
General Data.....	5

**1. BEFORE STARTING THE MOTOR.** Fill the crankcase with Mobiloil Arctic or any other high grade oil not heavier than S. A. E. No. 20. A HEAVIER OIL MUST NOT BE USED. Remove blue oil filler plug, slowly pour the oil directly on top of the oil drain plug so that the oil runs down the sides of the plug into the reservoir. This will prevent spilling. Crankcase holds  $\frac{1}{3}$  pint. Fill the gas tank with a good grade of clean regular gasoline. Tank holds 1 quart. Do not mix oil and gasoline. See paragraphs 11 to 19.

**2. HOW TO START.** Pull up the carburetor choke knob. Step down **quickly** on starter pedal and repeat **rapidly** until motor fires. As the motor warms up, gradually adjust choke until motor operates smoothly. Operate carburetor choke the same as you operate the choke on your automobile. A hot motor does not require as much choking as a cold motor. See paragraph 20.

**3. FAILURE OF MOTOR TO START.** If motor fails to start after a reasonable number of trials do not make any adjustments until you have studied the instructions referred to in the **Servicing Reference Chart**, on page 4.


**4. HOW TO STOP.** Pull the choke knob all the way out and hold until motor stops firing.

**5. GENERAL DATA.** You will find your Briggs & Stratton motor substantially built. It is made of high grade materials by skilled workmen, in a factory fully equipped with the most modern machinery. Before it was shipped, it received many tests and careful inspections.

**6.** Your motor will give you better service if you do not tinker with it. This does not mean, however, that it does not require a certain amount of attention. Give it the right kind of fuel, oil and care. Keep it clean both inside and out. You will be well repaid in trouble-free, satisfactory service.

**7.** If you should experience any difficulty, follow the instructions referred to in the **Servicing Reference Chart** on page 4. If you cannot easily remedy it, consult your dealer, or a nearby Briggs & Stratton Authorized Central Service Distributor. See page 15.

Briggs & Stratton 4-Cycle Motor, Model "WM" — Plate No. 1



# Servicing Reference Chart

## MOTOR FAILS TO START

	Paragraph
Out of Gasoline.....	1-16
Out of Oil.....	1-13-52
Dirt or Gum in Fuel System.....	16 to 19
Incorrect Use of Choke.....	20
Carburetor Out of Adjustment.....	22 to 25
Spark Plug Dirty.....	28-30
Ignition Cable Grounded.....	31
Magneto.....	32 to 40
Poor Compression.....	41 to 49
Starter Clutch.....	60

## MOTOR STOPS

Out of Gasoline.....	1-16
Out of Oil.....	1-13-52
Dirt or Gum in Fuel System.....	16 to 19
Motor Overheated.....	13-52-54-58
Motor Overloaded.....	58

## MOTOR OVERHEATS

	Paragraph
Out of Oil.....	1-13-52
Oil Needs Changing.....	14-15
Oil Too Heavy.....	14-15
Carburetor Out of Adjustment.....	22 to 25
Poor Spark.....	28 to 40
Carbon.....	54
Overloaded.....	58

## MOTOR LACKS POWER

Lack of Oil.....	1-13-52
Add or Change Oil.....	13 to 15
Carburetor Out of Adjustment.....	22 to 25
Motor Not Up to Speed.....	28-27
Poor Spark.....	28 to 40
Poor Compression.....	41 to 49
Carbon.....	54
Air Cleaner Clogged.....	55
Muffler or Exhaust Hose Fitting Clogged.....	56
Exhaust Tubing.....	57
Overloaded.....	58

# Instructions for Adjustment and Repair

	Paragraph
Operating Requirements.....	8
How a 4-Cycle Motor Works.....	10
Keep the Motor Clean.....	11
Use the Right Kind of Oil.....	12
Add Oil Regularly.....	13
Change Oil Frequently.....	14
Use Clean Gasoline.....	16
Avoid Gummy Gasoline.....	17
To Clean the Fuel Lines.....	19
Correct Use of the Choke.....	20
To Prime the Motor.....	21
To Adjust the Carburetor.....	22
To Remove and Replace Carburetor.....	24
To Remove and Replace Carburetor Throttle.....	25
Governor—Correct Motor Speed.....	26
The Ignition System.....	28
To Check for Spark.....	29
Spark Plug Adjustment.....	30
Ignition Cable.....	31
To Remove and Replace Flywheel.....	32
To Remove and Replace Magneto.....	34

	Paragraph
Magneto Timing.....	35
To Adjust and Clean Contact Points.....	36
To Replace Condenser.....	37
To Replace and Adjust Armature.....	39
Cylinder Head.....	41
Compression.....	42
Valve Adjustment.....	43
Piston.....	47
Piston Rings.....	49
Piston Pin.....	50
Connecting Rod.....	51
Oil Pump.....	52
Oil Leaks.....	53
Carbon.....	54
Air Cleaner.....	55
Muffler or Exhaust Hose Fitting.....	56
Exhaust Tubing.....	57
Overload.....	58
Starter Pedal Adjustment.....	59
Starter Clutch.....	60
Parts.....	61


**8. OPERATING REQUIREMENTS.** A gasoline motor to operate properly must have all parts in correct adjustment to provide good ignition, carburetion, compression and cooling. And of equal importance, the oil and gasoline used must be **clean** and of the recommended grades. The following instructions fully explain the simple adjustments and offer operating recommendations that will

assure you complete satisfaction. We urge you to carefully observe them.

**9.** The reliability, economy and ease of starting which characterize this motor are due in part to the fact that it is of the 4-stroke cycle design commonly called "4-cycle," the same design used in all automotive motors. As the name indicates there are four strokes to one complete power cycle.

**10. HOW A 4-CYCLE MOTOR OPERATES.** On the **intake stroke** the piston goes down, producing a vacuum in the cylinder, thereby drawing fuel up through the carburetor so that the space above the piston becomes filled with combustible gas. During this stroke the intake valve is open. Next the piston comes up on the **compression stroke** with both valves closed. At the top of the compression stroke a spark occurs at the spark plug, firing the highly compressed gas. This produces an explosion above the piston which forces it down on the **power stroke**. Both valves are closed. On the next upstroke of the piston, called the **exhaust stroke**, the exhaust valve is open, and the burned gases driven out. See plate No. 2.

The 4-Stroke Cycle  
Plate No. 2



**11. KEEP THE MOTOR CLEAN.** It will pay you to keep your motor clean both inside and outside. See that no dirt or water enters motor when filling with oil or gasoline. As a precautionary measure always wipe off the gasoline cap and oil filler plug, as well as around them before refilling. Dirt in the motor or gasoline tank will cause trouble and even serious damage.

**12. USE THE RIGHT KIND OF OIL.** Correct lubrication is important. We recommend the use of MOBIL OIL "ARCTIC" or other high grade oil with similar characteristics having a low carbon residue and a body not heavier than S. A. E. No. 20. **A heavier oil which might be satisfactory in a tractor or for lubricating farm machinery must NOT be used.** Do not mix oil with the gasoline. This 4-cycle motor is provided with an independent efficient pump and splash lubrication system. The pump maintains the proper oil level in the oil trough and a dipper on the connecting rod dips into the trough throwing the oil to all moving parts. There are no external parts which require separate oiling.


**13. ADD OIL REGULARLY.** A motor which is run without oil will be ruined within a few minutes. To avoid the possibility of such an occurrence and the resulting expense, always fill the oil reservoir at the blue plug to the top of the filler plug opening after each five hours of motor operation. Capacity of oil reservoir is  $\frac{1}{2}$  pint.

**14. CHANGE OIL FREQUENTLY.** After every twenty-five hours of motor operation, the oil should be completely drained from the crankcase. Do not remove motor from its mounting base. Remove blue oil filler plug and use special wrench furnished with your motor to unscrew oil drain plug located in base plate and remove it through oil filler opening. The old oil will drain straight down through this hole in the base plate into the pan or other receptacle you use. See plate No. 3. We do not recommend flushing out with kerosene. Replace the drain plug, refill with fresh oil and replace the blue filler plug.

**15.** In the normal running of any motor, small particles of metal from the cylinder walls, pistons and bearings will gradually work into the oil. Dust particles from the air also get into the oil.

Sludge, a gummy mass, forms which clogs up the oil passages. If the oil is not changed regularly, these foreign particles cause increased friction and a grinding action which shortens the life of the motor. Fresh oil also assists in cooling, for old oil gradually becomes thick and loses its cooling as well as its lubricating qualities.

How to Drain Oil  
Plate No. 3



**16. USE CLEAN GASOLINE.** A good grade of clean, fresh, regular gasoline is recommended. Too high test gasoline may form vapor-lock in gas line when motor gets hot. This interrupts the flow of gasoline and causes motor to stop. Be sure that the small vent hole in the gasoline tank cap is not clogged up, for air must enter the tank to allow the gasoline to flow to the carburetor. Test by blowing through top of cap.


**17. AVOID GUMMY GASOLINE.** If you experience trouble with a gummy, sticky substance with a peculiar sharp obnoxious smell, change to another grade of gasoline. This gum comes from the gasoline and clogs carburetor, gas line, gasoline tank, check valve, etc. You can check your gasoline by evaporating a half pint in an open dish. If a quantity of gum remains, try another kind that is clean and fresh.

**18.** You can avoid most trouble from gum if you will keep the tank full when you are not using the motor. If you use it only occasionally, drain tank completely and refill when motor is used again. The reason for this is that evaporation of stale gasoline causes most gum deposits.

**19. TO CLEAN THE FUEL LINES.** Disconnect the gasoline line at the carburetor and also at the gas tank. Blow through the gas line to clear. Remove the gas tank feed pipe which is screwed into the gas tank proper. At its base you will find a screen which may be clogged. To determine whether this pipe itself is clear, blow through the pipe from the screen end. There is a check ball in the base of this pipe which must be free. See plate No. 4. Check ball must close air passage when blowing through opposite end of pipe. When replacing gas pipe in tank,

be sure to place gasket between gas tank and gas pipe nut. **IMPORTANT:** If you find a gummy varnish-like substance, alcohol or acetone will dissolve it. See paragraphs 17 and 18.

Gas Pipe  
Plate No. 4



**20. CORRECT USE OF THE CHOKE.** The correct carburetor setting (see paragraph 23) gives the motor the best mixture to run on when it is hot. For starting, it is necessary to choke the carburetor to get a rich mixture, because cold gasoline does not vaporize readily. A warm or hot motor requires very little choking. Until you become familiar with your motor, however, you may make the mistake of not choking the carburetor enough or you may choke it too much. If motor fails to start after cranking three or four times with the choke up, or closed, try cranking two or three times with the choke part way down and then all the way down, or open. Use motor choke the same as you use an automobile choke.

**21. TO PRIME THE MOTOR.** The motor may fail to start for the reason that either the carburetor is incorrectly adjusted or dirty, or the fuel line or gas pipe check valve in the gasoline tank is dirty or clogged, or you are out of gasoline. To determine the cause, prime the motor by removing the spark plug and pour a half teaspoonful of gasoline into the spark plug opening. Replace the spark plug and crank the motor. If it fires for three or four revolutions and stops, the difficulty is definitely in the fuel system. See paragraphs 19, 22 to 25. If motor will not fire at all, check the ignition system, see paragraphs 28 to 40; also compression, paragraphs 42 to 49.


**22. TO ADJUST THE CARBURETOR.** The carburetor on the Model "WM" motor is of the suction type. The gasoline supply is regulated by a needle valve. The throttle is automatically controlled by the governor, see paragraph 26.

**23.** To adjust the carburetor, completely close needle valve by turning to right or clock-wise as far as possible. Do not screw up too tight or use force when closing needle valve, or the seat, or taper of needle valve may be damaged. From closed position, open needle valve one complete turn. After the motor has been started and warmed up with the choke wide open, make final adjustment by turning the needle valve to the point at which motor operates most smoothly with full load. This setting will also take care of starting with use of the choke. When starting cold motor, if it is necessary to keep choke partially closed several minutes before motor runs smoothly, carburetor setting is too lean and needle valve should be opened a notch or two—turn to left. If carburetor throttle acts sluggish or motor does not govern smoothly, it is usually caused by a dirty or gummy throttle. See paragraph 25. For governor adjustments see paragraph 26.

**24. TO REMOVE AND REPLACE CARBURETOR.** Disconnect gasoline line from carburetor. Remove blower case. Remove the governor blade by pulling out the governor rod and spacer washer which holds it in place. See plate No. 5. Remove valve cover plate. Loosen two carburetor mounting bolts. Carefully

remove carburetor and, without stretching governor spring, unhook its lower end. Do not remove governor spring or link from throttle arm. To replace, reverse the operations as performed above, inserting spacer washer between outside governor blade bearing and governor rod ear.

Carburetor and Governor Hook-up  
Plate No. 5



**25. To Remove and Replace Carburetor Throttle.** On models with die cast throttle lever and throttle (see plate No. 9, Fig. 1). To clean the carburetor throttle, remove the carburetor as explained in paragraph No. 24. Then remove throttle cotter pin and washer and slip throttle from body. Clean in alcohol or acetone. Do not scrape.

On models with steel throttle lever and brass sleeve (see plate No. 9, Fig. 2).

Carburetor Throttle  
Plate No. 9, Fig. 1





Plate No. 9, Fig. 2



To clean the carburetor throttle, remove the carburetor as explained in paragraph No. 24. To remove the throttle, loosen the set screw which holds the choke valve and carburetor throttle in place. The throttle is easily removed with the fingers. The throttle is part of an assembly consisting of the throttle, sleeve, throttle lever and governor spring. Clean in alcohol or acetone. Do not scrape. To reassemble, replace choke valve, insert throttle assembly into the carburetor body as far as it will go, lining up holes in sleeve with locating hole in body and with throttle stop between forked points of throttle lever. Push the sleeve of throttle in place by inserting a small tool between throttle lever and sleeve, so that set screw holes line up. Tighten set screw, being sure that choke valve friction spring, plain washer and lockwasher are in proper place.


**26. GOVERNOR—CORRECT MOTOR SPEED.** The speed of your model "WM" motor is automatically maintained under varying loads by a pneumatic governor. It is operated by the air current blown by the flywheel.

**27.** The governor was carefully adjusted at the factory to maintain normal speed under load. Do not re-adjust unless absolutely necessary. A sliding speed adjuster is located beneath carburetor. Moving the slide down increases motor speed, up decreases motor speed. Tap lightly to adjust. See plate No. 5. Recommended speed is from 2200 to 2400 R.P.M. The idling speed is set at 1100 R.P.M. On washing machine application, adjust motor speed to operate washing machine agitator at speed recommended by the manufacturer of your washer. To remove or replace governor parts, see paragraph 24.


**28. THE IGNITION SYSTEM.** The spark is produced by a high tension magneto consisting of armature, condenser, contact points and rotating magnets cast in the flywheel. This is a simple self-contained system which is very reliable. It also does away with batteries. The ignition current is sent into the motor cylinder through the ignition cable and spark plug. The magneto itself as well as the cable and spark plug must all be in proper condition and adjustment to insure a good hot spark.

**29. TO CHECK FOR SPARK.** To prove that a satisfactory spark is being delivered by the magneto, remove the ignition cable from the plug. Hold ignition cable terminal about  $\frac{1}{8}$ " from any metal part of the cylinder head (keep hand on insulated part of the cable to avoid a shock). Turn motor with starter, and if the spark jumps this gap the entire ignition system, with the exception of the spark plug, is O. K. See plate No. 7. (To check spark plug see paragraph 30.) If no spark, check cable, see paragraph 31, and refer to magneto adjustments paragraphs 32 to 40.

Checking Spark  
Plate No. 7



Spark Plug  
Plate No. 8




**30. SPARK PLUG ADJUSTMENT.** Spark plugs should be cleaned occasionally and points reset to .020". Points burn away in service. The porcelain is to prevent the spark from jumping anywhere except at the gap, and if cracked or broken it will prevent plug firing. Water on the outside of the spark plug may permit the high voltage current to leak over the surface of the porcelain. Dirt or carbon on it will do the same thing. Always keep

a new plug on hand. We recommend the use of Champion No. J8 or its exact equivalent.

**31. IGNITION CABLE.** Insulation must not be broken or soaked with oil or water or grounded in any way where it touches the motor, or it will interfere with good ignition. To check cable all the way to magneto it is necessary to remove blower case. Ignition cable should be securely wound to the secondary terminal loop of the coil. See plate No. 12.


**32. TO REMOVE AND REPLACE FLYWHEEL.** The flywheel is securely mounted to the crankshaft by means of a taper fit, a key, a LEFT hand nut and a spring washer. Remove the blower housing. Bolt or clamp motor to work bench. Place a wood block under flywheel fin on right side of flywheel or a small rod between fins, to hold it rigid and prevent turning as you loosen nut. See plate No. 9. Use large wrench, 10-inch or bigger. To start nut, to the RIGHT, tap end of wrench handle lightly with hammer. Tap carefully or a broken fin may result which will throw flywheel out of balance. After nut is removed, loosen flywheel by placing the wood block against end of crankshaft and striking with a hammer. Pull off flywheel.

Removing Flywheel  
Plate No. 9



**33.** To reassemble, locate flywheel on crankshaft with key and install spring washer with the hollow or concave side next to the flywheel. Turn nut to LEFT until tight. Then use block under fin on left side of flywheel or rod between fins to hold flywheel rigid and draw nut up very tight by tapping wrench handle with hammer.

Correct End Play  
Plate No. 10



**34. TO REMOVE AND REPLACE MAGNETO ASSEMBLY.** After removing the flywheel as explained in paragraph 32, remove cover plate from the valve chamber, remove carburetor, see paragraph 24, unhook governor spring, detach the ignition cable from spark plug, and unscrew the four magneto plate mounting screws. To replace use same gasket between the plate and crankcase, or, if damaged, a new gasket, see part numbers 67307, 67597, 67607, of proper thickness to get correct end play of .003" to .006" between magneto bearing and crankshaft thrust faces, as shown in plate No. 10. Use lockwashers under mounting screws.

**35.** Magneto assembly is always correctly timed with the motor when the flywheel is assembled to the tapered crankshaft with a key and securely held in place with LEFT hand threaded nut.


Do not attempt to change the timing by relocating any parts or filing crankshaft timing flat. Always use soft key part No. 61760 —if steel key is used and flywheel becomes loose, it will damage the keyway in the crankshaft.

**36. TO ADJUST AND CLEAN CONTACT POINTS.** Remove blower housing and flywheel. Turn crankshaft by hand to see if contact points open and close properly. Points must be clean and line up squarely to make good electrical contact. Do not file contact points—use fine sand paper or fine grit hone to clean points. Adjust gap to .020" by loosening the adjusting lock screw and moving contact point bracket up or down. When proper gap is obtained tighten lock screw securely. If either or both points become badly pitted or burned and need replacement, always order complete assembly Part No. 29667.

**37. TO REPLACE CONDENSER.** A leaky or weak condenser may cause the motor to start hard, to sputter or misfire under load. If motor misfires after checking gasoline line, carburetor, spark plug, cable and contact points, install a new condenser. Both the condenser lead and armature lead must be soldered to brass arm, see plate No. 11. Be sure to push condenser lead down between condenser and hub of magneto plate so it cannot rub against flywheel.

**38.** If after new condenser has been installed the ignition system does not deliver a satisfactory spark, we recommend sending the complete magneto and the flywheel to the nearest Briggs & Stratton Central Service Distributor, listed on page 15, for proper adjustment.


Contact Points and Condenser  
Plate No. 11



**39. TO REPLACE AND ADJUST ARMATURE.** Remove primary armature lead wire of coil from brass arm on contact bracket. Remove high tension ignition cable from secondary terminal-loop in coil. Unscrew four armature mounting screws. After installing new armature be sure that condenser lead wire and armature lead wire from coil are soldered to brass arm on contact bracket. See plates Nos. 11 and 12. Replace mounting screws inserting loop of ground wires under screw and draw screws up tight.

**40.** Air gap of .008" to .012" must be maintained between armature core ends and flywheel. Gap must only be sufficient to prevent rubbing but not over .012", or poor ignition will result. To adjust gap to proper clearance, loosen the four armature mounting screws, slide armature assembly up and place correct feeler gauge or 3 thicknesses of newspaper between rim of flywheel and armature core ends. Lower armature assembly until core ends rest on gauge or paper and tighten mounting screws securely. See plate No. 12.

Complete Magneto Assembly  
Plate No. 12



**41. CYLINDER HEAD.** The cylinder head is held on with six cap screws. When the cylinder head has been removed for the purpose of cleaning carbon or grinding valves, care should be used in replacing it. Use a new gasket if possible. Otherwise, clean the old one and coat both sides with cup grease. We do not recommend the use of shellac on cylinder head gaskets. Tighten each cap screw a little at a time so that the cylinder head is pulled down evenly. Screws need be only moderately tight.

**42. COMPRESSION.** Proper compression is obtained when valves seat properly, gaskets do not leak and piston and rings are properly fitted. When tuning up a motor, it is always well to check compression. This is done by turning the motor over slowly. If a point of resistance is offered every other revolution, compression should be satisfactory. If motor turns over without compression resistance for a full cycle, a worn piston, piston rings, cylinder wall, or leaky valves or leaky gaskets are present. See that spark plug has a gasket under it and is drawn up tight. Also check cylinder head gasket and tighten cylinder head bolts.


**43. VALVE ADJUSTMENT.** To check valve clearance remove valve cover plate on cylinder below carburetor. The correct clearance on the exhaust valve is .008" and on the intake valve .006" when the motor is cold. Tappet clearance is adjusted by grinding required amount from the end of valve stem. End of stem must be square with the stem proper.

44. To remove the valves, remove cylinder head and, if not dismantled, drain oil from crankcase. Invert cylinder. Compress the valve spring with a screw driver and pull out valve retainer pin with long nose pliers. Tilt cylinder back far enough to allow valve to drop, permitting its stem to clear the spring. Pry the spring out with screw driver. To replace, reverse the operations as performed above.

45. To reseat valves, grind in same manner as automobile valves. If valves stick they may be coated with gum or carbon. To remove gum use alcohol or acetone. Clean valve stems thoroughly with wire brush or emery cloth. Also scrape all carbon from valve ports.

46. The timing of the valves is taken care of by the meshing of the cam gear with the gear on the crankshaft. These gears are properly meshed when the mark on the cam shaft gear is in line with the mark on the crankshaft collar.

Valve Timing — Plate No. 13



47. **PISTON.** The piston in the model "WM" motor is made of a special aluminum alloy which is very light in weight. The clearance between the piston and cylinder wall is .005" to .0065". This clearance is to compensate for the expansion of aluminum when hot. When piston is removed be sure to clean carbon from head of piston and ring grooves. If piston is out of round or scored it should be replaced.


48. When fitting a new piston in the motor, assemble it with the free side pin hole (indicated with an "X" on boss) toward the magneto side. If an oversize piston is necessary, we recommend that reboring of cylinder be done by an Authorized Central Service Distributor or the factory.

49. **PISTON RINGS.** The piston rings when fitted in the cylinder should have a gap from .007" to .015". The rings should be fitted in the cylinder below the piston ring travel. Before assembling new rings to piston be sure that piston ring grooves are thoroughly cleaned, and rings fit free in the grooves.

50. **PISTON PIN.** The piston pin is a free fit in one side of the piston and a tight fit in the other. To remove this pin without special equipment, it is advisable to heat the piston in boiling water which causes the aluminum to expand. Cut a wooden pin a little smaller than the size of the piston pin and use this and a hammer to drive the pin out. Drive the pin out through the free fit hole. This hole is toward the magneto side and is indicated with an "X" on the pin hole boss. You should, of course, drive the pin out while the piston is still hot. To easily replace the pin, the piston should be heated.

86. **CONNECTING ROD.** The connecting rod is also made of special aluminum alloy which combines strength with light weight. The style of rod used on model "WM" motors varies, therefore be sure to read the following instructions carefully before ordering new rods or parts.


Connecting Rod — Plate No. 14



The connecting rod shown in Fig. 1 is used on motors with an oil pump. The cap is fastened with two No. 91849 fillister head screws. If screws only are needed, order by this number. Later "WM" models do not have oil pumps and are supplied with rod illustrated in Fig. 2. The cap is locked with one No. 91849 fillister head screw and one No. 91942 dipper screw. If screws only are needed, order these numbers. If you desire to replace either of the above rods (Figs. 1 or 2) with a complete new connecting rod assembly, order part No. 29733 (Fig. 3.). However, on rod in Fig. 1 be sure to also order new base plate No. 62904. This is the latest improved type and will operate efficiently in your motor. When assembling connecting rod to crankshaft the assembly marks on the lower bearing must be toward carburetor side.

52. **OIL PUMP.** The oil pump is permanently assembled to the base. An inoperative pump will result in insufficient lubrication which may score cylinder and piston assembly. To check oil pump, remove base screws. Place pump and base assembly in pan of oil about 1/4" below top of oil trough. Work plunger up and down. If oil trough fills up, oil pump is in good operating condition. If clogged send your motor to the nearest Briggs & Stratton Central Service Distributor listed on page 15 for special oil system change-over.

Oil Pump — Plate No. 15



**53. OIL LEAKS.** If oil leaks from either end of crankshaft, remove base plate from motor. Oil return valves are screwed into crank case and magneto back plate at base of main bearings. Remove oil return valve and clean or flush with gasoline and blow out any dirt lodged under the small disc. See plate No. 10.

**54. CARBON.** Excessive carbon is caused by improper grade of oil—too much oil, usually the result of piston rings not seating properly or sticking—carburetor set too rich—or long service. An unusual amount of carbon is noticeable by motor knocking or loss of power. Occasionally remove carbon from piston head, cylinder head and top of cylinder bore.

**55. AIR CLEANER.** If an air cleaner is used it should be occasionally removed and cleaned by washing in kerosene, then dipped in oil to make it efficient in catching dust. Test to see if it is clogged by noting if motor performs better with it off. If clogged it should be replaced.


**56. MUFFLER OR EXHAUST HOSE FITTING.** After long periods of service it is possible that the muffler, exhaust hose fitting, or the exhaust tubing will become clogged and reduce motor power. To check the muffler run water into the open end. If full streams of water come out of the small holes at the opposite end it is O.K. If not, it should be replaced. Exhaust hose fitting is removed by unscrewing nut—holes should be fully open.

**57. EXHAUST TUBING.** A certain amount of water forms inside of the exhaust tube after it cools off due to condensation. After motor is stopped, place exhaust tube so that water from condensation cannot drain into exhaust port of motor to corrode the mechanical parts and eventually result in trouble. If exhaust pipe is too long, or clogged, back pressure will reduce motor power.

**58. OVERLOAD.** Always be sure that the machine the motor is operating is well lubricated and running freely. If it is not, it may cause the motor to become overloaded resulting in it overheating, losing power, or even stopping entirely.

**59. STARTER PEDAL ADJUSTMENT.** The starter pedal is made in two parts, the pedal proper and pedal stop, held together with the adjusting bolt. To adjust, loosen the bolt and set pedal to desired position. Adjust the pedal to get the longest possible stroke without striking any part of the machine. The first tooth on the starter sector must clear the teeth of the starter pinion. Should the starter pedal return spring loosen or lose its tension, loosen the bolt which holds the return spring cup. Turn the cup to the left until there is just enough tension to return the starter pedal back to the normal position after depressing it, and tighten the bolt. Too much tension may cause spring to break. Be sure the spring is in the proper position with the long end below the pedal adjusting bolt and the hooked end in the slot of the cup.

**Starter Pedal Adjustment**  
Plate No. 16



**60. STARTER CLUTCH.** If the starter clutch slips or fails to turn the motor, when stepping on the starter pedal, it is probably caused by one of the following reasons:


Loose set screw.

Worn clutch housing.

Worn or broken pinion.

First tighten the set screw to be sure clutch is tight on the crankshaft. Use  $\frac{1}{8}$ " Allen hexagon set-screw wrench. If the clutch still slips, loosen set screw and remove clutch from the shaft. Pry out the snap spring with a sharp tool, holding the clutch in the position shown in plate No. 17, as a caution against the spring jumping out. Check the parts carefully for wear or damage and replace those necessary. To reassemble, replace the parts in the same order, and slip the spring back in place. Replace pulley clutch on shaft with the set screw hole lined up with recess in crankshaft extension. Securely tighten set screw.

**Starter Clutch**  
Plate No. 17



**61. PARTS.** All parts should be ordered from your dealer or the nearest Authorized Briggs & Stratton Service Distributor, listed on page 15.

**62.** To assure continued satisfactory performance, do not attempt to use substitute repair parts when overhauling or repairing the Briggs & Stratton Motor. Insist that all repair parts be original Briggs & Stratton parts.

**63. ALWAYS GIVE TYPE, MODEL AND SERIAL NUMBERS.** Briggs & Stratton motors are identified by a type number, model letter and a serial number. This information is stamped on a metal plate attached to the blower housing.

**64.** When writing to the factory or to a Central Service Distributor for service information, or when ordering new parts, be sure to specify the type number, the model, and the serial number of the motor to be serviced. This will assure prompt and efficient service without unnecessary correspondence.

**65.** Shipments will be made C.O.D. or send remittance with order to cover parts and add what you think will be sufficient for postage. Send postal or express money order, bank draft or certified check for this amount. Do not send currency in a letter. It is not safe.

**66. PRICES.** All prices in this book are subject to change without notice. In case of change in prices, orders will be filled at current prices. All prices shown are F.O.B. Factory at Milwaukee, Wis., or nearest Authorized Central Service Distributor. Prices higher in Canada.

## TO FIND THE CORRECT NUMBER OF THE PART YOU NEED

1. Make a note of your motor TYPE NUMBER (Not the Serial Number) that appears on the metal nameplate attached to motor blower housing.
2. Refer to pages illustrating parts and locate the Master Part Number by comparing your old part with the illustrations. Assemblies include all part numbers bracketed in illustration. All parts shown in assembly brackets on which part numbers are given can be purchased separately.
3. After the Master Part Number has been identified, refer to the following Parts List where these Master Part Numbers are listed in numerical order.  
The Master Part is used on all types of motors except those types listed under "Note."
4. If a "Note" appears below the Master Part Number, this means that this part is made different from the Master Part for certain types and if your type is listed under "Note," order the part referred to.
5. If two or more parts are bracketed (——) under "Note," they are used to replace the Master Part on the type numbers shown.
6. If your Motor Type Number does not appear after any part number listed under "Note," order the Master Part Number.
7. When ordering parts — or writing for service information — always specify the MODEL LETTER — TYPE NUMBER — and SERIAL NUMBER of your motor.





# Model "WM" Parts List

MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH	MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH
21277	Cam Gear.....	1.8	2.25	29671	Armature.....	2	3.00
21810	Breather Body.....	1	.10	29674	Ignition Cable.....	2	.15
21440	Control Lever.....	1	.50	29677	Magneto Plate and Bearing.....	3	2.75
22020	Throttle Shaft Retainer Washer.....	1	.05	Note: No. 29925 Magneto Plate and Bearing.....			
22082	Connecting Rod Screw Head Lock.....	1	.05	Used on type Nos. 20089, 20266, 60908, 60972.			
22216	Breather Cover.....	1	.10	No. 99162 Magneto Plate and Bearing.....			
22217	Oil Spray Shield.....	1	.10	Used on type Nos. 20027, 20099, 20413, 20414, 20419, 20494, 20959, 60887, 60888, 60988.			
Used on motors with inside breather.				29883	Spark Plug with Gasket.....	3	.65
Note: No. 82703 Oil Spray Shield.....				29704	Starter Pedal.....	1	1.50
Used on motors with outside breather.				29733	Connecting Rod.....	8	1.25
22353	Fibre Washer.....	1.3 for	.05	29739	Piston Assembly - Standard.....	8	2.90
22350	Governor Blade Spacer.....	1.2 for	.05	29741	Starter Clutch and Pulley 2-3/8" Dia.....	1	1.45
22368	Spring Washer.....	1	.10	Note: No. 29853 Clutch Pulley Assembly, 1-1/2" Groove (3-3/16" Dia. - 1/2" Groove) Used on type Nos. 20261, 20262, 20263, 20275, 20277, 20280, 20376, 20404, 60900, 60924, 60939.			
23058	Speed Adjuster Nut.....	1	.10	No. 29885 Clutch Pulley Assembly.....			
23059	Speed Adjuster Screw.....	1	.05	[2-3/8" Dia. - 39/64" Groove] Used on type Nos. 20251, 20252, 60909, 60935.			
23187	Valve Spring Retainer Pin.....	1	.05	No. 99348 Clutch Pulley Assembly.....			
23444	Valve Cover Stud.....	1	.05	[2-3/8" Dia. Cast Iron - 15/32" Groove] Used on type Nos. 20045, 20042, 20095, 20097, 20369, 20371, 20388, 20413, 20422, 20436, 20494, 20840, 20959, 20975, 60908, 60929, 60938, 60982, 60983.			
Used on motors with inside breather.				29748	Pulley - 2-3/4" Dia.....	8	.50
Note: No. 81707 Valve Cover Screw.....				Note: No. 29913 V Belt Pulley.....			
Used on motors with outside breather.				[1-15/16" Dia.] Used on type Nos. 20097, 20266, 20276, 60972.			
23495	Oil Retainer Ring.....	1	.20	29748	Cylinder.....	13	12.00
23571	Swivel.....	1	.20	Note: No. 29847 Cylinder.....			
23580	Control Lever Bushing.....	1	.10	Used on type Nos. 60915, 60961.			
28012	Crankshaft.....	3	4.50	29767	Choke Rod - 11-1/2" long.....	1	.15
Note: No. 28051 Crankshaft.....				Note: For other lengths specify: No. 19805 Choke Rod - 9-1/2" long.....			
Used on type Nos. 60915, 60961.				No. 29869 Choke Rod 11-7/8" long.....			
28021	Valve Spring.....	1	.05	No. 29875 Choke Rod - 15" long.....			
28025	Pedal Return Spring.....	1	.10	No. 29909 Choke Rod - 9-1/4" long.....			
28026	Piston Pin Lock.....	1.3 for	.05	29778	Piston Assembly - .010" Oversize.....	8	3.40
28032	Clutch Retainer Spring.....	1	.05	29779	Piston Assembly - .020" Oversize.....	8	3.40
28117	Governor Link.....	1	.10	29780	Piston Assembly - .030" Oversize.....	8	3.40
Note: No. 28034 Governor Link.....							
Used on type Nos. 60915, 60961.							
28328	Governor Spring.....	1	.10				
28330	Breather Spring.....	1	.05				
Used on motors with inside breather.							
29658	Outside Breather Tube.....	4	.40				
29667	Contact Point Assembly.....	2	.75				
29870	Magneto Plate Assembly.....	3	8.50				
Note: No. 29824 Magneto Plate Assembly.....							
Used on type No. 20089.							
Includes: No. 65905 Ground Wire.....							
No. 29835 Magneto Plate Assembly.....							
Used on type Nos. 20266, 60972.							
Includes: No. 65815 Ground Wire.....							
No. 29884 Magneto Plate Assembly.....							
Used on type No. 60908.							
Includes: No. 66155 Ground Wire.....							
No. 99163 Magneto Plate Assembly.....							
Used on type Nos. 20027, 20099, 20413, 20414, 20419, 20494, 20959, 60887, 60888, 60988.							

MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH	MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH
29781	Piston - .010" Oversize.....	6.....	2.00	61700	Pulley Clutch Housing.....	1.....	.80
29782	Piston - .020" Oversize.....	6.....	2.00		Notes: No. 61781 Pulley Clutch Housing... 1.....		.80
29783	Piston - .030" Oversize.....	6.....	2.00		Used on type Nos. 20261, 20262, 20263, 20275, 20277, 20280, 20376, 20404, 60900, 60924, 60939.		
29786	Starter Sector.....	14.....	1.25		Notes: No. 61784 Pulley Clutch Housing.. 1.....		.80
29788	Starter Pedal Assembly - right hand offset.....	3.....	2.25		Used on type Nos. 20251, 20252, 60909, 60935.		
29786	Carburetor Body.....	5.....	.85		Notes: No. 61973 Pulley Clutch Housing (Cast Iron).....	1.....	1.25
	Notes: No. 29875 Carburetor Body.....	5.....	.70		Used on type Nos. 20015, 20042, 20095, 20097, 20368, 20371, 20385, 20413, 20422, 20436, 20441, 20457, 20494, 20840, 20959, 20975, 60872, 60896, 60908, 60929, 60935, 60971, 60982, 60988.		
29800	Carburetor Assembly.....	8.....	2.00	61735	Oil Filler Cap.....	3.....	.15
	Notes: No. 29821 Carburetor Assembly.....	8.....	1.75	61742	Cylinder Head.....	2.....	1.15
	(Without Choke Valve)			61755	Exhaust Hose Fitting.....	8.....	.50
	Used on type Nos. 20009, 20015, 20027, 20042, 20095, 20097, 20099, 20368, 20376, 20388, 20404, 20413, 20414, 20419, 20422, 20436, 20448, 20494, 20959, 20974, 20975, 60872, 60887, 60888, 60908, 60937, 60938, 60939, 60971, 60974, 60980, 60982, 60988.			61758	Compression Ring Standard.....	1.....	.40
	Units: No. 82851 Washer			61757	Oil Ring - Standard.....	1.....	.60
	No. 81198 Lockwasher			61760	Flywheel Key.....	1.....	.10
	To plug choke valve retainer screw hole.			61758	Compression Ring .010" Oversize.....	1.....	.40
	No. 29828 Carburetor Assembly.....	8.....	2.25	61769	Compression Ring .020" Oversize.....	1.....	.40
	Used on type Nos. 60915, 60961.			61770	Compression Ring .030" Oversize.....	1.....	.40
29801	Choke Valve.....	2.....	.25	61771	Oil Ring - .010" Oversize.....	1.....	.60
	Notes: No. 61758 Choke Valve.....	1.....	.15	61772	Oil Ring - .020" Oversize.....	1.....	.60
	Used on type Nos. 60915, 60961.			61773	Oil Ring - .030" Oversize.....	1.....	.60
29804	Starter Pedal Assembly - left hand offset.....	3.....	2.25	62007	Gas Tank Clips.....	1.2 for	.05
	Notes: No. 29920 Starter Pedal Assembly..	3.....	2:25	62498	Blower Housing.....	2.....	1.00
	(Left Hand Offset)				Notes: No. 29828 Blower Housing.....	2.....	1.25
	Used on type No. 60938.				Screened-For rope starter motors.		
	No. 98101 Starter Pedal Assembly..	3.....	2.25		Notes: No. 29904 Blower Housing.....	2.....	1.25
	(L.H. Offset - Extension on Pedal Stop)				Full screen-For foot starter motors		
	Used on type No. 20152.			62534	Valve Spring Retainer.....	1.2 for	.05
	No. 99247 Starter Pedal Assembly..	3.....	2.25	62536	Return Spring Cup.....	1.....	.05
	(L.H. Offset - Extension on Pedal Stop)			62538	Clutch Retainer Plate.....	1.....	.05
	Used on type No. 20286.			62546	Valve Cover.....	6.....	.10
29806	Spark Plug Gasket.....	1.....	.05	62560	Governor Blade.....	2.....	.10
29807	Muffler.....	6.....	.25	62577	Flywheel Washer.....	1.....	.10
	Notes: Exhaust tubing not included; furnished by Manufacturer.			62597	Baffle Plate (right hand).....	1.....	.05
29809	Starter Pedal Assembly - Straight.....	3.....	1.75	62598	Baffle Plate (left hand).....	1.....	.05
29825	Gasoline Tank.....	1.....	1.25	62599	Spark Plug Wrench.....	6.....	.10
	Notes: No. 29852 Gasoline Tank.....	3.....	4.00	62600	Starter Pedal Stop.....	6.....	.25
	Used on type No. 60915.				Notes: No. 88102 Starter Pedal Stop.....	6.....	.30
	No. 29859 Gasoline Tank.....	1.....	1.25		Used on type No. 20152.		
	Used on type Nos. 20027, 20042, 20099, 20271, 20413, 20414, 20419, 20494, 20959, 60872, 60887, 60888, 60974, 60980, 60988.				No. 98246 Starter Pedal Stop.....	6.....	.30
	No. 98028 Gasoline Tank.....	1.....	1.50		Used on type No. 20286.		
	Used on type No. 60937.			62626	Choke Retainer Washer.....	1.....	.05
29830	Starter Pedal Assembly - Gooseneck.....	3.....	2.25		Notes: No. 82851 Washer.....	1.....	.05
	Notes: No. 29880 Starter Pedal Assembly (Gooseneck).....	3.....	2.25		For type numbers see "Note" under Master Part No. 29800.		
	Used on type Nos. 20271, 60936.			62641	Speed Adjuster Plate.....	1.....	.05
	No. 99086 Starter Pedal Assembly (Gooseneck).....	3.....	2.25		Notes: Earlier model motors used No. 62575 Friction Spring.		
	Used on type Nos. 20275, 20277.			62655	Magneto Point Dust Cover.....	8.....	.25
29835	Magneto Flywheel.....	6.....	6.00		Notes: No. 62635 Magneto Point Dust Cover.....	8.....	.15
29836	Starter Pedal - Gooseneck.....	1.....	1.25		Units: No. 62942 Spacers (2).....	1.....	.05
	Notes: No. 29879 Starter Pedal (Gooseneck).....	1.....	1.25		No. 90313 Nuts (2).....	1.....	.05
	Used on type Nos. 20271, 60936.				To mount dust cover to Magneto Plates with No. 91833 Dust cover studs, on type Nos. 20027, 20042, 20099, 20413, 20414, 20419, 20494, 20959, 60872, 60887, 60888, 60937, 60938, 60974, 60980, 60988.		
	No. 99082 Starter Pedal (Gooseneck).....	1.....	1.25	62693	Rope Starter Pulley (notched).....	12.....	.45
	Used on type Nos. 20275, 20277.				Notes: No. 62631 Rope Starter Pulley (Without Notch).....	12.....	.45
29861	Condenser.....	2.....	.45		Used on type Nos. 20009, 20027, 20414, 20419, 20441, 20448, 20457, 60872, 60887, 60889, 60896, 60915, 60937, 60974, 60930, 60961.		
29885	Gasoline Tank.....	1.....	1.75	62702	Choke Valve Washer.....	1.....	.05
	Notes: No. 29843 Gasoline Tank Assembly... 3.....	8.....	4.60	62853	Cylinder Shield.....	6.....	.15
	Used on type Nos. 20368, 60915.			62893	Throttle Link.....	1.....	.05
	No. 29886 Gasoline Tank Assembly... 1.....	8.....	2.00	62904	Base Plate.....	1.....	.40
	Used on type No. 60937.				Notes: Base plate with oil pump used on early Model Motor is replaced by No. 62904 which includes instructions for proper installation.		
	No. 29870 Gasoline Tank Assembly... 1.....	8.....	1.75	63058	Gas Line Connector.....	1.....	.15
	Used on type Nos. 20027, 20042, 20099, 20271, 20413, 20414, 20419, 20494, 20959, 60872, 60887, 60888, 60879, 60980, 60988.				Notes: No. 29864 Connector.....	1.....	.25
29878	Starter Rope.....	4.....	.25		Used on type Nos. 60915, 60961.		
29881	Starter Pedal - right hand offset.....	8.....	1.25				
	Notes: No. 29921 Starter Pedal (Right Hand Offset)	1.....	1.25				
	Used on type No. 60938.						
29882	Starter Pedal - left hand offset.....	8.....	1.25				
37346	Rivet - 1/8x1/4 - Tubular.....	1.4 for	.05				
38852	Washer.....	1.3 for	.05				

MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH
83770	Steel Clutch Ball.....	1.2 for	.05
83771	Starter Pedal Bushing.....	1.....	.10
83772	Oil Drain Plug.....	1.....	.10
83773	Piston Pin - Standard.....	2.....	.20
83774	Governor Blade Rod.....	1.....	.05
83782	Intake Valve.....	2.....	.50
83783	Exhaust Fitting Locknut.....	2.....	.25
83785	Cam Shaft.....	3.....	.20
83786	Valve Tappet.....	1.....	.25
83794	Starter Pinion.....	4.....	.80
83807	Exhaust Valve.....	2.....	1.00
83810	Needle Valve.....	1.....	.25
	Notes: No. 63844 Needle Valve.....	1.....	.20
	Used on type Nos. 60915, 60961.		
83816	Piston Pin - .005" Oversize.....	2.....	.35
83821	5/16" Allen Set Screw Wrench.....	1.....	.10
83828	Magneto Plate Studs.....	1.....	.15
	Notes: No. 62842 Dust Cover		
	Spacer.....	1.....	.05
	For type numbers see "Note" under		
	Master Part No. 62655.		
83948	Air Cleaner Stud.....	1.....	.35
85284	Gas Pipe Washer.....	1.....	.05
85451	Control Lever Base.....	4.....	.45
85459	Control Lever Assembly.....	8.....	1.35
85534	Filler Cap Gasket.....	1.....	.05
85704	Contact Point Plunger.....	1.....	.20
85787	Fibre Connector Gasket.....	1.2 for	.05
85868	Breather Disc.....	1.....	.05
	Used on motors with inside		
	breather.		
86432	Washer.....	1.....	.05
86856	Control Wire Casing - 47" long.....	8.....	.40
	Notes: If a longer casing is		
	needed specify length in		
	inches; if a shorter casing		
	is needed order No. 66856		
	and cut to required length.		
86856	Control Wire - 50" long.....	2.....	.25
	Notes: If a longer wire is needed		
	specify length in inches; if		
	a shorter wire is needed order		
	No. 66866 and cut to required		
	length.		
67807	Magneto Plate Gasket.....	1.....	.05
67816	Control Spring.....	1.....	.20
67827	Valve Cover Gasket.....	1.....	.05
67837	Cylinder Head Gasket.....	1.....	.10
67847	Oil Pump and Base Gasket.....	1.....	.05
67887	Magneto Plate Gasket - .005" thick.....	1.....	.05
67607	Magneto Plate Gasket - .009" thick.....	1.....	.05
67617	Needle Valve Packing.....	1.....	.05
67847	Slaves.....	1.....	.05
88122	Cam Shaft Plug.....	1.....	.05
88487	Carburetor Gasket.....	1.....	.05
88957	Air Cleaner Gasket.....	1.....	.05
89221	Gas Tank Cap.....	2.....	.15
	Notes: No. 28880 Gas Tank Cap.....	2.....	.15
	Used on type No. 60915.		
89243	Gas Pipe.....	2.....	.45
	Notes: No. 28863 Gas Tank Pipe.....	2.....	.45
	Used on type No. 60915.		
89355	Gasoline Line - 19" long.....	2.....	.30
	Notes: For other lengths specify:		
	No. 28245 Gasoline Line -		
	10" long.....	2.....	.25
	No. 28411 Gasoline Line -		
	13" long.....	2.....	.25
	No. 28544 Gasoline Line -		
	27" long.....	4.....	.40
	No. 28828 Gasoline Line -		
	25-1/2" long.....	4.....	.30
	No. 28858 Gasoline Line -		
	21" long.....	4.....	.30
	No. 28819 Gasoline Line -		
	18" long.....	3.....	.25
	No. 54408 Gasoline Line -		
	23" long.....	4.....	.30
	No. 64419 Gasoline Line -		
	9-1/4" long.....	2.....	.25
	No. 69358 Gasoline Line -		
	30" long.....	4.....	.50
	No. 89404 Gasoline Line -		
	16" long.....	3.....	.25
	No. 89502 Gasoline Line -		
	9-1/2" long.....	2.....	.25
	No. 89827 Gasoline Line -		
	10-1/2" long.....	2.....	.25
	No. 89095 Gasoline Line -		
	20" long.....	4.....	.30

MASTER PART NUMBER	NAME	SHIPPING WEIGHT Lbs. Oz.	SELLING PRICE EACH
89307	Oil Return Valve.....	1.....	.15
89340	Crankshaft Bearing.....	2.....	.40
	Includes: No. 23485 Oil Retainer Ring		
80068	Screw - 8-32x1/4" Rd. Hd.....	1.2 for	.05
80057	Screw - 8-32x5/16" Rd. Hd.....	1.2 for	.05
80202	Screw - 10-32x1/2" Fill. Hd.....	1.....	.05
80355	Nut - 10-32 Hex.....	1.....	.05
80364	Lockwasher - 11/64x3/64x1/32".....	1.2 for	.05
	Notes: No. 91199 Lockwasher.....	1.2 for	.05
	For type numbers see "Note" under		
	Master Part No. 62628.		
80366	Lockwasher.....	1.4 for	.05
80528	Screw - 4/4x28x3/4" Hex. Hd.....	1.....	.05
90889	Lockwasher - 1/4x5/64x1/16".....	1.3 for	.05
90847	Valve Cover Nut.....	1.....	.05
	Used on motors with inside breather.		
	Notes: No. 91707 Valve Cover Screw.....	1.....	.05
	Used on motors with outside breather.		
90850	Cap Screw.....	1.....	.05
91070	Lockwasher - No. 8 Shakeproof.....	1.3 for	.05
91195	Screw - 1/4-20x3/8" Rd. Hd.....	1.2 for	.05
91189	Lockwasher.....	1.2 for	.05
91208	Nut - 5/16-24x1/2x17/64" Hex.....	1.....	.05
91253	Screw - 6-32x5/16" Fill. Hd.....	1.2 for	.05
91324	Washer - 1/4" Standard.....	1.2 for	.05
91869	Screw - 10-32x3/4" Fill. Hd.....	1.2 for	.05
91398	Screw - 1/4x28x1/2" Hex. Hd.....	1.....	.05
	Notes: No. 82288 Screw - 5/16"		
	18x1/2" Hex. Hd.....	1.....	.05
	No. 90881 Screw - 5/16"		
	18x5/8" Hex. Hd.....	1.....	.05
	No. 91397 Nut - 5/16" 18 Hex.....	1.2 for	.05
	Used to mount motor to gas tank on		
	type Nos. 20366, 60915, 60961.		
91401	Screw - 8-32x1/4" Fill. Hd.....	1.2 for	.05
91432	Screw - 10-32x7/8".....	1.....	.05
91541	Screw 5/16-24x7/8" Hex. Hd.....	1.....	.05
91708	Flywheel Nut.....	1.....	.05
91711	Cylinder Head Screw (short).....	1.....	.05
	Notes: No. 91387 Cylinder Head Screw.....	1.....	.10
	Used on type Nos. 60915, 60961.		
91712	Cylinder Head Screw (long).....	1.....	.05
91741	Screw - 3/8-24x1/2" long.....	1.....	.05
91753	Armature Mounting Screw.....	1.2 for	.05
91758	Set Screw - 5/16-24x1/2" Holl. Hd.....	1.....	.10
81833	Dust Cover Studs.....	1.....	.05
91849	Slotted Head Connecting Rod Screw.....	1.....	.05
	Notes: If screw head in your connecting		
	rod is hexagon head order No. 92084.		
91942	Hexagon Head Dipper Screw.....	1.....	.25
	With shoulder under Hexagon Head.		
	Notes: If dipper screw in your connect-		
	ing rod has No shoulder under		
	head order No. 92080.		
92007	Throttle Lever Stop Screw.....	1.....	.05
	Notes: No. 91752 Throttle Lever Screw.....	1.2 for	.05
	Used on type Nos. 60915, 60961.		
82067	Wing Nut.....	1.....	.05
92080	Hexagon Head Dipper Screw.....	1.....	.25
92084	Hexagon Head Connecting Rod Screw.....	1.....	.05
	Notes: If screw head in your connecting		
	rod is slotted, order No. 91849.		
92265	Cotter Pin.....	1.4 for	.05
92287	Screw.....	1.2 for	.05
92290	Lockwasher.....	1.3 for	.05
92305	Washer - 1/16".....	1.....	.05
92306	Cap Screw - 1/4-28x5/8" Hex. Hd.....	1.....	.05
93023	Air Cleaner Assembly.....	1.....	3.35
98108	Air Cleaner Elbow.....	2.....	.30
98193	Muffler Assembly.....	8.....	.75
	Notes: Exhaust tubing not included; fur-		
	nished by equipment manufacturer.		
98588	Throttle Lever.....	2.....	.40
	Notes: No. 28851 Throttle Lever.....	2.....	.65
	Used on type No. 60961.		
	Early Model Motors used throttle		
	lever with steel shaft.		
99620	Air Cleaner.....	1.....	2.50
	Notes: Replaces No. 29823 Air Cleaner.		
89632	Spring Tooth Assembly.....	1.....	.35
89740	Piston and Pin Lock.....	8.....	1.50
89874	Speed Adjuster.....	1.....	.35
	Notes: Earlier model motors used;		
	No. 62576 Speed Adjuster.		



STARTER MOUNTING PARTS




PLATE-1085-83











PLATE-1084-83

Assemblies include all parts shown in brackets.

# NATION-WIDE SERVICE ORGANIZATION

To provide prompt and efficient service on Briggs & Stratton motors, Authorized Central Service Distributors and Motor Service Stations are located in the principal cities of the United States and Canada.

Each Authorized Service Organization carries a complete stock of original Briggs & Stratton repair parts. Each is equipped with special factory service tools and factory-trained mechanics, assuring expert repair service on all Briggs & Stratton motors.

All Authorized Service Organizations are instructed by the factory to replace free of charge all parts found to be defective in either material or workmanship, according to the conditions of the Briggs & Stratton Guarantee.

All gratis work done under the guarantee is the responsibility of the Authorized Service Organization until all the material involved and supporting facts are submitted to and approved by the factory.

In a difference of opinion regarding a Service Organization's decision, their terms should be accepted and, either through them or direct, have all materials and supporting facts submitted to the factory for review.

Genuine Briggs & Stratton service will assure continuous motor satisfaction. Our long experience in motor maintenance prompts us to urge that all service work be done by an Authorized Service Organization or at our factory. Mechanics unfamiliar with Briggs & Stratton products, or without proper tools, should not be permitted to make major repairs.

Parts and repair work are F. O. B. Factory or any Authorized Briggs & Stratton Central Service Distributor, or Motor Service Station. The Central Service Distributor nearest you (see list below) will be glad to give you the name of our Motor Service Station in your locality. Space does not permit listing here.


## Authorized Central Service Distributors

STATE	CITY	NAME	LOCATION
Alabama	Birmingham	Birmingham Electric Battery Co.	Ave. B. at 23rd St.
Arizona	Phoenix	Motor Supply Co.	315 N. Central Ave.
California	Los Angeles	Electric Equipment Company	1611 S. Hope St.
California	San Francisco	Automotive Service Co.	930 Van Ness Ave.
Colorado	Denver	Spitzer Electrical Company	43 W. 9th Ave.
Florida	Jacksonville	Spencer Electric, Inc.	40 W. Beaver St.
Florida	Miami	Electrical Equipment Co.	42-58 N. W. 4th St.
Florida	Tampa	Spencer Auto Electric, Inc.	607-11 E. Cass St.
Georgia	Atlanta	Auto Electric & Magneto Co.	477 Spring St., N. W.
Illinois	Chicago	Mid-States Auto Electric Co.	1905 So. Michigan Ave.
Indiana	Indianapolis	Gulling Auto Electric Co.	450 N. Capitol Ave.
Iowa	Des Moines	Magneto Carburetor & Electric Co., Inc.	1308 Grand Ave.
Kansas	Wichita	The E. S. Cowie Electric Co.	230 S. Topeka Ave.
Kentucky	Lexington	Kentucky Ignition Co., Incorporated	Rose and Vine Sts.
Louisiana	New Orleans	Suhren, Inc.	1319 St. Charles Ave.
Louisiana	Shreveport	Chain Battery & Automotive Supply, Inc.	Marshall at Cotton Sts.
Massachusetts	Boston	Wm. H. Flaherty Co.	48-52 Cummington St.
Michigan	Detroit	Auto Electric & Service Corporation	90 Selden Ave.
Minnesota	Minneapolis	Reinhard Brothers Co., Inc.	11 S. Ninth St.
Missouri	Kansas City	The E. S. Cowie Electric Co.	1819 Wyandotte St.
Missouri	St. Louis	Medart Auto Electric Co., Inc.	3134 Washington Blvd.
Montana	Billings	Pasley & Spitzer Co.	20 No. 33rd St.
Nebraska	Lincoln	Carl A. Anderson, Inc.	1637 P Street
Nebraska	Omaha	Carl A. Anderson, Inc.	16th and Jones St.
New York	Buffalo	The Battery & Starter Co., Inc.	2505 Main St.
New York	New York	The Durham Co., Inc.	17 W. 60th St.
New York	Syracuse	The Durham Co., Inc.	601 W. Genesee St.
North Carolina	Charlotte	Carolina Rim & Wheel Co.	312 N. Graham St.
North Dakota	Fargo	Reinhard Brothers, Inc.	109 Roberts St.
Ohio	Toledo	The Electric Power Maintenance Co.	26-30 Seventeenth St.
Oklahoma	Oklahoma City	American Electric Ignition Co.	725 N. Broadway
Oregon	Portland	Tracey & Co., Inc.	N. W. 10th and Glisan
Pennsylvania	Philadelphia	Auto Equipment & Service Co., Inc.	1522-24 Fairmount Ave.
Pennsylvania	Pittsburgh	Pitt Auto Electric Company	5135 Baum Blvd.
South Dakota	Aberdeen	Reinhard Brothers Co., Inc.	317 S. Lincoln St.
Tennessee	Knoxville	R. T. Clapp Company	401-7 N. Broadway
Tennessee	Memphis	Automotive Electric Service Co.	1095 Union Ave.
Texas	Amarillo	The E. S. Cowie Electric Co.	700 Van Buren St.
Texas	Dallas	Beard & Stone Electric Co., Inc.	2101 Bryan St.
Texas	El Paso	Motor Supply Co.	308 Chihuahua St.
Texas	Houston	Beard & Stone Electric Company, Inc.	Milam at Polk Ave.
Texas	San Antonio	S. X. Callahan	425 N. Flores St.
Utah	Salt Lake	Motor Equipment Company	605-609 So. State St.
Washington	Seattle	Sunset Electric Co.	300 Westlake North
Wisconsin	Milwaukee	Wisconsin Magneto Co.	918 N. Broadway

### DOMINION OF CANADA

Manitoba	Winnipeg	Beattie Auto Electric Limited	176 Fort St.
Ontario	Toronto-5	Auto Electric Service Company Limited	1009 Bay St.

**BRIGGS & STRATTON CORP.**  
**MILWAUKEE, WIS., U. S. A.**



### WHERE BRIGGS AND STRATTON MOTORS ARE MADE

**T**HESSE large and modern factory buildings, located in Milwaukee, Wisconsin, are complete with all modern equipment and machinery for precision construction, economical production, rigid inspection and thorough testing of Briggs & Stratton 4-cycle gasoline motors.

Briggs & Stratton Corp. produces more small 4-cycle air-cooled gasoline motors than any other manufacturer in the world.

