

Workshop Manual

Technical Data

**TAD1240GE, TAD1241GE/VE
TAD1242GE/VE, TWD1240VE**



Technical data

Engine

**TAD1240GE, TAD1241GE/VE
TAD1242GE/VE, TWD1240VE**

Contents

Safety information	2
Introduction	2
Important	2
General information	5
About the Service Manual	5
Spare parts	5
Certificated engines	5
Technical data	6
References to Service Bulletins	31




Safety information


The Service Manual contains technical data, descriptions and repair instructions relating to the Volvo Penta products or product versions included in the list of contents. Make sure you use the right workshop literature.

Read the safety information, “General information” and “Repair instructions” carefully before starting any service work.

Important


The following special warning symbols occur in the Service Manual and on the product.


 **WARNING!** Warns of the risk of injury and extensive damage to the product or property, or that serious functional faults could arise if the instructions are not followed.

 **IMPORTANT!** Used to draw attention to anything that could cause damage to the product or property or functional disorders in the same.


NOTE: Used to draw attention to important information for facilitating work operations or handling.


To provide an overview of the risks you should always be aware of and the precautionary measures that should always be adopted, we have listed them here.


 Make it impossible for the engine to start. Turn off the current by means of the main switch (or switches) and lock it (them) in the OFF position before starting service work. Affix a warning sign in the driver's area.


 As a rule, all service work should be carried out when the engine is stationary. Some work, including certain adjustments, nonetheless requires the engine to be running. Approaching an engine that is running could be dangerous. Bear in mind that loose-fitting clothes or long hair may get caught in rotating parts and cause serious injury.


If work is carried out near an engine that is running, an incautious movement or a dropped tool could in the worst case lead to bodily harm. Be mindful of hot surfaces (exhaust pipes, the turbocharger, charge air pipes, starter elements, etc.) and hot liquids in lines and hoses on an engine that is running or has just been stopped. Before starting the engine, refit all guards and protective elements that were removed in the course of carrying out service work.







 Make sure that the warning and/or information decals affixed to the product are always in plain sight. Replace decals that are damaged or have been painted over.








 Never start the engine unless the air filter is fitted. The rotating impeller in the turbo could cause serious injuries. Foreign objects in the inlet line could additionally cause machinery damage.

 Never use a starter spray or the like to help start the engine. It could cause an explosion in the inlet manifold. Danger of injury.

 Start the engine in well-ventilated premises only. If the engine is run in a confined space, exhaust gases and crankcase gases should be conducted away from the engine bay or workshop area.

 Avoid opening the coolant filler cap when the engine is still hot. Steam or hot coolant could squirt out while the built-up pressure will be lost. If necessary, open the filler cap slowly and release the pressure in the cooling system. Be extremely careful if a cock, plug or coolant line has to be removed while the engine is still hot. Steam or hot coolant could squirt out in an unexpected direction.

-  Hot oil can cause burns, Avoid getting hot oil on your skin. Make sure that the lubricating system is depressurized before starting any work on it. Never start or run the engine with the oil filler cap removed as oil under pressure could then escape.
-  Stop the engine before doing any work on the cooling system.
-  Always use protective goggles when carrying out work where splinters, grinding sparks and splashes of acid or other chemicals could occur. The eyes are especially sensitive and an injury could result in loss of sight.
-  Avoid getting oil on your skin. Prolonged or recurring contact with oil can remove the skin's natural moisture with irritation, dehydration, eczema and other skin disorders as a result. From a hygienic point of view, used oil is more harmful than fresh oil. Wear protective gloves and avoid clothes and rags ingrained with oil. Wash yourself regularly, particularly before mealtimes. Use skin lotion intended for this purpose to avoid dehydration and to facilitate cleansing of the skin.
-  Most chemicals intended for the product (such as engine and transmission oils, glycol, petrol and diesel oil) or chemicals for workshop use (such as degreasants, paints and solvents) are injurious to the health. Carefully read the instructions on the package. Always follow the prescribed safety rules (such as the use of respirators, protective goggles, gloves, etc.). Make sure that other personnel are not exposed without their knowledge to substances that are injurious to health, such as through the air they breathe. Make provision for good ventilation. Deal with used and surplus chemicals in the prescribed manner.
-  Exercise great care when detecting leaks in the fuel system and testing fuel nozzles. Wear protective goggles. The jets from a fuel nozzle are under very high pressure and have great penetrative power; the fuel can penetrate deep into body tissues and cause serious injury. Risk of blood poisoning.
-  **WARNING!** Under no circumstances should the engine's pressure pipes be bent or reshaped. Damaged pipes must be changed.
-  All fuels and many chemicals are flammable. Make sure that they cannot be ignited by a naked flame or spark. Petrol, certain diluents and hydrogen from batteries, when mixed with air in the right proportions, are highly flammable and explosive. No smoking! Arrange for adequate ventilation and take the necessary safety measures prior to the start of welding or grinding work in the vicinity. Always keep a fire extinguisher easily accessible at the workplace.
-  Ensure that rags saturated with oil and fuel, as well as used fuel and oil filters, are kept in a safe place prior to their disposal. Under certain conditions, spontaneous combustion can occur in oil-ingrained rags. Used fuel and oil filters comprise environmentally hazardous waste and, together with used lubricating oil, contaminated fuel, residual paint, solvents, degreasants and residual detergents, should be taken to a suitable plant for destruction.
-  Batteries should never be exposed to naked flames or electric sparks. Never smoke near the batteries. When the batteries are being charged they give off hydrogen which, when mixed with air, forms oxyhydrogen gas. This gas is highly flammable and extremely explosive. A spark, which can occur if the batteries are connected incorrectly, could cause a battery to explode with injury and damage as a result. Do not disturb the connections when attempting to start (risk of sparks) and do not lean over any of the batteries.
-  Never mistake the positive and negative terminals for each other when installing the batteries. If this happens it could cause serious damage to the electrical equipment. Compare with the wiring diagram.
-  Always wear protective goggles when charging and handling batteries. The battery electrolyte contains highly corrosive sulphuric acid. If it gets on your skin, wash the affected area with soap and plenty of water. If the electrolyte gets in your eyes, rinse them at once with plenty of water and see a doctor as soon as possible.

-  Stop the engine and cut off the current with the main switch (or switches) before starting to work on the electrical system.
-  The clutch should be adjusted with the engine switched off.
-  Use the lifting eyes mounted on the engine when lifting it. Always check that all lifting equipment is in good condition and that it has the right capacity for the job (engine weight plus reversing gear and extra equipment, if any). To ensure safe handling and to avoid damaging components mounted on the top of the engine, it should be lifted using an adjustable lifting beam or one suitably adapted to the engine. All chains or cables should run parallel to each other and as perpendicular as possible to the top of the engine.
If other equipment that has been connected to the engine changes its centre of gravity, special lifting devices may be needed to obtain the right balance and ensure safe handling.
Never carry out any work on an engine that is suspended solely from a lifting device (hoist, etc.).
-  Never work alone when heavy components are to be removed, not even when a safe lifting device like a lockable block and tackle is used. Even when a lifting device is used two people will generally be required, one to handle the lifting device and the other to make sure that the components go clear and are not damaged when lifted away.
Always make sure in advance that there is sufficient space for dismantling to be carried out in the area with no danger of it causing injury or material damage.
-  **WARNING!** Electrical system and fuel system components on Volvo Penta products are designed and manufactured to minimize the risk of explosion and fire. The engine must not be run in environments where they will be surrounded by explosive media.
-  Always use fuel recommended by Volvo Penta. See the Owner's Manual. The use of a poorer grade of fuel could damage the engine. On a diesel engine, a poor grade of fuel could lead to binding of the control rod and overrevving of the engine with a consequent risk of injury and damage. Poor fuel can also give rise to higher maintenance costs.
-  Bear in mind the following when cleaning with high-pressure equipment: never direct the jet of water on seals, rubber hoses or electrical components. Never use the high-pressure function when cleaning the engine.
-

General information

About the Service Manual

This Service Manual contains technical data for the standard versions of the TAD1240GE, TAD1241GE/VE, TA1242GE/VE and TWD1240VE engines.

All references from the service manuals containing repair instructions for the TAD1240GE, TAD1241GE, TAD1242GE and TWD1240VE engines will be found in the "Technical data" Service Manual.

The Service Manual is primarily produced for Volvo Penta's service workshops and their qualified personnel. It is therefore assumed that persons using the manual have the necessary basic knowledge and can carry out work of a mechanical/electrical nature that forms part of their occupational duties.

Volvo Penta is continuously developing its products and we therefore reserve the right to introduce changes and modifications. All the information in this manual is based on product data available up to the time of going to press. Any changes of vital importance that have been introduced in product or service methods after that date will be announced in the form of Service Bulletins.

Spare parts


Spare parts for the electrical and fuel systems are subject to different national safety requirements. Volvo Penta Original Spare Parts meet these requirements. All types of damage occurring as a result of using non-original Volvo Penta spare parts for the product in question will not be covered under the terms of warranty as undertaken by Volvo Penta.

Certificated engines

For engines that are certificated in compliance with national and regional environmental legislation the manufacturer undertakes to ensure that the environmental requirements are fulfilled both in new engines and those already in use. The product must correspond to the specimen product that was approved for certification. For Volvo Penta as the manufacturer to be answerable for ensuring that engines in use meet the stipulated environmental requirements, the following requirements in regard to service and spare parts must be fulfilled:

- The service intervals and maintenance measures recommended by Volvo Penta must be followed.
- Only Volvo Penta Original Spare Parts intended for the certificated engine version may be used.
- Service embracing injection pumps, pump settings and injectors must always be carried out by an authorized Volvo Penta workshop.
- The engine must not be rebuilt or modified in any way, except for the accessories and service kits that Volvo Penta has developed for the engine in question.
- Installation changes to exhaust pipes and supply air ducts for the engine bay (ventilation ducts) must not be made indiscriminately as this could affect exhaust emission levels.
- Security seals, if any, must not be broken by non-authorized personnel.


In other respects the general instructions for driving, operation and maintenance given in the Owner's Manual are applicable.

 **IMPORTANT!** When spare parts are required, use only Volvo Penta Original Spare Parts.

If non-original spare parts are used, AB Volvo Penta will no longer be responsible for ensuring that the engine corresponds to the certificated version.

All types of injury, damage and/or costs arising due to the use of non-original Volvo Penta Original Spare Parts for the product in question will not be covered under the terms of warranty as undertaken by Volvo Penta.

Technical data



General

Type designation	TAD1240GE	TAD1241/42GE	TWD1240VE	TAD1241/42VE
Number of cylinders	6			
Cylinder bore	131 mm (5.16")			
Stroke	150 mm (5.91")			
Swept volume	12.13 dm ³ (740.20 inch ³)			
Number of valves	24			
Direction of rotation (viewed from front)	Clockwise			
Compression ratio	18.5:1	17.5:1	18.5:1	17.5:1
Firing order	1-5-3-6-2-4			
Slow idling speed (rpm)	600-1200	600-1200	600-900	600-900
Fast idling speed (rpm)	1500-1620	1500-1620	2100	1000
	/1800-1920	/1800-1920		
Highest full-load engine speed (rpm)	1500/1800	1500/1800	2100	1800
Dry weight (kg)	1230*	1230*	1270	1230
	(2706 lbs)	(2706 lbs)	(2794 lbs)	(2706 lbs)

Weight TAD engines without radiator assembly and air filter

Engine block

Cylinder head


Type	One cylinder head for all cylinders with single overhead camshaft
Length	1078 mm (42.44")
Width	397 mm (15.63")
Height	135 mm (5.32")
Max. surface unevenness (bottom surface)	0.1 mm (0.004")

Cylinder head bolts

Number of bolts per cylinder head	38
Thread size	M16
Length	200 mm (7.87")

Cylinder liners

Type	Wet, replaceable
Sealing surface height above block surface	0.15–0.20 mm (0.006–0.0079")
Number of sealing rings per cylinder liner	4



Pistons

Height above cylinder block surface	0.05–0.45 mm (0.002–0.018")	
Diameter, combustion chamber	89 mm (3.5")	
Depth, piston bowl	18.55 mm (0.73") (E=17.5:1)	17.14 (E=18.5:1)
Number of ring grooves	3	
Front marking	Arrow pointing forwards	
Gudgeon pin diameter	55 mm (2.17")	

Piston rings

Compression rings

Number	2
Piston ring clearance in groove:	
upper compression ring	Trapezoidal section, no clearance
lower compression ring, vertical	0.05–0.08 mm (0.002–0.0031")
Piston ring gap:	
upper compression ring	0.425–0.575 mm (0.0167–0.0226")
wear tolerance	1 mm (0.04")
lower compression ring	0.8 mm (0.032")
wear tolerance	1.3 mm (0.051")

Oil control ring

Number	1
Width, incl. spring	4.3 mm (0.17")
Piston ring clearance, vertical	0.03–0.08 mm (0.0012–0.0031")
Piston ring gap	0.35–0.75 mm (0.014–0.03")

Valve mechanism

Valves

Valve head diameter

Inlet	40 mm (1.58")
Exhaust	40 mm (1.58")

Stem diameter

Inlet	7.960–7.975 mm (0.3134–0.3140")
Exhaust	7.947–7.962 mm (0.3129–0.3135")

Valve face angle

Inlet	29.5°
Exhaust	44.5°

Valve head face, (see illustration below)


Inlet (new valve)	Min. 1.8 mm (0.07")
wear tolerance	1.4 mm (0.055")
Exhaust (new valve)	Min. 1.6 mm (0.063")
wear tolerance	1.2 mm (0.0472")

Seat angle in cylinder head

Inlet	30°
Exhaust	45°

The valve seat should be ground down until the distance from the valve head (new valve) to the cylinder head surface is:

Inlet	0.9–1.4 mm (0.035–0.055")
wear tolerance	Max. 1.5 mm (0.06")



Exhaust	1.2–1.7 mm (0.047–0.067")
wear tolerance	Max. 1.8 mm (0.071")

If the distance is greater the valve seats must be changed.

Valve clearances, cold engine, setting value

Inlet	0.2 mm (0.008")
Exhaust	0.5 mm (0.020")

Valve clearance, cold engine, check value

Inlet	0.15–0.25 mm (0.006–0.010")
Exhaust	0.45–0.55 mm (0.018–0.022")

Valve seats

Outer diameter (**dimension A**) Standard:


Inlet	43.1 mm (1.697")
Exhaust	43.1 mm (1.697")

Oversize:

Inlet	43.3 mm (1.710")
Exhaust	43.3 mm (1.710")

Height (**dimension B**):

Inlet	8.4-8.6 mm (0.331-0.339")
Exhaust	7.9-8.1 mm (0.311-0.319")



Valve face seat

Diameter (**dimension C**) standard:

Inlet	43 mm (1.69")
Exhaust	43 mm (1.69")

Diameter (**dimension C**) oversize:

Inlet	43.200-43.225 mm (1.701-1.702")
Exhaust	43.200-43.225 mm (1.701-1.702")

Depth (**dimension D**):


Inlet	11.2±0.1 mm (0.441±0.004")
Exhaust	11.2±0.1 mm (0.441±0.004")

Seat bottom radius (**dimension R**):

Inlet, max.	0.8 mm (0.032")
Exhaust, max.	0.8 mm (0.032")

Dimension between valve head and cylinder head surface:

Inlet	0.9-1.4 mm (0.035-0.055")
Exhaust	1.2-1.7 mm (0.047-0.067")



Valve guides

Length:

Inlet	83.2-83.5 mm (3.28-3.29")
Exhaust	83.2-83.5 mm (3.28-3.29")

Inner diameter:

Inlet	8.0 mm (0.032")
Exhaust	8.0 mm (0.032")

Height above cylinder head spring plane:

Inlet	26.5±0.4 mm (1.04±0.016")
Exhaust	18.5±0.4 mm (0.73±0.016")

Clearance, valve stem - guide:

Inlet	0.03-0.05 mm (0.001-0.002")
Wear tolerance	0.2 mm (0.008") ¹
Exhaust	0.04-0.07 mm (0.002-0.003")
Wear tolerance	0.3 mm (0.012") ¹

¹ Max. permissible clearance between valve stem and valve guide:
(according to the method described in "Service Manual Engine block D12CA: valve guides, inspection")

Valve springs

Valve springs, exhaust/inlet

Valve springs:


Length without load	72-73 mm (2.8-2.9")
With 600 N (61.2 kgfm (134.6 lbs)) load	56 mm (2.2")
With 1076 N (109.7 kgfm (241.3 lbs)) load	43 mm (1.7")
Rigid length max.	41 mm (1.6")

Inner valve spring (exhaust):

Length without load	67-68 mm (2.6-2.7")
With 243 N (24.8 kgfm (54.6 lbs)) load	52 mm (2.1")
With 447 N (45.6 kgfm (100.3 lbs)) load	39 mm (1.5")
Rigid length max.	36 mm (1.4")

Timing

1. Drive, camshaft (z=76)
2. Drive, compressor (z=29)
3. Idler (z=83)
4. Drive, coolant pump (z=27)
5. Drive, crankshaft (z=38)
6. Drive, lubricating oil pump (z=23)
7. Idler (z=44)
8. Drive, hydraulic pump (z=39)
9. Idler (z=71)
10. Drive to belt and fuel pump (z=27)
11. Drive, servo pump (z=23)
12. Spray nozzle, drive lubrication
13. Idler, adjustable (z=97)



Flank clearance, adjustable intermediate gear (13) ..	0.05–0.17 mm (0.0020–0.0067")
Intermediate gear shaft journal, diameter	99.99±0.01 mm (3.937±0.0004")
Intermediate gear bush, diameter	100.04±0.01 mm (3.939±0.0004")
Radial clearance for intermediate, max. diameter ..	0.03–0.07 mm (0.0012–0.0028")
Axial clearance for intermediate gear	0.07–0.17 mm (0.0028–0.0067")

Camshaft

Checking camshaft setting. The engine should be cold and the No. 1 cylinder valves should be adjusted to a clearance of 0. At a flywheel position of 6° ATDC the No. 1 cylinder inlet valve should have opened 1.6 ± 0.3 mm (0.063 ± 0.012 ").

When checking this the timing mechanism must be rotated in the right direction (clockwise viewed from the front) to take up any backlash.

NOTE: Do not forget to adjust the valve clearance back to the correct value after the test.

Drive	Gears
Number of bearings	7
Diameter of journals, standard	70 mm (2.76 ")
Diameter of journals, undersize:	
0.25	69.720–69.780 mm (2.7449–2.7472")
0.50	69.470–69.530 mm (2.7350–2.7374")
0.75	69.220–69.280 mm (2.7252–2.7276")

Wear tolerances

Axial clearance, max.	0.35 mm (0.0014")
Radial clearance, max.	0.01 mm (0.0004")
Valve lift:	
Inlet	13.1 mm (0.516")
Exhaust	13.1 mm (0.516")
Unit injector (stroke)	17 mm (0.669")

Camshaft bearings


Camshaft bearing thickness, standard:	1.9 mm (0.075")
Oversize:	
0.25	2.0 mm (0.079")
0.50	2.2 mm (0.087")
0.75	2.3 mm (0.091")
Diameter, camshaft bearing housings:	
Bearings 1-7	73.9 mm (2.91")

Crank movement

Crankshaft

Length	1203 mm (47.36")
Crankshaft axial clearance ¹	0.10–0.40 mm (0.0039–0.0157")
Main bearing radial clearance ¹	0.01–0.15 mm (0.0004–0.0059")
Max. permissible ovality of main bearing journals and crankpins	0.08 mm (0.003")
Max. permissible conicity of main bearing journals and crankpins	0.05 mm (0.002")
Max. runout of centre bearing	0.15 mm (0.006")

¹ The dimensions apply to oiled parts



Main bearing journals

Diameter (Ø) for machining, standard	108.0 mm (4.25")
Undersize:	
0.25 mm (0.010")	107.73–107.75 mm (4.2413–4.2421")
0.50 mm (0.020")	107.48–107.50 mm (4.2315–4.2323")
0.75 mm (0.030")	107.23–107.25 mm (4.2216–4.2224")
1.00 mm (0.040")	106.98–107.0 mm (4.2118–4.2126")
1.25 mm (0.050")	106.73–106.75 mm (4.2020–4.2027")
Surface finish, main bearing journal	Ra 0.25
Surface finish, radius	Ra 0.4
Width, thrust bearing journal (A) standard	47.0 mm (1.85")
Oversize:	
0.2 mm (0.008") (thrust bearing 0.1)	47.175–47.225 mm (1.8573–1.8592")
0.4 mm (0.016") (thrust bearing 0.2)	47.375–47.425 mm (1.8652–1.8651")
0.6 mm (0.024") (thrust bearing 0.3)	47.575–47.625 mm (1.8730–1.8750")
Fillet radius (R)	3.75–4.00 mm (0.148–0.158")

Thrust washers (thrust bearing)

Width (B) standard	3.1–3.2 mm (0.122–0.126")
Oversize:	
0.1 mm (0.004")	3.2–3.3 mm (0.126–0.130")
0.2 mm (0.008")	3.3–3.4 mm (0.130–0.134")
0.3 mm (0.012")	3.4–3.5 mm (0.134–0.138")

Main bearing shells

Type replaceable

Outer diameter (**C**) 113.0 mm (4.45")Thickness (**D**) standard 2.5 mm (0.098")

Oversize:

0.25 mm (0.010") 2.6–2.7 mm (0.102–0.106")

0.50 mm (0.020") 2.7–2.8 mm (0.106–0.110")

0.75 mm (0.030") 2.8–2.9 mm (0.110–0.114")

1.00 mm (0.040") 2.9–3.0 mm (0.114–0.118")

1.25 mm (0.050") 3.1–3.2 mm (0.122–0.126")

Crankpins

Diameter (**Ø**) for machining, standard 92.0 mm (3.62")

Undersize:

0.25 mm (0.010") 91.73–91.75 mm (3.6114–3.612")

0.50 mm (0.020") 91.48–91.50 mm (3.6016–3.6024")


0.75 mm (0.030") 91.23–91.25 mm (3.5917–3.5925")

1.00 mm (0.040") 90.98–91.00 mm (3.5819–3.5827")

1.25 mm (0.050") 90.73–90.75 mm (3.5720–3.5728")

Surface finish, crankpin Ra 0.25

Surface finish, radius Ra 0.4

Width (**A**) thrust bearing journal 56.9–57.0 mm (2.240–2.244")Fillet radius (**R**) (5.25–5.5) 3.75–4.00 mm (0.148–0.158")**Big-end bearing shells**Outside diameter (**B**) 96.85 mm (3.8130")Thickness (**C**) standard 2.39–2.40 mm (0.0941–0.0945")

Oversize:

0.25 mm (0.010") 2.51–2.52 mm (0.0988–0.0992")


0.50 mm (0.020") 2.64–2.65 mm (0.1039–0.1043")

0.75 mm (0.030") 2.76–2.77 mm (0.1087–0.1091")

1.00 mm (0.040") 2.89–2.90 mm (0.1138–0.1142")

1.25 mm (0.050") 3.01–3.02 mm (0.1185–0.1189")

Diameter, bearing shell seat (**D**) 96.84–96.85 mm (3.8126–3.8130")



Connecting rod

Length, centre-to-centre (E) 260 mm (10.236")

Marking:

Connecting rod and cap¹ 1 to 6

"FRONT" on the shank to face Forwards

Connecting rod bush inside diameter (G) 55 mm (2.165")

Axial clearance, big-end - crankshaft, max.² 0.35 mm (0.014")

Big-end bearing, radial clearance, max.² 0.10 mm (0.004")

Straightness, max. deviation per 100 mm (3.94")

measured length 0.06 mm (0.002")

Warping, max. deviation per 100 mm (3.94")

measured length 0.15 mm (0.006")

¹ Marking on same side

² The measurements apply to oiled parts

Flywheel. fitted

Max. permissible axial runout,
test radius 150 mm (5.91") 0.20 mm (0.008")

Number of teeth on starter ring 153

Sensor grooves on flywheel 3 x 18

Lubricating system

Oil grade	Fuel sulphur content in per cent by weight		
	up to 0.5 %	0.5 - 1.0 %	more than 1.0 %
	Oil change interval: in operation whichever reached first		
VDS-2 and ACEA E3 ²⁾	600 hours or 12 months	300 hours or 12 months	150 hours or 12 months
VDS and ACEA E3 ²⁾	400 hours or 12 months	200 hours or 12 months	100 hours or 12 months ³⁾
ACEA : E4, E3, E2 API: CE, CF, CF-4, CG-4, CH-4	200 hours or 12 months	100 hours or 12 months	50 hours or 12 months ³⁾

NOTE: Mineral-based, fully-synthetic or synthetic-based oil can be used provided that the above oil grade requirements are fulfilled.


- 1) At a sulphur content >1.0 per cent by weight, oil with a TBN >15 should be used.
- 2) Lubricating oil should meet both requirements.
Note: API: CG-4 or CH-4 is acceptable in markets outside Europe (instead of ACEA E3).
- 3) Lubricating oil with TBN 14-20 should be used

VDS = Volvo Drain Specification

ACEA = Association des Constructeurs Européenne d'Automobiles

API = American Petroleum Institute

TBN = Total Base Number



Viscosity

The viscosity should be selected from the adjacent table. Note: the temperatures refer to constant outside air temperature.

* Refers to synthetic or synthetic-based oil.

Oil

Change volume including changing three filters:

For horizontal installation 35 litres (9.2 US gal)

Oil pressure

Operating engine speed 1100 rpm or higher 400–550 kPa (58–80 psi)

Idling speed, minimum 175 kPa (25 psi)

Oil filters

Number 3


Full-flow filter (tightened 1/2–3/4 turn after fitting) ... 2

Bypass filter (tightened 3/4–1 turn after fitting) 1

Oil pump

Type Gear driven

Oil valves




1. Safety valve

Marking Yellow
 Safety valve opening pressure 700 kPa (101 psi)


2. Delivery valve, oil cooler

Marking 124
 Delivery valve, oil cooler, opening pressure 300 kPa (43 psi)



3, 5. Overflow valve, oil filter, full-flow/by-pass

Marking on spring Blue/yellow
 Overflow valve, oil filter, opening pressure 110 kPa (16 psi)
 Free length 68.8 mm (2.71")
 Loaded with 25–29 N (2.5–2.9 kgf (5.5–6.4 lbs)) 40.0 mm (1.58")




4. Piston cooling valve

Marking Orange
 Piston cooling valve, opening pressure 200 kPa (29 psi)

6. Pressure reducing valve

Marking Blue
 Pressure reducing valve, opening pressure 480 kPa (70 psi)

Fuel system



Injection order

Injection order 1-5-3-6-2-4

Feed pump

Feed pressure after fuel filter at 1000 rpm, min. 350 kPa (51 psi)

Feed pressure after fuel filter at full load, min. 350 kPa (51 psi)

Overflow valve

Opening pressure 400–450 kPa
(58–65 psi)


Sensor spacing

Camshaft 0.3–1.0 mm (0.012–0.040")

Flywheel 0.75–2.1 mm (0.030–0.083")

Unit injectors

Prestress (setting with gauge) 68.9±0.1 mm (2.712±0.004")



Inlet and exhaust system

Engine	TAD1240GE	TAD1241GE/VE
	TWD1240VE	TAD1242GE/VE
Turbocharger		
Manufacturer and type	3K/Warner	K31 3971 QXAKB
		K31 3971 QXAKB
		24.21 DCAYD
		27.21 DCAYD
Lubrication system	Force-feed lubrication	
Max. permissible axial clearance	0.16 mm (0.0063")	
Max. permissible radial clearance		
(turbocharger side)	0.45 mm (0.0177")	

Pressure drop indicator

Air filter	TAD1240-42GE	TAD1241-42VE
		TWD1240VE
Level for indication (vacuum)	500 mm (19.7") w.g.	
Exhaust back pressure		
Exhaust back pressure, max.	10 kPa	15 kPa
	(1.5 psi)	(2,2 psi)

Cooling system

General

Type	Overpressure, closed
Pressure cap valve opens at	75 kPa (11 psi)
Capacity (engine)	20 litres (5.3 US gal)
Capacity (engine + radiator and hoses)	44 litres (11.6 US gal)

Thermostat

	TAD1240-42GE	TWD1240VE
	TAD1241-42VE	
Type	Piston thermostat	
Number	1	
Opening temperature	82° C	75° C
	(187° F)	(167° F)

Coolant filter

Number	1
--------------	---

Coolant pump

Type	Geared centrifugal pump
------------	-------------------------

Coolant

Type	Volvo Penta glycol
Consisting of	Glycol + corrosion inhibiting additives
Colour	Blue-green
Mixed with	Water*

Corrosion inhibitor

Type	Volvo original corrosion inhibitor
Used	When Volvo Penta anti-freeze is unnecessary
Mixed with	Water*

NOTE: The corrosion inhibitor additive must not be mixed with coolant or any other type of corrosion inhibitor as this could give rise to adverse effects.

*** Water quality**

To avoid the risk of clogging in the cooling system the coolant should be mixed with **pure** water to ASTM D4985. If in any doubt about the purity of the water, **distilled water** or **ready-mixed coolant** should be used instead.

ASTM D4985:

Total solid particulate	< 340 ppm
Total hardness	< 9.5° dH
Chloride	< 40 ppm
Sulphate	< 100 ppm
pH value	5.5–9
Silicon	< 20 mg SiO ₂ /l (<20 ppm SiO ₂)
Iron	< 0.10 ppm
Manganese	< 0.05 ppm
Conductivity	< 500 µS/cm
Organic content, COD _{Mn}	< 15 mg KMnO ₄ /l (<15 ppm KMnO ₄)

Tightening torques

General tightening torques	Nm	(kgfm)
M6 standard bolt 8.8	10±1.5	(1.0±0.15)
M8 standard bolt 8.8	24±4	(2.4±0.4)
M10 standard bolt 8.8	48±8	(4.8±0.8)
M12 standard bolt 8.8	85±15	(8.5±1.5)
M14 standard bolt 8.8	140±25	(14.0±2.5)
Special tightening torques	Nm	(kgfm) Angle tightening
Group 21		
Front engine mounting, crossmember (M14)	180±15	(18.0±1.5)
Front engine mounting (M16)	220±35	(22.0±3.5)
Rear engine mounting, flywheel housing (M16)	220±35	(22.0±3.5)
Main bearings		
Stage 1	150±20	(15.0±2.0)
Stage 2	120°±5°	
Big-end cap	275±12	(27.5±1.2)
Flywheel		
(see tightening diagram "Flywheel" page 22)	245 ₊₂₅ ⁰	+24.5 _{+2.5} ⁰
Flywheel housing	140±14	(14.0±1.4)
Vibration damper, inner (2 socket cap screws)		
Stage 1	60±5	(6.0±0.5)
Stage 2		90°±5°
Vibration damper outer or Pulley (10 bolts, see tightening diagram "Outer vibration damper" page 24)		
Stage 1	60±5	(6.0±0.5)
Stage 2		90°±5°
Rocker cover (see tightening diagram "Rocker cover" page 22)	20±2	(2.0±0.2)
Stud, rocker cover	40±3	(4.0±0.3)
Cylinder head (see tightening diagram "Cylinder head" page 23)		
Stage 1	60±10	(6.0±1.0)
Stage 2 (check tightening)	60±10	(6.0±1.0)
Stage 3		90°±5°
Stage 4		90°±5°
Clean-out plugs, cylinder head	60±10	(6.0±1.0)
Lock nut, valve adjustment bolt	38±4	(3.8±0.4)

Special tightening torques

Bolts for camshaft bearing caps should be tightened in 5 stages, see tightening diagram "Bearing caps, camshaft/rocker arm shaft" page 23.

Timing cover, upper (see tightening diagram "Timing cover, upper" page 25)

Timing gear incl. toothed wheel (see tightening diagram "Timing gear" page 25)


	Nm	(kgfm) Angle tightening
Timing plate (see "Timing plate" page 24)	34±4	(3.4±0.4)
Group 22		
Oil nozzle in timing gear (see "Timing gear" page 25)	34±4	(3.4±0.4)
Oil cooler, retaining bolts	27±4	(2.7±0.4)
Cover, oil cooler (see tightening diagram "Cover, oil cooler" page 27)	24±4	
Delivery oil pipe (see "Delivery oil pipe" page 26) ..	180° new pipe	60° used pipe
Bolt, piston cooling nozzle (see "Piston cooling nozzle" page 26)	24±4	(2.4±0.4)
Drain plug, oil sump	60±10	(6.0±1.0)
Group 23		
Bolt, retaining yoke, unit injector (new copper sleeve)		
First tightening		
Stage 1	20±5	(2.0±0.5)
Stage 2		180°±5°
Undo the bolt for the unit injector retaining yoke before the second tightening		
Second tightening		
Stage 1	20±5	(2.0±0.5)
Stage 2		60°±5°
Bolt, retaining yoke, unit injector (old copper sleeve)		
Stage 1	20±5	(2.0±0.5)
Stage 2		60°±5°
Lock nut for adjusting screw, unit injector	52±4	(5.2±0.4)
Nut, connection, unit injector	1.5±0.5	(0.15±0.05)
Clamping and tightening torques for fuel lines (see "Fuel lines" page 28).		




IMPORTANT! Pay attention and do **NOT** tighten the nut for the electrical connections (on the unit injector) to a higher torque than specified above.

Tightening diagram


Flywheel




Rocker cover



Cylinder head




Bearing caps, camshaft/rocker arm shaft



NOTE: Tightening in stage 2 should be carried out gradually to ensure that the rocker arm shaft bottoms against the bearing housings without bending.


NOTE: In stage 4 undo the marked bolts before continuing to stage 5. If the rocker arm shaft has been loosened or removed, only the bolts retaining the shaft should be tightened according to the diagram on refitting.

Timing plate





Centre the plate using tool 9998267. No special tightening sequence for marked bolts.


Outer vibration damper



Timing cover, upper




Timing



Piston cooling nozzle


NOTE: The piston cooling nozzle retaining bolt has a friction coating and can be used only once.


⚠ IMPORTANT! Incorrect piston cooling always leads to seizing of the piston or pistons. If it is suspected that the piston cooling nozzle could be damaged or deformed it must be changed. This applies to new nozzles also. Always check that the piston cooling nozzle is correctly located in the hole in the cylinder block and that the retaining plate lies flat against the cylinder block. If the piston cooling nozzle is not correctly fitted, engine breakdown when under load will be the immediate result.



Delivery oil pipe

Tighten to "0 clearance" and then angle tighten 60° for a used delivery oil pipe and 180° for a new delivery oil pipe.




Cover, oil cooler

Always use locating pins when positioning the cover on the engine.


- 1 Insert screws A and B to align the cover.
- 2 Tighten screws C and D.
- 3 Insert all screws, tighten the screws in numerical order from the center outwards, in accordance with the diagram (1 - 4).
- 4 Check screws C and D for tightness.

Fuel lines TAD




- A. Banjo bolt 34 ± 4 Nm (25 ± 3 lbf. ft)
- B. Nipple 14 ± 3 Nm (10 ± 2.2 lbf. ft)
- C. Overflow valve 55 ± 5 Nm (41 ± 3.7 lbf. ft)
- D. Banjo bolt 35 ± 4 Nm (26 ± 3 lbf. ft)
- E. Nut 65 ± 5 Nm (48 ± 3.7 lbf. ft)
- F. Nut 65 ± 5 Nm (48 ± 3.7 lbf. ft)
- G. Banjo bolt 15 ± 2.5 Nm (11 ± 1.8 lbf. ft)
- 1 H. Bolt 55 ± 5 Nm (41 ± 3.7 lbf. ft)


Fuel lines TWD



- A. Overflow valve 55±5 Nm (41±3.7 lbf ft)
- B. Banjo bolt 35±5 Nm (26±3.7 lbf ft)
- C. Nut 65±5 Nm (48±3.7 lbf ft)
- D. Nut 65±5 Nm (48±3.7 lbf ft)
- E. Banjo bolt 15±2 Nm (11±1.5 lbf ft)
- 1 F. Banjo bolt 34±4 Nm (25±3 lbf ft)
- 2 G. Hose connection 55±5 Nm (41±3.7 lbf ft)




Exhaust manifold



- Stage 1. Tighten bolts 1 to 10 Nm (0.7 to 7.4 lbf.ft) (max.)
 Stage 2. Tighten bolts 2 to 10 Nm (1.5 to 7.4 lbf.ft) (max.)
 Stage 3. Tighten bolts 3 to 52 ±4 Nm (2.2 to 38 ±3 lbf.ft)
 Stage 4. Tighten bolts 2 to 52 ±4 Nm (1.5 to 38 ±3 lbf.ft)
 Stage 5. Tighten bolts 4 to 52 ±4 Nm (3.0 to 38 ±3 lbf.ft)
 Stage 6. Tighten bolts 1 to 52 ±4 Nm (0.7 to 38 ±3 lbf.ft)

Intercooler (TWD)



Tightening diagram

Tightening is done in two stages, in accordance with the tightening diagram.

Stage 1. Insert all of the screws; screw them down until they touch the surface.

Stage 2. Tighten the screws in accordance with the tightening diagram, to a torque of 20 ±2 Nm (14.7 ±1.5 lb. ft.).

Notes

A series of horizontal dotted lines for writing notes.

Report form

Do you have any complaints or other comments about this manual. Please make a copy of this page, write your comments down and send them to us. The address is at the bottom. We would prefer you to write in English or Swedish.

From:

.....
.....
.....

Refers to publication:

Publication No.: Date of issue:

Proposal/motivation:

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

Date:

Signed:

AB Volvo Penta
Technical Information
Dept. 42200
SE-405 08 Göteborg
Sweden

