

Electrical system

The engine is equipped with a bi-polar electrical system with alternator. System voltage is 24 volt.

IMPORTANT

The following applies to engines with alternator:

1. **Never break the circuit between the alternator and battery while the engine is running. The main switch must therefore not be turned off before the engine has stopped.** Cables must not be disconnected while the engine is running as this may also damage the voltage regulator.
2. Batteries, battery cables and cable terminals must be checked regularly. Battery terminals must be clean and cable shoes must be securely tightened and well greased to prevent breaks in the power supply. All cables must be well tightened with no loose connections.

NB! Take care not to switch the positive and negative battery terminals when connecting the batteries. Refer to the wiring diagram. Check drive belt tension regularly.

3. When starting using auxiliary batteries, see "**Start using auxiliary battery**".
4. Both battery cables must be disconnected before carrying out any repairs on the alternator. The same applies when rapid-charging the batteries.

NB! Observe current safety regulations when charging batteries.

5. Never use a screwdriver or similar tool to check a connection.

Arc welding

The following preparation must always be carried out whenever arc welding is performed on the engine or installed components:

Remove the 2 battery connections and then all the alternator leads from the alternator. Always connect the weld clamp to the component being welded and as close to the welding point as possible. Never attach the welding clamp to the engine or in any way that would entail welding current passing through a bearing. After completed welding: Fit the alternator leads **before** connecting the battery cables.

Start using auxiliary battery



WARNING! Batteries (especially auxiliary batteries) contain a mixture of hydrogen gas that is extremely explosive. One spark, which can result from incorrect connection of the cables, is sufficient to make a battery explode and cause personal injury and mechanical damage.

If the batteries have frozen, they must be thawed out before trying to start with an auxiliary battery.

1. Make sure the auxiliary batteries are connected (in series or parallel) so that the rated voltage corresponds with the system voltage of the engine.
2. Connect one end of the red cable to the positive terminal of the auxiliary battery (marked P or + in red) Make sure all the cable shoes are well tightened to avoid sparks.
3. Connect the other end of the red cable to the positive terminal of the battery where the positive cable to the engine is connected.
4. Connect the end of the black cable to the negative terminal of the auxiliary battery (marked N or - in blue).
5. Connect the other end of the black cable to a point a distance away from the flat batteries, e.g. by the main switch, or the negative cable or the negative cable connection on the engine.
6. Start the engine.

NB! Do not touch the connections while starting (risk for sparks) and do not lean over any of the batteries.

7. Remove the cables in the exact reverse order to connecting.


NB! The ordinary cables to the standard batteries must never be disconnected.

EDC system

TWD740VE is equipped with EDC (Electronic Diesel Control). A system that electronically governs the engine injection pump. More information on EDC can be found in "Workshop Manual, Fuel system EDC, TWD740VE, TWD1231VE".

Wiring diagram


1. Instrument panel and engine (equipped with stop solenoid)



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Oil pressure gauge 2. Coolant temperature gauge 3. Tachometer with integrated hour counter 4. Warning light, charging 5. Semi-automatic fuses (manual reset) 6. Stop button 7. Interlock button 8. Start button 9. Coolant level switch relay (extra equipment) 10. Coolant temperature switch relay, oil pressure switch 11. Holding current relay (operating current and instrument) 12. Terminal block (extra power socket, fused for 16 A, socket for automatic stop, making for fault.) 13. Relay for starting heater 14. Starting heater 15. Starter motor | <ol style="list-style-type: none"> 16. Batteries 17. Alternator 18. Engine speed sensor 19. Engine coolant temperature sensor 20. Coolant temperature switch (normal open) 21. Oil pressure sensor 22. Oil pressure switch 23. Coolant level switch (extra equipment) 24. Stop solenoid (Basic circuit diagram 1)/Fuel cut-off valve (basic circuit diagram 2) (live during operation) 25. Horn 26. Joint 27. Main switch 28. Relay 29. Engine speed sensor, overrevving protection 30. Overrevving protection 31. Fuse, 8 A |
|---|--|

* Disengaged when installing GAC regulator

2. Instrument panel and engine (equipped with fuel cut-off valve)



Cable areas in mm² (specified after the colour code in the wiring diagram). If an area is not specified, 1.5 mm² will apply.

Colour:	BL = Blue	LBN = Light brown
	OR = Orange	SB = Black
	LBL = Light blue	GN = Green
	VO = Violet	W = White
	BN = Brown	GR = Grey
	R = Red	Y = Yellow

The area of the battery cables depends on the location of the battery.



Distance starter motor - batteries: max. 2 m, area = 70 mm²

max. 4 m, area = 120 mm²

Relationship mm²/AWG (American Wiring Gauge)

mm ²	1.0	1.5	2.5	10	16
AWG	16 (17)	15 (16)	13	7	5

4. Connection of time relay (extra equipment.) for connecting time relay kit




- 1. Time relay
- 2. Connector, 8-pin.
- 3. Key switch
- 4. Temperature switch (extra equipment)
- 5. Starting heater


- 6. Indicator lamp
- 7. Battery
- 8. High power relay for starting heater
- 9. Fuse (8 A)

Electronic speed regulator

Engagement



Engagement actuator for 24 V system



Stop solenoid/fuel cut-off valve (8) connected live for operation (option). Engine stopped with switch (6).

NB! Later versions of stop solenoid have integrated transient protection, so that separate transient protection (7) is only required for the control unit.

1. Control unit
2. Actuator
3. Engine speed sensor (pickup)
4. Multi-turn potentiometer*
5. Fuse (quick-acting) 8 A
6. Main switch
7. Transient protection
8. Stop solenoid/fuel cut-off valve
9. Engine speed sensor for overrevving protection
10. Overrevving protection (speed switch)
11. Relay

* Not from Volvo Penta

Troubleshooting

1. Engine will not start

Starter motor not turning round engine

CAUSE	ACTION
<ul style="list-style-type: none"> Discharged batteries 	Charge batteries/change batteries (or connect auxiliary batteries as directed in "Start using auxiliary battery").
<ul style="list-style-type: none"> Main switch turned off 	Turn on main switch.
<ul style="list-style-type: none"> One of the semi-automatic fuses in the terminal box triggered (pos. 6 on engine wiring diagram) 	Reset fuse by pressing button on fuse.
<ul style="list-style-type: none"> Bad contact/break in connections and electric leads 	Rectify any breaks/loose connections. Check that connections have not oxidized. Clean when necessary and spray connections with moisture repelling spray. See "Wiring diagram".
<ul style="list-style-type: none"> Faulty starting switch/start button 	Change starting switch/start button.
<ul style="list-style-type: none"> Faulty starter relay 	Change starter relay.
<ul style="list-style-type: none"> Faulty starter motor/solenoid (actuator solenoid) 	Check starter motor/solenoid.
<ul style="list-style-type: none"> Water in compression chamber 	Do not attempt further starting if water is suspected. Check engine.

Starter motor rotates slowly

CAUSE	ACTION
<ul style="list-style-type: none"> Discharged batteries 	Charge batteries/change batteries (or connect auxiliary batteries as directed in "Start using auxiliary battery").
<ul style="list-style-type: none"> Bad contact/break in connections and electric leads 	Rectify any breaks/loose connections. Make sure that connections have not oxidized. Clean when necessary and spray connections with moisture repelling spray. See "Wiring diagram".

Starter motor cranking normally but engine will not start

CAUSE	ACTION
<ul style="list-style-type: none"> • Air in fuel system 	Bleed fuel system, see "Fuel system, bleeding".
<ul style="list-style-type: none"> • Lack of fuel <ul style="list-style-type: none"> – fuel cocks closed – fuel tank empty – blocked fuel filter (due to impurities/or due to paraffin precipitation in fuel at low outside temperature) 	Open fuel cocks. Refuel. Fit new fuel filter (pre-filter and/or fine filter). Bleed system, see "Fuel system, bleeding".
<ul style="list-style-type: none"> • Stop solenoid wrongly connected/sticking 	Make sure stop solenoid is in active position.
<ul style="list-style-type: none"> • Insufficient pre-heating <ul style="list-style-type: none"> – incorrect starting procedure – starting heater not engaged 	Try starting again as described in instruction manual. Make sure none of the semi-automatic fuses have triggered (pos. 6 on engine wiring diagram). Reset fuse by pressing button on fuse. Check electric wiring and interlock button, starter relay and high-power relay. Change starting heater if necessary.
<ul style="list-style-type: none"> • Blocked air intake 	Check air intake to engine compartment

2. Engine starts then stops again/runs unevenly

CAUSE	ACTION
<ul style="list-style-type: none"> • Air in fuel system 	Bleed fuel system, see "Fuel system, bleeding".
<ul style="list-style-type: none"> • Lack of fuel <ul style="list-style-type: none"> – fuel cocks closed – fuel tank empty – blocked fuel filter (due to impurities/or due to paraffin precipitation in fuel at low outside temperature) 	Open fuel cocks. Refuel Fit new fuel filter (pre-filter and/or fine filter). Bleed system, see "Fuel system, bleeding".
<ul style="list-style-type: none"> • Stop solenoid/fuel cut-off valve engaged/sticking 	Make sure that stop solenoid/fuel cut-off valve in operating position.
<ul style="list-style-type: none"> • Insufficient pre-heating <ul style="list-style-type: none"> – incorrect starting procedure – starting heater not engaged 	Try starting again as described in instruction manual. Make sure none of the semi-automatic fuses have triggered (pos. 6 on engine wiring diagram). Reset fuse by pressing button on fuse. Check electric wiring and interlock button, starter relay and high-power relay. Change starting heater if necessary

- | | |
|--|--|
| <ul style="list-style-type: none"> • Insufficient air supply to engine <ul style="list-style-type: none"> – blocked air filter • Faulty injector | <p>Fit new air filter/clean air filter, check ventilation to engine compartment.</p> <p>Check/change injector.</p> |
|--|--|

3. Coolant temperature too high

CAUSE	ACTION
<ul style="list-style-type: none"> • Coolant level in engine too low (air in system) 	Top up coolant in engine and bleed system, see "Filling with coolant".
<ul style="list-style-type: none"> • Faulty thermostat 	Fit new thermostat.
<ul style="list-style-type: none"> • Blocked radiator and/or intercooler (TAD) 	Clean, see "Cleaning cooling system".
<ul style="list-style-type: none"> • Faulty circulation pump 	Recondition/change circulation pump.
<ul style="list-style-type: none"> • Faulty temperature gauge/temperature sensor 	Check/change temperature gauge/temperature sensor.
<ul style="list-style-type: none"> • Faulty injection timing 	Check/adjust injection timing.

4. Coolant temperature too low

CAUSE	ACTION
<ul style="list-style-type: none"> • Faulty thermostat 	Fit new thermostat.

5. Engine does not attain correct operating speed at wide open throttle

CAUSE	ACTION
<ul style="list-style-type: none"> • Engine overloaded 	Reduce load if possible.
<ul style="list-style-type: none"> • Insufficient fuel supply <ul style="list-style-type: none"> – blocked fuel filter (due to impurities/or due to paraffin precipitation in fuel at low outside temperature) 	<p>Fit new fuel filter (pre-filter and/or fine filter).</p> <p>Bleed system, see "Fuel system, bleeding".</p>
<ul style="list-style-type: none"> • Water in fuel 	Clean fuel tank. Drain water from pre-filter.
<ul style="list-style-type: none"> • Insufficient air supply to engine <ul style="list-style-type: none"> – blocked air filter – air leak between turbo and engine intake manifold – faulty turbocharger – poor engine compartment ventilation 	<p>Fit new air filter/clean air filter.</p> <p>Check rubber hose between turbo and connect intake manifold, and other connections. Tighten hose clips.</p> <p>Clean compressor. Recondition as necessary turbocharger.</p> <p>Make sure ventilation passages to engine compartment are not blocked.</p>
<ul style="list-style-type: none"> • Accelerator control adjusted wrongly 	Adjust accelerator control.
<ul style="list-style-type: none"> • High back pressure in exhaust system 	Make sure there are no restrictions in exhaust line.

<ul style="list-style-type: none"> • Incorrect adjustment of injector pump 	Adjust injector pump.
<ul style="list-style-type: none"> • Faulty smoke limiter <ul style="list-style-type: none"> – smoke limiter sticking – pressure line between intake manifold and smoke limiter leaking 	Recondition smoke limiter. Fit new pressure line.
<ul style="list-style-type: none"> – faulty diaphragm in smoke limiter – incorrect setting 	Change diaphragm in smoke limiter. Adjust smoke limiter setting.
<ul style="list-style-type: none"> Stop control position 	Make sure stop control is in full operating position.

6. Engine does not stop

CAUSE	ACTION
<ul style="list-style-type: none"> • One of the semi-automatic fuses in the terminal box triggered (pos. 6 on engine wiring diagram) 	Reset fuse by pressing button on fuse.
<ul style="list-style-type: none"> • Bad contact/break in connections and leads 	Rectify any breaks/loose connections. Make sure that connections have not oxidized. Clean when necessary and spray connections with moisture repelling spray. See "Wiring diagram".
<ul style="list-style-type: none"> • Faulty stop button 	Change stop button.
<ul style="list-style-type: none"> • Faulty stop solenoid/fuel cut-off valve 	Check, change stop solenoid/fuel cut-off valve.

Notes

A series of horizontal dotted lines for writing notes.

Notes

A series of horizontal dotted lines for writing notes.

Notes

A series of horizontal dotted lines for writing notes, spanning the width of the page.