




# Operation and Maintenance Manual L10 Series Engines Industrial Models



## Foreword

This manual contains information for the correct operation and maintenance of your Cummins engine. It also includes important safety information, engine and systems specifications, troubleshooting guidelines, and listings of Cummins Authorized Repair Locations and component manufacturers.

**Read and follow all safety instructions. Refer to the WARNING in the General Safety Instructions in this section.**

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.




















The information, specifications, and recommended maintenance guidelines in this manual are based on information in effect at the time of printing. Cummins Engine Company, Inc. reserves the right to make changes at any time without obligation. If you find differences between your engine and the information in this manual, contact your local Cummins Authorized Repair Location.

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



**Note: Warranty information is located in Section W. Make sure you are familiar with the warranty or warranties applicable to your engine.**

# Table of Contents

	Section	
Introduction .....	i	
Engine Identification.....	E	
Operating Instructions.....	1	
Maintenance Guidelines .....	2	
Maintenance Procedures - Daily.....	3	
Maintenance Procedures - Weekly.....	4	
Maintenance Procedures - 250 Hours or 6 Months .....	5	
Maintenance Procedures - 1500 Hours or 1 Year .....	6	
Maintenance Procedures - 6000 Hours or 2 Years .....	7	
Maintenance Procedures - 6000 Hours or 3 Years .....	8	
System Diagrams .....	D	
Troubleshooting.....	T	
Adjustment, Repair and Replacement.....	A	
Specifications and Torque Values .....	V	
Service Assistance .....	S	
Component Manufacturers .....	C	
Warranty.....	W	
Additional Service Literature.....	L	
Index .....	X	

## NOTES

## Important Reference Numbers

Fill in the part name and number in the blank spaces provided below. This will give you a reference whenever service or maintenance is required.

Engine Model	_____
Engine Serial Number	_____
Engine CPL	_____
Fuel Pump Part Number	_____
Filter Part Numbers:	
• Air Cleaner Element	_____
• Lubricating Oil	_____
• Fuel	_____
• Fuel Water Separator	_____
Belt Part Numbers	_____
	_____
	_____
	_____
	_____

## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Section i - Introduction

### Section Contents

	Page
About the Manual .....	i-2
Definition of Terms .....	i-9
General Safety Instructions .....	i-8
How to Use the Manual .....	i-2
Illustrations .....	i-7
Symbols .....	i-3
To The Owner and Operator .....	i-2

## To The Owner and Operator

Preventative maintenance is the easiest and least expensive type of maintenance. Follow the maintenance schedule recommendations outlined in Maintenance Guidelines (Section 2).

Keep records of regularly scheduled maintenance.

Use the correct fuel, oil and coolant in your engine as specified in Engine Specifications (Section V).

Cummins Engine Company, Inc. uses the latest technology and the highest quality components to produce its engines. Cummins recommends using only genuine Cummins parts and ReCon® exchange parts.

Personnel at Cummins Authorized Repair Locations have been trained to provide expert service and parts support. If you have a problem that **cannot** be resolved by a Cummins Authorized Repair Location, follow the steps outlined in the Service Assistance (Section S).

## About the Manual

This manual contains information needed to correctly operate and maintain your engine as recommended by Cummins Engine Company, Inc. Additional service literature can be ordered from your local Cummins distributor.

This manual does **not** cover vehicle or equipment maintenance procedures. Consult the vehicle or equipment manufacturer for specific maintenance recommendations.

Both metric and U.S. customary values are listed in this manual. The metric value is listed first, followed by the U.S. customary in brackets.

Numerous illustrations and symbols are used to aid in understanding the meaning of the text. Refer to page i-3 for a complete listing of symbols and their definitions.

Each section is preceded by a "Section Contents" to aid in locating information quickly.

## How to Use the Manual

This manual is organized according to intervals at which maintenance on your engine is to be performed. A table which gives required intervals and checks to be made is located in Section 2. Locate the interval at which you are performing maintenance then follow the steps given in that section for all the procedures to be performed. In addition, the procedures completed under previous maintenance intervals **must** also be performed.

Keep a record of all the checks and inspections made. A record form for recording date or hours at which maintenance checks were performed is located in Section 2.

Refer to Section T for a guide to troubleshooting your engine. Follow the directions given on page 2 to locate and correct engine problems.

Refer to Section V for specifications recommended by Cummins Engine Company, Inc., for your engine. Specifications and torque values for each engine system are given in that section.



## Symbols

The following symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below:



**WARNING** - Serious personal injury or extensive property damage can result if the warning instructions are **not** followed.



**CAUTION** - Minor personal injury can result or a part, an assembly, or the engine can be damaged if the caution instructions are **not** followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



**INSPECTION** is required.



**CLEAN** the part or assembly.



**PERFORM** a mechanical or time **MEASUREMENT**.



**LUBRICATE** the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



**TIGHTEN** to a specific torque.



**PERFORM** an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.



The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.

## Simbolos

Los símbolos siguientes son usados en este manual para clarificar el proceso de las instrucciones. Cuando aparece uno de estos símbolos, su significado se especifica en la parte inferior.



**ADVERTENCIA** - Serios daños personales o daño a la propiedad puede resultar si las instrucciones de Advertencia **no** se consideran.



**PRECAUCION** - Daños menores pueden resultar, o de piezas del conjunto o el motor puede averiarse si las instrucciones de Precaución **no** se siguen.



Indica un paso de **REMOCION** o **DESMONTAJE**.



Indica un paso de **INSTALACION** o **MONTAJE**.



Se requiere **INSPECCION**.



**LIMPIESE** la pieza o el montaje.



**EJECUTESE** una **MEDICION** mecánica o del tiempo.



**LUBRIQUESE** la pieza o el montaje.



Indica que se dará una **LLAVE DE TUERCAS** o el **TAMAÑO DE HERRAMIENTA**.



**APRIETESE** hasta un par torsor específico.



**EJECUTESE** una **MEDICION** eléctrica.



Para información adicional refiérase a otro emplazamiento de este manual o a otra publicación anterior.



El componente pesa 23 kg [50 lb] o mas. Para evitar dano corporal empleen una cabria u obtengan ayuda para elevar el componente.

## Symbole

In diesem Handbuch werden die folgenden Symbole verwendet, die wesentliche Funktionen hervorheben. Die Symbole haben folgende Bedeutung:



**WARNUNG** - Wird die Warnung **nicht** beachtet, dann besteht erhöhte Unfall- und Beschädigungsgefahr.



**VORSICHT** - Werden die Vorsichtsmassnahmen **nicht** beachtet, dann besteht Unfall- und Beschädigungsgefahr.



**AUSBAU** bzw. **ZERLEGEN**.



**EINBAU** bzw. **ZUSAMMENBAU**.



**INSPEKTION** erforderlich.



Teil oder Baugruppe **REINIGEN**.



**DIMENSION** - oder **ZEITMESSUNG**.



Teil oder Baugruppe **ÖLEN**.



**WERKZEUGGRÖSSE** wird angegeben.



**ANZUG** auf vorgeschriebenes Drehmoment erforderlich.



Elektrische **MESSUNG DURCHFÜHREN**.



Weitere Informationen an anderer Stelle bzw. in anderen Handbüchern.



Das teil wiegt 23 kg [50 lb] oder mehr. Zur vermeidung von koerperverletzung winde benutzen oder hilfe beim heben des teils in anspruch nehmen.

## Symboles

Les symboles suivants sont utilisés dans ce manuel pour aider à communiquer le but des instructions. Quand l'un de ces symboles apparaît, il évoque le sens défini ci-dessous:



**AVERTISSEMENT** - De graves lésions corporelles ou des dommages matériels considérables peuvent survenir si les instructions données sous les rubriques "Avertissement" **ne sont pas** suivies.



**ATTENTION** - De petites lésions corporelles peuvent survenir, ou bien une pièce, un ensemble ou le moteur peuvent être endommagés si les instructions données sous les rubriques "Attention" **ne sont pas** suivies.



Indique une opération de **DEPOSE**.



Indique une opération de **MONTAGE**.



**L'INSPECTION** est nécessaire.



**NETTOYER** la pièce ou l'ensemble.



**EFFECTUER** une **MESURE** mécanique ou de temps.



**GRAISSER** la pièce ou l'ensemble.



Indique qu'une **DIMENSION DE CLE** ou **D'OUTIL** sera donnée.



**SERRER** à un couple spécifique.



**EFFECTUER** une **MESURE** électrique.




Se reporter à un autre endroit dans ce manuel ou à une autre publication pour obtenir des informations plus complètes.




Le composant pèse 23 kg [50 lb] ou davantage. Pour éviter toute blessure, employer un appareil de levage ou demander de l'aide pour le soulever.

## Illustrations

The illustrations used in the "Repair Sections" of this manual are intended to give an example of a problem, and to show what to look for and where the problem can be found. Some of the illustrations are "generic" and might **not** look exactly like the engine or parts used in your application. The illustrations can contain symbols to indicate an action required, and an acceptable or **not** acceptable condition.



The illustrations are intended to show repair or replacement procedures. The illustration can differ from your application, but the procedure given will be the same.



## General Safety Instructions

### Important Safety Notice



### WARNING



**Improper practices or carelessness can cause burns, cuts, mutilation, asphyxiation or other bodily injury or death.**

Read and understand all of the safety precautions and warnings before performing any repair. This list contains the general safety precautions that **must** be followed to provide personal safety. Special safety precautions are included in the procedures when they apply.

- Make sure the work area surrounding the product is dry, well lit, ventilated; free from clutter, loose tools, parts, ignition sources and hazardous substances. Be aware of hazardous conditions that can exist.
- **Always** wear protective glasses and protective shoes when working.
- Rotating parts can cause cuts, mutilation or strangulation.
- Do **not** wear loose-fitting or torn clothing. Remove all jewelry when working.
- Disconnect the battery (negative [-] cable first) and discharge any capacitors before beginning any repair work. Disconnect the air starting motor if equipped to prevent accidental engine starting. Put a "Do Not Operate" tag in the operator's compartment or on the controls.
- Use **ONLY** the proper engine barring techniques for manually rotating the engine. Do **not** attempt to rotate the crankshaft by pulling or prying on the fan. This practice can cause serious personal injury, property damage, or damage to the fan blade(s) causing premature fan failure.
- If an engine has been operating and the coolant is hot, allow the engine to cool before you slowly loosen the filler cap and relieve the pressure from the cooling system.
- Do **not** work on anything that is supported **ONLY** by lifting jacks or a hoist. **Always** use blocks or proper stands to support the product before performing any service work.
- Relieve all pressure in the air, oil, and the cooling systems before any lines, fittings, or related items are removed or disconnected. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do **not** check for pressure leaks with your hand. High pressure oil or fuel can cause personal injury.
- To prevent suffocation and frostbite, wear protective clothing and **ONLY** disconnect liquid refrigerant (freon) lines in a well ventilated area. To protect the environment, liquid refrigerant systems **must** be properly emptied and filled using equipment that prevents the release of refrigerant gas (fluorocarbons) into the atmosphere. Federal law requires capture and recycling refrigerant.
- To avoid personal injury, use a hoist or get assistance when lifting components that weigh 23 kg [50 lb] or more. Make sure all lifting devices such as chains, hooks, or slings are in good condition and are of the correct capacity. Make sure hooks are positioned correctly. **Always** use a spreader bar when necessary. The lifting hooks **must not** be side-loaded.
- Corrosion inhibitor contains alkali. Do **not** get the substance in your eyes. Avoid prolonged or repeated contact with skin. Do **not** swallow internally. In case of contact, immediately wash skin with soap and water. In case of contact, immediately flood eyes with large amounts of water for a minimum of 15 minutes. **IMMEDIATELY CALL A PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
- Naptha and Methyl Ethyl Ketone (MEK) are flammable materials and **must** be used with caution. Follow the manufacturer's instructions to provide complete safety when using these materials. **KEEP OUT OF REACH OF CHILDREN.**
- To avoid burns, be alert for hot parts on products that have just been turned OFF, and hot fluids in lines, tubes, and compartments.
- **Always** use tools that are in good condition. Make sure you understand how to use them before performing any service work. Use **ONLY** genuine Cummins or Cummins Recon® replacement parts.
- **Always** use the same fastener part number (or equivalent) when replacing fasteners. Do **not** use a fastener of lesser quality if replacements are necessary.
- Do **not** perform any repair when fatigued or after consuming alcohol or drugs that can impair your functioning.
- Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.

## Definition of Terms

<b>AFC</b>	Air Fuel Control	<b>in-lb</b>	Inch Pound
<b>API</b>	American Petroleum Institute	<b>kg</b>	Kilograms
<b>ASA</b>	Air Signal Attenuator	<b>km</b>	Kilometers
<b>ASTM</b>	American Society of Testing and Materials	<b>km/l</b>	Kilometers per Liter
<b>C</b>	Celsius	<b>kPa</b>	Kilopascal
<b>CARB</b>	California Air Resources Board	<b>l</b>	Liter
<b>C.I.D.</b>	Cubic Inch Displacement	<b>m</b>	Meter
<b>cm</b>	Centimeter	<b>mm</b>	Millimeter
<b>CPL</b>	Control Parts List	<b>MPa</b>	Megapascal
<b>cSt</b>	Centistokes	<b>MPH</b>	Miles Per Hour
<b>DCA</b>	Diesel Coolant Additive	<b>MPQ</b>	Miles Per Quart
<b>E.C.S.</b>	Emission Control System	<b>N•m</b>	Newton-meter
<b>EPA</b>	Environmental Protection Agency	<b>OEM</b>	Original Equipment Manufacturer
<b>F</b>	Fahrenheit	<b>ppm</b>	Parts Per Million
<b>ft-lb</b>	Foot Pound	<b>psi</b>	Pounds Per Square Inch
<b>GVW</b>	Gross Vehicle Weight	<b>PTO</b>	Power Takeoff
<b>Hg</b>	Mercury	<b>RPM</b>	Revolutions Per Minute
<b>HP</b>	Horsepower	<b>S.A.E.</b>	Society of Automotive Engineers
<b>H<sub>2</sub>O</b>	Water	<b>VS</b>	Variable Speed

## This image shows a single page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, leaving small margins at the top and bottom. There is no handwriting or other markings on the paper.




# Section E - Engine and Component Identification

## Section Contents

	Page
<b>Engine Identification</b> .....	E-2
Cummins Engine Nomenclature .....	E-2
Engine Dataplate .....	E-2
Fuel Pump Dataplate .....	E-2
<b>General Specifications</b> .....	E-3
Air Intake System .....	E-4
Batteries (Specific Gravity) .....	E-4
Cooling System .....	E-3
Electrical System .....	E-4
Exhaust System .....	E-4
External Engine Components .....	E-5
Fuel System .....	E-3
General Engine Data .....	E-3
Lubricating Oil System .....	E-3

## Engine Identification



### Engine Dataplate

The engine dataplate shows specific information about your engine. The engine serial number and Control Parts List (CPL) provide information for ordering parts and service needs.

**NOTE:** The engine dataplate **must not** be changed unless approved by Cummins Engine Company, Inc.

The dataplate is located on the fuel pump side of the engine on the side of the rocker housing.

Have the following engine data available when communicating with a Cummins Authorized Repair Location:

1. Engine Serial Number (ESN)
2. CPL
3. Model
4. Horsepower and RPM Rating

A detailed diagram of the engine dataplate. It is a rectangular plate with various fields and labels. Numbered callouts point to specific areas: 1 points to the 'Engine No.' field, 2 points to the 'CPL' field, 3 points to the 'Model' field, and 4 points to the 'Horsepower and RPM Rating' section. The plate includes fields for 'Advert. HP', 'Fuel rate at Advert. HP', 'Peak Torque (FT-LB)', 'Valve Lash Cold', 'Inj. Set', 'RPM', 'E.C.S.', 'Inj. Timing Code', 'C.I.D./L.', 'Exh. CPL', 'Governed Speed', 'Family', 'Injector Torque', 'Inch-Lbs.', 'Warranty St. Date', and 'Rel. No.'. It also features a 'Cummins' logo and the text 'Manufactured by Cummins Engine Co. Inc. Made in U.S.A.' and '3074259'.

A diagram of the fuel pump dataplate. It is a rectangular plate with the title 'FUEL PUMP DATAPLATE' at the top. Below the title are four fields: 'CPL', 'Fuel Code', 'Revision', and 'Serial No.'. Each field contains a number or code: '0749', '4219-A', '840508', and '3043327'. Below these fields are two more fields: 'Service Part No.' and 'Pump Production Part No.'. The plate also includes the 'Cummins' logo and the text 'Ip8plga'.

### Fuel Pump Dataplate

The fuel pump dataplate is located on the top of the fuel pump. It provides information for fuel pump calibration.

### Cummins Engine Nomenclature

The Cummins engine nomenclature provides the following engine data:

**NOTE:** A = Agriculture  
C = Construction  
G = Generator Drive

L 10 - C 240

L = Engine Model Designation  
 10 = Displacement (Liters)  
 C = Market Application (See Note)  
 240 = Brake Horsepower

## General Specifications

Metric [U.S. Customary]

### General Engine Data

Horsepower (Refer to the engine dataplate)

Engine speed @ Maximum Output:

- Standard Rating (RPM) ..... 2100

Bore and Stroke ..... 125 mm [4.921 in] X 136 mm [5.354 in]

Displacement ..... 10 liters [611 C.I.D.]

Compression Ratio: ..... 16.3:1

Firing Order ..... 1-5-3-6-2-4

Engine Weight (with Standard Accessories):

- Dry Weight ..... 884.5 kg [1950 lb]
- Wet Weight ..... 929.8 kg [2050 lb]

Crankshaft Rotation - (viewed from the front of the engine).....Clockwise

### Fuel System

For performance and fuel rate values, refer to the engine data sheet, or the fuel pump code for the particular model involved.

Maximum Allowable Restriction to Pump:

- With **Clean** Filter ..... 102 mm Hg [4 in Hg]
- With **Dirty** Filter ..... 204 mm Hg [8 in Hg]

Maximum Allowable Return Line Restriction ..... 63 mm Hg [2.5 in Hg]

Maximum Allowable Return Line Restriction with Check Valves and/or Overhead Tanks . 165 mm Hg [6.5 in Hg]

### Lubricating Oil System

Oil Pressure - Low Idle (Minimum Allowable) ..... 70 kPa [10 psi]

- At 1200 RPM or Torque Peak (Minimum Allowable) ..... 207 kPa [30 psi]

Oil Capacity of Standard Engine:

- Combination Filter ..... 2.6 liters [0.7 U.S. gal]
- Oil Pan (High-Low) ..... 34 to 30.3 liters [9 to 8 U.S. gal]

Total System Capacity including filters ..... 38 liters [10 U.S. gal]

### Cooling System

Coolant Capacity (Engine Only) ..... 11 liters [12 U.S. qts]

Standard Modulating Thermostat Range ..... 82 to 93°C [180 to 200°F]

Minimum Recommended Pressure Cap ..... 50 kPa [7 psi]

Minimum Recommended Operating Temperature ..... 70°C [158°F]

Maximum Allowable Operating Temperature ..... 100°C [212°F]

## Exhaust System

Exhaust Pipe Size (Normally Acceptable Inside Diameter) ..... 102 mm [4 in]

Maximum Exhaust Pipe Restriction

- H<sub>2</sub>O ..... 1016 mm [40 in]
- Hg ..... 75 mm [3 in]

## Air Intake System

Maximum Allowable Intake Restriction with Clean Air Filter Element:

- Heavy Duty Dry Type Cleaner ..... 25.4 cm H<sub>2</sub>O [10 in. H<sub>2</sub>O]

Maximum Allowable Intake Restriction with Dirty Air Filter Element ..... 64 cm H<sub>2</sub>O [25 in. H<sub>2</sub>O]

## Electrical System

Minimum Recommended Battery Capacity

System Voltage	Ambient Temperatures			
	-18°C [0°F]		0°C [32°F]	
	Cold Cranking Amperes	Reserve Capacity *	Cold Cranking Amperes	Reserve Capacity* Amperes
12 Volt	1800	640	1280	480
24 Volt **	900	320	640	240

\* The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time which sustained cranking can occur.


\*\* CCA ratings are based on two, 12 volt batteries in series.


## Batteries (Specific Gravity)

Specific Gravity at 27°C [80°F]	State of Charge
1.260 to 1.280	100%
1.230 to 1.250	75%
1.200 to 1.220	50%
1.170 to 1.190	25%
1.110 to 1.130	Discharged

## External Engine Components

The illustrations which follow show the locations of the major external engine components, the filters, and other service and maintenance points. Some external components will be at different locations for different engine models.





**Exhaust Side**

ew200g04

# Section 1 - Operating Instructions

## Section Contents

	Page
Cold Weather Operation .....	1-8
Cold Weather Starting (Below 0°C [32°F]) .....	1-4
Using Starting Fluid With Mechanical or Electrical Metering Equipment .....	1-4
Engine Operating Range .....	1-7
Engine Shut-down .....	1-9
General Information .....	1-2
Jacobs® Engine Brakes .....	1-10
Normal Starting Procedure (Above 0°C [32°F]) .....	1-3
Operating the Engine .....	1-6
Power Takeoff Application with Variable Speed Controls .....	1-9

Engine Maintenance Schedule (1-2)				
Daily or Before Starting	Every 15,000 km (10,000 mi) or 5 months (2-3)	Every 30,000 km (20,000 mi) or 10 months (4-5)	Every 45,000 km (30,000 mi) or 15 months (6-7)	Every 60,000 km (40,000 mi) or 20 months (8-9)
<ul style="list-style-type: none"> <li>Check oil level and change if necessary</li> <li>Check coolant level</li> <li>Check battery electrolyte level</li> <li>Check battery terminals for corrosion</li> <li>Check air filter</li> <li>Check water pump</li> <li>Check belt tension</li> <li>Check for leaks</li> <li>Check for loose parts</li> <li>Check for unusual noises</li> <li>Check for unusual vibrations</li> </ul>	<ul style="list-style-type: none"> <li>Change oil and filter</li> <li>Check coolant level</li> <li>Check battery electrolyte level</li> <li>Check battery terminals for corrosion</li> <li>Check air filter</li> <li>Check water pump</li> <li>Check belt tension</li> <li>Check for leaks</li> <li>Check for loose parts</li> <li>Check for unusual noises</li> <li>Check for unusual vibrations</li> </ul>	<ul style="list-style-type: none"> <li>Change oil and filter</li> <li>Check coolant level</li> <li>Check battery electrolyte level</li> <li>Check battery terminals for corrosion</li> <li>Check air filter</li> <li>Check water pump</li> <li>Check belt tension</li> <li>Check for leaks</li> <li>Check for loose parts</li> <li>Check for unusual noises</li> <li>Check for unusual vibrations</li> </ul>	<ul style="list-style-type: none"> <li>Change oil and filter</li> <li>Check coolant level</li> <li>Check battery electrolyte level</li> <li>Check battery terminals for corrosion</li> <li>Check air filter</li> <li>Check water pump</li> <li>Check belt tension</li> <li>Check for leaks</li> <li>Check for loose parts</li> <li>Check for unusual noises</li> <li>Check for unusual vibrations</li> </ul>	<ul style="list-style-type: none"> <li>Change oil and filter</li> <li>Check coolant level</li> <li>Check battery electrolyte level</li> <li>Check battery terminals for corrosion</li> <li>Check air filter</li> <li>Check water pump</li> <li>Check belt tension</li> <li>Check for leaks</li> <li>Check for loose parts</li> <li>Check for unusual noises</li> <li>Check for unusual vibrations</li> </ul>

NOTE: Refer to the appropriate section for correct procedure and torque specifications for the listed items.

1. The lubricating oil and fuel used in this engine can be recycled based on the fuel and oil consumption rate of the engine. See Section 1 for the correct method.

2. Follow the manufacturer's recommended maintenance procedures for the engine, alternator, generator, battery, and other components. Engine oil should be changed at 15,000 km (10,000 mi) or 5 months, whichever comes first.


3. At intervals of 15,000 km (10,000 mi), perform the periodic checks in addition to the ones specified.

oi201vu


## General Information

Correct care of your engine will result in longer life, better performance and more economical operation.

- Follow the daily maintenance checks listed in Maintenance Guidelines, Section 2.



- Check the oil pressure indicators, temperature indicators, warning lights and other gauges daily to make sure they are operational.



**Warning: DO NOT OPERATE A DIESEL ENGINE WHERE THERE ARE OR CAN BE COMBUSTIBLE VAPORS.** These vapors can be sucked through the air intake system and cause engine acceleration and over-speeding, which in turn can destroy the engine and result in a fire, personal injury and extensive property damage. Numerous safety devices are available, such as air intake shutoff devices, to minimize the risk of overspeeding where an engine, due to its application, might operate in a combustible environment, such as due to a fuel spill or gas leak. Remember, Cummins has no way of knowing the use you have for your engine. THE EQUIPMENT OWNER AND OPERATOR ARE RESPONSIBLE FOR SAFE OPERATION IN A HOSTILE ENVIRONMENT. CONSULT YOUR CUMMINS AUTHORIZED REPAIR LOCATION FOR FURTHER INFORMATION CONCERNING PROTECTION DEVICES SUITABLE FOR YOUR APPLICATION.



## Normal Starting Procedure (Above 0°C [32°F])





**Caution:** To prevent damage to the starter, do not engage the starting motor more than 30 seconds. Wait two (2) minutes between each attempt to start (electrical starting motors only).


- Disengage any driven accessories and put the transmission in neutral.
- Activate the ignition switch to open the fuel pump shutoff valve.
- Start the engine with the throttle in the idle position.
- Engines equipped with air starters require a minimum of 480 kPa [70 psi].

- The engine must have adequate oil pressure within 15 seconds after starting. If the warning light indicating low oil pressure has not gone out, or there is no oil pressure indicated on a gauge within 15 seconds, shut off the engine immediately to avoid engine damage. Confirm the correct oil level in the oil pan.


- Idle the engine three (3) to five (5) minutes before operating with a load.
- Increase the engine speed (RPM) slowly to provide adequate lubrication to the bearings, and to allow the oil pressure to stabilize.

Do **not** keep the engine at low idle for excessively long periods. Long periods at low idle more than 10 minutes, can damage an engine because combustion chamber temperatures drop so low the fuel will **not** burn completely. This will cause carbon to build up around the injector spray holes and piston rings, and can cause the valves to stick.






If the engine coolant temperature becomes too low, 60°C [140°F], raw fuel will wash the lubricating oil off the cylinder walls and dilute the crankcase oil. Fuel dilution adversely affects lubricating oil properties and can shorten engine life. Utilize the fast idle to prevent these conditions.




**Caution:** To avoid damage to CELECT™ engine parts, do not connect jumper starting or battery charging cables to any CELECT™ part. When using jumper cables to start the engine, make sure to connect the cables in parallel: positive (+) to positive (+) and negative (-) to negative (-). When using an external electrical source to start the engine, turn the disconnect switch to the "OFF" position. Remove the key before attaching the jumper cables.



The accompany illustration shows a typical parallel battery connection. This arrangement doubles the cranking amperage.



This illustration shows a typical series battery connection. This arrangement, positive to negative, doubles the voltage.




## Cold Weather Starting (Below 0°C [32°F])

### Using Starting Fluid With Mechanical or Electrical Metering Equipment

- Set the throttle at idle.
- Disengage any driven accessories and put the transmission in neutral.
- Activate the ignition switch to open the fuel pump shutoff valve.


**Caution:** Do not use excessive amounts of starting fluid when starting an engine. The use of too much starting fluid will cause engine damage.

- While cranking the engine, inject a metered amount of starting fluid.




**Warning:** Starting fluid is highly flammable and explosive. Keep flames, sparks and arcing switches away from starting fluid.


Due to increased safety hazards and potential for engine damage, do **NOT** use starting fluid without metering equipment.




- The engine **must** have adequate oil pressure within 15 seconds after starting. If the warning light indicating low oil pressure has not gone out, or there is no oil pressure indicated on a gauge within 15 seconds, shut off the engine immediately to avoid engine damage. Confirm the correct oil level in the oil pan.



- Do not increase the engine speed above low idle until the coolant temperature gauge needle starts to move or 10 minutes have elapsed. This will ensure adequate lubrication to the bearings.
- Monitor the oil pressure after normal operation is initiated.







## Operating the Engine

- If equipped, monitor the oil pressure and coolant temperature gauges frequently. Refer to Lubricating Oil System Specifications or Cooling System Specifications, in Section V, for recommended operating pressures and temperatures. Shut off the engine if any pressure or temperature does **not** meet the specifications.


**NOTE:** Continuous operation with a low coolant temperature, below 60°C [140°F], or a high coolant temperature, above 100°C [212°F], can damage the engine.



- If an overheating condition starts to occur, reduce the power output of the engine by releasing the throttle pedal pressure until the temperature returns to the normal operating range. If the engine temperature does **not** return to normal, shut off the engine and refer to Troubleshooting, Section T, or contact a Cummins Authorized Repair Location.



- Most failures give an early warning. Look and listen for changes in performance, sound or engine appearance that can indicate service or engine repair is needed. Some changes to look for are as follows:
  - Engine misfires
  - Vibration
  - Unusual engine noises
  - Sudden changes in engine operating temperature or pressure
  - Excessive smoke
  - Loss of power
  - An increase in oil consumption
  - An increase in fuel consumption
  - Fuel, oil or coolant leaks




- Allow the engine to idle three to five minutes before shutting it off after a full load operation. This allows adequate cool down of pistons, cylinder liners, bearings and turbocharger components.

## Engine Operating Range

**Caution:** Do not operate the engine at full throttle below peak torque RPM (refer to engine dataplate for peak torque RPM) for more than 30 seconds. This condition will shorten engine life to overhaul, can cause serious engine damage, and is considered driver abuse.


Cummins engines are designed to operate successfully at full throttle under transient conditions down to peak torque RPM. This is consistent with recommended driving practices.



**Caution:** Do not operate the engine beyond high idle speed. Operating the engine beyond high idle speed can cause severe engine damage. The engine speed must not exceed 2,300 RPM under any circumstances. When descending a steep grade, use a combination of transmission gears and engine or service brakes to control the vehicle and engine speed.



**Caution:** To prevent damage to the camshaft and the valve train when using an engine compression brake, do not exceed governed speed.



## Cold Weather Operation

It is possible to operate diesel engines in extremely cold environments if they are properly prepared and maintained. The correct lubricants, fuels and coolant **must** be used for the cold weather range for which the equipment is being operated. Refer to the chart below for recommendations in different operating ranges.

Winterize 0° to -23°C [32° to -10°F]	Winterize -23° to -32°C [-10° to -25°F]	Arctic Specifications -32° to -54°C [-25° to -65°F]
Use 50 percent ethylene glycol antifreeze, 50 percent water mixture.	Use 50 percent ethylene glycol antifreeze, 50 percent water mixture.	Use 60 percent ethylene glycol antifreeze, 40 percent water mixture.
Use multi viscosity oils meeting API, CE/CF-4 specifications.	Use multi viscosity oil meeting API, CE/CF-4 specifications.	Use Arctic oil meeting API, CE/CF-4 specifications.
Fuel to have maximum cloud and pour points 6°C [10°F] lower than ambient temperature in which engine operates.	Fuel to have maximum cloud and pour points 6°C [10°F] lower than ambient temperatures in which engine operates.	Fuel to have maximum cloud and pour points 6°C [10°F] lower than ambient temperature in which engine operates.

The following cold weather operating aids are required for cold weather situations:


Cold Weather Operating Aids									
Temperature	Starting Aid	Coolant Heater	Oil Heater	Under-hood Air	Fuel Heater	Battery Heater	Radiator Shutters	Engine Enclosure	Thermatic Fan
50 to 32° F 10 to 0° C									
32 to -10° F 0 to -23° C									
-10 to -25° F -23 to -32° C	Required	Required	Required	Required	Required	Required	Required	Required	Required
-25 to -65° F -32 to -54° C									

\* Required dependent upon viscosity/pour point.

oi204vg

### Winterfronts


Canvas or plastic "winter front" and engine compartment covers may be required when operating in cold temperatures. "Winter front" and engine compartment covers will protect the engine and engine compartment from cold air flow and eliminate shutter leakage. "Winterfronts" are designed so that the cover opening **must** be adjusted manually, depending on the ambient temperature and operation of the radiator shutters. Engine compartment covers **must not** restrict the air intake and exhaust systems during operation.



### Shutters


The flow of air across the radiator core into the engine compartment can be prevented by installing radiator shutters. Because air flow has a major effect on heat loss through radiation, reducing the air flow with shutters will reduce the time required for engine warm-up and help maintain engine operating temperature.

Shutters **must** operate in the same temperature range as the thermostat with which they are used.



### Engine Shut-down

- Allow the engine to idle three to five minutes before shutting it off after a full load operation. This allows adequate cool down of pistons, cylinders, bearings and turbocharger components.
- Turn the ignition key switch to the "OFF" position.





### Power Takeoff Application with Variable Speed Controls

The variable speed governor on power takeoff applications is used to control engine speed at the desired RPM.

To engage the variable speed governor with the engine idling on standard throttle:


- Put the variable speed control lever (1) in the idle position.
- Lock the standard throttle lever (2) in the full open position.
- Adjust the variable speed control lever (1) to the speed desired.





To return to standard throttle operation:


- Return the standard throttle lever (2) to the idle position.
- Lock the variable speed control lever (1) in the maximum speed position.



## Jacobs® Engine Brakes


**NOTE:** Do not exceed governed speed. Engine damage can occur. The engine brake is designed to assist the vehicle's service brake to slow down the vehicle.

An engine brake is a device which uses the energy of the engine compression to provide vehicle retardation. Engine brakes provide the maximum retarding power at governed speed.



The engine brake converts the engine to an energy absorbing device to reduce vehicle speed.

This is accomplished by a hydraulic circuit that opens the exhaust valves near the end of the compression stroke.




The amount of braking power available in a given engine series varies. Braking power depends on turbocharger boost pressure, engine RPM, compression ratio, injector timing and when the brake opens the exhaust valves.




The engine brake controls consist of the following:


- An OFF/LO/HI selector switch
- A clutch switch
- A fuel pump switch



The ON/OFF switch (1), clutch switch (2) and fuel pump switch (3) work together to activate or deactivate the brake.





The ON/OFF switch (1), clutch switch (2) and fuel pump switch (3) **must** all be in the closed position to activate the brake since they are connected in series. However, any one of the three switches can be used to deactivate the brake.




The selector switch allows the operator to choose the desired braking level.

Position "LO" activates three cylinders and position "HI" activates six cylinders.





Always start the engine with the engine brake ON/OFF switch in the "OFF" position.



**Caution:** Do not operate the engine if the engine brake will not deactivate. To do so will cause severe engine damage.

If the engine brake will **not** shut off, shut off the engine immediately and contact a Cummins Authorized Repair Location.



Refer to the manufacturer's maintenance recommendations. A listing of addresses and telephone numbers is provided in Component Manufacturers, Section C, of this manual.

**Section 2 - Maintenance Guidelines**  
**Section Contents**

	Page
General Information .....	2-2
Maintenance Record Form .....	2-5
Maintenance Schedule .....	2-3
Page References for Maintenance Instructions .....	2-4
Tool Requirements .....	2-2



## General Information

Cummins Engine Company, Inc. recommends that the engine be maintained according to the Maintenance Schedule on page 2-3.

If the engine is operating in ambient temperatures consistently below -18°C [0°F] or above 38°C [100°F], perform maintenance at shorter intervals. Shorter maintenance intervals are also required if the engine is operated in a dusty environment.. See your Cummins Authorized Repair Location for recommended intervals.

Some of these maintenance procedures require special tools, or **must** be done by qualified personnel. These procedures are outlined in the specific manuals as follows:

<u>Procedure</u>	<u>Bulletin No.</u>	<u>Description</u>
• Clean and Calibrate the Injectors	3810344	PT (Type D) Top Stop Injector Shop Manual
• Clean and Calibrate the Fuel Pump	3379084	Fuel Pump (PT Type G) Rebuild and Calibrate
• Repair and Rebuild Components*	3810476	Shop Manual

Use the chart provided on page 2-5 as a convenient way to keep a record of maintenance performed.

\*If your engine is equipped with a component or an accessory **not** manufactured by Cummins Engine Company, Inc., refer to the component manufacturer's maintenance recommendations. A listing of suppliers' addresses and telephone numbers is provided in Component Manufacturers, Section C.

## Tool Requirements

Most of the maintenance operations described in this manual can be performed with common hand tools (metric and S.A.E. wrenches, sockets, and screwdrivers).

The following is a list of special service tools required for some maintenance operations:

<b>Tool Part No.</b>	<b>Description</b>
3375044	Torque Wrench
3375049	Oil Filter Wrench
3376592	Torque Wrench (Valve and Injector Adjustment)
3376807	Engine Coolant and Fuel Filter Wrench
3823024	Injector Puller
3822524	Belt Tension Gauge, Click Type (v-belts and v-ribbed with 4 or 5 ribs)
3822525	Belt Tension Gauge, Click Type (v-ribbed with 6 to 12 ribs)
ST-537	Dial Depth Gauge
ST-669	Torque Wrench Adapter (Used with 3376592 Torque Wrench)
ST-1138	Belt Tension Gauge (v-belts)
ST-1225	Thermostat Seal Mandrel
ST-1272-11	Chip Removing Tool
ST-1293	Belt Tension Gauge (v-ribbed belts)

Contact your nearest Cummins Authorized Repair Location for the required service tools.

## Maintenance Schedule

L10 Engine Maintenance Schedule					
Daily	Weekly <sup>2</sup>	250 Hours or 6 months <sup>2</sup> <sup>3</sup>	1500 Hours or 1 Year <sup>2</sup>	6000 Hours or 2 Years <sup>2</sup>	6000 Hours or 3 Years <sup>2</sup>
<ul style="list-style-type: none"> <li>• Check operator's report.</li> <li>• Check and bring to correct level — Engine Oil — Coolant</li> <li>• Visually inspect fan.</li> <li>• Visually inspect engine for damage, leaks, loose or frayed belts and correct or record for future action.</li> <li>• Drain fuel-water separator.</li> </ul>	<b>Repeat Daily Check</b> <ul style="list-style-type: none"> <li>• Check air intake system for wear points or damage to piping, loose clamps, and leaks.</li> <li>• Check air cleaner restriction.</li> <li>• Check and clean air cleaner element.</li> <li>• Drain moisture from air tanks.</li> </ul>	<b>Repeat Daily and Weekly Check</b> <ul style="list-style-type: none"> <li>• Change Lubricating Oil</li> <li>• Change Lubricating Oil Filters</li> <li>• Change Fuel Filter</li> <li>• Change Coolant Filter</li> <li>• Replace element on Cummins 2 cylinder air compressor if equipped with an air cleaner.</li> <li>• Check engine coolant DCA4 concentration level. Add make-up DCA4, if required.</li> </ul>	<b>Repeat Previous Intervals</b> <ul style="list-style-type: none"> <li>• Adjust valves and injectors.</li> <li>• Steam clean engine.</li> <li>• Check torque on turbocharger mounting nuts.</li> <li>• Check torque on engine mounting bolts.</li> <li>• Replace hoses as required.</li> <li>• Check shutterstats and thermatic fans (if equipped).</li> <li>• Inspect water pump</li> </ul>	<b>Repeat Previous Intervals</b> <ul style="list-style-type: none"> <li>• Clean cooling system and change coolant and antifreeze</li> </ul>	<b>Repeat Previous Intervals Which Are Due</b> <ul style="list-style-type: none"> <li>• Clean and calibrate injectors, fuel pump.</li> </ul> <hr/> <b>Inspection</b> <hr/> <ul style="list-style-type: none"> <li>• Turbocharger</li> <li>• Air Compressor</li> <li>• Fan Clutch</li> <li>• Water pump</li> <li>• Fan hub</li> <li>• Fan idler pulley assembly</li> <li>• Vibration Damper</li> </ul>
<b>NOTE:</b> Refer to the appropriate sections for complete inspection and maintenance procedures.					
<sup>1</sup> Follow the manufacturer's recommended maintenance procedures for the starter, alternator, generator, batteries, electrical components, engine brake, exhaust brake, air compressor, freon compressor, and fan clutch. Refer to Section C for addresses and telephone numbers.					
<sup>2</sup> At each scheduled maintenance interval, perform all previous maintenance checks which are due for scheduled maintenance.					
<sup>3</sup> For standby generator applications, the recommended oil change interval is 250 hours or 12 months, whichever comes first.					

## Page References for Maintenance Instructions

For your convenience, listed below are the page numbers which contain specific instructions for performing the maintenance checks listed in the maintenance schedule.

### Daily

- Belts - inspect ..... 3-4
- Engine oil level - check ..... 3-3
- Engine coolant level - check ..... 3-3
- Fan - inspect ..... 3-4
- Fuel-water separator - drain ..... 3-3

### Weekly

- Air intake system - check ..... 4-6
- Air cleaner restriction - check ..... 4-2
- Air Cleaner Element - check and clean ..... 4-3
- Air Tanks - drain ..... 4-8

### Every 250 Hours or 6 Months

- Lubricating oil - change ..... 5-4
- Lubricating oil filters - change ..... 5-4
- Fuel filter - replace ..... 5-3
- Coolant Additive Concentration (DCA4) - check ..... 5-8
- Coolant filter - replace ..... 5-7
- Air compressor air cleaner element (Cummins two-cylinder only) - replace ..... 5-9

### Every 1,500 Hours or 1 Year

- Valves and injectors - adjust ..... 6-3
- Engine - steam clean ..... 6-12
- Turbocharger mounting nuts - check torque ..... 6-11
- Engine mounting bolts - check torque ..... 6-12
- Hoses - check and replace as required ..... 6-10
- Shutters and thermatic fan (if equipped) - check ..... 6-11
- Water pump - inspect ..... 6-10

### Every 6,000 Hours or 2 Years

- Cooling system - clean ..... 7-3
- Coolant and antifreeze - change ..... 7-3

### Every 6,000 Hours or 3 Years

- Injectors - clean and calibrate ..... 8-3
- Fuel pump - clean and calibrate ..... 8-13
- Turbocharger - inspect ..... 8-16
- Air compressor - inspect ..... 8-18
- Fan hub - inspect ..... 8-16
- Idler pulley assembly - inspect ..... 8-16
- External vibration damper - inspect ..... 8-3

Maintenance Record	
Engine Serial No. _____	Engine Model _____
Owner's Name _____	Equipment Name/Number _____

[illegible]

Maintenance Record	
Engine Serial No. _____	Engine Model _____
Owner's Name _____	Equipment Name/Number _____

[illegible]



## Section 3 - Daily Maintenance Procedures

### Section Contents

	Page
<b>Belt Tension</b> .....	3-5
Checking .....	3-5
<b>Belts</b> .....	3-4
Inspection .....	3-4
<b>Coolant Level</b> .....	3-3
Checking .....	3-3
<b>Cooling Fan</b> .....	3-4
Inspection .....	3-4
<b>Engine Operation Report</b> .....	3-2
<b>Fuel-Water Separator</b> .....	3-3
Draining .....	3-3
<b>General Information</b> .....	3-2
<b>Oil Level</b> .....	3-3
Checking .....	3-3

## General Information

Preventative maintenance begins with day-to-day awareness of the condition of the engine and its systems. Before starting the engine, check the oil and coolant levels. Look for:

- Leaks
- Loose or damaged parts
- Worn or damaged belts
- Any change in engine appearance

## Engine Operation Report

The engine **must** be maintained in top mechanical condition if the operator is to get optimum satisfaction from its use. The maintenance department needs daily running reports from the operator to make necessary adjustments in the time allotted and to make provisions for more extensive maintenance work as the reports indicate the necessity.

Comparison and intelligent interpretation of the daily report along with a practical follow-up action will eliminate most failures and emergency repairs.

Report to the Maintenance Department any of the following conditions:

- Low lubricating oil pressure
- Low power
- Abnormal water or oil temperature
- Unusual engine noise
- Excessive smoke
- Excessive use of coolant, fuel or lubricating oil
- Any fuel, coolant or lubricating oil leaks.

## Fuel-Water Separator


### Draining

If the engine is equipped with a fuel-water separator, drain the water and sediment from the separator daily.

Shut off the engine. Use your hand to open the drain valve. Turn the valve **counterclockwise** approximately 1 1/2 to 2 turns until draining occurs. Drain the filter sump of water until clear fuel is visible.

When closing the drain valve, do **not** overtighten the valve. Overtightening can damage the threads.

Turn the valve **clockwise** to close the drain valve.




## Oil Level

### Checking

The engine **must** be level when checking the oil level to make sure the measurement is correct.

Check the oil level daily.

**Never** operate the engine with the oil level below the "L" (Low) mark, or above the "H" (High) mark. Wait at least five minutes after shutting off the engine to check the oil level. This allows time for the oil to drain to the oil pan.




## Coolant Level

### Checking

**Warning:** Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50° C [120° F] before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray or steam. Remove the filler cap slowly to relieve coolant system pressure.

**Never** use a sealing additive to stop leaks in the coolant system. This can result in coolant system plugging and inadequate coolant flow causing the engine to overheat.


The coolant level **must** be checked daily.




**Caution:** Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50° C [120° F] before adding coolant.

Makeup coolant added to the engine **must** be mixed with the correct proportions of antifreeze, DCA and water.

Refer to Coolant Recommendations and Specifications in Section V.






Antifreeze overconcentration reduces freeze protection. Do **not** use more than 68 percent antifreeze or overheating can result. A mixture of low silicate antifreeze and 50 percent water is sufficient for freeze protection to  $-37^{\circ}\text{C}$  [ $-34^{\circ}\text{F}$ ].


Use ethylene glycol antifreeze year-round to provide freeze point and boil-over protection.

The Fleetguard® refractometer, Part No. CC2800, provides a reliable and easy to read measurement of freeze point protection and glycol (antifreeze) concentration.



Fill the cooling system with coolant to the bottom of the fill neck in the radiator fill or expansion tank.

**NOTE:** Some radiators have two fill necks, both of which **must** be filled when the cooling system is drained.




## Cooling Fan

### Inspection

**Warning:** Personal injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blades(s) and cause fan failure.

Rotate the crankshaft by using the accessory drive shaft.

A visual inspection of the cooling fan is required daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the capscrews if necessary. Replace any fan that is damaged.



## Belts

### Inspection

Visually inspect the belts daily. Replace belts that are cracked or frayed. Adjust belts that have a glazed or shiny surface which indicates belt slippage. Correctly installed and tensioned belts will show even pulley and belt wear.

Belt damage can be caused by:

- Incorrect tension
- Incorrect size or length
- Pulley misalignment
- Incorrect installation
- Severe operating environment
- Oil or grease on the belts


## Belt Tension

### Checking

Measure the belt tension in the center span of the pulleys.

Refer to Belt Tension Chart, Section V, for the correct gauge and tension value for the belt width used.

An alternate method (deflection) can be used to check belt tension by applying 110 N [25 lbf] between the pulleys on v-belts. If the deflection is more than one (1) belt thickness per foot of pulley center distance, the belt tension **must** be adjusted.



## NOTES

[illegible]

## Section 4 - Weekly Maintenance Procedures


### Section Contents

	Page
<b>Air Cleaner Element</b> .....	4-3
Cartridge Type Element - Cleaning .....	4-5
Cleaning .....	4-3
Dual - Heavy Duty Dry-Type Element - Replacement .....	4-4
Replacement .....	4-3
Single - Heavy Duty Dry-Type Element .....	4-3
<b>Air Cleaner Restriction</b> .....	4-2
Checking .....	4-2
Vacuum Indicator .....	4-2
<b>Air Intake System</b> .....	4-6
Inspection .....	4-6
<b>Air Tanks</b> .....	4-8
Draining.....	4-8
<b>General Information</b> .....	4-2



## General Information

All checks or inspections listed under the daily maintenance interval **must** also be performed at this time in addition to those listed under this maintenance interval.



### Air Cleaner Restriction

#### Checking


Every 250 hours or 6 months, check the air cleaner restriction. Maximum intake air restriction is 63.5 cm H<sub>2</sub>O [25 in H<sub>2</sub>O].

**Never** operate the engine without an air cleaner. Intake air **must** be filtered to prevent dirt and debris from entering the engine and causing premature wear.

Follow the filter manufacturer's instructions when cleaning or replacing the air cleaner element.

Check the air cleaner service indicator, if equipped. Change the filter element when the red indicator flag (2) is at the raised position in the window (1).

After the air cleaner has been serviced, reset the button (3) in the end of the service indicator.



#### Vacuum Indicator

Vacuum switches actuate a warning light on the instrument panel when the air restriction becomes excessive.

Air restriction on turbocharged engines **must not** exceed 64 cm [25 inches H<sub>2</sub>O] under full power conditions.




## Air Cleaner Element

**NOTE:** The illustrations in this section show typical parts. The particular engine parts can vary.


### Cleaning

The paper element (6) in a dry-type air cleaner can be cleaned several times by using compressed air to remove the dirt, approximately 207 kPa [30 psi]. Do **not** hold the air jet too close to the paper element when cleaning.



Elements that have been cleaned several times will finally clog and air flow to the engine will be restricted. After cleaning, check the restriction as previously described. Replace the element if necessary.

**Caution:** Holes, loose end seals, dented sealing surfaces and other forms of damage render the cleaner inoperative and require immediate element replacement.




### Replacement

Remove the wing nut (1) that secures the bottom cover (2) to the cleaner housing (3). Remove the cover.

Pull the element (6) down from the center bolt (4).

**Caution:** Pull the cover and the element straight out when removing them from the housing to avoid damage to the element.

Remove the gasket (5) from the outlet end (7) of the housing.





### Single - Heavy Duty Dry-Type Element

Heavy duty air cleaners (single and dual types) combine centrifugal cleaning with element filtering before air enters the engines.

Before disassembly, wipe dirt from the cover and the upper portion of the air cleaner. To clean the single types:

Loosen the wing bolt, and remove the band securing the dust pan (1).





Loosen the wing nut (2). Remove the dust shield (3) from the dust pan (1). Clean the dust pan and shield.



Remove the wing nut (5) and secure the air cleaner primary element in the air cleaner housing. Inspect the rubber sealing washer on the wing nut (4).




Clean the element from the clean air side with compressed air **not** exceeding 207 kPa [30 psi]. Inspect the element after cleaning. Install the cleaned primary element or a new element.

Make sure the gasket washer is in place under the wing nut before tightening.



Assemble the dust shield and dust pan again. Position them to the air cleaner housing and secure with the band.




### Dual - Heavy Duty Dry-Type Element - Replacement

Heavy duty air cleaners (single and dual types) combine centrifugal cleaning with element filtering before air enters the engines.



Before disassembly, wipe dirt from the cover and the upper portion of the air cleaner. To clean the dual types:

Loosen the wing bolt (1), and remove the band securing the dust pan (2).



Loosen the wing nut (3). Remove the dust shield (4) from the dust pan (2). Clean the dust pan and shield.



Remove the wing nut (5) and secure the air cleaner primary element (6) in the air cleaner housing. Inspect the rubber sealing washer on the wing nut (9).



Clean the element from the clean air side with compressed air **not** exceeding 207 kPa [30 psi]. Inspect the element after cleaning. Install the cleaned primary element or a new element.

Make sure the gasket washer is in place under the wing nut before tightening.

Assemble the dust shield and dust pan again. Position them to the air cleaner housing and secure with the band.

On the dual element type Cyclopac cleaner:

Check the air restriction indicator. If the air restriction is excessive, disassemble the air cleaner, remove the wing nut (7) and replace the safety element (8).

Assemble the air cleaner as described above.

### Cartridge Type Element - Cleaning

Loosen the wing nuts (4) on the air cleaner housing (5) to remove the pre-cleaner panel with the dust bin (6). To remove the pre-cleaner panel (2) equipped with an exhaust aspirator, loosen the U bolt clamp securing the pre-cleaner to the aspirator tubing.

Remove the dirty Pamic cartridge (3), by inserting your fingers in the cartridge opening (loosen all four corners of the cartridge, one at a time) and pulling it straight out.

With the larger cartridge, it can be necessary to break the seal along the edges of the cartridge. After the seal has been broken, pull the cartridge straight out and slightly up so the cartridge will clear the sealing frame and edges of the air cleaner housing.

### Cleaning and Inspection





Clean the pre-cleaner openings (2) of all soot, oil film and any other objects that can become lodged in the openings. Remove any dust or dirt in the lower portion of the pre-cleaner and aspirator tubing. Inspect the inside of the air cleaner housing for foreign material.


Inspect the dirty cartridge for soot or oil. If there is soot inside the Pamic tubes, check for leaks in the engine exhaust system, exhaust blow-back into the air intake and exhaust from other equipment. If the cartridge appears oily, check for fumes escaping from the crankcase breather. Excessive oil mist shortens the life of any dry-type cartridge. Troubleshooting at this point can appreciably lengthen new cartridge life.

It is **not** recommended to clean and reuse the cartridge. When returned to service, life expectancy of a cleaned cartridge will be only a fraction of the original service life.

Inspect clamps and flexible hose or tubing to make sure all fittings are air tight on cleaners with exhaust aspirators.

The pre-cleaner dust (6) bin is self-cleaning.






### Assembly



Inspect the new filter cartridge for shipping damage before installing.

To install a new cartridge, hold the cartridge (3) in the same manner as when removing it from the housing. Insert the clean cartridge into the housing, avoiding hitting the cartridge tubes against the sealing flange on the edges of the air cleaner housing.




As the cleaner requires no separate gaskets for seals, care **must** be taken when inserting the cartridge to insure a proper seat within the cleaner housing. Firmly press all edges and corners of the cartridge with your fingers to effect a positive air seal against the sealing flange of the housing. The cartridge **must not** be pounded or pressed in the center to seal.

Replace the pre-cleaner panel (2) and tighten the wing nuts (4) by hand. For final tightness turn the wing nuts 1 to 1 1/2 turns with a small adjustable wrench. Do **not** tighten too much. On a pre-cleaner with an exhaust aspirator, assemble the aspirator tube to the pre-cleaner panel and tighten the U bolt.

Care **must** be taken to keep the cleaner face unobstructed.

Reset the mechanical inlet air restriction indicator.



## Air Intake System

### Inspection



Once a week inspect the intake piping for cracked hoses, loose clamps or punctures which can damage the engine.



Replace damaged pipes and tighten loose clamps as necessary to make sure the air intake system does not leak.


**Torque Value:** 8 N•m [72 in-lb]



Check for corrosion of the intake system piping under the clamps and hoses. Corrosion can allow corrosive products and dirt to enter the intake system. Disassemble and clean as required.


Operate the engine at high idle and use a solution of soapy water to spot intake air leaks.

If an air leak exists, the soap bubbles will be drawn in with the air.



Operate the engine at high idle.

Listen for a high pitched whistling noise from the turbocharger, nearby piping and connections.




The noise can be caused by an air leak from the:

- Turbocharger to discharge elbow connection.


Inspect for damage. Tighten loose clamps.


**Torque Value:** 8 N•m [72 in-lb]



- Turbocharger to exhaust manifold mounting connection.

Replace the gasket. Refer to Section A for turbocharger removal and installation.






- Turbine housing sealing surface exhaust leak.

Tighten the turbine housing capscrews or v-band clamp nut.



**Torque Value:**

Capscrews	13.6 N•m	[120 in-lb]
V-Band	15.8 N•m	[140 in-lb]




- Compressor housing sealing surface air leak.

Tighten the compressor housing capscrews or v-band clamp nut.



**Torque Value:**

Capscrews	7 N•m	[60 in-lb]
V-Band	8.5 N•m	[75 in-lb]



## Air Tanks

### Draining

Drain the moisture from the air system wet tank weekly.

# Section 5 - Maintenance Procedures at 250 Hours or 6 Months

## Section Contents

	Page
Air Compressor Air Cleaner Element (Cummins Two Cylinder Only).....	5-9
Replacement .....	5-9
Coolant Additive Concentration .....	5-8
Checking .....	5-8
Coolant Filter .....	5-7
Replacement .....	5-7
Fuel Filter(s) .....	5-3
Replacement .....	5-3
General Information .....	5-2
Lubricating Oil and Filter .....	5-4
Changing .....	5-4



## General Information

All checks or inspections listed under daily or previous maintenance intervals **must** also be performed at this time in addition to those listed under this maintenance interval.




## Fuel Filter(s)

### Replacement

The fuel filter(s) **must** be replaced every 250 hours or 6 months.


Clean the area around the fuel filter head and filter.

Remove the fuel filter with filter wrench, Part No. 3376807.



Remove the thread adapter sealing ring (1).

Use a clean lint-free towel to clean the filter head gasket surface.




Use the correct filter(s) for your engine. Cummins Engine Company, Inc. recommends that a fuel-water separator or fuel filter and water separator be installed in the fuel supply system. Either arrangement **must** remove a minimum of 94 percent of free water (per SAE J1839) and 88 percent of emulsified water (per SAE J1488).

### Superfilter (Fuel-Water Separator)

Cummins Part No. 3315843  
Fleetguard® Part No. FS-1212


Install the new thread adaptor sealing ring supplied with the new filter. Use clean oil to lubricate the filter seal, and fill the new filter(s) with clean fuel.




Install the filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.

Tighten the filter an additional one-half to three-fourths of a turn, or as specified by the filter manufacturer.

**NOTE:** Mechanical overtightening can distort the threads or damage the filter element seal.





## Lubricating Oil and Filter Changing





**Warning:** Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.

Change the lubricating oil and filter at the specified oil change interval.


Operate the engine until the water temperature reaches 60° C [140° F]. Shut off the engine. Remove the oil drain plug. Drain the oil immediately to make sure all the oil and suspended contaminants are removed from the engine.

On standby generator applications, Cummins Engine Co. recommends oil sampling and analysis at the time of oil change to monitor oil contaminant levels.



Clean the area around the lubricating oil filter head.  
Remove the filter.

Clean the sealing surface of the filter head. The o-ring can stick on the filter head. Make sure it is removed.



Use the correct oil filter for your engine.

### Combination Lube Filter:


Cummins Part No. 3318853  
Fleetguard® Part No. LF-3000

Cummins Engine Company requires a lubricating oil filter(s) be used that meets the specifications given in the table below.

Lubricating Oil Filter Specifications			
Per Cummins Source Approval Method (SAM)	Combo (LF3000) 10,634	Full Flow (LF670) 10,509	Bypass LF777) 10,547
Flow vs. Restriction	21 kPa [3 psi]	21 kPa [3psi]	N/A
• Pressure Differential at 40 GPM maximum			
Element Collapse	1034 kPa [150 psi]	1034 kPa [150 psi]	1034 kPa [150 psi]
• Pressure differential			
Partical Retention	N/A	100%	N/A
• Absolute retention, percent of 40 micrometre and above, minimum			
• Percent retention of 20 to 30 micrometre	N/A	95%	N/A
Hydrostatic Pressure	1724 kPa [250 psi]	1724 kPa [250 psi]	1724 kPa [250 psi]
• Pressure, minimum			

Fill the oil filter with clean lubricating oil. The lack of lubrication during the delay until the filter is pumped full of oil is harmful to the engine.


Apply a light film of lubricating oil to the gasket sealing surface before installing the new filter.



Install the filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.

Tighten the filter and additional one-half to three-fourths of a turn, or as specified by the filter manufacturer.


**NOTE:** Mechanical overtightening can distort the threads or damage the filter element seal.



Clean and check the oil drain plug threads and the sealing surface.


Install and tighten the oil drain plug.

**Torque Value:** 88 N•m [65 ft-lb]






Use a high quality 15W-40 multi-viscosity oil such as Cummins Premium Blue, or its equivalent, in Cummins engines. Choose the correct oil for your operating climate as outlined in Section V.




Fill the engine with clean oil to the correct level. Total system capacity including filter is approximately 38 liters [10 U.S. gal].

**NOTE:** The oil pan capacity is 34 liters [9 U.S. gal]. The filter capacity is 2.6 liters [0.7 U.S. gal].



Operate the engine at idle speed to inspect for leaks at the filters and the drain plug.

**NOTE:** Engine oil pressure **must** be indicated on the gauge within 15 seconds after starting. If oil pressure is **not** registered within 15 seconds, shut off the engine immediately to avoid engine damage. Confirm the correct oil level in the oil pan.



Shut off the engine. Wait approximately five minutes to let the oil drain from the upper parts of the engine. Check the oil level again.

Add oil as necessary to bring the oil level to the "H" (High) mark on the dipstick.

## Coolant Filter

### Replacement



Change the coolant filter at every oil and filter change interval unless the SCA concentration level is over 3 units. Refer to Coolant Additive Concentration - Checking in this section.

**NOTE:** The supplemental coolant additive (SCA) level **must** be tested every six months.


The correct coolant filter to be used is determined by the total cooling system capacity and other operational factors. Refer to the Coolant System Specifications in Section V for the correct filter selection.

**Warning:** Do not remove the radiator cap from a hot engine. Hot steam will cause serious personal injury. Remove the coolant system pressure cap and close the shutoff valve, if equipped, before removing the coolant filter. Failure to do so can result in personal injury from heated coolant spray.


Turn the coolant shutoff valve to the "OFF" position.




Remove and discard the coolant filter. Clean the gasket surface.



Apply a light film of lubricating oil to the gasket sealing surface before installing the new coolant filter.






**Caution:** Mechanical overtightening can distort the threads or damage the filter head.




Install the filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.



Tighten the filter an additional one-half to three-fourths of a turn, or as specified by the filter manufacturer.




Open the shutoff valve and install the coolant system pressure cap.



Operate the engine, and check for coolant leaks.

After the air has been purged from the system, check the coolant level again.



## Coolant Additive Concentration Checking

Check the SCA concentration level:

- At least twice a year.
- At every subsequent oil drain interval if the concentration is above 3 units.
- Whenever coolant is added to the cooling system between filter changes.

Use Fleetguard® coolant test kit, Part No. CC2626, to check the concentration level. Instructions are included with the test kit.


## Air Compressor Air Cleaner Element (Cummins Two Cylinder Only)

### Replacement

Every 250 hours or 6 months, remove the wing nut which secures the cover to the housing. Remove the cover and the element. Clean the cover and the housing with a clean cloth. Inspect the rubber gasket on the center bolt. Replace if damaged.

Install a new element, Fleetguard® Part No. AF-251 or Cummins Part No. 256837, in the front cover and assemble over the center bolt. Use your fingers to install and tighten the wing nut.

**NOTE:** If other compressors are used, follow the manufacturer's service requirements.



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



## Section 6 - Maintenance Procedures at 1500 Hours or 1 Year

### Section Contents

	Page
Engine Mounting Bolts .....	6-12
General Information .....	6-2
Hoses .....	6-10
Checking and Replacement .....	6-10
Shutters and Thermatic Fan .....	6-11
Checking .....	6-11
Steam or Chemically Cleaning Engine .....	6-12
Thermal Control Settings Graph .....	6-11
Turbocharger .....	6-11
Checking .....	6-11
Valves and Injectors - Adjustment .....	6-3
Jacobs Engine Brake - Adjustment .....	6-9
Water Pump .....	6-10
Inspection .....	6-10



## General Information

All checks or inspections listed under daily or previous maintenance intervals **must** also be performed at this time in addition to those listed under this maintenance interval.

## Valves and Injectors - Adjustment

Valves and injectors **must** be correctly adjusted for the engine to operate efficiently. Valve and injector adjustment **must** be performed using the values listed in this section. The accompanying table gives the adjustment limits for fixed time engines.


Adjust the valves and the injectors at each 1,500 hours or 1 year maintenance interval. If the valves and injectors have been adjusted during troubleshooting or before the 1500 hours or 1 year scheduled maintenance interval, adjustment is not required at this time.

### Valve and Injector Adjustment Limits

**"Top Stop" Injector Preload:**  
0.6 to 0.7 N•m [5 to 6 in-lb]

	mm	in
Intake Valve	0.35	0.014
Exhaust Valve	0.68	0.027
Engine Brakes	0.38	0.015


All overhead, valve and injector adjustments **must** be made when the engine is cold, and stabilized coolant temperature is 60° C [140 ° F] or below.



Remove the crankcase breather tube from the crankcase breather outlet.

Remove the 16 capscrews, isolators and spacers from the cover.


Remove the rocker lever cover and gasket.




Each cylinder has three rocker levers:

- The long rocker lever (E) is the exhaust lever.
- The center rocker lever is the injector lever.
- The short rocker lever (I) is the intake lever.

Refer to the accompanying chart for valve rocker lever locations.





The crankshaft rotation is **clockwise** when viewed from the front of the engine.

The cylinders are numbered from the front gear cover end of the engine.

The engine firing order is 1-5-3-6-2-4.

Injector and Valve Adjustment Sequence			
Bar Engine In Direction of Rotation	Pulley Position	Set Cylinder Injector	Valve
Start	A	3	5
Advance to	B	6	3
Advance to	C	2	6
Advance to	A	4	2
Advance to	B	1	4
Advance to	C	5	1


Firing Order: 1-5-3-6-2-4

ci100vd

The valves and injectors on the same cylinders are **not** adjusted at the same index mark on the accessory drive pulley on fixed time engines.

One pair of valves and one injector are adjusted at each pulley index mark before rotating the accessory drive to the next index mark.


Two crankshaft revolutions are required to adjust all the valves and injectors.



**Warning:** Do not pull or pry on the fan to manually rotate the crankshaft. To do so can damage the fan blades. Damaged fan blades can cause premature fan failures which can result in serious personal injury or property damage.

The valve set marks are located on the accessory drive pulley. The marks align with a pointer on the gear cover.

Use the accessory drive shaft to rotate the crankshaft.




The adjustment can begin on any valve set mark. In the following example the adjustment will begin on the 'A' valve set mark with cylinder number five valves closed and cylinder number three injector ready for adjustment.

Rotate the accessory drive shaft **clockwise** until the 'A' valve set mark on the accessory drive pulley is aligned with the pointer on the gear cover.

When the 'A' mark is aligned with the pointer, the intake and exhaust valves for cylinder number five **must** be closed. If these conditions are **not** correct, cylinder number four injector and cylinder number two valves **must** be ready to set.


Both valves are closed when both rocker levers are loose and can be moved from side to side.




Loosen the injector adjusting screw locknut on cylinder number three. Tighten the adjusting screw until all the clearance is removed from the injector train.



Tighten the adjusting screw one additional turn to correctly seat the link.



Loosen the injector adjusting screw until the injector spring retainer washer touches the top stop screw.





**Caution:** An overtightened setting on the injector adjusting screw will produce increased stress on the injector train and the camshaft injector lobe which can result in engine damage.



Use torque wrench, Part No. 3376592, to tighten the adjusting screw.

**Torque Value:** 0.6 to 0.7 N•m [5 to 6 in-lb]





Hold the adjusting screw in this position. The adjusting screw **must not** turn when the locknut is tightened.

**Torque Value:**

- **Without** Torque Wrench Adapter:  
61 N•m [45 ft-lb]
- **With** Torque Wrench Adapter (1), Part No. ST-669  
47 N•m [35 ft-lb]


Injector and Valve Adjustment Sequence			
Bar Engine in Direction of Rotation	Pulley Position	Set Cylinder Injector Valve	
Start	A	3	5
Advance to	B	6	3
Advance to	C	2	6
Advance to	A	4	2
Advance to	B	1	4
Advance to	C	5	1

Firing Order: 1-5-3-6-2-4

oil00vd




Adjust the valves on the appropriate cylinder according to the sequence chart before rotating the accessory drive to the next valve set mark.



Select a feeler gauge for the correct valve lash specification.

Valve Lash Specifications	
Intake	Exhaust
0.36 mm [0.014 in.]	0.69 mm [0.027 in.]

Insert the feeler gauge between the top of the crosshead and the rocker lever pad.



Two different methods for establishing valve lash clearance are described below. Either method can be used; however, the torque wrench method has proven to be the most consistent. It eliminates the need to feel the drag on the feeler gauge.

- **Torque Wrench Method** : Use the inch pound torque wrench, Part No. 3376592, (normally used to set preload on top stop injectors) and tighten the adjusting screw.

**Torque Value:** 0.7 N•m [6 in-lb]


- **Touch Method** : Tighten the adjusting screw until a light drag is felt on the feeler gauge.

Hold the adjusting screw in this position. The adjusting screw **must not** turn when the locknut is tightened. Tighten the locknut.




**Torque Value:**


- **Without** Torque Wrench Adapter:  
61 N•m [45 ft-lb]
- **With** Torque Wrench Adapter (1), Part No. St-669  
47 N•m [35 ft-lb]



After tightening the locknut to the correct torque value, check to make sure the feeler gauge will slide backward and forward between the crosshead and the rocker lever with only a slight drag.




If using the touch method, attempt to insert a feeler gauge that is 0.03 mm [0.001 in] thicker between the crosshead and the rocker lever pad. The valve lash is **not** correct when a thicker feeler gauge will fit.



Adjust the Jacobs Engine Brake, if applicable, after adjusting the valves before rotating the accessory drive pulley to the next index mark. Refer to Jacobs Engine Brake - Adjustment following this procedure.

After adjusting the valves, rotate the accessory drive and align the next valve set mark on the accessory drive pulley with the pointer on the gear cover.



Injector and Valve Adjustment Sequence			
Bar Engine in Direction of Rotation	Pulley Position	Set Cylinder Injector Valve	
Start	A	3	5
Advance to	B	6	3
Advance to	C	2	6
Advance to	A	4	2
Advance to	B	1	4
Advance to	C	5	1

Firing Order: 1-5-3-6-2-4


oi100vd



Adjust the appropriate injector and valves following the Injector and Valve Adjustment Sequence Chart.


Repeat the process to adjust all injectors and valves.

After adjusting all the valves and injectors, check the torque on the adjusting screw locknuts to make sure none were overlooked.




If the valve cover gasket was **not** damaged, it can be used again. If the gasket was damaged, it **must** be discarded and a new one used.

Install the gasket on the cover.



Install the cover on the rocker lever housing.

Install the 16 isolators, spacers and capscrews in the cover.




Tighten the capscrews in the sequence shown.

**Torque Value:** 15 N•m [130 in-lb]




Install the hose on the crankcase breather.



### Jacobs Engine Brake - Adjustment

**Caution:** To ensure maximum brake operating efficiency and prevent engine damage by piston-to-valve contact, complete the following instructions carefully.

After adjusting the exhaust valves on the appropriate cylinder, insert a feeler gauge 0.38 mm [0.015 in] between the slave piston and the actuating pin in the crosshead.




Turn the slave piston adjusting screw down until it touches the feeler gauge.

Hold the screw in position and tighten the locknut.





#### Torque Value:

- **Without** Torque Wrench Adapter:  
34 N•m [25 ft-lb]
- **With** Torque Wrench Adapter, Part No. ST-669  
30 N•m [22 ft-lb]



After the slave piston adjusting screw locknut is tightened to the correct torque value, check the clearance with the feeler gauge again. Do **not** tighten the adjusting screws too tight. The engine can be damaged.






Continue to rotate the crankshaft in firing order rotation and adjust all six slave pistons using this procedure.



Install the rocker lever cover. Refer to the valve adjustment procedure.



## Water Pump


### Inspection

Every 1500 hours or 1 year, whichever comes first, visually inspect the water pump body for indications of water leakage at the weep hole.


A streak or chemical buildup at the weep hole is **not** justification for water pump replacement. If a steady flow of coolant or oil is observed, replace the water pump with a new or rebuilt unit.



Refer to Section A for the replacement procedure.



Make sure the weep hole is open. A small screwdriver or a similar tool can be used to remove any debris.



## Hoses

### Checking and Replacement


Annually inspect the cooling system hoses and hose connections for leaks or deterioration. Particles of deteriorated hose can be carried through the cooling system and slow, or partially stop circulation.

## Shutters and Thermatic Fan


### Checking

Check the shutters and the thermatic fan annually.

Shutters and thermatic fans **must** operate in the same temperature range as the thermostat with which they are used. Refer to the Thermal Control Settings Graph.



## Thermal Control Settings Graph




## Turbocharger


### Checking

Check the turbocharger mounting nuts annually.

Tighten the mounting nuts.

**Torque Value:** 61 N•m [45 ft-lb]






Check the turbine housing sealing surface for exhaust leaks.



If a leak is found, tighten the turbine housing capscrews or v-band clamp nut.

**Torque Value:**

- Capscrews 14 N•m [120 in-lb]
- V-Band 16 N•m [140 in-lb]




Check the compressor housing sealing surface for leaks.



If a leak is found, tighten the compressor housing capscrews or v-band clamp nut.

**Torque Value:**

- Capscrews 7 N•m [60 in-lb]
- V-Band 9 N•m [75 in-lb]



## Steam or Chemically Cleaning Engine




**Warning:** To avoid serious personal injury when using a steam cleaner, wear protective clothing and safety glasses or a face shield.



The engine **must** be steam cleaned annually. Steam is the best method of cleaning a dirty engine or a piece of equipment. If steam is not available, use a solvent to wash the engine.

Protect all electrical components, openings and wiring from the full force of the cleaner spray nozzle.



## Engine Mounting Bolts



Check the torque on the nuts and bolts annually. Tighten any that are loose. Refer to the equipment manufacturer for torque specifications. Inspect the rubber for deterioration and age hardening. Replace any broken or lost bolts, capscrews or damaged rubber.

## Section 7 - Maintenance Procedures at 6000 Hours or 2 Years

### Section Contents

	Page
Cooling System .....	7-3
Antifreeze Concentration - Checking .....	7-5
Cleaning and Changing Antifreeze .....	7-3
General Information .....	7-2



## General Information

All checks or inspections listed under daily or previous maintenance intervals **must** also be performed at this time in addition to those listed under this maintenance interval.


## Cooling System

### Cleaning and Changing Antifreeze


Every two (2) years, or 6,000 hours of operation, change the coolant and antifreeze.

The cooling system **must** be clean to work correctly.

Do **not** use caustic cleaners in the cooling system. Aluminum components will be damaged.




**Warning:** Wait until the temperature is below 50° C [120° F] before removing the coolant system pressure cap. Failure to do so can cause personal injury from heated coolant spray.




RESTORE is a heavy duty cooling system cleaner which removes corrosion products, silicate gelaton and other deposits.


The performance of RESTORE is dependent on time, temperature and concentration levels. An extremely scaled or flow restricted system, for example, can require higher concentrations of cleaners, higher temperatures or longer cleaning times. Up to twice the recommended concentration levels of RESTORE can be used safely. RESTORE PLUS **must** be used only at its recommended concentration level. Extremely scaled or fouled systems will probably require more than one cleaning.



Drain the cooling system. Do **not** allow the cooling system to dry out.

Do **not** remove the coolant filters.






**Caution: Fleetguard® RESTORE contains no antifreeze. Do not allow the cooling system to freeze during the cleaning operation.**




Immediately add 3.8 liters [1 U.S. gal.] of Fleetguard® RESTORE, or equivalent, for each 38 to 57 liters [10 to 15 U.S. gal.] of cooling system capacity, and fill the system with plain water.

Turn the heater temperature switch to "HIGH" to allow maximum coolant flow through the heater core. The blower does **not** have to be on.




Operate the engine at normal operating temperature, at least 85° C [185° F], for 1 to 1 1/2 hours.

Shut off the engine and drain the cooling system.



Fill the cooling system with clean water until the level is at the bottom of the radiator fill neck.



Operate the engine at high idle for five minutes with the coolant temperature above 85° C [185° F].

Shut off the engine and drain the cooling system.


If the water being drained is still dirty, the system **must** be flushed again until the water is clean.



Install a new coolant filter and fill the cooling system with Heavy Duty Coolant.

Use a precharge filter to bring the coolant to the correct supplemental coolant additive concentration level. Refer to the Coolant Specifications in Section V.


Install the pressure cap. Operate the engine until it reaches a temperature of 80° C [180° F] and check for coolant leaks.



### Antifreeze Concentration - Checking


Antifreeze overconcentration reduces freeze protection. Do **not** use more than 68 percent antifreeze or overheating can result. A mixture of 50 percent antifreeze and 50 percent water is sufficient for freeze protection to -37° C [-34° F].

Refer to Section V for water and antifreeze recommendations.



The Fleetguard® refractometer, Part No. CC2800, provides a reliable and easy to read measurement of freeze point protection and glycol (antifreeze) concentration.

The freeze point protection **must** be checked if coolant is added to the cooling system. Refer to the manufacturer's instructions for correct operation.



## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Section 8 - Maintenance Procedures at 6000 Hours or 3 Years

### Section Contents

	Page
<b>Air Compressor</b> .....	8-18
Air Compressor Discharge - Inspection .....	8-18
Air Compressor Intake - Inspection .....	8-19
Inspection .....	8-18
<b>Fan Hub (Belt Driven)</b> .....	8-16
Inspection .....	8-16
<b>Fan Idler Pulley</b> .....	8-16
Inspection .....	8-16
<b>Fuel Pump - Calibration</b> .....	8-13
Cleaning and Inspection .....	8-14
Fuel Pump to Air Compressor Installation .....	8-15
Removal .....	8-13
<b>General Information</b> .....	8-2
<b>Injectors</b> .....	8-3
Cleaning and Calibration .....	8-3
Installation .....	8-5
Removal .....	8-3
<b>Turbocharger</b> .....	8-16
Axial Clearance - Checking .....	8-17
Inspection .....	8-16
Radial Bearing Clearance - Checking .....	8-17
<b>Vibration Damper</b> .....	8-3
Inspection .....	8-3



## General Information

Checks or inspections under previous maintenance intervals that are due for scheduled maintenance **must** also be performed at this time in addition to those listed under this maintenance interval.


## Vibration Damper

### Inspection

The silicone fluid in the damper will become solid after extended service and will make the damper inoperative. An inoperative damper can cause major engine or drive line failures.

Check the damper for evidence of fluid loss, dents and wobble. Visually inspect the vibration damper thickness for any deformation or raising of the damper front cover plate.

If any variations or deformations are detected, refer to the engine shop manual, Bulletin No. 3810476, for inspection procedures, or to your nearest Cummins Authorized Repair Location.




## Injectors

### Cleaning and Calibration

Every 6000 hours or three (3) years, clean and calibrate the injectors.

Calibration requires special equipment, and **must** be completed at a Cummins Authorized Repair Location.




### Removal

To clean and calibrate the injectors, remove them from the engine.

Remove the breather tube and the tube retaining clip.

Remove the 16 capscrews, isolators and spacers from the cover.

Remove the cover and gasket.




If the engine is equipped with Jacobs® Engine Brakes, the brakes **must** be removed to remove the injectors.


If the engine is **not** equipped with brakes, it is **not** necessary to loosen or remove the rocker lever assemblies. Disregard portions of the following text which refers to brake removal.

Disconnect the two electrical connections from the terminals on the inside and outside of the Jacobs® Brake spacer housing.


Disconnect the oil supply hose connection.

Remove the oil supply hose.





Remove the 16 capscrews and the spacer.




The push rods **must** be removed before removing the Jacobs® Brake housings to prevent the push rods from falling into the engine.

Some push rods are under compression due to the valves being open. Rotate the crankshaft **clockwise** with the accessory drive pulley to relieve the spring tension.


Hold the push rod with one hand to prevent it from falling into the engine.



Loosen each adjusting screw and remove the push rod. Mark each push rod with its position number as it is removed. Due to wear patterns, the push rods **must** be installed in the same location from which they were removed.



Use your fingers or a screwdriver to press the oil connector into the front brake housing to allow clearance for the housing removal.



Remove the eight Jacobs® Brake housing capscrews and both housings.




It is **not** necessary to remove the rocker lever assemblies to remove the injectors. Install the brake housing capscrews through the rocker lever assemblies. Do **not** tighten more than finger tight. This will prevent the assemblies from falling over and becoming disassembled.

Rotate the rocker levers up on each cylinder.


Remove the injector link.

Remove the two clamp capscrews and the injector hold down clamp.



Use injector puller, Part No. 3823024, to remove the injectors.


Take the injectors to a Cummins Authorized Repair Location for cleaning and calibration.



Do **not** use anything metal to scrape the injector copper sleeves. Damage to the injector sleeve can occur.

Use a clean wooden stick with a clean cloth wrapped around the end to remove all of the carbon from the injector copper sleeves in the cylinder head.


**NOTE:** Chip removing unit, Part No. ST-1272-11, can be used also to remove the carbon from the top of the piston.




## Installation

Do **not** stretch the o-rings as they are installed. The o-rings **must** be correctly installed in the grooves to prevent leaks.


Install the new o-rings on the injector. Use clean 15W-40 oil to lubricate the o-rings.





Check the bores in the cylinder head for burrs or sharp edges which can damage the o-rings. Repair damaged injector bores.


Install the injector into the cylinder head injector bore with the fuel drain hole toward the camshaft side of the engine. The screen on the fuel inlet hole will be toward the exhaust side of the engine.




**Caution:** The instrument used to install the injectors must be placed on the body of the injector, and not on the plunger. The plungers will be damaged.



Use a clean blunt instrument to seat the injector in the bore.



A "snap" will be heard and felt as the injector is seated. If the injector does **not** seat, remove it and check the o-rings for damage. Replace damaged o-rings.




Install the hold down clamp and capscrews over the injector body.



Use inch pound torque wrench, Part No. 3375044, to tighten the capscrews alternately and evenly. Either a M10x1.50 capscrew or a M8x1.25 capscrew is used. The torque values for both are given.

**M10x1.50:** Step 1 6 N•m [55 in-lb]  
2 12 N•m [110 in-lb]  
3 19 N•m [165 in-lb]


**M8x1.25:** Step 1 5 N•m [45 in-lb]  
2 10 N•m [90 in-lb]  
3 15 N•m [130 in-lb]




Install the injector link into each injector.

Inspect the injector plunger links for free movement. Raise the link approximately 1/3 of its length. Let the link fall into the injector.

If the link does **not** move freely, loosen the clamp capscrews. Tighten the capscrews again and check the free movement of the link.





Remove the rocker lever support capscrews.



Loosen the locknuts on the Jacobs® Brake slave pistons. Make sure the slave pistons are fully retracted.

Install the rear Jacobs® Brake housing on the rear rocker lever supports.






Use clean 15W-40 oil to coat the bottom of the capscrew heads and the threads.



Install the Jacobs® Brake capscrews into the rocker lever supports.

Do **not** tighten the capscrews at this time.




Install new o-rings on the brake housing oil connector.

Use clean 15W-40 oil to lubricate the o-rings.



Press the oil connector all the way into the front housing by hand.

When installing the front housing, be sure the oil connector and o-ring are in position to be pushed into the rear housing.




Install the front Jacobs® Brake housing on the front rocker lever supports.

Center the oil connector between the front and rear housings before tightening the capscrews. Snug the capscrews.

**Torque Value:** 5 N•m [45 in-lb]



**NOTE:** This is **not** the final torque value. The rocker lever side clearance **must** be adjusted before the capscrews are tightened to their final torque value.



Push the number five rocker lever support toward the front of the engine and tighten the support capscrews.


**Torque Value:** 122 N•m [90 ft-lb]

Install a 0.55 mm [0.022 in] feeler gauge between the number five support and the intake lever for the number four cylinder.



Push the number six support toward the front of the engine and tighten the support capscrew.

**Torque Value:** 122 N•m [90 ft-lb]




Install the feeler gauge between the number six support and the exhaust lever for the number five cylinder.



Push the number seven support toward the front of the engine and tighten the support capscrew.

**Torque Value:** 122 N•m [90 ft-lb]




Install the feeler gauge between the number seven support and the intake lever for the number six cylinder.



Push the number eight support toward the front of the engine and tighten the support capscrew.


**Torque Value:** 122 N•m [90 ft-lb]




Push the number four support toward the rear of the engine and tighten the support capscrew.



**Torque Value:** 122 N•m [90 ft-lb]






Install the feeler gauge between the number four support and the intake lever for the number three cylinder.

Push the number three support toward the rear of the engine and tighten the support capscrew.


**Torque Value:** 122 N•m [90 ft-lb]



Install the feeler gauge between the number three support and the exhaust lever for the number two cylinder.

Push the number two support toward the rear of the engine and tighten the support capscrew.

**Torque Value:** 122 N•m [90 ft-lb]




Install the feeler gauge between the number two support and the intake lever for the number one cylinder.

Push the number one support toward the rear of the engine and tighten the support capscrew.

**Torque Value:** 122 N•m [90 ft-lb]

Check the front and rear assemblies for correct clearance. Check the support capscrews for the correct torque value.



Use clean 15W-40 oil to coat the ball end of the push rods and push tubes.

The injector push rods (I) are longer than the valve push tubes (V).


Do **not** allow the push rods or tubes to fall into the engine. They can be damaged.

The crankshaft **must** be rotated to install all the push rods and tubes. The push rods and tubes **must** be installed in the same location as from which they were removed.


Install the injector push rods and valve push tubes.

Position the rods and tubes under the rocker lever adjusting screws.


Tighten the adjusting screws enough to hold them in place.



Make sure the push rods and tubes are properly seated in the cam follower sockets.




Adjust the valves and injectors. Refer to Section 6.




Clean the old RTV and oil from the top of the rocker lever housing and the Jacobs® Brake spacer housing.

Apply a bead of sealant, Part No. 3823494 or equivalent, to the top of the rocker lever housing.


Install the Jacobs® Brake spacer housing.





Install the capscrews and tighten in the sequence shown.


**Torque Value:** 25 N•m [18 ft-lb]




Install and tighten the oil supply hose fitting to the front brake housing.

Install the Jacobs®, terminal electrical leads on the outside of the spacer.

Connect the two solenoid electrical wires to the terminals on the inside of the spacer.



Install a new gasket on the cover.



Install the cover on the rocker lever housing.

Install the 16 isolators and capscrews in the cover.



Tighten the capscrews in the sequence shown.


**Torque Value:** 15 N•m [130 in-lb]

Install the breather hose and clip.

## Fuel Pump - Calibration


Every 6000 hours or 3 years, clean and calibrate the fuel pump.

Calibration requires special equipment and **must** be completed at a Cummins Authorized Repair Location.




## Removal


Disconnect the battery cables.




Clean the fuel pump and the surrounding area before removing it from the engine.




Remove the wire to the fuel shutoff valve.  
Remove the linkage from the throttle lever.





Remove the fuel tubing and air tube:

- Fuel drain line from the T-block connection (1)
- Gear pump cooling drain (2)
- Gear pump suction line (3)
- Fuel supply to the injectors (4)
- AFC air supply tube (5)
- Tachometer cable (6) (if used)




Remove the two fuel pump support bracket capscrews.

Remove the four fuel pump mounting capscrews and the fuel pump.

Remove the coupling spider.

Take the fuel pump to a Cummins Authorized Repair Location.




### Cleaning and Inspection

Clean the gasket surface of the fuel pump and the air compressor or accessory drive.



Inspect the surfaces for damage.



Visually inspect the spider coupling for damage.




## Fuel Pump to Air Compressor Installation

Install the fuel pump drive spider coupling.

Use a new gasket to install the fuel pump.

Install the four fuel pump mounting capscrews.

**Torque Value:** 47 N•m [35 ft-lb]



Install the support bracket to the cylinder block with two capscrews. Do **not** tighten the capscrews.


Install the support bracket to the fuel pump housing. Do **not** tighten the capscrews.

Tighten the support bracket to cylinder block capscrews.

**Torque Value:** 47 N•m [35 ft-lb]


Tighten the support bracket to the fuel pump housing capscrews.

**Torque Value:** 11 N•m [95 in-lb]



Install the AFC air tube and fuel tubing:


- Fuel drain from the T-block connection (1)
- Gear Pump cooling drain (2)
- Gear pump suction line (3)
- Fuel supply to the injectors (4)
- AFC air supply tube (5)
- Tachometer cable (if used) (6)




Install the electric wire to the fuel shutoff valve. The wire connection nut **must** be clean and tight.


**Torque Value:** 30 N•m [25 in-lb]

Install the linkage to the throttle lever.





Install the battery cables.




## Fan Idler Pulley

### Inspection

Every 6000 hours or 3 years, measure the pulley end clearance.

The end clearance **must** be 0.05 to 0.25 mm [0.002 to 0.010 in].

If the end clearance does **not** meet the above specifications, it **must** be rebuilt or replaced. Refer to Section A for replacement procedures. Refer to the Shop Manual, Bulletin No. 3810476, for rebuilding procedures.




## Fan Hub (Belt Driven)

### Inspection

Every 6000 hours or 3 years, measure the drive pulley flange end clearance.

The end clearance **must** be 0.08 to 0.41 mm [0.003 to 0.016 in].

If the end clearance does **not** meet the above specifications, it **must** be rebuilt or replaced. Refer to Section A for replacement procedures. Refer to the Shop Manual, Bulletin No. 3810476, for rebuilding procedures.



## Turbocharger

### Inspection

Every 6000 hours or 3 years, inspect the turbocharger. Remove the air intake and the exhaust piping. Check the turbocharger as follows:

- Look for damaged or cracked compressor or turbine blades. Check to see that the turbocharger shaft spins freely.



If visual inspections or dimensional checks indicate a problem, contact a Cummins Authorized Repair Location for assistance. Refer to the model number on the turbocharger dataplate.




Radial Bearing Clearance - Checking

Use a narrow blade or a wire type feeler gauge to measure the clearance between the compressor wheel and housing.


Gently push the compressor wheel toward the compressor housing and gauge.

Record this clearance.



With the feeler gauge in the same location, gently push the compressor wheel away from the compressor housing and measure the clearance between the compressor wheel and housing.


Record this clearance.



Subtract the smaller clearance from the larger clearance. This is the radial bearing clearance.

Radial Bearing Clearance		
mm		in
0.15	MIN	0.006
0.64	MAX	0.025

Replace the turbocharger if the radial bearing clearance does **not** meet the specifications. Refer to Section A for replacement procedure.





Axial Clearance - Checking

Use dial depth gauge, Part No. ST-537, to measure the end clearance.

Push the rotor assembly away from the gauge.

Set the gauge on zero (0).






Push the rotor assembly toward the gauge and record the data.


Axial Clearance		
mm		in
0.038	MIN	0.0015
0.089	MAX	0.0035

Replace the turbocharger if the clearance does **not** meet the specifications. Refer to Section A for replacement procedure.



Install the intake and exhaust air pipes. Tighten the clamps.


**Torque Value:** 8 N•m [72 in-lb]



## Air Compressor Inspection

A complete inspection of the air compressor is required every 6000 hours or 3 years.

All air compressors have a small amount of oil carryover which lubricates the piston rings and moving parts. When this oil is exposed to normal air compressor operating temperatures over a period of time, it will form varnish or carbon deposits. If the following inspections are **not** done, the air compressor piston rings will be affected by high operating temperatures and pressures, and will **not** seal correctly.




## Air Compressor Discharge - Inspection


Drain the air system wet tank to release the system air pressure. Remove the air discharge line from the air compressor.

Measure the total carbon deposit thickness inside the air discharge line as shown. If the total carbon deposit ( $X + X$ ) exceeds 2 mm [1/16 inch], clean and inspect the cylinder head, the valve assembly and the discharge line. Replace if necessary. Refer to the appropriate air equipment manual listed below for procedures, or contact your Cummins Authorized Repair Location:


- Single Cylinder, Bulletin No. 3810242
- Twin Cylinder, Bulletin No. 3379056



If the total carbon deposit exceeds specifications, continue checking the air discharge line connections, up to the first tank, until total carbon deposit is less than 2 mm [1/16 inch]. Clean or replace any lines or connections that exceed this specification.




Inspect any air driers, spitter valves, pressure relief valves and alcohol injectors for carbon deposits or malfunctioning parts. Inspect for air leaks. Maintain and repair the parts according to the manufacturer's specifications.




## Air Compressor Intake - Inspection

**Warning:** Hold the unloader valve down when removing the capscrews. Personal injury can result from the sudden release of the spring loaded unloader valve.



Remove the capscrews, the lock washers and the flat washers that secure the unloader valve assembly to the cylinder head cover. Remove the unloader valve assembly and the spring from the cylinder head and the cover.






Visually inspect the unloader valve for carbon buildup. If carbon or heavy varnish is present, remove, clean and inspect the compressor head and the valve assembly. Replace parts as necessary. Refer to the appropriate air equipment manual listed below for procedures or contact your nearest Cummins Authorized Repair Location:

- Single Cylinder, Bulletin No. 3810242
- Twin Cylinder, Bulletin No. 3379056



If the unloader valve is clean or only lightly varnished, install a new o-ring on the unloader body and a new rectangular seal inside the unloader body cavity.

The open side of the rectangular seal **must** face the top of the unloader body.



Lubricate the unloader cap with anti-seize compound. Lubricate the unloader body o-ring with engine oil. Assemble the unloader assembly to the cylinder head cover. Tighten the capscrews.

**Torque Value:** 14 N•m [10 ft-lb]

## Section D - System Diagrams

### Section Contents

	Page
Air Intake System Flow Diagram .....	D-6
Compressed Air System Flow Diagrams.....	D-8
Coolant Flow Diagram .....	D-5
Exhaust System Flow Diagram.....	D-7
Fuel System Flow Diagram.....	D-3
General Information .....	D-2
Lubricating Oil Flow Diagram.....	D-4



## General Information

The following drawings show the flow through the engine systems. Although parts can change between different applications and installations, the flow remains the same. The systems shown are:

- Fuel System
- Lubricating Oil System
- Coolant System
- Intake Air System
- Exhaust System
- Compressed Air System


Knowledge of the engine systems can help you in troubleshooting, service and general maintenance of your engine.



## Fuel System Flow Diagram


### Fuel System

1. Fuel Inlet Supply
2. Fuel Filter
3. Fuel Pump
4. Fuel to Injectors
5. Injector
6. Fuel Drain Return
7. Gear Pump Cooling Return



## Lubricating Oil Flow Diagram



1. Oil Pump
2. Pressure Regulator Valve
3. Oil Return to Pan
4. High Pressure Relief Valve
5. Oil Return to Pan
6. Oil Thermostat
7. Oil Cooler
8. By-pass Filtered Oil Return
9. Combination Oil Filter
10. Filter By-pass Valve
11. Accessory Drive/Air Compressor
12. Idler Gears



## Coolant Flow Diagram

### Coolant System

1. Water Pump Coolant Inlet
2. Coolant to Lower Manifold Cavity
3. Coolant to Cylinder Liner Block Cavity
4. Coolant to Cylinder Head
5. Coolant to Upper Manifold Cavity
6. Lower Manifold Coolant to Oil Cooler



### Oil Cooler/ Aftercooler Coolant

1. Coolant Entry to Lower Manifold Cavity
2. Lower Manifold Coolant to Oil Cooler/Aftercooler
3. Aftercooler Coolant Outlet to Upper Manifold Cavity
4. Oil Cooler Water Outlet to Upper Manifold Cavity

### Closed

1. Upper Manifold Cavity (Coolant to Thermostat)
2. Coolant Bypass (Return to Water Pump)


### Open

1. Water Pump Coolant Inlet
2. Upper Manifold Cavity (Coolant to Thermostat)
3. Coolant Outlet

## Air Intake System Flow Diagram

### Intake System


1. Filtered Intake Air to Turbocharger
2. Turbocharger Air to Aftercooler
3. Aftercooler
4. Intake Manifold
5. Intake Valve Ports





## Exhaust System Flow Diagram

### Exhaust System

1. Exhaust Valve Ports
2. Exhaust Manifold
3. Turbocharged Exhaust Outlet



## Compressed Air System Flow Diagrams



cp800pb

## Section T - Troubleshooting

### Section Contents

	Page
Troubleshooting Procedures and Techniques .....	T-2
Troubleshooting Symptoms.....	T-2
Air Compressor Air Pressure Rises Slowly .....	T-3
Air Compressor Noise Excessive .....	T-4
Air Compressor Pumping Excess Lubricating Oil Into Air System .....	T-5
Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously) .....	T-6
Air Compressor Will Not Stop Pumping .....	T-7
Alternator Not Charging or Insufficient Charging .....	T-8
Coolant Loss - External .....	T-17
Coolant Temperature Above Normal - Gradual Overheat.....	T-18
Coolant Temperature Above Normal - Sudden Overheat.....	T-19
Coolant Temperature Below Normal.....	T-20
Crankcase Gases (Blowby) - Excessive.....	T-9
Engine Cranks But Will Not Start (No Smoke From Exhaust) .....	T-13
Engine Difficult to Start or Will Not Start - Exhaust Smoke Present.....	T-12
Engine Power Output Low .....	T-22, T-23
Engine Starts But Will Not Keep Running .....	T-14
Engine Will Not Crank or Cranks Slowly ( Electric Starting Motor).....	T-11
Engine Will Not Crank or Cranks Slowly (Air Starting Motor) .....	T-10
Engine Will Not Reach Rated Speed When Loaded .....	T-24
Engine Will Not Shut Off.....	T-15
Exhaust Smoke Excessive Under Load.....	T-21
Lubricating Oil Pressure Low .....	T-16
White Smoke or Rough Running At Idle (After Warmup Period) .....	T-25

## **Troubleshooting Procedures and Techniques**

This guide describes some typical engine operating problems, their causes, and some acceptable corrections to those problems. Unless noted otherwise, the problems listed are those which an operator can diagnose and repair. See a Cummins Authorized Repair Location for diagnosis and repair of problems **not** listed.

Follow the suggestions below to develop good troubleshooting procedures:

- Study the problem thoroughly before acting.
- Do the easiest and obvious things first.
- Find and correct the basic cause of the problem.

## **Troubleshooting Symptoms**

Use the charts on the following pages of this section to aid in diagnosing specific engine problems. Read each row of blocks from top to bottom. Follow the arrows through the chart to identify corrective action.



### Air Compressor Air Pressure Rises Slowly

#### Cause

#### Corrections

Intake Air Restriction to Air Compressor Excessive (Naturally Aspirated Air Compressors Only)

Replace air compressor air cleaner (if installed). Check engine intake air restriction if air compressor inlet is installed in intake piping between air cleaner and turbocharger.

OK



Air Sytem Leaks

Check for air compressor gasket leaks. Check safety pressure valve leaks. Rating must be 150 psi. Check safety pressure valve location. Move if located near air compressor outlet. Refer to the manufacturer's instructions for other air system leaks.

OK



Carbon Buildup Excessive in the Air Discharge Line. Check Valve and/or Cylinder Head

To check carbon build-up, refer to Page 8-19. To replace air compressor head, refer to L10 Shop Manual, Bulletin No. 3810476. To replace discharge line, refer to equipment manufacturer.

OK



Contact an Authorized Repair Facility

### Air Compressor Noise Excessive

#### Cause

#### Corrections

Carbon Buildup Excessive in the Air Discharge Line. Check Valve and/or Cylinder Head

To check carbon buildup, refer to Page 8-19. To replace air compressor head, refer to L10 Shop Manual, Bulletin No. 3810476. To replace air discharge line(s), refer to equipment manufacturer.

OK

Contact an Authorized Repair Facility

## Air Compressor Pumping Excess Lubricating Oil Into Air System

### Cause

### Corrections

Intake Air Restriction to Air Compressor  
Excessive (Naturally Aspirated Air  
Compressor Only)

Replace air compressor air cleaner (if  
installed). Check engine intake restriction if  
air compressor inlet is installed in intake  
piping between air cleaner and turbocharger.

OK



Air Compressor Pumping Time  
Excessive

Check air compressor duty cycle. Refer  
to Installation Recommendations -  
Compressed Air Systems, Bulletin  
No. 3382886.

OK



Contact an Authorized Repair Facility

### Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously)

Cause

Corrections

Air System Leaks

Check for air compressor gasket leaks.  
Refer to the manufacturer's instructions for  
the other air system leaks.

OK



Contact an Authorized Repair Facility

Air Compressor Will Not Stop Pumping

Cause

Corrections

Air System Leaks

Check for air compressor gasket leaks.  
Refer to the manufacturer's instructions for  
other air system leaks.

OK




Contact an Authorized Repair Facility

### Alternator Not Charging or Insufficient Charging

Cause

Corrections



### Crankcase Gases (Blowby) - Excessive

Cause

Corrections

Crankcase Breather Vent Tube  
Restricted

Check breather tube restriction.

OK  
→

Contact an Authorized Repair Facility

### Engine Will Not Crank or Cranks Slowly (Air Starting Motor)

Cause

Corrections

Air Pressure Insufficient in Air Tank

Increase pressure using external air supply.

OK  
↓

Engine Drive Units Engaged

Disengage engine driven units.

OK  
↓

Oil Incorrect for Operating Conditions

Change oil and filters. Use the type recommended (15W-40). Check operation.

OK  
↓

Oil Temperature Too Low

Install oil pan heater or drain oil and refill with warm oil.

OK  
↓


Contact an Authorized Repair Facility



## Engine Will Not Crank or Cranks Slowly ( Electric Starting Motor)

Cause

Corrections



### Engine Difficult to Start or Will Not Start - Exhaust Smoke Present

Cause

Corrections

Starting Procedure Incorrect

Refer to the vehicle manufacturer's starting instructions.

OK  
↓

Engine Driven Units Engaged

Disengage engine driven units.

OK  
↓

Starting Aid Needed for Cold Weather or Malfunction

Check/repair or replace cold starting aid if necessary.

OK  
↓

Fuel Filter Plugged

Replace fuel filter. Refer to page 5-3.

OK  
↓

Contact an Authorized Repair Facility

### Engine Cranks But Will Not Start (No Smoke From Exhaust)

Cause

Corrections

No Fuel in Tank

Add fuel.

OK  
↓

Shutoff Valve Closed

Use manual override. Repair fuel shutdown solenoid. Refer to Page E-5.

OK  
↓

Contact an Authorized Repair Facility

### Engine Starts But Will Not Keep Running

Cause

Corrections

Engine Driven Units Engaged

Disengage engine driven units.

OK  
↓

Air In The Fuel System

Check for air in fuel, tighten fuel connections, tighten filter, check fuel tank stand pipe.

OK  
↓

Fuel Filter Plugged or Fuel Waxing  
Due to Cold Weather

Replace fuel filter. Weather conditions can require fuel heater.

OK  
↓

Fuel Suction Line Restricted

Inspect fuel line for restriction.

OK  
↓


Fuel Contaminated

Verify by operating engine from a temporary supply tank.


OK  
↓

Contact an Authorized Repair Facility


### Engine Will Not Shut Off



### Lubricating Oil Pressure Low




### Coolant Loss - External



### Coolant Temperature Above Normal - Gradual Overheat

#### Cause

#### Corrections






### Coolant Temperature Above Normal - Sudden Overheat

Cause

Corrections



### Coolant Temperature Below Normal

Cause

Corrections


Continuously Operating in Low  
Ambient Temperature

Refer to Bulletin No. 3387266-R (Cold  
Weather Operation).

OK  
↓

Contact an Authorized Repair Facility

### Exhaust Smoke Excessive Under Load



## Engine Power Output Low

Cause	Corrections
Excessive Load for Engine Horsepower Rating	Reduce vehicle load.
OK ↓	
Low Power Due to Altitude	Derate engine above 3600 meters [12,000 feet].
OK ↓	
Fuel Suction Line or Fuel Filter Restricted	Check fuel line for restriction. Replace fuel filter.
OK ↓	
Lubricating Oil Level Too High	Check dipstick calibration and oil pan capacity.
OK ↓	
Throttle Linkage Adjustment Incorrect	Check throttle linkage adjustment for full opening of throttle lever.
OK ↓	
Intake or Exhaust System Restricted	Check intake and exhaust systems for restrictions.
OK ↓	
Air in Fuel - Spongy Throttle is Symptom	Check for air in fuel, tighten fuel connections and filter, check fuel tank stand pipe.
OK ↓	

(Continued)

## Engine Power Output Low (Continued)

### Cause

### Corrections

Fuel Drain Line Restricted or Fuel Tank Vents Plugged

Check fuel drain line for loops, crimps or clamped points. Remove, clean, or replace vents.

OK



Fuel Quality Poor

Verify by operating engine from a temporary tank that contains good fuel and refer to fuel oil specifications.

OK



High Intake Air Temperature - (Above 38°C [100°F])

Use outside air to turbocharger in warm weather.

OK



Low Intake Air Temperature - (Below 0°C [32°F])

Use intake air from under hood in cold weather.

OK



High Fuel Temperatures - (Above 70°C [158°F])

Fill fuel tanks; turn off fuel heater. Maximum fuel temperature 70°C [158°F].

OK



Contact an Authorized Repair Facility

Engine Will Not Reach Rated Speed When Loaded

Cause

Corrections

Excessive Load for Engine Horsepower Rating

Reduce vehicle load or use lower gear.

OK

Tachometer Has a Malfunction

Check with hand or digital tachometer.

OK

Throttle Linkage Adjustment Incorrect

Check for full throttle travel.

OK

Fuel Suction Line Restricted

Check fuel inlet for restriction.

OK

Contact an Authorized Repair Facility

### White Smoke or Rough Running At Idle (After Warmup Period)

Cause

Corrections

Low Coolant Temperature

Refer to "Coolant Temperature Below Normal" chart.

OK



Fuel Quality Poor

Verify by operating engine from a temporary tank that contains good fuel.

OK



Overhead Adjustments Incorrect

Reset valves and injectors. Refer to Section 6.

OK



Contact an Authorized Repair Facility




## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



## Section A - Adjustment, Repair and Replacement

### Section Contents

	Page
Air Starting Motor .....	A-18
Air Starting Motor Maintenance.....	A-18
Alternator Drive Belt .....	A-3
Adjustment .....	A-3
Replacement .....	A-4
Fan Drive Belt .....	A-2
Adjustment .....	A-2
Replacement .....	A-2
Fan Hub - Replacement .....	A-14
Installation .....	A-14
Removal .....	A-14
Fan Idler - Replacement.....	A-12
Installation .....	A-13
Removal .....	A-12
Storage for Engines Out of Service.....	A-18
Thermostat - Replacement .....	A-9
Installation .....	A-11
Removal .....	A-9
Turbocharger - Replacement .....	A-15
Installation .....	A-16
Removal .....	A-15
Water Pump - Replacement .....	A-5
Installation .....	A-6
Removal .....	A-5




## Fan Drive Belt

### Adjustment

Do **not** adjust belt tension to full value with the adjusting screw. Belt tension can increase when the locknut is tightened and cause reduced belt and bearing life.


- Loosen the idler pulley shaft locknut.
- Use belt tension gauge, Part No. ST-1293, to adjust the belt to the correct tension. Refer to the Belt Tension Chart in Section V for the correct value.



- Tighten the idler pulley shaft locknut:


**Torque Value:** 190 N•m [140 ft-lb]

- Check the belt tension again to make sure the belt is **not** too tight.



### Replacement

Loosen the idler pulley shaft locknut.




Loosen the adjusting mechanism and move the pulley centers as close as possible. The belt can then be removed and a new one installed without excessive force.

To prevent damage to the pulley and new belt, do **not** roll the belt over the pulley or pry it on with a tool.



Install a new belt on the pulley.


Refer to the Belt Tension Chart in Section V to select the correct gauge and tension value for the belt width. Adjust the belt to the correct tension.



Tighten the idler pulley shaft locknut.


**Torque Value:** 190 N•m [140 ft-lb]

Check the tension again to make sure the belt is adjusted to the correct value.



Check the pulley alignment.

Pulley misalignment **must not** exceed 6 mm for each meter [1/16 inch for each 12 inches] of distance between the pulley centers.



## Alternator Drive Belt


### Adjustment


Loosen the adjusting screw locknut (1).

Loosen the adjustment link locking capscrew (2).

Loosen the pivot capscrew and nut (3).

Turn the adjusting screw (4) to adjust belt tension. Refer to Belt Tension Chart in Section V for correct tension value.






Tighten the adjusting screw locknut (2) against the re-tainer.

Tighten the adjustment link locking capscrew (3).

**Torque Value:** 80 N•m [60 ft-lb]

Tighten the pivot capscrew (4) and nut (5).

**Torque Value:** 47 N•m [35 ft-lb]



## Replacement


Loosen the adjusting screw locknut (1).

Loosen the adjustment link locking capscrew (2).

Loosen the alternator mounting capscrew (3).

Turn the adjusting screw (4) **counterclockwise** to release tension.

Remove the alternator belt.




Install a new belt on the water pump and alternator pulleys. To prevent damage, do **not** roll a belt over the pulley or pry it on with a tool.

Turn the adjusting screw (1) **clockwise** to increase the belt tension.

Use belt tension gauge, Part No. ST-1293, to measure the belt tension.

Refer to the belt tension chart in Section V for the correct belt tension.



Tighten the adjusting screw locknut (2) against the re-tainer.

Tighten the adjustment link locking capscrew (3).


**Torque Value:** 80 N•m [60 ft-lb]

Tighten the pivot capscrew (4) and nut (5).

**Torque Value:** 47 N•m [35 ft-lb]



Belts **must not** touch the bottom of the pulley grooves, nor **must** they protrude over 3 mm [3/32-inch] above the top edge of the groove.




## Water Pump - Replacement

### Removal


**Warning:** Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50°C [120°F] before removing the coolant system pressure cap. Failure to do so can cause personal injury from heated coolant spray.

Remove the radiator cap after the engine is cool.



Drain the cooling system as follows:

- Open the radiator draincock
- Remove the lower radiator hose
- Remove the plug or Compuchek® fitting from the bottom of the water pump.





Remove the alternator drive belt. Refer to Alternator Drive Belt - Replacement procedure in this section.

Remove the water pump pulley capscrew.

Use pulley puller, Part No. ST-647 and two 5/16 X 18 X 2 capscrews to remove the pulley.


Be sure the puller capscrews are threaded all the way to through the pulley before applying pressure to the puller screw.





Remove the five water pump oil seal capscrews, clamping ring, oil seal and gasket.


Remove the alternator.



Loosen the coolant bypass hose clamps.

Remove the inlet hose.


Remove the three mounting capscrews and the water pump cover.



Remove the two water transfer connection capscrews and slide the connection into the water pump.

Remove the three mounting capscrews and the water pump.

**NOTE:** To prevent damage to the needle bearing, do **not** angle the pump outward from the cylinder block until the pump shaft has cleared the needle bearing.




## Installation

Be sure surfaces (1) and (2) of the water pump are clean.

Make sure the gear housing water pump and seal mounting surfaces are clean.

Install a new o-ring on the water transfer tube.  
Apply a film of lubricating oil to the o-ring.  
Install the transfer tube in the water pump.




Install a new o-ring on the water pump mounting flange.  
**NOTE:** The water pump **must** be installed straight in once the shaft enters the gear housing needle bearing to prevent damage to the bearing.

Install the water pump and the three mounting capscrews.  
Tighten the capscrews.

**Torque Value:** 47 N•m [35 ft-lb]


Install a new gasket on the water pump transfer connection. Install and tighten the water transfer connection capscrews.

**Torque Value:** 25 N•m [18 ft-lb]



Install a new o-ring on the water pump cover.  
Install the cover and tighten the capscrews.


**Torque Value:** 47 N•m [35 ft-lb]




Install the coolant bypass hose. Tighten the hose clamps.

**Torque Value:** 3 N•m [30 in-lb]

Install the coolant inlet hose. Tighten the hose clamp to the manufacturer's specifications.





The oil seal **must** be installed with the lip of the seal and the shaft clean and dry. Do **not** lubricate. The yellow dust lip **must** be facing out. The oil seal cap screw threads **must** be coated with pipe sealant to prevent oil leakage.




Install the new gasket and oil seal. Use the installation sleeve provided with the new seal to install the seal.

Install the five cap screws and tighten in a star pattern.



**Torque Value:** Step 1 - 7 N•m [60 in-lb]  
2 - 20 N•m [175 in-lb]




Use pulley pusher adapter (1), Part No. 3377401, and pulley pusher (2), Part No. 3376326, to install the pulley.

Install the cap screw in the shaft.




**Torque Value:** 75 N•m [55 ft-lb]



Install the alternator.

Install and adjust the alternator drive belt. Refer to Alternator Drive Belt - Replacement procedure in this section.



Close the radiator draincock and install the lower radiator hose.


Tighten the hose clamp to the manufacturer's specifications.



The correct concentration of coolant additives **must** be used in the cooling system. Refer to Section V.

Fill the cooling system. Refer to Section 3.

Operate the engine until it reaches a temperature of 80°C [180°F] and check for coolant leaks.




## Thermostat - Replacement

### Removal


**Warning:** Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50°C [120°F] before removing the coolant system pressure cap. Failure to do so can cause personal injury from heated coolant spray.

Remove the radiator cap after the engine is cool.




Drain the cooling system as follows:


- Open the radiator draincock.
- Remove the lower radiator hose.
- Remove the plug or Compuchek® fitting from the bottom of the water pump.




Remove the upper radiator hose from the thermostat housing.

Loosen the coolant bypass hose clamps.






Remove the four thermostat housing mounting capscrews and the thermostat housing.




Remove the thermostat from the housing.



Visually inspect the thermostat seal for cracks, corrosion or other damage.

If the seal is damaged, it **must** be replaced.



**NOTE:** Use care when removing the thermostat seal so as not to damage the housing.




Use a punch and hammer to remove the seal from the housing.

Inspect the housing for cracks or damage.

Make sure the thermostat housing is clean before installing the new seal.

**NOTE:** When installing the new seal, the flat side of the seal **must** be facing the mandrel.


Use thermostat seal mandrel, Part No. ST-1225, and a hammer to install the new seal.



## Installation


Install the thermostat in the housing.

Install a new gasket on the thermostat housing.



Install the hose on the thermostat housing bypass outlet.  
Install the thermostat housing and four mounting cap-screws.

**Torque Value:** 54 N•m [40 ft-lb]





Install the upper radiator hose to the thermostat housing outlet.

Refer to the manufacturer's specifications for the correct torque value.

Tighten the coolant bypass hose clamps.

**Torque Value:** 3 N•m [30 in-lb]






Close the radiator draincock and install the lower radiator hose.

Tighten the hose clamp.

**Torque Value:** 5 N•m [40 in-lb]




The correct concentration of coolant additives **must** be used in the cooling system. Refer to Section V.

Fill the cooling system. Refer to Section 3.




Operate the engine until it reaches a temperature of 80°C [180°F] and check for coolant leaks.



## Fan Idler - Replacement Removal

Loosen the idler pulley shaft locknut.



Loosen the adjusting mechanism and move the pulley centers as close as possible.


Remove the fan belt.

Remove the roll pin from the idler pulley adjusting screw.

Remove the locknut and washer from the back of the idler pulley shaft.

Remove the adjusting screw.

Remove the idler pulley from the fan hub support bracket.




## Installation

Do **not** tighten the locknut until the fan drive belt has been installed and adjusted.


Install the idler pulley in the fan hub support bracket.

Install the washer and locknut on the idler pulley shaft.



Install the adjusting screw in the idler pulley shaft.

Turn the adjusting screw in far enough to install the roll pin in the shaft at the bottom of the fan hub support bracket.




Install and adjust the fan drive belt. Refer to the Belt Tension Chart in Section V for the correct tension.

Tighten the idler pulley shaft locknut.

**Torque Value:** 190 N•m [140 ft-lb]


Check the belt tension again after the locknut is tightened.



## Fan Hub - Replacement

### Removal


Loosen the idler pulley shaft locknut.



Loosen the adjusting mechanism and move the pulley centers as close as possible.


Remove the fan belt.

Remove the fan and fan clutch assembly.



Remove the fan drive pulley.


Remove the four capscrews and the fan hub.



### Installation

Install the new fan hub and four capscrews.

Torque Value: 47 N•m [35 ft-lb]




Install the fan drive pulley.

Install the fan and clutch assembly on the engine. Install the capscrews and tighten.


**Torque Value:** 68 N•m [50 ft-lb]

Install and adjust the fan drive belt. Refer to Belt Tension Chart in Section V for the correct tension.



Tighten the idler pulley shaft locknut.

**Torque Value:** 190 N•m [140 ft-lb]




## **Turbocharger - Replacement**


### **Removal**


Remove the oil supply line from the turbocharger.

Remove the oil drain line from the turbocharger.



Remove the intake and exhaust pipes from the turbocharger.






Loosen the hose clamps on the aftercooler air inlet connection.

Remove the four turbocharger mounting nuts.

Remove the turbocharger and gasket.



### Installation

Apply a film of high temperature antiseize compound to the turbocharger mounting studs.


Use a new gasket and install the turbocharger.

Install the four mounting nuts.

Install the aftercooler air inlet hose evenly over the turbocharger outlet and the aftercooler inlet.


Tighten the turbocharger mounting nuts.

**Torque Value:** 61 N•m [45 ft-lb]



Tighten the hose clamps.

**Torque Value:** 8 N•m [72 in-lb]



Install a new gasket on the turbocharger oil drain line connection and install the drain line to the bottom of the turbocharger. Tighten the two cap screws.

**Torque Value:** 27 N•m [20 ft-lb]




## Section A - Adjustment, Repair and Replacement L10

## Turbocharger - Replacement Page A-17

Pour 50 to 60 cc [2.0 to 3.0 ounces] of clean engine oil in the top of the turbocharger at the oil supply line connection.


Install a new gasket on the turbocharger oil supply line and install the supply line to the top of the turbocharger. Tighten the two capscrews.

**Torque Value:** 20 N•m [15 ft-lb]




Install the intake and exhaust pipes and tighten the clamps.

**Torque Value:** 8 N•m [72 in-lb]



Operate the engine and check for air leaks.



## Air Starting Motor

The air starting motor system (tanks, line sizes, and valves) is designed and installed by the original equipment manufacturers and the starting motor suppliers. Refer any questions about the air starting systems to the manufacturer.

## Air Starting Motor Maintenance

- Do **not** operate the air starting motor with air pressure lower than 480 kPa [70 psi].
- Maintain the air compressor according to the recommendations outlined in the manual.
- For maximum efficiency, the hoses, tubes, and lines **must not** leak.
- Refer to the original equipment manufacturer's and starting motor manufacturer's manuals for specific information regarding the starting motors, valves, and systems.

## Storage for Engines Out of Service

If the engine will be out of service longer than 6 months, take special precautions to prevent rust. Contact the nearest Cummins Authorized Repair Location, or refer to the Engine Shop Manual, Bulletin No. 3810476, for information concerning engine storage procedures.

## Section V - Specifications and Torque Values

### Section Contents

	Page
Arctic Operation .....	V-19
Capscrew Markings and Torque Values .....	V-20
Capscrew Markings and Torque Values - Metric .....	V-20
Capscrew Markings and Torque Values - U.S. Customary .....	V-21
Coolant Recommendations/Specifications .....	V-7
Coolant Blending/Mixing .....	V-9
Coolant Capacity Charts .....	V-11
Cooling System Sealing Additives .....	V-8
Cooling System Soluble Oils .....	V-8
Fleetguard® DCA4 Service Filters and Liquid Pre-Charge .....	V-10
Heavy Duty Coolant .....	V-7
Cummins/Fleetguard® Filter Specifications .....	V-4
Drive Belt Tension .....	V-17
Engine Component Torque Value .....	V-18
Engine Specifications .....	V-2
Air Intake System .....	V-3
Compressed Air System .....	V-3
Cooling System .....	V-2
Electrical System .....	V-3
Exhaust System .....	V-3
Fuel System .....	V-2
General .....	V-2
Lubricating Oil System .....	V-2
Fuel Recommendations/Specifications .....	V-4
Lubricating Oil Recommendations/Specifications .....	V-4
New Engine Break-in Oils .....	V-4
Supplemental Coolant Additives .....	V-12
Instructions For Proper Kit Use .....	V-14
Precautions .....	V-14
Test Intervals .....	V-14



## Engine Specifications

Metric [U.S. Customary]

### General

Engine Speed @ at Maximum Output  
Standard Rating (RPM) ..... 2100

**NOTE:** Refer to the engine dataplate for optional engine speed rating.

Displacement.....10.0 liters [611 C.I.D.]

Bore and Stroke.....125 mm [4.921 in.] x 136 mm [5.354 in.]

Dry Engine Weight ..... 884.5 Kg [1950 lbs]

Firing Order.....1-5-3-6-2-4

Valve and Injector Settings:

Intake Valve Adjustment .....0.35 mm [0.014 in.]

Exhaust Valve Adjustment.....0.68 mm [0.027 in.]

Top Stop Injector Adjustment ..... 0.6 to 0.7 N•m [5 to 6 in-lb]

### Fuel System

**NOTE:** For performance and fuel rate values, consult the engine data sheet or the fuel pump code for the particular model involved.

Maximum Allowable Restriction to pump

With Clean Filter.....100 mm Hg [4 in. Hg]

With Dirty Filter .....200 mm Hg [8 in. Hg]

Maximum Allowable Fuel Return Line Restriction

Without Check Valves.....64 mm Hg [2.5 in. Hg]

With Check Valves and/or Overhead Tanks.....165 mm Hg [6.5 in. Hg]

Minimum Allowable Fuel Tank Vent Capability.....0.42 m<sup>3</sup>/h [15 ft<sup>3</sup>/hr]

### Lubricating Oil System

Oil Pressure - at Idle (Minimum Allowable) .....70 kPa [10 psi]

At 1200 RPM or Peak Torque (Minimum Allowable) .....207 kPa [30 psi]

Oil Capacity of Standard Engine

Combination Filter.....2.6 liters [0.7 U.S. gal.]

Oil pan (High-Low) ..... 34 to 30.3 liters [9 to 8 U.S. gal.]

Total System Capacity Including Filter .....38 liters [10 U.S. gal.]

### Cooling System

Coolant Capacity (Engine Only).....11 liters [12 U.S. qt.]

Standard Modulating Thermostat Range.....82 to 93°C [180 to 200°F]

Coolant Cylinder Block Pressure (Pressure Cap Removed) .....124 to 275 kPa [18 to 40 psi]

Maximum Allowable Operating Temperature .....100°C [212°F]

Minimum Recommended Operating Temperature .....70°C [158°F]

Minimum Recommended Pressure Cap.....50 kPa [7 psi]

## Air Intake System

**NOTE:** Engine intake air **must** be filtered to prevent dirt and debris from entering the engine. If intake air piping is damaged or loose, unfiltered air will enter the engine and cause premature wear.

Maximum Inlet Restriction (Clean Filter) .....250 mm H<sub>2</sub>O [10 in. H<sub>2</sub>O]  
Maximum Inlet Restriction (Dirty Filter) .....635 mm H<sub>2</sub>O [25 in. H<sub>2</sub>O]

## Exhaust System

Maximum Allowable Back Pressure Created by Piping and Silencer  
- Hg.....75 mm [3 in.]  
- H<sub>2</sub>O .....1016 mm [40 in.]  
Exhaust Pipe Size (Normally Acceptable Inside Diameter) .....102 mm [4 in.]

## Compressed Air System

### Single Cylinder Air Compressor

Cylinders .....1  
Compressor capacity @ 1250 RPM .....6.2 L per sec. [13.20 CFM]  
Piston displacement .....296 C.C. [18.6 C.I.D.]  
Bore .....92.08 mm [3.625 in.]  
Stroke.....44.45 mm [1.750 in.]  
Speed .....Engine speed  
Cooling.....Engine coolant  
Lubrication .....Engine lubricating oil

### Two-Cylinder Air Compressor

Cylinders .....2  
Compressor capacity @ 1250 RPM .....14.2 L per sec. [30.00 CFM]  
Piston displacement .....676 C.C. [41.3 C.I.D.]  
Bore .....92.08 mm [3.625 in.]  
Stroke.....50.8 mm [2.00 in.]  
Speed .....Engine speed  
Cooling.....Engine coolant  
Lubrication .....Engine lubricating oil

## Electrical System

System Voltage	Ambient Temperatures			
	-18°C [0°F]		0°C [32°F]	
	Cold Cranking Amperes	Reserve Capacity *	Cold Cranking Amperes	Reserve Capacity *
12 Volt	1800	640	1280	480
24 Volt**	900	320	640	240

\* The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time which sustained cranking can occur.

\*\* CCA ratings are based on two 12-volt batteries in series.

## Cummins/Fleetguard® Filter Specifications

Fleetguard is a subsidiary of Cummins Engine Company. Fleetguard filters are developed through joint testing at Cummins and Fleetguard. Fleetguard filters are standard on new Cummins engines. Cummins Engine Company recommends their use.

Fleetguard products meet all Cummins' Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, the purchaser should insist on products which the supplier has tested to meet Cummins' high quality standards.

Cummins cannot be responsible for problems caused by non-genuine filters which do not meet Cummins' performance or durability requirements.

## Fuel Recommendations/Specifications



**Warning:** Do not mix gasoline or alcohol with diesel fuel. This mixture can cause an explosion.

Cummins Engine Company, Inc. recommends the use of ASTM No. 2 D fuel. The use of No. 2 diesel fuel will result in optimum engine performance. At operating temperatures below 0°C [32°F], acceptable performance can be obtained by using blends of No. 2 D and No. 1 D. The use of lighter fuels can reduce fuel economy.

The viscosity of the fuel **must** be kept above 1.3 cSt to provide adequate fuel system lubrication.

For a more detailed description of fuel properties, refer to Fuel For Cummins Engines, Bulletin No. 3379001. See ordering information in the back of this manual.

## Lubricating Oil Recommendations/Specifications

The use of quality engine lubricating oils combined with appropriate oil drain and filter change intervals is a critical factor in maintaining engine performance and durability.

Cummins Engine Company, Inc. recommends the use of a high quality SAE 15W-40 heavy duty engine oil, such as Cummins Premium Blue, which meets the American Petroleum Institute (API) performance classification CE or CF-4.

**NOTE:** CD or CD/SF engine oils can be used in areas where CE and CF-4 oil is not yet available.

A sulfated ash limit of 1.0 mass percent will yield optimal control of valve and piston deposit, and will minimize oil consumption. The sulfated ash **must not** exceed 1.85 mass percent.

For further details and discussion of engine lubricating oils for Cummins engines, refer to Bulletin No. 3810340, Cummins Engine Oil Recommendations.

## New Engine Break-in Oils

Special "break-in" engine lubricating oils are **not** recommended for new or rebuilt Cummins engines. Use the same type oil during the "break-in" as that which is used in normal operation.




**Caution:** A sulfated ash limit of 1.85 percent has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash oils can cause valve and/or piston damage and lead to excessive oil consumption.

Additional information regarding lubricating oil availability throughout the world is available in the E.M.A. Lubricating Oils Data Book for Heavy Duty Automotive and Industrial Engines. The data book can be ordered from the Engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is: (312) 644-6610.


## Section V - Specifications and Torque Values L10

The use of low viscosity oils, such as 10W or 10W-30, can be used to aid in starting the engine and in providing sufficient oil flow at ambient temperatures below -5°C [23°F]. Continuous use of low viscosity oils can decrease engine life due to wear. Refer to the accompanying chart.


## Lubricating Oil Recommendations/Specifications Page V-5



The API service symbols are shown in the accompanying illustration. The upper half of the symbol displays the appropriate oil categories; the lower half can contain words to describe oil energy conserving features. The center section identifies the SAE oil viscosity grade.



As the engine oil becomes contaminated, essential oil additives are depleted. Lubricating oils protect the engine as long as these additives are functioning properly. Progressive contamination of the oil between oil and filter change intervals is normal. The amount of contamination will vary depending on the operation of the engine, kilometers or miles on the oil, fuel consumed, and new oil added.



Do **not** extend lubricating oil and filter change intervals unless the engine is operating with very low fuel consumption and high oil consumption. Extended oil and filter change intervals will decrease engine life due to factors such as: corrosion, deposits, and wear.

Use the following table to determine the oil drain interval for your application:

USE THE FOLLOWING OIL DRAIN INTERVALS FOR YOUR APPLICATION				
Vehicle/Equip.	KM	MILES	HRS	MOS
Truck Crane	10,000	6,000	250	6
Logging Truck	16,000	10,000	250	6
Mining Truck	N/A	N/A	250	6
Cranes	N/A	N/A	250	6
Backhoe	N/A	N/A	250	6
Dozer	N/A	N/A	250	6
Scraper	N/A	N/A	250	6
Skidder	N/A	N/A	250	6
Fram Tractors	N/A	N/A	250	6
Combines	N/A	N/A	250	6
Irrigation Equip.	N/A	N/A	250	6
Generator Set	N/A	N/A	250	6
Standby Generator	N/A	N/A	250	12
Air Compressor	N/A	N/A	250	6



## Coolant Recommendations/Specifications

Heavy duty diesel engines require a "heavy duty coolant". Heavy duty coolant is defined as a correct mixture of good quality water, low silicate antifreeze and supplemental coolant additives (SCA's).

The following pages will give an explanation of water, antifreeze, and SCA's, and the correct way to mix them. They will also explain how to test antifreeze and SCA levels.

This section also contains information on cooling system maintenance and a coolant treatment chart that is used to determine the correct DCA4 service filters and liquid pre-charge.

### Heavy Duty Coolant

#### Water

Water quality is important for cooling system performance. Excessive levels of calcium and magnesium contribute to scaling problems, and excessive levels of chlorides and sulfates cause cooling system corrosion.


Water Quality	
Calcium Magnesium (Hardness)	170 PPM as (CaCO <sub>3</sub> + MgCO <sub>3</sub> )
Chloride	40 PPM as (Cl)
Sulfur	100 PPM as (SO <sub>4</sub> )


#### Antifreeze

Cummins/Fleetguard® recommends using a low-silicate antifreeze concentrate that meets ASTM D4985 specifications (less than 0.10% silicate, expressed as Na<sub>2</sub>SiO<sub>3</sub>).




Low silicate antifreeze **must** be mixed with quality water at a 50/50 ratio (40 to 60% working range). A 50/50 mixture of antifreeze and water gives a -34° freeze point and a boiling point of 228°F, which is adequate for locations in North America. The actual lowest freeze point of ethylene glycol antifreeze is at 68%. Using higher concentrations of antifreeze will raise the freeze point of the solution and increase the possibility of silicate gel problem.






A refractometer **must** be used to accurately measure the freeze point of the coolant.




Do **not** use a floating ball hydrometer. Using floating ball hydrometers will give incorrect readings.



### Cooling System Sealing Additives

Do **not** use sealing additives in the cooling systems. The use of sealing additives will:

- build up in coolant low flow areas,
- clog coolant filters,
- plug radiator and oil cooler.



### Cooling System Soluble Oils

Do **not** use soluble oils in the cooling systems. The use of soluble oils will:


- allow cylinder liner pitting,
- corrode brass and copper,
- damage heat transfer surfaces, and
- damage seals and hoses.

## Coolant Blending/Mixing

Proper blending of **Heavy Duty Coolant** requires:

- Pour water into the container
- Add low-silicate antifreeze
- Add DCA4 liquid
- Thoroughly blend the components

Following the correct order for mixing the **Heavy Duty Coolant** will prevent additive dropout during the mixing process.



This chart, shown later in this document, **must** be followed to determine how much liquid SCA **must** be added to pre-charge different quantities of make-up coolant (water and low-silicate antifreeze). **Remember, a service filter must also be installed.**

In addition to using the chart as shown, the system requirements can also be calculated as shown in the following examples.

**NOTE:** It is important to know the cooling system capacity. If **not** sure of system capacity, contact the equipment OEM.

The following example illustrates how to calculate the required SCA quantity to add to the coolant to reach the desired concentration level.

When mixing 11 to 15 gallons of **Coolant**, 4 pints of DCA4 liquid **must** be added to obtain the correct SCA concentration level.

### Example:

$$15 \text{ gallons} \times 1.2 \text{ units per gallon} = 18 \text{ units}$$

$$18 \text{ units} \div 5 \text{ units per pint} = 3.6 \text{ pints DCA4}$$

For an 80-gallon system, three (3) gallons of DCA4 liquid **must** be added to pre-charge the coolant to the correct SCA concentration level.

### Example:

$$80 \text{ gallons} \times \frac{1.2 \text{ units}}{\text{gallon}} = 96 \text{ units}$$

$$96 \text{ units} \div \frac{20 \text{ units}}{1/2 \text{ gallons DCA4}} = 5 \text{ half gallon containers of DCA4}$$

or 2.5 gallons of DCA4



WHEN TESTED AT EVERY SUBSEQUENT OIL CHANGING INTERVAL

### COOLANT CAPACITY CHART

PRECHARGE 1.2 UNITS OF DCA4 PER GALLON OF COOLANT PLUS THE CORRECT SERVICE FILTER						SERV			
GALLONS OF COOLANT	DCA4 LIQUID GALLONS	DCA4 UNITS	DCA4 UNITS PER GAL.	MILES	HOURS	INSTALL A SERVICE FILTER WITH DCA4 UNITS SHOWN BELOW			
5 - 7	2 PINTS	10	1.4 - 2.0	25,000	825	2	4	8	12
8 - 11	3 PINTS	15	1.3 - 1.9	20,000	500	2	4	0	8
11 - 15	4 PINTS	20	1.3 - 1.9	15,000	375	2	4	4	6
16 - 20	5 PINTS	25	1.3 - 1.9	10,000	250	2	2	4	4
21 - 30	1.00	40	1.3 - 1.9	5,000	125	2	2	2	2
31 - 50	1.50	60	1.2 - 1.8						
51 - 75	2.25	90	1.2 - 1.8						
76 - 100	3.00	120	1.2 - 1.8						
101 - 150	4.50	180	1.2 - 1.8						
151 - 200	6.00	240	1.2 - 1.8						
201 - 300	7.50	300	1.2 - 1.8						
301 - 350	9.00	360	1.2 - 1.4						
351 - 400	10.50	420	1.2 - 1.4						
401 - 450	12.00	480	1.2 - 1.4						

SYSTEM SIZE IN GALLONS

PART NUMBER: WF2070    WF2071    WF2072    WF2073    WF2074  
UNITS OF DCA4: 2    4    6    8    12



## Fleetguard® DCA4 Service Filters and Liquid Pre-Charge

Fleetguard® Part No. DCA4 Spin-On Coolant Filters	Cummins Part No.	DCA4 Units
WF-2070	3318157	2
WF-2071	3315116	4
WF-2072	3318201	6
WF-2073	3315115	8
WF-2074	3316053	12
WF-2075	3318318	15
WF-2076	3318319	23
<b>DCA4 Liquid</b>		
DCA60L (1 pin)	3315459	5
DCA65L (1/2 gallon)	3305373	20
DCA75L (5 gallons)	3317428	200
DCA80L (55 gallons)		2200
<b>DCA4 Power</b>		
DCA95	3318320	20

## Coolant Capacity Charts

<b>PRECHARGE</b>			
Replace the service filter and add 1.2 units of DCA4 per gallon of coolant.			
GALLONS OF COOLANT	DCA4 LIQUID GALLONS	DCA4 UNITS	DCA4 UNITS PER GALLON
5 to 7	2 Pints	10	1.4 to 2.0
8 to 11	3 Pints	15	1.3 to 1.9
11 to 15	4 Pints	20	1.3 to 1.8
16 to 20	5 Pints	25	1.2 to 1.6
21 to 30	1.00	40	1.3 to 1.9
31 to 50	1.50	60	1.2 to 1.9
51 to 75	2.25	90	1.2 to 1.8
76 to 100	3.00	120	1.2 to 1.6
101 to 150	4.50	180	1.2 to 1.8
151 to 200	6.00	240	1.2 to 1.6
201 to 250	7.50	300	1.2 to 1.5
251 to 300	9.00	360	1.2 to 1.4
301 to 350	10.50	420	1.2 to 1.4
351 to 400	12.00	480	1.2 to 1.4





<b>SERVICE</b>								
System Size In Gallons	Install a Service Filter With DCA4 Units Shown Below					Gallons of Coolant	Add DCA4 Liquid Pints As Shown	
							250 Hours	500 Hours
0 to 5		2	2	2	2	21 to 30	2	3
6 to 10	2	2	4	4	4	31 to 50	3	5
11 to 15	2	4	4	6	8	51 to 75	4	8
16 to 20	2	4	6	8	12	76 to 100	5	10
	8000	16,000	24,000	32,000	40,000	101 to 150	8	15
	[5000]	[10,000]	[15,000]	[20,000]	[25,000]	151 to 200	10	20
	125	250	375	500	625	201 to 250	13	25
	Kilometers [Miles] or Hours					251 to 300	15	30
						301 to 350	18	35
						351 to 400	20	40
						8 PINTS EQUALS 1 U.S. GALLON		

### Notes:

- Consult the vehicle equipment manufacturer's maintenance information for total cooling system capacity.
- When draining and replacing the coolant, **always** pre-charge the cooling system to a SCA level of 1.5 units per gallon. This concentration level **must never** be allowed to go below 1.2 units and **must** be controlled when level is greater than 3 units. Action needed when the level goes below 1.2 is a filter and liquid pre-charge; from 1.2 to 3.0 units, filter only; above 3.0, test at every oil change until level falls to 3.0 or below.

**NOTE:** When performing service which requires draining the cooling system, take special precautions to collect it in a clean container, seal it to prevent contamination, and save for reuse.

- Change coolant filters at each oil change to protect the cooling system. Consult the coolant capacity chart to determine the correct coolant filter for a given cooling system capacity and oil drain interval.



## Supplemental Coolant Additives

Supplemental Coolant Additives (SCA's), or equivalent, are required to protect the cooling system from fouling, solder blooming, and general corrosion. The cooling filter is required to protect the coolant system from abrasive materials, debris, and precipitated coolant additives.

Supplemental Coolant Additives (or equivalent) are used to prevent liner pitting, corrosion, and scale deposits in the cooling system.

**NOTE:** Cummins Engine Company requires that a service filter be used and SCA liquid added when the coolant is changed or a significant (more than 50 percent) coolant loss occurs. A service filter **must** be used during the normal oil change interval.

After changing the coolant, the initial charge of SCA concentration **must** be 1.5 units per 3.8 liters [1 U.S. gallon] of coolant in the system.

**NOTE:** The cooling system **must** be clean before adding DCA4 (or equivalent).

**Caution:** Insufficient concentration of the coolant additives will result in liner pitting and engine failure.

The SCA concentration **must not** fall below 1.2 units or exceed 3 units per gallon of cooling system capacity.

If make-up coolant is added between intervals, additional SCA will be required. Any coolant added **must** be pre-mixed with SCA to a concentration of 1.2 units per 3.8 liters [1 U.S.A. gallon] of coolant. With the service filter installed, the total system concentration **must** be 1.5 units SCA per gallon of coolant.


## Section V - Specifications and Torque Values L10

Use the correct Fleetguard® coolant filter to maintain the recommended SCA concentration in the system.

Maintain the correct concentration by changing the service coolant filter at each oil drain interval.


**NOTE:** The correct filter is determined by the total cooling system capacity and oil drain interval.

## Supplemental Coolant Additives Page V-13



### Testing SCA Concentration Level CC-2626 Test Kit

Carefully follow the instructions to test the coolant and take the appropriate action recommended by the kit.



## Precautions

### Do

- Do carry out testing in a well-lighted area.
- Do make sure that hands are dry before removing strips from bottles.
- Do allow coolant sample to reach room temperature for best results.
- Do make sure that pad ends of strips are dipped.

Do replace and tighten caps on strip bottles to avoid getting moisture on strips.

Do make sure that all plastic containers are rinsed with water after each use to avoid contamination.

### Don't

- Don't handle pad ends of strip.
- Don't allow pad ends of wet strips to touch during testing.
- Don't get solution in eyes or on skin and clothing.

Don't allow contamination of the strips and solution bottles.

Don't allow contamination of the plastic containers during testing.

Don't use kits beyond expiration date.

## Instructions For Proper Kit Use

Any variation to the technique listed below will give false readings resulting in incorrect service action.

1. Fill large plastic cup at least half full with coolant. Allow the sample to reach room temperature.
2. With syringe, draw coolant sample to the stop point and dispense into small plastic container.
3. Hold small plastic container at eye level and fill to the black line with Solution #1, then swirl to mix. (Note: Many coolants will become cloudy at this point which is normal.)
4. Dip strip A into solution for 1 to 2 seconds, remove and shake vigorously to remove excess coolant. This action is much like shaking down a thermometer. Lay strip A down on a clean surface and read after reading strip B.
5. Dip strip B into solution for 1 to 2 seconds, shake vigorously, wait 30 seconds and match to nearest color on the test kit chart within the next 30 seconds. If **not** sure of exact color, read to the left or lower concentration.
6. Read strip A the same as strip B.
7. Determine the intersecting block of strips A and B on the chart, and follow requirements listed above under Testing DCA4.
8. Clean all plastic containers by rinsing cups and filling or flushing syringe with tap water after each use.

### When to Test

- When Not Sure of SCA Level
- Twice a Year
- When Over 3 Units Per Gallon of SCA

### Test Intervals

Testing is recommended if the operator is **not** sure of his cooling system condition due to leaks, uncontrolled topping off of the system, or major coolant loss.

Testing is also recommended twice a year to monitor the SCA level. If the SCA level is above 3 units, test at subsequent oil drain intervals until the concentration is back under 3 units. When the concentration is back under 3 units, start installing the correct service filters at each drain interval.



If the concentration is below 1.2 to 3 units per gallon, replace the filter.

### Below 1.2 Units

- Replace Service Filter
- Pre-charge With Liquid


If the concentration is above 3 units per gallon, do **not** replace the service filter. Test the coolant at subsequent oil drain intervals until the concentration is back under 3 units. When the concentration is back under 3 units, start installing service filters at each oil change interval.

### Above 3 Units

- Do Not Replace Service Filter
- Test at Every Oil Change

**NOTE:** Do **not** utilize the test kit to maintain minimum SCA concentration levels (i.e., 1.5 units).

**NOTE:** In some instances, the A or B reading can be high. However, it is the combined reading that is important. **So, always follow the chart.**



The following coolant testing devices are available to assist in determining the condition of the coolant:

**CC2626 Coolant Test Kit** — Works with any SCA formulation (Call 1-800-521-4005 if you have this test kit and the color chart does not show the number of units of DCA per gallon of coolant. A new chart will be mailed to you. The new chart will allow you to use your existing test kit with the new service requirements detailed on the reverse side of this paper.)


**Probalizer:**

**3318169S Plug** — Installs on the engine for easy coolant sampling  
**3318168S Cap** — Use with Monitor C bottle to sample coolant  
**CC2706 Monitor C** — Lab analysis of coolant samples

Call the following numbers to get answers to any questions you may have about cooling system maintenance.

**Cummins: 1-800-DIESELS**

**Fleetguard: 1-800-521-4005**



**Coolant Replacement Requirement**

Drain and flush the cooling system after 2 years, 6,000 hours, or 240,000 miles of service. Refill with new **Heavy Duty Coolant** and install the **correct service coolant filter**.

**NOTE:** If the coolant is **not** going to be reused, dispose of used coolant/antifreeze in accordance with federal, state, and local laws and regulations.

## Drive Belt Tension

To measure belt tension with a gauge, use the Belt Tension Chart to select the correct gauge for the belt width.

Belt Tension Specifications							
SAE Belt Size	Belt Tension Gauge		New Belt		*Used Belt		
	Part No.		Installation Tension		Tension Limits		
in.	Click-Type	Burroughs	N	lbf	N	min-max	lbf
.380	3822524	N/A	620	140	270 to 490		60 to 110
.440	3822524	N/A	620	140	270 to 490		60 to 110
1/2	3822524	ST-1138	620	140	270 to 490		60 to 110
11/16	3822524	ST-1138	620	140	270 to 490		60 to 110
3/4	3822524	ST-1138	620	140	270 to 490		60 to 110
7/8	3822524	ST-1138	620	140	270 to 490		60 to 110
4 Rib	3822524	ST-1138	620	140	270 to 490		60 to 110
5 Rib	3822524	ST-1138	670	150	330 to 530		75 to 120
6 Rib	3822525	ST-1293	710	160	400 to 580		90 to 130
8 Rib	3822525	ST-1293	890	200	530 to 710		120 to 160
10 Rib	3822525	3823138	1110	250	670 to 890		150 to 200
• 12 Rib	3822525	3823138	1330	300	800 to 1070		180 to 240

\* A belt is considered used if it has been in operation for 10 minutes or longer. If used belt tension is less than the minimum value, tighten the belt to the maximum value.

- Front-end loaders 12 Rib used belt tension limit is 890 to 1070 N [200 to 240 lbf].

**NOTE:** This chart does **not** apply to automatic belt tensioners.



## Engine Component Torque Value

Component	Wrench Size	Torque Value	
		N•m	ft-lb
Oil Pan Drain Plug	1-1/4 in.	88	65
Turbocharger Mounting Nuts	16 mm	68	50
Air Compressor Unloader Valve Capscrews	1/2 in.	14	10
Fan Drive Idler Pulley Shaft Locknut		165•190	120•140
Injector Adjusting Screw Locknut	3/4 in.	61	45
With Adapter, Part No. ST-669		47	35
Valve Adjusting Screw Locknut	3/4 in.	61	45
With Adapter, Part No. ST-669		47	35
Engine Brake Adjusting Screw Locknut		50	40
With Adapter ST-669		47	35
Fuel Pump Mounting Capscrews	7/16 in.	47	35
Fuel Pump Bracket to Cylinder Block	5/8 in.	47	35
Fuel Pump Bracket to Pump Housing	7/16 in.	11	95 in-lb
Rocker Lever Cover Capscrews	13 mm	15	130 in-lb
Injector Holddown Clamp Capscrews M10 x 1.50  M8 x 1.25		Step 1 - 6	55 in-lb
		2 - 12	110 in-lb
		3 - 19	165 in-lb
		Step 1 - 5	45 in-lb
		2 - 10	90 in-lb
		3 - 15	130 in-lb

## Arctic Operation

If an engine is operated in ambient temperatures consistently below -23°C [-10°F] and there are no provisions to keep the engine warm when it is **not** in operation, use a synthetic API CE or CF-4 engine oil with adequate low temperature properties such as 5W-20 or 5W-30.

The oil supplier **must** be responsible for meeting the performance service specifications.



**Caution:** The use of a synthetic base oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.



## Capscrew Markings and Torque Values



**Caution:** When replacing capscrews, always use a capscrew of the same measurement and strength as the capscrew being replaced. Using the wrong capscrews can result in engine damage.

Metric capscrews and nuts are identified by the grade number stamped on the head of the capscrew or on the surface of the nuts. U.S. Customary capscrews are identified by radial lines stamped on the head of the capscrew.

The following examples indicate how capscrews are identified:

Metric - M8-1.25 X 25		
M8	1.25	25
Major Thread Diameter in Millimeters	Distance Between Threads in Millimeters	Length in Millimeters







U.S. Customary [5/16 X 18 X 1-1/2]		
5/16	18	1-1/2
Major Thread Diameter in Inches	Number Threads per Inch	Length in Inches

### NOTES:

1. **Always** use the torque values listed in the following tables when specific torque values are **not** available.
2. Do **not** use the torque values in place of those specified in other sections of this manual.
3. The torque values in the table are based on the use of lubricated threads.
4. When the ft-lb value is less than 10, give consideration to converting the ft-lb value to in-lb to obtain a better torque with an in-lb torque wrench. Example: 6 ft-lb equals 72 in-lb.




## Capscrew Markings and Torque Values - Metric

### Commercial Steel Class

8.8		10.9		12.9	
Capscrew Head Markings					
					

Body Size Diam. mm	Torque				Torque				Torque			
	Cast Iron		Aluminum		Cast Iron		Aluminum		Cast Iron		Aluminum	
	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
6	9	5	7	4	12	9	7	4	14	9	7	4
7	14	9	11	7	18	14	11	7	23	18	11	7
8	25	18	18	14	33	25	18	14	40	29	18	14
10	45	33	30	25	60	45	30	25	70	50	30	25
12	80	60	55	40	105	75	55	40	125	95	55	40
14	125	90	90	65	165	122	90	65	195	145	90	65
16	180	130	140	100	240	175	140	100	290	210	140	100
18	230	170	180	135	320	240	180	135	400	290	180	135

## Capscrew Markings and Torque Values - U.S. Customary

SAE Grade Number		5				8			
Capscrew Head Markings									
These are all SAE Grade 5 (3) line									
									
Capscrew Body Size	Capscrew Torque - Grade 5 Capscrew				Capscrew Torque - Grade 8 Capscrew				
	Cast Iron		Aluminum		Cast Iron		Aluminum		
	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	
1/4 - 20	9	7	8	6	15	11	8	6	
- 28	12	9	9	7	18	13	9	7	
5/16 - 18	20	15	16	12	30	22	16	12	
- 24	23	17	19	14	33	24	19	14	
3/8 - 16	40	30	25	20	55	40	25	20	
- 24	40	30	35	25	60	45	35	25	
7/16 - 14	60	45	45	35	90	65	45	35	
- 20	65	50	55	40	95	70	55	40	
1/2 - 13	95	70	75	55	130	95	75	55	
- 20	100	75	80	60	150	110	80	60	
9/16 - 12	135	100	110	80	190	140	110	80	
- 18	150	110	115	85	210	155	115	85	
5/8 - 11	180	135	150	110	255	190	150	110	
- 18	210	155	160	120	290	215	160	120	
3/4 - 10	325	240	255	190	460	340	255	190	
- 16	365	270	285	210	515	380	285	210	
7/8 - 9	490	360	380	280	745	550	380	280	
- 14	530	390	420	310	825	610	420	310	
1 - 8	720	530	570	420	1100	820	570	420	
- 14	800	590	650	480	1200	890	650	480	



## NOTES



**Section S - Service Assistance**  
**Section Contents**

	Page
<b>Service Assistance</b> .....	S-2
Distributors - International .....	S-19
Distributors and Branches - Australia .....	S-13
Distributors and Branches - Canada .....	S-12
Distributors and Branches - New Zealand .....	S-15
Distributors and Branches - United States .....	S-5
Division and Regional Offices .....	S-4
Emergency Service .....	S-2
Problem Solving .....	S-3
Regional Offices - International .....	S-16
Routine Service .....	S-2



## Service Assistance


### Routine Service

Personnel at a Cummins Authorized Repair Location can assist you with the correct operation or service of your engine. We have a worldwide service network of more than 5,000 Cummins Distributors and Dealers who have been trained to provide sound advice, expert service, and complete parts support. Check the telephone directory yellow pages or refer to the directory in this section for the nearest Cummins Authorized Repair Location.

### Emergency Service

The Cummins Customer Relations Department provides a 24-hour, toll free telephone number to aid in locating emergency service when a local Cummins Authorized Repair Location can **not** be reached. The emergency service telephone numbers are:

- United States and Canada (excluding Alaska and Hawaii)
  - (800) D-I-E-S-E-L-S
  - (800) 343-7357
- Outside of North America contact your Regional Office. Telephone numbers and addresses are listed in this section.



## Problem Solving

Normally, any problem that arises with the sale, service, or repair of your engine can be handled by a Cummins Authorized Repair Location in your area. Refer to the telephone directory yellow pages for the one nearest you. If the problem has **not** been handled satisfactorily, follow the steps outlined below:

1. If the disagreement is with a Dealer, talk to the Cummins Distributor with whom he has his service agreement.
2. If the disagreement is with a Distributor, call the nearest Cummins Division or Regional Office; however, most problems are solved below the Division or Regional office level. Telephone numbers and addresses are listed in this section. Before calling, write down the following information:
  - a. Engine model and serial number
  - b. Type and make of equipment
  - c. Total kilometers [miles] or hours of operation
  - d. Warranty start date
  - e. Nature of problem
  - f. Summary of the current problem arranged in the order of occurrence
  - g. Name and location of the Cummins Distributor or Dealer
3. If a problem can **not** be resolved satisfactorily through your Cummins Authorized Repair Location or Division Office, write to:

Customer Relations - 41403, Cummins Engine Company, Inc., Box 3005, Columbus, IN 47202-3005



## Division and Regional Offices

**NOTE:** The following list contains offices in U.S., Canada, Australia, New Zealand, and Puerto Rico.

### United States

#### Northern Division Office

Cummins Engine Company, Inc.  
21 Southpark Blvd.  
Greenwood, IN 46143  
Telephone: (317) 885-4400

#### Southern Division Office

Cummins Engine Company, Inc.  
425 Franklin Road  
Suite 500  
Marietta, GA 30067  
Telephone: (404) 423-1108

#### Western Division Office

Cummins Engine Company, Inc.  
5660 Greenwood Plaza Blvd.  
Englewood, CO 80111  
Telephone: (303) 773-2866

#### Western Regional Office

Cummins Engine Company, Inc.  
569 First Street West  
Sonoma, CA 95476  
Telephone: (707) 935-3842

#### Plains Regional Office

Cummins Engine Company, Inc.  
1901 Central Drive  
Suite 356  
Bedford, TX 76021  
Telephone: (817) 267-3172

### Canada

#### Canadian Division Office

Cummins Diesel of Canada, Ltd.  
700 Dorval Drive  
Suite 600  
Oakville, Ontario L6K 3V3  
Telephone: (416) 842-8070

#### Western Canada Regional Office

Cummins Diesel of Canada, Ltd.  
18452 - 96th Avenue  
Surrey, B.C. V4N 3P8  
Telephone: (604) 882-5727

#### Eastern Canada Regional Office

Cummins Diesel of Canada Ltd.  
800 Montee DeLiesse  
Saint Laurent, Quebec H4T 1P3  
Telephone: (514) 342-4042

#### Central Canada Regional Office

Cummins Diesel of Canada Ltd.  
14755 - 121 A Avenue  
Edmonton, Alberta T5L 2T2  
Telephone: (403) 455-2151

### Australia Regional Office

#### Cummins Diesel Australia

2 Caribbean Drive  
Scoresby, Victoria 3179  
Australia  
Telephone: (61) 3-765-3222

**NOTE:** This office also serves New Zealand.

#### Cummins Americas Regional Office

#### Cummins Caribbean

16085 N. W. 52nd Avenue  
Hialeah, FL 33014  
Telephone: (305) 621-1300

**NOTE:** This office serves Puerto Rico and South America excluding Brazil.

## Distributors and Branches - United States

**Alabama****Birmingham Distributor**

Cummins Alabama, Inc.  
2200 Pinson Highway  
P.O. Box 1147  
Birmingham, AL 35201  
Telephone: (205) 841-0421

**Mobile Branch**

Cummins Alabama, Inc.  
1924 Beltline Highway,  
I-65 North  
P.O. Box 2566  
Mobile, AL 36601  
Telephone: (205) 456-2236

**Mobile Onan/Marine Branch**

Cummins Alabama, Inc.  
Cummins/Onan/Power Systems Center  
3422 Georgia Pacific Avenue  
Mobile, AL 36617  
Telephone: (205) 452-6426

**Montgomery Branch**

Cummins Alabama, Inc.  
2325 West Fairview Avenue  
P.O. Box 9271  
Montgomery, AL 36108  
Telephone: (205) 263-2594

**Alaska****Anchorage - (Branch of Seattle)**

Cummins Northwest, Inc.  
2618 Commercial Drive  
Anchorage, AK 99501-3095  
Telephone: (907) 279-7594

**Arizona****Phoenix Distributor and Branch**

Cummins Southwest, Inc.  
2239 North Black Canyon Hwy.  
P.O. Box 6688  
Phoenix, AZ 85005-6688  
Telephone: (602) 252-8021

**Phoenix Generator Branch**

Cummins Southwest, Inc.  
Power Systems Division  
2222 N. 23rd Drive  
Phoenix, AZ 85009  
Telephone: (602) 252-8021

**Tucson Branch**

Cummins Southwest, Inc.  
1912 West Prince Road  
Tucson, AZ 85705  
Telephone: (602) 887-7440

**Arkansas****Little Rock - (Branch of Memphis)**

Cummins Mid-South, Inc.  
6600 Interstate 30  
Little Rock, AR 72209  
Telephone: (Sales): (501) 569-5600  
(Service): (501) 569-5656  
(Parts): (501) 569-5613

**California****San Leandro Distributor**

Cummins West, Inc.  
1601 Aurora Drive  
San Leandro, CA 94577  
Telephone: (510) 351-6101

**Bakersfield Branch**

Cummins West, Inc.  
301 East Fourth Street  
Bakersfield, CA 93307  
Telephone: (805) 325-9404

**Hayward Distribution Center**

Cummins West, Inc.  
788 Sandoval Way  
Hayward, CA 94544  
Telephone: (510) 351-6101

**Los Angeles Distributor**

Cummins Cal Pacific Inc.  
1939 Deere Avenue (Irvine)  
Irvine, CA 92714  
Telephone: (714) 756-8700

**Montebello Branch**

Cummins Cal Pacific Inc.  
1105 South Greenwood Avenue  
Montebello, CA 90640  
Telephone: (213) 728-8111

**Rialto Branch**

Cummins Cal Pacific Inc.  
3061 S. Riverside Avenue  
Rialto, CA 92377  
Telephone: (909) 877-0433

**San Diego Branch**

Cummins Cal Pacific Inc.  
9191 Kearny Villa Court  
San Diego, CA 92123  
Telephone: (619) 278-4160

**San Leandro Branch**

Cummins West, Inc.  
1601 Aurora Drive  
San Leandro, CA 94577  
Telephone: (510) 351-6101

**West Sacramento Branch**

Cummins West, Inc.  
2661 Evergreen Avenue  
West Sacramento, CA 95691  
Telephone: (916) 371-0630

**Colorado****Denver Distributor**

Cummins Power, Inc.  
5100 East 58th Avenue  
Commerce City, CO 80022  
Telephone: (303) 287-0201

**Denver Generator Branch**

Gen Power, Inc.  
5720 Holly Street  
Unit A  
Commerce City, CO 80022  
Telephone: (303) 286-7697

**Grand Junction Branch**

Cummins Power, Inc.  
2380 U.S. Highway 6 & 50  
P.O. Box 339  
Grand Junction, CO 81501  
Telephone: (303) 242-5776

**Greeley Branch**

Cummins Power, Inc.  
250 Sixth Avenue  
Greeley, CO 80631  
Telephone: (303) 351-0448

**Connecticut****Hartford Distributor**

Cummins - Connecticut, Inc.  
260 Murphy Road  
Hartford, CT 06114  
Telephone: (203) 527-9156  
Parts: (203) 525-5606

**Florida****Tampa Distributor**

Cummins Southeastern Power, Inc.  
Corporate Office  
5421 N. 59th Street  
Tampa, FL 33610  
Telephone: (813) 621-7202

**Ft. Myers Branch**

Cummins Southeastern Power, Inc.  
2671 Edison Avenue, Unit #3  
Ft. Myers, FL 33916  
Telephone: (813) 337-1211

**Jacksonville Branch**

Cummins Southeastern Power, Inc.  
2060 West 21st Street  
P.O. Box 12036  
Jacksonville, FL 32209  
Telephone: (904) 355-3437

**Miami Branch**

Cummins Southeastern Power, Inc.  
9900 N.W. 77th Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**Orlando Branch**

Cummins Southeastern Power, Inc.  
4020 North  
Orange Blossom Trail  
Orlando, FL 32810  
Telephone: (407) 298-2080

**Tampa Branch**

Cummins Southeastern Power, Inc.  
5910 E. Hillsborough Avenue  
P. O. Box 11737  
Tampa, FL 33680  
Telephone: (813) 626-1101

**Georgia**

**Atlanta Distributor**

Cummins South, Inc.  
5125 Georgia Highway 85  
College Park, GA 30349  
Telephone: (404) 763-0151

**Albany Branch**

Cummins South, Inc.  
1915 W. Oakridge Drive  
Albany, GA 31707-4938  
Telephone: (912) 888-6210

**Atlanta Branch**

Cummins South, Inc.  
100 University Avenue, S.W.  
Atlanta, GA 30315-2202  
Telephone: (404) 527-7800

**Augusta Branch**

Cummins South, Inc.  
1255 New Savannah Road  
Augusta, GA 30901-3891  
Telephone: (706) 722-8825

**Dalton Branch**

Cummins South, Inc.  
204 Carbondale Road  
Dalton, GA 30720-5303  
Telephone: (706) 277-1144

**Savannah Branch**

Cummins South, Inc.  
8 Interchange Court  
Savannah, GA 31401-1627  
Telephone: (912) 232-5565

**Hawaii**

**Honolulu Distributor**

Cummins Hawaii Diesel Power, Inc.  
215 Puuhale Road  
Honolulu, HI 96819-2235  
Telephone: (808) 845-6606

**Idaho**

**Boise - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2851 Federal Way  
P.O. Box 5212  
Boise, ID 83705  
Telephone: (208) 336-5000

**Pocatello - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
14299 Highway 30 West  
Pocatello, ID 83201  
Telephone: (208) 234-1661

**Illinois**

**Chicago Distributor**

Cummins Northern Illinois, Inc.  
7145 Santa Fe Drive  
Hodgkins, IL 60525  
Telephone: (708) 579-9222

**Bloomington-Normal - (Branch of Indianapolis)**

Cummins Mid-States Power, Inc.  
P.O. Box 348  
(at U.S. 51 N and I-55)  
Bloomington-Normal, IL 61761  
Telephone: (309) 452-4454

**Harrisburg (Branch of St. Louis)**

Cummins Gateway, Inc.  
Rt. 4, Box 629  
Harrisburg, IL 62946  
Telephone: (618) 273-4138

**Rock Island - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
7820-42nd Street West  
Rock Island, IL 61204  
Telephone: (309) 787-4300

**Rockford Branch**

Cummins Northern Illinois, Inc.  
4617 Sandy Hollow Road  
Rockford, IL 61109  
Telephone: (815) 874-1700

**Indiana**

**Indianapolis Distributor**

Cummins Mid-States Power, Inc.  
P.O. Box 42917  
2421 Production Drive  
Indianapolis, IN 46242-917  
Telephone: (317) 243-7979

**Evansville - (Branch of Louisville)**

Cummins Cumberland, Inc.  
7901 Highway 41 N.  
Evansville, IN 47711  
Telephone: (812) 867-4400

**Ft. Wayne Branch**

Cummins Mid-States Power, Inc.  
3415 Coliseum Blvd. West  
(At Jct. I-69 & 30/33)  
Ft. Wayne, IN 46808  
Telephone: (219) 482-3691

**Gary - (Branch of Chicago)**

Cummins Northern Illinois, Inc.  
1440 Texas Street  
Gary, IN 46402  
Telephone: (219) 885-5591

**Indianapolis Branch**

Cummins Mid-States Power, Inc.  
P. O. Box 42917  
3621 West Morris Street  
Indianapolis, IN 46242-917  
Telephone: (317) 244-7251

**Linton Branch**

Cummins Mid-States Power, Inc.  
1244 N.E. A Street  
(Indiana Highway 54 East)  
Linton, IN 47441-0678  
Telephone: (812) 847-2201 and  
(812) 847-2202

**Zionsville Branch**

Cummins-Onan Power, Inc.  
5005 West 106th Street  
P.O. Box 668  
Zionsville, IN 46077  
Telephone: (317) 873-5005

**Iowa**

**Cedar Rapids - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
625 - 33rd Avenue SW  
P.O. Box 1107  
Cedar Rapids, IA 52406  
Telephone: (319) 366-7537 (24 hours)

**Des Moines - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
1680 N.E. 51st Avenue  
P.O. Box B  
Des Moines, IA 50313  
Telephone: (515) 262-9591  
Parts: (515) 262-9744  
(515) 262-9591 after midnight

**Des Moines - (Branch of Omaha)**

Midwestern Power Products  
Division of Cummins Great Plains  
Diesel, Inc.  
10100 Dennis Drive  
Des Moines, IA 50322  
Telephone: (515) 278-5521

**Kansas**

**Colby - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
1880 South Range  
Colby, KS 67701  
Telephone: (913) 462-3945  
(913) 462-3143

**Garden City - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
2008 West Mary  
Garden City, KS 67846  
Telephone: (316) 275-2277

**Olathe - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
11615 South Rogers Road (66062)  
P. O. Box 3108  
Olathe, KS 66063  
Telephone: (913) 469-5660

**Wichita - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
5101 North Broadway  
Wichita, KS 67219  
Telephone: (316) 838-0875

**Kentucky****Louisville Distributor**

Cummins Cumberland, Inc.  
(Corporate Office)  
304 Whittington Parkway  
Suite 200  
Louisville, KY 40222  
Telephone: (502) 426-9300

**Hazard Branch**

Cummins Cumberland, Inc.  
Highway 15 South  
P.O. Box 510  
Hazard, KY 41701  
Telephone: (606) 436-5718

**Louisville Branch**

Cummins Cumberland, Inc.  
9820 Bluegrass Parkway  
Louisville, KY 40299  
Telephone: (502) 491-4263

**Louisiana****Morgan City - (Branch of Memphis)**

Cummins Mid-South, Inc.  
Hwy. 90 East  
P.O. Box 1229  
Amelia, LA 70340  
Telephone: (504) 631-0576

**New Orleans - (Branch of Memphis)**

Cummins Mid-South, Inc.  
110 E. Airline Highway  
Kenner, LA 70062  
Telephone: (504) 468-3535

**Maine****Bangor (Branch of Boston)**

Cummins Northeast, Inc.  
142 Target Industrial Circle  
Bangor, ME 04401  
Telephone: (207) 941-1061

**Scarborough - (Branch of Boston)**

Cummins Northeast, Inc.  
10 Gibson Road  
Scarborough, ME 04074  
Telephone: (207) 883-8155

**Maryland****Baltimore Distributor**

Cummins Chesapeake, Inc.  
6120 Holabird Avenue  
Baltimore, MD 21224  
Telephone: (410) 633-5161

**Baltimore Branch**

Cummins Chesapeake  
3140 Washington Boulevard  
Baltimore, MD 21230-1090  
Telephone: (410) 644-6500

**Massachusetts****Boston Distributor**

Cummins Northeast, Inc.  
100 Allied Drive  
Dedham, MA 02026  
Telephone: (617) 329-1750

**West Springfield Branch**

Cummins Northeast, Inc.  
124 Ashley Avenue  
West Springfield, MA 01089  
Telephone: (413) 737-2659

**Michigan****Detroit Distributor**

Cummins Michigan, Inc.  
41216 Vincent Court  
Novi, MI 48375  
Telephone: (810) 478-9700

**Blissfield, Michigan**

Diesel Fuel Systems, Inc.  
211 N. Jipson Street  
Blissfield, MI 49228  
Telephone: (517) 486-4324

**Dearborn Branch**

Cummins Michigan, Inc.  
3760 Wyoming Avenue  
Dearborn, MI 48120  
Telephone: (810) 843-6200

**Grand Rapids Branch**

Cummins Michigan, Inc.  
3715 Clay Avenue, S.W.  
Grand Rapids, MI 49508  
Telephone: (616) 538-2250

**Grand Rapids Branch**

Standby Power, Inc.  
7580 Expressway Drive S.W.  
Grand Rapids, MI 49548  
Telephone: (616) 281-2211

**Iron Mountain - (Branch of De Pere)**

Cummins Great Lakes, Inc.  
P.O. Box 703  
1901 Stevenson Avenue  
Iron Mountain, MI 49801  
Telephone: (906) 774-2424  
(800) 236-2424

**Novi Branch**

Cummins Michigan, Inc.  
21500 Novi Road  
Novi, MI 48375  
Telephone: (810) 380-4300

**Saginaw Branch**

Cummins Michigan, Inc.  
722 N. Outer Drive  
Saginaw, MI 48605  
Telephone: (517) 752-5200

**Standby Power - (Branch of Detroit)**

Standby Power, Inc.  
12130 Dixie  
Redford, MI 48239  
Telephone: (810) 538-0200

**Minnesota****St. Paul Distributor**

Cummins Diesel Sales, Inc.  
2690 Cleveland Avenue North  
St. Paul, MN 55113  
(Mailing Address)  
P.O. Box 64578  
St. Paul, MN 55164  
Telephone: (612) 636-1000

**Duluth Branch**

Cummins Diesel Sales, Inc.  
3115 Truck Center Drive  
Duluth, MN 55806-1786  
Telephone: (218) 628-3641

**Hibbing Branch**

Cummins Diesel Sales, Inc.  
604 West 41st Street  
P.O. Box 159  
Hibbing, MN 55746  
Telephone: (218) 263-7558

**Mississippi****Jackson - (Branch of Memphis)**

Cummins Mid-South, Inc.  
325 New Highway 49 South  
P.O. Box 54224  
Jackson, MS 39288-4224  
Telephone: Admin.: (601) 932-7016  
Parts: (601) 932-2720  
Service: (601) 939-1800

**Missouri****Kansas City Distributor**

Cummins Mid-America, Inc.  
1760 Universal  
P.O. Box 4985  
Kansas City, MO 64120  
General Accounting Office  
Telephone: (816) 483-5070

**Kansas City Branch**

Cummins Mid-America, Inc.  
3527 Gardner Avenue  
Kansas City, MO 64120  
Telephone: (816) 483-6313

**Kansas City Fuel Systems Branch**

KC Diesel & Electric  
2810 Nicholson  
Kansas City, MO 64120  
Telephone: (816) 241-3400

**Joplin Branch**

Cummins Mid-America, Inc.  
3507 East 20th Street  
Joplin, MO 64801  
Telephone: (417) 623-1661

**Springfield Branch**

Cummins Mid-America, Inc.  
3637 East Kearney  
Springfield, MO 65803  
Telephone: (417) 862-0777

**St. Louis Distributor**

Cummins Gateway, Inc.  
7210 Hall Street  
St. Louis, MO 63147  
Telephone: (314) 389-5400

**Columbia Branch**

Cummins Gateway, Inc.  
5221 Highway 763 North  
Columbia, MO 65202-1028  
Telephone: (314) 449-3711

**Sikeston Branch**

Cummins Gateway, Inc.  
101 Keystone Drive  
Sikeston, MO 63801  
Telephone: (314) 472-0303

**Montana**

**Billings - (Branch of Denver)**

Cummins Power, Inc.  
5151 Midland Road  
P.O. Box 30377  
Billings, MT 59101  
Telephone: (406) 245-4194

**Great Falls - (Branch of Denver)**

Cummins Power, Inc.  
415 Vaughn Road (59404)  
P.O. Box 1199  
Great Falls, MT 59403  
Telephone: (406) 452-8561

**Missoula - (Branch of Seattle)**

Cummins Northwest, Inc.  
4950 North Reserve Street  
Missoula, MT 59802-1498  
Telephone: (406) 728-1300

**Nebraska**

**Omaha Distributor and Branch**

Cummins Great Plains Diesel, Inc.  
5515 Center Street  
P.O. Box 6068  
Omaha, NE 68106  
Telephone: (402) 551-7678 (24 hours) or  
(402) 493-4656

**Kearney Branch**

Cummins Great Plains Diesel, Inc.  
515 Central Avenue  
P.O. Box 1326  
Kearney, NE 68847  
Telephone: (308) 234-1994

**Nevada**

**Elko - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
5370 East Idaho Street  
Elko, NV 89801  
Telephone: (702) 738-6405

**Las Vegas - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2750 Losee Road  
North Las Vegas, NV 89036  
Telephone: (702) 399-2339  
(Mailing Address:)  
P. O. Box 3997  
North Las Vegas, NV 89036-3998

**Sparks - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
150 Glendale Avenue  
Sparks, NV 89431  
Telephone: (702) 331-4983

**New Jersey**

**Newark - (Branch of Bronx)**

Cummins Metropower, Inc.  
Routes U.S. 1 & 22  
Newark, NJ 07114  
Telephone: (201) 242-2255

**New Mexico**

**Albuquerque - (Branch of Phoenix)**

Cummins Southwest, Inc.  
1921 Broadway N.E.  
Albuquerque, NM 87102  
Telephone: (505) 247-2441

**Farmington - (Branch of Phoenix)**

Cummins Southwest, Inc.  
1101 North Troy King Road  
Farmington, NM 87401  
Telephone: (505) 327-7331

**New York**

**Bronx Distributor**

Cummins Metropower, Inc.  
890 Zerega Avenue  
Bronx, NY 10473  
Telephone: (718) 892-2400

**Albany - (Branch of Boston)**

Cummins Northeast, Inc.  
101 Railroad Avenue  
Albany, NY 12205  
Telephone: (518) 459-1710

**Buffalo - (Branch of Boston)**

Cummins Northeast, Inc.  
480 Lawrence Bell Dr.  
Williamsville, NY 14221-7090  
Telephone: (716) 631-3211

**Syracuse - (Branch of Boston)**

Cummins Northeast, Inc.  
29 Eastern Avenue  
Syracuse, NY 13211  
Telephone: (315) 437-2751

**North Carolina**

**Charlotte Distributor**

Cummins Atlantic, Inc.  
11101 Nations Ford Road  
P.O. Box 240729  
Charlotte, NC 28224-0729  
Telephone: (704) 588-1240

**Charlotte Branch**

Cummins Atlantic, Inc.  
3700 North Interstate 85  
Charlotte, NC 28206  
Telephone: (704) 596-7690

**Greensboro Branch**

Cummins Atlantic, Inc.  
513 Preddy Boulevard  
P.O. Box 22066  
Greensboro, NC 27420-2066  
Telephone: (919) 275-4531

**Wilson Branch**

Cummins Atlantic, Inc.  
1514 Cargill Avenue  
P.O. Box 1177  
Wilson, NC 27894-1117  
Telephone: (919) 237-9111

**North Dakota**

**Fargo - (Branch of St. Paul)**

Cummins Diesel Sales, Inc.  
4050 West Main Avenue (58103)  
P.O. Box 2111  
Fargo, ND 58107  
Telephone: (701) 282-2466

**Grand Forks - (Branch of St. Paul)**

Cummins Diesel Sales, Inc.  
4728 Gateway Drive  
P.O. Box 636  
Grand Forks, ND 58201  
Telephone: (701) 775-8197  
(701) 772-7689 after 12:30 a.m.

**Minot - (Branch of St. Paul)**

Cummins Diesel Sales, Inc.  
1501 - 20th Avenue, S.W.  
P.O. Box 1179  
Minot, ND 58702  
Telephone: (701) 852-3585  
(701) 839-3417 after 12:30 a.m.



**Ohio****Columbus Distributor and Branch**

Cummins Ohio, Inc.  
4000 Lyman Drive  
Hilliard (Columbus), OH 43026  
Telephone: (614) 771-1000

**Akron Branch**

Cummins Ohio, Inc.  
1033 Kelly Avenue  
Akron, OH 44306  
Telephone: (216) 773-7821

**Cincinnati Branch**

Cummins Ohio, Inc.  
10470 Evendale Drive  
Cincinnati, OH 45241  
Telephone: (513) 563-6670

**Cincinnati Branch**

Cummins Ohio, Inc.  
Power Systems Division  
10660 Evendale Drive  
Cincinnati, OH 45241  
Telephone: (513) 563-9303

**Cleveland Branch**

Cummins Ohio, Inc.  
7585 Northfield Road  
Cleveland, OH 44146  
Telephone: (216) 439-6800

**Lima Branch**

Cummins Ohio, Inc.  
960 Broadway  
Lima, OH 45804  
Telephone: (419) 227-2641

**Strasburg Branch**

Cummins Ohio, Inc.  
777 South Wooster Avenue  
Box 136  
Strasburg, OH 44680  
Telephone: (216) 878-5511  
After hours: (216) 364-1433

**Toledo Branch**

Cummins Ohio, Inc.  
801 Illinois Avenue  
Maumee  
(Toledo), OH 43537  
Telephone: (419) 893-8711

**Youngstown Branch**

Cummins Ohio, Inc.  
7145 Masury Road  
Hubbard  
(Youngstown), OH 44425  
Telephone: (216) 534-1935

**Oklahoma****Duncan - (Branch of Arlington)**

Cummins Southern Plains, Inc.  
1400 East Bois D'Arc  
P.O. Box 310  
Duncan, OK 73534-0310  
Telephone: (405) 255-1414 (24 hours)

**Oklahoma City - (Branch of Arlington)**

Cummins Southern Plains, Inc.  
5800 West Reno  
P.O. Box 1636  
Oklahoma City, OK 73101-1636  
Telephone: (405) 946-4481 (24 hours)

**Tulsa - (Branch of Arlington)**

Cummins Southern Plains, Inc.  
9725 E. Admiral Place  
P.O. Box 471616  
Tulsa, OK 74116-2527  
Telephone: (918) 838-2555 (24 hours)

**Oregon****Bend - (Branch of Seattle)**

Cummins Northwest, Inc.  
3500 N. Highway 97 (97701-5729)  
P.O. Box 309  
Bend, OR 97709-0309  
Telephone: (503) 389-1900

**Coburg/Eugene - (Branch of Seattle)**

Cummins Northwest, Inc.  
91201 Industrial Parkway  
Coburg, OR 97401  
(Mailing Address)  
P.O. Box 10877  
Eugene, OR 97440-2887  
Telephone: (503) 687-0000

**Medford - (Branch of Seattle)**

Cummins Northwest, Inc.  
4045 Crater Lake Highway  
Medford, OR 97504-9796  
Telephone: (503) 779-0151

**Pendleton - (Branch of Seattle)**

Cummins Northwest, Inc.  
223 S.W. 23rd Street  
Pendleton, OR 97801-1810  
Telephone: (503) 276-2561

**Portland - (Corporate Branch of Seattle)**

Cummins Northwest, Inc.  
4711 N. Basin Avenue  
P. O. Box 2710 (97208-2710)  
Portland, OR 97217-3557  
Telephone: (503) 289-0900

**Portland - (Branch of Seattle)**

Cummins Northwest, Inc.  
4711 N. Basin Avenue  
P. O. Box 2710 (97208-2710)  
Portland, OR 97217-3557  
Telephone: (503) 289-0900

**Pennsylvania****Philadelphia Distributor**

Cummins Diesel Engines, Inc.  
2727 Ford Road  
Bristol, PA 19007-6895  
Telephone: (215) 785-6005

**Bristol Onan Branch**

Keystone Onan Power, Inc.  
2727 Ford Road  
Bristol, PA 19007-6895  
Telephone: (215) 785-6005

**Clearfield Branch**

Cummins Diesel Engines, Inc.  
Clearfield Parts Center  
501 Williams Street  
Clearfield, PA 16830  
Telephone: (814) 765-2421

**Harrisburg Branch**

Cummins Diesel Engines, Inc.  
4499 Lewis Road  
Harrisburg, PA 17111  
Telephone: (717) 564-1344

**Harrisburg Onan Branch**

Keystone Onan Power, Inc.  
1549 Bobali Drive  
Harrisburg, PA 17104-3208  
Telephone: (717) 986-9126

**Monroeville Branch**

Cummins Diesel Engines, Inc.  
2740 Mossdale Boulevard  
Monroeville, PA 15146  
Telephone: (412) 856-6700

**Puerto Rico****Catano**

Cummins Diesel Power, Inc.  
Calle C #31 El Matadero  
Puerto Nuevo, Puerto Rico 00920  
Telephone: (809) 793-0300

**South Carolina****Charleston - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
3028 West Montague Avenue  
Charleston, SC 29418-5593  
Telephone: (803) 554-5112

**Charleston - (Onan Branch of Charlotte)**

Cummins Atlantic, Inc.  
Atlantic Power Generation  
3028 West Montague Avenue  
Charleston, SC 29418  
Telephone: (803) 554-9804

**Columbia - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
1233 Bluff Road  
P.O. Box 13543  
Columbia, SC 29201-3543  
Telephone: (803) 799-2410

**South Dakota****Sioux Falls - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
701 East 54th Street North  
Sioux Falls, SD 57104  
Telephone: (605) 336-1715  
(605) 334-6492

## Tennessee

### Memphis Distributor & Distribution Center

Cummins Mid-South, Inc.  
666 Riverside Drive  
P.O. Box 3080  
Memphis, TN 38103  
Telephone: (901) 577-0666

### Chattanooga - (Branch of Atlanta)

Cummins South, Inc.  
1509 East 26th Street  
Chattanooga, TN 37407-1095  
Telephone: (615) 629-1447

### Knoxville - (Branch of Louisville)

Cummins Cumberland, Inc.  
1211 Ault Road  
Knoxville, TN 37914  
Telephone: (615) 523-0446

### Memphis Branch

Cummins Mid-South, Inc.  
1784 E. Brooks Road  
Memphis, TN 38116  
Telephone:  
Sales/Admin.: (901) 345-7424  
Parts: (901) 345-1784  
Service: (901) 345-6185

### Nashville - (Branch of Louisville)

Cummins Cumberland, Inc.  
706 Spence Lane  
Nashville, TN 37217  
Telephone: (615) 366-4341

## Texas

### Arlington Distributor

Cummins Southern Plains, Inc.  
600 N. Watson Road  
P.O. Box 90027  
Arlington, TX 76004-3027  
Telephone: (817) 640-6801 (24 hours)

### Amarillo Branch

Cummins Southern Plains, Inc.  
5224 Interstate 40 -  
Expressway East  
P.O. Box 31570  
Amarillo, TX 79120-1570  
Telephone: (806) 373-3793 (24 hours)

### Corpus Christi Branch

Cummins Southern Plains, Inc.  
1302 Corn Products Road  
P.O. Box 48  
Corpus Christi, TX 78403-0048  
Telephone: (512) 289-0700 (24 hours)

### Dallas Branch

Cummins Southern Plains, Inc.  
3707 Irving Boulevard  
Dallas, TX 75247  
Telephone: (214) 631-6400 (24 hours)

### El Paso - (Branch of Phoenix)

Cummins Southwest, Inc.  
14333 Gateway West  
El Paso, TX 79927  
Telephone: (915) 852-4200

## Fort Worth Branch

Cummins Southern Plains, Inc.  
3250 North Freeway  
Fort Worth, TX 76111  
Telephone: (817) 624-2107 (24 hours)

## Houston Branch

Cummins Southern Plains, Inc.  
4750 Homestead Road  
P.O. Box 1367  
Houston, TX 77251-1367  
Telephone: (713) 675-7421 (24 hours)

## Mesquite Branch

Cummins Southern Plains, Inc.  
2615 Big Town Blvd.  
Mesquite, TX 75150  
Telephone: (214) 321-5555 (24 hours)

## Odessa Branch

Cummins Southern Plains, Inc.  
1210 South Grandview  
P.O. Box 633  
Odessa, TX 79760-0633  
Telephone: (915) 332-9121 (24 hours)

## San Antonio Branch

Cummins Southern Plains, Inc.  
6226 Pan Am Expressway North  
P.O. Box 18385  
San Antonio, TX 78218-0385  
Telephone: (512) 655-5420 (24 hours)

## Utah

### Salt Lake City Distributor

Cummins Intermountain, Inc.  
1030 South 300 West  
P.O. Box 25428  
Salt Lake City, UT 84125  
Telephone: (801) 355-6500

### Vernal Branch

Cummins Intermountain, Inc.  
1435 East 335 South  
P.O. Box 903  
Vernal, UT 84078  
Telephone: (801) 789-5732

## Virginia

### Bristol - (Branch of Louisville)

Cummins Cumberland, Inc.  
400 Stage Coach Road  
1-81 at Old Airport Road  
Bristol, VA 24201  
Telephone: (703) 669-4200

### Norfolk - (Branch of Charlotte)

Cummins Atlantic, Inc.  
Atlantic Power Generation  
1114 Ballentine Blvd.  
Norfolk, VA 23504  
Telephone: (804) 627-9470

### Richmond - (Branch of Charlotte)

Cummins Atlantic, Inc.  
3900 Deepwater Terminal Road  
Richmond, VA 23234  
Telephone: (804) 232-7891

## Roanoke - (Branch of Charlotte)

Cummins Atlantic, Inc.  
5307 Peters Creek Road  
P.O. Box 7237  
Roanoke, VA 24019-7237  
Telephone: (703) 362-1673

## Washington

### Seattle Distributor

Cummins Northwest, Inc.  
811 S.W. Grady Way (98055-2944)  
P.O. Box 9811  
Renton, WA 98057-9811  
Telephone: (206) 235-3400

### Chehalis Branch

Cummins Northwest, Inc.  
1200 N.W. Maryland  
Chehalis, WA 98532-1813  
Telephone: (206) 748-8841

### Spokane Branch

Cummins Northwest, Inc.  
E. 3904 Trent Avenue (99202-4471)  
P.O. Box 2746 -  
Terminal Annex  
Spokane, WA 99220-2746  
Telephone: (509) 534-0411

### Tacoma Branch

Cummins Northwest, Inc.  
3701 Pacific Highway East  
Tacoma, WA 98424-1135  
Telephone: (206) 922-2191

### Yakima Branch

Cummins Northwest, Inc.  
1905 East Central Avenue (98901-3609)  
P.O. Box 9129  
Yakima, WA 98909-0129  
Telephone: (509) 248-9033

## West Virginia

### Charleston - (Branch of Louisville)

Cummins Cumberland, Inc.  
Charleston Ordnance Center  
P.O. Box 8456  
South Charleston, WV 25303  
Telephone: (304) 744-6373

### Fairmont - (Branch of Louisville)

Cummins Cumberland, Inc.  
South Fairmont Exit, I-79  
145 Middletown Road  
Fairmont, WV 26554  
Telephone: (304) 367-0196

## Wisconsin

### DePere Distributor

Cummins Great Lakes, Inc.  
875 Lawrence Drive  
(Mailing Address)  
P.O. Box 530  
DePere (Green Bay), WI 54115  
Telephone: (414) 337-1991

**Chippewa Falls Branch**

Cummins Great Lakes, Inc.  
Route #7  
Box Number 88  
Chippewa Falls (Eau Claire), WI 54729  
Telephone: (715) 832-4329

**DePere Branch**

Cummins Great Lakes, Inc.  
939 Lawrence Drive  
(Mailing Address)  
P. O. Box 530  
DePere (Green Bay), WI 54115  
Telephone: (414) 336-9631

**Milwaukee Branch**

Cummins Great Lakes, Inc.  
9401 South 13th Street  
P.O. Box D  
Oak Creek, WI 53154  
Telephone: (414) 768-7400  
(800) 472-8283

**Wausau Branch**

Cummins Great Lakes, Inc.  
4703 Rib Mountain Drive  
Wausau, WI 54401  
Telephone: (715) 359-6888  
(800) 236-3744

**Wyoming**

**Gillette - (Branch of Denver)**

Cummins Power, Inc.  
2700 Hwy. 14 & 16 North  
P.O. Box 1207 (82717)  
Gillette, WY 82716  
Telephone: (307) 682-9611

**Rock Springs - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2000 Foothill Blvd.  
P.O. Box 1634  
Rock Springs, WY 82901  
Telephone: (307) 362-5168



## Distributors and Branches - Canada

### Alberta

#### Edmonton Distributor

Cummins Alberta  
14755 - 121A Avenue  
Edmonton, Alberta T5L 2T2, Canada  
Telephone: (403) 455-2151

#### Calgary Branch

Cummins Alberta  
4887 - 35th Street S.E.  
Calgary, Alberta T2B 3H6, Canada  
Telephone: (403) 569-1122

#### Hinton Branch

Cummins Alberta  
135 Veats Avenue  
Hinton, Alberta T7V 1S8, Canada  
Telephone: (403) 865-5111

#### Lethbridge Branch

Cummins Alberta  
240 - 24th Street North  
Lethbridge, Alberta T1J 3T8, Canada  
Telephone: (403) 329-6144

### British Columbia

#### Vancouver Distributor

Cummins British Columbia  
18452-96 Avenue  
Surrey, B.C.  
V4N 3P8  
Telephone: (604) 882-5000

#### Kamloops Branch

Cummins British Columbia  
976 Laval Crescent  
Kamloops, B.C. Canada V2C 5P5  
Telephone: (604) 828-2388

#### Prince George Branch

Cummins British Columbia  
1378 - 5th Avenue  
Prince George, B.C. V2L 3L4  
Telephone: (604) 564-9111

#### Sparwood Branch

Cummins British Columbia  
731 Douglas Fir Road  
Sparwood, B.C. V0B 2G0, Canada  
Telephone: (604) 425-0522

#### Tumbler Ridge Branch

Cummins British Columbia  
Industrial Site, Box 226  
Tumbler Ridge, B.C.  
Canada V0C 2W0  
Telephone: (604) 242-4217

### Manitoba

#### Winnipeg Distributor

Cummins Mid-Canada Ltd.  
489 Oak Point Road  
P.O. Box 1860  
Winnipeg, MB R3C 3R1, Canada  
Telephone: (204) 632-5470

### New Brunswick

#### Fredericton - (Branch of Montreal)

Diesel Cummins  
Branch of Cummins Americas, Inc.  
R.R. #1, Doak Road  
Fredericton,  
New Brunswick E3B 4X2, Canada  
Telephone: (506) 451-1929

### Newfoundland

#### St. John's - (Branch of Montreal)

Cummins Diesel  
Branch of Cummins Americas, Inc.  
122 Clyde Avenue  
Donovans Industrial Park  
Mount Pearl, Newfoundland A1N 4S3  
Canada  
Telephone: (709) 747-0176

#### Wabush - (Branch of Montreal)

Cummins Diesel  
Branch of Cummins Americas, Inc.  
Wabush Industrial Park  
Wabush, Newfoundland A0R 1B0  
Telephone: (709) 282-3626

### Nova Scotia

#### Halifax - (Branch of Montreal)

Cummins Diesel  
Branch of Cummins Americas, Inc.  
50 Simmonds Drive  
Dartmouth, Nova Scotia B3B 1R3  
Telephone: (902) 468-7938

### Ontario

#### Toronto Distributor

Cummins Ontario Inc.  
Corporate Office & Parts Distribution  
Centre  
301 Wyecroft Road  
Oakville, Ontario L6K 2H2, Canada  
Telephone: (416) 844-5851

#### Toronto Branch

Cummins Ontario Inc.  
150 N. Queen Street  
Etobicoke, Ontario M9C 1A8  
P.O. Box 40, Station "U"  
Toronto, Ontario M8Z 5N1  
Telephone: (416) 621-9921

#### Ottawa Branch

Cummins Ontario Inc.  
3189 Swansea Crescent  
Ottawa, Ontario K1G 3W5, Canada  
Telephone: (613) 736-1146

#### Thunder Bay Branch

Cummins Ontario Inc.  
1400 W. Walsh Street  
Thunder Bay  
Ontario P7E 4X4  
Telephone: (807) 577-7561

### Whitby Branch

Cummins Ontario Inc.  
1311 Hopkins Street  
Whitby, Ontario L1N 2C2, Canada  
Telephone: (416) 668-6886

### Quebec

#### Montreal Distributor

Cummins Diesel  
Branch of Cummins Americas, Inc.  
7200 Trans Canada Highway  
Pointe Claire, Quebec H9R 1C2, Canada  
Telephone: (514) 695-8410

#### Montreal Branch

Cummins Diesel  
Branch of Cummins Americas, Inc.  
7200 Trans Canada Highway  
Pointe Claire, Quebec H9R 1C2, Canada  
Telephone: (514) 695-8410  
Sales: (514) 694-5143  
Parts: (514) 694-5880

#### Quebec City Branch

Cummins Diesel  
Branch of Cummins Americas, Inc.  
2400 Watt Street  
Ste. Foy, Quebec G1P 3T3, Canada  
Telephone: (418) 651-2911

### Saskatchewan

#### Lloydminster - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.  
3709 - 44th Street  
P.O. Box 959  
Lloydminster, SK S9V 0Y9, Canada  
Telephone: (306) 825-2062

#### Regina - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.  
110 Kress Street  
P.O. Box 98  
Regina, SK S4P 2Z5, Canada  
Telephone: (306) 721-9710

#### Saskatoon - (Branch of Winnipeg)

Cummins Mid-Canada, Ltd.  
3001 Faithful Avenue  
P.O. Box 7679  
Saskatoon, SK S7K 4R4, Canada  
Telephone: (306) 933-4022

**Distributors and Branches - Australia****Sydney (Lansvale)**

Cummins Diesel Sales & Service  
P.O. Box 150  
Cambramatta, 2166  
New South Wales, Australia

Location:  
164-170 Hume Highway  
Lansvale, 2166, Australia

Telephone: (61-2) 728-6211

**Branches:****Adelaide**

Cummins Diesel Sales & Service  
P.O. Box 108  
Blair Athol, 5084  
South Australia, Australia

Location:  
45-49 Cavan Road  
Gepps Cross, 5094

Telephone: (61-8) 262-5211

**Brisbane**

Cummins Diesel Sales & Service  
P.O. Box 124  
Darra, 4076  
Queensland, Australia

Location:  
33 Kimberley Street  
Darra, 4076, Australia

Telephone: (61-7) 375-3277

**Cairns**

Cummins Diesel Sales & Service  
P.O. Box 7189  
Cairns Mail Centre, 4870  
Queensland, Australia

Location:  
Cnr. Toohey & Knight Streets  
Portsmith, Cairns, 4870

Telephone: (61-70) 35-1400

**Campbellfield**

Cummins Diesel Sales & Service  
Private Bag 9  
Campbellfield, 3061  
Victoria, Australia

Location:  
1788-1800 Hume Highway  
Campbellfield, 3061

Telephone: (613) 357-9200

**Dandenong**

Cummins Diesel Sales & Service  
Lot 7 Greens Road  
Dandenong, 3175  
Victoria, Australia  
Telephone: (613) 706-8088

**Darwin**

Cummins Diesel Sales & Service  
P.O. Box 37587  
Winnellie, 0821  
Northern Territory, Australia

Location:  
Lot 1758 Graffin Crescent  
Winnellie, 0821

Telephone: (61-89) 47-0766

**Devonport**

Cummins Diesel Sales & Service  
P.O. Box 72E  
Tasmania, Australia

Location:  
2 Matthews Way  
Devonport, 7310

Telephone: (61-04) 24-8800

**Emerald**

Cummins Diesel Sales & Service  
P.O. Box 668  
Emerald, 4720  
Queensland, Australia

Location:  
Capricorn Highway  
Emerald, 4720

Telephone: (61-79) 82-4022

**Grafton**

Cummins Diesel Sales & Service  
P.O. Box 18  
South Grafton, 2461  
New South Wales, Australia

Location:  
18-20 Induna Street  
South Grafton, 2461

Telephone: (61-66) 42-3655

**Hexham**

Cummins Diesel Sales & Service  
21 Galleghan Street  
Hexham, 2322  
New South Wales, Australia  
Telephone: (61-49) 64-8466

**Kalgoorlie**

Cummins Diesel Sales & Service  
P.O. Box 706  
Kalgoorlie, 6430  
Western Australia, Australia

Location:  
16 Atbara Street  
Kalgoorlie, 6430

Telephone: (61-90) 21-2588 or 21-2994

**Mackay**

Cummins Diesel Sales & Service  
P.O. Box 842  
Mackay, 4740  
Queensland, Australia

Location:  
4 Presto Avenue  
Mackay, 4746

Telephone: (61-79) 55-1222

**Mount Gambier**

Cummins Diesel Sales & Service  
P.O. Box 2219  
Mount Gambier, 5290  
South Australia, Australia

Location:  
2 Avey Road  
Mount Gambier, 5290

Telephone: (61-87) 25-6422

**Penrith**

Cummins Diesel Sales & Service  
P.O. Box 132  
Cambridge Park, 2747  
New South Wales, Australia

Location:  
7 Andrews Road  
Penrith, 2750

Telephone: (61-47) 29-1313

**Queanbeyan**

Cummins Diesel Sales & Service  
P.O. Box 527  
Queanbeyan, 2620  
New South Wales, Australia

Location:  
15-27 Bayldon Road  
Queanbeyan, 2620

Telephone: (61-62) 97-3433

**Swan Hill**

Cummins Diesel Sales & Service  
P.O. Box 1264  
Swan Hill, 3585  
Victoria, Australia

Location:  
5 McAllister Road  
Swan Hill, 3585

Telephone: (61-50) 32-1511

**Tamworth**

Cummins Diesel Sales & Service  
P.O. Box 677  
Tamworth, 2320  
New South Wales, Australia

Location:  
Lot 65 Gunnedah Road  
Tamworth, 2340

Telephone: (61-67) 65-5455

**Welshpool**

Cummins Diesel Sales & Service  
P. O. Box 52  
Welshpool, 6986  
Western Australia, Australia

**Location:**

50 Kewdale Road  
Welshpool, 6106

Telephone: (61-9) 458-5911

**Wodonga**

Cummins Diesel Sales & Service  
P.O. Box 174  
Wodonga, 3690  
Victoria, Australia

**Location:**

9-11 McKoy Street  
Wodonga, 3690

Telephone: (61-60) 24-3655

## Distributors and Branches - New Zealand

### Auckland

Cummins Diesel Sales & Service (NZ)  
Ltd.  
Private Bag 92804  
Penrose, Auckland, New Zealand

Location:  
440 Church Street  
Penrose

Telephone: (64-9) 579-0085

### Branches:

#### Auckland

Cummins Diesel Engines  
Private Bag 92804  
Penrose, Auckland, New Zealand

Location:  
440 Church Street  
Penrose

Telephone: (64-9) 579-0085

#### Christchurch

Cummins Diesel Engines  
P.O. Box 16-149  
Hornby, Christchurch, New Zealand

Location:  
35 Parkhouse Road  
Sockburn, Christchurch

Telephone: (64-3) 348-8170

#### Mt. Maunganui

Cummins Diesel Engines  
P.O. Box 4005  
Mt. Maunganui, New Zealand

Location:  
101 Totara Street  
Mt. Maunganui

Telephone: (64-7) 575-0545

#### Palmerston North

Cummins Diesel Engines  
P.O. Box 9024  
Palmerston North, New Zealand

Location:  
852-860 Tremain Avenue  
Telephone: (64-6) 356-2209



**Regional Offices - International**

**North Africa Regional Office - Algiers**

Cummins Corporation  
Bureau de Liaison  
38, Lotissement Benachour Abdelkader  
Cheraga  
42300 Wilaya de Tipasa  
Algeria  
Telephone: (213) 2374326  
Country  
Covered: Algeria

**European Regional Office - Mechelen**

Cummins Diesel N.V.  
Blarenberglaan 4  
Industriepark Noord 2  
2800 Mechelen  
Brussels  
Telephone: (32-15) 20003  
Countries: Austria Luxembourg  
Covered: Belgium Netherlands  
Czech Republic Norway  
Denmark Portugal  
Finland Slovakia  
Greece Spain  
Hungary Sweden  
Iceland Switzerland  
Israel

**Cumbrasa Regional Office - Brazil**

Cummins Brasil S.A.  
Rua Jati, 266  
07180-900 Guarulhos  
Sao Paulo, Brazil

Mailing Address:  
P.O. Box 13  
07180-900 Guarulhos  
Sao Paulo, Brazil  
Telephone: (55-11) 945-9811  
Country  
Covered: Brazil

**Beijing Regional Office - China**

Cummins Corporation  
China World Tower, Suite 917  
China World Trade Center  
No. 1 Jian Guo Men Wai  
Beijing 100004  
People's Republic of China  
Telephone: (86-1) 505-4209/10  
Countries  
Covered: China  
Mongolia

**Bogota Regional Office - Columbia**

Cummins Engine Co. de Colombia S.A.  
Carrera 11A No. 90-15 Of. 601/602  
Bogota, D.E., Colombia  
Telephone: (57-1) 610-4849

Mailing Address:  
Apartado Aereo 90988  
Bogota D.E., Colombia  
Countries  
Covered: Argentina  
Bolivia  
Chile  
Colombia  
Ecuador  
Paraguay  
Peru  
Uruguay

**Lyon Regional Office - France**

Cummins Diesel Sales Corporation  
39, rue Ampere - Zone Industrielle  
69680 Chassieu  
France  
Telephone: (33) 72-22-92-72  
Countries  
Covered: Algeria  
France  
Guadeloupe  
Guyana  
Martinique  
New Caledonia  
Reunion

**Gross-Gerau Regional Office - Germany**

Cummins Diesel Deutschland GmbH  
Odenwaldstr. 23  
D-6080 Gross-Gerau  
Germany  
Telephone: (49-6152) 174-0  
Countries: Albania  
Covered: Bulgaria  
\*Czech Republic  
Germany  
Luxembourg  
Poland  
Romania  
Southeastern Europe  
Slovakia  
\*Marine Only

**Hong Kong Regional Office - Hong Kong**

Cummins Engine H.K. Ltd.  
Unison Industrial Centre  
15th Floor, Units C & D  
27-31 Au Pui Wan Street  
P. O. Box 840 Shatin  
Fo Tan, Shatin, N.T.  
Hong Kong  
Telephone: (852) 606-5678  
Country  
Covered: Hong Kong



**Pune Kirloskar Regional Office - India**

Kirloskar Cummins Limited  
Kothrud  
Pune - 411 029, India  
Telephone: (91-212) 33-0240, 33-5435, 33-1105  
Countries  
Covered: Bhutan  
India  
Nepal

**Milan Regional Office - Italy**

Cummins Diesel Italia S.P.A.  
Piazza Locatelli 8  
Zona Industriale  
20098 San Giuliano Milanese  
Milan, Italy  
Telephone: (39-2) 982-81235/6/7  
Country  
Covered: Italy

**North Asia Regional Office - Japan**

Cummins Diesel Sales Corporation  
1-12-10 Shintomi  
Chuo-ku, Tokyo 104  
Japan  
Telephone: (81-3) 3555-3131/2/3/4/5  
Country  
Covered: Japan

**Seoul Regional Office - Korea**

Cummins Korea Ltd.  
5th Floor, Hye Sung Building  
35-26 Sam Sung Dong, Kang Nam Ku  
Seoul, South Korea  
Telephone: (82-2) 516-0431/2/3, 517-3370/1  
Country  
Covered: South Korea

**Cummsa Regional Office - Mexico**

Cummins, S.A. de C.V.  
Arquimedes No. 209  
Col. Polanco  
11560 Mexico, D.F.  
Mexico  
Telephone: (52-5) 254-3822/3783/3622

**Mailing/Shipping Address:**

Gonzalez de Castilla Inc.  
P.O. Box 1391  
4605 Modern Lane  
Modern Industrial Park  
Laredo, TX 78040  
Telephone: (512) 722-5207  
Country  
Covered: Mexico

**Moscow Regional Office - Russia**

Cummins Engine Co., Inc.  
Park Place  
Office E708  
Leninsky Prospect 113  
Russia 11798  
Telephone: (7-502) 256-5122 or  
256-5123

Countries	Armenia	Lithuania
Covered:	Azerbaijan	Moldova
	Bolarus	Russia
	Estonia	Tadzhikistan
	Georgia	Turkmenistan
	Kirghizia	Ukraine
	Latvia	Uzbekistan

**South And East Asia Area Office - Singapore**

Cummins Diesel Sales Corporation  
8 Tanjong Penjuru  
Jurong Industrial Estate  
Singapore 2260  
Telephone: (65) 265-0155

Countries	Bangladesh	Malaysia
Covered:	Brunei	Mongolia
	Burma/Mynamar	Philippines
	Cambodia	Singapore
	China	Sri Lanka
	Hong Kong	Taiwan
	Indonesia	Thailand
	Laos	Vietnam
	Macau	

**Taipei Regional Office - Taiwan**

Cummins Corporation - Taiwan  
12th Floor, No. 149  
Min-Sheng E. Road  
Section 2  
Taipei, Taiwan  
R.O.C. 104  
Telephone: (886-2) 515-0891  
Country  
Covered: Taiwan

**Turkey and Iran Regional Office - Turkey**

Cummins Corporation  
Istanbul Office  
Buyukdere Cad.  
Beytem Han, Kat 11  
Sisli 80220  
Istanbul  
Telephone: (90-1) 246-2575/2775/2545  
Countries Iran  
Covered: Turkey

**Middle East/Africa Regional Office -  
Daventry (U.K.)**

Cummins Engine Company Ltd.  
Royal Oak Way South  
Daventry, Northants NN11 5NU  
England  
Telephone: (44-327) 76000  
Countries Covered:

**MIDEAST**

Afghanistan	Jordan	Saudi Arabia
Bahrain	Kuwait	Sudan
Cyprus	Lebanon	Syria
Djibouti	Oman	U.A.E.
Egypt	Pakistan	Yemen
Iraq	Qatar	

**NORTH/WEST AFRICA**

Benin	Gabon	Mauritania
Burkina-Paso	Gambia	Morocco
Cameroon	Ghana	Niger
Cape Verde	Guinea	Nigeria
Central African Republic	Guinea- Bissau	Sao Tome & Principe
Chad	Liberia	Senegal
Cote d'Ivoire	Libya	Siera Leone
Equatorial Guinea	Mali	Togo
	Malta	Tunisia

**SOUTH AFRICA**

Botswana	Namibia	Swaziland
Lesotho	South Africa	

**New Malden Regional Office - U.K.**

Cummins Engine Company Limited  
46-50 Coombe Road  
New Malden  
Surrey KT3 4QL  
England  
Telephone: (44-81) 949-6171  
Countries  
Covered: Ireland  
United Kingdom

**Latin America Regional Office - Miramar  
(U.S.A.)**

Cummins Americas, Inc.  
Miramar Park of Commerce  
3450 Executive Way  
Miramar, FL 33025  
Telephone: (305) 431-5511  
Countries  
Covered: Argentina  
Bolivia  
Chile  
Colombia  
Costa Rica  
Dominican Republic  
El Salvador  
Ecuador  
Guatemala  
Honduras  
Nicaragua  
Panama  
Paraguay  
Peru  
Uruguay  
Venezuela

**Caracas Regional Office - Venezuela**

Cummins Engine Company  
Oficina de Delegado  
Torre La Primera, Oficina 5-D  
Av. Francisco de Miranda  
Chacao, Caracas 1060

**Mailing Address:**

Cummins Engine Company M-227  
c/o Jet Cargo International  
P.O. Box 020010  
Miami, FL 33102-0010 U.S.A.  
Telephone: (58-2) 32-0563, 32-718  
Countries  
Covered:

Costa Rica  
Dominican Republic  
El Salvador  
Guatemala  
Honduras  
Nicaragua  
Panama  
Venezuela

**East/Southern Africa Regional Office -  
Harare, Zimbabwe**

Cummins Zimbabwe (Private) Limited  
72 Birmingham Road  
Southerton  
Harare, Zimbabwe

**Mailing Address:**

P.O. Box ST363  
Southerton  
Harare, Zimbabwe  
Telephone: (263-4) 67645, 60553, 69220

Countries  
Covered: Angola  
Burundi  
Comoros Island  
Congo  
Ethiopia  
Kenya  
Madagascar  
Malawi  
Mauritius  
Mozambique  
Reunion  
Rwanda  
Seychelles  
Somalia  
Tanzania  
Uganda  
Zaire  
Zambia  
Zimbabwe

**ABU DHABI**

-See United Arab Emirates

**AFGHANISTAN**

-See Middle East Regional Office

**ALBANIA**

-See Germany Regional Office -  
Gross Gerau

**ALGERIA****Algiers**

Cummins Corporation  
Bureau de Liaison  
38, Lotissement Benachour Abdelkader  
Cheraga  
43200 Wilaya de Tipasa  
Algeria  
Telephone: (213) 237-43-26

**AMERICAN SAMOA**

- See South Pacific Regional Office

**ANDORRA**

-See European Regional Office  
- Mechelen

**ANTIGUA****Miami (Office In U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**ARGENTINA****Buenos Aires**

Distribuidora Cummins, S.A.  
(DICUMAR)  
Av. Del Libertador 602 Piso 5  
Buenos Aires, Argentina  
Telephone: (54-1)814-1895/1395/1393

**ARUBA, ISLAND OF**

-See Netherlands Antilles

**AUSTRIA****Neudoerfl**

Cummins Diesel Motorenvertriebsges  
m.b.H. Trenner & Co.  
Bickfordstr. 25  
A-7201 Neudoerfl  
Austria  
Telephone: (43-2622) 77418/77625

**BAHAMAS****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**BAHRAIN****Bahrain**

Yusuf Bin Ahmed Kanoo W.L.L.  
P.O. Box 45, Manama  
Bahrain  
Telephone: (973) 400414/400506

**Distributors - International  
BALEARIC ISLANDS****Madrid (Office in Spain)**

Cummins Ventas y Servicio, S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 367-2000  
376-2404

**BANGLADESH****Dhaka**

Equipment & Engineering Co., Ltd.  
G.P.O. Box 2339  
Dhaka 1000, Bangladesh

Location:  
56, Dilkusha Commercial Area  
2nd Floor/Eastern Block  
Telephone: (880-2) 234357, 234060

**BARBADOS****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**BELGIUM****Brussels**

Cummins Distributor  
Belgium S.A.  
623/629 Chaussee de Haecht  
B-1030 Brussels, Belgium  
Telephone: (24 hr.)  
(32-2) 216-81-10

**BELIZE****Tampa (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
5421 N. 59th Street  
Tampa, FL 33610  
Telephone: (813) 621-7202

**BENIN**

-See Togo

**BERMUDA****Bronx (Office in U.S.A.)**

Cummins Metropower, Inc.  
890 Zerega Avenue  
Bronx, NY 10473  
Telephone: (718) 892-2400

**BHUTAN****Pune (Office in India)**

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune - 411 038, India  
(State of Maharashtra) India  
Telephone: (91-212) 331234/331554/  
331635/  
330066/330166/  
330356/331703

**BOLIVIA****La Paz**

Machinery & Auto Service  
Casilla 4042  
La Paz, Bolivia

Location:  
Av. 20 de Octubre Esq.  
Rosendo Gutierrez  
Telephone: (591-2) 379650, 366394

**BONAIRE, ISLAND OF**

-See Netherlands Antilles

**BOTSWANA**

-See East and Southern  
Africa Regional Office  
Harare

**BRAZIL****Ananindeua**

Marcos Marcelino & Companhia  
Ltda.  
Rodovia BR-316, Km 9  
67020-010 Ananindeua, Para,  
Brazil  
Telephone: (55-91) 235-4100/4132/  
4143/4012

**Belo Horizonte**

Distribuidora Cummins  
Minas S.A.  
31950-640 Olhos D'Agua Norte  
Belo Horizonte, MG  
Brazil  
Telephone: (55-31) 288-1344

**Campo Grande**

Distribuidora Cummins  
Mato Grosso Ltda.  
Rodovia BR 163 Km 01  
79060-000 Campo Grande  
Mato Grosso do Sul, Brazil  
Telephone: (55-67) 787-1166

**Curitiba**

Distribuidora Cummins Parana S.A.  
Rua Brasílio Itiberê, 2195  
80230 Curitiba, Parana  
Brazil  
Telephone: (55-41) 222-4036

**Fortaleza**

Distribuidora Cummins Diesel  
Do Nordeste Ltda.  
Av. da Abolicão, 3882,  
Mucuripe  
60165-081 Fortaleza, Ceara  
Brazil  
Telephone: (55-85) 263-1212

**Goianian**

Distribuidora de Motores Cummins  
Centro Oeste Ltda.  
Av. Caiapo 777 - Setor Sta. Genoveva  
74672-400 Goiania, Goias  
Brazil  
Telephone: (55-62) 207-1010

**Manaus**

Distribuidora Cummins  
Amazonas Ltda.  
Estrada da Ponta Negra, 6080 - Sao  
Jorge  
69037 Manaus, Amazonas,  
Brazil  
Telephone: (55-92) 656-5444

**Porto Alegre**

Distribuidora Cummins  
Meridional S.A.  
Rua Dona Alzira, 98, Sarandi  
91110-010 Porto Alegre,  
Rio Grande do Sul, Brazil  
Telephone: (55-51) 340-8222

**Rio de Janeiro**

Distribuidora Cummins  
Leste Ltda.  
Rua Sariema, 138-Olaria  
21030-550 Rio de Janeiro,  
Rio de Janeiro, Brazil  
Telephone: (55-21) 290-7899

**Sao Paulo**

Companhia Distribuidora  
de Motores Cummins  
Rua Martin Burchard, 291 - Bras  
03043-020 Sao Paulo,  
Sao Paulo, Brazil  
Telephone: (55-11) 270-2311

**BRITISH VIRGIN ISLANDS**

-See Puerto Rico

**BRUNEI**

-See Malaysia

**BURKINA - FASO**

-See North/West Africa Regional  
Office - Daventry

**BULGARIA**

-See Germany Regional Office - Gross  
Gerau

**BURMA**

**Kuala Lumpur (Office In Malaysia)**

Contact: Scott &  
English (M) Sdn Bhd  
P.O. Box 10324  
50710 Kuala Lumpur  
West Malaysia

Location:  
16 Jalan Chan Sow Lin  
55200 Kuala Lumpur  
West Malaysia  
Telephone: (60-3) 2211033

**BURUNDI**

**Brussels (Office in Belgium)**

Bia, S.A.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 6892811

**CAMBODIA**

-See South & East Asia  
Regional Office - Singapore

**CANARY ISLANDS**

**Madrid (Office in Spain)**

Cummins Ventas y  
Servicio, S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 3672000/3672404

**CAPE VERDE**

-See North/West Africa  
Regional Office - Daventry

**CENTRAL AFRICAN REPUBLIC**

-See North/West Africa  
Regional Office - Daventry

**CEYLON**

-See Sri Lanka

**CHAD**

-See North/West Africa  
Regional Office - Daventry

**CHILE**

**Santiago**

Distribuidora Cummins Diesel  
S.A.C.I.  
Casilla Postal 1230  
Calle Bulnes 1203  
Santiago, Chile  
Corporate Office:  
Av. Providencia 2653, Office 1901  
Santiago, Chile  
Telephone: (56-2) 698-2113/4/5,  
697-3566/7/8,  
697-2709

**CHINA, PEOPLE'S REPUBLIC**

-See China Regional  
Office - Beijing

**COLOMBIA**

**Barranquilla**

Cummins de Colombia S.A.  
Apartado Aereo 5347  
Barranquilla, Colombia

Location: Calle 30, No. 19 - 21  
Telephone: (57-58) 40-02-06/40-13-46

**Bogota**

Cummins Colombiana Ltda.  
Apartado Aereo No. 7431  
Bogota, D.E. Colombia

Location:  
Av. Americas X Carrera  
42C No. 19-45  
Telephone: (57-1) 244-5688/5882

**Bucaramanga**

Cummins API, Ltda.  
Apartado Aereo 352  
Bucaramanga, Colombia

Location:  
Autopista a Giron, Km 7  
Telephone: (57-76) 468060

**Cali**

Distribuidora Cummins del Valle, Ltda.  
Apartado Aereo No. 6398  
Cali, Colombia

Location: Av. 3a. # 39-35 - Vipasa  
Telephone: (57-3) 65-4343

**Medellin**

Equipos Tecnicos Ltda.  
Apartado Aereo No. 2046  
Medellin, Colombia

Location: Carrera 52 No. 10-184  
Telephone: (57-4) 255-4200

**Pereira**

Equipos Tecnicos Ltda. C.Q.R.  
Apartado Aereo No. 1240  
Pereira, Colombia

Location: Carrera 8a. No. 45-39  
Telephone: (57-63) 366341

**COMOROS**

-See East and Southern  
Africa Regional Office  
Harare

**CONGO, PEOPLE'S REPUBLIC**

**Brussels (Office in Belgium)**

Bia, S.A.  
Rameistraat, 123  
B-3090  
Overijse, Belgium  
Telephone: (32-2) 6892811

**CORSICA**

-See France

**COSTA RICA**

**San Jose**

Servicios Unidos, S.A.  
P.O. Box 559  
San Jose, Costa Rica

Location:  
100 metros al este de  
Excelsior Antiguo  
Curridabat, San Jose  
Telephone Office: (506) 53-93-93  
Telephone Service Shop:  
(506) 26-00-76

**CUBA**

**Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**CYPRUS**

**Nicosia**

Alexander Dimitriou & Sons Ltd.  
P.O. Box 1932  
Nicosia, Cyprus

Location:  
4 Salamis Avenue  
Telephone: (357-2) 349450

**CZECH REPUBLIC**

-See European Regional  
Office - Mechelen

**DENMARK**

**Glostrup**

Preben Lange Industrimaskiner A/S  
Post Box 166  
2605 Broendby, Denmark

Location:  
Midtager 22  
Telephone: (45-43) 96-21-61

**DJIBOUTI**

-See Middle East Regional Office -  
Daventry

**DOMINICA****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**DOMINICAN REPUBLIC****Santo Domingo**

Argico C. Por A.  
P.O. Box 292-2 Feria  
Santo Domingo  
Dominican Republic, ZP-6

**Location:**

Calle Jose A. Soler  
No. 3, ESQ.  
Avenida Lope de Vega  
Telephone: (809) 562-6281

**DUBAI**

-See United Arab Emirates

**ECUADOR****Guayaquil**

Motores Cummins (MOTCUM) S.A.  
P.O. Box 1062  
Guayaquil, Ecuador

**Location:**

Avenida Carlos Julio  
Arosemena Km. 4  
Telephone: (593-4) 203995/201177

**Quito**

Rectificadora Botar S.A.  
P.O. Box 17-01-3344  
Quito, Ecuador

**Location:**

Av. 10 de Agosto No. 5980  
Telephone: (593-2) 465-176/177/  
178/195/197

**EGYPT****Cairo**

ADAT  
P.O. Box 1572  
Cairo, Egypt

**Sales and Service Location:**

25, Pyramid Road  
Giza, Cairo, Egypt  
Telephone: (20-2) 384-6607/384-6609  
385-4001/2/4/5/6/8/9

**EL SALVADOR****San Salvador**

Salvador Machinery  
Company, S.A. de C.V.  
P.O. Box 125  
San Salvador, El Salvador

**Location:**

Blvd. Ejercito Nacional  
Telephone: (503) 711022, 228388

**ENGLAND**

-See United Kingdom

**EQUATORIAL GUINEA**

-See North/West Africa Regional  
Office - Daventry

**ESTONIA**

- See Moscow Regional Office, Moscow

**FAROE ISLANDS****Wellingborough (Office in United Kingdom)**

Cummins Diesel  
Denington Industrial Estate  
Wellingborough  
Northants NN8 2QH,  
England  
Telephone: (44-933) 276231

**FERNANDO PO**

-See Spain

**FIJI**

- See Cummins Diesel Sales & Service  
New Zealand Ltd.

**FINLAND****Helsinki**

Machinery OY  
P.O. Box 56  
SF 00511 Helsinki, Finland

**Location:**

Teollisuuskatu 29  
Telephone: Int: (358-9) 77221

**FRANCE****Lyon**

Cummins Diesel  
Sales Corporation  
39, rue Ampere Z.I.  
69680 Chassieu, France  
Telephone: (33) 72-22-92-72  
Parts and Service Telephone: (33) 72-22-  
92-69

**GABON**

- See North/West Africa  
Regional Office - Daventry

**GAMBIA**

Senegal (Matforce)

**GEORGIA**

-See Moscow Regional Office -  
Moscow

**GERMANY****Gross-Gerau**

Cummins Diesel Deutschland GmbH  
P.O. Box 1134  
D-6080 Gross-Gerau,  
Germany

**Location: Odenwaldstr. 23**

Telephone: (49-6152) 174-0

**GHANA****Accra**

Leyland DAF (Ghana) Ltd.  
P.O. Box 2969  
Accra, Ghana

**Location:**

39/40 Ring Road South  
Industrial Estate  
Telephone: (233-21) 22-88-06

**GREECE****Athens**

Eliopoulos Brothers Ltd.  
P.O.B. 51528  
14 Km. National Rd.  
Athens-Lamia  
14510 Kifissia, Greece  
Telephone: (30-1) 6202401/6202066/  
6201955

**GREENLAND**

-See Denmark

**GRENADA****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**GUADELOUPE****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**GUAM****Barrigada**

Mid-Pac Far East, Inc.  
Airport Industrial Park  
825 Tiyan Parkway  
Barrigada, Guam 96921  
Telephone: (671) 632-5160

**GUATEMALA****Guatemala City**

Maquinaria y Equipos, S.A.  
P.O. Box 2304  
Guatemala City, Guatemala

**Location:**

Carretera Amatitlan  
Km 12 zona 12  
Telephone: (502-2) 773334/7/9

**GUINEA BISSAU**

-See North/West Africa Regional  
Office - Daventry

**GUYANA****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**GUYANA, FRENCH****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**HAITI****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## HOLLAND

-See Netherlands

## HONDURAS

### Tegucigalpa

Comercial Laeisz  
Honduras, S.A.  
P.O. Box 1022  
Tegucigalpa, D.C., Honduras

Location:  
Zona La Burrera,  
Blvd. Toncontin  
Frente a Gasolinera Esso.  
Telephone: (504) 333570/335615

## HONG KONG

### Kowloon

Cummins Engine H. K. Ltd.  
P.O. Box 840 Shatin  
N.T., Hong Kong

Location:  
Unison Industrial Centre  
15th Floor, Units C & D  
27-31 Au Pui Wan Street  
Fo Tan, Shatin, Hong Kong  
Telephone: (852) 606-5678

## INDIA

### Pune

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune - 411 038, (State of Maharashtra)  
India  
Telephone: (91-212)

331234, 331554,  
331635, 330066,  
330166, 330356,  
331703

### Bombay

Cummins Diesel Sales & Service (I) Ltd.  
298, Perin Nariman Street, Fort,  
Bombay 400001, India  
Telephone: (91-22) 2863566/2862247

### Calcutta

Cummins Diesel Sales & Service (I) Ltd.  
94, Tivoli Court, I/C Ballygunge  
Circular Road  
Calcutta 700 019 (West Bengal), India  
Telephone: (91-33) 2478065/2470481/  
2470774

### New Delhi

Cummins Diesel Sales & Service (I) Ltd.  
Flat No. 307, Meghdoot Building  
94 Nehru Place  
New Delhi 110 019, India  
Telephone: (91-11) 6431051/6445756/  
6452817

### Raipur

Cummins Diesel Sales & Service (I) Ltd.  
Plot No. 15, Jalashay Marg  
Choube Colony  
Raipur 492 001 (Madhya Pradesh), India  
Telephone: (91-771) 24994/23157/29498

## Ranchi

Cummins Diesel Sales & Service (I) Ltd.  
'Shanti Kunj' C-202, Vidyalaya Marg  
Road No. 1, Ashoknagar  
Ranchi 834 002 (Bihar)  
India  
Telephone: (91-651) 301948/303623

## INDONESIA

### Jakarta

P.T. Alltrak 1978  
P.O. Box 64/KBYL  
Jakarta Selatan 12330, Indonesia

Location:  
J1. R.S.C. Veteran No. 4  
Bintaro, Rempoa  
Telephone: (62-21) 736-1978/736-3302

## IRAN

### Tehran

Technical Service Development  
Company  
P.O. Box 13445/741  
No. 152 Sohravardi Crossing  
Dr. Beheshti Avenue  
Tehran, Iran  
Telephone:  
Head Office: (98-21) 846666, 851021-7  
Work Shop: (98-21) 995021-2/993240

## IRAQ

- See Middle East Regional  
Office - Daventry

## IRELAND

### Wellingborough (Office in England)

Cummins Diesel  
Denington Estate  
Wellingborough  
Northants NN8 2QH, England  
Telephone: (44-933) 276231

## ISRAEL

### Tel Aviv

Israel Engines &  
Trailers Co. Ltd.  
Levinson Brothers Engineers  
P. O. Box 390  
33 Hahashmal Street  
Tel Aviv, Israel 61003  
Telephone: (972-3) 5607671

## ITALY

### Milan

Cummins Diesel Italia S.p.A.  
Piazza Locatelli, 8  
Zona Industriale Sesto Ulteriano  
20098 S. Giuliano  
Milanese (Milan), Italy  
Telephone: (39-2) 9828-1235/6/7

## IVORY COAST

-See Cote d' Ivoire

## JAMAICA

### Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## JAPAN

### Tokyo

Cummins Diesel (Japan) Ltd.  
1-12-10-Shintomi  
Chuo-ku, Tokyo 104  
Japan  
Telephone: (81-3) 3555-8511

## JORDAN

### Amman

S.E.T.I. Jordan Limited  
P.O. Box 8053  
Amman, Jordan  
Telephone: (962-6) 621867/621884

## KENYA

### Nairobi

Werrot & Company Limited  
P.O. Box 41216  
Nairobi, Kenya

Location:  
Lusaka Road  
Telephone: (254-150) 20316

## KOREA, SOUTH

### Seoul

Hwa Chang Trading Co., Ltd.  
Central P.O. Box No. 216  
Seoul, South Korea

Location:  
143-11 Doksan-dong, Kuro-ku  
Telephone: (82-2) 854-0071/2/3/4/5,  
869-1411/2/3

## KUWAIT

### Kuwait

General Transportation &  
Equipment Co.  
(Sales Department)  
P.O. Box 1096  
13011 Safat, Kuwait

Location:  
Shuwaikh Behind  
Canada Dry Factory  
Telephone: (965) 4833380/1/2

### Kuwait

General Transportation &  
Equipment Co.  
(Service Department)  
East Ahmadi Area  
13011 Safat, Kuwait  
Telephone: (965) 3981577

## LAOS

-See South and East  
Asia Regional Office  
- Singapore

## LATVIA

- See Moscow Regional  
Office - Moscow

**LEBANON****Beirut**

S.E.T.I. Charles Keller  
S.A.L.  
B.P. 16-6726  
Beirut, Lebanon

Location:  
Corniche du Fleuve  
Telephone: (961-1) 425040/41

**LESOTHO**

-See South Africa

**LIBYA**

- See North/West Africa Regional  
Office - Daventry

**LIECHTENSTEIN**

-See Switzerland

**LUXEMBOURG****Gross Gerau (Office in Germany)**

Cummins Diesel Deutschland GmbH  
P.O. Box 11 34  
Odenwaldstrasse 23  
D-6080 Gross-Gerau, Germany  
Telephone: (49-6152) 174-0

**MACAU**

-See Hong Kong

**MADAGASCAR**

-See East and Southern  
Africa Regional Office -  
Harare

**MADEIRA ISLANDS**

-See Portugal

**MALAYSIA****Kuala Lumpur**

Cummins Diesel Sales & Service  
Div. of Scott & English  
(M) Sdn. Bhd.  
P.O. Box 10324  
50710 Kuala Lumpur, West Malaysia

Location:  
16 Jalan Chan Sow Lin  
55200 Kuala Lumpur  
Telephone: (60-3) 2211033

**MALI**

-See Senegal (Matforce)

**MALTA****Valletta**

Plant & Equipment Ltd.  
Regency House  
254, Republic Street  
Valletta, Malta  
Telephone: (356) 23-26-20, 23-33-43, 23-  
16-23, 24-75-17

**MARTINIQUE****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**MEXICO****Guadalajara**

Cummins Del Occidente, S.A.  
Lazaro Cardenas No. 2950  
Fracc. Alamo Industrial  
45560 Guadalajara, Jal. Mexico  
Telephone: (52-3) 670-93-06, 670-53-38,  
670-63-61, 670-62-33

**Monterrey**

Tecnica Automotriz, S.A.  
Av. Alfonso Royes  
No. 3637 Nte.  
Monterrey, Nuevo Leon, Mexico  
Telephone: (52-83) 51-41-51, 51-46-56

**Merida**

Cummins Del Sureste, S.A. de C.V.  
Av. Aviacion Civil No. 647  
Esquina Calle 100  
Col. Sambula  
97259 Merida, Yucatan, Mexico  
Telephone: (52-99) 24-11-55, 24-00-15

**Puebla**

Cummins de Oriente, S.A. de C.V.  
Av. Reforma No. 2112,  
Puebla, Pue. Mexico  
Telephone: (52-22) 48-76-74, 48-76-75

**Queretaro**

Distribuidor Cummins Del Centro, S.A.  
de C.V.  
Blvd. Bernardo Quintana No. 518  
Col. Arboledas  
C.P. 76140 Queretaro, Qro., Mexico  
Telephone: (52-42) 12-41-90, 12-58-90,  
12-62-94  
14-04-16, 14-08-81, 14-15-91

**Tlalnepantla**

Distribuidor Cummins  
Metropolitana, S.A. DE C.V.  
Sor Juana Ines de la Cruz No. 555  
54000 Tlalnepantla, Edo. de Mexico,  
Mexico  
Telephone: (52-5) 327-38-00, 390-64-37,  
390-12-27

**MOROCCO****Casablanca**

Societe Auto-Hall, S.A.  
44 Avenue Lalla Yacout  
Casablanca, Morocco  
Telephone: (212) 31-84-60, 31-70-52,  
31-90-56, 31-70-44

**MOZAMBIQUE**

-See East and Southern  
Africa Regional Office -  
Harare

**NAMIBIA (Southwest Africa)****Windhoek**

Propower, Namibia  
P.O. Box 3637, Windhoek 9000  
Namibia (Southwest Africa)

Location: 7 Nasmyth Street  
Southern Inudustria  
Telephone: (264-61) 37693

**NEPAL****Pune (Office in India)**

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune, - 411 038, (State of Maharashtra)  
India  
Telephone: (91-212) 331234, 331554,  
331635,  
330066, 330166,  
330356, 331703

**NETHERLANDS****Dordrecht**

Cummins Diesel Sales &  
Service, b.v.  
Galvanistraat 35  
3316 GH Dordrecht  
Netherlands  
Telephone: (31-78) 18-12-00

**NETHERLANDS ANTILLES****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**NEW CALEDONIA**

-See South Pacific Regional  
Office - Melbourne

**NEW GUINEA**

-See Papua New Guinea

**NICARAGUA****Managua**

F. Alf. Pellas & Cia.  
Apartado Postal No. 46  
Managua, Nicaragua

Location:  
6a. Calle  
30 y 31 Avs. N.O., Zona 5  
Telephone: (505-2) 660616

**NIGERIA****Lagos**

SCOATRAC MOSEL  
P.M.B. 21108  
Ikeja, Lagos  
Nigeria

Location:  
Apapa-Oshodi Expressway  
Isolo Industrial Estate,  
Isolo  
Telephone: (234-1) 52-15-39, 52-19-31,  
52-46-70

**Paris (Office in France)**

SCOATRAC MOSEL  
c/o SCOA  
9 et 11 rue Robert de Flers  
75740 Paris, Cedex 15  
France  
Telephone: (33-1) 40-58-48-48

**NORTHERN IRELAND**

-See United Kingdom

**NORWAY**

**Oslo**

Cummins Diesel Salg & Service A/S  
P.O. 6288  
Etterstad 0603, Oslo 6  
Norway

Location:  
Verkseler Furulunds vei 11  
Telephone: (47) 22326110

**OMAN**

**Ruwi**

Universal Engineering  
Services L.L.C.  
P.O. Box 5688  
Ruwi  
Sultanate of Oman  
Telephone: (968) 590830, 591304

**PAKISTAN**

**Karachi**

-See Middle East  
Regional Office - Daventry

**PANAMA**

**Panama City**

Grupo Tiesa, S.A.  
Apartado Postal #55-0549  
Partillo, Panama  
Telephone: (507) 67-3866

**PAPUA NEW GUINEA**

**Sydney (Office in Australia)**

Cummins Diesel Sales & Service  
P.O. Box 150  
Cabramatta, 2166  
New South Wales, Australia

**PARAGUAY**

**Asuncion**

Automotores y Maquinaria,  
S.R.L.  
Yegros y Fulgencio R. Moreno  
P.O. Box 1160  
Asuncion, Paraguay  
Telephone: (595-21) 493111, 493115

**PERU**

**Lima**

Comercial Diesel  
del Peru S.A.  
P.O. Box 14-0234  
Lima, Peru

Location:  
Ave. V.R. Haya  
de la Torre 2648  
Lima 3, Peru  
Telephone: (51-14) 74-3173/4374/  
3144/2281

**PHILIPPINES**

**EDSA**

Power Systems, Inc. EDSA  
P.O. Box 3241  
Manila  
Philippines 1501

Location:  
79E. Delos Santos Ave.  
Mandaluyong, Metro Manila  
Telephone: (63-2) 791769, 791771,  
5311945,  
5315448, 5311934,  
5312531, 53414513

**POLAND**

-See Germany Regional Office - Gross-  
Gerau

**PORTUGAL**

**Lisbon**

Electro Central  
Vulcanizadora, Lda.  
P.O. Box 3077  
1302 Lisbon, Portugal

Location:  
Rua Conselheiro  
Martins de Carvalho  
Lote 1480  
1400 Lisboa (Restelo)  
Telephone: (351-1) 3015361

**QATAR**

**Doha**

Jaidah Motors & Trading Co.  
P.O. Box 150  
Doha, Qatar (Arabian Gulf)  
Telephone: (974) 810000

**REUNION**

-See Lyon Regional Office - Lyon

**RIO DE ORO**

-See Spain

**ROMANIA**

-See Germany Regional Office -  
Gross-Gerau

**RUSSIA**

-See Moscow Regional Office - Moscow

**RWANDA**

**Brussels (Office in Belgium)**

Bia, S.A.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 6892811

**ST. LUCIA**

**Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**ST. VINCENT**

**Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**SAN MARINO**

-See Italy

**SAO TOME AND PRINCIPE**

-See North/West Africa Regional  
Office - Daventry

**SAUDI ARABIA**

**Dammam**

General Contracting Company  
P.O. Box 5111  
Dammam 31422, Saudi Arabia  
Telephone: (966-3) 842-1216

**SCOTLAND**

-See United Kingdom

**SENEGAL**

**Dakar**

Matforce  
B.P. 397  
Dakar, Senegal

Location:  
10 Avenue Faidherbe  
Telephone: (221) 22-30-40

**SEYCHELLES**

-See East/Southern Africa Regional Of-  
fice - Harare

**SIERRA LEONE**

-See North/West Africa Regional  
Office - Daventry

**SINGAPORE**

**Singapore**

Applied Diesel Sales & Service Pte Ltd  
8 Tanjong Penjuru  
Jurong Industrial Estate  
Singapore 2260  
Telephone: (65) 261-3555

**SLOVAKIA**

- See European Regional  
Office - Mechelen

**SOLOMON ISLANDS**

-See South Pacific Regional  
Office - Melbourne

**SOMALIA**

-See East and Southern  
Africa Regional Office -  
Harare



**SOUTH AFRICA****Johannesburg**

Propower Pty. Ltd.  
Private Bag X4  
Wendywood 2144  
South Africa

Location:  
13 Eastern Service Road  
Kelvin 2054  
Telephone: (27-11) 444-3225

**SOUTHWEST AFRICA**

-See Namibia

**SPAIN****Madrid**

Cummins Ventas y  
Servicio S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 367-2000/3672404

**SPANISH GUINEA**

-See Spain

**SRI LANKA****Colombo**

Trade Promoters Ltd  
P.O. Box 321  
69, Walukarama Road  
Colombo 3  
Sri Lanka  
Telephone: (94-1) 573927, 574651,  
575005

**SUDAN****Khartoum**

Bittar Engineering Ltd.  
P.O. Box 1011  
Gamhouria Street  
Khartoum, Sudan  
Telephone: (249-11) 70952, 71245, 70306

**SURINAM****Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**SWAZILAND**

-See South Africa

**SWEDEN****Stockholm**

SMA Maskin AB  
Aggelundavagen 7  
S-17562 Jarfalla  
Sweden  
Telephone: (46-8) 621-25-00

**SWITZERLAND****Regensdorf**

Robert Aebi AG  
Riedthofstrasse 100  
8105 Regensdorf  
Switzerland  
Telephone: (41-1) 842-5111

**SYRIA****Damascus**

Puzant Yacoubian & Sons  
P.O. Box 3617  
Damascus, Syria

Location:  
Abou Baker El Saddik Street  
Kafar Sousse Square  
Telephone: (963-11) 231547/8/9

**TAHITI, ISLAND OF**

-See French Polynesia

**TAIWAN****Taipei**

Cummins Corporation - Taiwan Branch  
12th Floor, No. 149  
Min-Sheng E. Road, Sec. 2  
Taipei, Taiwan  
Telephone: (886-2) 515-0891

**TANZANIA****Dar es Salaam**

Riddoch Motors 1987 Ltd  
P.O. Box 40040  
Dar es Salaam  
Tanzania

Location:  
92 Kipawa-Pugu Road  
Dar es Salaam  
Telephone: (255-51) 44493, 41140

**THAILAND****Bangkok**

Diethelm & Company Ltd.  
1696 New Petchburi Road  
Bangkok 10310, Thailand  
Telephone: (66-2) 254-4900

**TOGO (and BENIN)****Lome**

Togomat  
B.P. 1641  
Lome, Togo

Location:  
Zone Industrielle CNPPME  
Telephone: (228) 21-23-95

**TONGA, ISLAND OF**

- See South Pacific Regional  
Office - Melbourne

**TRINIDAD and TOBAGO****Miami (Office in U.S.A.)**

Cummins Southeastern Power Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**TURKEY****Istanbul**

Hamamcioglu Mueesseseleri  
Ticaret T.A.S.  
P.K. 136  
80222 Sisli  
Istanbul, Turkey

Location:  
Buyukdere Caddesi, 13/A  
80260 Sisli  
Istanbul, Turkey  
Telephone: (90-1) 231-3406, 234-5123

**UKRAINA**

- See Moscow Regional  
Office - Moscow

**UNITED ARAB EMIRATES****Abu Dhabi**

Technical Oilfield Supplies Centre  
P.O. Box 2647  
Abu Dhabi,  
United Arab Emirates  
Telephone: (971-2) 723863, 723298

**UNITED KINGDOM****Wellingborough**

Cummins Diesel  
Denington Estate  
Wellingborough  
Northants NN8 2QH, England  
Telephone: (44-933) 276231

**UPPER VOLTA**

-See Burkina - Faso

**URUGUAY****Montevideo**

Santaro S.A.  
P.O. Box 379  
Montevideo  
Uruguay

Location:  
Avenida Millan No. 2441  
Telephone: (598-2) 293908

**U.S.S.R.**

-See Moscow Regional  
Office - Moscow

**VATICAN CITY**

-See Italy

**VENEZUELA****Caracas**

Sudimat  
Apartado Postal 1322  
Carmelitas  
Caracas 1010  
Venezuela

Location:  
Final Avenida San Martin  
Urb. la Quebradita  
Caracas 1061  
Telephone: (58-2) 442-6161/2647

**VIETNAM**

-See South and East Asia  
Regional Office - Singapore

**WESTERN SAMOA**

- See South Pacific Regional  
Office - Melbourne

**YEMEN ARAB REPUBLIC**

**Sana'a**

Zubieri Trading Co.  
P.O. Box 535  
Sana'a, Yemen Arab Republic

**Location:**

Zubieri Street  
Telephone: (967-1) 244400/79149

**YEMEN, SOUTH**

-See Middle East Regional  
Office - Daventry

**YUGOSLAVIA**

- See Southeastern Europe

**ZAIRE**

**Brussels (Office in Belgium)**

N.V. Bia, S.A.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 689-28-11

**ZAMBIA**

**Ndola**

N.E.I. (Zambia) Ltd.  
P.O. Box 71501  
Ndola, Zambia  
Telephone: (260-2) 610729

**ZIMBABWE**

**Harare**

Cummins Zimbabwe (Pvt) Ltd.  
P.O. Box ST363  
Southerton  
Harare, Zimbabwe

**Location:**

72 Birmingham Road  
Southerton, Harare  
Telephones: (263-4) 67645, 69220

## Section C - Component Manufacturers

### Section Contents

	Page
<b>Component Manufacturers' Addresses .....</b>	<b>C-2</b>
Air Compressors .....	C-2
Air Cylinders .....	C-2
Air Heaters .....	C-2
Air Starting Motors .....	C-2
Alternators .....	C-2
Auxiliary Brakes .....	C-2
Belts .....	C-2
Catalytic Convertors .....	C-2
Clutches .....	C-2
Coolant Heaters .....	C-2
Drive Plates .....	C-2
Electric Starting Motors .....	C-3
Engine Protection Controls .....	C-3
Fan Clutches .....	C-3
Fans .....	C-3
Filters .....	C-3
Flexplates .....	C-3
Fuel Warmers .....	C-3
Gauges .....	C-3
Governors .....	C-3
Heat Sleeves .....	C-4
Hydraulic and Power Steering Pumps .....	C-4
Oil Heaters .....	C-4
Torque Converters .....	C-4



## Component Manufacturers' Addresses

**NOTE:** The following list contains addresses and telephone numbers of suppliers of accessories used on Cummins engines. Suppliers may be contacted directly for any specifications **not** covered in this manual.

### Air Compressors

Bendix Heavy Vehicles Systems  
Div. of Allied Automotive  
901 Cleveland Street  
Elyria, OH 44036  
Telephone: (216) 329-9000

Holset Engineering Co., Inc.  
1320 Kemper Meadow Drive  
Suite 500  
Cincinnati, OH 45240  
Telephone: (513) 825-9600

Midland-Grau  
Heavy Duty Systems  
Heavy Duty Group Headquarters  
10930 N. Pomona Avenue  
Kansas City, MO 64153  
Telephone: (816) 891-2470

### Air Cylinders

Bendix Ltd.  
Douglas Road  
Kingswood  
Bristol  
England  
Telephone: 0272-671881

Catching Engineering  
2101 Roberts Drive  
Broadview, IL 60153  
Telephone: (312) 344-2334

### Air Heaters

Fleetguard, Inc.  
P.O. Box 6001  
Cookeville, TN 38502  
Telephone: (615) 526-9551

Kim Hotstart Co.  
West 917 Broadway  
Spokane, WA 99210  
Telephone: (509) 534-6171

### Air Starting Motors

Ingersoll Rand  
Chorley New Road  
Horwich  
Bolton  
Lancashire  
England  
BL6 6JN  
Telephone: 0204-65544

Ingersoll-Rand Engine  
Starting Systems  
888 Industrial Drive  
Elmhurst, IL 60126  
Telephone: (312) 530-3800

StartMaster  
Air Starting Systems  
A Division of Sycon Corporation  
P. O. Box 491  
Marion, OH 43302  
Telephone: (614) 382-5771

### Alternators

Robert Bosch Ltd.  
P.O. Box 98  
Broadwater Park  
North Orbital Road  
Denham  
Uxbridge  
Middlesex UD9 5HG  
England  
Telephone: 0895-833633

Butec Electric  
Cleveland Road  
Leyland  
PR5 1XB  
England  
Telephone: 0744-21663

C.A.V. Electrical Equipment  
P.O. Box 36  
Warple Way  
London  
W3 7SS  
England  
Telephone: 01-743-3111

A.C. Delco Components Group  
Civic Offices  
Central Milton Keynes  
MK9 3EL  
England  
Telephone: 0908-66001

C. E. Niehoff  
2021 Lee Street  
Evanston, IL 60202  
Telephone: (708) 866-6030

Delco-Remy  
P.O. Box 2439  
Anderson, IN 46018  
Telephone: (317) 646-7838

Leece-Neville Corp.  
1374 E. 51st St.  
Cleveland, OH 44013  
Telephone: (216) 431-0740

### Auxiliary Brakes

The Jacobs Manufacturing Company  
Vehicle Equipment Division  
22 East Dudley Town Road  
Bloomfield, CT 06002  
Telephone: (203) 243-1441

### Belts

Dayco Rubber U.K.  
Sheffield Street  
Stockport  
Cheshire  
SK4 1RV  
England  
Telephone: 061-432-5163

T.B.A. Ind. Products  
P.O. Box 77  
Wigan  
Lancashire  
WN2 4XQ  
England  
Telephone: 0942-59221

Dayco Corp.  
Belt Technical Center  
P.O. Box 3258  
Springfield, MO 65804  
Telephone: (417) 881-7440

Gates Rubber Company  
5610 Crawfordsville Road  
Suite 2002  
Speedway, IN 46224  
Telephone: (317) 248-0386

Goodyear Tire and  
Rubber Company  
49 South Franklin Road  
Indianapolis, IN 46219  
Telephone: (317) 898-4170

### Catalytic Convertors

Donaldson Company, Inc.  
1400 West 94th Street  
P.O. Box 1299  
Minneapolis, MN 55440  
Telephone: (612) 887-3131

Nelson Industries, Inc.  
Exhaust and Filtration Systems  
Highway 51 West, P.O. Box 428  
Stoughton, WI 53589  
Telephone: (608) 873-4373

Walker Manufacturing  
3901 Willis Road  
P.O. Box 157  
Grass Lake, MI 49240  
Telephone: (517) 522-5500

### Clutches

Twin Disc International S.A.  
Chaussee de Namur  
Nivelles  
Belgium  
Telephone: 067-224941

Twin Disc Clutch Co.  
Racine, WI 53403  
Telephone: (414) 634-1981

### Coolant Heaters

Fleetguard, Inc.  
P.O. Box 6001  
Cookeville, TN 38502  
Telephone: (615) 526-9551

### Drive Plates

Detroit Diesel Allison  
Division of General Motors  
Corporation  
P.O. Box 894  
Indianapolis, IN 46206  
Telephone: (317) 244-1511

**Electric Starting Motors**

Butec Electrics  
Cleveland Road  
Leyland  
PR5 1XB  
England  
Telephone: 0744-21663

C.A.V. Electrical Equipment  
P.O. Box 36  
Warple Way  
London  
W3 7SS  
England  
Telephone: 01-743-3111

A.C. Delco Components Group  
Civic Offices  
Central Milton Keynes  
MK9 3EL  
England  
Telephone: 0908-66001

Delco-Remy  
P.O. Box 2439  
Anderson, IN 46018  
Telephone: (317) 646-7838

Leece-Neville Corp.  
1374 E. 51st Street  
Cleveland, OH 44013  
Telephone: (216) 431-0740

Nippondenso Sales, Inc.  
24777 Denso Drive  
P.O. Box 5133  
Southfield, MI 48086-5133  
Telephone: (313) 350-7500

Nippondenso of Los Angeles, Inc.  
3900 Via Oro Avenue  
Long Beach, CA 90810  
Telephone: (310) 834-6352

**Engine Protection Controls**

Teddington Industrial  
Equipment  
Windmill Road  
Sunburn on Thames  
Middlesex  
TW16 7HF  
England  
Telephone: 09327-85500

The Nason Company  
10388 Enterprise Drive  
Davisburg, MI 48019  
Telephone: (313) 625-5381

**Fan Clutches**

Holset Engineering Co. Ltd.  
P.O. Box 9  
Turnbridge  
Huddersfield  
England  
Telephone: 0484-22244

Horton Industries, Inc.  
P.O. Box 9455  
Minneapolis, MN 55440  
Telephone: (612) 378-6410

Rockford Division  
Borg-Warner Corporation  
1200 Windsor Road  
P.O. Box 7007  
Rockford, IL 61125-7007  
Telephone: (815) 633-7460

Transportation Components Group  
Facet Enterprises, Inc.  
Elmira, NY 14903  
Telephone: (607) 737-8212

**Fans**

Truffo Ltd.  
Westwood Road  
Birmingham  
B6 7JF  
England  
Telephone: 021-557-4101

Hayes-Albion  
1999 Wildwood Avenue  
Jackson, MI 49202  
Telephone: (517) 782-9421

Engineering Cooling Systems  
201 W. Carmel Drive  
Carmel, IN 46032  
Telephone: (317) 846-3438

Brookside  
McCordsville, IN 46055  
Telephone: (317) 335-2014

Aerovent  
8777 Purdue Rd.  
Indianapolis, IN 46268  
Telephone: (317) 872-0030

Kysor  
1100 Wright Street  
Cadillac, MI 49601  
Telephone: (616) 775-4681

Schwitzer  
1125 Brookside Avenue  
P.O. Box 80-B  
Indianapolis, IN 46206  
Telephone: (317) 269-3100

**Filters**

Fleetguard International Corp.  
Cavalry Hill Industrial Park  
Weedon  
Northampton NN7 4TD  
England  
Telephone: 0327-41313

Fleetguard, Inc.  
P.O. Box 6001  
Cookeville, TN 38502  
Telephone: (615) 526-9551

**Flexplates**

Corrugated Packing and  
Sheet Metal  
Hamsterley  
Newcastle Upon Tyne  
Telephone: 0207-560-505

Allison Transmission  
Division of General Motors  
Corporation  
P.O. Box 894  
Indianapolis, IN 46206  
Telephone: (317) 244-1511

Allison Transmission  
Division of General Motors  
36501 Van Born Road  
Romulus, MI 48174  
Telephone: (313) 595-5711

Midwest Mfg. Co.  
30161 Southfield Road  
Southfield, MI 48076  
Telephone: (313) 642-5355

Wohler Corporation  
708 East Grand River Avenue  
Lansing, MI 48906  
Telephone: (517) 485-3750

**Fuel Warmers**

Fleetguard, Inc.  
P.O. Box 6001  
Cookeville, TN 38502  
Telephone: (615) 526-9551

**Gauges**

A.I.S.  
Dyffon Industrial Estate  
Ystrad Mynach  
Hengoed  
Mid Glamorgan  
CF8 7XD  
England  
Telephone: 0443-812791

Grasslin U.K. Ltd.  
Vale Rise  
Tonbridge  
Kent  
TN9 1TB  
England  
Telephone: 0732-359888

Icknield Instruments Ltd.  
Jubilee Road  
Letchworth  
Herts  
England  
Telephone: 04626-5551

Superb Tool and Gauge Co.  
21 Princip Street  
Birmingham  
B4 61E  
England  
Telephone: 021-359-4876

Kabi Electrical and Plastics  
Cranborne Road  
Potters Bar  
Herts  
EN6 3JP  
England  
Telephone: 0707-53444

Datcon Instrument Co.  
P.O. Box 128  
East Petersburg, PA 17520  
Telephone: (717) 569-5713

Rochester Gauge of Texas  
11637 Denton Drive  
Dallas, TX 75229  
Telephone: (214) 241-2161

**Governors**

Woodward Governors Ltd.  
P.O. Box 15  
663/664 Ajax Avenue  
Slough  
Bucks  
SL1 4DD  
England  
Telephone: 0753-26835

Woodward Governor Co.  
1000 E. Drake Road  
Fort Collins, CO 80522  
Telephone: (303) 482-5811

Barber Colman Co.  
1300 Rock Street  
Rockford, IL 61101  
Telephone: (815) 877-0241

United Technologies  
Diesel Systems  
1000 Jorie Blvd.  
Oak Brook, IL 60521  
Telephone: (312) 325-2020

### **Heat Sleeves**

Bentley Harris Manufacturing Co.  
100 Bentley Harris Way  
Gordonville, TN 38563  
Telephone: (313) 348-5779

### **Hydraulic and Power Steering Pumps**

Hobourn Eaton Ltd.  
Priory Road  
Stroud  
Rochester  
Kent  
ME2 2BD  
Telephone: 0634-71773

Honeywell Control Systems Ltd.  
Honeywell House  
Charles Square  
Bracknell  
Berks RG12 1EB  
Telephone: 0344-424555

Sundstrand Hydratec Ltd.  
Cheney Manor Trading Estate  
Swindon  
Wiltshire  
SN2 2PZ  
England  
Telephone: 0793-30101

Sperry Vickers  
1401 Crooks Road  
Troy, MI 48084  
Telephone: (313) 280-3000

Z.F.  
P.O. Box 1340  
Grafvonsoden Strasse  
5-9 D7070  
Schwaebisch Gmuend  
West Germany  
Telephone: 7070-7171-31510

### **Oil Heaters**

Fleetguard, Inc.  
P.O. Box 6001  
Cookeville, TN 38502  
Telephone: (615) 526-9551

Kim Hotstart Co.  
West 917 Broadway  
Spokane, WA 99210  
Telephone: (509) 534-6171

### **Torque Converters**

Twin Disc International S.A.  
Chaussee de Namur  
Nivelles  
Belgium  
Telephone: 067-224941

Twin Disc Clutch Co.  
Racine, WI 53403  
Telephone: (414) 634-1981

Rockford Division  
Borg-Warner Corporation  
1200 Windsor Road  
P.O. Box 7007  
Rockford, IL 61125-7007  
Telephone: (815) 633-7460

Modine  
1500 DeKoven Avenue  
Racine, WI 53401  
Telephone: (414) 636-1640

**Section W - Warranty**  
**Section Contents**

	Page
Cummins Warranty International Industrial .....	W-2
Cummins Warranty United States and Canada Industrial .....	W-4
Worldwide Generator Drive Engines .....	W-6



## **Cummins Warranty International Industrial**

### **Coverage**

#### **PRODUCTS WARRANTED**

This warranty applies to new Engines sold by Cummins Engine Company, Inc., hereinafter 'Cummins', and delivered to the first user on or after February 1, 1993, that are used in industrial (off-highway) applications anywhere in the world where Cummins-approved service is available, except the United States\* and Canada. Different warranty coverage is provided for Engines used in marine, generator drive and certain defense applications.

#### **BASE ENGINE WARRANTY**

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or workmanship (Warrantable Failure).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, coverage continues until the end of the first year.

#### **EXTENDED MAJOR COMPONENTS WARRANTY**

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This coverage begins with the expiration of the Base Engine Warranty and ends three years or 10,000 hours of operation, after the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.

### **Cummins Responsibilities**

#### **DURING THE BASE ENGINE WARRANTY**

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to a Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

#### **DURING THE EXTENDED MAJOR COMPONENTS WARRANTY**

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

### **Owners Responsibilities**

#### **DURING THE BASE ENGINE WARRANTY**

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during warranty repairs unless such items are not reusable due to the Warrantable Failure.

#### **DURING THE EXTENDED MAJOR COMPONENTS WARRANTY**

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.



Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

## **DURING THE BASE ENGINE AND EXTENDED MAJOR COMPONENTS WARRANTIES**

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the product available for repair by such facility. Locations are listed in the Cummins International Sales and Service Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

## **Limitations**

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

With certain exceptions, this warranty does not apply to accessories supplied by Cummins which bear the name of another company. The exceptions to which this warranty does apply are:

1. Accessories, except for clutches and filters, supplied by Cummins as part of a fire pump or power unit (package units) are covered for the duration of Base Engine Warranty.
2. Starters, alternators, power steering pumps and non-Cummins air compressors supplied by Cummins on B or C Series Engines in applications other than fire pumps or power units are covered for six months.

Examples of accessories to which this warranty does not apply are: air conditioning compressors, clutches, air cleaners, fans, filters, transmissions and torque convertors.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

**CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.**

**CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

**THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

In case of consumer sales, in some countries, the Owner has statutory rights which cannot be affected or limited by the terms of this warranty.

Nothing in this warranty excludes or restricts any contractual rights the Owner may have against third parties.

\* United States includes American Samoa, the Commonwealth of Northern Mariana Islands, Guam, Puerto Rico and the U.S. Virgin Islands.

## **Cummins Warranty United States and Canada Industrial**

### **Coverage**

#### **PRODUCTS WARRANTED**

This warranty applies to new Engines sold by Cummins Engine Company, Inc., hereinafter 'Cummins', and delivered to the first user on or after February 1, 1993, that are used in industrial (off-highway) applications in the United States\* and Canada, except for Engines used in marine, generator drive and certain defense applications, for which different warranty coverage is provided.

#### **BASE ENGINE WARRANTY**

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or workmanship (Warrantable Failure).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, coverage continues until the end of the first year.

#### **EXTENDED MAJOR COMPONENTS WARRANTY**

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This coverage begins with the expiration of the Base Engine Warranty and ends after three years or 10,000 hours of operation, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

#### **CONSUMER PRODUCTS**

The warranty on Consumer Products in the United States is a LIMITED warranty. **CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Any implied warranties applicable to Consumer Products in the United States terminate concurrently with the expiration of the express warranties applicable to the product. In the United States, some states do not allow the exclusion of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

**These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.**

### **Cummins Responsibilities**

#### **DURING THE BASE ENGINE WARRANTY**

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to the Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

#### **DURING THE EXTENDED MAJOR COMPONENTS WARRANTY**

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

### **Owners Responsibilities**

#### **DURING THE BASE ENGINE WARRANTY**

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items provided during warranty repairs unless such items are not reusable due to the Warrantable Failure.

## **DURING THE EXTENDED MAJOR COMPONENTS WARRANTY**

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

## **DURING THE BASE ENGINE AND EXTENDED MAJOR COMPONENTS WARRANTIES**

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the Engine available for repair by such facility. Locations in the United States and Canada are listed in the Cummins Off Highway Authorized Dealer Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

## **Limitations**

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

For power units and fire pumps (package units), this warranty applies to accessories, except for clutches and filters, supplied by Cummins which bear the name of another company.

Except for power units and fire pumps, this warranty does not apply to accessories which bear the name of another company. This category includes, but is not limited to: alternators, starters, fans, air conditioning compressors, clutches, filters, transmissions, torque converters, steering pumps, and non-Cummins fan drives, engine compression brakes and air compressors.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

**CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.**

**CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

**THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

\* United States includes American Samoa, the Commonwealth of Northern Mariana Islands, Guam, Puerto Rico and the U.S. Virgin Islands.

## Worldwide Generator Drive Engines

### Engines Warranted

This warranty applies to new Engines sold by Cummins Engine Company, Inc., hereinafter 'Cummins', and delivered to the first user on or after June 1, 1993 that are used in generator drive application anywhere in the world where Cummins approved service is available. These Engines will have the following rating designations:

#### Standby Power Rating

Engines of this rating are applicable for supplying emergency power for the duration of the utility power outage. No overload capability is available for this rating. Under no condition is an Engine allowed to operate in parallel with the public utility at the Standby Power rating. This rating should be applied where reliable utility power is available. A standby rated engine is to be sized for a maximum of an 80 percent average load factor and 200 hours of operation per year. This includes less than 25 hours per year at the Standby Power rating. Standby rating should never be applied except in true emergency power outages. Negotiated power outages contracted with a utility company are not considered an emergency.

#### Unlimited Time Running Prime Power Rating

Engines with this rating are available for an unlimited number of hours per year in a variable load application. Variable load is not to exceed a 70 percent average of the Prime Power Rating during any operating period of 250 hours. Total operating time at 100 percent Prime Power shall not exceed 500 hours per year.

A 10 percent overload capability is available for a period of one hour within a twelve hour period of operation. Total operating time at the 10 percent overload power shall not exceed 25 hours per year.

#### Limited Time Running Prime Power Rating

Engines of this rating are available for a limited number of hours in a non-variable load application. It is intended for use in situations where power outages are contracted, such as in utility power curtailment. Engines may be operated in parallel to the public utility up to 750 hours per year at power levels never to exceed the Prime Power rating.

Limited Time Running Prime Power ratings differ from Unlimited Time Running in that even though the maximum power output of the engines are the same, the Limited Time Running allows the Engine to be parallel to Public Utility and run at the full Prime Power rating and must never exceed the Prime Power rating.

#### Continuous/Base Power Rating

Engines with this rating are available for supplying utility power at a constant 100 percent load for an unlimited number of hours per year. No overload capability is available for this rating.

Continuous/Base Power ratings differ from Unlimited Time Running Prime Power ratings in that the Continuous/Base Load ratings are significantly reduced from the Prime Power ratings. Continuous/Base Load ratings have no load factor or application restrictions.

### Coverage

#### Base Engine Warranty

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or workmanship (Warrantable Failure).

Coverage begins with the sale of the Engine by Cummins and continues for the Duration stated below. The Duration commences either on the date of delivery of the Engine to the first user, or on the date the Engine is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first.

#### Base Engine Warranty

Rating	Duration Whichever Occurs First	
	Months	Hours
Standby Power	24	400
Unlimited Prime Power	12	Unlimited
Limited Prime Power	12	750
Continuous/Base Power	12	Unlimited

## Extended Major Components Warranty

The Extended Major Components Warranty applies to Engines other than B and C series and covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts). Bushing and bearing failures are not covered. This coverage begins with the expiration of the Base Engine Warranty and continues for the Duration stated below. The Duration commences either on the date of delivery of the Engine to the first user, or on the date the Engine is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first.

Extended Major Components Warranty		
Rating	Duration Whichever Occurs First	
	Months	Hours
Standby Power	36	600
Unlimited Prime Power	36	10,000
Limited Prime Power	36	2,250
Continuous/Base Power	36	10,000

## Consumer Products

This warranty on Consumer Products in the United States is a LIMITED warranty. **CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Any implied warranties applicable to Consumer Products terminate concurrently with the expiration of the express warranties applicable to the product. In the United States, some states do not allow the exclusion of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.

## Cummins Responsibilities

### During Base Engine Warranty

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure, when performed during normal business hours. All labor costs will be paid in accordance with Cummins published Standard Repair Time guidelines.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to the Warrantable Failure.

Cummins will pay reasonable travel expenses for mechanics to travel to and from the Engine site, including meals, mileage, and lodging when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

### During the Extended Major Components Warranty

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

## Owner's Responsibilities

### During the Base Engine Warranty

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during warranty repairs unless such items are not reusable due to the Warrantable Failure.

### During the Extended Major Components Warranty

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor cost for Engine removal and reinstallation. When Cummins elects to repair a part instead of replacing it, the Owner is not responsible for the labor needed to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

## During the Base Engine and Extended Major Components Warranties

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the Engine available for repair by such facility. Locations in the United States and Canada are listed in the Cummins United States and Canada Sales and Service Directory; other locations are listed in the Cummins International Sales and Service Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

Owner is responsible for providing sufficient access to and reasonable ability to remove the Engine from the installation in the event of a Warrantable Failure.

Owner is responsible for maintaining an operating Engine hourmeter. If the hourmeter is not operational, engine usage will be estimated at 400 hours per month.

## Limitations

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications to the Engine. Cummins is also not responsible for Engine performance problems or failures caused by incorrect oil or fuel, or by water, dirt or other contaminants in the fuel or oil.

This warranty does not apply to accessories supplied by Cummins which bear the name of another company. This category includes, but is not limited to: alternators, starters, fans, air conditioning compressors, clutches, filters, transmissions, air cleaners and safety shutdown switches.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failure of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first after the warranty start date.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

Cummins is not responsible for Engine performance problems or failures resulting from:

1. Use or application of the Engine inconsistent with its rating designation as set forth above.
2. Inadequate or incorrect installations deviating from Cummins Generator Drive Installation Guidelines.

**CUMMINS IS NOT RESPONSIBLE FOR WEAR OR WEAROUT OF COVERED PARTS.**

**CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

**THE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

In the United States\* and Canada, this warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Outside the United States\* and Canada, in case of consumer sales, in some countries, the Owner has statutory rights which cannot be affected or limited by the terms of this warranty.

Nothing in this warranty excludes or restricts any contractual rights the owner may have against third parties.

\*United States includes American Samoa, the Commonwealth of Northern Mariana Islands, Guam, Puerto Rico, and the U.S. Virgin Islands.

**Section L - Service Literature**  
**Section Contents**

	Page
Publication Titles .....	L-2
Service Literature Ordering Location .....	L-3
Service Publications Order Form.....	L-5



## Publication Titles

The following publications can be purchased by filling in and mailing the Service Literature Order Form:

<b>Bulletin No.</b>	<b>Title Of Publication</b>
3810439	Troubleshooting & Repair Manual, L10 Engine, External Damper Models
3810476	Shop Manual, L10 Series Engines - External Damper Models
3810498	Specifications Manual, L10 Series Engines - External Damper Models
3810388	L10 Overhead Reuse Guidelines
3810340	Cummins Engine Oil Recommendations
3810344	PT (Type D) Top Stop Injector Shop Manual
3379001	Fuel for Cummins Engines (QP-20)
3379084	Fuel Pump (PT Type G) Rebuild and Calibrate
3379876	LT, LTA10 Construction Parts Catalog
3384246	LT, LTA10 Agriculture Parts Catalog
3384307	LT, LTA10C Reduced Noise Design Construction Parts Catalog
3810490	Shop and Installation Manual - Rear Engine Power Takeoff



## Service Literature Ordering Location

### Region

United States and Canada

### Ordering Location

Cummins Distributors

or

Cummins Engine Co., Inc.  
Publishing Services CMC 40924  
Box 3005  
Columbus, IN 47202-3005

U.K., Europe, Mid-East, Africa,  
and Eastern European Countries

Cummins Engine Co., Ltd.  
Royal Oak Way South  
Daventry  
Northants, NN11 5NU, England

South and Central America  
(excluding Brazil and Mexico)

Cummins Americas, Inc.  
16085 N.W. 52nd Avenue  
Hialeah, FL 33104

Brazil and Mexico

Cummins Engine Co., Inc.  
International Parts Order Dept., MC 40931  
Box 3005  
Columbus, IN 47202-3005

Far East (excluding  
Australia and New Zealand)

Cummins Diesel Sales Corp.  
Literature Center  
8 Tanjong Penjuru  
Jurong Industrial Estate  
Singapore

Australia and New Zealand

Cummins Diesel Australia  
Maroondah Highway, P.O.B. 139  
Ringwood 3134  
Victoria, Australia

Obtain current price information from your local Cummins Distributor or (for U.S.A.) by calling Cummins Toll Free Number 1-800-DIESELS (1-800-343-7357).



## Literature Order Form

Use this form for prompt handling of your literature order.

Item	Bulletin Number	Title of Publication	Quantity	U.S. Price Each	Amount
1				\$	\$
2					
3					
4					
5					
6					
Order Total					\$

Contact your Cummins distributor for prices and availability.

For problems with literature orders, contact 1-800-DIESELS (1-800-343-7357) (for U.S.A. and Canada).

Prices subject to change without notice.



Mail the Literature Order Form along with your ship-to address to your nearest Cummins distributor.

**FROM:**

Name: \_\_\_\_\_

Street Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip Code: \_\_\_\_\_

Country: \_\_\_\_\_

**SHIP TO: (Name and address where literature is to be shipped)**

Name: \_\_\_\_\_

Street Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip Code: \_\_\_\_\_

Country: \_\_\_\_\_

About the Manual .....	i-2	Cooling System Soluble Oils .....	V-8
Air Cleaner Element .....	4-3	Fleetguard® DCA4 Service Filters and Liquid Pre-Charge .....	V-10
Cartridge Type Element - Cleaning .....	4-5	Heavy Duty Coolant .....	V-7
Cleaning .....	4-3	Cooling Fan .....	3-4
Dual - Heavy Duty Dry-Type Element - Replacement .....	4-4	Inspection .....	3-4
Replacement .....	4-3	Cooling System .....	7-3
Single - Heavy Duty Dry-Type Element .....	4-3	Antifreeze Concentration - Checking .....	7-5
Air Cleaner Restriction .....	4-2	Cleaning and Changing Antifreeze .....	7-3
Checking .....	4-2	Cummins Warranty International Industrial .....	W-2
Vacuum Indicator .....	4-2	Cummins Warranty United States and Canada Industrial .....	W-4
Air Compressor .....	8-18	Cummins/Fleetguard® Filter Specifications .....	V-4
Air Compressor Discharge - Inspection .....	8-18	Definition of Terms .....	i-9
Air Compressor Intake - Inspection .....	8-19	Drive Belt Tension .....	V-17
Inspection .....	8-18	Engine Component Torque Value .....	V-18
Air Compressor Air Cleaner Element (Cummins Two Cylinder Only) .....	5-9	Engine Identification .....	E-2
Replacement .....	5-9	Cummins Engine Nomenclature .....	E-2
Air Intake System .....	4-6	Engine Dataplate .....	E-2
Inspection .....	4-6	Fuel Pump Dataplate .....	E-2
Air Intake System Flow Diagram .....	D-6	Engine Mounting Bolts .....	6-12
Air Starting Motor .....	A-18	Engine Operating Range .....	1-7
Air Starting Motor Maintenance .....	A-18	Engine Operation Report .....	3-2
Air Tanks .....	4-8	Engine Shut-down .....	1-9
Draining .....	4-8	Engine Specifications .....	V-2
Alternator Drive Belt .....	A-3	Air Intake System .....	V-3
Adjustment .....	A-3	Compressed Air System .....	V-3
Replacement .....	A-4	Cooling System .....	V-2
Arctic Operation .....	V-19	Electrical System .....	V-3
Belt Tension .....	3-5	Exhaust System .....	V-3
Checking .....	3-5	Fuel System .....	V-2
Belts .....	3-4	General .....	V-2
Inspection .....	3-4	Lubricating Oil System .....	V-2
Capscrew Markings and Torque Values .....	V-20	Exhaust System Flow Diagram .....	D-7
Capscrew Markings and Torque Values - Metric .....	V-20	Fan Drive Belt .....	A-2
Capscrew Markings and Torque Values - U.S. Customary .....	V-21	Adjustment .....	A-2
Cold Weather Operation .....	1-8	Replacement .....	A-2
Cold Weather Starting (Below 0°C [32°F]) .....	1-4	Fan Hub - Replacement .....	A-14
Using Starting Fluid With Mechanical or Electrical Metering Equipment .....	1-4	Installation .....	A-14
Component Manufacturers' Addresses .....	C-2	Removal .....	A-14
Air Compressors .....	C-2	Fan Hub (Belt Driven) .....	8-16
Air Cylinders .....	C-2	Inspection .....	8-16
Air Heaters .....	C-2	Fan Idler - Replacement .....	A-12
Air Starting Motors .....	C-2	Installation .....	A-13
Alternators .....	C-2	Removal .....	A-12
Auxiliary Brakes .....	C-2	Fan Idler Pulley .....	8-16
Belts .....	C-2	Inspection .....	8-16
Catalytic Convertors .....	C-2	Fuel Filter(s) .....	5-3
Clutches .....	C-2	Replacement .....	5-3
Coolant Heaters .....	C-2	Fuel Pump - Calibration .....	8-13
Drive Plates .....	C-2	Cleaning and Inspection .....	8-14
Electric Starting Motors .....	C-3	Fuel Pump to Air Compressor Installation .....	8-15
Engine Protection Controls .....	C-3	Removal .....	8-13
Fan Clutches .....	C-3	Fuel Recommendations/Specifications .....	V-4
Fans .....	C-3	Fuel System Flow Diagram .....	D-3
Filters .....	C-3	Fuel-Water Separator .....	3-3
Flexplates .....	C-3	Draining .....	3-3
Fuel Warmers .....	C-3	General Information .....	1-2
Gauges .....	C-3	General Information .....	4-2
Governors .....	C-3	General Safety Instructions .....	i-8
Heat Sleeves .....	C-4	Important Safety Notice .....	i-8
Hydraulic and Power Steering Pumps .....	C-4	General Specifications .....	E-3
Oil Heaters .....	C-4	Air Intake System .....	E-4
Torque Converters .....	C-4	Batteries (Specific Gravity) .....	E-4
Compressed Air System Flow Diagrams .....	D-8	Cooling System .....	E-3
Coolant Additive Concentration .....	5-8	Electrical System .....	E-4
Checking .....	5-8	Exhaust System .....	E-4
Coolant Filter .....	5-7	External Engine Components .....	E-5
Replacement .....	5-7	Fuel System .....	E-3
Coolant Flow Diagram .....	D-5	General Engine Data .....	E-3
Coolant Level .....	3-3	Lubricating Oil System .....	E-3
Checking .....	3-3	Hoses .....	6-10
Coolant Recommendations/Specifications .....	V-7	Checking and Replacement .....	6-10
Coolant Blending/Mixing .....	V-9	How to Use the Manual .....	i-2
Coolant Capacity Charts .....	V-11	Illustrations .....	i-7
Cooling System Sealing Additives .....	V-8	Injectors .....	8-3
		Cleaning and Calibration .....	8-3
		Installation .....	8-5

# Index


## Page X-2

Removal .....	8-3	Turbocharger - Replacement .....	A-15
Jacobs® Engine Brakes .....	1-10	Installation .....	A-16
Lubricating Oil and Filter .....	5-4	Removal .....	A-15
Changing .....	5-4	Valves and Injectors - Adjustment .....	6-3
Lubricating Oil Flow Diagram .....	D-4	Jacobs Engine Brake - Adjustment .....	6-9
Lubricating Oil Recommendations/Specifications .....	V-4	Vibration Damper .....	8-3
New Engine Break-in Oils .....	V-4	Inspection .....	8-3
Maintenance Record Form .....	2-5, 2-6	Water Pump .....	6-10
Maintenance Schedule .....	2-3	Inspection .....	6-10
Normal Starting Procedure (Above 0°C [32°F]) .....	1-3	Water Pump - Replacement .....	A-5
Oil Level .....	3-3	Installation .....	A-6
Checking .....	3-3	Removal .....	A-5
Operating the Engine .....	1-6	Worldwide Generator Drive Engines .....	W-6
Page References for Maintenance Instructions .....	2-4		
Power Takeoff Application with Variable Speed Controls .....	1-9		
Publication Titles .....	L-2		
Service Assistance .....	S-2		
Distributors - International .....	S-19		
Distributors and Branches - Australia .....	S-13		
Distributors and Branches - Canada .....	S-12		
Distributors and Branches - New Zealand .....	S-15		
Distributors and Branches - United States .....	S-5		
Division and Regional Offices .....	S-4		
Emergency Service .....	S-2		
Problem Solving .....	S-3		
Regional Offices - International .....	S-16		
Routine Service .....	S-2		
Service Literature Ordering Location .....	L-3		
Shutters and Thermatic Fan .....	6-11		
Checking .....	6-11		
Steam or Chemically Cleaning Engine .....	6-12		
Storage for Engines Out of Service .....	A-18		
Supplemental Coolant Additives .....	V-12		
Instructions For Proper Kit Use .....	V-14		
Precautions .....	V-14		
Test Intervals .....	V-14		
Symbols .....	i-3		
Thermal Control Settings Graph .....	6-11		
Thermostat - Replacement .....	A-9		
Installation .....	A-11		
Removal .....	A-9		
To The Owner and Operator .....	i-2		
Tool Requirements .....	2-2		
Troubleshooting Procedures and Techniques .....	T-2		
Troubleshooting Symptoms .....	T-2		
Air Compressor Air Pressure Rises Slowly .....	T-3		
Air Compressor Noise Excessive .....	T-4		
Air Compressor Pumping Excess Lubricating Oil Into Air System .....	T-5		
Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously) .....	T-6		
Air Compressor Will Not Stop Pumping .....	T-7		
Alternator Not Charging or Insufficient Charging .....	T-8		
Coolant Loss - External .....	T-17		
Coolant Temperature Above Normal - Gradual Overheat .....	T-18		
Coolant Temperature Above Normal - Sudden Overheat .....	T-19		
Coolant Temperature Below Normal .....	T-20		
Crankcase Gases (Blowby) - Excessive .....	T-9		
Engine Cranks But Will Not Start (No Smoke From Exhaust) ..	T-13		
Engine Difficult to Start or Will Not Start - Exhaust Smoke Present .....	T-12		
Engine Power Output Low .....	T-22, T-23		
Engine Starts But Will Not Keep Running .....	T-14		
Engine Will Not Crank or Cranks Slowly ( Electric Starting Motor) .....	T-11		
Engine Will Not Crank or Cranks Slowly (Air Starting Motor) ..	T-10		
Engine Will Not Reach Rated Speed When Loaded .....	T-24		
Engine Will Not Shut Off .....	T-15		
Exhaust Smoke Excessive Under Load .....	T-21		
Lubricating Oil Pressure Low .....	T-16		
White Smoke or Rough Running At Idle (After Warmup Period) ..	T-25		
Turbocharger .....	8-16		
Axial Clearance - Checking .....	8-17		
Checking .....	6-11		
Inspection .....	8-16		
Radial Bearing Clearance - Checking .....	8-17		

[illegible]

[illegible]






NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 15, COLUMBUS INDIANA

—POSTAGE WILL BE PAID BY ADDRESSEE—

CUMMINS ENGINE COMPANY, INC.  
MAIL CODE 41308  
BOX 3005  
COLUMBUS, IN 47202-9982



# Literature Survey Form

We are always open to any suggestions or recommendations that will aid in improving our manuals. Use this postage paid survey form to evaluate this manual. Please check the appropriate response and use the space provided below to list any additional comments:

	Yes	No
Is the needed information easy to locate in the manual?	_____	_____
Is the information easy to read?	_____	_____
Is the information easy to understand?	_____	_____
Does the information sufficiently cover the subject?	_____	_____
Are subjects in the Index specific enough to locate in the manual?	_____	_____
Are the important points sufficiently emphasized?	_____	_____
Are the illustrations easy to understand?	_____	_____
Does the text support the operation being illustrated?	_____	_____
Do you use the Table of Contents?	_____	_____
Do you use the Index?	_____	_____

Please comment on any response(s) marked "No" in this survey. \_\_\_\_\_

Do you have any other comments that you feel would **help** improve the manual? \_\_\_\_\_

Name: \_\_\_\_\_

Company: \_\_\_\_\_

Address: City \_\_\_\_\_ State \_\_\_\_\_ Country \_\_\_\_\_ Zip Code \_\_\_\_\_

Please note the bulletin No. and the printing date on the **back** of the manual you are referencing and fill in the blanks below:

Bulletin No. 3810492-03 Printing Date 6-94