


OPERATOR'S MANUAL

POWERTECH® 4.5 L & 6.8 L Mechanically Controlled OEM Diesel Engines

OMRG25204 Issue 01FEB02 (English)



POWERTECH® 4.5 L & 6.8 L 4045 and 6068 Mechanically-Controlled OEM Diesel Engines

OPERATOR'S MANUAL POWERTECH 4.5/6.8 L Mechanically Controlled OEM Diesel Engines

OMRG25204 Issue 01Feb02 (ENGLISH)

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your engine and should remain with the engine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by standing at the drive or flywheel end (rear) of the engine and facing toward the front of the engine.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

IMPORTANT: This manual covers all PowerTech® 4.5 and 6.8 L OEM diesel engines which are either non-certified or Tier I emission certified. These engines have mechanical fuel systems and were produced at Dubuque Iowa,

from the year 1996 on.

Tier II emission certified engines beginning in the year 2001 are covered in a separate operators manual, OMRG33324. These later **OEM** engines have electronic fuel systems and can be identified by the engine serial number with the suffix "275", as in 6068HF275

Saran France and Torreon Mexico

NOTE: This operators manual covers only engines provided to OEM (Outside Equipment Manufacturers). For engines in Deere machines, refer to the machine operators manual.

OMRGOEM,IFC -19-07JAN02-1/1

Engine Owner

John Deere Engine Owner:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer.

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

Aux Utilisateurs De Moteurs John Deere:

N'attendez pas d'être obligé d'avoir recours a votre concessionnaire John Deere ou point de service le plus proche pour vous adresser a lui.

Renseignez-vous des que possible pour l'identifier et le localiser. A la premiere occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de vous proposer ses services le moment venu.

An Den Besitzer Des John Deere Motors:

Warten Sie nicht auf einen evt. Reparaturfall um den nächstgelegenen John Deere Händler kennen zu lernen.

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

Proprietario Del Motore John Deere:

Non aspetti fino a quando ha bisogno della garanzia o di un altro tipo di assistenza per incontrarsi con il Suo Concessionario che fornisce l'assistenza tecnica.

Impari a conoscere chi è e dove si trova. Alla Sua prima occasione cerchi d'incontrarlo. Egli desidera farsi conoscere e conoscere le Sue necessità.

Propietario De Equipo John Deere:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio.

Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.


John Deere MotorÄgare:

Vänta inte med att besöka Din John Deere återförsäljare till dess att Du behöver service eller garanti reparation.


Bekanta Dig med var han är och vem han är. Tag första tillfälle att besöka honom. Han vill också träffa Dig för att få veta vad Du behöver och hur han kan hjälpa Dig.


DPSG,OUOE003,2736 -19-11JAN99-1/1

POWERTECH® 4.5 L Engines With Mechanical Controls (Tier I Emission Certified)



4045D Engine





4045T Engine



4045T Engine


POWERTECH is a trademark of Deere & Company

RG,RG34710,5501 -19-04JAN02-1/1


POWERTECH® 6.8 L Engines With Mechanical Controls (Tier I Emission Certified)




6068D Engine



6068D Engine



6068T Engine



6068T Engine

POWERTECH is a trademark of Deere & Company

RG,RG34710,5503 -19-04JAN02-1/1

Introduction

Contents

Page	Page
Record Keeping	Generator Set (Standby) Applications15-9
PowerTech Medallion	Starting the Engine
Engine Serial Number Plate 01-1	Warming Engine
Record Engine Serial Number 01-2	Normal Engine Operation
Engine Option Codes	Cold Weather Operation
Record Fuel Injection Pump Model Number 01-5	Changing Engine Speed 15-15
·	Avoid Excessive Engine Idling 15-15
Safety	Stopping the Engine
Suisty	Using a Booster Battery or Charger 15-17
Fuels, Lubricants, and Coolant	Label and a second Marketon and
Diesel Fuel	Lubrication and Maintenance
Lubricity of Diesel Fuel	Observe Service Intervals
Bio-Diesel Fuel	Use Correct Fuels, Lubricants, and Coolant 20-1
Handling And Storing Bio-Diesel Fuel 10-4	Lubrication and Maintenance Service
Diesel Fuel Storage	Interval Chart—Standard Industrial Engines 20-2
Dieselscan Fuel Analysis 10-5	Lubrication and Maintenance Service
Filling Fuel Tank10-6	Interval Chart—Generator (Standby)
Minimizing the Effect of Cold Weather on	Applications
Diesel Engines	
Diesel Engine Break-In Oil	Lubrication & Maintenance/Daily
Diesel Engine Oil	Daily Prestarting Checks
Extended Diesel Engine Oil Service	
Intervals	Lubrication & Maintenance/250 Hour/6 Month
Mixing of Lubricants	Servicing Fire Extinguisher
OILSCAN®and COOLSCAN™	Changing Engine Oil and Replacing Filter 30-2
Alternative and Synthetic Lubricants 10-11	Checking Engine Mounts
Lubricant Storage	Servicing Battery
Grease	Manual Belt Tensioner Adjustment 30-7
Diesel Engine Coolant	Manual Belt Tensioner Adjustment Using
Diesel Engine Coolants, Supplemental	Belt Tension Tool (Alternate Method
Additive Information	For Engines Without Auxiliary Drive)30-8
Testing Diesel Engine Coolant 10-15	
Supplemental Coolant Additives 10-16	Lubrication & Maintenance/500 Hour/12 Month
Operating in Warm Temperature Climates 10-16	Cleaning Crankcase Vent Tube
Disposing of Coolant 10-17	Checking Air Intake System
	Replacing Fuel Filter Element
Engine Operating Guidelines	Checking Belt Tensioner Spring Tension
Instrument (Gauge) Panels	and Belt Wear (Automatic Tensioner) 35-4
Instrument (Gauge) Panel (North America) 15-2	Checking Engine Electrical Ground
VDO Instrument (Gauge) Panel (Except	Connections
North America)	Checking Cooling System
Engine Break-In Service	
Auxiliary Gear Drive Limitations 15-9	Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2002
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRUCTION® Manual
Previous Editions
Copyright © 1996, 2000

Contents


Page	Page
Replenishing Supplemental Coolant Additives (SCAs) Between Coolant Changes	Engine Crankcase Oil Fill Quantities 60-8 Unified Inch Bolt and Cap Screw Torque Values
Lubrication & Maint./2000 Hour/24 Month Adjusting Variable Speed (Droop) on Generator Set Engines	Lubrication and Maintenance Records Using Lubrication and Maintenance Records
Additional Service Information	Statement
Troubleshooting General Troubleshooting Information	
Storage Engine Storage Guidelines	
Specifications General OEM Engine Specifications—4.5 L Engines	

ii

Record Keeping

PowerTech® Medallion

A medallion is located on the rocker arm cover which identifies each engine as a John Deere **Power**TECH® engine.





POWERTECH is a trademark of Deere & Company.


RG,RG34710,5505 -19-04JAN02-1/1

Engine Serial Number Plate

Each engine has a 13-digit John Deere engine serial number. The first two digits identify the factory that produced the engine:

- "T0" indicates the engine was built in Dubuque, Iowa
- "CD" indicates the engine was built in Saran, France
- "PE" indicates the engine was built in Torreon, Mexico
- "J0" indicates the engine was built in Rosario, Argentina

Your engine's serial number plate (A) is located on the right-hand side of cylinder block behind the fuel filter.



13-Digit Engine Serial Number Plate

RG,RG34710,5506 -19-04JAN02-1/1

Record Engine Serial Number

Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.

Engine Serial Number (B)

Engine Model Number (C)

Coefficient of Absorption Value (D) (Saran Engines Only)



Dubuque Engine Serial Number Plate




Saran Engine Serial Number Plate



Torreon Engine Serial Number Plate

RG,RG34710,5507 -19-04JAN02-1/1

Engine Option Codes



Engine Option Codes

A-Engine Base Code

In addition to the serial number plate, OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

NOTE: These option codes are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The list on the next page shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

Continued on next page

RG,RG34710,5508 -19-04JAN02-1/2

NOTE: Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

> If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

An additional option code label may also be delivered with the engine. Place this sticker or tag, for reference, either on this page or in the engine owner's warranty booklet under OPTION CODES title.

Option Codes	Description	Option Codes	Description
11	Rocker Arm Cover	45	Balancer Shafts
12	_ Oil Fill Inlet	46	Cylinder Block With Liners and Camshaft
13	Crankshaft Pulley	47	Crankshaft and Bearings
14	Flywheel Housing	48	Connecting Rods and Pistons
15	Flywheel	49	Valve Actuating Mechanism
16	Fuel Injection Pump	50	Oil Pump
17	Air Inlet	51	Cylinder Head With Valves
18	Air Cleaner	52	Auxiliary Gear Drive
19	Oil Pan	55	Shipping Stand
20	Coolant Pump	56	Paint Option
21	_ Thermostat Cover	57	Coolant Pump Inlet
22	Thermostat	59	Oil Cooler
23	Fan Drive	60	Add-on Auxiliary Drive Pulley
24	Fan Belt	62	Alternator Mounting Bracket
25	Fan	64	Exhaust Elbow
26	Engine Coolant Heater	65	Turbocharger
27	Radiator	66	Temperature Switch
28	Exhaust Manifold	67	Electronic Tachometer Sensor
29	Ventilator System	68	Crankshaft Rear Damper
30	Starter Motor	69	Engine Serial Number Plate
31	Alternator	74	Air Conditioning (Freon) Compressor
32	Instrument Panel	75	Air Restriction Indicator
33	Tachometer	76	Oil Pressure Switch
35	Fuel Filters	78	Air Compressor
36	Front Plate	81	Water Separator
37	Fuel Transfer Pump	86	Fan Pulley
39	Thermostat Housing	87	Belt Tensioner
40		88	Oil Filter
41	Belt-Driven Front Auxiliary Drive	95	Special Equipment (Factory Installed)
43	Starting Aid	97	Special Equipment (Field Installed)
44	Timing Gear Cover With Gears	98	Shipping
		99	Service Only Items

_ Engine Base Code

RG,RG34710,5508 -19-04JAN02-2/2


Record Keeping

Record Fuel Injection Pump Model Number

Record the fuel injection pump model and serial information found on the serial number plate (A).

Model No.	RPM
Manufacturer's No	
Serial No	

A—Serial Number Plate



Record Injection Pump Serial Number


RG,RG34710,5511 -19-20MAY96-1/1

Safety

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

A DANGER

AWARNING

A CAUTION

S187 -19-30S

DX,SIGNAL -19-03MAR93-1/1


Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




11 -UN-23AUG88

DX,READ -19-03MAR93-1/1

Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



Prevent Bypass Starting

Avoid possible injury or death from engine runaway.

Do not start engine by shorting across starter terminal. Engine will start with PTO engaged if normal circuitry is bypassed.

Start engine only from operator's station with PTO disengaged or in neutral.



RG,RG34710,7508 -19-30JUN97-1/1

Handle Fuel Safely—Avoid Fires

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.




DX,FIRE1 -19-03MAR93-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93-1/1

Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



1356 -UN-18ľ

DX,FIRE3 -19-16APR92-1/1

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure engine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.




27 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

Service Engines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near engine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR -19-10SEP90-1/1

Protect Against Noise

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



FS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



1644 -

DX,PTO -19-12SEP95-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.




DX,SERV -19-17FEB99-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area




Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




DX,FLUID -19-03MAR93-1/1

-UN-23AUG88

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.


Remove paint before heating:

- Remove paint a minimum of 76 mm (3 in.) from area to be affected by heating.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.



DX,PAINT -19-19JUL01-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.




Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



DX,DUST -19-15MAR91-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling or dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Do not induce vomiting.
- 2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
- 3. Get medical attention immediately.




DX.POISON -19-21APR93-1/1

Protect Against High Pressure Spray

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,SPRAY -19-16APR92-1/1

Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93-1/1

Fuels, Lubricants, and Coolant

Diesel Fuel

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

Required fuel properties

In all cases, the fuel must meet the following properties:

Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1500 m (5000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum load level of 3100 grams as measured by ASTM D6078 or, maximum scar diameter of 0.45 mm as measured by ASTM D6079.

Sulfur content:

- Diesel fuel quality and fuel sulfur content must comply with all existing regulations for the area in which the engine operates.
- Sulfur content less than 0.05% (500 ppm) is preferred.
- If diesel fuel with sulfur content greater than 0.05% (500 ppm) is used, crankcase oil service intervals may be affected. (See recommendation for Diesel Engine Oil.)
- DO NOT use diesel fuel with sulfur content greater than 1.0%.

IMPORTANT: DO NOT mix used engine oil or any other type of lubricating oil with diesel fuel.

OUOD002,0000171 -19-18DEC01-1/1

10-1

Lubricity of Diesel Fuel

Diesel fuel must have adequate lubricity to ensure proper operation and durability of fuel injection system components.

Diesel fuels for highway use in the United States and Canada require sulfur content less than 0.05% (500 ppm).

Diesel fuel in the European Union requires sulfur content less than 0.05% (500 ppm).

Experience shows that some low sulfur diesel fuels may have inadequate lubricity and their use may reduce performance in fuel injection systems due to inadequate lubrication of injection pump components. The lower concentration of aromatic compounds in these fuels also adversely affects injection pump seals and may result in leaks.

Use of low lubricity diesel fuels may also cause accelerated wear, injection nozzle erosion or corrosion, engine speed instability, hard starting, low power, and engine smoke.

Fuel lubricity should pass a minimum load level of 3100 gram as measured by the ASTM D6078 or maximum scar diameter of 0.45 mm as measured by ASTM D6079.

ASTM D975 and EN 590 specifications do not require fuels to pass a fuel lubricity test.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER (or equivalent) at the specified concentration.

OUOD002,0000179 -19-18DEC01-1/1

Bio-Diesel Fuel

Consult your local fuel distributor for properties of the bio-diesel fuel available in your area.

Bio-diesel fuels may be used ONLY if the bio-diesel fuel properties meet the latest edition of ASTM PS121, DIN 51606 or equivalent specification.

It has been found that bio-diesel fuels may improve lubricity in concentrations up to a 5% blend in petroleum diesel fuel.

When using a blend of bio-diesel fuel, the engine oil level must be checked daily when the air temperature is -10°C (14°F) or lower. If the oil becomes diluted with fuel, shorten oil change intervals accordingly.

IMPORTANT: Raw pressed vegetable oils are NOT acceptable for use for fuel in any concentration in John Deere engines.

These oils do not burn completely, and will cause engine failure by leaving deposits on injectors and in the combustion chamber.

A major environmental benefit of bio-diesel fuel is its ability to biodegrade. This makes proper storage and handling of bio-diesel fuel especially important. Areas of concern include:

- Quality of new fuel
- · Water content of the fuel
- Problems due to aging of the fuel

Potential problems resulting from deficiencies in the above areas when using bio-diesel fuel in concentrations above 5% may lead to the following symptoms:

- Power loss and deterioration of performance
- Fuel leakage
- Corrosion of fuel injection equipment
- Coked and/or blocked injector nozzles, resulting in engine misfire
- Filter plugging
- Lacquering and/or seizure of internal components
- Sludge and sediments
- Reduced service life of engine components

RG41183,0000046 -19-18DEC01-1/1

Handling And Storing Bio-Diesel Fuel



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

Keep all storage tanks as full as practicable to minimize condensation.

Ensure that all fuel tank caps and covers are installed properly to prevent moisture from entering.

Monitor water content of the fuel regularly.

Fuel filter may require more frequent replacement due to premature plugging.

Check engine oil level daily prior to starting engine. A rising oil level may indicate fuel dilution of the engine oil.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and prevent water condensation. Contact your fuel supplier for recommendations.

OUOD002,0000176 -19-18DEC01-1/1

10-4

Diesel Fuel Storage



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

IMPORTANT: DO NOT store diesel fuel in galvanized containers. Diesel fuel stored in galvanized containers reacts with zinc coating on container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters, damage injection nozzles and injection pump.

> DO NOT use brass-coated containers for fuel storage. Brass is an alloy of copper and zinc.

Store diesel fuel in plastic, aluminum, and steel containers specially coated for diesel fuel storage.

Avoid storing fuel over long periods of time. If fuel is stored for more than a month prior to use, or there is a slow turnover in fuel tank or supply tank, add a fuel conditioner such as John Deere PREMIUM DIESEL FUEL CONDITIONER or equivalent to stabilize the fuel and prevent water condensation. John Deere PREMIUM DIESEL FUEL CONDITIONER is available in winter and summer formulas. Fuel conditioner also reduces fuel gelling and controls wax separation during cold weather.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace with an original vented cap.

RG,RG34710,7526 -19-18DEC01-1/1

Dieselscan Fuel Analysis

DIESELSCAN™ is a John Deere fuel sampling program to help you monitor the quality of your fuel source. It verifies fuel type, cleanliness, water content, suitability for cold weather operation, and if fuel is within ASTM specifications. Check with your John Deere dealer for availability of DIESELSCAN kits.

DIESELSCAN is a trademark of Deere & Company

DX,FUEL6 -19-06DEC00-1/1

Filling Fuel Tank



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while filling fuel tank or servicing fuel system.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented

Fill fuel tank at the end of each day's operation to prevent condensation in tank. As moist air cools, condensation may form and freeze during cold weather.



RG,RG34710,7527 -19-30JUN97-1/1

Minimizing the Effect of Cold Weather on Diesel Engines

John Deere diesel engines are designed to operate effectively in cold weather.

However, for effective starting and cold weather operation, a little extra care is necessary. The information below outlines steps that can minimize the effect that cold weather may have on starting and operation of your engine. See your authorized engine distributor or servicing dealer for additional information and local availability of cold weather aids.

Use Grade No. 1-D Fuel

When temperatures fall below 5°C (40°F), Grade No. 1-D fuel is best suited for cold weather operation. Grade No. 1-D fuel has a lower cloud point and a lower pour point.

Cloud point is the temperature at which wax will begin to form in the fuel and this wax causes fuel filters to plug. **Pour point** is the temperature at which fuel begins to thicken and becomes more resistant to flow through fuel pumps and lines.

NOTE: On an average, Grade No. 1-D fuel has a lower BTU (heat content) rating than Grade No. 2-D fuel. When using Grade No. 1-D fuel you may notice a drop in power and fuel efficiency, but should not experience any other engine performance effects. Check the grade of fuel being used before troubleshooting for low power complaints in cold weather operation.

Coolant Heaters

Engine block heaters (coolant) are an available option to aid cold weather starting.

Seasonal Viscosity Oil and Proper Coolant Concentration

Use seasonal grade viscosity engine oil based on expected air temperature range between oil changes

and a proper concentration of low silicate antifreeze as recommended. (See DIESEL ENGINE OIL and ENGINE COOLANT REQUIREMENTS later in this section).

Diesel Fuel Flow Additive

IMPORTANT: Treat fuel when outside temperature drops below 0°C (32°F). For best results, use with untreated fuel. Follow all recommended instructions on label.

Use John Deere Premium Diesel Fuel Conditioner (Winter) or equivalent to treat fuel during the cold weather season. This winter formulation is a combination diesel fuel conditioner and anti-gel additive.

Winterfronts

Use of fabric, cardboard, or solid winterfronts is not recommended with any John Deere engine. Their use can result in excessive engine coolant, oil, and charge air temperatures. This can lead to reduced engine life, loss of power and poor fuel economy. Winterfronts may also put abnormal stress on fan and fan drive components potentially causing premature failures.

If winterfronts are used, they should never totally close off the grill frontal area. Approximately 25% area in the center of the grill should remain open at all times. At no time should the air blockage device be applied directly to the radiator core.

Radiator Shutters

If equipped with a thermostatically controlled radiator shutter system, this system should be regulated in such a way that the shutters are completely open by the time the coolant reaches 93°C (200°F) to prevent excessive intake manifold temperatures. Manually controlled systems are not recommended.

Continued on next page

RG,RG34710,7529 -19-30JUN97-1/2

If air-to-air aftercooling is used, the shutters must be completely open by the time the intake manifold air temperature reaches the maximum allowable temperature out of the charge air cooler. For more information, see your John Deere engine distributor or servicing dealer.

RG,RG34710,7529 -19-30JUN97-2/2

Diesel Engine Break-In Oil

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level.

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CD
- API Service Classification CC
- ACEA Specification E1

After the break-in period, use John Deere PLUS-50® or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use PLUS-50 oil or engine oils meeting any of the following during the first 100 hours of operation of a new or rebuilt engine:

- API CI-4
- ACEA E5
- API CH-4
- ACEA E4
- API CG-4
- ACEA E3API CF-4
- ACEA E2

These oils will not allow the engine to break-in properly.

PLUS-50 is a registered trademark of Deere & Company.

OUOD002,0000178 -19-17DEC01-1/1

Diesel Engine Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred:

John Deere PLUS-50[®]

The following oil is also recommended:

• John Deere TORQ-GARD SUPREME®


Other oils may be used if they meet one or more of the following:

- API Service Classification CI-4
- API Service Classification CH-4
- API Service Classification CG-4
- API Service Classification CF-4
- ACEA Specification E5
- ACEA Specification E4
- ACEA Specification E3
- ACEA Specification E2

Multi-viscosity diesel engine oils are preferred.

If diesel fuel with sulfur content greater than 0.5% (5000 ppm) is used, reduce the service interval by 50%.

Extended service intervals may apply when John Deere preferred engine oils are used. Consult your John Deere dealer for more information.



PLUS-50 is a registered trademark of Deere & Company.
TORQ-GARD SUPREME is a registered trademark of Deere & Company

OUOD007,0000034 -19-08JAN02-1/1

10-9 ₀₂₀

Extended Diesel Engine Oil Service Intervals

When John Deere PLUS-50® oil and the specified John Deere filter are used, the service interval for engine oil and filter changes may be increased by 50% or to every 375 hours.

If other than PLUS-50® oil and the specified John Deere filter are used, change the engine oil and filter at the normal service interval.

PLUS-50 is a trademark of Deere & Company PLUS-50 is a trademark of Deere & Company. In Europe, oils meeting ACEA E5 standard can also be used.

OUOD002,0000165 -19-10JAN02-1/1

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere engine distributor or servicing dealer to obtain specific information and recommendations.


DX,LUBMIX -19-18MAR96-1/1

OILSCAN®and COOLSCAN™

OILSCAN,® OILSCAN PLUS,® COOLSCAN™ and, COOLSCAN PLUS™ are John Deere sampling programs to help you monitor machine performance and identify potential problems before they cause serious damage.

Oil and coolant samples should be taken from each system prior to its recommended change interval.

Check with your John Deere engine distributor or servicing dealer for the availability of OILSCAN,® OILSCAN PLUS,® COOLSCAN™ and, COOLSCAN PLUS™ kits.



Recommended Change Interval

OUOD002,0000173 -19-23NOV01-1/1

OILSCAN is a registered trademark of Deere & Company. COOLSCAN is a trademark of Deere & Company. OILSCAN PLUS is a registered trademark of Deere & Company. COOLSCAN PLUS is a trademark of Deere & Company.

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-15JUN00-1/1

Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation. Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

Grease

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following greases are preferred:

• John Deere SD POLYUREA GREASE


The following greases are also recommended:

- John Deere HD MOLY GREASE
- John Deere HD LITHIUM COMPLEX GREASE
- John Deere HD WATER RESISTANT GREASE
- John Deere GREASE-GARD

Other greases may be used if they meet the following:

• NLGI Performance Classification GC-LB

IMPORTANT: Some types of grease thickener are not compatible with others. Consult your grease supplier before mixing different types of grease.



DX,GREA1 -19-24JAN00-1/1

Diesel Engine Coolant

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F).

The following engine coolant is preferred for service:

• John Deere COOL-GARD Prediluted Coolant

The following engine coolant is also recommended:

• John Deere COOL-GARD Coolant Concentrate in a 40 to 60% mixture of concentrate with quality water.

Other low silicate ethylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D5345 (prediluted coolant)
- ASTM D4985 (coolant concentrate) in a 40 to 60% mixture of concentrate with quality water

Coolants meeting these specifications require use of supplemental coolant additives, formulated for heavy-duty diesel engines, for protection against corrosion and cylinder liner erosion and pitting.

A 50% mixture of ethylene glycol engine coolant in water provides freeze protection to -37°C (-34°F). If protection at lower temperatures is required, consult your John Deere dealer for recommendations.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

Coolant Drain Intervals

Drain the factory fill engine coolant, flush the cooling system, and refill with new coolant after the first 3 years or 3000 hours of operation. Subsequent drain intervals are determined by the coolant used for service. At each interval, drain the coolant, flush the cooling system, and refill with new coolant.

When John Deere COOL-GARD is used, the drain interval may be extended to 5 years or 5000 hours of operation, provided that the coolant is tested annually AND additives are replenished, as needed, by adding a supplemental coolant additive.

If COOL-GARD is not used, the drain interval is reduced to 2 years or 2000 hours of operation.

Diesel Engine Coolants, Supplemental Additive Information

Engine coolants are a combination of three chemical components: ethylene glycol (antifreeze), inhibiting coolant additives, and quality water.

Coolant Specifications

Some products, including John Deere John Deere COOL-GARD Prediluted Coolant, are fully formulated coolants that contain all three components in their correct concentrations. Do not add an initial charge of supplemental coolant additives to these fully formulated products.

Some coolant concentrates, including John Deere COOL-GARD Coolant Concentrate, contain both ethylene glycol antifreeze and inhibiting coolant additives. Mix these products and quality water, but do not add an initial charge of supplemental coolant additives.

Coolants meeting ASTM D5345 (prediluted coolant) or ASTM D4985 (coolant concentrate) require an initial charge of supplemental coolant additives.

Replenish Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD is used. Follow the recommendations in this manual for the use of supplemental coolant additives.

Why Use Supplemental Coolant Additives?

Operating without proper coolant additives will result in increased corrosion, cylinder liner erosion and pitting, and other damage to the engine and cooling system. A simple mixture of ethylene glycol and water will not give adequate protection.

Use of supplemental coolant additives reduces corrosion, erosion, and pitting. These chemicals reduce the number of vapor bubbles in the coolant and

help form a protective film on cylinder liner surfaces. This film acts as a barrier against the harmful effects of collapsing vapor bubbles.

Avoid Automotive-Type Coolants

Never use automotive-type coolants (such as those meeting ASTM D3306 or ASTM D4656). These coolants do not contain the correct additives to protect heavy-duty diesel engines. They often contain a high concentration of silicates and may damage the engine or cooling system.

Water Quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate. All water used in the cooling system should meet the following minimum specifications for quality:

Chlorides	<40 mg/L
Sulfates	<100 mg/L
Total Dissolved Solids	<340 mg/L
Total Hardness	<170 mg/L
рН	5.5 to 9.0

Freeze Protection

The relative concentrations of ethylene glycol and water in the engine coolant determine its freeze protection limit.

Ethylene Glycol	Freeze Protection Limit		
40%	-24°C (-12°F)		
50%	-37°C (-34°F)		
60%	-52°C (-62°F)		

DO NOT use a coolant-water mixture greater than 60% ethylene glycol.

DX,COOL7 -19-24JAN00-1/1

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 month or less and whenever excessive coolant is lost through leaks or overheating.

Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN™ and COOLSCAN PLUS™

For a more thorough evaluation of your coolant, perform a COOLSCAN or COOLSCAN PLUS™ analysis. See your John Deere dealer for information.



Coolant Test Strips



CoolScan Bellows

3G7397 -UN-05DEC97

3G7297 -UN-22SEP99

COOLSCAN is a trademark of Deere & Company COOLSCAN PLUS is a trademark of Deere & Company.

OUOD002,0000174 -19-18DEC01-1/1

Supplemental Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. For all recommended coolants, replenish additives between drain intervals by adding a supplemental coolant additive every 12 months or as determined necessary by coolant testing.

John Deere COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

IMPORTANT: Do not add a supplemental coolant additive when the cooling system is drained and refilled with John Deere COOL-GARD.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

DX,COOL4 -19-15JUN00-1/1

Operating in Warm Temperature Climates

John Deere engines are designed to operate using glycol base engine coolants.

Always use a recommended glycol base engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant in emergency situations only.

> Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation will occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended glycol base engine coolant as soon as possible.

DX,COOL6 -19-18MAR96-1/1


Disposing of Coolant

Improperly disposing of engine coolant can threaten the environment and ecology.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere engine distributor or servicing dealer.



TS1133 -UN-26NOV90

RG,RG34710,7543 -19-30JUN97-1/1

Engine Operating Guidelines

Instrument (Gauge) Panels


All controls and gauges are optional equipment for John Deere OEM Engines. They may be provided by the equipment manufacturer instead of John Deere. The following information applies only to those controls and gauges provided by John Deere.

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

Two types of instrument panels are offered on 4.5 L and 6.8 L engines, as shown on this page. See following for complete information on each type of instrument panel.



North American Instrument Panel



VDO Instrument Panel (Except North America)

RG10606A -UN-19JUN00

RG11299 -UN-12SEP00

DPSG,RG34710,107 -19-10JAN02-1/1

Instrument (Gauge) Panel (North America)

All controls and gauges are optional equipment for John Deere OEM Engines. They may be provided by the equipment manufacturer instead of John Deere. The following information applies only to those controls and gauges provided by John Deere.

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

Following is a brief description of the components on the instrument (gauge) panel:

A—Oil Pressure Gauge - This gauge indicates oil pressure. It also has an adjustable electrical contact which activates the safety switch when oil pressure goes below the pressure set point. This will automatically stop the engine.


B—Coolant Temperature Gauge - This gauge indicates coolant temperature. It also has an electrical contact which activates the safety switch when coolant temperature goes above the temperature set point. This will automatically stop the engine.

C—Key Switch - The key switch is used to start and stop the engine. A key is required to operate the switch so as to prevent unauthorized operation of the engine.


D—Tachometer - The tachometer indicates engine speed in hundreds of revolutions per minute (rpm).

E—Safety Switch (Reset Button) - The safety switch de-energizes the fuel shut-off solenoid or injection rack puller to stop the engine, if one or more conditions are met:

- · Low or no oil pressure
- High coolant temperature
- Low crankcase oil level (if equipped with engine oil level switch)
- High crankcase oil level (if equipped with engine oil level switch)



North American Instrument Panel



Hour Meter And Tachometer Codes

- A-Oil Pressure Gauge
- **B**—Coolant Temperature Gauge
- C-Key Switch
- D—Tachometer
- E-Reset (Safety) Switch
- F—Fuse Holder (14 Amp Fuse)
- G—Ammeter
- H—Hourmeter
- I—Hand Throttle
- J-Tachometer Binary Code

Continued on next page

DPSG,RG34710,108 -19-08JAN02-1/2

3G11299B -UN-17AUG00

The reset button has to be held in when starting the engine. The button allows the safety switch to override the shut-down circuits until safe engine oil pressure is maintained. Once engine oil pressure is within specifications, the safety switch will latch and the reset button can be released.

F—Fuse Holder - Contains 14 amp fuse.

G—Ammeter - The ammeter indicates the rate of charge (+) or discharge (—) of the battery. When the engine is first started, the ammeter will usually indicate a charge rate of approximately 30 amps. After a short period of operation, the ammeter needle will point slightly to the right of "0", indicating the charging system is operating normally. A problem with the charging system is indicated if the ammeter needle points to the left of "0" during engine operation.

H-Hour Meter - The hour meter operates when the engine is operating, or when the reset button is manually held in while the key switch is in the ON position. The accumulated hours are displayed in hours and tenths of hours. On some panels, the hourmeter may be separate from the tachometer.

I—Hand Throttle - The hand throttle is used to manually control engine speed. If the hand throttle is electronic (as shown), turn the knob clockwise or counterclockwise to change engine speed. If the hand throttle is mechanical (not shown), turning the handle, either clockwise or counterclockwise, will lock the throttle position. Turn the handle half way between the two lock positions to unlock the throttle.

J—Tachometer Binary Code - The tachometer is calibrated to the number of flywheel gear teeth read. The dip switch to set the binary code is located in back of tachometer and must be set at "10110011" to operate at 30 pulses per revolution.

DPSG,RG34710,108 -19-08JAN02-2/2

VDO Instrument (Gauge) Panel (Except North America)

All controls and gauges are optional equipment for John Deere OEM Engines. They may be provided by the equipment manufacturer instead of John Deere. The following information applies only to those controls and gauges provided by John Deere.

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

Following is a brief description of the components on the instrument (gauge) panel:

A—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure.

B—Coolant Temperature Gauge - The coolant temperature gauge indicates coolant temperature.


C—Tachometer - The tachometer indicates engine speed in hundreds of revolutions per minute (rpm).

The engine control system consists of the following:

D—Engine Control Light - The engine control light illuminates after the engine has started and oil pressure is up to specification. The light indicates that the engine protection circuitry is activated.

E—Preheater Light - The preheater light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. When the key switch is held in position II, the engine preheater is energized and the preheater light illuminates.

F—Fuel Level Light - The fuel level light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine runs out of fuel, the light will illuminate and protection circuitry will stop the engine. The fuel level light will remain on indicating the engine was stopped due to the fuel tank being empty.



VDO Instrument Panel

- A—Oil Pressure Gauge
- **B**—Coolant Temperature Gauge
- C—Tachometer
- **D**—Engine Control Light
- E—Preheater Light
- F-Fuel Level Light
- **G**—Battery Light
- H-Oil Pressure Light
- I—Coolant Temperature Light
- J-Key/Start Switch
- K—Hour Meter

G—Battery Light - The battery light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the alternator stops charging, the light will illuminate and protection circuitry will stop the engine. The battery light will remain on indicating the engine was stopped due to the alternator not charging.

H—Oil Pressure Light - The oil pressure light illuminates when the key switch is turned to the bulb test position (position I). The light will remain on until the engine is started and the specified oil pressure is reached. If oil pressure is lost during engine operation, the light will illuminate and protection circuitry will stop the engine. The oil pressure light will remain on, indicating that the engine was stopped due to a low oil pressure condition.

I—Coolant Temperature Light - The coolant temperature light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine overheats, the light will illuminate and protection circuitry will stop the engine. The coolant temperature light will remain on indicating the engine was stopped due to the engine overheating.

Other components on the instrument panel:

 $\mbox{\bf J--Key/Start~Switch}$ - The four-position key start switch controls the electrical system.

K—Hour Meter - The hour meter is an integral part of the tachometer. It shows the accumulated hours of engine service. The hour meter operates when the engine is running and accumulated hours are displayed in hours and tenths of hours.

DPSG,RG34710,109 -19-08JAN02-2/2

Engine Break-In Service

The engine is ready for normal operation. However, extra care during the first 100 hours of operation will result in more satisfactory long-term engine performance and life. DO NOT exceed 100 hours of operation with break-in oil.

- 1. This engine is factory-filled with John Deere ENGINE BREAK-IN OIL. Operate the engine at heavy loads with minimal idling during the break-in period.
- 2. If the engine has significant operating time at idle, constant speeds, and/or light load usage, or makeup oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, an additional 100 hour break-in period is recommended using a new change of John Deere ENGINE BREAK-IN OIL and a new John Deere oil filter.





Check Engine Oil

Continued on next page

RG,RG34710,5553 -19-07JAN02-1/4

IMPORTANT: DO NOT add makeup oil until the oil level is BELOW the ADD mark on dipstick. John Deere ENGINE BREAK-IN OIL (TY22041) should be used to make up any oil consumed during the break-in period.





DO NOT fill above the crosshatch pattern (A) or the FULL mark, whichever is present. Oil levels anywhere within the crosshatch are considered in the acceptable operating range.

Specification

Engine ¹ —Oil Pressure at Full	
Load Rated Speed	$345 \pm 103 \text{ kPa} (3.45 \pm 1.03 \text{ bar})$
	$(50 \pm 15 \text{ psi})$
Minimum Oil Pressure at Rated	
Speed	275 (2.75 bar) (40 psi)
Minimum Oil Pressure at 850 rpm	105 kPa (1.05 bar) (15 psi)
Coolant Temperature Range	82°-94°C (180°-202°F)

PLUS-50 is a trademark of Deere & Company.

¹At normal operating temperature of 115°C (240°F) sump.

RG8028A -UN-15JAN99

Crosshatch Pattern On Oil Dipstick

A-Crosshatch Pattern On Oil Dipstick

Continued on next page

RG,RG34710,5553 -19-07JAN02-2/4

15-7

- 4. During the first 20 hours, avoid prolonged periods of engine idling or sustained maximum load operation. If engine will idle longer than 5 minutes, stop engine.
- Before the first 100 hours (maximum), change engine oil and replace engine oil filter. (See CHANGING ENGINE OIL AND REPLACING OIL FILTER in Lubrication and Maintenance/250 Hour/6 Month Section.) Fill crankcase with seasonal viscosity grade oil. (See DIESEL ENGINE OIL, in Fuels, Lubricants, and Coolant Section.)

NOTE: Some increase in oil consumption may be expected when low viscosity oils are used. Check oil levels more frequently.

If air temperature is below -10 $^{\circ}$ C (14 $^{\circ}$ F), use an engine block heater.



Changing Oil And Oil Filter Before First 100 Hours

RG,RG34710,5553 -19-07JAN02-3/4

- Watch coolant temperature gauge (A) closely. If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop the engine and determine the cause before resuming operation.
- NOTE: When the coolant temperature gauge reads approximately 115°C (239°F), the engine will shutdown automatically, if equipped with safety controls.
- 7. Check poly-vee belt for proper alignment and seating in pulley grooves.
 - A—Coolant Temperature Gauge



North American (1999—) Instrument Panel Shown

3G11299F -UN-17AUG00


RG,RG34710,5553 -19-07JAN02-4/4

Auxiliary Gear Drive Limitations

IMPORTANT: When attaching an air compressor, hydraulic pump, or other accessory to be driven by the auxiliary gear drive (A) (engine timing gear train at front of engine), power requirements of the accessory must be limited to values listed below:

- 30 kW (40 hp) Continuous Operation at 2500 rpm
- 37 kW (50 hp) Intermittent Operation at 2500 rpm

A-Auxiliary Gear Drive



RG,RG34710,5555 -19-20MAY96-1/1

Generator Set (Standby) Applications

To assure that your engine will deliver efficient standby operation when needed, start engine and run at rated speed (with 50%-70% load) for 30 minutes every 2 weeks. DO NOT allow engine to run extended period of time with no load.


RG,RG34710,5556 -19-20MAY96-1/1

Starting the Engine


The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network. The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.



CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.



- 1. Perform all prestarting checks outlined in Lubrication & Maintenance/Daily Section later in this manual.
- 2. Open the fuel supply shut-off valve, if equipped.
- 3. Disengage clutch (if equipped) controlling any engine drivelines.



Use Proper Ventilation

Continued on next page

RG,RG34710,5557 -19-07JAN02-1/2

NOTE: Electronically controlled governor applications may be equipped with a rotary speed potentiometer on the throttle (A) on the instrument panel.

- 4. On mechanical governor (7-10% regulation) engines, pull hand throttle (A) 1/3 of the way out. Turn the handle in either direction to lock it in place.
- 5. If equipped, depress and hold reset button (B) while starting.

IMPORTANT: Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see Troubleshooting Section.

6. Turn the key switch (C) clockwise to crank the engine. When the engine starts, release the key so that it returns to the "ON" position.


IMPORTANT: If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This will prevent possible damage to the starter and/or flywheel.

7. After the engine starts, continue to hold the reset button in until the oil pressure gauge (D) reads at least 105 kPa (1.05 bar) (15 psi). The safety controls will not allow the engine to run at a lower oil pressure unless the reset button is held in.


IMPORTANT: Should the engine die when operating under load, immediately disengage PTO clutch and restart the engine.

Overheating of turbocharger parts may occur when oil flow is stopped.

8. Check all gauges for normal engine operation. If operation is not normal, stop the engine and determine the cause.



North American Standard Instrument Panel (1999-) Shown



VDO Standard Instrument Panel (Except North America)

- A—Hand Throttle
- **B**—Reset Button
- C-Key Start Switch
- D-Oil Pressure Gauge

RG,RG34710,5557 -19-07JAN02-2/2

-UN-170CT0

3G11610

Warming Engine

IMPORTANT: To assure proper lubrication, operate engine at or below 1200 rpm with no load for 1-2 minutes. Extend this period 2-4 minutes when operating at

temperatures below freezing.

Engines used in generator set applications where the governor is locked at a specified speed may not have a slow idle function. Operate these engines at high idle for 1 to 2 minutes before applying the load. This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated

1. Check oil pressure gauge (A) as soon as engine starts. If gauge needle does not rise above minimum oil pressure specification of 105 kPa (1.05 bar) (15.0 psi) within 5 seconds, stop the engine and determine the cause. Normal engine oil pressure is 345 kPa (3.45 bar) (50 psi) at rated full load speed (1800-2500 rpm) with oil at normal operating temperature of 115°C (240°F).


NOTE: On certain engines, the oil pressure and coolant temperature gauges are replaced by indicator warning lights. The lights must be "OFF" when engine is running.

2. Watch coolant temperature gauge (B). Do not place engine under full load until it is properly warmed up. The normal engine coolant temperature range is 82°— 94°C (180°—202°F).

NOTE: It is a good practice to operate the engine under a lighter load and at lower speeds than normal for the first few minutes after start-up.



Standard North American Instrument Panel



Standard VDO Instrument Panel (Except North America)

A-Oil Pressure Gauge **B**—Coolant Temperature Gauge

RG,RG34710,5560 -19-08JAN02-1/1

3G11612 -UN-17OCT01

Normal Engine Operation

Observe engine coolant temperature and engine oil pressure. Temperatures and pressures will vary between engines and with changing operating conditions, temperatures, and loads.

Normal engine coolant operating temperature range is 82°—94°C (180°—202°F). If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop engine and determine cause before resuming operation.

Operate the engine under a lighter load and at slower than normal speed for first 15 minutes after start-up. DO NOT run engine at slow idle.

IMPORTANT: Should the engine die while operating under load, immediately

remove load and restart the engine. Overheating of the turbocharger parts may occur when oil flow is stopped.

Stop engine immediately if there are any signs of part failure. Symptoms that may be early signs of engine problems are:

- Sudden drop in oil pressure
- Abnormal coolant temperatures
- Unusual noise or vibration
- Sudden loss of power
- Excessive black exhaust
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

RG,RG34710,5552 -19-20MAY96-1/1

15-13

Cold Weather Operation



CAUTION: Ether injector starting fluid is highly flammable. DO NOT use starting fluid on engines equipped with air intake heaters.

DO NOT use starting fluid near fire, sparks, or flames. DO NOT incinerate or puncture a starting fluid container.

Engines may be equipped with intake air heaters, coolant heaters, or ether injectors as a cold weather starting aid.


Starting aids are required below 32°F (0°C). They will enhance starting performance above these temperatures and may be needed to start applications that have high parasitic loads during cranking and/or start acceleration to idle.

Using correct grade of oil (per engine and machine operator's manual) is critical to achieving adequate cold weather cranking speed.

Other cold weather starting aids are required at temperatures below -22°F (-30°C) or at altitudes above 1500 m (5000 ft).

- 1. Follow steps 1—4 as listed under, then proceed as follows according to the instrument (gauge) panel on your engine.
- 2. Switch on the air intake heater for 30 seconds or activate ether injector by following suppliers instructions.
- 3. Follow remaining steps 5—8 as listed under earlier in this section.

Additional information on cold weather operation is available from your authorized servicing dealer.



Cold Weather Starting Guidelines

RG,RG34710,5050 -19-08JAN02-1/1

Changing Engine Speed

To increase engine speed, turn throttle handle (A), if equipped, to the horizontal position and pull out until desired engine speed is obtained. Turn the handle in either direction to lock throttle position. The handle is pushed inward to decrease engine speed.

NOTE: On engines without handle, use throttle lever to control engine speed.

A—Throttle Handle



North American Standard Instrument Panel Shown

RG,RG34710,5561 -19-07JAN02-1/1

Avoid Excessive Engine Idling

Prolonged idling may cause the engine coolant temperature to fall below its normal range. This, in turn, causes crankcase oil dilution, due to incomplete fuel combustion, and permits formation of gummy deposits on valves, pistons, and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system.

Once an engine is warmed to normal operating temperatures, engine should be idled at slow idle speed. Slow idle speed for this engine is 850 rpm at factory. If an engine will be idling for more than 5 minutes, stop and restart later.

NOTE: Generator set applications where the governor is locked at a specified speed may not have a slow idle function. These engines will idle at no load governed speed (high idle).

RG,RG34710,5562 -19-20MAY96-1/1

Stopping the Engine

- 1. Disengage clutch (if equipped) controlling engine drivelines.
- 2. Move the throttle (A) to slow idle on standard (mechanical) governor engines.


IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes at 1000-1200 rpm to cool hot engine parts.

> For engines in generator set applications, where the governor is locked at a specified speed and no slow idle function is available, run engine for at least 2 minutes at fast idle and no load.

3. Turn key switch (B) to "OFF" position to stop the engine. Remove ignition key.

IMPORTANT: Make sure that exhaust stack cap (rain cap) is installed when engine is not running. This will prevent water and dirt from entering engine.

> A—Throttle B-Key Switch



North American Standard Instrument Panel Shown



Exhaust Stack Rain Cap

3G11299J -UN-11SEP00

RG,RG34710,5563 -19-07JAN02-1/1

Using a Booster Battery or Charger

A 12-volt booster battery can be connected in parallel with battery (ies) on the unit to aid in cold weather starting. ALWAYS use heavy duty jumper cables.



CAUTION: Gas given off by battery is explosive. Keep sparks and flames away from battery. Before connecting or disconnecting a battery charger, turn charger off. Make last connection and first disconnection at a point away from battery. Always connect NEGATIVE (–) cable last and disconnect this cable first.


WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**


IMPORTANT: Be sure polarity is correct before making connections. Reversed polarity will damage electrical system. Always connect positive to positive and negative to ground. Always use 12-volt booster battery for 12-volt electrical systems and 24-volt booster battery (ies) for 24-volt electrical systems.

1. Connect booster battery or batteries to produce the required system voltage for your engine application.


NOTE: To avoid sparks, DO NOT allow the free ends of jumper cables to touch the engine.

- 2. Connect one end of jumper cable to the POSITIVE (+) post of the booster battery.
- 3. Connect the other end of the jumper cable to the POSITIVE (+) post of battery connected to starter.
- 4. Connect one end of the other jumper cable to the NEGATIVE (–) post of the booster battery.
- 5. ALWAYS complete the hookup by making the last connection of the NEGATIVE (–) cable to a good ground on the engine frame and away from the battery (ies).





12-Volt System



A—12-Volt Machine Battery (ies)

B—12-Volt Booster Battery (ies)

C-Booster Cable

D—Cable to Starting Motor

Continued on next page

RG,RG34710,5564 -19-20MAY96-1/2

-UN-23AUG88

3G4678 -UN-14DEC88

Engine Operating Guidelines

Start the engine. Disconnect jumper cables immediately after engine starts. Disconnect NEGATIVE (–) cable first.

RG,RG34710,5564 -19-20MAY96-2/2

15-18


Lubrication and Maintenance

Observe Service Intervals

Using hour meter (A) as guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed using charts provided in Lubrication and Maintenance Records Section.

IMPORTANT: Recommended service intervals are for normal operating conditions. Service MORE OFTEN if engine is operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.

A-Hour Meter



North American Instrument Panel Hour Meter Shown

RG11299A -UN-17AUG00

DPSG,OUOE003,20 -19-07JAN02-1/1

Use Correct Fuels, Lubricants, and Coolant

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere engine distributor, servicing dealer or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.



DPSG,OUOE003,20 -19-06JAN99-1/1

Lubrication and Maintenance Service Interval Chart—Standard Industrial Engines

NOTE: The service intervals below are for standard industrial engines. See details in Sections which follow these charts.

	Lubrication and Maintenance Service Intervals				
ltem	Daily	250 Hour/ 6 Month	500 Hour/ 12 Month	2000 Hour/ 24 Month	As Required
Check Engine Oil and Coolant Level	•				
Check Fuel Filter/Water Separator Bowl	•				
Check Air Cleaner Dust Unloader Valve & Indicator ^a	•				
Perform Visual Walkaround Inspection	•				
Service Fire Extinguisher		•			
Change Engine Oil And Replace Oil Filter ^b		•			
Check Engine Mounts		•			
Service Battery		•			
Check Manual Belt Tensioner and Belt Wear		•			
Clean Crankcase Vent Tube			•		
Check Air Intake Hoses, Connections, & System			•		
Replace Fuel Filter Element			•		
Check Automatic Belt Tensioner and Belt Wear			•		
Check Engine Electrical Ground Connection			•		
Check Cooling System			•		
Coolant Solution Analysis-Add SCAs as required			•		
Pressure Test Cooling System			•		
Check Crankshaft Vibration Damper (6.8 L Engines) ^c				•	
Flush Cooling System ^d				•	
Test Thermostats				•	
Check and Adjust Engine Valve Clearance				•	
Add Coolant					•
Replace Air Cleaner Elements					•
Replace Poly-Vee Belt					•

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H2O.

Continued on next page

RG,RG34710,7559 -19-07JAN02-1/2

^bChange the oil for the first time before 100 hours maximum of (break-in) operation, then every 250 hours thereafter. If PLUS-50 oil is used along with a John Deere oil filter, the oil change interval may be extended by 50 percent to 375 hours.

^cReplace crankshaft damper every 4500 hours or 60 months, whichever occurs first.

^dIf John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished as needed by adding a supplemental coolant additive, the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

Lubrication and Maintenance

	Lubrication and Maintenance Service Intervals				
Item	Daily	250 Hour/ 6 Month	500 Hour/ 12 Month	2000 Hour/ 24 Month	As Required
Check Fuses					•
Bleed Fuel System					•

RG,RG34710,7559 -19-07JAN02-2/2

20-3 020102

Lubrication and Maintenance Service Interval Chart—Generator (Standby) Applications

NOTE: Use service intervals listed below for generator (standby) applications. Match service items below to titles in Lubrication and Maintenance Sections for procedures.

	Lubrication and Maintenance Service Intervals				
ltem	Every 2 Weeks	250 Hours or 12 Months	500 Hours or 12 Months	2000 Hours or 24 Months	As Required
Operate Engine at Rated Speed and 50%–70% Load a Minimum of 30 Minutes	•				
Check Engine Oil and Coolant Level	•				
Check Fuel Filter/Water Separator Bowl	•				
Check Air Cleaner Dust Unloader Valve & Indicator ^a	•				
Perform Visual Walkaround Inspection	•				
Service Fire Extinguisher	•				
Change Engine Oil and Replace Oil Filter ^b		•			
Check Engine Mounts		•			
Service Battery		•			
Clean Crankcase Vent Tube		•			
Check Air Intake Hoses, Connections, & System		•			
Replace Fuel Filter Element—Bleed Fuel System		•			
Check Belt Tensioner and Belt Wear		•			
Check Engine Electrical Ground Connection		•			
Check Cooling System		•			
Coolant Solution Analysis-Add SCAs as required		•			
Pressure Test Cooling System		•			
Check Crankshaft Vibration Damper (6.8 L Engines) ^c			•		
Flush Cooling System ^d			•		
Test Thermostats			•		
Check and Adjust Engine Valve Clearance			•		
Add Coolant					•
Replace Air Cleaner Elements					•
Replace Poly-Vee Belt					•

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H2O.

Continued on next page

RG,RG34710,7560 -19-07JAN02-1/2

^bChange the oil for the first time before 100 hours maximum of (break-in) operation, then every 250 hours thereafter. If PLUS-50 oil is used along with a John Deere oil filter, the oil change interval may be extended by 50 percent to 375 hours.

^cReplace crankshaft damper every 4500 hours or 60 months, whichever occurs first.

^dIf John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished as needed by adding a supplemental coolant additive, the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

Lubrication and Maintenance

	Lubrication and Maintenance Service Intervals				
ltem	Every 2 Weeks	250 Hours or 12 Months	500 Hours or 12 Months	2000 Hours or 24 Months	As Required
Check Fuses					•
Bleed Fuel System					•

RG,RG34710,7560 -19-07JAN02-2/2

20-5 020102

Lubrication & Maintenance/Daily

Daily Prestarting Checks

Do the following BEFORE STARTING THE ENGINE for the first time each day:


IMPORTANT: DO NOT add makeup oil until the oil level is BELOW the add mark.

1. Check engine oil level on dipstick. Add as required, using seasonal viscosity grade oil. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for oil specifications.)


Depending on application, oil may be added at left (A) or right (B) side oil filler cap and rocker arm cover filler cap (C) locations.

IMPORTANT: DO NOT fill above the top mark on the dipstick. Oil levels anywhere within crosshatch (D) are considered in the acceptable operating range.

- A-Left Side Oil Filler Cap
- B-Right Side Oil Filler Cap
- C—Cover Oil Filler Cap
- D-Crosshatch On Dipstick




Left Side Oil Filler Cap



Right Side Oil Filler Cap



Rocker Arm Cover Filler Cap



Crosshatch on Dipstick

Continued on next page

DPSG,OUOE003,20 -19-07JAN02-1/4



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when engine is cold or when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


2. Check the coolant level when engine is cold. Coolant level should be at bottom of filler neck. Fill radiator (A) with proper coolant solution if level is low. (See ADDING COOLANT in Service As Required Section.) Check overall cooling system for leaks.

NOTE: Refer to your vehicle's operator's manual for recommendations for non-John Deere supplied accessories.

A-Fill Radiator



High-Pressure Fluids



-UN-14DEC88

Continued on next page

DPSG,OUOE003,20 -19-07JAN02-2/4

-UN-23AUG88

3. Check the fuel filter for water or debris. If filter is fitted with a see-through bowl, drain as needed based on a daily visual inspection.


IMPORTANT: Drain water into a suitable container and dispose of properly.

- a. Loosen drain plug (B) at bottom of fuel filter or bowl, if equipped, two or three turns.
- b. Loosen air bleed plug (A) two full turns on fuel filter mounting and drain water from bottom until fuel starts to drain out.
- c. When fuel starts to drain out, tighten drain plug securely.

After draining water from the fuel filter, the filter must be primed by bleeding all air from the fuel system.

- a. Operate primer lever of the fuel supply pump (C) until fuel flow is free from air bubbles.
- b. Tighten bleed plug securely, continue operating hand primer until pumping action is not felt. Push hand primer inward (toward engine) as far as it will go.

If the fuel system needs further bleeding of air, see BLEEDING FUEL SYSTEM in Service As Required Section, later in this manual.



Drain Fuel Filter



Priming At Fuel Supply Pump

A-Air Bleed Plug

B—Drain Plug

C—Fuel Supply Pump Primer Lever

Continued on next page

DPSG,OUOE003,20 -19-07JAN02-3/4

4. If the air cleaner has an automatic dust unloader valve (A), squeeze the unloader valve on air cleaner assembly to clear away any dust buildup.

If equipped with air intake restriction indicator gauge (B), check gauge to determine if air cleaner needs to be serviced.

IMPORTANT: Maximum air intake restriction is 6.25 kPa (0.06 bar) (1.0 psi) (25 in. H²O). A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine.


5. Make a thorough inspection of the engine compartment. Look for oil or coolant leaks, worn fan and accessory drive belts, loose connections and trash build-up. Remove trash buildup and have repairs made as needed if leaks are found.

NOTE: Wipe all fittings, caps, and plugs before performing any maintenance to reduce the chance of system contamination.

Inspect:

- Radiator for leaks and trash build-up.
- Air intake system hoses and connections for cracks and loose clamps.
- Fan, alternator, and accessory drive belts for cracks, breaks or other damage.
- Water pump for coolant leaks.

NOTE: It is normal for a small amount of leakage to occur as the engine cools down and parts contract. Excessive coolant leakage may indicate the need to replace the water pump seal. Contact your engine distributor or servicing dealer for repairs.



Dust Unloader Valve and Indicator Gauge

A—Dust Unloader Valve **B**—Air Restriction Indicator

DPSG,OUOE003,20 -19-07JAN02-4/4

Lubrication & Maintenance/250 Hour/6 Month

Servicing Fire Extinguisher

A fire extinguisher (A) is available from your authorized servicing dealer or engine distributor.

Read and follow the instructions which are packaged with it. The extinguisher should be inspected at least every 250 hours of engine operation or once a month. Once extinguisher is operated, no matter how long, it must be recharged. Keep record of inspections on the tag which comes with the extinguisher instruction booklet.

A-Fire Extinguisher



Fire Extinguisher

RG,RG34710,5567 -19-20MAY96-1/1

30-1

Changing Engine Oil and Replacing Filter

NOTE: Change engine oil and oil filter for the first time before 100 hours maximum of operation, then every 250 hours thereafter.


If John Deere PLUS-50® engine oil and a John Deere oil filter are used, the oil and filter change interval may be extended by 50 percent or to 375 hours.

OILSCAN® or OILSCAN PLUS® is a John Deere sampling program to help you monitor machine performance and identify potential problems before they cause serious damage. OILSCAN® and OILSCAN PLUS®kits are available from your John Deere engine distributor or servicing dealer. Oil samples should be taken prior to the oil change. Refer to instructions provided with kit.

To change engine oil and oil filter:

- 1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
- 2. Remove oil pan drain plug (arrow).
- 3. Drain crankcase oil from engine while warm.

NOTE: Drain plug location may vary, depending on the application.



Oil Filter



Oil Pan Drain Plug

A-Oil Filter Element

PLUS-50 is a trademark of Deere & Company. OILSCAN is a trademark of Deere & Company. OILSCAN PLUS is a trademark of Deere & Company.

Continued on next page

RG,RG34710,5570 -19-07JAN02-1/3

3G11616 -UN-24OCT01

 Turn filter element (A) counterclockwise using a suitable filter wrench to remove. Discard oil filter element.

NOTE: Depending on engine application, oil filter may be located on either side of the engine.


5. Remove oil filter packing and clean filter mounting pad.

IMPORTANT: Filtration of oils is critical to proper lubrication. Always change filter regularly. Use filter meeting John Deere performance specifications.

- Oil new packing and install new filter element. Hand tighten element according to values printed on filter element. If values are not provided, tighten element approximately 3/4 — 1-1/4 turn after packing contacts filter housing. DO NOT overtighten filter element.
- Install oil pan drain plug with O-ring or copper washer.
 If copper washer is used, install with raised center against plug. If O-ring or washer is damaged, replace it.
- 8. Tighten drain plug to specifications.

Specification

Oil Pan Drain Plug With Copper	
Washer—Torque	70 Nem (52 lb ft)
Oil Pan Drain Plug With O-Ring—	
Torque	50 N•m (37 lb ft)



Removing Oil Filter Element

A-Oil Filter Element

Continued on next page

RG,RG34710,5570 -19-07JAN02-2/3

 Fill engine crankcase with correct John Deere engine oil through rocker arm cover opening (B) or either side oil filler (C) depending on engine application. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for determining correct engine oil.)


To determine the correct oil fill quantity for your engine, see ENGINE CRANKCASE OIL FILL QUANTITIES in the Specifications Section of this manual.

IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.


NOTE: Crankcase oil capacity may vary slightly.

ALWAYS fill crankcase to full mark or within crosshatch on dipstick, whichever is present. DO NOT overfill.

- 10. Start engine and run to check for possible leaks.
- 11. Stop engine and check oil level after 10 minutes. Oil level reading should be within crosshatch of dipstick.



Rocker Arm Cover Oil Filler



Side Oil Filler

B—Rocker Arm Cover Oil Filler C—Side Oil Filler

RG,RG34710,5570 -19-07JAN02-3/3

Checking Engine Mounts

Engine mounting is the responsibility of the vehicle or generator manufacturer. Follow manufacturer's guidelines for mounting specifications.

IMPORTANT: Use only Grade SAE 8 or higher grade of hardware for engine mounting.

- Check the engine mounting bracket, vibration isolators, and mounting bolts on support frame and engine block for tightness. Tighten as necessary.
- 2. Inspect overall condition of vibration isolators, if equipped. Replace isolators if rubber has deteriorated or mounts have collapsed, as necessary.

DPSG,RG34710,111 -19-07JAN02-1/1

Servicing Battery



CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded NEGATIVE (-) battery clamp first and replace it last.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

 On regular batteries, check electrolyte level. Fill each cell to bottom of filler neck with distilled water.

NOTE: Low-maintenance or maintenance-free batteries should require little additional service. However, electrolyte level can be checked by cutting the center section of decal on dash-line, and removing cell plugs. If necessary, add clean, soft water to bring level to bottom of filler neck.

2. Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove any corrosion, and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections securely.

NOTE: Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.

 Keep battery fully charged, especially during cold weather. If a battery charger is used, turn charger off before connecting charger to battery(ies). Attach POSITIVE (+) battery charger lead to POSITIVE (+) battery post. Then attach NEGATIVE (-) battery charger lead to a good ground.



Exploding Battery

S204 -UN-23AUG88

Continued on next page

RG,RG34710,5568 -19-20MAY96-1/2



CAUTION: Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling or dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10–15 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Drink large amounts of water or milk.
- 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.

In freezing weather, run engine at least 30 minutes to assure thorough mixing after adding water to battery.

If necessary to replace battery(ies), replacements must meet or exceed the following recommended capacities at -18°C (0°F):

Specification

12 Volt Standard Duty Starter—	
Cold Cranking Amps	640
12 Volt Heavy Duty Starter—Cold	
Cranking Amps	800
24 Volt Standard Duty Starter—	
Cold Cranking Amps	570



Sulfuric Acid

RG,RG34710,5568 -19-20MAY96-2/2

Manual Belt Tensioner Adjustment

NOTE: Two types of manual tensioners shown.

NOTE: Inspect belts for cracks, fraying, or stretched-out areas. Replace if necessary.

> As a reference check, twist belt in the middle of a 254-305 mm (10-12 in.) span with two fingers. A properly tensioned belt will turn 75—85 degrees. If belt turns more, it needs to be tightened. If belt turns less, it needs to be loosened.

NOTE: If timing gear cover or alternator bracket interfere with installation/centering of belt tension gauge (A), install gauge with face toward engine.

- 1. Install JDG1341 Belt Tension Gauge (A) on belt, halfway between pulleys as shown. (JDG1341 Belt Tension Gauge available from local John Deere Dealer or Distributor.)
- 2. Loosen cap screws (B) and (C).
- 3. Slide alternator or tensioner bracket (D) in slot by hand to remove all excess slack in belt.




4. Stretch belt by prying outward on alternator front frame or tensioner bracket. Observing tension gauge, stretch the belt until specified tension is achieved.


Specification

8-Rib Poly-Vee Belt-Bosch and New Magneton Alternator New Old Magneton Alternator New Belt (Option Code 3101) Tension 470—650 N (105—145 lb-force)

5. Tighten cap screws (B) and (C).



Check Belt Tension



Adjust Belt Tension

- A—Belt Tension Gauge
- **B—Cap Screw**
- C—Cap Screw
- **D—Tensioner Bracket**

Continued on next page

DPSG,RG41165,128 -19-12NOV01-1/2

NOTE: After ten minutes run-in, new belts are considered used. Belt tension must then be rechecked per used belt specifications.

- 6. Run engine for ten minutes and immediately re-check belt tension per used belt specification above.
- 7. Reset belt tension as necessary.

DPSG,RG41165,128 -19-12NOV01-2/2


Manual Belt Tensioner Adjustment Using **Belt Tension Tool (Alternate Method For Engines Without Auxiliary Drive)**

NOTE: The JDG1520 Belt Tension Tool may not be compatible with all alternators. In that case, use the preceeding method for belt tensioning.


NOTE: Inspect belts for cracks, fraying, or stretched-out areas. Replace if necessary.

> As a reference check, twist belt in the middle of a 254—305 mm (10—12 in.) span with two fingers. A properly tensioned belt will turn 75-85 degrees. If belt turns more, it needs to be tightened. If belt turns less, it needs to be loosened.

- 1. Loosen upper (A) and lower (B) alternator bracket cap screws. Lower cap screw must remain tight enough to prevent excessive alternator play but allow alternator to pivot by hand.
- 2. Insert JDG1520 Belt Tension Tool (C) behind belt (D) and over alternator mounting screw.



Alternator Bracket and Cap Screws



Belt Tension Tool

- A-Upper Alternator Bracket Cap Screw
- B-Lower Alternator Bracket Cap Screw
- C-JDG1520 Belt Tension Tool
- D-Belt

Continued on next page

OUOD002,000016D -19-05NOV01-1/2


3. Place torque wrench (C) on belt tensioning tool (B) at 90° to tool. Pivot alternator (A) until desired torque is achieved according to specification using the following table.

Specification


New Belt—Tension	535—715 N (120—160 lb-force)
Used Belt—Tension	. 400—580 N (90—130 lb-force)

JDG1520 Belt Tensioning Tool Torque Table				
Desired Belt Tension N (lb-force)	Applied Torque On Tool N•m (lb-ft)			
445 (100)	108 (90)			
489 (110)	115 (85)			
534 (120)	122 (90)			
623 (140)	135 (100)			

- 4. While holding tension with torque wrench (B), scribe a reference mark (D) on alternator in line with notch (E) on upper alternator bracket.
- 5. Continue to hold tension with torque wrench and tighten upper alternator bracket cap screw.
- 6. Check position of reference mark to see if alternator moved while tightening. If alternator moved, loosen upper alternator bracket cap screw and repeat the tension adjustment procedure.
- 7. Remove belt tension tool and tighten lower alternator bracket cap screw.
 - A-Alternator
 - **B**—Belt Tensioning Tool
 - C—Torque Wrench
 - D-Reference Mark
 - E-Alternator Upper Bracket Notch



Belt Tension Tool and Torque Wrench



Scribe Reference Mark

OUOD002,000016D -19-05NOV01-2/2


Lubrication & Maintenance/500 Hour/12 Month

Cleaning Crankcase Vent Tube

If you operate the engine in dusty conditions, clean the tube at shorter intervals.

- 1. Remove and clean crankcase vent tube (A).
- 2. Install the vent tube. Be sure the O-ring fits correctly in the rocker arm cover for elbow adapter. Tighten hose clamp securely.

A—Crankcase Vent Tube



Crankcase Vent Tube

RG,RG34710,5574 -19-08JAN02-1/1

35-1

Checking Air Intake System


IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in internal engine damage due to abrasive dirt and dust entering the intake system.

- 1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
- 2. Check clamps (A) on piping which connect the air cleaner, engine and, if present, turbocharger. Tighten clamps as necessary. This will help prevent dirt from entering the air intake system through loose connections causing internal engine damage.
- 3. If engine has a rubber dust unloader valve (B), inspect the valve on bottom of air cleaner for cracks or plugging. Replace as necessary.


IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.

4. Test air restriction indicator (C) for proper operation. Replace indicator as necessary.

IMPORTANT: If not equipped with air restriction indicator, replace air cleaner elements at 500 Hours or 12 Months, whichever occurs first.



Check Clamps



Unloader Valve and Air Restriction Indicator

- A—Clamps
- **B**—Dust Unloader Valve
- C-Air Restriction Indicator

RG,RG34710,5575 -19-07JAN02-1/1

Replacing Fuel Filter Element



CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


- 1. Close fuel shut-off valve, if equipped.
- 2. Thoroughly clean fuel filter assembly and surrounding area.
- 3. Loosen drain plug (C) and drain fuel into a suitable container.

NOTE: Lifting up on retaining ring as it is rotated helps to get it past raised locators.


- 4. Firmly grasp the retaining ring (A) and rotate it counterclockwise 1/4 turn. Remove ring with filter element (B).
- 5. Inspect filter mounting base for cleanliness. Clean as required.

NOTE: Raised locators on fuel filter canister must be indexed properly with slots in mounting base for correct installation.

6. Install new filter element onto mounting base. Be sure element is properly indexed and firmly seated on base. It may be necessary to rotate filter for correct alignment.



High-Pressure Fluids



Fuel Filter

- A-Retaining Ring
- **B**—Filter Element
- C-Drain Plug
- D—Bleed Plug

Continued on next page

RG,RG34710,5576 -19-07JAN02-1/2

-UN-23AUG88

If equipped with water separator, remove filter element from water separator bowl. Drain and clean separator bowl. Dry with compressed air. Install water separator bowl onto new element. Tighten securely.

- 7. Align keys on filter element with slots in filter base.
- Install retaining ring onto mounting base making certain dust seal is in place on filter base. Hand tighten ring (about 1/3 turn) until it "snaps" into the detent. DO NOT overtighten retaining ring.

NOTE: The proper installation is indicated when a "click" is heard and a release of the retaining ring is felt.

A plug is provided with the new element for plugging the used element.

 Open fuel shut-off valve and bleed the fuel system. (See BLEEDING FUEL SYSTEM in Service As Required Section.) Tighten bleed plug (D).

RG,RG34710,5576 -19-07JAN02-2/2

Checking Belt Tensioner Spring Tension and Belt Wear (Automatic Tensioner)

Belt drive systems equipped with automatic (spring) belt tensioners cannot be adjusted or repaired. The automatic belt tensioner is designed to maintain proper belt tension over the life of the belt. If tensioner spring tension is not within specification, replace tensioner assembly.

Continued on next page


RG,RG34710,5578 -19-08JAN02-1/3

Checking Belt Wear

The belt tensioner is designed to operate within the limit of arm movement provided by the cast stops (A and B) when correct belt length and geometry is used.

Visually inspect cast stops (A and B) on belt tensioner assembly.

If the tensioner stop on swing arm (A) is hitting the fixed stop (B), check mounting brackets (alternator, belt tensioner, idler pulley, etc.) and the belt length. Replace belt as needed (see REPLACING FAN AND ALTERNATOR BELTS in Service As Required Section).



Cast Stops

A—Cast Stops **B**—Cast Stop

Continued on next page

RG,RG34710,5578 -19-08JAN02-2/3

Checking Tensioner Spring Tension


A belt tension gauge will not give an accurate measure of the belt tension when automatic spring tensioner is used. Measure tensioner spring tension using a torque wrench and procedure outlined below:

- 1. Release tension on belt using a breaker bar and socket on tension arm. Remove belt from pulleys.
- 2. Release tension on tension arm and remove breaker bar.
- 3. Put a mark (A) on swing arm of tensioner as shown.
- 4. Measure 21 mm (0.83 in.) from (A) and put a mark (B) on tensioner mounting base.
- 5. Install torque wrench (C) so that it is aligned with center of pulley and tensioner. Rotate the swing arm with the torque wrench until marks (A and B) are aligned.
- 6. Record torque wrench measurement and compare with specification below. Replace tensioner assembly as required.




NOTE: Threads on belt tensioner roller cap screw are LEFT-HAND threads


- A-Mark On Swing Arm
- **B**—Mark On Tensioner Mounting Base
- C—Torque Wrench



Marks on Tensioner



Align Marks



Align Torque Wrench With Pulley And Tensioner

RG,RG34710,5578 -19-08JAN02-3/3

-UN-14NOV97

-UN-08JAN02

Checking Engine Electrical Ground Connections

Keep all engine ground connections clean and tight to prevent electrical arcing which can damage electronic components.

OUOD002,0000169 -19-08OCT01-1/1

Checking Cooling System



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug when all the air has been expelled.

- 1. Visually check entire cooling system for leaks. Tighten all clamps securely.
- 2. Thoroughly inspect all cooling system hoses for hard, flimsy, or cracked condition. Replace hoses if any of the above conditions are found.



High-Pressure Fluids

-UN-23AUG88

RG,RG34710,5580 -19-20MAY96-1/1

Replenishing Supplemental Coolant Additives (SCAs) Between Coolant Changes

IMPORTANT: Do not add supplemental coolant additives when the cooling system is drained and refilled with John Deere **COOL-GARD®**

NOTE: If system is to be filled with coolant that does not contain SCAs, the coolant must be precharged. Determine the total system capacity and premix with 3% John Deere Coolant Conditioner.


Through time and use, the concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD® is used. The cooling system must be recharged with additional supplemental coolant additives available in the form of liquid coolant conditioner.

Maintaining the correct coolant conditioner concentration (SCAs) and freeze point is essential in your cooling system to protect against rust, liner pitting and corrosion, and freeze-ups due to incorrect coolant dilution.


John Deere LIQUID COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

DO NOT mix one brand of SCA with a different brand.

Test the coolant solution every 500 hours or 12 months of operation using either John Deere coolant test strips or a COOLSCAN® analysis. If a COOLSCAN® analysis is not available, recharge the system per instructions printed on label of John Deere Liquid Coolant Conditioner.



Radiator Coolant Check



COOL-GARD is a registered trademark of Deere & Company COOLSCAN is a registered trademark of Deere & Company

Continued on next page

DPSG,OUOD002,1921 -19-07JAN02-1/2

IMPORTANT: ALWAYS maintain coolant at correct level and concentration. DO NOT operate engine without coolant even for a few minutes.

If frequent coolant makeup is required, the glycol concentration should be checked with JTO7298 Coolant/Battery Tester to ensure that the desired freeze point is maintained. Follow manufacturer's instructions provided with Coolant/Battery Tester.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

See DIESEL ENGINE COOLANTS AND SUPPLEMENTAL ADDITIVE INFORMATION for proper mixing of coolant ingredients before adding to the cooling system.

DPSG,OUOD002,1921 -19-07JAN02-2/2

35-9

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN

For a more thorough evaluation of your coolant, perform a COOLSCAN analysis. See your John Deere dealer for information about COOLSCAN.


DX,COOL9 -19-17FEB99-1/1

35-10


-UN-20JAN93

3G6557

Pressure Testing Cooling System



Test Radiator Cap



Test Cooling System



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

Test Radiator Cap

- 1. Remove radiator cap and attach to D05104ST Tester as shown.
- 2. Pressurize cap to specification listed. Gauge should hold pressure for 10 seconds within the normal range if cap is acceptable.

If gauge does not hold pressure, replace radiator cap.

Specification

3. Remove the cap from gauge, turn it 180°, and retest cap. This will verify that the first measurement was accurate.

Test Cooling System

NOTE: Engine should be warmed up to test overall cooling system.

- Allow engine to cool, then carefully remove radiator cap.
- Fill radiator with coolant to the normal operating level.

IMPORTANT: DO NOT apply excessive pressure to cooling system, doing so may damage radiator and hoses.

- Connect gauge and adapter to radiator filler neck.
 Pressurize cooling system to specification listed for radiator cap.
- 4. With pressure applied, check all cooling system hose connections, radiator, and overall engine for leaks.

If leakage is detected, correct as necessary and pressure test system again.

If no leakage is detected, but the gauge indicated a drop in pressure, coolant may be leaking internally within the system or at the block-to-head gasket. Have your engine distributor or servicing dealer correct this problem immediately.


RG,RG34710,5586 -19-07JAN02-1/1

Lubrication & Maint./2000 Hour/24 Month

Adjusting Variable Speed (Droop) on **Generator Set Engines**

Stanadyne Mechanical Injection Pumps Only

- 1. Warm engine to normal operating temperature.
- 2. When necessary, disconnect throttle linkage or cable.
- 3. Adjust slow idle (C) and adjust fast idle (B) speed when necessary.
- 4. Run engine at fast idle, then apply load until reaching rated speed.
- 5. Check power. Adjust with the screw (A) if needed.
- 6. Remove load from engine.
- 7. Again check and adjust fast idle if screw (A) has been turned.
- 8. Repeat procedure until both the engine power and the fast idle speed are correct.
- 9. Reinstall throttle linkage if previously removed.



Droop Adjustment Screw

- A-Adjustment Screw
- B—Fast Idle Adjustment
- C—Slow Idle Adjustment


Continued on next page

RG,RG34710,5583 -19-28JAN02-1/3

RG12066 -UN-29JAN02

DENSO In-Line Injection Pumps Only

- 1. Check for specified no-load (frequency). If governor regulation is within 5–7% range, no adjustment is necessary.
- 2. If governor regulation is above 7% or below 5%, stop engine and remove cap nuts from adjusting screws before making adjustments.
- 3. Remove droop adjusting screw access plug (B, shown removed) from top of governor housing.
- 4. Back out slow idle (adjusting) screw (D) and bumper screw. Pull back on throttle lever (F, toward rear of governor housing) by hand until the droop adjusting screw (C) inside housing can be adjusted through the access plug hole.
- 5. Screw the droop screw in (clockwise), counting the turns until screw bottoms out. Then, return screw to original setting.
- NOTE: A noticeable click will occur at each 1/4 turn of droop adjusting screw. One click clockwise will increase no-load speed approximately 10 rpm, counterclockwise will reduce speed by 10 rpm.
- Screw in the droop screw (clockwise) no more than 1/2 turn (two clicks) at a time to reduce governor droop. Turn counterclockwise no more than two clicks at a time to increase governor droop (to reduce governor sensitivity).
- Replace access plug in top of governor housing. Start engine, apply full (100%) load, and readjust high idle adjusting screw until 1500 rpm is obtained at the specified power.
- 8. Screw in idle (bumper) spring until engine speed increases 5–10 rpm.
- 9. Repeat steps 4 through 7 until governor regulation is within the 5–7% range.
- 10. Replace all cap nuts onto adjusting screws and tighten lock nuts securely.



DENSO In-Line Injection Pump

- A-Fast Idle (Stop) Screw
- B—Droop Adjusting Screw Access Plug Location
- C-Droop Adjusting Screw
- D-Slow Idle (Adjusting) Screw
- E—Idle (Bumper) Spring
- F—Throttle Lever
- G—Mechanical Shutoff Lever

Continued on next page

RG,RG34710,5583 -19-28JAN02-2/3

Delphi (Lucas) Injection Pumps Only

See your authorized Delphi (Lucas) Repair Station for speed droop adjustment. This service requires that an internal pump adjustment be made.

RG,RG34710,5583 -19-28JAN02-3/3


Checking Crankshaft Vibration Damper (6-Cylinder Engine Only)

- 1. Remove belts (shown removed).
- 2. Grasp vibration damper with both hands and attempt to turn it in both directions. If rotation is felt, damper is defective and should be replaced.

IMPORTANT: The vibration damper assembly is not repairable and should be replaced every 4500 hours or 60 months, whichever occurs first.

- Check vibration damper radial runout by positioning a dial indicator (A) so probe contacts damper outer diameter.
- 4. With engine at operating temperature, rotate crankshaft using either JDE83 or JD81-1 Flywheel Turning Tool.
- 5. Note dial indicator reading. If runout exceeds specifications given below, replace vibration damper.

Specification



Grasp Vibration Damper



Check Runout

RG,RG34710,5585 -19-16JAN02-1/1

Flushing Cooling System



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

NOTE: When John Deere COOL-GARD is used, the drain interval is 3000 hours or 36 months. The drain interval may be extended to 5000 hours or 60 months of operation, provided that the coolant is tested annually AND additives are replenished, as needed, by adding a supplemental coolant additive (SCA).

> If COOL-GARD is not used, the flushing interval is 2000 hours or 24 months of operation.

Drain old coolant, flush the entire cooling system, test thermostats, and fill with recommended clean coolant.

- 1. Pressure test entire cooling system and pressure cap if not previously done. (See PRESSURE TESTING COOLING SYSTEM, in the Lubrication and Maintenance/600 Hour/12 Month Section.)
- 2. Slowly open the engine cooling system filler cap or radiator cap to relieve pressure and allow coolant to drain faster.



High-Pressure Fluids

-UN-23AUG88


Continued on next page

- 3. Open engine block drain valve (A) on left side of engine. Drain all coolant from engine block.
- 4. Open radiator drain valve. Drain all coolant from radiator.
- 5. Remove thermostats at this time, if not previously done. Install cover (without thermostats) using old gasket and tighten cap screws to 47 N•m (35 lb-ft).
- 6. Close all drain valves after coolant has drained.



CAUTION: Do not run engine longer than 10 minutes. Doing so may cause engine to overheat which may cause burns when radiator water is draining.

- 7. Fill the cooling system with clean water. Run the engine about 10 minutes to stir up possible rust or sediment.
- 8. Stop engine, pull off lower radiator hose and remove radiator cap. Immediately drain the water from system before rust and sediment settle.
- 9. After draining water, close drain valves. Reinstall radiator cap and radiator hose and clamp. Fill the cooling system with clean water and a heavy duty cooling system cleaner such as Fleetguard® RESTORE™ and RESTORE PLUS™. These products may be available from your John Deere dealer. Follow manufacturer's directions on label.
- 10. After cleaning the cooling system, drain cleaner and fill with water to flush the system. Run the engine about 10 minutes, remove radiator cap and pull off lower radiator hose to drain out flushing water.
- 11. Close all drain valves on engine and radiator. Reinstall radiator hose and tighten clamps securely. Install thermostats using a new gasket. (See TESTING THERMOSTATS OPENING TEMPERATURE later in this section.)



Engine Block Drain Valve

A-Engine Block Drain Valve

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug after filling cooling system.

- 12. Add coolant to radiator until coolant touches bottom of filler neck. (See ADDING COOLANT in Service As Required Section.) Install radiator cap.
- 13. Run engine until it reaches operating temperature. This mixes the solution uniformly and circulates it through the entire system. The normal engine coolant temperature range is 82°—94°C (180° 202°F).
- 14. After running engine, check coolant level and entire cooling system for leaks.

RG,RG34710,5587 -19-07JAN02-3/3

40-6

Testing Thermostats Opening Temperature

To Remove Thermostat(s)

NOTE: On some engines, the coolant manifold/thermostat housing is an integral part of the cylinder head.



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns. DO NOT drain coolant until it has cooled below operating temperature. Always loosen radiator pressure cap or drain valve slowly to relieve pressure.

- 1. Visually inspect area around thermostat housing for leaks.
- 2. Remove radiator pressure cap and partially drain cooling system.
- 3. Remove thermostat cover-to-water pump tube (A) and seal.

A-Cover-To-Coolant Pump Tube




High Pressure Fluids



Thermostat Cover-to-Water Pump Tube

DPSG,RG34710,112 -19-07JAN02-1/5

- 4. Remove thermostat cover (B) with gasket.
- 5. Remove thermostat(s)
- 6. Remove and discard all gasket material. Clean gasket surfaces.
- 7. Clean and check cover for cracks or damage.
 - **B—Thermostat Cover**



Thermostat Cover

Continued on next page

DPSG,RG34710,112 -19-07JAN02-2/5

Ď-

-UN-23AUG88

Testing Thermostats Opening Temperature

- 1. Remove thermostat(s).
- 2. Visually inspect thermostat(s) for corrosion or damage. If dual thermostats, replace as a matched set as necessary.



CAUTION: DO NOT allow thermostat or thermometer to rest against the side or bottom of container when heating water. Either may rupture if overheated.


- 3. Suspend thermostat and a thermometer in a container of water.
- 4. Stir the water as it heats. Observe opening action of thermostat and compare temperatures with the specification given in chart below.

NOTE: Due to varying tolerances of different suppliers, initial opening and full open temperatures may vary slightly from specified temperatures.

THERMOSTAT TEST SPECIFICATIONS

Rating	Initial Opening (Range)	Full Open (Nominal)
71°C (160°F)	69—72°C (156—162°F)	84°C (182°F)
77°C (170°F)	74—78°C (166—172°F)	89°C (192°F)
82°C (180°F)	80—84°C (175—182°F)	94°C (202°F)
89°C (192°F)	86—90°C (187—194°F)	101°C (214°F)
90°C (195°F)	89—93°C (192—199°F)	103°C (218°F)
92°C (197°F)	89—93°C (193—200°F)	105°C (221°F)
96°C (205°F)	94—97°C (201—207°F)	100°C (213°F)
99°C (210°F)	96-100°C (205-212°F)	111°C (232°F)

- 5. Remove thermostat and observe its closing action as it cools. In ambient air the thermostat should close completely. Closing action should be smooth and slow.
- 6. Replace any defective thermostat. On a dual thermostat engine, replace both thermostats.



Testing Thermostat Opening Temperature

Continued on next page

DPSG,RG34710,112 -19-07JAN02-3/5

RG5971 -UN-23NOV97


To Install Thermostats

IMPORTANT: Install manifold gasket so that smaller (round) holes are at lower left and upper right corners of manifold (matching studs A).

- 1. Clean all gasket material from thermostat cover and housing mounting surfaces.
- 2. Using guide studs (A) to keep gasket in place, install a new gasket on cylinder head.
- 3. Install thermostat(s) with jiggle wire facing up in the 12 o'clock position.
- 4. Using a screwdriver to hold thermostat(s) in place, install thermostat(s) and water manifold/thermostat cover.
- 5. Tighten cover cap screws to 70 N•m (52 lb-ft).
- 6. Lubricate new O-ring with PT507 Multi-Purpose Grease. Install seal (B) in thermostat cover.

A—Guide Studs

B—Seal



Installing Thermostat Cover



Thermostat Cover Seal

DPSG,RG34710,112 -19-07JAN02-4/5

- 7. Install coolant manifold/thermostat cover-to-coolant pump tube (C). Tighten clamps.
- 8. If not already done, fill cooling system and check for leaks.

IMPORTANT: Air must be expelled from cooling system when filling. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Tighten fitting or plug when all air has been expelled.



Cover-To-Coolant Pump Tube

C—Cover-To-Coolant Pump Tube

DPSG,RG34710,112 -19-07JAN02-5/5

Check and Adjust Valve Clearance



CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect NEGATIVE (—) battery terminal.

IMPORTANT: Valve clearance MUST BE checked and adjusted with engine COLD.

 Remove rocker arm cover and crankcase ventilator tube.

IMPORTANT: Visually inspect contact surfaces of valve tips and rocker arm wear pads.

Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms that exhibit excessive valve clearance should be inspected more thoroughly to identify damaged parts.


2. Remove plastic plugs or cover plate from engine timing/rotation hole (A) and timing pin hole (B).

NOTE: Some engines are equipped with flywheel housings which do not allow use of an engine flywheel rotation tool. These engines may be rotated from front nose of engine, using JDG966 Crankshaft Front/Rear Rotation Adapter.

 Using JDE83 or JD81-1 Flywheel Turning Tool, rotate engine flywheel in running direction (clockwise viewed from front) until No. 1 cylinder is at TDC compression stroke. Insert JDG1571 or JDE81-4 Timing Pin in flywheel.

If No.1 cylinder rocker arms are loose, the engine is at No. 1 TDC compression.

If No. 1 cylinder rocker arms are not loose, rotate engine one full revolution (360°) to No. 1 TDC compression.



Flywheel Housing Timing Holes

A—Timing/Rotation Hole B—Timing Pin Hole

RG7408 -UN-06AUG96

4. With engine lock-pinned at TDC of No. 1 piston's compression stroke, check valve clearance to following specifications. (Use sequence for 4-cylinder or 6-cylinder engines as outlined on next page.)

Specification

Intake Valve Clearance For Checking (Rocker Arm-to-Valve Tip) (Engine Cold)—Clearance 0.31—0.38 mm (0.012—0.015 in.) Exhaust Valve Clearance For Checking (Rocker Arm-to-Valve Tip) (Engine Cold)—Clearance...... 0.41—0.48 mm (0.016—0.019 in.)


DPSG,RG41165,137 -19-16JAN02-2/5

5. If valves need adjusting, use the appropriate valve clearance adjustment procedure on the next page and adjust to specifications below. Loosen the jam nut (A) on rocker arm adjusting screw. Turn adjusting screw until feeler gauge slips with a slight drag. Hold the adjusting screw from turning with screwdriver and tighten jam nut to specifications. Recheck clearance again after tightening jam nut. Readjust clearance as necessary.

Specification

Intake Valve Clearance For Adjusting (Rocker Arm-to-Valve Tip) (Engine Cold)—Clearance 0.36 mm (0.014 in.) Exhaust Valve Clearance For Adjusting (Rocker Arm-to-Valve Tip) (Engine Cold)—Clearance................................. 0.46 mm (0.018 in.)

6. Replace rocker arm cover and crankcase ventilator tube.



Adjusting Valves

A-Adjusting Screw Jam Nut

Continued on next page

DPSG,RG41165,137 -19-16JAN02-3/5

4-Cylinder Engine:

NOTE: Firing order is 1-3-4-2.

- 1. Using JDE81-4 Timing Pin, lock No. 1 piston at TDC compression stroke (B).
- 2. Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
- 3. Turn crankshaft 360°. Lock No. 4 piston at TDC compression stroke (C).
- 4. Adjust valve clearance on No. 2 and 4 exhaust valves and No. 3 and 4 intake valves.


A-Front of Engine

B-No. 1 Piston TDC Compression

C-No. 4 Piston TDC Compression

E-Exhaust Valve

I-Intake Valve




DPSG,RG41165,137 -19-16JAN02-4/5

6-Cylinder Engine:

NOTE: Firing order is 1-5-3-6-2-4.

- 1. Lock No. 1 piston at TDC compression stroke (B).
- 2. Adjust valve clearance on No. 1, 3 and 5 exhaust valves and No. 1, 2, and 4 intake valves.
- 3. Turn crankshaft 360°. Lock No. 6 piston at TDC compression stroke (C).
- 4. Adjust valve clearance on No. 2, 4 and 6 exhaust valves and No. 3, 5, and 6 intake valves.



6-Cylinder Engine Valve Adjustment

A-Front of Engine

B-No. 1 Piston TDC Compression

C-No. 6 Piston TDC Compression

E-Exhaust Valve


I-Intake Valve

DPSG,RG41165,137 -19-16JAN02-5/5

Service as Required

Additional Service Information

This is not a detailed service manual. If you want more detailed service information, use the form in the back of this manual to order a component technical manual.



Component Technical Manual

RG,RG34710,5591 -19-20MAY96-1/1

Do Not Modify Fuel System

IMPORTANT: Modification or alteration of the injection pump (arrow), the injection pump timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

> In addition, tampering with fuel system which alters emission-related equipment on engines may result in fines or other penalties, per EPA regulations or other local emission laws.

Do not attempt to service injection pump or fuel injectors yourself. Special training and special tools are required. (See your authorized servicing dealer or engine distributor.)



Fuel Injection Pump

RG,RG34710,5592 -19-08JAN02-1/1

Adding Coolant



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Never pour cold liquid into a hot engine, as it may crack cylinder head or block. DO NOT operate engine without coolant for even a few minutes.

> John Deere TY15161 Cooling System Sealer may be added to the radiator to stop leaks. DO NOT use any other stop-leak additives in the system.

Air must be expelled from cooling system when coolant is added.

1. Loosen temperature sending unit fitting at rear of cylinder head or plug in side of thermostat housing to allow air to escape when filling system.

IMPORTANT: When adding coolant to the system, use the appropriate coolant solution. (See **ENGINE COOLANT SPECIFICATIONS in** Fuels, Lubricants, and Coolant Section for mixing of coolant ingredients before adding to cooling system.)

> Do not overfill cooling system. A pressurized system needs space for heat expansion without overflowing at top of radiator.

- 2. Fill until coolant level touches bottom of radiator filler neck.
- 3. Tighten plugs and fittings when air has been expelled from system.
- 4. Run engine until it reaches operating temperature.



High-Pressure Fluids

-UN-23AUG88

RG,RG34710,5593 -19-07JAN02-1/1

3G11319A -UN-06SEP00

Replacing Single Stage Air Cleaner

IMPORTANT: ALWAYS REPLACE air cleaner when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere single stage air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

- 1. If equipped, loosen body clamp.
- 2. Loosen clamp around outlet neck (A).
- 3. Remove air cleaner.
- 4. Install new filter so that overlap (B) of air cleaner outlet neck and engine intake pipe is to specification below.




Specification

Overtightening may cause crushing of air cleaner body. Tighten body clamp only until snug.


6. If equipped, tighten body clamp until snug.

IMPORTANT: Whenever the air cleaner has been serviced or removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

7. If equipped, fully depress air restriction indicator reset button and release to reset indicator.



Single Stage Air Filter



Installation of Single Stage Air Cleaner

A—Outlet Neck Clamp B—Filter to Engine Overlap

RG,RG34710,5594 -19-07JAN02-1/1

Replacing Axial Seal Air Cleaner Filter Element

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.


NOTE: This procedure applies to John Deere 2-stage axial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

- 1. Remove wing nut and remove canister cover shown in small illustration inset.
- 2. Remove wing nut (A) and remove primary element (B) from canister.
- 3. Thoroughly clean all dirt from inside canister.


NOTE: Some engines may have a dust unloader valve (C) on the air cleaner. If equipped, squeeze valve tip to release any trapped dirt particles.

IMPORTANT: Remove secondary (safety) element (E) ONLY for replacement. DO NOT attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary ONLY when primary element has a hole in it.


- 4. To replace secondary element, remove retaining nut (D) and secondary element (E). Immediately replace secondary element with new element to prevent dust from entering air intake system.
- 5. Install new primary element and tighten wing nut securely. Install cover assembly and tighten retaining wing nut securely.



Wing Nut and Primary Element



Dust Unloader Valve



Retaining Nut and Secondary Element

- A-Wing Nut
- **B**—Primary Element
- C—Dust Unloader Valve
- D—Retaining Nut
- E—Secondary Element

Continued on next page

RG41165,000008A -19-12NOV01-1/2

Service as Required

IMPORTANT: Whenever the air cleaner has been serviced or had cover removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

6. If equipped, fully depress air restriction indicator reset button and release to reset indicator.

RG41165,000008A -19-12NOV01-2/2

Replacing Radial Seal Air Cleaner Filter Element

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.)
H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere 2-stage radial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

- 1. Unlatch and remove dust cup/cover (A) of air cleaner.
- 2. Move end of filter (B) back and forth gently to break seal.
- 3. Pull filter (B) off outlet tube and out of housing.
- 4. Thoroughly clean all dirt from inside housing and from outlet bore.

IMPORTANT: Remove secondary (safety) element (C)
ONLY for replacement. DO NOT attempt
to clean, wash, or reuse secondary
element. Replacement of secondary
element is usually necessary ONLY
when primary element has a hole in it.

- To replace secondary element (C), pull filter element out gently. Immediately replace secondary element with new element to prevent dust from entering air intake system.
- 6. Install new primary filter element. Apply pressure by hand at outer rim of filter.

IMPORTANT: Do NOT use latches on cover to force filter into air cleaner. Using cover to force filter will damage cleaner housing.

7. Close housing with dust unloader valve aimed down and latch latches.



Dust Cup/Cover



Primary Filter Element



Secondary Filter Element

A—Dust Cap/Cover

B—Primary Filter Element

C—Secondary Filter Element

P00

3G11321A -UN-08SEP00

RG11322A -UN-08SEP00

RG11327A -UN-08SEP00

Service as Required

IMPORTANT: Whenever the air cleaner has been serviced or cover has been removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

8. If equipped, fully depress air restriction indicator reset button and release to reset indicator.

RG41165,000008B -19-06SEP00-2/2

Replacing Fan and Alternator Belts

Refer to CHECKING BELT TENSIONER SPRING TENSION AND BELT WEAR in Lubrication and Maintenance/250 Hour/6 Month Section for additional information on the belt tensioner.


- 1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
- 2. To replace belt with automatic tensioner, release tension on belt using a breaker bar and socket on tension arm.

To replace belt with manual tensioner, release tension at belt tensioner (See MANUAL BELT TENSIONER ADJUSTMENT in Lubrication and Maintenance/250 Hour/6 Month Section.)


- 3. Remove poly-vee belt from pulleys and discard belt.
- 4. Install new belt, making sure belt is correctly seated in all pulley grooves. Refer to belt routing at right for your application.
- 5. Apply tension to belt with tensioner. Remove socket.
- 6. Start engine and check belt alignment.

*Measured from crank centerline to fan drive center.


A—Alternator
CSP—Crankshaft Pulley
FC—Freon (A/C) Compressor
FD—Fan Drive
I—Idler Pulley
T—Tensioner
CP—Coolant Pump



290 mm (11.4 in.) Fan Height and Lower*



338 mm (13.3 in.) Fan Height and Higher Without Freon Compressor*



402 mm (15.8 in.) Fan Height With Freon Compressor*

3G11952 -UN-07NOV01

RG,RG34710,5599 -19-12NOV01-1/1

RG11951 -UN-07NOV0

3G11950 -UN-07NOV01

Checking Fuses In Instrument Panels

The following instructions apply to engines equipped with John Deere instrument panels.


 On Engines With The North American Standard Instrument Panel (—1998), check the fuse (A) between the ammeter (B) and key switch (C) located on back side of instrument panel. If defective, replace with an equivalent 25-amp fuse.

Also check the fuse (D) mounted on the bottom of the magnetic safety switch. If defective, install an equivalent 14-amp fuse.


- 2. On later (1999—) North American Standard Instrument Panels, check the fuse in fuse holder (E) on front face of instrument panel. Replace as necessary with an equivalent 14-amp fuse.
- 3. For VDO Instrument Panels, the fuse is located on the electronic control card inside the panel's rear access cover. Remove cover and check fuse (F). If defective, replace with a 10-amp fuse. There is a spare fuse (G) available on the card in the "SPARE" terminal.

NOTE: For main electrical system fuses, see engine wiring diagrams later in this manual in Troubleshooting Section.


- A—25 Amp Fuse
- **B**—Ammeter
- C-Key Switch
- D—14 Amp Fuse
- E—Fuse Holder F—10 Amp Fuse
- G—Spare Fuse




North American (-1998) Standard Instrument Panel Shown



North American (-1998) Standard Instrument Panel Shown



North American (1999—) Instrument Panel Shown



VDO Instrument Panel

_

RG,RG34710,5601 -19-07JAN02-1/1

3G11937 -UN-17OCT01

Bleeding the Fuel System



CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Whenever the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.




High-Pressure Fluids

RG,RG34710,5602 -19-07JAN02-1/7

1. Loosen the air bleed vent screw (A) two full turns by hand on fuel filter base.

A-Vent Screw



Air Bleed Vent Screw

Continued on next page


RG,RG34710,5602 -19-07JAN02-2/7

X9811 -UN-23AUG88

- 2. Operate supply pump primer lever (B) until fuel flow is free from air bubbles.
- 3. Tighten bleed plug securely, continue operating hand primer until pumping action is not felt. Push hand primer inward (toward engine) as far as it will go.
- 4. Start engine and check for leaks.

If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.

B—Fuel Supply Pump Primer Lever




Fuel Supply Pump Primer Lever

RG,RG34710,5602 -19-07JAN02-3/7

At Fuel Injection Pump

On Stanadyne rotary pumps:

- 1. Slightly loosen fuel return line connector (A) at fuel injection pump.
- 2. Operate fuel supply pump primer lever until fuel, without air bubbles, flows from fuel return line connection.
- 3. Tighten return line connector to 27 Nem (20 lb-ft).
- 4. Primer lever is spring-loaded and will return to normal position.



Stanadyne Rotary Fuel Injection Pump

A-Fuel Return Line Connector

Continued on next page

RG,RG34710,5602 -19-07JAN02-4/7

45-11

On Lucas rotary pumps:


1. Loosen bleed screw (B) on pump cover.

NOTE: On Models DP200/201/203 Injection Pumps, bleed screw is located on top of cover near the fuel return line.

- 2. Operate fuel supply pump primer lever or turn ignition switch to "ON".
- 3. Wait until fuel flow is free of air bubbles. Tighten bleed screw.
- 4. Primer lever is spring loaded and will return to normal position.



CAUTION: NEVER loosen screw (C) securing pump head, otherwise pump damage may occur.



Lucas Rotary Fuel Injection Pumps

B—Bleed Screw C—Screw


RG,RG34710,5602 -19-07JAN02-5/7

On DENSO and Motorpal in-line pumps:

- 1. On DENSO pump shown, unscrew hand primer on fuel supply pump until it can be pulled by hand.
- 2. Open fuel filter port plug.
- 3. Operate the hand primer until a smooth flow of fuel, free of bubbles, comes out of the filter plug hole.
- 4. Simultaneously stroke the hand primer down and close the filter port plug. This prevents air from entering the system. Tighten plug securely. DO NOT overtighten.

IMPORTANT: Be sure hand primer is all the way down in barrel before tightening to prevent internal thread damage.

5. On DENSO pump shown, lock hand primer in position.



DENSO Fuel Injection Pump Shown

Continued on next page

RG,RG34710,5602 -19-07JAN02-6/7

At Fuel Injection Nozzles

- 1. Move the engine speed control lever to half throttle position. On engines equipped with electronic fuel shut-off solenoid, energize solenoid.
- 2. Using **two** open-end wrenches, loosen fuel line connection at injection nozzle as shown.
- 3. Crank engine over with starter motor, (but do not start engine), until fuel free from bubbles flows out of loosened connection.
- 4. Retighten connection to 27 Nem (20 lb-ft).
- Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.

If engine still will not start, see your authorized servicing dealer or engine distributor.



Fuel Line Connection

RG,RG34710,5602 -19-07JAN02-7/7

General Troubleshooting Information

Troubleshooting engine problems can be difficult. An engine wiring diagram is provided in this section to help isolate electrical problems on power units using John Deere wiring harness and instrument (gauge) panel.

Wiring diagrams are shown for the two types of instrument panels offered for these engines.

Later in this section is a list of possible engine problems that may be encountered accompanied by possible causes and corrections. The illustrated diagrams and troubleshooting information are of a general nature, final design of the overall system for your engine application may be different. See your engine distributor or servicing dealer if you are in doubt.

A reliable program for troubleshooting engine problems should include the following basic diagnostic thought process:

- Know the engine and all related systems.
- Study the problem thoroughly.
- Relate the symptoms to your knowledge of engine and systems.
- Diagnose the problem starting with the easiest things first.
- Double-check before beginning the disassembly.
- Determine cause and make a thorough repair.
- After making repairs, operate the engine under normal conditions to verify that the problem and cause was corrected.

RG,RG34710,5605 -19-07JAN02-1/1

Engine Wiring Diagram Legend (Standard Instrument Panel For North America)

A1 — Speed Control Unit

B1 — Magnetic Speed Sensor

B2 — Coolant Temperature Sensor

B3 — Oil Pressure Sensor

F1 — Starting Circuit Fuse (14 amp)

F3 — Fuse (Early Models)1

G1 — Battery

G2 — Alternator

H1 — Coolant Temperature Indicator Lamp

H2 — Oil Pressure Indicator Lamp

H3 — Alternator Indicator Lamp

K1 — Starter Relay

M1 — Starter Motor

P1 — Coolant Temperature Gauge

P2 — Oil Pressure Gauge

P3 — Crankcase Oil Level Switch/Gauge

P4 — Tachometer¹

P5 — Hourmeter (Early Models)²

P6 — Ammeter

R1 — Resistor (48 ohm)3

S1 — Key Switch

S2 — Magnetic Safety Switch—North American

Auto Override Module—European (Saran)

W1 — Ground on K1 Starter Relay Mounting Stud

Y1 — Starter Solenoid

Y2 - Fuel Shut-off Solenoid

BLK — Black

BLU — Blue

BRN — Brown

DK BLU — Dark Blue

GRN — Green

ORG — Orange

PUR — Purple

RED — Red

YEL - Yellow


DPSG,RG41165,126 -19-19JUN00-1/1

¹ P4 tachometer has a built-in hourmeter. On some earlier engines, a separate hourmeter (P5) and fuse (F3) were used.

² P4 tachometer has a built-in hourmeter. On some engines, a separate hourmeter (P5) and fuse (F3) are used.

³ Later harnesses have two parallel 100 ohm resistors for the alternator.

Wiring Diagram (Standard Instrument Panel For North America) S1 KEY SWITCH G ACC. ON ST. OFF ACC. ON START S1 P4 P1 P2 P3 OFF START ACC. W1 P6 RED OR BRN F1 PUR-ST RED OR BRN RED OR BRN RED OR BRN S2 8 ۶ <u>8</u> 8 8 8 S RED OR BRN -RED OR BRN -RED OR BRN - DK BLU RED Y2 R1 **Y**1 K1 M1 G2 W1 RG11329 **B**1 DPSG,RG41165,127 -19-19JUN00-1/1



Engine Wiring Diagram Legend—VDO Instrument Panel (Except North America)

A-6 mm², Red

B — 1.5 mm², Black

C—6 mm², Blue

D-4 mm², Black

E — 0.75 mm², Orange

F — 0.75 mm², White

G — 0.75 mm², Blue

H — 0.75 mm², Purple

I — 0.75 mm², Grey

J — 0.75 mm², Brown

K-0.75 mm², Dark Blue

L — 0.75 mm², Black

M — 0.75 mm², Green/Yellow

N — 0.75 mm², Red

O—R — Not Used

 ${\bf S} - {\bf Preheater}$

T — Battery

U — Starter Motor

V — Electrical Shut-Off

W — Alternator

X — Oil Pressure Sensor

Y — Coolant Temperature Sensor

Z—Fuel Tank Gauge

DPSG,RG41165,129 -19-19JUN00-1/1

Engine Troubleshooting		
Symptom	Problem	Solution
Engine cranks but will not start	Incorrect starting procedure.	Verify correct starting procedure.
	No fuel.	Check fuel in tank and manual shut-off valve.
	Exhaust restricted.	Check and correct exhaust restriction.
	Fuel filter plugged or full of water.	Replace fuel filter or drain water from filter.
	Injection pump not getting fuel or air in fuel system.	Check fuel flow at supply pump or bleed fuel system.
	Faulty injection pump or nozzles.	Consult authorized diesel repair station for repair or replacement.
Engine hard to start or will not start	Engine starting under load.	Disengage driveline.
	Improper starting procedure.	Review starting procedure.
	No fuel.	Check fuel tank.
	Air in fuel line.	Bleed fuel line.
	Cold weather.	Use cold weather starting aids.
	Slow starter speed.	See "Starter Cranks Slowly".
	Crankcase oil too heavy.	Use oil of proper viscosity.
	Improper type of fuel.	Consult fuel supplier; use proper type fuel for operating conditions.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Clogged fuel filter.	Replace filter element.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Injection pump shut-off not reset.	Turn key switch to "OFF" then to "ON".

Continued on next page

RG,RG34710,5608 -19-07JAN02-1/7

Symptom	Problem	Solution
Engine knocks	Low engine oil level.	Add oil to engine crankcase.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Low coolant temperature.	Remove and check thermostat.
	Engine overheating.	See "Engine Overheats".
Engine runs irregularly or stalls frequently	Low coolant temperature.	Remove and check thermostat.
	Clogged fuel filter.	Replace fuel filter element.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
Below normal engine temperature	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check gauge, sender, and connections.
	Continued on next page	RG,RG34710,5608 -19-07JAN02-2/7

50-8

Symptom	Problem	Solution
Lack of power	Engine overloaded.	Reduce load.
	Intake air restriction.	Service air cleaner.
	Clogged fuel filter.	Replace filter elements.
	Improper type of fuel.	Use proper fuel.
	Overheated engine.	See "Engine Overheats".
	Below normal engine temperature.	Remove and check thermostat.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning. (Turbocharger engines only.)	See your authorized servicing dealer or engine distributor.
	Leaking exhaust manifold gasket.	See your authorized servicing dealer or engine distributor.
	Defective aneroid control line.	See your authorized servicing dealer or engine distributor.
	Restricted fuel hose.	Clean or replace fuel hose.
	Low fast idle speed.	See your authorized servicing dealer or engine distributor.
Low oil pressure	Low oil level.	Add oil.
	Improper type of oil.	Drain, fill crankcase with oil of proper viscosity and quality.
	Continued on next page	RG,RG34710,5608 -19-07JAN02-3/7

Symptom	Problem	Solution
High oil consumption	Crankcase oil too light.	Use proper viscosity oil.
	Oil leaks.	Check for leaks in lines, gaskets, and drain plug.
	Restricted crankcase vent tube.	Clean vent tube.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
Engine emits white smoke	Improper type of fuel.	Use proper fuel.
	Low engine temperature.	Warm up engine to normal operating temperature.
	Defective thermostat.	Remove and check thermostat.
	Defective injection nozzles.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
Engine emits black or gray exhaust smoke	Improper type of fuel.	Use proper fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning.	See your authorized servicing dealer or engine distributor.
	Continued on next page	RG,RG34710,5608 -19-07JAN02-4/7

50-10

Symptom	Problem	Solution
Engine overheats	Engine overloaded.	Reduce load.
	Low coolant level.	Fill radiator to proper level, check radiator and hoses for loose connections or leaks.
	Faulty radiator cap.	Have serviceman check.
	Stretched poly-vee belt or defective belt tensioner.	Check automatic belt tensioner and check belts for stretching. Replace as required.
	Low engine oil level.	Check oil level. Add oil as required.
	Cooling system needs flushing.	Flush cooling system.
	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check water temperature with thermometer and replace, if necessary.
	Incorrect grade of fuel.	Use correct grade of fuel.
High fuel consumption	Improper type of fuel.	Use proper type of fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
	Low engine temperature.	Check thermostat.

Continued on next page

RG,RG34710,5608 -19-07JAN02-5/7

Symptom	Problem	Solution	
Undercharged electrical system	Excessive electrical load from added accessories.	Remove accessories or install higher output alternator.	
	Excessive engine idling.	Increase engine rpm when heavy electrical load is used.	
	Poor electrical connections on battery, ground strap, starter, or alternator.	Inspect and clean as necessary.	
	Defective battery.	Test battery.	
	Defective alternator.	Test charging system.	
Battery uses too much water	Cracked battery case.	Check for moisture and replace as necessary.	
	Defective battery.	Test battery.	
	Battery charging rate too high.	Test charging system.	
Batteries will not charge	Loose or corroded connections.	Clean and tighten connections.	
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.	
	Stretched poly-vee belt or defective belt tensioner.	Adjust belt tension or replace belts.	
Starter will not crank	Engine driveline engaged.	Disengage engine driveline.	
	Loose or corroded connections.	Clean and tighten loose connections	
	Low battery output voltage.	See your authorized servicing dealer or engine distributor.	
	Faulty start circuit relay.	See your authorized servicing dealer or engine distributor.	
	Blown main system fuse (MDL-25)	Replace fuse.	
Starter cranks slowly	Low battery output.	See your authorized servicing dealer or engine distributor.	
	Crankcase oil too heavy.	Use proper viscosity oil.	
	Loose or corroded connections.	Clean and tighten loose connections	

Continued on next page

RG,RG34710,5608 -19-07JAN02-6/7

Symptom	Problem	Solution
Starter and hour meter functions; rest of electrical system does not function	Blown fuse on magnetic switch.	Replace fuse.
Entire electrical system does not function	Faulty battery connection.	Clean and tighten connections.
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.
	Blown main system fuse (MDL-25).	Replace fuse.
		RG,RG34710,5608 -19-07JAN02-7/7

50-13

Storage

Engine Storage Guidelines

- John Deere engines can be stored outside for up to three (3) months with no long term preparation IF COVERED BY WATERPROOF COVERING.
- 2. John Deere engines can be stored in a standard overseas shipping container for up to three (3) months with no long term preparation.
- 3. John Deere engines can be stored inside, warehoused, for up to six (6) months with no long term preparation.
- John Deere engines expected to be stored more than six (6) months, long term storage preparation MUST BE taken. (See PREPARING ENGINE FOR LONG TERM STORAGE, later in this section.)

RG,RG34710,5610 -19-23NOV01-1/1

Preparing Engine for Long Term Storage

The following storage preparations are good for long term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

IMPORTANT: Any time your engine will not be used for over six (6) months, the following recommendations for storing it and removing it from storage will help to minimize corrosion and deterioration.

- Change engine oil and replace filter. Used oil will not give adequate protection. (See CHANGE ENGINE OIL AND FILTER in Lubrication and Maintenance/500 Hour Section.)
- Service air cleaner. (See REPLACING AIR CLEANER FILTER ELEMENTS in Service As Required Section.)
- 3. Draining and flushing of cooling system is not necessary if engine is to be stored only for several months. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. (See RECOMMENDED ENGINE COOLANT in Fuels, Lubricants, and

Coolant Section and ADDING COOLANT in Service As Required Section.)

- 4. Crank the engine several revolutions with starter (do not allow the engine to start).
- 5. Remove fan/alternator poly-vee belt, if desired.
- 6. Remove and clean batteries. Store them in a cool, dry place and keep them fully charged.
- 7. Disengage the clutch for any driveline.
- 8. Clean the exterior of the engine with salt-free water and touchup any scratched or chipped painted surfaces with a good quality paint.
- 9. Coat all exposed (machined) metal surfaces with grease or corrosion inhibitor if not feasible to paint.
- 10. Seal all openings on engine with plastic bags and tape.
- 11. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

RG,RG34710,5612 -19-23NOV01-1/1

Removing Engine from Long Term Storage

Refer to the appropriate section for detailed services listed below or have your authorized servicing dealer or engine distributor perform services that you may not be familiar with.

- Remove all protective coverings from engine.
 Unseal all openings in engine and remove covering from electrical systems.
- 2. Remove the batteries from storage. Install batteries (fully charged) and connect the terminals.
- 3. Install fan/alternator poly-vee belt if removed.
- 4. Fill fuel tank.
- 5. Perform all appropriate prestarting checks. (See DAILY PRESTARTING CHECKS in Lubrication and Maintenance/Daily Section.)

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

- Crank engine for 20 seconds with starter (do not allow the engine to start). Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.
- 7. Start engine and run at low idle and no load for several minutes. Warm up carefully and check all gauges before placing engine under load.
- 8. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.

RG,RG34710,5613 -19-20MAY96-1/1

General OEM Engine Specifications—4.5 L **Engines**

ITEM				ENG	INE			
	4045DF120	4045DF150	4045TF120	4045TF150	4045TF220	4045TF250	4045HF120	4045HF150
Number of Cylinders	4	4	4	4	4	4	4	4
Bore	106 mm							
	(4.19 in.)							
Stroke	127 mm							
	(5.0 in.)							
Displacement	4.5 L							
	(276 cu							
	in.)							
Compression Ratio	17.8:1	17.6:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1
Max. Crank Pressure	0.5 kPa							
	(2 H₂O)							
Governor Regulation (Industrial)	7—10 %	7—10 %	N/A	7—10 %	N/A	7—10 %	N/A	7—10 %
Governor Regulation (Generator)	N/A	5 %	5%	5 %	5%	5 %	5%	5 %
Oil Pressure At Rated Speed, Full Load (± 15 psi)	345 kPa							
	(50 psi)							
Oil Pressure At Low Idle (Minimum)	105 kPa							
	(15 psi)							
Length	844.0 mm	861.0 mm						
	(33.2 in.)	(33.9 in.)						
Width	550 mm	598 mm						
	(21.7 in.)	(23.5 in.)	(23.5 in.)	(23.5 in.)	(23.5 in)	(23.5 in.)	(23.5 in.)	(23.5 in.)
Height	871 mm	854 mm	980 mm					
	(34.3 in.)	(33.6 in.)	(38.6 in.)					
Weight	429 kg	387 kg	396 kg					
	(945 lb)	(851 lb)	(872 lb)					

NOTE: Engine models listed with numbers ending in "120" and "220" are emission non-certified. Engines with model numbers ending in "150" and "250" are Tier I emission certified. (Later engines with model numbers ending in "275" are Tier II emission certified with electronic fuel systems and are covered in another manual, OMRG33324.)

General OEM Engine Specifications—6.8 L Engines

ITEM	ENGINE								
	6068DF150	6068TF120	6068TF150	6068TF220	6068TF250	6068HF120	6068HF150	6068HF250	
Number of Cylinders	6	6	6	6	6	6	6	6	
Bore	106 mm	106 mm	106 mm	106 mm	106 mm	106 mm	106 mm	106 mm	
	(4.19 in.)	(4.19 in.)	(4.19 in.)	(4.19 in.)	(4.19 in.)	(4.19 in.)	(4.19 in.)	(4.19 in.)	
Stroke	127 mm	127 mm	127 mm	127 mm	127 mm	127 mm	127 mm	127 mm	
	(5.0 in.)	(5.0 in.)	(5.0 in.)	(5.0 in.)	(5.0 in.)	(5.0 in.)	(5.0 in.)	(5.0 in.)	
Displacement	6.8 L	6.8 L	6.8 L	6.8 L	6.8 L	6.8 L	6.8 L	6.8 L	
	(414 cu in.)	(414 cu in.)	(414 cu in.)	(414 cu in.)	(414 cu in.)	(414 cu in.)	(414 cu in.)	(414 cu in.)	
Compression	17.6:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1	
Max. Crank Pressure	0.5 kPa	0.5 kPa	0.5 kPa	0.5 kPa	0.5 kPa	0.5 kPa	0.5 kPa	0.5 kPa	
	(2 H ₂ O)	(2 H ₂ O)	(2 H₂O)						
Governor Regulation (Industrial)	7—10 %	N/A	7—10 %	7—10 %	7—10 %	N/A	7—10 %	7—10 %	
Governor Regulation (Generator)	5 %	5%	5 %	5%	5 %	5 %	5 %	5%	
Oil Pressure Rated Speed	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	
Oil Pressure Low Idle	105 kPa	105 kPa (15	105 kPa						
	(15 psi)	psi)	(15 psi)	(15 psi)	(15 psi)	(15 psi)	(15 psi)	(15 psi)	
Length	1117 mm	1117 mm	1117 mm	1116 mm	1117 mm	1141 mm	1116 mm	1141 mm	
	(44.0 in.)	(44.0 in.)	(44.0 in.)	(43.9 in.)	(44.0 in.)	(44.9 in.)	(43.9 in.)	(44.9 in.)	
Width	598 mm	598 mm	598 mm	623 mm	598 mm	623 mm	623 mm	623 mm	
	(23.5 in.)	(23.5 in.)	(23.5 in.)	(24.5 in.)	(23.5 in.)	(24.5 in.)	(24.5 in.)	(24.5 in.)	
Height	956 mm	984 mm	984 mm	1012 mm	984 mm	1009 mm	1009 mm	1009 mm	
	(37.6 in.)	(38.7 in.)	(38.7 in.)	(39.9 in.)	(38.7 in.)	(39.7 in.)	(39.7 in.)	(39.7 in.)	
Weight	522 kg	533 kg	533 kg	551 kg	533 kg	568 kg	550 kg	568 kg	
	(1149 lb)	(1172 lb)	(1172 lb)	(1212 lb)	(1172 lb)	(1250 lb)	(1210 lb)	(1250 lb)	

NOTE: Engine models listed with numbers ending in "120" and "220" are emission non-certified. Engines with model numbers ending in "150" and "250" are Tier I emission certified with electronic fuel systems and are covered in another manual, OMRG33324.).

OUOD005,000017B -19-07JAN02-1/1

Engine Power Ratings And Fuel Injection Pump Specifications

NOTE: The power specifications shown below apply to Dubuque, Torreon and Saran-built OEM engines. Specifications are subject to change. Refer to factory DTAC for assistance.

Engine speeds listed are as preset to factory specification. In most cases, slow idle speed will be reset depending upon specific vehicle application requirements. Refer to your machine technical manual for engine speeds that are different from those preset at the factory.

Power ratings specify flywheel power for a bare engine without the drag effect of a cooling fan or other accessories like an air compressor.

	POWER RATINGS ON DYNAMOMETER FOR OEM ENGINES									
Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)		
4045DF120	16MR	RE504463		STD	2500	850	2700	63 (85)		
	16MS	RE504464		STD	2500	850	2700	63 (85)		
4045DF150	1601	RE61649	RE67557	STD	2500	850	2700	60 (80)		
	1601	RE67557		STD	2500	850	2700	60 (80)		
	1602	RE59809		STD	2500	850	2700	63 (85)		
	1603	RE63555	RE67558	3—5%	1800	1150	1870	53 (71)		
	1603	RE67558	RE505070	3—5%	1800	1150	1870	53 (71)		
	1603	RE505070	RE506132	3—5%	1800	1150	1870	53 (71)		
	1603	RE506132		3—5%	1800	1150	1870	53 (71)		
	1663	RE71089	RE500949	STD	2500	1600	2700	60 (80)		
	1663	RE500949		STD	2500	1600	2700	60 (80)		
	1671	RE67559	RE502714	STD	2500	850	2700	60 (80)		
	1671	RE502714		STD	2500	850	2700	60 (80)		
	1673	RE60085	RE67560	3—5%	1800	1400	1870	53 (71)		
	1673	RE67560	RE506130	3—5%	1800	1400	1870	53 (71)		
	1673	RE506130		3—5%	1800	1400	1870	53 (71)		
	1674	RE60089	RE67561	3—5%	1800	1400	1870	53 (71)		
	1674	RE67561	RE506131	3—5%	1800	1400	1870	53 (71)		
	1674	RE506131		3—5%	1800	1400	1870	53 (71)		
	1691	RE61649	RE500831	STD	2500	850	2700	60 (80)		
	1691	RE500831	RE500948	STD	2500	850	2700	60 (80)		
	1691	RE500948		STD	2500	850	2700	60 (80)		
	16BG	RE69778	RE502712	STD	2500	850	2700	63 (85)		
	16BG	RE502712		STD	2500	850	2700	63 (85)		
	16BH	RE500873	RE502715	STD	2500	850	2700	63 (85)		
	16BH	RE502715		STD	2500	850	2700	63 (85)		
	16BJ	RE500589		STD	2250	850	2450	36 (48)		
	16CL	RE501364	RE502713	STD	2200	950	2400	58 (78)		
	16CL	RE502713		STD	2200	950	2400	58 (78)		
	16DL	RE70452		STD	2400	850	2600	61 (82)		
	16EN	RE502019		STD	2500	850	2700	60 (80)		

Continued on next page

RG,RG34710,5616 -19-16JAN02-1/6

POWER RATINGS ON DYNAMOMETER FOR OEM ENGINES									
Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)	
	16GB	RE502711		STD	2500	850	2700	60 (80)	
	16GC	RE502716		STD	2500	850	2700	60 (80)	
	16HJ	RE500948		STD	2500	1400	2700	60 (80)	
	16HK	RE500949		STD	2500	1600	2700	60 (80)	
	16HV	RE503258		STD	2250	850	2450	36 (48)	
	16KE	RE503560		STD	2500	850	2700	52 (70)	
	16LM	RE502711		STD	2500	850	2700	53 (71)	
	16LN	RE67558	RE505070	3—5%	1800	1150	1870	53 (71)	
	16LN	RE505070	RE506132	3—5%	1800	1150	1870	53 (71)	
	16LN	RE506132		3—5%	1800	1150	1870	53 (71)	
	16RB	RE503729		3—5%	1500	1400	1560	44 (59)	
	16RC	RE504693		3—5%	1500	1400	1560	44 (59)	
4045DF151	1663	RE71089	RE500949	STD	2500	1600	2700	60 (80)	
	1663	RE500949		STD	2500	1600	2700	60 (80)	
4045DF152	1601	RE67557		STD	2500	850	2700	60 (80)	
	16GB	RE502711		STD	2500	850	2700	60 (80)	
4045DF154	16AY	RE500505		STD	2400	850	2600	62 (83)	
	16JS	RE500505		STD	2400	850	2600	62 (83)	
4045HF120	16GR	RE503050		3—5%	1500	1400	1560	102 (137)	
	16LW	RE503832		3—5%	1500	1400	1560	102 (137)	
4045HF150	1610	RE68826		STD	2400	850	2600	104 (140)	
	1611	RE60237		3—5%	1800	1400	1870	95 (127)	
	160B	RE68827		3—5%	1800	1400	1870	95 (127)	
	160C	RE69588		STD	2400	850	2600	104 (140)	
	16GR	RE503050		3—5%	1500	1150	1560	100 (134)	
	16LW	RE503832		3—5%	1500	1150	1560	100 (134)	
	16QZ	RE503050		3—5%	1800	1400	1870	111 (149)	
	16RA	RE503832		3—5%	1800	1400	1870	111 (149)	
4045HF152	16RM	RE505959		STD	2400	850	2600	104 (140)	
4045HF158	16GR	RE503050		3—5%	1500	1150	1560	100 (134)	
	16LW	RE503832		3—5%	1500	1150	1560	100 (134)	
	16ME	RE503739		3—5%	1800	1400	1870	123 (165)	
	16MF	RE504698	RE504966	3—5%	1800	1400	1870	123 (170)	
	16MF	RE504966		3—5%	1800	1400	1870	123 (170)	
4045TF120	16MT	RE503733		3—5%	1500	1400	1560	70 (94)	
	16MU	RE505050		3—5%	1500	1400	1560	70 (94)	
4045TF150	1605	RE61668	RE69781	STD	2500	850	2700	86 (115)	
-	1605	RE69781		STD	2500	850	2700	86 (115)	
	1606	RE64133		STD	2400	850	2600	93 (125)	
	1656	RE63610	RE67562	3—5%	1800	1150	1870	75 (100)	
	1656	RE67562		3—5%	1800	1150	1870	75 (100)	
	1675	RE60091	RE69782	STD	2500	850	2700	86 (115)	

Continued on next page

RG,RG34710,5616 -19-16JAN02-2/6

	POWER RATINGS ON DYNAMOMETER FOR OEM ENGINES										
Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)			
	1675	RE69782		STD	2500	850	2700	86 (115)			
	1676	RE60093		STD	2500	850	2700	86 (115)			
	1677	RE60096	RE67563	3—5%	1800	1150	1870	75 (100)			
	1677	RE67563		3—5%	1800	1150	1870	75 (100)			
	1692	RE61668	RE500881	STD	2500	1400	2700	86 (115)			
	1692	RE500881	RE502416	STD	2500	1400	2700	86 (115)			
	1692	RE502416		STD	2500	1400	2700	86 (115)			
	1694	RE67863	RE69779	STD	2500	850	2700	75 (100)			
	1694	RE69779		STD	2500	850	2700	75 (100)			
	1695	RE69739	RE69780	STD	2500	850	2700	75 (100)			
	1695	RE69780		STD	2500	850	2700	75 (100)			
	16AB	RE69779		STD	2500	850	2700	75 (100)			
	16BF	RE500848		STD	2200	950	2400	73 (98)			
	16CE	RE501180		STD	2500	850	2700	75 (100)			
	16CM	RE501365		STD	2200	950	2400	66.6 (89)			
	16GL	RE502706		STD	2300	850	2500	78 (105)			
	16LP	RE67562		3—5%	1800	1150	1870	75 (100)			
	16LZ	RE503735		3—5%	1800	1400	1870'	70 (94)			
	16MA	RE504696	RE504931	3—5%	1800	1400	1870	82 (110)			
	16MA	RE504931		3—5%	1800	1400	1870	82 (110)			
	16MT	RE503733	RE505050	3—5%	1500	1400	1560	70 (94)			
	16MT	RE505050		3—5%	1500	1400	1560	70 (94)			
	16MU	RE504695	RE505050	3—5%	1500	1400	1560	70 (94)			
	16MU	RE505050		3—5%	1500	1400	1560	70 (94)			
	16TG	RE507941		STD	2000	850	2185	77 (103)			
	16YJ	RE508834		STD	2000	850	2185	77 (103)			
4045TF151	1677	RE67563		3—5%	1800	850	1870	75 (100			
	16CU	RE501192		STD	2200	850	2400	79.5 (107)			
	16NH	RE505411		3—5%	1800	1150	2240	75 (100)			
4045TF154	1605	RE69781		STD	2500	850	2700	86 (115)			
4045TF220	16GQ	RE503048		3—5%	1500	1400	1560	83 (111)			
	16LV	RE503830		3—5%	1500	1400	1560	83 (111)			
	16MV	RE503736		3—5%	1800	1400	1870	100 (134)			
	16MW	RE505051		3—5%	1800	1400	1870	100 (134)			
	16NT	RE504465		STD	2500	850	2700	86 (115)			
	16NU	RE504466		STD	2500	850	2700	86 (115)			
4045TF250	1606	RE64133		STD	2400	850	2600	93 (125)			
	1608	RE67564		3—5%	1800	1400	1870	84 (113)			
	1667	RE59968		STD	2400	850	2600	93 (125)			
	1682	RE67566		3—5%	1800	1400	1870	84 (113)			
	1683	RE60124		STD	2400	850	2600	93 (125)			
	160R	RE70941		3—5%	1800	1400	1870	84 (113)			
	16CV	RE501346		STD	2200	950	2400	85 (114)			
	1000	1.2001040	1	L	ued on next page	300	_	616 –19–16JAN0			

Continued on next page RG,RG34710,5616 -19-16JAN02-3/6

Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)
	16GQ	RE503048		3—5%	1500	1150	1560	83 (111)
	16LQ	RE67564		3—5%	1800	1400	1870	84 (113)
	16LV	RE503830		3—5%	1500	1150	1560	83 (111)
	16MB	RE503737		3—5%	1800	1400	1870	91(122)
	16MC	RE504932		3—5%	1800	1400	1870	91 (122)
	161C	RE507525		3—5%	1800	1400	1870	100 (134)
	161D	RE507526		3—5%	1800	1400	1870	100 (134)
4045TF251	1606	RE64133		STD	2400	850	2600	93 (125)
6068DF150	1613	RE59861		STD	2500	850	2700	93 (125)
	1678	RE60101		STD	2500	850	2700	93 (125)
	16LR	RE59861		STD	2500	850	2700	93 (125)
6068HF120	16GT	RE503051		3—5%	1500	1400	1560	155 (208)
	16LY	RE503834		3—5%	1500	1400	1560	155 (208)
	16RL	RE506085		3—5%	2100	950	2200	197 (264)
	16SJ	RE506627		3—5%	2100	950	2200	197 (264)
	16TP	RE506883		3—5%	1500	1150	1560	183 (245)
	16TQ	RE506884		3—5%	1500	1150	1560	183 (245)
	16ZQ	RE509428		3—5%	2100	950	2200	197 (264)
	16ZR	RE509429		3—5%	2100	950	2200	197 (264)
6068HF150	1621	RE66575		STD	2400	850	2600	157 (210)
	160D	RE69589		STD	2400	850	2600	157 (210)
	16CY	RE501345		STD	2200	1350	2400	143 (192)
	16GT	RE503051		3—5%	1500	1400	1560	153 (205)
	16LY	RE503836		3—5%	1500	1400	1560	153 (205)
	16ML	RE503746		3—5%	1800	1400	1870	187 (251)
	16MM	RE504702	RE505049	3—5%	1800	1400	1870	187 (251)
	16MM	RE505049		3—5%	1800	1400	1870	187 (251)
	16QV	RE503051		3—5%	1800	1400	1870	166 (223)
	16QW	RE503836		3—5%	1800	1400	1870	166 (223)
6068HF250	1622	RE59521ª		STD	2400	850	2600	168 (225)
	1623	RE66761 ^a		3—5%	1800	1400	1870	148 (198)
	16YH	RE59969		STD	2400	850	2600	138 (185)
6068TF120	16MX	RE503740		3—5%	1500	1400	1560	105 (141)
	16MY	RE505052		3—5%	1500	1400	1560	105 (141)
6068TF150	1614	RE61669	RE69789	STD	2500	850	2700	127 (170)
	1614	RE69789		STD	2500	850	2700	127 (170)
	1680	RE60105	RE69790	STD	2500	850	2700	127 (170)
	1680	RE69790		STD	2500	850	2700	127 (170)
	1681	RE67571		3—5%	1800	1150	1870	112 (150)
	1688	RE67572		3—5%	1800	1150	1870	112 (150)
	1696	RE67864	RE69787	STD	2500	850	2700	116 (155)

Continued on next page

RG,RG34710,5616 -19-16JAN02-4/6

Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)
	1696	RE69787		STD	2500	850	2700	116 (155)
	1697	RE68740	RE69788	STD	2500	850	2700	116 (155)
	1697	RE69788		STD	2500	850	2700	116 (155)
	16BE	RE63559	RE501302	STD	2200	950	2400	117 (157)
	16BE	RE501302		STD	2200	950	2400	117 (157)
	16CN	RE501522		STD	2100	950	2300	110.5 (148
	16CP	RE501523		STD	2200	950	2400	94 (126)
	16DK	RE70938		STD	2100	900	2300	96 (129)
	16DY	RE501758		STD	2500	850	2700	116 (155)
	16GM	RE502693		STD	2300	850	2500	110 (148)
	16GN	RE502704		STD	2400	850	2600	116 (155)
	16LS	RE67572		3—5%	1800	1150	1870	112 (150)
	16MG	RE503742		3—5%	1800	1400	1870	123 (165)
	16MH	RE504967		3—5%	1800	1400	1870	123 (165)
6068TF151	1681	RE67571	RE505358	3—5%	1800	1150	1870	112 (150)
	1681	RE505358		3—5%	1800	1150	1870	112 (150)
	1696	RE69787		STD	2500	850	2700	116 (155)
	16NJ	RE505358		3—5%	1800	1150	1870	112 (150)
6068TF152	1696	RE69787		STD	2500	850	2700	116 (155)
	16JU	RE69787		STD	2500	850	2700	116 (155)
6068TF220	16GS	RE503049		3—5%	1500	1400	1560	121 (162)
	16KK	RE502694		STD	2500	850	2700	127 (170)
	16LX	RE503836		3—5%	1500	1400	1560	121 (162)
	16RK	RE506083		3—5%	2600	850	2700	138 (185)
	16RJ	RE506084		3—5%	2100	950	2200	172 (231)
	16SG	RE506625		3—5%	2100	950	2200	172 (231)
	16SH	RE506626		3—5%	2600	850	2700	138 (185)
	16ZL	RE509424		3—5%	2100	950	2200	172 (231)
	16ZM	RE509425		3—5%	2100	950	2200	172 (231)
	16ZN	RE509426		STD	2600	850	2800	138 (185)
	16ZP	RE509427		STD	2600	850	2800	138 (185)
6068TF250	1615	RE62366	RE69791	STD	2400	850	2600	138 (185)
	1615	RE69791		STD	2400	850	2600	138 (185)
	1619	RE67573		3—5%	1800	1150	1870	124 (166)
	1668	RE59969 ^a		STD	2400	850	2600	138 (185)
	1685	RE67574		3—5%	1800	1150	1870	124 (166)
	1686	RE60131	RE69792	STD	2400	850	2600	138 (185)
	1686	RE69792		STD	2400	850	2600	138 (185)
	16CW	RE501344		STD	2200	950	2400	106 (142)
	16CX	RE70390		STD	2300	900	2500	128 (172)
	16GS	RE503049		3—5%	1500	1400	1560	120 (172)
	16LT	RE69791		STD	2400	850	2600	138 (185)

Continued on next page

RG,RG34710,5616 -19-16JAN02-5/6

POWER RATINGS ON DYNAMOMETER FOR OEM ENGINES										
Engine Model	Injection Pump Option Code	Original Injection Pump (Part No.)	Replaced By Injection Pump (Part No.)	Governor Regulation	Rated Speed (rpm) At Full Load	Slow Idle (rpm)	No Load Fast Idle (rpm)	Power Rating kW (HP)		
	16LU	RE67573		3—5%	1800	1150	1870	124 (166)		
	16LX	RE503834		3—5%	1500	1400	1560	120 (161)		
	16MJ	RE503744		3—5%	1800	1400	1870	142 (190)		
	16MK	RE504701	RE504968	3—5%	1800	1400	1870	142 (190)		
	16MK	RE504968		3—5%	1800	1400	1870	142 (190)		
6068TF251	1615	RE62366		STD	2400	850	2600	138 (185)		

RG,RG34710,5616 -19-16JAN02-6/6

Engine Crankcase Oil Fill Quantities

To determine the option code for the oil fill quantity of your engine, refer to the engine option code label affixed to the rocker arm cover. The first two digits of the code (19) identify the oil pan option group. The last two digits of each code identify the specific oil pan on your engine.

The following table lists engine crankcase oil fill quantities for each "19__" option code for these engines.

Continued on next page

RG,RG34710,5617 -19-07JAN02-1/4

Engine Model	Oil Pan Option Code(s)	Crankcase Oil Capacity L (qt)
045DF120	1901	8.0 (8.5)
	1902	8.0 (8.5)
	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1020	10.0 (10.0)
045DF150	1901	8.0 (8.5)
04001 100	1902	8.0 (8.5)
	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)
0.450.54.54	4004	0.0 (0.5)
045DF151	1901	8.0 (8.5)
045DF152	1902	8.0 (8.5)
0.007.102	1002	0.0 (0.0)
045DF154	1937	12.5 (13.2)
		,
045HF120	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)
045HF150	1904	13.5 (14.3)
	1921	16.5 (17.4)
	1922	16.5 (17.4)
	1923	
		15.0 (15.8)
	1949	12.5 (13.2)
045HF158	1949	12.5 (13.2)
.045TF120	1903	10.5 (12.0)
04517120		12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)
		10 7 (10 0)
045TF150	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)
0.4575454	4000	10.5 (10.0)
045TF151	1903	12.5 (13.2)
	1934	12.5 (13.2)
	1936	12.5 (13.2)
0.4575000	1000	10.5 (10.0)
.045TF220	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)
1045 TF 050	1000	10.5 (10.0)
1045TF250	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1949	12.5 (13.2)

Continued on next page

RG,RG34710,5617 -19-07JAN02-2/4

Engine Model 1045TF251	Oil Pan Option Code(s) 1904	Crankcase Oil Capacity L (qt) 13.5 (14.3)
04011201	1004	10.0 (14.0)
6068DF150	1907	19.5 (20.6)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1950	20.0 (21.1)
068TF120	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1944	20.0 (21.1)
	1956	18.0 (19.0)
068TF150	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1950	20.0 (21.1)
	1956	18.0 (19.0)
	1930	18.0 (19.0)
068TF151	1907	19.0 (20.1)
	1909	19.0 (20.1)
	1944	20.0 (21.1)
5068TF152	1909	19.0 (20.1)
000011 132	1909	19.0 (20.1)
6068TF159	1963	21.5 (22.7)
6068TF220	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1950	20.0 (21.1)
	1956	18.0 (19.0)
00075050	1007	40.0 (00.4)
068TF250	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1924	25.0 (26.4)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1950	20.0 (21.1)
	1956	18.0 (19.0)
068TF251	1909	19.0 (20.1)
6068HF120	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1950	20.0 (21.1)
	1956	18.0 (19.0)

Continued on next page


RG,RG34710,5617 -19-07JAN02-3/4

Engine Model	Oil Pan Option Code(s)	Crankcase Oil Capacity L (qt)
6068HF150	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1924	24.2 (25.6)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1950	20.0 (21.1)
	1956	18.0 (19.0)
	1968	32.0 (34.0)
6068HF157	1950	20.0 (21.1)
6068HF158	1950	20.0 (21.1)
6068HF250	1907	19.0 (20.1)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1924	24.2 (25.6)
	1944	20.0 (21.1)
	1948	20.0 (21.1)
	1961	32.0 (34.0)
	1968	32.0 (34.0)

NOTE: Crankcase oil capacity may vary slightly from amount shown. ALWAYS fill crankcase to within crosshatch on dipstick. DO NOT overfill.

RG,RG34710,5617 -19-07JAN02-4/4

Unified Inch Bolt and Cap Screw Torque Values



Top, SAE Grade and Head Markings; Bottom, SAE Grade and Nut Markings

	Grade 1 (No Mark)	Grade 2ª	(No Mark)	Grade 5,	5.1 or 5.2	Grade 8 or 8.2	
Size	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)						
1/4	3.8 (2.8)	4.7 (3.5)	6 (4.4)	7.5 (5.5)	9.5 (7)	12 (9)	13.5 (10)	17 (12.5)
5/16	7.7 (5.7)	9.8 (7.2)	12 (9)	15.5 (11.5)	19.5 (14.5)	25 (18.5)	28 (20.5)	35 (26)
3/8	13.5 (10)	17.5 (13)	22 (16)	27.5 (20)	35 (26)	44 (32.5)	49 (36)	63 (46)
7/16	22 (16)	28 (20.5)	35 (26)	44 (32.5)	56 (41)	70 (52)	80 (59)	100 (74)
1/2	34 (25)	42 (31)	53 (39)	67 (49)	85 (63)	110 (80)	120 (88)	155 (115)
9/16	48 (35.5)	60 (45)	76 (56)	95 (70)	125 (92)	155 (115)	175 (130)	220 (165)
5/8	67 (49)	85 (63)	105 (77)	135 (100)	170 (125)	215 (160)	240 (175)	305 (225)
3/4	120 (88)	150 (110)	190 (140)	240 (175)	300 (220)	380 (280)	425 (315)	540 (400)
7/8	190 (140)	240 (175)	190 (140)	240 (175)	490 (360)	615 (455)	690 (510)	870 (640)
1	285 (210)	360 (265)	285 (210)	360 (265)	730 (540)	920 (680)	1030 (760)	1300 (960)
1-1/8	400 (300)	510 (375)	400 (300)	510 (375)	910 (670)	1150 (850)	1450 (1075)	1850 (1350)
1-1/4	570 (420)	725 (535)	570 (420)	725 (535)	1280 (945)	1630 (1200)	2050 (1500)	2600 (1920)
1-3/8	750 (550)	950 (700)	750 (550)	950 (700)	1700 (1250)	2140 (1580)	2700 (2000)	3400 (2500)
1-1/2	990 (730)	1250 (930)	990 (730)	1250 (930)	2250 (1650)	2850 (2100)	3600 (2650)	4550 (3350)

^a Grade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.


DX,TORQ1 -19-01OCT99-1/1

TORQ1A -UN-27SEP99

^b "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^c "Dry" means plain or zinc plated without any lubrication.

Metric Bolt and Cap Screw Torque Values



Top, Property Class and Head Markings; Bottom, Property Class and Nut Markings

	Clas	Class 4.8		.8 or 9.8	Class	10.9	Class 12.9	
Size	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricateda N•m(lb-ft)	Dry⁵ N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry⁵ N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)
M6	4.7 (3.5)	6 (4.4)	9 (6.6)	11.5 (8.5)	13 (9.5)	16.5 (12.2)	15.5 (11.5)	19.5 (14.5)
M8	11.5 (8.5)	14.5 (10.7)	22 (16)	28 (20.5)	32 (23.5)	40 (29.5)	37 (27.5)	47 (35)
M10	23 (17)	29 (21)	43 (32)	55 (40)	63 (46)	80 (59)	75 (55)	95 (70)
M12	40 (29.5)	50 (37)	75 (55)	95 (70)	110 (80)	140 (105)	130 (95)	165 (120)
M14	63 (46)	80 (59)	120 (88)	150 (110)	175 (130)	220 (165)	205 (150)	260 (190)
M16	100 (74)	125 (92)	190 (140)	240 (175)	275 (200)	350 (255)	320 (235)	400 (300)
M18	135 (100)	170 (125)	265 (195)	330 (245)	375 (275)	475 (350)	440 (325)	560 (410)
M20	190 (140)	245 (180)	375 (275)	475 (350)	530 (390)	675 (500)	625 (460)	790 (580)
M22	265 (195)	330 (245)	510 (375)	650 (480)	725 (535)	920 (680)	850 (625)	1080 (800)
M24	330 (245)	425 (315)	650 (480)	820 (600)	920 (680)	1150 (850)	1080 (800)	1350 (1000)
M27	490 (360)	625 (460)	950 (700)	1200 (885)	1350 (1000)	1700 (1250)	1580 (1160)	2000 (1475)
M30	660 (490)	850 (625)	1290 (950)	1630 (1200)	1850 (1350)	2300 (1700)	2140 (1580)	2700 (2000)
M33	900 (665)	1150 (850)	1750 (1300)	2200 (1625)	2500 (1850)	3150 (2325)	2900 (2150)	3700 (2730)
M36	1150 (850)	1450 (1075)	2250 (1650)	2850 (2100)	3200 (2350)	4050 (3000)	3750 (2770)	4750 (3500)

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TORQ2 -UN-07SEP99

DX,TORQ2 -19-01OCT99-1/1

^b "Dry" means plain or zinc plated without any lubrication.

Lubrication and Maintenance Records

Using Lubrication and Maintenance Records

Refer to specific Lubrication and Maintenance Section for detailed service procedures.

- 1. Keep a record of the number of hours you operate your engine by regular observation of hour meter.
- 2. Check your record regularly to learn when your engine needs service.
- DO ALL the services within an interval section.
 Write the number of hours (from your service records) and the date in the spaces provided. For a

complete listing of all items to be performed and the service intervals required, refer to the quick-reference chart near the front of the Lubrication and Maintenance Section.

IMPORTANT: The service recommendations covered in this manual are for the accessories that are provided by John Deere. Follow manufacturer's service recommendations for servicing engine driven equipment

not supplied by Deere.

RG,RG34710,5620 -19-20MAY96-1/1

Daily (Prestarting) Service

- Check engine oil level.
- · Check coolant level.

IMPORTANT: Drain water by rotating drain valve on fuel/water separator bowl counterclockwise. Premature injection pump failure may occur if water is not drained daily.

- Check fuel filter/water separator bowl.
- Check air cleaner dust unloader valve and air restriction indicator, if equipped.
- Visual walkaround inspection.

RG,RG34710,5621 -19-07JAN02-1/1

250 Hour/6 Month Service

- Change engine oil and filter.1
- Service fire extinguisher.

- Service battery.
- Check automatic belt tensioner and belt wear.

¹If John Deere PLUS-50 oil is used along with a John Deere oil filter, the oil and filter change interval may be extended by 50 percent to every 375 hours.

RG,RG34710,5623 -19-07JAN02-1/1

500 Hour/12 Month Service

- Clean crankcase vent tube.
- Check air intake hoses, connections, and system.
- Replace fuel filter element.
- Check automatic belt tensioner and belt wear.
- Check engine electrical ground connection.
- Check cooling system.
- Coolant solution analysis add SCAs as needed.
- Pressure test cooling system.

Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					

RG,RG34710,5624 -19-07JAN02-1/1

2000 Hour/24 Month Service

- Check crankshaft vibration damper (6-cylinder only).
- Flush cooling system.¹

- Test thermostats.
- Check and adjust valve clearance.

Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					

¹If John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours, or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished as needed by adding a supplemental coolant additive, the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

RG,RG34710,5625 -19-20MAY96-1/1

Service as Required

- Add coolant
- Service air cleaner.
- Replace poly-vee belts.
- Check fuses
- Bleed fuel system

Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					
Hours					
Date					

RG,RG34710,5627 -19-07JAN02-1/1

Emission System Warranty

U.S. EPA Emissions Control Warranty Statement

Emissions control-related parts and components are warranted by John Deere for five years or 3000 hours of operation, whichever occurs first. John Deere further warrants that the engine covered by this warranty was designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards at the time of manufacture, and that it is free of defects in materials and workmanship which would cause it not to meet these standards within the period of five years or 3000 hours of operation, whichever occurs first.

Warranties stated in this manual refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately as the "John Deere New Off-Highway Engine Warranty".

RG,RG34710,7629 -19-30JUN97-1/1

Emissions Control System Certification Label



CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply to the user or dealer.

The emissions warranty described below applies only to those engines marketed by John Deere that have been certified by the United States Environmental Protection Agency (EPA) and/or California Air Resources Board (CARB); and used in the United States and Canada in non-road mobile (self-propelled or portable/transportable¹) equipment. The presence of an emissions label like the one shown signifies that the engine has been certified with the EPA and/or CARB. The EPA and CARB warranties only apply to new engines having the certification label affixed to the engine and sold as stated above in the geographic areas. The presence of an EU number in the third line of the label signifies that the engine has been certified with the European Union countries per Directive 97/68/EC. The emissions warranty does not apply to the EU countries.

NOTE: The hp/kW rating on the engine emissions certification label specifies the gross engine hp/kW, which is flywheel power without fan. In most applications this will not be the same rating as the advertised vehicle hp/kW rating.

IMPORTANT ENGINE INFORMATION

DEERE & COMPANY

- This engine is certified to run on Diesel Fuel. This engine conforms to 2001 Model Year US EPA and California regulations on heavy-duty non road diesel cycle engines.
- Exhaust Emission Control System: EM, TC Family No. YJDXL06.8015
- Engine Model: 6068TN052 Displacement: 6.8 L
- Valve Clearance: Intake 0.356 mm Exhaust: 0.457 mm
- Fuel Rate: 95.7 mm³/stroke @ 200 hp [149 kW] @ 2400 rpm
 Injection Timing: 16.2 °BTDC No Other Adjustments Required.

John Deere Engine Manufacturing

R503149 For Engine Service and Parts Call 1-800-JD ENGINE

-UN-170CT01

Emissions Label

¹Equipment moved at least once every 12 months.

DPSG,RG41165,133 -19-10JUL00-1/1

John Deere Service Literature Available

Technical Information

Technical information is available from John Deere. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number, serial number, and name of the product.

Available information includes:

- PARTS CATALOGS list service parts available for your machine with exploded view illustrations to help you identify the correct parts. It is also useful in assembling and disassembling.
- OPERATOR'S MANUALS providing safety, operating, maintenance, and service information. These manuals and safety signs on your machine may also be available in other languages.
- OPERATOR'S VIDEO TAPES showing highlights of safety, operating, maintenance, and service information.
 These tapes may be available in multiple languages and formats.
- TECHNICAL MANUALS outlining service information for your machine. Included are specifications, illustrated assembly and disassembly procedures, hydraulic oil flow diagrams, and wiring diagrams. Some products have separate manuals for repair and diagnostic information. Some components, such as engines, are available in separate component technical manuals
- FUNDAMENTAL MANUALS detailing basic information regardless of manufacturer:
 - Agricultural Primer series covers technology in farming and ranching, featuring subjects like computers, the Internet, and precision farming.
 - Farm Business Management series examines "real-world" problems and offers practical solutions in the areas of marketing, financing, equipment selection, and compliance.
 - Fundamentals of Services manuals show you how to repair and maintain off-road equipment.
 - Fundamentals of Machine Operation manuals explain machine capacities and adjustments, how to improve machine performance, and how to eliminate unnecessary field operations.



Parts Catalogs



Operator Manuals



Component Technical Manuals



Fundamental Manuals

6MAR98

-UN-16MAR98

-UN-16MAR98

TS1663 -UN-100CT97

DPSG,RG41165,134 -19-10JUL00-1/1

Publications for this Engine

Technical information is available from John Deere in support of our products. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number, and name of the product.

Title	Order Number				
POWERTECH 4.5 L and 6.8 L OEM Diesel Engines (English):					
Operation and Maintenance Manual	OMRG25204				
Parts Catalogs POWERTECH 4.5 L POWERTECH 6.8 L	PC2521 PC2522				
Component Technical Manuals: Base Engine Mechanical Fuel Systems	CTM104 CTM207				
OEM Engine Accessories	CTM67				
Alternators and Starter Motors	CTM77				

DPSG,RG34710,105 -19-04OCT99-1/1

John Deere Service Literature Available

Index

Page	Page
A Acid burns	Flush
Ammeter	Damper, checking.40-3Diesel engine oil.10-9Diesel fuel.10-1Storage.10-5Dieselscan fuel analysis.10-5
В	
Batteries Charge/Boost	Emissions
С	Warming
Chart, service interval	Engine mounts 30-4 Checking. 30-4 Engine oil 10-8 Change. 30-2 Diesel 10-9 Engine speed, changing 15-15
Supplemental additives	Fan belts 45-8 Filter, replace 35-3 Oil 30-2 Fire extinguisher, service 30-1

Index


Page	Page
Fuel Bio-Diesel 10-3 Diesel 10-1 Dieselscan Analysis 10-5 Storage 10-5 Final filter	Lubrication and Maintenance Service Interval Chart
Fuel filter Checking	Maintenance interval chart Generator (Standby) applications
Filling	Metric torque values
G	
Gauge panel	Oil 10-11 Analysis 10-11 Dipstick 25-1 Fill quantity 60-8 Filler locations 25-1 Oil filter, change 30-2
H Hand throttle	Oil pressure gauge .15-2, 15-4 Operating engine
Idling engine.15-15Inch torque values60-12Instrument panels15-2, 15-4	Poly-vee belts Replace
K	Power ratings 60-3
Key switch	R
L Lubricants Mixing	Radiator cap testing

Index-2

Index

Page	Page
s	Vibration damper
Serial number 01-1 Engine 01-5 Service 01-5 Battery 30-5 Fire extinguisher 30-1 Intervals 20-2, 20-4 Service literature 75-2 Specifications 30-5 Belt tensioner 35-4 Damper 40-3 Engine crankcase oil fill 60-8 Fuel injection pump 60-3 4.5 L 60-1 6.8 L 60-2 Standby power units 15-9 Starting engine 15-10 Stopping engine 15-16	Warming engine
Storage Guidelines	
Temperature gauge (coolant) .15-2, 15-4 Tensioner, belt	
Metric	

Index-3



Index-4 020102