



MAGNAMAXDVR[®] GENERATOR

INSTALLATION OPERATION, AND MAINTENANCE MANUAL

TABLE OF CONTENTS

TABLE OF CONTENTS	2
SAFETY	6
GENERAL INFORMATION	7
MECHANICAL DESIGN	7
General	7
Conduit Box	7
MagnaMAX ^{DVR} Unirotor TM Construction	7
Adapters and Drive Discs	7
ELECTRICAL DESIGN	8
Temperature Rise	8
Standby Generator Ratings	8
Premium Insulation System	8
Power Factor	8
MagnaMAX ^{DVR} Voltage Regulator	8
HOW TO READ A MODEL NUMBER	9
INSTALLATION	10
RECEIVING YOUR MAGNAMAX^{DVR} GENERATOR	10
UNPACKING AND HANDLING	10
STORAGE	10
PREPARATION FOR USE	10
GENERATOR MOUNTING - SINGLE BEARING	11
GENERATOR MOUNTING-TWO BEARING	11
BELT DRIVE	11
ENVIRONMENTAL CONCERNS	11
ELECTRICAL CONNECTIONS	12
GENERATOR LEAD CONNECTIONS	12
12 LEAD HIGH WYE CONNECTION	13
12 LEAD LOW WYE CONNECTION	13
12 LEAD HIGH DELTA CONNECTION	14
12 LEAD LOW DELTA CONNECTION	14
10 LEAD HIGH WYE CONNECTION	15
10 LEAD LOW WYE CONNECTION	15
6 LEAD WYE CONNECTION	16
6 LEAD DELTA CONNECTION	16
3 LEAD DELTA CONNECTION	17
4 LEAD WYE CONNECTION	17

DOUBLE DELTA -- SINGLE PHASE CONNECTION	18
LOW ZIG ZAG -- SINGLE PHASE CONNECTION	18
HIGH ZIG ZAG -- SINGLE PHASE CONNECTION	18
<i>PARALLELING OPERATIONS</i>	19
PRIME MOVER.....	19
VOLTAGE REGULATOR.....	19
SWITCHGEAR.....	19
PARALLELING BASICS.....	19
REACTIVE LOAD CONTROL.....	20
PARALLELING CIRCUITRY	20
<i>THYRISTOR OR SCR LOADING</i>	21
<i>OPERATION</i>	21
PRE-START INSPECTION	21
STARTING-UP THE GENERATOR.....	22
FIELD FLASHING	22
VOLTAGE ADJUSTMENTS.....	22
OTHER ADJUSTMENTS	23
<i>MAINTENANCE</i>	23
GENERAL INFORMATION	23
AIR INTAKE AND EXHAUST.....	23
ELECTRICAL CONNECTIONS, WINDINGS	24
LUBRICATION	24
DRYING ELECTRICAL INSULATION.....	26
Space Heaters.....	26
Oven.....	26
Forced Air	26
"Short Circuit" Method.....	26
CLEANING METHODS.....	27
Solvents.....	27
Cloth and Compressed Air	27
Brushing and Vacuum Cleaning	27
Shell Blasting.....	27
Steam Cleaning	27
<i>DISASSEMBLY</i>	28
REMOVAL FROM PRIME MOVER.....	28
CONDUIT BOX REMOVAL	29
EXCITER STATOR (FIELD) REMOVAL	30
EXCITER ARMATURE (ROTOR) REMOVAL.....	30

PMG STATOR REMOVAL	31
MAIN ROTOR REMOVAL	33
FRONT END BRACKET REMOVAL.....	35
<i>EXCITER INSPECTION</i>	35
EXCITER STATOR.....	35
EXCITER (ROTOR) ARMATURE.....	36
<i>PMG INSPECTION</i>	37
PMG STATOR.....	37
PMG ROTOR	37
<i>MAIN ROTOR INSPECTION</i>	37
BEARING.....	37
FAN	38
MAIN ROTOR CORE AND WINDINGS.....	40
DRIVE DISCS (SINGLE BEARING GENERATORS ONLY).....	40
<i>FRONT (EXCITER) END BRACKET INSPECTION</i>	40
<i>DRIVE END BRACKET OR SAE ADAPTER INSPECTION</i>	41
<i>MAIN STATOR INSPECTION</i>	42
<i>FRONT END BRACKET INSTALLATION</i>	42
<i>MAIN ROTOR INSTALLATION</i>	42
<i>PMG INSTALLATION</i>	45
<i>EXCITER INSTALLATION</i>	46
<i>CONDUIT BOX INSTALLATION</i>	47
<i>ASSEMBLY TO PRIME MOVER</i>	48
<i>TROUBLESHOOTING</i>	50
INTRODUCTION.....	50
SYMPTOM:	51
NO VOLTAGE OR RESIDUAL VOLTAGE.....	51
LOW VOLTAGE -	52
NO LOAD	52
LOW VOLTAGE WHEN LOAD IS APPLIED	53
HIGH VOLTAGE	53
VOLTAGE IS FLUCTUATING	54
OPERATES SATISFACTORILY WHEN COLD, BUT SHUTS DOWN WHEN WARM	54
BUILDS VOLTAGE FROM STARTUP, THEN GOES TO LOW (RESIDUAL) VOLTAGE.....	54
EQUIPMENT RUNS NORMALLY ON UTILITY POWER, BUT WILL NOT RUN ON GENERATOR SET	54
<i>GENERATOR TESTING</i>	55
VISUAL INSPECTION.....	55

CONSTANT EXCITATION (12V BATTERY) TEST.....	55
MEASURING VOLTAGES.....	56
Generator Output Voltage	57
Regulator Output (Exciter Stator Input)	57
Regulator Sensing.....	57
Regulator Input Volts (PMG Output Volts)	57
CURRENT (AMP) MEASUREMENTS.....	57
MEASURING RESISTANCE	58
Main Stator	58
Exciter Rotor.....	58
TESTING DIODES (RECTIFIERS)	58
INSULATION RESISTANCE - MAIN STATOR.....	59
GENERATOR TESTING.....	59
INSULATION RESISTANCE - MAIN ROTOR.....	59
INSULATION RESISTANCE - EXCITER STATOR.....	60
INSULATION RESISTANCE - EXCITER ROTOR.....	60
MAIN ROTOR FIELD AC IMPEDANCE TEST	60
MAGNAMAX EXPLODED VIEW	61
STANDARD TOOLS.....	65
SPECIAL TOOLS	65
MISCELLANEOUS	66
PREPARATION FOR SHIPMENT OR <u>EXTENDED STORAGE</u>	66
SHIPPING INSTRUCTIONS.....	66
STORAGE INSTRUCTIONS.....	66
TABLE 12-1: MAGNA MAX - FASTENER AND TORQUE SPECIFICATIONS	68
TABLE 12-2: CAPSCREW TORQUE VALUES.....	69
TABLE 12-3:EXCITATION DATA -60 HZ - 1800 RPM	70
TABLE 12-4:EXCITATION DATA -50 HZ - 1500 RPM	71
TABLE 12-5: RESISTANCE VALUES - MAIN WINDINGS.....	72
TABLE 12-6: RESISTANCE VALUES - EXCITER WINDINGS.....	73

SAFETY

PLEASE REMEMBER SAFETY FIRST. If you are not sure of the instructions or procedures, seek qualified help before continuing.

This service manual emphasizes the safety precautions necessary during the installation, operation, and maintenance of your generator.

Each section has caution and warning messages. These messages are for your safety and the safety of the equipment involved. If any of the cautions or warnings is not readily understood, seek clarification from qualified personnel before proceeding.

Before any service work is done, disconnect all power sources and, where appropriate, lock out all controls, to prevent an unexpected start-up of the generator set. Proper grounding in compliance with local and national electrical codes must be provided. These safety precautions are necessary to prevent potential serious personal injury, or even death.

The hazards associated with lifting or moving the generator are pointed out in the installation and service sections; incorrect lifting or moving can result in personal injury or property damage.

Whenever the generator is running, always assume and proceed as if voltage is present. Residual voltage is present at the generator leads and at the regulator panel connections, even with the regulator fuse removed. Caution must be observed, or serious personal injury or death can result.

Whenever solvents, cleaners, or flammable liquids are present, adequate ventilation must be available to avoid fire, explosion, and health hazards. Always avoid breathing vapors and use suitable personal protective equipment to prevent personal injuries. (Such as eyes, face, and hand protection.)

This manual is not intended to be a substitute for properly trained personnel. Only qualified trained people should attempt repairs. The cautions and warnings point out known conditions that are potentially dangerous. Each installation will create its own set of circumstances. No manual can cover every possible situation.

When in doubt, ask. Don't be embarrassed to ask, "dumb questions". Remember that dumb questions are much easier to handle than dumb mistakes.

GENERAL INFORMATION

MECHANICAL DESIGN

General

All single and two bearing units are manufactured with cast iron end brackets and adapters, and fabricated steel frames. Flexible drive discs and SAE adapters are machined to SAE standards. Pre-lubricated, regreasable, shielded ball bearings are used on MagnaMAX^{DVR} generators. Standard units are fully guarded. Drip proof shields are available as an option.

Conduit Box

The large end mounted conduit box is constructed of formed sheet steel that will allow the addition of top mounted control packages. Refer to Katolight for top mounted controls of more than 240 lbs. There is ample room inside the conduit box for a circuit breaker (through 800A Frame) and other options. The conduit box cover properly directs outside ventilating air through the generator.

MagnaMAX^{DVR} Unirotor™ Construction

An aluminum die cast rotor core affords high mechanical integrity and low vibration at operating speeds. Amortisseur winding and coil supports are die cast as an integral part of the rotor. Laminations are 4-pole, one piece laminations which are shrunk fit and keyed to the shaft. No dovetails, cross bolts or other pole to shaft connecting devices are used. The cast unidirectional aluminum alloy ventilation fan provides even air distribution to maximize cooling and generator efficiency.

Adapters and Drive Discs

All single bearing units are available with several adapters and drive disc arrangements. These can be shipped to order or can be changed in the field with standard shop tools. When changing flexible drive discs, spacers are used between the discs and the cast iron hub to maintain SAE standard dimensions.

ELECTRICAL DESIGN

All standard products have 2/3 pitch main windings to eliminate the third harmonic. This serves to lower operating temperatures, give lower harmonic content and better waveform, and extend the overall life of the generator.

Temperature Rise

All ratings and frame sizes are based on NEMA and CSA Class F and Class H temperature rises on both the rotor and stator windings. Ratings for British, German, French, IEC and all popular marine agencies are available.

Standby Generator Ratings

Synchronous generators used on emergency backup power can have temperature rises up to 25°C above those for continuous operation. (NEMA MG1 -22.40 and MG 1-22.84).

Premium Insulation System

All MagnaMAX^{DVR} generators are built with Class H or better insulation materials. All standard generators are suitable for continuous duty at Class F temperature rise and will give equivalent or better winding life expectancy to generators supplied with Class A or B insulation systems operated within their temperature limits. The varnishes and epoxies used are synthetic, non-hygroscopic. Multiple dip and bake

cycles of the main winding, plus a final coat of epoxy, make the standard winding moisture and fungus resistant. The MagnaMAX^{DVR} rotor is wet wound with thermo-setting epoxy applied between each layer, plus a final coating of epoxy for moisture and abrasion resistance.

MagnaMAX^{DVR} generators can be ordered with an epoxy vacuum pressure impregnated insulation system as an option. (MagnaMAX^{DVR} generators with form wound coils include VPI as standard.)

Power Factor

All standard generators are designed for operation at rated kVA at 0.8 lagging power factor but can be operated at rated kVA over the 0.8 to 1.0 power factor range.

MagnaMAX^{DVR} Voltage Regulator

The standard voltage regulator is a fully encapsulated, static types with a solid state build up circuit. Standard features include 3-phase RMS sensing, paralleling, adjustable under frequency protection, and over excitation protection. The regulator meets EMI suppression to Mil Std-461C, part 9. An optional feature is adjustable armature current limiting. See the regulator manual for more information.

HOW TO READ A MODEL NUMBER

It is extremely important to properly identify the machine when requesting parts or service. Always have the generator model number and serial number when requesting information from the factory. We cannot help you without this information.

An Example For MagnaMAX^{DVR} Generators **431RSL 4009**

Character	Category	Description
1 st three characters	Frame Number	
4 th character	Winding type	R—Random Wound F—Form Wound
5 th character	Bearing arrangement	S—1 Bearing D—2 Bearings
6 th character	Voltage range	L—Up to 480 volts M—1000-6600 volts S—600 volts
7 th Character	Product style	4-Magna
8 th Character	Type	
9 th & 10 th Character	Wk2 Code	
11 th Character	Modification	A-Z assigned sequentially
12 th Character	Mounting Arrangement	A-Y see chart figure 2-1
13 th , 14 th & 15 th characters	Modification numbers	For internal use only

Arrangement	Adapter SAE Size	Drive Disc SAE Size
A	3	11-1/2
B	2	11-1/2
C	4	8
D	3	10
E	1	11-1/2
F	1	14
G	4	7-1/2
H	1	Delco
J	1/2	14
K	2	10
L	1/2	Delco
M	0	14
N	2	Small Delco
O	None	None
P	0	18
S	0	Delco
U	00	18
V	4	6-1/2
W	00	21
Y	4	10

Figure 2-1

INSTALLATION

RECEIVING YOUR MAGNAMAX^{DVR} GENERATOR

Upon receipt of the generator, it is recommended that it be carefully examined for possible damage incurred in shipment. The generator was given to the Freight Company in good condition, and they are responsible for the product from our dock to yours. Any damage should be noted on the freight bill before accepting the shipment. Claims for damages must be promptly filed with the Freight Company.

UNPACKING AND HANDLING

Read all instruction cards carefully. When lifting, attach an overhead crane to the lifting lugs on the generator frame. Apply lifting forces in a vertical direction.

WARNING
THE LIFTING LUGS ON THE
GENERATOR ARE DESIGNED TO
SUPPORT THE GENERATOR ONLY.
DO NOT LIFT COMPLETE
GENERATOR SET BY MEANS OF
LIFTING DEVICES ON THE
GENERATOR. PERSONAL INJURY
OR EQUIPMENT DAMAGE MAY
OCCUR.

STORAGE

In the event that the generator is not to be installed on the prime mover immediately, it is recommended that it be stored in a clean, dry area that is not subject to rapid changes in temperature and humidity. See "STORAGE INSTRUCTIONS" for more information.

PREPARATION FOR USE

Although the generator is carefully inspected and tested in operation before it leaves the factory, it is recommended the unit be thoroughly inspected. The insulation on the wire should be inspected and all bolts should be checked for tightness.

Remove all shipping tapes, bags, blocks, and skids, which are used to prevent vibration and rotor movement during shipment. Dry, low-pressure compressed air of approximately 30 PSI (206 KPA) can be used to blow out the interior of the generator. In the case of two bearing machines, it is possible to turn the rotor by hand to make sure that it rotates smoothly without binding.

If the machine has been in storage for a year or longer it is recommended that it be lubricated according to the lubrication instructions and chart supplied in the maintenance section.

If the machine has been exposed to damp, humid conditions the insulation resistance should be checked. Refer to the instructions supplied in this manual.

GENERATOR MOUNTING - SINGLE BEARING

Single bearing generators are provided with an SAE flywheel adapter and flexible drive discs. Very close tolerances are maintained in the manufacture of the generator so that the alignment procedure is extremely simple. A coupling hub of nodular iron is shrunk on the shaft and special steel drive discs are bolted to the hub. Holes are provided in the periphery of the coupling disc, which correspond to tapped holes in the flywheel. The outside diameter of the discs fits in a rabbet in the flywheel so that concentricity is assured in all cases.

WARNING

DO NOT APPLY ANY FORCE TO THE GENERATOR FAN FOR LIFTING OR FOR ROTATING THE GENERATOR ROTOR. DISREGARDING THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE

CAUTION: GRADE 8 CAPSCREWS OR GRADE 8 FLANGE BOLTS AND HARDENED WASHERS ARE RECOMMENDED TO MOUNT THE DRIVE DISCS TO THE FLYWHEEL. DO NOT USE HELICAL OR OTHER LOCKING DEVICES UNLESS APPROVED.

The SAE adapter and the flywheel housing are designed to match each other with no further alignment necessary. Shims may be necessary under the feet of the generator to insure a solid mounting. See THE SERVICE SECTION for more information.

GENERATOR MOUNTING-TWO BEARING

Two bearing generators are provided with a shaft extension and key way. For direct-coupled sets the assembler furnishes a flexible coupling which is installed between the driver and the generator shaft.

IMPORTANT: Aligning the two machines as accurately as possible will reduce vibration, increase bearing life, and insure minimum coupling wear. It may be necessary to shim the generator feet for proper support and alignment. Consult the coupling manufacturer's instructions for alignment specifications and procedures.

BELT DRIVE

Please refer to Katolight for applications involving belt driven installations.

ENVIRONMENTAL CONCERNS

Dirt, moisture, heat, and vibration are enemies of electrical equipment. The ambient temperature should not exceed the value shown on the generator nameplate. Generators for outdoor application should be protected from the elements by housings with proper openings for ventilation. This protection should be designed to prevent the direct contact of wind driven rain, snow, or dust with the generator. In moist or humid areas, such as the Tropics and marine service, additional protection is recommended. Although the standard windings are humidity and moisture resistant, special insulation and accessories such as space heaters can increase generator life. In extremely dirty and dusty environments a means of providing filtered cooling air to the generator is recommended. Please refer to Katolight for filter kits that are available.

ELECTRICAL CONNECTIONS

The generator conduit box construction allows conduit to enter the top, bottom, or either side of the box. A hole-saw or any suitable tool can be used to provide for the conduit entrance. Protect the interior of the generator from shavings when drilling or sawing. An approved connector must be used in conjunction with the conduit.

To minimize the transmission of vibration, it is essential that flexible conduit be used for all electrical cable entrance to the generator.

Refer to the connection diagram supplied with the generator and / or the proper diagrams shown in this section. Install all intercomponent and external wiring in accordance with the regulations of the national and local electrical codes. Clean all contact surfaces to assure good electrical bonding with the generator lugs or bus bars. Use heavy-duty terminal lugs or good quality clamps for making all connections. Insulate all connections in accordance with national and local regulations.

Be sure the generator frame is grounded to all the other components of the system with a ground wire in accordance with national and local regulations.


GENERATOR LEAD CONNECTIONS

The electrical connections in the conduit box should be made in accordance with the appropriate "connection diagram." Use the diagram appropriate for the number of leads and voltage range required. Refer to the drawings supplied with the generator and to drawings in this section.

The final voltage setting is established within the selected range by an adjustment of the voltage regulator.


CAUTION: SOME GENERATORS HAVE MULTIPLE, IDENTICALLY MARKED, CABLES FOR EACH LEAD. CONNECT ALL IDENTICALLY MARKED CABLES TOGETHER WHEN MAKING CONNECTIONS.

12 LEAD HIGH WYE CONNECTION




VOLTAGE		
	L-L	L-N
60 HZ	480	277
	460	266
	440	254
	416	240
	380	219
50 HZ	416	240
	400	231
	380	219

12 LEAD LOW WYE CONNECTION




VOLTAGE		
	L-L	L-N
60 HZ	240	139
	230	133
	220	127
	208	120
	190	110
50 HZ	208	120
	200	115
	190	110

12 LEAD HIGH DELTA CONNECTION




VOLTAGE		
	L-L	L-N
60 H Z	240 277	120 139
50 H Z	200 220 240	100 110 220

12 LEAD LOW DELTA CONNECTION




VOLTAGE		
	L-L	L-N
60 H Z	120 139	N A
50 H Z	100 120	N A

10 LEAD HIGH WYE CONNECTION




VOLTAGE		
	L-L	L-N
60 H Z	480	277
	460	266
	440	254
	416	240
	380	219
50 H Z	416	240
	400	231
	380	219

10 LEAD LOW WYE CONNECTION




VOLTAGE		
	L-L	L-N
60 H Z	240	139
	230	133
	220	127
	208	120
	190	110
50 H Z	208	120
	200	115
	190	110

6 LEAD WYE CONNECTION




VOLTAGE		
	L-L	L-N
60 HZ	13800	7967
	6600	3811
	4160	2400
	3300	1905
	240	139
	230	1363
	220	127
	203	120
	190	110
50 HZ	11000	6351
	6600	3811
	3300	1905
	208	120
	200	115
	190	110

6 LEAD DELTA CONNECTION




VOLTAGE		
	L-L	L-N
60 HZ	7967	N A
	2400	
50 HZ	6351	N A
	1905	

3 LEAD DELTA CONNECTION




	VOLTAGE	
	L-L	L-N
60 HZ	7967	NA
	2402	NA
50 HZ	6351	NA
	1905	NA

4 LEAD WYE CONNECTION




	VOLTAGE	
	L-L	L-N
60 HZ	13800	7967
	6600	3811
	4160	2400
	3300	1905
	2400	1386
	600	346
	480	277
	380	219
50 HZ	11000	6351
	6600	3811
	3300	1905
	416	240
	400	231
	380	219

DOUBLE DELTA -- SINGLE PHASE CONNECTION




V O L T A G E		
	L - L	L - N
6 0	2 4 0	1 2 0
H Z	2 2 0	1 1 0
	2 0 0	1 0 0
5 0	2 2 0	1 1 0
H Z	2 0 0	1 0 0

LOW ZIG ZAG -- SINGLE PHASE CONNECTION



V O L T A G E		
	L - L	L - N
6 0	2 4 0	1 2 0
H Z	2 2 0	1 1 0
	2 0 0	1 0 0
5 0	2 2 0	1 1 0
H Z	2 0 0	1 0 0

HIGH ZIG ZAG -- SINGLE PHASE CONNECTION



V O L T A G E		
H Z	L - L	L - N
6 0	4 8 0	2 4 0
	4 4 0	2 2 0
5 0	4 4 0	2 2 0
	4 0 0	2 0 0

PARALLELING OPERATIONS

MagnaMAX^{DVR} generators come standard with amortisseur windings die cast as an integral part of the rotor. This exclusive, UnirotorTM, construction makes all MagnaMAX^{DVR} generators suitable for paralleling operations when the proper control equipment is added. Paralleling with other generator sets and / or with the utility power grid offers a number of advantages. Multiple unit installations increase power capacity; they can be added or removed from the line depending on the load requirements; they can be better maintained and repaired (since single source breakdown would mean total loss of power), and they often provide more reliable, efficient, and economical operation.

Successful parallel operation means that the generator's deliver power to the external system without delivering power to each other, or accepting power from the load bus or power grid. Additional equipment is necessary to insure safe and successful operation.

PRIME MOVER

The prime mover provides the speed and torque which will be necessary to keep the machines in synchronized operation. A governor controls the prime mover's speed. The governor will directly control the watt or kW output and frequency of the unit. The governor must have special paralleling provisions to permit parallel operation with the other machines.

VOLTAGE REGULATOR

The voltage regulator controls the generator output voltage and the reactive power supplied by the generator. When two or more ac

generators operate in parallel, the voltage regulator must have paralleling provisions (either internally or external to the regulator) to control the reactive or VAR load while it is in parallel operation. A separate paralleling current transformer is required to sense the reactive current and signal the voltage regulator. This additional paralleling circuitry is absolutely necessary to control the reactive current flowing between the generator sets.

SWITCHGEAR

There are additional relays and breaker controls that are necessary to insure safe, trouble free operation of paralleled units. Reverse power relays monitor the direction of power flow to insure that the generator is delivering power, not accepting it. These power relays control breakers, which are a means of connecting and disconnecting the generator from the load. The total system can include over-voltage, over-current protection, under frequency protection, power factor correction provision and a variety of associated control equipment from manual switchgear to microprocessors. The amount of control gear and level of sophistication will be determined by the needs and requirements of the particular application.

PARALLELING BASICS

The following points are basic criteria which must be met before two units can be paralleled. **THIS IS NOT MEANT TO BE SPECIFIC INSTRUCTIONS FOR PARALLELING OPERATION.**

1. Additional paralleling circuitry
 - A. Voltage regulator-paralleling provisions
 - B. Paralleling current transformer(s)
 - C. Paralleling provisions on governor controls
 - D. Switchgear
2. The voltage and frequency must be the same for all sets with voltages in phase.

3. The voltage regulation characteristics of the individual generators should be similar.

4. The generators must have the same phase rotation.

5. The driving engines should have the same speed regulation characteristics and the governors should be adjusted to give the same speed regulation.

Before operating generator sets in parallel, each set should be checked by starting, operating, and adjusting the sets as individual units before attempting paralleling.

REACTIVE LOAD CONTROL

When two identical generators are operating together in parallel and an unbalance occurs in field excitation, circulating currents begin to flow between the generators. This current will appear as a lagging power factor or inductive load to the highly excited generator, and as a leading power factor or capacitive load to the generator with the lower field current. This is known as the reactive circulating current and there are two methods of controlling it in parallel operation:

1. Reactive droop compensation. (Formerly known as parallel droop compensation.)

The bus voltage droops, or decreases, as the reactive lagging power factor load is increased.

2. Reactive differential compensation.

(Formerly known as cross current compensation.) The reactive differential compensation circuit allows parallel generators to share reactive loads with no decrease or droop in generator voltage.

The circuit must meet the following criteria:

A. All paralleling current transformers for all the generators being paralleled must be included in the secondary interconnection loop.

B. When different size generators are paralleled all paralleling current transformers must have the same proportional ratios that give approximately the same secondary current.

C. Voltage regulator paralleling circuitry must be the same.

D. Current transformer secondary and the generator lines must be isolated electrically.

E. It is also desirable to have an auxiliary contact on the main generator breaker to short the parallel CT secondary when that breaker is open (not connected to the load bus).

Because of the above criteria, reactive differential compensation cannot be used when paralleling with the utility power grid. There is no limit, however, in the number of generators that can be included in this type of circuit.

PARALLELING CIRCUITRY

Because of the number of variables involved in paralleling generator sets, every installation will have its own circuitry and methods or procedure of bringing paralleled units on line. There are numerous ways of connecting paralleled units and an almost unlimited variety of applications and associated equipment.

When parallel operation is desired, it is important that the control manufacturer, the generator manufacturer, and the systems engineer work together to insure the proper selection of all components. Please refer to Katolight for application assistance.

THYRISTOR OR SCR LOADING

Solid state electronic control devices which utilize thyristors or SCR firing circuits (such as variable frequency induction motor controls, precision motor speed controls, no-break powered battery chargers, etc.) can introduce high frequency harmonics which adversely affect or destroy the normal waveform of the generator. This creates additional heat in the generator stator and rotor, and can cause overheating. These devices can and do present problems to non-utility power generating equipment or any limited power bus system. The problems that can occur are not limited to the generator itself, but can effect the solid state control device, the equipment it controls, other associated loads, monitoring devices or a number of combinations over the entire system.

MagnaMAX^{DVR} generators can supply power to thyristor or SCR loads when properly applied. The standard voltage regulator is PMG powered and senses 3 phase RMS voltages for maximum stability against severely distorted waveforms. SCR type applications such as cranes, shovels, etc., require special consideration of the generator insulation system due to greater dielectric stress and severe environmental conditions. It is important that the control manufacturer, the generator manufacturer, and the systems engineer work together to insure the proper selection of all components. Please refer to Katolight for application assistance.

OPERATION

PRE-START INSPECTION

Before operating the generator for the first time, the following checks are recommended.

1. A visual inspection should be made to check for any loose parts, connections, or foreign materials
2. Check for clearance in the generator and exciter air gap. Be sure the generator set turns over freely. Bar the generator over by hand at least 2 revolutions to be sure there is no interference.

WARNING

DO NOT APPLY ANY FORCE TO THE GENERATOR FAN FOR LIFTING OR FOR ROTATING THE GENERATOR ROTOR. DISREGARDING THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE

3. Check all wiring against the proper connection diagrams and make sure all connections are properly insulated. Support and tie leads to keep them from being damaged by rotating parts or by chafing on sharp corners.
4. Be sure the equipment is properly grounded.
5. Inspect for any remaining packing materials and remove any loose debris, building materials, rags, etc. that could be drawn into the generator.
6. Check fasteners for tightness.
7. Check to be sure no tools or other hardware have been left inside or near the machine.
8. Install and check to be sure all covers and guards are in place and secure.

WARNING

RESIDUAL VOLTAGE IS PRESENT AT THE GENERATOR LEADS AND AT THE REGULATOR PANEL CONNECTIONS EVEN WITH THE REGULATOR FUSE REMOVED. CAUTION MUST BE OBSERVED OR SERIOUS PERSONAL INJURY OR DEATH CAN RESULT.

STARTING-UP THE GENERATOR

The following procedure should be followed for starting-up the generator for the first time:

1. The generator output must be disconnected from the load. Be certain that the main circuit breaker is open.
2. Disable the voltage regulator by removing the fuse.

WARNING
DO NOT OVERSPEED THE
GENERATOR. EXCESSIVE
CENTRIFUGAL FORCES COULD
DAMAGE THE ROTATING FIELDS. BE
PREPARED FOR AN EMERGENCY
SHUTDOWN.

3. Follow the manufacturer's instructions and start the prime mover. Check the speed and adjust to the RPM shown on the generator nameplate.
4. Replace the regulator fuse and adjust the voltage to the required. Check all line to line and line to neutral voltages to be sure they are correct and balanced. If the voltages are not correct shut down immediately and recheck all connections.
5. Close the main circuit breaker and apply the load.
6. Monitor the generator output current to verify it is at or below nameplate amps.
7. Adjust engine speed at full load to 1800 rpm for 60 hertz, 1500 rpm for 50 hertz. (Refer to prime mover/governor instruction manuals.)
8. Before stopping the engine, remove the load by tripping the main circuit breaker.

FIELD FLASHING

The standard MagnaMAX^{DVR} generator is supplied with a PMG (permanent magnet generator). **It will never require field flashing.** In rare cases where a special generator may be furnished without a PMG, refer to the factory for more detailed information. Include the complete generator model and serial number.

VOLTAGE ADJUSTMENTS

The voltage regulator controls the generator output voltage. There is a cover to access the control panel on the side of the generator conduit box




Figure 4-1




Figure 4-2 Regulator Access

Refer to the regulator manual for detailed information. In cases where special or remote mounted regulators are used, refer to instructions supplied by the generator set assembler and to the voltage regulator manual.

OTHER ADJUSTMENTS

Depending upon application, adjustments to other protective and control gear may be required. Refer to instructions provided by the by the supplier of the generator set.

The standard MagnaMAX^{DVR} voltage regulator also has many protective and control circuits.

It is imperative that the set up instructions for any regulator supplied be followed.

MAINTENANCE

GENERAL INFORMATION

Dirt, heat, moisture, and vibration are common enemies of a generator. Keeping the generator clean and dry, maintaining proper alignment of the generator and its prime mover, and preventing overloads will result in efficient operation and long life.

Generators that are outdoors should be protected from the elements by suitable houses or enclosures.

Dirt and dust will conduct electricity between points of different electrical potential. Moisture will aggravate the problem further. Insulation system failure can result if corrective action is not taken. Measuring insulation resistance can test the condition of the insulation system.
(See Generator Testing.).

Insulation resistance should be checked when putting the generator into service after it has been in storage and anytime contamination by moisture and dirt is suspected.

Normally, moisture buildup is not a problem while the generator is running, since heat

produced internally will tend to keep it dry but can collect in the generator when it is shut down. The problem will be worse in humid environments or in areas where extreme temperature changes cause condensation (dew) to form inside the generator.

Space heaters, air filters, and premium insulation systems, such as our VPI process, should be considered in difficult environments.

Accumulations of dust and dirt not only contribute to insulation breakdown, but they can also increase temperature by restricting the dissipation of heat. Materials such as talc, lint, rock dust, or cement dust may obstruct the ventilation.

The most harmful types of foreign materials include carbon black, metallic dust and similar substances that not only impede ventilation, but also form a conductive film over the insulation, increasing the possibility of insulation failure.

Machines operating in dirty places should be disassembled and cleaned periodically.

AIR INTAKE AND EXHAUST

Check the area around the air intake and exhaust openings to be sure they are unobstructed.




Figure 5-1

ELECTRICAL CONNECTIONS, WINDINGS

Inspect for loose or contaminated connections. Check wires for cracked or frayed insulation. Tighten connections and replace defective or oil soaked insulation.

If inspection shows that varnish coatings on the windings have deteriorated, they should be coated with insulating varnish.

Please refer to Katolight for insulation system requirements.

LUBRICATION

All generators are lubricated before leaving the factory and are ready for operation. As a general rule, bearings should be re-lubricated annually or at the indicated intervals in table 5-3, whichever occur first.

Unusually severe operating conditions, such as high ambient or dusty environments, require more frequent lubrication (every six months or one half the table intervals, whichever occurs first).

Use Chevron SRI or equivalent anti-friction type high quality, grease with a lubrication temperature range of -22° to +350° F (-30° to +175° C)

To add or renew grease, proceed as follows:

1. Stop unit.
2. Wipe the grease plugs and surrounding parts to insure they are clean.
3. Remove both the fill and drain plugs. See figure 5-2
4. Insert 1/8" N.P.T. grease fitting in fill pipe.
5. Free the drain holes of any hard grease, using a piece of wire if necessary.
6. Using a low-pressure grease gun, add grease according to the amounts in table 5-3.
7. Start unit with drain plug removed - fill pipe may be open or closed. Allow unit to run 15 minutes to allow excess grease to drain.
8. Stop unit, wipe off any drained grease, and replace filler and drain plugs.




Figure 5-2

The amount of grease added is very important! Only enough grease should be added to replace the grease used by the bearing.

CAUTION: TOO MUCH GREASE CAN BE AS HARMFUL AS INSUFFICIENT GREASE. USE THE PROPER AMOUNT.

Type	Frame Size	Bearing Size	Amount of Grease			Intervals --- Max. hours or annually	
			Ounces	Cubic Inches	Teaspoons	60 Hz	50 Hz
Single Bearing Units	431, 432, 433	314	1.2	2.1	7.0	6500	8400
	571, 572, 573, 574	316	1.5	2.6	8.3	5600	7200
	741, 742, 743, 744	322	2.4	4.2	14.0	3000	4500
Double Bearing Units	431, 432	318	1.7	3.0	9.9	4600	6200
	571, 572, 573, 574	318	1.7	3.0	9.9	4600	6200
	741, 742, 743, 744	322	2.4	4.2	14.0	3000	4500

TABLE 5-3

During an overhaul, the grease reservoir should be thoroughly cleaned and new grease added. The reservoir should be 1/3 to 1/2 filled with new grease.

DRYING ELECTRICAL INSULATION

Electrical components must be dried before placing in operation if tests indicate that the insulation resistance is below a safe value. (See Generator testing for test procedure.)

Machines that have been idle for sometime in unheated and damp locations, may have absorbed moisture. Sudden changes in temperature can cause condensation or the generator may have become wet by accident. Windings should be dried out thoroughly before being put into service. The following are recommended drying methods.

Space Heaters

Electric space heaters can be installed inside of the generator. When energized (from a power source other than the generator) they will heat and dry the inside of the generator. If an alternate source of electricity is not available, enclose the generator with a covering and insert heating units to raise the temperature 15-18 degrees F (8-10 degrees C) above the temperature outside of the enclosure. Leave a hole at the top of the enclosure to permit the escape of moisture.

Oven

Place the machine in an oven and bake it at a temperature not to exceed 194 F (90°C). The voltage regulator and any electronic component accessories must be removed from the generator when using this method.

Forced Air

A portable forced air heater can be used by directing heat into the air intake (conduit box) and running the generator with no load and without excitation (this can be accomplished by removing the regulator fuse). Heat at point of entry should not exceed 150° F (66° C).

"Short Circuit" Method

Using this method can dry out the generator quickly and thoroughly.

WARNING:

BE SURE THAT ALL OF THE FOLLOWING STEPS ARE PERFORMED AND ALL PRECAUTIONS TAKEN AS PERSONAL INJURY OR SERIOUS DAMAGE TO THE GENERATOR COULD RESULT.

1. Disconnect exciter leads F1 and F2 from the regulator.
2. Connect a battery or other dc power source approximately 20-35 volts to the exciter lead F1 and F2. An adjustable voltage source desirable, however, a rheostat (rated approximately 2 amps) in series with the dc power source will work.
3. Short circuit the generator output lead wires to each other (L1 to L2 to L3). If using jumpers, be sure they are large enough to carry full load amps.
4. Start the generator and measure the current through the output leads with a clip-on ammeter.
5. Adjust the voltage source to produce approximately 80% of the rated ac nameplate current but in no case exceed nameplate amps. If a adjustable source is not available and current is excessive, use a lower dc source voltage or larger resistor in series with the source.

Running time will be determined by the amount of moisture present in the machine. Insulation resistance checks should be taken every one to four hours until a fairly constant value obtained. (See section -

Generator testing for instructions on measuring insulation resistance.)

6. After the generator is dry and the insulation resistance is brought up to specification remove the short circuit from the line lead disconnect the dc source and reconnect the F and F2 leads at the regulator. Be sure all connections are tight and correct before attempting to run the generator.

CLEANING METHODS

When electrical components get dirty, the insulation must be cleaned. There are a number of acceptable methods for cleaning the generator, each of which will necessitate disassembly of the unit. The kind of dirt, and when the unit must be returned to service will determine the method of cleaning. Drying after cleaning is necessary.

Whenever the generator is disassembled, the windings should be given a thorough inspection and the insulation cleaned, if necessary. The inspection should include the connection of the windings, insulation, and varnish coverage. Check the winding ties and coil supports. Look for any signs of coil movement or looseness and repair as required.

An electric motor repair shop in your area can normally assist with the proper cleaning of the generator windings. They may also be experienced in special problems (such as seacoast, marine, oilrig, mining, etc.) that may be peculiar to a certain area.

Solvents

A solvent is usually required to remove accumulated soil containing oil or grease. Only petroleum distillates should be used for cleaning electrical components. Petroleum solvents of the safety type with a flash point greater than 100° F (38° C) are

recommended. **CAUTION: A SOLVENT THAT DOES NOT ATTACK EPOXY OR POLYESTER BASED MATERIALS SHOULD BE USED.**

Apply the solvent with a soft brush or rag. Be careful not to damage the magnet wire or insulation on the windings. Dry components thoroughly with moisture-free, low pressure compressed air.

Cloth and Compressed Air

Cleaning with a dry cloth may be satisfactory when components are small, the surfaces are accessible and only dry dirt is removed. Blowing dirt out with compressed air is usually effective particularly when the dirt has collected in places that cannot be reached with a cloth. Use clean dry air at 30 PSI (206 KPA).

Brushing and Vacuum Cleaning

Dry dust and dirt may be removed by brushing with bristle brushes followed by vacuum cleaning. Do not use wire brushes. Vacuum cleaning is an effective and desirable method of removing dry and loose dirt.

Shell Blasting

Air blasting with ground nut shells may be satisfactory for removal of hard dirt deposits from insulation. Use mild abrasives such as 12-20 mesh ground walnut shells.

Steam Cleaning

If the generator is completely disassembled, including bearings and electronic components, steam cleaning of the major parts and windings is very effective. However, the machine must be thoroughly dried in an oven to remove all moisture before the generator can be put back into service.

DISASSEMBLY

REMOVAL FROM PRIME MOVER

BE SURE ALL POWER IS OFF BEFORE SERVICING. FAILURE TO FOLLOW ALL SAFETY INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH.

NOTE: Before disconnecting any electrical wiring, be sure it is marked and can be identified for reinstallation. Re-label as required.

1. Remove conduit box covers (Figure 6-1 and 6-2)




Figure 6-1




Figure 6-2

2. Disconnect all external wiring from the generator leads inside the conduit box.

3. Remove all conduits or ducting from the conduit box.

4. Attach a suitable hoist to the generator lifting

5. For single bearing generators, remove the bolts mounting the screen assembly to the SAE adapter and remove the screen. (Figure 6-3.)




Figure 6-3

(NOTE: Do not remove the drip cover from the screen assembly if so equipped.) Remove the cap screws attaching the drive discs to the flywheel and remove the cap screws attaching the SAE adapter to the flywheel housing.

For two-bearing generators, disconnect the coupling or sheave and belts between the generator and prime mover. (Follow the coupling manufacturer's instructions for direct connection.)

WARNING

DO NOT APPLY ANY FORCE TO THE GENERATOR FAN FOR LIFTING OR ROTATING THE GENERATOR

CONDUIT BOX REMOVAL

1. Note the location and markings (re-mark as required) and remove connections from voltage regulator (Figure 6-4), capacitor (Figure 6-5), and any other conduit box mounted controls.




Figure 6-4




Figure 6-5

2. On generators equipped with bus bars, mark all connections and disassemble main stator (power) leads from the generator side of the bus bars.

3. Remove bolts holding conduit box in place. (Figure 6-6.)



Figure 6-6

4. Remove conduit box. (Figure 6-7).




Figure 6-7

EXCITER STATOR (FIELD) REMOVAL

1. Disconnect F1 and F2 leads from the corresponding F1 and F2 terminals on the regulator.
2. Remove all cable ties so the F1 and F2 leads can be removed with the exciter stator. Remove the four cap screws and Belleville washers holding the exciter stator in place. (Figure 6-8.)




Figure 6-8

Remove the exciter stator. Using a lifting strap or fixture. (Figure 6-9.)




Figure 6-9

EXCITER ARMATURE (ROTOR) REMOVAL

1. Note markings and disconnect the main rotor leads coming out of the lead hole of the aluminum standoff plate from the rectifier aluminum angle. (Figure 6-10.)




Figure 6-10

2. Remove the cap screw and Belleville washer that holds the exciter (rotor) armature to the generator shaft. (Figure 6-11.)




Figure 6-11

3. Use a six inch, 3/4-16NF, cap screw for a puller (See section 9.) The hole that the mounting bolt goes through is threaded. Screw the pull bolt into the hole and it will push against the end of the shaft. (Figure 6-12.)




Figure 6-12

Carefully feed the main rotor leads through the hole as the exciter armature is removed. (Figure 6-13.)




Figure 6-13

CAUTION:
DO NOT TIGHTEN THE PULLER BOLT BEYOND THE END OF THE THREADS. IF A BOLT WITH SUFFICIENT THREAD LENGTH CANNOT BE FOUND, USE A PIECE OF THREADED ROD WITH A NUT WELDED ON THE END.

PMG STATOR REMOVAL

1. Remove exciter armature. (Follow instructions found earlier in this section.)
2. Remove the PMG output leads from the capacitor (Figure 6-14) and loosen all cable ties so the leads can be removed with the PMG stator.




Figure 6-14

3. Note the position of the PMG stator leads that exit at the left inboard side or mark the stator so it can be reinstalled in the same position.
4. Remove the four mounting cap screws. (See Figure 6-15.)




Figure 6-15

5. Carefully remove the PMG stator from its mounting pads and slide over the PMG rotor. The magnets used in the PMG are very strong and will resist removal of the PMG stator. (Figure 6-16.)




Figure 6-16

PMG ROTOR REMOVAL

1. Remove the exciter armature and PMG stator. (Follow instructions found earlier in this section.)
2. Remove the snap ring that holds the PMG rotor in place on the shaft. (Figure 6-17 and 6-18.)




Figure 6-17




Figure 6-18

3. Slide the PMG rotor off of the shaft. (Figure 6-19.)




Figure 6-19

4. Remove the loading spring. (if the loading spring is not on the shaft, check to see if it is stuck on the back of the PMG rotor.).
5. On 430 frame generators a second snap ring is used inboard of the PMG rotor. (Larger generators have a step on the shaft.)

This snap ring must be removed before the generator main rotor can be removed. (Figure 6-20.)




Figure 6-20

MAIN ROTOR REMOVAL

1. Remove the exciter armature and PMG.
2. For single bearing generators, remove the four cap screws holding the bearing caps to the front-end bracket. (Figure 6-21.) Remove the outer cap. (Figure 6-22.)

For two-bearing generators, remove the drive coupling or sheave and key from the shaft extension. Remove the four cap screws holding the bearing lock to the drive end bracket. (Figure 6-23.) Remove the four cap screws holding the bearing caps to the front-end bracket. (Figure 6-21.) Remove the outer cap. (Figure 6-22.)




Figure 6-21




Figure 6-22




Figure 6-23

3. If the screen assembly is still mounted, remove bolts securing the screen assembly to the drive end bracket or the SAE adapter and remove the screen assembly. (Figure 6-24.) (NOTE: Do not remove the drip cover from the screen assembly if so equipped.)




Figure 6-24

4. For single bearing generators, remove the cap screws and hardened washers holding the drive discs to the drive hub. (Figure 6-25.) Remove all drive discs (and spacers if any).




Figure 6-25

5. For single bearing generators, remove the cap screws holding the SAE adapter to the generator and remove the adapter. (Figure 6-26 and 6-27.)




Figure 6-26




Figure 6-27

CAUTION: ON LARGE GENERATORS, A HOIST AND LIFTING STRAP SHOULD BE USED TO ASSIST IN DRIVE END BRACKET OR SAE ADAPTOR REMOVAL

For two bearing generators remove the cap screws holding the drive end bracket to the generator and remove the bracket (Figures 6-26 and figure 6-28)




Figure 6-28

6. Using a rotor lifting fixture and a suitable hoist, carefully remove the rotor assembly from the main stator and frame assembly through the drive end. (Figure 6-29.)

CAUTION:
SPECIAL CARE SHOULD BE TAKEN WHEN REMOVING THE MAIN ROTOR, WINDING DAMAGE COULD RESULT IF THE ROTOR IS ALLOWED TO HIT THE MAIN STATOR.




Figure 6-29

WARNING
DO NOT APPLY ANY FORCE TO THE GENERATOR FAN FOR LIFTING OR ROTATING THE GENERATOR ROTOR. DISREGARDING THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE.

FRONT END BRACKET REMOVAL

1. Remove front bracket mounting screws. (Figure 6-30.)
2. Remove the front-end bracket from the main stator assembly. (Figure 6-31.)

CAUTION: ON LARGE GENERATORS, A HOIST AND LIFTING STRAP SHOULD BE USED TO ASSIST IN THE FRONT END BRACKET REMOVAL




Figure 6-30




Figure 6-31

EXCITER INSPECTION

EXCITER STATOR

1. Clean dust and dirt from the exciter stator winding. (Figure 6-32.) (See section 5.)




Figure 6-32

2. Check the exciter stator for a loose, frayed, or burnt winding. Measure winding resistance and insulation resistance. (See section 8.)

Repair or replace as necessary. If field repair of the winding is necessary, contact Katolight for special winding procedures and materials.

3. Look for score marks in the bore of the exciter core caused by rubbing. (This could indicate bearing or assembly problems and should be investigated.)

EXCITER (ROTOR) ARMATURE

1. Clean dust and dirt from and rectifier assembly. (Figure 6-33) (See Section 5)




Figure 6-33

2. Check the exciter armature for burrs on the mating surfaces.

3. Check the rectifiers and surge protector for proper operation. Replace defective parts.

CAUTION: THREE FORWARD AND THREE REVERSE POLARITY DIODES ARE USED. BE SURE THE CORRECT PART IS INSTALLED IN THE CORRECT LOCATION. THE SURGE SUPPRESSOR IS POLARIZED. OBSERVE POLARITY MARKINGS WHEN CHANGING THE SURGE SUPPRESSOR




Figure 6-34

Torque mounting nuts to 80 in-lb. Torque lead terminal nuts to 25 in-lb. Never torque against the diode terminal - use a 7/16-in. wrench to support the terminal.




Figure 6-35

4. Check the exciter armature and rectifier assembly for loose, frayed, or burnt winding or loose connections. Measure winding resistance and insulation resistance. DO NOT megger diodes or surge suppressor. Repair or replace as necessary. If field repair of the winding is necessary, contact Katolight for special winding procedures and materials.

5. Look for score marks on the outside diameter of the armature core caused by rubbing. (This could indicate bearing or assembly problems and should be investigated.)

PMG INSPECTION

PMG STATOR

1. Clean dust and dirt from the PMG stator winding.




Figure 6-36

2. Check PMG stator for a loose, frayed, or burnt winding. Measure winding resistance and insulation resistance. (See section 8.) Repair or replace as necessary. Contact Katolight for special winding procedures and materials.
3. Look for score marks in the bore caused by rubbing.

PMG ROTOR

WARNING
THE PMG ROTOR USES VERY STRONG MAGNETS. KEEP AWAY FROM IRON AND STEEL PARTS THAT COULD BE DRAWN TO THE MAGNETS AS WELL AS OTHER COMPONENTS THAT CAN BE DAMAGED BY MAGNETIC FIELDS.



Figure 6-37

1. Clean dust and dirt from the PMG rotor.
2. Check to be sure all magnets are tightly bonded to the PMG rotor.
3. Check the bore and keyway of the PMG rotor for burrs or corrosion.
4. Look for score marks on the outside diameter caused by rubbing. (This could indicate bearing or assembly problems and should be investigated.)
5. Inspect snap rings and loading spring, replace as required.

MAIN ROTOR INSPECTION

BEARING

1. Check the bearing for damage or wear. Clean old grease from the bearing cap, and fill bearing cap grease cavity 1/3 to 1/2 full of r Chevron SRI (or equivalent).

CAUTION: If the bearing needs to be removed any reason, always install a new bearing.

2. If the bearing is to be replaced, remove with suitable puller. (Figure 6-38.)




Figure 6-38

3. Be sure the inner bearing cap is on the shaft before installing the new bearing.

4. Heat the new bearing in an oven to a maximum temperature of 212°F (100°C). Apply a thin coat of clean lubricating oil to the press-fit area of rotor shaft. Install the bearing over the end of the shaft until it seats against the shaft shoulder as shown in Figure 6-39. The bearing should slide on the shaft and seated without excessive force. If the bearing binds on the shaft before being fully seated a piece of tubing, slightly larger than the press area, can be used to drive the bearing into place. Using light taps with a soft mallet, apply pressure to the inner race only.

CAUTION:

UNDER NO CIRCUMSTANCES SHOULD PRESSURE BE APPLIED TO THE OUTER RACE OF THE BEARING, AS PERMANENT BEARING DAMAGE COULD RESULT.




Figure 6-39

Allow the bearing to cool for one hour before attempting to assemble the generator.

FAN

1. Check the fan for cracks or broken blades. Replace the fan if defective.

2. Mark the hub and fan for alignment, this is necessary to be sure the balance weights will be in the same position when the fan is reinstalled.

3. For single bearing generators. Remove the fan mounting cap screws (Figure 6-40) and slide the fan off the shaft. (Figure 6-41.) For two-bearing generators, remove the drive end bearing and bearing cap. (See bearing removal instructions.) Remove the fan mounting cap screws and slide fan off the shaft. (Figure 6-40 and 6-41.)




Figure 6-40




Figure 6-41

4. To reinstall, slide the fan on the shaft making sure the fan-mounting surface is toward the drive hub. Align reference marks (this is important for assembly balance) and mount the fan to the drive hub with the cap screws and Belleville washers. (Figure 6-42.) Torque the cap screws to 60 ft-lb. (81 N-m).




Figure 6-42

5. NOTE: Balance weights on the fan are for balance of the complete rotor assembly. The rotor assembly should be rebalance if a new fan has been installed.

6. On two-bearing generators, install bearing cap and new bearing according to the bearing assembly instructions. (Item A.)

Drive Hub (Single Bearing Generators)

1. Check the drive hub for cracks or stripped drive disc mounting holes. Replace the hub if defective.

2. If the hub is to be replaced, remove the fan (See Item B) and install a suitable puller to the hub. Remove the two set screws in the hub over the key. Using a torch, rapidly heat the hub at the outer diameter while tightening the puller. (This must be done rapidly before the heat can expand the shaft.) Remove the hub. (Figure 6-43)




Figure 6-43

3. To insure proper fan location, mark the new hub in the same place as the old hub relative to the keyway. Install key in shaft. Heat the new hub in an oven to 500°-600°F (260°-316°C). Use suitable heat resistant gloves, slide the hub over the key in the shaft until it seats against the shaft shoulder. (Figure 6-44.)




Figure 6-44

4. Allow the hub to cool for one hour. After the hub has cooled, tighten the set screws in the hub to 50 ft-lbs. (68 N.M.) torque. Match the alignment marks on the fan and hub and mount the fan. (See item B.)

5. Rebalancing the rotor assembly is not necessary if only the hub is replaced and the fan is mounted in the same location relative to the hub and shaft.

MAIN ROTOR CORE AND WINDINGS

1. Clean all parts. Remove dust and dirt from the rotor winding air passages with low-pressure, moisture-free air.




Figure 6-45

2. Check the rotor for loose, frayed, or burned windings. Measure winding

resistance and insulation resistance. Test for shorted turns using an A-C impedance test. A defective rotor winding must be rewound. The rotor assembly must be rebalanced after any rework or repair has been completed.

DRIVE DISCS (SINGLE BEARING GENERATORS ONLY)

1. Inspect the drive discs for distorted or bent edges. (Figure 6-46) Inspect for worn mounting holes. Replace all defective discs as necessary.




Figure 6-46

2. Inspect the drive disc mounting cap screws for damaged threads. Replace cap screws if damaged.

FRONT (EXCITER) END BRACKET INSPECTION

1. Remove the filler and drain grease pipes and the grease plugs from outer bearing cap. (Figure 6-47.)




Figure 6-47

2. Clean the end bracket, outer bearing cap, grease pipes, and cap screws to remove all dust, dirt, and grease.

3. Inspect the cap screws for stripped threads and replace if defective.

4. Inspect the end bracket for stripped threads, cracks, and burred or rough mating surfaces. Inspect the bearing bore for burrs or wear. If the bracket shows excessive bearing bore wear, it should be repaired or replaced. (Figure 6-48.)




Figure 6-48

5. Inspect the mounting pads for the PMG stator and exciter stator. Be sure they are smooth, clean, and free of any burrs or rust. That could interfere with proper alignment. (Figure 6-47 and 6-48.)

6. Re-assemble the grease pipes and fittings to the bearing cap.

DRIVE END BRACKET OR SAE ADAPTER INSPECTION

1. For two-bearing generators, remove the grease plugs from the bracket.

2. Clean the bracket or adapter, cap screws and screen assembly to remove all dust, dirt, and grease.

3. Inspect the cap screws for stripped threads and replace if defective.

4. Inspect the bracket or adapter for stripped threads, cracks, and burred or rough mating surfaces. (Figure 6-49 and 6-50.)




Figure 6-49




Figure 6-50

5. For two-bearing generators, inspect the bearing bore for burrs or wear. If the drive end bracket shows excessive bearing bore wear, it should be repaired or replaced.

MAIN STATOR INSPECTION

1. Clean dust and dirt from the stator frame and winding. (Figure 6-51.) (See section 5.)




Figure 6-51

2. Inspect the frame for stripped threads, cracks, burred mating surfaces, or other damage.
3. Inspect the stator for a loose, frayed, or burnt winding. Measure winding resistance and insulation resistance. (See section 8.) Repair or replace as necessary.

FRONT END BRACKET INSTALLATION

1. Install two guide pins (threaded rod can be used) into the generator side of the end bracket mounting holes. Align the guide pins with the holes in the generator frame and slide the bracket onto the frame. (Figure 6-52.) Install bracket mounting cap screws. (Figure 6-53.)




Figure 6-52

CAUTION: ON LARGE GENERATORS, A HOIST AND LIFTING STRAP SHOULD BE USED TO ASSIST IN THE FRONT END BRACKET INSTALLATION.




Figure 6-53

2. Remove the two guide pins and insert the remaining cap screws and torque to specifications given in section 12:

MAIN ROTOR INSTALLATION

1. Grease bearing cavity and bearing with Chevron SRI (or equivalent) grease.
2. Using a rotor lifting fixture and a suitable hoist, carefully install the rotor assembly into the main stator assembly through the drive end. (Figure 6-54.) Carefully feed the rotor leads through the front-end bracket shaft hole as the rotor is installed.




Figure 6-54

CAUTION:
SPECIAL CARE SHOULD BE TAKEN
WHEN INSTALLING THE ROTOR
ASSEMBLY. WINDING DAMAGE
COULD RESULT IF THE ROTOR
IS ALLOWED TO HIT THE MAIN
STATOR.

WARNING
DO NOT APPLY ANY FORCE TO THE
GENERATOR FAN FOR LIFTING OR
ROTATING THE GENERATOR
ROTOR. DISREGARDING THESE
INSTRUCTIONS MAY CAUSE PER-
SONAL INJURY OR EQUIPMENT
DAMAGE.

3. For single bearing generators, slide the SAE adapter over the fan and secure to the main stator and frame assembly with cap screws torqued per section 12. (Figure 6-55 and 6-56.) It may be necessary to raise the rotor assembly slightly to allow the mounting of the SAE adapter.




Figure 6-55




Figure 6-56




Figure 6-57

For two-bearing generators, insert two guide pins in the rear bearing lock holes. (Figure 6-57.) Fill the grease cavity of the drive end bracket 1/3 to 1/2 full of Chevron SRI (or equivalent) grease. Assemble all grease plugs in the bracket. Mount the bracket on the bearing and guide the bearing lock pins through the bracket holes. (Figure 6-58.)




Figure 6-58

Align the drive end bracket and mount with the cap screws. (Figure 6-59.) Insert two cap screws with lock washers into the bearing lock and tighten. Remove the guide pins and replace with the remaining two cap screws with lock washers. Torque bearing cap screws to 25 lb.-ft (34 NM). Torque bracket mounting cap screws per specifications given in section 12.




Figure 6-59

CAUTION:
ON LARGE GENERATORS, A HOIST AND LIFTING STRAP SHOULD BE USED TO ASSIST IN THE DRIVE END BRACKET OR THE SAE ADAPTER ASSEMBLY.

4. For single bearing generators, insert a guide stud into the drive hub. Position all

spacers (if any), then all drive discs, one at a time until all discs are installed. (Figure 6-61.)




Figure 6-61

Make sure that all disc mounting holes at the inner and outer diameter are properly aligned. Secure the discs with the grade eight 5/8-18 cap screws and hardened washers. Torque to 192 ft.-lb. (260 N-m). Torque the bolts in sequence according to Figure 6-62.




Figure 6-62

5. Install the outer bearing cap on the exciter end. (Figure 6-63.) Align holes in inner and outer bearing cap and install cap screws. Torque to 25 lb.-ft (34 N-M) (Figure 6-64.)




Figure 6-63




Figure 6-64

PMG INSTALLATION

1. Install inboard snap ring, where supplied, and loading spring on shaft. (Figure 6-65.)



Figure 6-65

2. Slide PMG rotor onto shaft. (Figure 6-66.)




Figure 6-66

3. Install snap ring. (Figure 6-67.) Use a piece of pipe slightly larger than the shaft (2-3/4 inches) to push the rotor back against the loading spring until the snap ring seats in the slot. (Figure 6-68.)




Figure 6-67




Figure 6-68

4. Install the PMG stator on its mounting pads, with the leads in the left (9:00 o'clock) inboard position, and secure with the four

mounting cap screws and Belleville washers. (Figure 6-69 and 6-72.) Torque to 4 ft-lb. (5 N-M).




Figure 6-69

5. Route and secure PMG moving parts.

EXCITER INSTALLATION

1. Attach a wire to the main rotor leads and feed the wire through the armature bore and the lead hole in the aluminum standoff plate. On larger exciters, it will be helpful to install a guide pin in the end of the shaft to support the armature while fishing the rotor leads through. (Figure 6-70.)




Figure 6-70

Align the key in the armature bore to the keyway in the shaft. Slide the armature on the shaft while feeding the main rotor leads

through the lead hole in the aluminum standoff plate. (Figure 6-71.)




Figure 6-71

Insert the cap screw and Belleville washer (Figure 6-72.) through the mounting hole in the aluminum standoff plate and secure to the shaft (Figure 6-73). Tighten the cap screw until the armature seats on the shaft. Torque to 84 lb.-ft (114 N-M).




Figure 6-72




Figure 6-73

2. Observe the polarity markings and connect the main rotor leads to the rectifier

assembly. (Figure 6-74.) Torque the nuts to 4 ft-lb. (5.4 N-M).




Figure 6-74

3. Position the exciter field leads at the left (9:0'clock) inboard position. Using a suitable lifting device, mount the exciter stator on the front e bracket mounting pads and align the mounting holes. (Figure 6-75.) Mount the cap screws with Belleville washers. (Figure 6-72.) Torque the cap screws to 60 ft-lb. (81 N-M). Route and secure the exciter stator leads away from any moving parts.




Figure 6-75

CONDUIT BOX INSTALLATION

1. Install the conduit box over the main stator leads (be sure the leads are in the upper compartment and secure with bolts and lock washers. (Fig 6-76 and 6-77.)




Figure 6-76




Figure 6-77

2. On generators with bus bar assemblies, reassemble main stator leads and insulating blocks to bus bars. (Figure 6-78.)




Figure 6-78

3. Reconnect exciter leads, PMG leads and other accessories according to the connection prints and markings installed before disassembly.

ASSEMBLY TO PRIME MOVER

1. Attach a suitable hoist to the generator lifting lugs, and move the generator until the generator foot mounting holes are aligned with the base and slightly above.

2. For single bearing generators, if the screen assembly is mounted on the adapter, remove the mounting bolts and remove the screen. (Figure 6-79.)




Figure 6-79

(NOTE: Do not remove the drip cover from the screen assembly if so equipped.) Insert two guide pins in the flywheel and two in the flywheel housing. Adjust the generator position until the drive discs are piloted in the flywheel. Remove the guide pins and secure the discs with Grade 8 place bolts and hardened washers or Grade 8 cap screws and heavy series lockwashers.

Torque per specifications given in section 12.

Position the generator so that the SAE adapter mates with the flywheel housing.

WARNING
DO NOT APPLY ANY FORCE TO THE GENERATOR FAN FOR LIFTING OR ROTATING THE GENERATOR ROTOR. DISREGARDING THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE.

CAUTION:
DO NOT FORCE THE ALIGNMENT OF THE UNITS. SHIFT THE GENERATOR FROM SIDE TO SIDE OR RAISE OR LOWER WITH A LIFTING DEVICE AS NECESSARY.

It may be necessary to use shims under the mounting feet of either the generator or the prime mover to obtain proper alignment. Use the same shims as removed under disassembly or proceed as follows: Using the extreme bottom four cap screws, mount the SAE adapter to the flywheel housing.

With a .0015 to .002 inch feeler gauge at the extreme top of the adapter to flywheel housing fit, raise the generator or lower the prime mover until the gauge is snug. Relieve just enough to release the feeler gauge and torque the remaining SAE adapter cap screws to the flywheel housing.

Mount the screen assembly and tighten the mounting bolts.

For two-bearing generators, align the coupling halves or sheaves between the generator and the prime mover by adding shims under the feet.

3. Shim under the generator feet for proper support, ensuring that the generator mounting surfaces are level.

4. Install the mounting bolts that secure the generator to the base.

5. For two bearing generators, assemble the coupling halves or sheave belts between the generator and the prime mover. (Follow the coupling manufacturer's instructions for assembly and alignment.)

6. Connect all conduits and ducting to the conduit box.

7. Connect all external wiring to the generator inside the conduit box.

8. Check the exciter air gap (the gap between exciter armature and stator) by inserting a .010 inch feeler gauge in the gap and rotating around the armature diameter to ensure the minimum air gap is available. (See Figure 80.) If the feeler gauge cannot be rotated full revolution, then check for a "cocked" exciter stator or loose stator mounting screws.




Figure 6-80

NOTE: On single bearing units, the exciter air gap cannot be checked properly until the generator is mounted to the prime mover.

9. Install the conduit box covers.

TROUBLESHOOTING

INTRODUCTION

This section is intended to suggest a systematic approach to locating and correcting generator or regulator malfunctions. The sections are arranged according to the symptoms of the problem. The steps in each section have been arranged in an attempt to do the easy checks first then to prevent further damage when troubleshooting a disabled machine.

The first and perhaps most important step of troubleshooting should be to gather as much information as possible from personnel who may have been present during the failure. Information on how long the generator had been running, what loads were on the line, weather conditions, what protective equipment operated, etc., can help isolate the problem.

Always make a thorough visual inspection to check for any obvious problems before attempting to run the generator.

WARNING

HIGH VOLTAGES CAN BE PRESENT AT THE GENERATOR AND REGULATOR TERMINALS. HIGH RESIDUAL VOLTAGES CAN BE PRESENT EVEN WITH THE REGULATOR DISCONNECTED OR ITS FUSES REMOVED. SOME EQUIPMENT (SUCH AS SPACE HEATERS) MAY BE ENERGIZED WHEN THE GENERATOR IS OFF. TOOLS, EQUIPMENT, CLOTHING, AND YOUR BODY MUST BE KEPT CLEAR OF ROTATING PARTS AND ELECTRICAL CONNECTIONS.

SPECIAL CAUTION MUST BE TAKEN DURING TROUBLESHOOTING SINCE PROTECTIVE COVERS AND SAFETY DEVICES MAY BE DISABLED TO GAIN ACCESS AND MAKE TESTS.

BE CAREFUL. SERIOUS PERSONAL INJURY OR DEATH CAN RESULT FROM THESE HAZARDS. CONSULT QUALIFIED PERSONNEL WITH ANY QUESTIONS.

SYMPTOM:		
NO VOLTAGE OR RESIDUAL VOLTAGE	Regulator Fuse Blown Check fuse with ohmmeter.	Replace bad fuse.
	Voltmeter Off	Check to be sure meter phase selector switch is not in the off position.
	Defective Voltmeter	Verify proper operation of panel meter with another meter that is known to be accurate.
	Incorrect Connections	Verify generator connections.
	Defective Connections/Wiring	Inspect all wiring for grounds, open circuits & short circuits.
	No Regulator Input	Measure voltage at regulator input (PMG output)
	Defective Diodes, Surge Suppressor	Test generator with constant excitation (12 volt battery test) refer or Generator Windings
	Voltage Regulator Protective Shutdown Circuits are Operating	Correct problem and adjust regulator. Refer to regulator manual.
	Voltage Regulator Inoperative	Adjust or replace regulator. Refer to regulator manual.

LOW VOLTAGE - NO LOAD	Under speed Operation	Check speed using tachometers and/or frequency meters.
	Defective Voltmeter	Verify operation of panel meter with another meter that is known to be accurate.
	Residual Voltage	Disconnect F1 and F2 leads at the voltage regulator. If voltage goes down continue on to next step, if voltage does not change refer to troubleshooting for symptoms of "No Voltage - No Residual Voltage".
	Incorrect Generator Connections	Verify generator connections refer to drawings supplied V generator set and section 3.
	Defective Connections / Wiring	Inspect all wiring for grounds, open circuits, short circuits, and loose and dirty connections.
	Regulator Adjustments	Adjust regulator. Refer to regulator manual. Check exciter field volts.
	Defective Diodes, Surge Suppressor, Generator Windings	Test generator with constant excitation (12 volt battery test)
	Voltage Regulator not Operating	Adjust or replace regulator. Refer to regulator manual. Properly

LOW VOLTAGE WHEN LOAD IS APPLIED	Overload	Measure amps and verify that the load does not exceed nameplate rating of the generator
	Defective Ammeter	Verify operation of ammeter by using a separate meter known to be accurate
	Droop Circuit	If the generator set is equipped for paralleling, some voltage droop is normal as load increases. Refer to the regulator instruction manual
	Continue troubleshooting for symptoms "Generator Produces Low Voltage - No Load".	Continue troubleshooting for symptoms "Generator Produces Low Voltage - No Load".
HIGH VOLTAGE	Defective Voltmeter	Verify operation of panel meter with another meter that is known to be accurate
	Incorrect Operating Speed	Verify speed with tachometer or frequency meter.
	Incorrect Connections	Verify generator connections Refer to drawings supplied with generator set
	Defective Connections / Wiring	Inspect all wiring for grounds, open circuits, and short circuits.
	Regulator Adjustments	Adjust regulator. Refer to regulator manual
	Diode Polarity Incorrect	Check diodes, verify proper diodes are installed and polarity is correct.
	Voltage Regulator not Operating	Adjust or replace regulator. Refer to regulator instruction manual.

VOLTAGE IS FLUCTUATING	Incorrect Speed	Verify speed with tachometer or frequency meter.
	Unstable Speed	Verify governor stability.
	Voltage Regulator Stability	Adjust regulator stability. Refer to regulator manual.
	Defective / Loose Connections	Inspect all wiring for loose or dirty connections.
	Defective Diodes, Surge Suppressor or Generator Windings	Test generator with constant excitation (12-volt battery test).
	Remote Voltage Adjust	Check operation. Refer to regulator manual.
	Defective Regulator	Replace regulator. Refer to regulator manual.
OPERATES SATISFACTORILY WHEN COLD, BUT SHUTS DOWN WHEN WARM	<i>Regulator Shutdown on Over Temperature</i>	Correct cooling problems. Refer to regulator manual.
BUILDS VOLTAGE FROM STARTUP, THEN GOES TO LOW (RESIDUAL) VOLTAGE	Regulator Protective Circuit is Operating	Check indicators on regulator. Correct problems and adjust as required. Refer to regulator manual.
EQUIPMENT RUNS NORMALLY ON UTILITY POWER, BUT WILL NOT RUN ON GENERATOR SET	Voltage Waveform is Distorted	Analyze load. Excessive SCR (Thyristor) loading will cause distortion. Some equipment may be sensitive to distorted waveforms. Refer to Katolight.

GENERATOR TESTING

VISUAL INSPECTION

Whenever testing and troubleshooting a generator set, it is always a good practice to make a thorough visual inspection. Remove covers and look for any obvious problems. Burnt windings, broken connectors, leads, mounting brackets, etc., can usually be identified. Look for any loose or frayed insulation, loose or dirty connections, broken wires. Be sure all wiring is clear of rotating parts.

Verify that the generator is connected for the voltage required this is especially important on new installations.

Check for any foreign objects, loose nuts, bolts, and electrical connectors. Clear paper, leaves, building materials, etc., that could be sucked into the generator. (Generators are air-cooled. Air enters the lower portion of the conduit box.) Check the air gap for clearance or obstructions (main generator and exciter).

If possible, rotate the generator rotor by hand to be sure it turns freely.

If serious problems can be identified before attempting to operate the machine, additional damage can be avoided.

CONSTANT EXCITATION (12V BATTERY) TEST

THEORY: The generator output voltage is dependent on generator speed, generator design, load, and exciter input current. If the generator speed and exciter input are known, the output voltage at no load can be measured and compared to the design value.

Problems can be isolated to either the generator or regulator system by using this test.

TEST PROCEDURE:

1. Shut the generator set down.
2. Connect a voltmeter to the generator output.
3. Disconnect the F1 and F2 leads at the regulator.
4. Connect a 12-volt battery capable of supplying 1 amp to the F1 and F2 leads. F1 is plus (+), F2 is minus (—).

CAUTION: Beware of arcing when connecting leads. Stay clear of battery vents. Escaping hydrogen gas can explode. If hazardous conditions exist - use a suitable switch to connect or disconnect the battery.

5. With no load on the generator, (main breakers open) run generator at rated speed.
6. Measure the generator output voltage.
7. Shut generator down.
8. Disconnect battery (see Caution - Step 3).
9. Compare voltage reading with value shown in section 12.

Conclusion: If voltage readings are normal, the main generator and exciter are operating properly. Troubleshooting should continue with the regulator. If readings are not normal the problem is in the generator. Continue testing diodes, surge suppressor, windings.

MEASURING VOLTAGES

When testing the generator and regulator, the most frequent (and usually easiest) measurement will be a voltage. The generator will need to be running at rated speed and may have some of the protective guards and covers removed. **BE CAREFUL.** Keep yourself and your test leads out of the way. It is best to shut the unit down when connecting meters. When using alligator clips or push on terminals, be sure the leads are supported so vibration does not shake them loose when running the generator set.

See figure 8-1 for measurement points and expected meter range settings. When in doubt, start with a higher range and work down. Consult meter instruction manual to verify its operation and limitations.




Figure 8-1

TYPICAL VOLTAGE MEASUREMENTS

Voltage Measurement	Test Point	Meter/Range Selection Requirement
Generator Output Voltage	Output "T" leads or bus bars, also main circuit breaker "line" side.	System voltage - volts AC See generator nameplate and connection diagram.
Regulator Output (Exciter Stator Input)	F1 and F2 terminals at the regulator.	200 volts D.C. range. F1 is plus (+), F2 if minus (—)
Regulator Sensing	E1, E2, E3 terminals at the Voltage the regulator.	Usually the same as the system voltage (generator output volts). However, in some cases, sensing taken from winding center taps or instrument potential transformers. Maximum 600 volts AC Example: Center tap of 480-volt system would give 240 volts E1, E2, or E3. Example: A 4160-volt system must use a transformer to step voltage down below 600 volts. See the connection diagram supplied with generator set.
Regulator Input Volts (PMG Output Volts)	"PMG" leads at the regulator or capacitor.	200-240 VAC 300 Hz @ 1800 rpm 180-220 VAC 250 Hz @ 1500 rpm

CURRENT (AMP) MEASUREMENTS

Current measurement (AC) can be easily taken with a clamp on type meter.

NOTE: Most clamp type ammeters will not measure D.C.

When measuring generator output current, be sure the clamp is around all cables for

each phase. If the physical size of the conductors or the capacity of the meters will not permit all cables to be measured at once, Each one can be measured individually. Add the individual readings together to get the total. Compare readings to the generator nameplate (nameplate ratings are always given per phase).

Amperage should never exceed the nameplate rating when running the intended load. (Amperage may go above nameplate momentarily when starting large motors.) When measuring exciter field amps (F1 and F2 leads) a D.C. meter is required. The maximum field current under full regulator forcing is 6.5 amps D.C.

MEASURING RESISTANCE

The generator windings can be measured and compared to the values shown in the service specifications.

Main Stator

The main stator winding resistance is very low. A meter capable of readings in the milliohm range would be required. However, a standard V.O.M. can be used to check for continuity, shorts, or grounds.

Example: With leads disconnected, a measurement from T1 to T4 should be very low (continuity most V.O.M.'s). Measured from T1 or T4 to any other lead should be infinite. Measure from the 'T' lead the generator frame to check for grounds (reading should be infinite).

Normal full load reading is approximately 3 amps.

The exciter stator resistance is measured by disconnecting the F1 and F2 leads at the regulator. Measure the resistance between the leads (this value is 22-24 ohms on standard generators). Measure from the leads to the frame to check for grounds.

Note markings and disconnect the main rotor leads (F1 leads and F2 leads) from the rectifier assembly. Measure the resistance of the main rotor winding. Compare reading to value shown in service specification section 12. Measure from the leads to the exciter-mounting bolt to check for grounds.

Exciter Rotor

Disconnect the exciter rotor leads at the diodes (leave leads disconnected if proceeding to check diodes). Measure resistance between phases. Compare value to service specification section 12. Measure from the leads to the exciter-mounting bolt to check for grounds.

TESTING DIODES (RECTIFIERS)

Diodes perform the function of an "electrical check valve". They conduct in one direction only and are used to "rectify" ac current into dc current. To test, measure the resistance first in one direction and then reverse the leads and test in the other direction. The reading should be high in the reverse direction and low in the forward direction. A shorted diode will read low in both directions. An open diode will read high in both directions.

NOTES:

1. Two different polarities of diodes are used. The only difference is in the way the device is mechanically placed in the case. When changing diode, be sure the correct polarity is used.

Refer to section 6 figure 6-34.

2. Some meters do not have enough voltage output from their internal batteries to turn the diode on (about 0.6 volts is required), and the voltage can change with different

range settings. Consult the instruction manual for your meter.

3. Polarities supplied by the meters internal battery may or may not correspond to the (+) (—) markings on the meter.

INSULATION RESISTANCE - GENERAL

Insulation resistance is a measurement of the integrity of the insulating materials that separate the electrical windings from the generators steel core. This resistance can degrade over time or due to contaminants (dust, dirt, oil, grease, and especially moisture). Most winding failures are due to a breakdown in the insulation system. In many cases, low insulation resistance is caused by moisture collected when the generator is shut down. The problem can be corrected simply by drying out the windings. Section 5.

Normally the resistance of the insulation system is on the order of millions of ohms. It is measured with a device called a "megger" which is a megohm meter (Meg is for million) and a power supply. The power supply voltage varies, but the most common is 500 volts. A megger voltage over 500 is not recommended except for measuring medium voltage (2400/4160) stators only.

CAUTION: First disconnect any electronic components, regulators, diodes, surge protectors, protective relays, etc., will be destroyed if subjected to the high megger voltages.

To measure insulation resistance, connect the red or positive megger lead to the leads for the winding to be tested, connect the back or negative megger lead to the generator frame. Be sure the leads of the part being tested are not touching any metal parts of the generator. (If the neutral is

grounded, it must be disconnected.) Take megger reading (refer to the manual for the megger).

INSULATION RESISTANCE - MAIN STATOR

CAUTION: Be sure the regulator, and any other electronic components, metering, protective relays, etc., are disconnected before meggering. High megger voltages will destroy these parts. All stator leads must be isolated from ground and connected together (on most systems with grounded neutrals - the neutral can be isolated from ground and used as a test point). Connect the positive megger lead to the main stator leads. Connect the negative megger lead to the generator grounding stud. Take the megohm reading (refer to instructions for the megger).

GENERATOR TESTING

The minimum acceptable value can be calculated using the following formula.
$$\text{Minimum Insulation Resistance} = \frac{\text{Gen. Voltage} + 1}{1000} \text{ (Megohms)}$$

Example:

For a 480 volt generator
 $480 + 1 = 1.48 \text{ Megohms}$

If the reading is below the recommended value, the winding must be dried out or repaired.

INSULATION RESISTANCE - MAIN ROTOR

Disconnect the main rotor leads from the diode bridge on the exciter rotor. Connect the leads together with the positive megger lead. Connect the negative megger lead to a good ground on the rotor assembly such as the exciter mounting bolt. Take the megohm

reading (refer to instructions for the megger).

The minimum acceptable value is 1.5 megohms.

If the reading is low, the winding must be dried out or repaired.

INSULATION RESISTANCE - EXCITER STATOR

Disconnect the exciter leads F1 and F2 from the regulator. Never subject the regulator to a megger. Connect F1 and F2 together with the positive megger lead. Connect the negative megger lead to the ground stud. Take the megohm reading (refer to instructions for the megger).

The minimum value is 1.5 megohms.

If the reading is low, the winding must be dried out or repaired.

INSULATION RESISTANCE - EXCITER ROTOR

Disconnect the exciter rotor windings (6 leads from the diodes). Connect all leads together with the positive megger lead. Connect the negative megger lead to a good ground on the rotor assembly such as the mounting bolt. Take the megohm reading (refer to the instructions for the megger).

The minimum acceptable value is 1.5 megohms.

If the reading is low, the winding must be dried out or repaired.

MAIN ROTOR FIELD AC IMPEDANCE TEST

THEORY: The main rotor resistance can be measured with a very accurate meter that is able to measure low (1 ohm) resistance but it is difficult to determine if there are turn to turn shorts in the field pole windings. One shorted turn would only change a resistance reading on the order of one half of one percent.

The ac impedance test measures the impedance (inductance and resistance) of the field pole coils. Shorted turns in the field pole windings change the coil inductance to a much greater degree than the resistance.

PROCEDURE:

Step 1: The rotor must be supported on a non-magnetic surface such as a wooden skid. Do not use a steel table that would create a magnetic "short circuit" between the poles.

Step 2: Apply 120 volts ac to disconnected main rotor leads F1 and F2.

Step 3: Measure and record voltages pole. Between points "A" and "C", "C" and "D", "D" and "E" across each "B", "B" and (Figure 8-1).

Step 4: The voltage readings should balance within one volt.

RESULTS: If the ac voltages are not balanced ($30v \pm 1v$ ac with 120v ac input) across each pole, the winding has shorted turns and should be rewound.

Refer to Katolight for further information.

MAGNAMAX EXPLODED VIEW




TABLE 9-1 PARTS LIST

NOTE: The parts in this list are subject to change, model number and serial number must accompany any parts order or inquiry.

TABLE 9-1 PARTS LIST							
NOTE: The parts in this list are subject to change, model number and serial number must accompany any parts order or inquiry.							
Item	Part Description	430 Frame Series		570 Frame Series		740 Frame Series	
		Part Number	Qty.	Part Number	Qty.	Part Number	Qty.
1	Screen Assembly						
	Screen	B-525565-1	1	B-525565-2	1	B-525565-3	1
	Screen Mounting Bolt Screen	A-9646-200	2	A-9646-200	2	A-9646-200	2
	Mounting Nut	A-7551-18	2	A-7551-18	2	A-7551-18	2
2	Drip Cover assembly	B-525566-1	1	B-525566-2	2	B-525566-3	1
3	Adapter						
	#3 Adapter	B-525512A	1				
	#2 Adapter	B-525512B	1				
	#1 Adapter	B-525513A	1	B-525618A	1		
	#1/2 Adapter	B-525514B	1	B-525616A	1		
	#0 Adapter	B-525514A	1	B-525603A	1	B-525720A	1
	#00 Adapter (#18 Disc)			B-525617A	1	B-525721A	1
	#00 Adapter (#21 Disc)			B-526228A	1	B-52572 1A	1
4	Disc Mounting Fasteners						
	Cap screw for #11-1/2	A-9674-200	6				
	Cap screw for #14	A-9674-150	6	A-9674-150	9		
	Cap screw for #18	A-9674-150	6	A-9674-150	9	A-9674-200	18
	Cap screw for #21					A-9674-150	18
	Cap screw for Delco	A-9674-150	6	A-9674-150	9	A-9674-200	18
5	Hardened Washer	A-9667-1	6	A-9667-1	9	A-9667-1	18
	Drive Discs						
	#11-1/2 Disc	A-525506	5	—	—	—	—
	#14 Disc	A-525508	5	A-525508	5	—	—
	#18 Disc	B-525975	4	A-525579	5	A-525579	10
	#21 Disc	—	—	A-525580	5	A-525580	10
6	Delco Disc (17.75" 0.0.)	A-525507	5	A-525507	5	A-525507	10
	Spacers						
	For #11-1/2 Disc	A-525567	14	—	—	—	—
	For #14 Disc	A-525567	5	A-525503	6	—	—
	For #18 Disc	—	—	—	—	A-525503	10
	For #21 Disc	—	—	—	—	—	—
7	For Delco Disc	—	—	A-525503	1	A-525503	12
	Fan Mounting Fasteners						
	Cap screw	A-9626-150	4	A-9626-150	8	A-9626-1 50	8
	Cap screw (2 Brg. Only)	A-9626-150	4	A-9626-200	8	A-9626-200	8
8	Belleville Washer	A-9682-1	4	A-9682-1	8	A-9682-1	8
	Fan	B-525510A	1	B-525604A	1	B-525719A	1

TABLE 9-1 PARTS LIST

NOTE: The parts in this list are subject to change, model number and serial number must accompany any parts order or inquiry.

Item	Part Description	430 Frame Series		570 Frame Series		740 Frame Series	
		Part Number	Qty.	Part Number	Qty.	Part Number	Qty.
9	Hub						
	Drive Hub (Sgl Brg. Only)	B-525509A	1	B-525606A	1	B-525726A	1
	Fan Hub (2 Brg. Only)	A-525568A	1	B-525694A	1	B-525750A	1
10	Drive Hub Set Screws		—	A-9675-50	2	A-9675-50	2
11	Drive Hub Key	A-25658-30	1	A-25658-30	1	A-25658-46	1
12	Main Rotor Assembly with Windings	REFER TO FACTORY					
13	Front Bearing Cap	B-525519A	1	B-525613A	1	B-525743A	1
14	Front Ball Bearing	A-7812R-70	1	A-7812R-80	1	A-7812R-110	1
15	Main Body Assembly	REFER TO FACTORY					
16	Adapter Mounting Fasteners	-					
	Cap screw	A-9680-125	12	A-9680-125	16	A-9626-150	16
	Lock Washer	A-7653-3	12	A-7653-3	16	A-7653-4	16
	Flat Washer	A-7656-8	16	A-7656-8	16	A-9667-1	16
17	Bracket Mounting Fasteners	-		-		-	
	Cap screw	A-9680-1 25	8	A-9680-125	8	A-9626-150	8
	Lock Washer	A-7653-3	8	A-7653-3	8	A-7653-4	8
	Flat Washer	A-7656-8	8	A-7656-8	8	A-9667-1	8
18	Front Bracket	B-525518A	1	B-525605A	1	B-525739A	1
19	PMG Bearing Cap	B-525520A	1	B-525612A	1	B-525742A	1
20	Bearing Cap Fasteners	-	-	-	-	-	-
	Cap screw	A-9680-350	4	A-9680-400	4	A-9680-450	4
	Lock Washer	A-7653-3	4	A-7653-3	4	A-7653-3	4
21	Conduit Box	D-525673	1	D-525680	1	D-525771	1
22	Conduit Box Mtg. Fasteners						
	Cap screw	A-9680-75	8	A-9680-75	8	A-9626-75	8
	Lock Washer	A-7675-2	8	A-7675-2	8	A-7675-4	8
23	Snap Ring - Inner	A-7610-275	1			—	—
24	Loading Spring	A-7661-45	1	A-7661-45	1	A-7661-45	1
25	PMG Rotor	A-526816	1	A-526816	1	A-526816	1
26	Snap Ring-Outer	A-7610-275	1	A-7610-275	1	A-7610-275	1
27	PMG Stator	A-525548-1	1	A-525548-1	1	A-525548A-1	1
28	PMG Stator Mtg. Fasteners						
	Cap screw	A-9812-200	4	A-9812-200	4	A-9812-200	4
	Belleville Washer	A-9682-2	4	A-9682-2	4	A-9682-2	4
29	Exciter Stator	A-400N-200A	1	A-400N-300A	1	See Table 9-2	1
30	Exciter Stator Fasteners	-	-	-	-	-	-
	Cap Screw	A-9626-300	4	A-9626-400	4	See Table 9-2	4
	Belleville Washer	A-9682-1	4	A-9682-1	4	A-9682-1	4
31	Exciter Rotor Assy. (Incl. 42)	-	-	-	-	See Table 9-2	
	430 Frame - All	B-526483-2	1	—	—		
	570 Frame - Low Voltage	—	—	B-526483-3	1		
	570 Frame - Med. Voltage	—	—	B-526483-10	1		

TABLE 9-1 PARTS LIST

NOTE: The parts in this list are subject to change, model number and serial number must accompany any parts order or inquiry.

Item	Part Description	430 Frame Series		570 Frame Series		740 Frame Series	
		Part Number	Qty.	Part Number	Qty.	Part Number	Qty.
32	Exciter Rotor Fastener	-	-	-	-	-	-
	Cap screw	A-9670A-200	1	A-9670A-200	1	A-9670A-200	1
	Belleville Washer	A-9682-1	1	A-9682-1	1	A-9682-1	1
33	Grounding Stud Assembly	-	-	-	-	-	-
	Stud	A-26937-300	1	A-26937-300	1	A-525574-400	1
	Washer	A-9787-1	2	A-9787-1	2	A-9787-3	2
	Nut	A-9786-1	1	A-9786-1	2	A-9786-3	2
34	Bus Bar Assembly	REFER TO FACTORY					
35	DVR2000 AVR	D-526352	1	D-526352	1	D-526352	1
36	Capacitor (DVR2000)	A-66377-45	1	A-66377-45	1	A-66377-45	1
37	Side Panels Blank Machined for (DVR2000)	B-525679A	1	B-525686A	1	B-525707A	1
		B-525679AE	1	B-525686AN	1	B-525707W	1
38	Fuse	A-525698-1	1	A-525698-1	1	A-525698-1	1
39	Fuse Holder Cap	A-525893	1	A-525893	1	A-525893	1
40	Solid Cover	B-525676	1	B-525687	1	B-525706	1
41	Louvered Cover	C-525562	1	C-525647	1	C-525670	1
42	Exciter Rectifier Assy. (Includes 43,44,45)	B-525528A	1	B-525528A	1	B-525528B	1
43	Diode Standard Polarity	B-525570-1	3	B-525570-1	3	B-525570-2	3
44	Diode Reverse Polarity	B-525571-1	3	B-525571-1	3	B-525571-2	3
45	Surge Suppressor	B-526482-1	1	B-526482-1	1	B-526482-2	1
46	Cover Mtg. Screws	A-9646-75	33	A-9646-75	33	A-9646-75	33

TABLE 9-2 : EXCITER ASSEMBLIES

Frame	Type	Insulation	Exciter Stator	Exciter Stator Mtg. Cap screws	Exciter Rotor
572	RSL	Standard	A-400N-250A	A-9626-350	B-526483-24
573,574	RSL	Standard	A-400N-300A	A-9626-400	B-526483-3
572	RSL	VPI	A-400N-250AA	A-9626-350	B-526483-25
573,574	RSL	VPI	A-400N-300AA	A-9626-400	B-526483-9
573,574	FSM	VPI	A-400N-300AA	A-9626-400	B-526483-10
741, 742	RSL	Standard	A-400N-500A	A-9626-600	B-526483-5
741, 742, 743	RSL	VPI	A-400N-500A	A-9626-600	B-526483-11
741, 742	FSM	VPI	A-400N-500A	A-9626-600	B-526483-11
743	FSM	VPI	A-400N-600A	A-9626-700	B-526483-12
744	RSL	VPI	A-400N-600A	A-9626-700	B-526483-12
744	FSL	VPI	A-400N-650A	A-9626-750	B-526483-13

STANDARD TOOLS

The MagnaMAX generator is assembled with American standard SAE hardware. All fasteners should be properly torqued. (See section 12). Torque wrenches ranging from 25 in-lb. through 200 ft-lb. should be available.

Electrical test equipment should include a voltmeter or multimeter (VOM), clamp on ammeter, accurate frequency meter or tachometer, and a megohmmeter. See section Generator Testing for more information.

SPECIAL TOOLS

In addition to the standard tools mentioned above, the following special tools would facilitate removal and installation of large and/or special parts. These tools can be obtained from the Katolight parts department.

Exciter stator lifting fixture (Figure 10-1).




Figure 10-1

In cases where the exciter stator is to be serviced without removing the generator conduit box this fixture can be used with overhead rigging to remove and reinstall the exciter stator.

Exciter rotor puller bolt (Figure 10-2). The exciter rotor has a built in pulling system. With the use of this bolt, the rotor can be easily removed from the shaft without damage to the winding.



Figure 10-2

The PMG rotor is installed to the generator shaft with a snap ring.

The nominal shaft diameter is 2-3/4 inches and the ring must be spread approximately 3/4 inches for removal. To install the snap ring, use a piece of pipe with a 2-3/4 inch I.D. (Figure 10-4). Push the PMG rotor and snap ring onto the shaft until the ring snaps into the groove.




Figure 10-4

Rotor lifting fixture (Figure 10-5). The main generator rotor is heavy (approximately 1/2 the weight of the generator) and difficult to handle. The proper fixture should be used whenever removing or installing the main rotor into the main stator. Without proper care and equipment, the windings can be easily damaged.




Figure 10-5

MISCELLANEOUS

A selection of wiring devices such as electric connectors, tape, cable ties, crimping and stripping tools, etc., should also be a part of the generator service tool kit. The standard regulator uses flat 1/4 inch female insulated terminals for AWG #14 wire.

PREPARATION FOR SHIPMENT OR EXTENDED STORAGE

SHIPPING INSTRUCTIONS

Shipping and handling will be much easier if the generator is fastened to a suitable shipping skid that will allow handling by a forklift. The skid should extend beyond the generator in all directions. If the original skid is available it should be used. Katolight will supply shipping skid drawings upon request.

Overseas shipping may require special export crating. Check with your freight carrier.

When installed, single bearing generator rotors are supported on the drive end by the drive discs bolted to the engine flywheel. When the engine is removed, the rotor must be supported by an appropriate fixture to prevent main rotor, main stator or exciter damage (Figure 11-1). Before shipping any single bearing generator, the main rotor must be supported by the adapter using an appropriate fixture.




Figure 11-1

STORAGE INSTRUCTIONS

If the generator is placed in storage, the following precautions should be taken to protect it:

A. Equipment must be kept clean.

1. Store indoors.
2. Keep covered to eliminate airborne dust and dirt.
3. Cover openings for ventilation, conduit connections, etc. to prevent entry of rodents, snakes, birds, and insects, etc.

B. Equipment must be kept dry.

1. Store in a dry area indoor.
2. Temperature swings should be minimal to prevent condensation.
3. If stored in an unheated or damp building, space heaters will be required to prevent internal condensation.
4. Treat unpainted flanges, shafts, drive discs, and fittings with a rust inhibitor.
5. Check insulation resistance of all windings before starting the generator. If readings are low, the windings must be dried.

C. Keep bearings lubricated.

1. Every six months rotate shaft several turns to distribute grease in bearings.
2. If unit has been stored more than one year, add grease before start-up.

D. Review and follow instructions in Sections 3 and 4 before putting the gen-set into service.

CAUTION
DO NOT ATTEMPT TO TRANSPORT
ANY GENERATOR WITHOUT
PROPER ROTOR
SUPPORT, EXTENSIVE
EQUIPMENT DAMAGE CAN OCCUR.

TABLE 12-1: MAGNA MAX - FASTENER AND TORQUE SPECIFICATIONS					
Part Description	Fastener Spec.®	430-570 Frames		740 Frames	
		Size Dia.- Thread	Torque Ft-Lb.	Size Dia.- Thread	Torque Ft-Lb.
Front Bracket	Grade 5 cap screws with flat and lock washers	3/8 - 16	25	1/2 - 13	60
Bearing Caps	Grade 5 cap screws with lock washers	3/8 - 16	25	3/8 - 16	25
Drive Disc	Grade 8 cap screws with hardened washers	5/8 - 18	192	5/8 - 18	192
Adapter (or rear bracket)	Grade 5 cap screws with flat and lock washers	3/8 - 16	25	1/2-13	60
Conduit Box	Grade 5 cap screw with star type lock washer	3/8 - 16	25	1/2-13	60
PMG Stator	Grade 5 cap screws with Belleville washers	1/2-13	4	1/2-13	4
Exciter Stator	Grade 5 cap screws with Belleville washers	1/2-13	60	1/2-13	60
Exciter Armature (rotor)	Grade 8 cap screw with Belleville washer	1/2-13	84	1/2-13	84
Cooling Fan	Grade 5 cap screws with Belleville washers	1/2-13	60	1/2-13	60
Main Rotor Coil Supports	Grade 8 cap screws with Belleville washers	5/16-18	19	3/8 - 16	35
Rectifier Assembly Mounting	Grade 5 cap screws	1/4-20	4	1/4-20	4
Drive Hub Set Screw	Socket head set screw 1/4 in. hex key	1/2-13	50	1/2-13	50

NOTES: For table 12-1

All fasteners are SAE (American) standard.

All torque values are for plated hardware that is standard on the MagnaMAX.

If hardware is replaced with non-plated, refer to Table 12-2.

Always use quality hardware of the grade specified.

Main Rotor Coil Supports 570 and 740 frame only. Not used on 430 frames.

TABLE 12-2: CAPSCREW TORQUE VALUES**NOTES: Cap screws threaded into aluminum may require reductions in torque of 30% or more.**

	Cap screw Diameter and Ultimate Tensile Strength (PSI)								
	To 1/2 - 69,000 PSI To 3/4 - 64,000 PSI To 1 - 55,000 PSI			To 3/4 - 120,000 PSI To 1 - 115,000 PSI			150,000 PSI		
SAE Grade	1 OR 2			5			8		
Size (Inches) - (Thread)	Torque Ft-LB (N-M)			Torque Ft-Lb. (N-M)			Torque Ft-LB (N-M)		
	Dry	Oiled	Plated	Dry	Oiled	Plated	Dry	Oiled	Plated
1/4-20	5(7)	4.5 (6)	4(5)	8 (11)	7 (9)	6 (8)	12 (16)	11 (15)	10 (14)
1/4-28	6(8)	5.4 (7)	4.8 (6)	10 (14)	9 (12)	8 (11)	14 (19)	13 (18)	11 (15)
5/16-18	11 (15)	10 (14)	9 (12)	17 (23)	15 (20)	14 (19)	24 (33)	22 (30)	19 (26)
5/16-24	13 (18)	12 (16)	10 (14)	19 (26)	17 (23)	15 (20)	27 (37)	24 (33)	22 (30)
3/8-16	18 (24)	16 (22)	14 (19)	31 (42)	28 (38)	25 (34)	44 (60)	40 (54)	35 (47)
3/8- 24	20 (27)	18 (24)	16 (22)	35 (47)	32 (43)	28 (38)	49 (66)	44 (60)	39 (53)
7/16 - 14	28 (38)	25 (34)	22 (30)	49 (66)	44 (60)	39 (53)	70 (95)	63 (85)	56 (76)
7/16-20	30 (41)	27 (37)	24 (33)	55 (75)	50 (68)	44 (60)	78 (106)	70 (95)	62 (84)
1/2-13	39 (53)	35 (47)	31 (42)	75 (102)	68 (92)	60 (81)	105 (142)	95 (129)	84 (114)
1/2-20	41 (56)	37 (50)	33 (45)	85 (115)	77 (104)	68 (92)	120 (163)	108 (146)	96 (130)
9/16-12	51 (69)	46 (62)	41 (56)	110 (149)	99 (134)	88 (119)	155 (210)	140 (190)	124 (168)
9/16-18	55 (75)	50 (68)	44 (60)	120 (163)	108 (146)	96 (130)	170 (230)	153 (207)	136 (184)
5/8-11	83 (113)	75 (102)	66 (89)	150 (203)	135 (183)	120 (163)	210 (285)	189 (256)	168 (228)
5/8-18	95 (129)	86 (117)	76 (103)	170 (230)	153 (207)	136 (184)	240 (325)	216 (293)	192 (260)
3/4-10	105 (142)	95 (130)	84 (114)	270 (366)	243 (329)	216 (293)	375 (508)	338 (458)	300 (407)
3/4-16	115 (156)	104 (141)	92 (125)	295 (400)	266 (361)	236 (320)	420 (569)	378 (513)	336 (456)
7/8-9	160 (217)	144 (195)	128 (174)	395 (535)	356 (483)	316 (428)	605 (820)	545 (739)	484 (656)
1-14	175 (237)	158 (214)	140 (190)	435 (590)	392 (531)	348 (472)	675 (915)	608 (824)	540 (732)
1 - 8	235 (319)	212 (287)	188 (255)	590 (800)	531 (720)	472 (640)	910 (1234)	819 (1110)	728 (987)
1- 14	250 (339)	225 (305)	200 (271)	660 (895)	594 (805)	528 (716)	990 (1342)	891 (1208)	792 (1074)

TABLE 12-3:EXCITATION DATA -60 HZ - 1800 RPM

Model Number Low Volts	Exciter Field Resistance-Ohms @25°C	Exciter Field Volts F1 and F2 at regulator No Load 240/480 Volts	No Load Output Voltage With Fixed Excitation High Wye Connection®	
			12V DC	24V DC
431RSL4005	22.5	13.3	460	550
431RSL4007	22.5	14.2	450	545
432RSL4009	22.5	15.3	445	535
432RSL4011	22.5	13.5	460	550
432RSL4013	22.5	11.3	490	580
432RSL4015	22.5	13.1	440	530
432RSL4017	22.5	14.4	450	545
433RSL4019	22.5	16.9	430	525
433RSL4021	22.5	13.7	450	550
572RSL4024	23.0	16.1	440	520
572RSL4027	23.0	16.1	440	520
572RSL4028	23.0	17.5	425	510
572RSL4030	23.0	15.2	440	530
573RSL4032	23.0	15.0	445	530
573RSL4034	23.0	17.0	430	520
574RSL4036	23.0	18.2	420	510
574RSL4038	23.0	15.0	440	540
741RSL4042	22.0	14.8	445	540
741RSL4044	22.0	15.2	440	540
741RSL4046	22.0	15.6	430	540
742RSL4048	22.0	17.4	410	525
743RSL4050	22.0	13.7	460	565
743RSL4052	22.0	19.4	400	510
744RSL4054	22.1	18.6	400	510
744FSL4060	22.1	15.1	420	570
744FSL4062	22.1	16.6	410	535
Model Number Medium Volts	Exciter Field Resistance-Ohms @25°C	Exciter Field Volts F1 and F2 at Regulator No Load 4160 Volts	No Load Output Voltage With Fixed Excitation Wye Connection	
			12V DC	24V DC
573FSM4352	23.0	23.5	3100	4200
573FSM4354	23.0	20.3	3300	4400
574FSM4356	23.0	20.7	3200	4300
574FSM4358	23.0	17.3	3500	4600
741FSM4360	22.0	16.7	3600	4600
742FSM4364	22.0	15.4	3700	4700
742FSM4366	22.0	16.3	3600	4600
743FSM4368	22.1	17.7	3200	4600
743FSM4370	22.1	17.0	3500	4600

For rated load exciter field volts - see generator nameplate.

For low wye connection: divide value shown in table by 2.

For high delta connection: divide value shown in table by 1.732.

For delta connection: divide value shown in table by 1.732.

TABLE 12-4: EXCITATION DATA -50 HZ - 1500 RPM

Model Number Medium Volts	Exciter Field Resistance-Ohms @25°C	Exciter Field Volts F1 and F2 at Regulator No load @ 415 Volts	No Load Output Voltage With Fixed Excitation High Wye Connection	
			1 2V DC	24V DC
431RSL4005	22.5	15.6	380	460
431RSL4007	22.5	17.1	370	450
432RSL4009	22.5	18.0	360	445
432RSL4011	22.5	16.0	380	455
432RSL4013	22.5	13.1	400	480
432RSL4015	22.5	18.7	360	440
432RSL4017	22.5	17.4	370	450
433RSL4019	22.5	20.7	340	430
433RSL4021	22.5	16.7	360	450
572RSL4024	23.0	19.8	360	430
572RSL4027	23.0	20.0	355	430
572RSL4028	23.0	21.2	370	430
572RSL4030	23.0	18.4	360	440
573RSL4032	23.0	18.9	360	440
573RSL4034	23.0	20.7	350	430
574RSL4036	23.0	21.6	345	425
574RSL4038	23.0	17.7	365	450
741RSL4042	22.0	17.8	360	450
741RSL4044	22.0	18.1	360	450
741RSL4046	22.0	18.7	350	445
742RSL4048	22.0	20	340	440
743RSL4050	22.0	16.1	370	470
743RSL4052	22.0	22.9	330	420
744RSL4054	22.1	22.6	320	420
744FSL4060	22.1	17.0	350	470
744FSL4062	22.1	19.5	330	440
Model Number Medium Volts	Exciter Field Resistance-Ohms @25°C	Exciter Field Volts F1 and F2 at Regulator No load @ 3300 Volts	No Load Output Voltage With Fixed Excitation High Wye Connection	
			1 2V DC	24V DC
573FSM4352	23.0	21.2	2600	3400
573FSM4354	23.0	18.2	2700	3600
574FSM4356	23.0	18.4	2700	3600
574FSM4358	23.0	15.7	2800	3800
741FSM4360	22.0	15.4	3000	3800
742FSM4364	22.0	14.5	3000	3900
742FSM4366	22.0	15.6	2800	3800
743FSM4368	22.1	15.5	2800	3900
743FSM4370	22.1	15.5	2900	3800

For rated load exciter field volts - see generator nameplate.

For low wye connection: divide value shown in table by 2.

For high delta connection: divide value shown in table by 1.732. For delta connection: divide value shown in table by 1.732.

TABLE 12-5: RESISTANCE VALUES - MAIN WINDINGS

NOMINAL COLD (25°C) RESISTANCE IN OHMS

Base Model Low Voltage	Winding H-SG-	Main Stator	Main Rotor
431RSL4005	430049	.0855	.153
431RSL4007	430048	.0648	.173
432RSL4009	430046	.0418	.190
432RSL4011	430018	.0410	.186
432RSL4013	430015	.0370	.189
432RSL4015	430017	.0260	.225
432RSL4017	430016	.0240	.226
433RSL4019	430042	.0140	.286
433RSL4021	430039	.0137	.297
572RSL4024	570078	.0132	.376
572RSL4027	570072	.0126	.398
572RSL4028	570080	.0092	.423
572RSL4030	570074	.0089	.426
573RSL4032	570075	.0074	.472
573RSL4034	570076	.0059	.507
574RSL4036	570077	.0049	.584
574RSL4038	570069	.0048	.601
741 RSL4042	740040	.0045	.677
741 RSL4044	740041	.0039	.708
742RSL4046	740042	.0036	.748
742RSL4048	740043	.0030	.776
743RSL4050	740051	.0023	.889
743RSL4052	740045	.0018	.979
744RSL4054	740046	.0015	1.100
744FSL4060	740306	.0026	.892
744FSL4062	740307	.0018	1.044
Base Model Medium Voltage	Winding H-SG-	Main Stator®	Main Rotor
573FSM4352	570213	1.030	.383
573FSM4354	570214	.854	.411
574FSM4356	570215	.568	.508
741FSM4360	740230	.277	.667
742FSM4364	740204	.233	.768
742FSM4366	740206	.151	.888
743FSM4368	740207	.127	.954
743FSM4370	740208	.101	1.053

Main stator values shown are line to line on the high wye connection. For low wye connection divide value shown in table by 4.

TABLE 12-6: RESISTANCE VALUES - EXCITER WINDINGS

NOMINAL COLD (25°C) RESISTANCE IN OHMS

Low Voltage	Exciter Stator (Field)	Exciter Rotor (Armature)	PMG Stator
430 Frames	22.5	0.022	2.1
570 Frames	23.0	0.045	2.1
741 Frames	22.0	0.043	2.1
742 Frames	22.0	0.043	2.1
743 Frames	22.0	0.043	2.1
744 Frames	22.1	0.048	2.1
Medium Voltage	Exciter Stator (Field)	Exciter Rotor (Armature)	PMG Stator
570 Frames	23.0	0.070	2.1
741 Frames	22.0	0.043	2.1
742 Frames	22.0	0.043	2.1
743 Frames	22.1	0.048	2.1