

OPERATION AND PARTS MANUAL



ULTRA-SILENT™ SERIES MODEL DCA-45USI 50/60 Hz GENERATOR Australia

PARTS LIST NO. M1871400004B

Revision #0 (07/19/05)

To find the latest revision of this
publication, visit our website at:
www.mqpower.com



THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.

**WARNING**

CALIFORNIA — Proposition 65 Warning
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL
NUMBER *ON-HAND* WHEN CALLING

MQ POWER CORPORATE OFFICE

18910 Wilmington Ave.

800-421-1244

Carson, CA 90746

FAX: 310-632-2656

Email: mqpower@multiquip.com

Internet: www.mqpower.com

PARTS DEPARTMENT

800-427-1244

FAX: 800-672-7877

310-537-3700

FAX: 310-637-3284

SERVICE DEPARTMENT

800-835-2551

FAX: 310-638-8046

310-537-3700

TECHNICAL ASSISTANCE

800-478-1244

FAX: 310-631-5032

WARRANTY DEPARTMENT

800-835-2551, EXT. 279

FAX: 310-638-8046

310-537-3700, EXT. 279

© COPYRIGHT 2005, MULTIQUIP INC.

Multiquip Inc, MQ Power Inc, Ultra-Silent series, the MQ logo and the MQ Power logo are registered trademarks of Multiquip Inc. and may not be used, reproduced, or altered without written permission. All other trademarks are the property of their respective owners and used with permission.

This manual **MUST** accompany the equipment at all times. This manual is considered a permanent part of the equipment and should remain with the unit if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Illustrations are based on the *DCA-45USI (50/60 Hz) Ultra Silent Generator*. Multiquip Inc. reserves the right to discontinue or change specifications, design or the information published in this publication at any time without notice and without incurring any obligations.

**To find the latest revision of this
publication, visit our website at:
www.mqpower.com**




MQ POWER DCA-45USI AC GENERATOR

Here's How To Get Help	3
Table Of Contents	4
Parts Ordering Procedures	5
DCA-45USI (50/60 Hz) Specifications	6
Dimensions	7
Safety Message Alert Symbols	8-9
Rules for Safe Operation	10-13
Generator Decals	14-15
Installation	16-17
General Information	18
Major Components	19
Generator Control Panel	20
Engine Operating Panel	21
Output Terminal Panel Familiarization	22-24
Load Application	25
Generator Outputs	26
Gauge Reading	27
Output Terminal Panel Connections	28-29
Pre-setup	30-33
Generator Start-up Procedure	34-36
Generator Shut-down Procedure	37
Maintenance (Engine)	38-39
Trailer Maintenance	40-43
Trailer Wiring Diagram	44
Engine Wiring Diagram	45-46
Generator Wiring Diagram	47
Generator Troubleshooting	48
Explanation of Codes in Remarks Column	50
Suggested Spare Parts	51

COMPONENT DRAWINGS

Generator Assembly	52-53
Control Box Assembly	54-57
Engine & Radiator Assembly	58-61
Output Terminal Assembly	62-63
Battery Assembly	64-65
Muffler Assembly	66-67
Fuel Tank Assembly	68-69
Enclosure Assembly	70-75
Rubber Seal Assembly	76-77
Nameplate and Decals	78-79
Terms and Condition of Sale — Parts	80



Specification and part number
are subject to change without
notice.

DCA-45USI (50/60 Hz) — PARTS ORDERING PROCEDURES

When ordering parts, please supply the following information:

- ☐ Dealer account number
- ☐ Dealer name and address
- ☐ Shipping address (if different than billing address)
- ☐ Return fax number
- ☐ Applicable model number
- ☐ Quantity, part number and description of each part
- ☐ Specify preferred method of shipment:
 - ✓ FedEx or UPS Ground
 - ✓ FedEx or UPS Second Day or Third Day
 - ✓ FedEx or UPS Next Day
 - ✓ Federal Express Priority One
 - ✓ DHL
 - ✓ Truck

Note: Unless otherwise indicated by customer, all orders are treated as "Standard Orders", and will ship within 24 hours. We will make every effort to ship "Air Shipments" the same day that the order is received, if prior to 2PM west coast time. "Stock Orders" must be so noted on fax or web forms.



Here's how to get help...

Please have the model and serial number on hand when calling.

MQ POWER CORPORATE OFFICE

18910 Wilmington Ave. 800-421-1244
Carson, CA 90746 FAX: 310-632-2656
Email: mqpower@multiquip.com
Internet: www.mqpower.com

PARTS DEPARTMENT

800-427-1244 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

SERVICE DEPARTMENT

800-835-2551 FAX: 310-638-8046
310-537-3700

TECHNICAL ASSISTANCE

800-478-1244 FAX: 310-631-5032

WARRANTY DEPARTMENT

800-835-2551, EXT. 279 FAX: 310-638-8046
310-537-3700, EXT. 279

Place Your Parts Order Via Web or Fax For Even More Savings!

(Domestic USA Dealers Only)

Extra Discounts!

All parts orders which include complete part numbers and are received by our automated web parts order system, or by fax qualify for the following extra discounts:

Ordered via	Standard orders	Stock orders (\$750 list and above)
Fax	3%	10%
Web	5%	10%

Special freight allowances when you order 10 or more line items via Web or Fax! **

FedEx Ground Service **at no charge for freight**

No other allowances on freight shipped by any other carrier.

****Common nuts, bolts and washers (all items under \$1.00 list price) do not count towards the 10+ line items.**

NOTE: DISCOUNTS ARE SUBJECT TO CHANGE



MQPOWER
A Division of Multiquip Inc.
POST OFFICE BOX 6254
CARSON, CA 90749
310-537-3700 • 800-421-1244
FAX: 310-632-2656
E-MAIL: mqpower@multiquip.com
INTERNET: www.mqpower.com

Direct TOLL-FREE access to our Parts Department:

Toll-free nationwide — 800-427-1244

Toll-free FAX — 800-6-PARTS-7 (800/672-7877)

DCA-45USI (50/60 Hz)— SPECIFICATIONS

Table 1. Generator Specifications

Model	DCA-45USI	
Type	Revolving field, self ventilated, open protected type synchronous generator	
Armature Connection	Star with Neutral	Zig Zag
Phase	3	Single
Standby Output	38.9 KVA (31.0 KW) @50 Hz 47.3 KVA (37.8 KW) @60 Hz	23.1 KW @50 Hz 27.3 KW @60 Hz
Prime Output	37 KVA (29.6 KW) @50 Hz 45 KVA (36 KW) @60 Hz	21 KW @50 Hz 26 KW @60 Hz
Voltage	200V or 400V@50 Hz 240V or 480V@60 Hz	200/100V@50 Hz 240/120V@60 Hz
Frequency	50/60 Hz	
Speed	1500 rpm (50 Hz)/1800 rpm (60 Hz)	
Power Factor	0.8	1
Aux. AC Power	Single Phase, 60 Hz	
Voltage	100 VAC @50 Hz/120 VAC @60 Hz	
Output	4.8 KW (2.4 KW x 2)	

Table 2. Engine Specifications

Model	ISUZU BB-4JG1T	
Type	4 Cycle, water-cooled, direct injection, turbocharged	
No. of Cylinders	4 cylinders	
Bore x Stroke	3.76 in. x 4.21 in. (95.4 mm x 107 mm)	
Rated Output	55.3 HP/1,800 rpm	
Displacement	187 cu. in. (3,059 cc)	
Starting	Electric	
Coolant Capacity	3.6 gal. (13.7 liters)	
Lube Oil Capacity	2.64 gal. (10.0 liters)	
Fuel Consumption	2.6 gal. (9.84 L)/hr at full load	1.97 gal. (7.47 L)/hr at 3/4 load
	1.43 gal. (5.42 L)/hr at 1/2 load	0.87 gal. (3.3 L)/hr at 1/4 load
Battery	12V - BCI Group 27	
Fuel	#2 Diesel Fuel	

DCA-45USI (50/60 Hz)— DIMENSIONS (SIDE AND FRONT)





TABLE 3. DIMENSIONS			
Reference Letter	Dimension ft. (mm.)	Reference Letter	Dimension in. (mm.)
A	30.55 in. (776 mm.)	F	82.28 in. (2,090 mm.)
B	24.37 in. (619 mm.)	G	61 in. (1,550 mm.)
C	30.16 in. (766 mm.)	H	37.40 in. (950 mm.)
D	24.37 in. (619 mm.)		
E	30.16 in. (766 mm.)		

DCA-45USI (50/60 Hz)— SAFETY MESSAGE ALERT SYMBOLS

FOR YOUR SAFETY AND THE SAFETY OF OTHERS!

Safety precautions should be followed at all times when operating this equipment. Failure to read and understand the Safety Messages and Operating Instructions could result in injury to yourself and others.



This **Operation and Parts** Manual has been developed to provide complete instructions for the safe and efficient operation of the MQ Power **Model DCA-45USI(50/60Hz) UltraSilent™ Generator**.

Before using this generator, ensure that the operating individual has read and understands all instructions in this manual.

SAFETY MESSAGE ALERT SYMBOLS

The three (3) Safety Messages shown below will inform you about potential hazards that could injure you or others. The Safety Messages specifically address the level of exposure to the operator, and are preceded by one of three words: **DANGER**, **WARNING**, or **CAUTION**.

DANGER

You **WILL** be **KILLED** or **SERIOUSLY** injured if you do not follow directions.

WARNING

You **COULD** be **KILLED** or **SERIOUSLY** injured if you do not follow directions.

CAUTION

You **CAN** be injured if you do not follow directions

HAZARD SYMBOLS

Potential hazards associated with the operation of this equipment will be referenced with "**Hazard Symbols**" which appear throughout this manual, and will be referenced in conjunction with Safety "**Message Alert Symbols**".

WARNING - LETHAL EXHAUST GASES



Gasoline engine exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause **DEATH** if inhaled. **NEVER** operate this equipment in a confined area or enclosed structure that does not provide ample free flow air.

WARNING - EXPLOSIVE FUEL



Gasoline is extremely flammable, and its vapors can cause an explosion if ignited. **DO NOT** start the engine near spilled fuel or combustible fluids. **DO NOT** fill the fuel tank while the engine is running or hot.

DO NOT overfill tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system. Store fuel in approved containers, in well-ventilated areas and away from sparks and flames. **NEVER** use fuel as a cleaning agent.

WARNING - BURN HAZARDS



Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operations. **NEVER** operate the engine with heat shields or heat guards removed.

DANGER - ELECTROCUTION HAZARDS

During operation of this generator, there exists the possibility of **electrocution, electrical shock or burn**, which can cause **severe bodily harm** or even **DEATH!**



DCA-45USI (50/60 Hz)— SAFETY MESSAGE ALERT SYMBOLS

WARNING - ROTATING PARTS



NEVER operate equipment with covers, or guards removed. Keep ***fingers, hands, hair*** and clothing away from all moving parts to prevent injury.

CAUTION - RESPIRATORY HAZARDS



ALWAYS wear approved ***respiratory*** protection.

CAUTION - ACCIDENTAL STARTING



ALWAYS place the **Engine ON/OFF** switch in the **OFF** position and remove the ignition key when the pump is not in use.

CAUTION - SIGHT AND HEARING HAZARDS



ALWAYS wear approved ***eye*** and ***hearing*** protection.



CAUTION - OVER-SPEED CONDITIONS



NEVER tamper with the factory settings of the engine governor or settings. Personal injury and damage to the engine or equipment can result if operating in speed ranges above maximum allowable.

CAUTION - EQUIPMENT DAMAGE MESSAGES

Other important messages are provided throughout this manual to help prevent damage to your generator, other property, or the surrounding environment.



This generator, other property, or the surrounding environment could be damaged if you do not follow instructions.

DCA-45USI (50/60 Hz)— RULES FOR SAFE OPERATION

DANGER - READ THIS MANUAL!

Failure to follow instructions in this manual may lead to **serious injury** or even **DEATH**! This equipment is to be operated by trained and qualified personnel only! This equipment is for industrial use only.

The following safety guidelines should always be used when operating the **DCA-70USI (50/60 Hz) Ultra Silent™ Generator**.

General Safety:

- **DO NOT** operate or service this equipment before reading this entire manual.



The operator **MUST BE** familiar with proper safety precautions and operations techniques before using generator.

- This equipment should not be operated by persons under 18 years of age.
- **NEVER** operate this equipment without proper protective clothing, shatterproof glasses, steel-toed boots and other



protective devices required by the job.

- **NEVER** operate this equipment when not feeling well due to fatigue, illness or taking medicine.



- **NEVER** operate this equipment under the influence or



drugs or alcohol.

- **NEVER** use accessories or attachments, which are not recommended by MQ Power for this equipment. Damage to the equipment and/or injury to user may result.
- Manufacturer does not assume responsibility for any accident due to equipment modifications. Unauthorized equipment modification will void all warranties.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult read.

- **ALWAYS** check the machine for loosened threads or bolts before starting.


- **NEVER** operate the generator in an explosive atmosphere or near combustible materials. An explosion or fire could result causing severe **bodily harm or even death**.

- **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing engine or generator.



- **High Temperatures** – Allow the engine to cool before performing service and maintenance functions. Contact with **hot!** components can cause serious burns.

- The engine of this generator requires an adequate free flow of cooling air. **NEVER** operate the generator in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause serious damage to the generator or engine and may cause injury to people. The generator engine gives off **DEADLY** carbon monoxide gas.



- **DO NOT** place hands or fingers inside generator engine compartment when engine is running.
- **NEVER** run engine without air filter. Severe engine damage may occur.
- **DO NOT** leave the generator running in the **manual mode** unattended.
- Refer to the **ISUZU Engine Owner's Manual** for engine technical questions or information.
- **ALWAYS** store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children.

DCA-45USI (50/60 Hz)— RULES FOR SAFE OPERATION

Generator Grounding

To guard against electrical shock and possible damage to the equipment, it is important to provide a good **EARTH** ground.

Article 250 (Grounding) of the **National Electrical Code** (NEC) provides guide lines for proper grounding and specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

The following safety recommendations should also be followed:

- **ALWAYS** make sure generator is properly grounded.
- **NEVER** use gas piping as an electrical ground.
- **ALWAYS** make sure that electrical circuits are properly **grounded** per the **National Electrical Code** (NEC) and local codes before operating generator. Severe **injury** or **DEATH!** by electrocution can result from operating an ungrounded generator.
- **ALWAYS** be sure to use the ground terminal (green wire) when connecting a load to the U,V, and W output terminal lugs.

Electrical Safety

- **ALWAYS** have a qualified electrician perform the generator wiring installation.
- **ALWAYS** make sure generator installation is accordance with the **National Electrical Code** (NEC) and local codes before operating generator.
- **NEVER** use a defective or frayed power cable. Check the cable for cuts in the insulation.
- **NEVER** use a extension cord that is frayed or damaged where the insulation has been cut.
- **ALWAYS** make certain that proper extension cord has been selected for the job. See Table 6.
- **NEVER** power cables or cords **lay in water**.
- **NEVER stand in water** while AC power from the generator is being transfer to a load.



DANGER - ELECTROCUTION HAZARDS


During operation of this generator, there exists the possibility of **electrocution**, **electrical shock or burn**, which can cause **severe bodily harm** or even **DEATH!**




To avoid these hazards:

NEVER use damaged or worn cables when connecting equipment to the generator. Make sure power connecting cables are securely connected to the generator's output terminals, insufficient tightening of the terminal connections may cause damage to the generator and electrical shock.


NEVER grab or touch a live power cord with wet hands.



NEVER touch output terminals during operation. This is extremely dangerous. **ALWAYS** stop the machine and place the circuit breaker in the **OFF** position when contact with the output terminals is required.



Backfeed to a utility system can cause **electrocution** and or property damage. **DO NOT** connect to any building's electrical system except through an approved device or after building main switch is opened. **ALWAYS** have a licensed electrician perform the installation



DCA-45USI (50/60 Hz)— RULES FOR SAFE OPERATION

Maintenance Safety

- The electrical voltage required to operate the generator can cause severe injury or even death through physical contact with live circuits. Turn all circuit breakers **OFF** before performing maintenance on the generator.
- **NEVER** lubricate components or attempt service on a running machine.
- **ALWAYS** disconnect the **NEGATIVE battery terminal** before performing service on the generator.
- Follow all Battery Safety Guidelines listed in this manual when handling or servicing the generator.
- **ALWAYS** allow the machine a proper amount of time to cool before servicing.
- Keep the machinery in proper running condition.
- Fix damage to the machine immediately and always replace broken parts.
- **ALWAYS** service air cleaner frequently to prevent engine malfunction.

WARNING - BURN HAZARDS

To prevent burns, **DO NOT** touch or open any of the below mentioned components while the engine is running or immediately after operations. Always allow sufficient time for the engine and generator to cool before performing maintenance.




- **Radiator Cap** - Removing the radiator cap while the engine is hot will result in high pressurized, boiling water to gush out of the radiator, causing severe scalding to any persons in the general area of the generator.
- **Coolant Drain Plug** - Removing the coolant drain plug while the engine is hot will result in hot coolant gushing out of the coolant drain plug, therefore causing severe scalding to any persons in the general area of the generator.
- **Engine Oil Drain Plug** - Removing the engine oil drain plug while the engine is hot will result in hot oil gushing out of the oil drain plug, therefore causing severe scalding to any persons in the general area of the generator.

Battery Safety

Use the following guidelines when handling the battery:


- The battery contains acids that can cause injury to the eyes and skin. To avoid eye irritation, **always** wear safety glasses.
- Use well insulated gloves when picking up the battery.



DANGER - EXPLOSION HAZARDS

The risk of an explosion exists when performing service on the battery. To avoid **severe injury** or **DEATH**:

- **DO NOT** drop the battery. There is the possibility of risk that the battery may explode.
- **DO NOT** expose the battery to open flames, sparks, cigarettes etc. The battery contains combustible gases and liquids. If these gases and liquids come in contact with a flame or spark, an explosion could occur.



- **ALWAYS** keep the battery charged. If the battery is not charged a buildup of combustible gas will occur.
- **ALWAYS** keep battery charging and cables in good working condition. Repair or replace all worn cables.
- **ALWAYS** recharge the battery in an vented air environment, to avoid risk of a dangerous concentration of combustible gases.
- In case the battery liquid (dilute sulfuric acid) comes in contact with **clothing or skin**, rinse skin or clothing immediately with plenty of water.
- In case the battery liquid (dilute sulfuric acid) comes in contact with your **EYES**, rinse eyes immediately with plenty of water and contact the nearest doctor or hospital to seek medical attention.

DCA-45USI (50/60 Hz)— RULES FOR SAFE OPERATION

Towing & Transporting Safety

To reduce the possibility of an accident while transporting the generator on public roads, always make sure the trailer that supports the generator and the towing vehicle are in good operating condition and both units are mechanically sound.

The following list of safety precautions should be followed when towing your generator:

CAUTION - FOLLOW TOWING REGULATIONS



Check with your local county or state safety towing regulations, in addition to meeting **Department of Transportation (DOT) Safety Towing Regulations**, before towing your generator.

- **ALWAYS** shutdown engine before transporting.
- Tighten both fuel tank caps securely.
- If generator is mounted on a trailer, make sure trailer complies with all local and state safety transportation laws. Follow the listed **Towing & Transporting Safety** guidelines for basic towing techniques.
- Make sure the hitch and coupling of the towing vehicle are rated equal to, or greater than the trailer "gross vehicle weight rating."
- **ALWAYS** inspect the hitch and coupling for wear. **NEVER** tow a trailer with defective hitches, couplings, chains etc.
- Check the tire air pressure on both towing vehicle and trailer. **Trailer tires should be inflated to 50 psi cold.** Also check the tire tread wear on both vehicles.
- **ALWAYS** make sure the trailer is equipped with a "Safety Chain".
- **ALWAYS** attach trailer's safety chains to towing vehicle properly.
- **ALWAYS** make sure the vehicle and trailer directional, backup, brake, and trailer lights are connected and working properly.
- DOT Requirements include the following:
 - Connect and test electric brake operation.
 - Secure portable power cables in cable tray with tie wraps.

- The maximum speed for highway towing is **55 MPH** unless posted otherwise. Recommended off-road towing is not to exceed **15 MPH** or less depending on type of terrain.
- Place **chock blocks** underneath wheel to prevent **rolling**, while parked.
- Use the trailer's swivel jack to adjust the trailer height to a level position while parked.
- Avoid sudden stops and starts. This can cause skidding, or jack-knifing. Smooth, gradual starts and stops will improve towing.
- Avoid sharp turns.
- Trailer should be adjusted to a level position at all times when towing.
- Raise and lock trailer wheel stand in up position when transporting.
- Place **support blocks** underneath the trailer's bumper to prevent **tipping**, while parked.
- Avoid sharp turns to prevent rolling.
- **DO NOT** transport generator with fuel in tank.

Emergencies

- **ALWAYS** know the location of the nearest **fire extinguisher**.
- **ALWAYS** know the location of the nearest and **first aid kit**.
- **ALWAYS** know the location of the nearest phone or **keep a phone on the job site**, in case of emergencies.
- **ALWAYS** have easy access to the phone numbers of the nearest **Ambulance, Doctor** and **Fire Department**. This information will be invaluable in the case of an emergency.



DCA-45USI (50/60 Hz)— GENERATOR DEC.

The **DCA-45USI (50/60 Hz) Ultra Silent™ Generator** is equipped with a number of safety decals (Figures 2 and 3). These decals are provided for operator safety and maintenance information. The illustration below and on the preceding page show the decals as they appear on the machine. Should any of these decals become unreadable, replacements can be obtained from your dealer.

OPERATING PROCEDURES

Manual Starting

1. Check the engine oil, coolant, and fuel levels. Replenish if necessary.
2. Place all Generator Circuit Breakers in the "OFF" position and close all doors.
3. Check that the Voltage select switch (or the Voltage change-over board) is present at desired voltage.
4. (In case of generator having multiple voltage ratings.)
5. Set the Engine speed switch to the "LOW" position.
6. Turn the Auto-Off/Reset-Manual switch to the "Manual" position to start the engine. If the engine fails to start in the specified number of attempts, the overcrank lamp will indicate and the Auto-Off/Reset-Manual switch must be returned to the "Off/Reset" position before proceeding.
7. When the engine is ready for starting during cold weather operating conditions, push the Intake Heater button for approximately 30 seconds. Start engine using the Auto-Off/Reset-Manual switch to the "Manual" position. As soon as the engine starts, release the button.
8. If the engine still does not start, utilize the water heater until water is warm. (If additional water heater is supplied.)
9. After starting, allow the engine to run for 1 or 2 minutes to warm-up. At temperatures below freezing, this time period must be extended to 2 to 4 minutes.
10. When the engine starts, immediately check for abnormal noise, vibration, fluid leakage or any indication of a problem. Check the control panel gauges. If all is normal, let the engine remain at the "Low" position for a short time, depending on the ambient conditions, warm up.
11. After sufficient warm-up time has elapsed, set the Engine speed switch to the "High" position and the unit is ready for operation.
12. Check the NO Load speed as shown in the table below. 60Hz operation—Approx. 60.0Hz (1800rpm)
13. Adjust the Voltage Regulator to the specified voltage.

M35200010

P/N M3552000103

SAFETY INSTRUCTIONS

Improper operation of this machine can cause severe injury or death.

- Read the instruction manual carefully before operating or servicing.

This machine should only be operated by a person with sufficient knowledge and skill to ensure safe operation.

High voltage circuits are located inside the output terminal cover and control panel.


- Close the cover and control panel before operating.

Moving parts and hot surfaces are contained within the enclosure.


- Close all doors and lock them before operating.

M92010030


P/N M9520100304



P/N M9520000104




P/N M9520000204




P/N M950000004



P/N M9510200002



P/N M9520200104



P/N M9500300104



P/N M9500300004



P/N M9500500004



P/N M9503000103

Figure 2. Generator Decals

DCA-45USI (50/60 Hz)— GENERATOR DECALS

	⚠ WARNING	⚠ WARNING	⚠ WARNING
	ELECTRIC SHOCK HAZARD - Do not touch output terminals when this machine is operating. - Turn power off before servicing.	ELECTRIC SHOCK HAZARD Always complete the grounding path from the ground terminal on this genset to an external grounding source. See instruction manual for details.	- Before connecting this generator to any building's electrical system, a licensed electrician must install an isolation (transfer) switch. - Serious injury or death may result without this transfer switch.

M9520100503

P/N M9520100503

	⚠ WARNING
	HOT COOLANT can cause severe burns. Do not remove cap if radiator is hot.

M90310000

P/N M9503100004

	⚠ WARNING
	ENGINE EXHAUST can cause severe injury or death. Use only in open, well ventilated areas or vent exhaust outside.

M90320000

P/N M9503200004

DANGER
HIGH VOLTAGE

M9520100401

P/N M9520100404

⚠ CAUTION
Stop engine before switching

M9520100204

P/N M9520100204

	⚠ CAUTION
	MOVING PARTS can cause severe injury. - Do not operate with doors open. - Stop engine before servicing.

M90300000

P/N M9503000004

NOTE
To use 50 amp receptacles, adjust the voltage selector switch to the single phase position and the main line circuit breaker to the on position.

P/N M1500020

P/N M1550000204

	⚠ CAUTION
	HOT PARTS can burn skin. - Do not touch until the machine has sufficiently cooled.

M91010000

P/N M9510100004

	⚠ WARNING
	ELECTRIC SHOCK HAZARD - Do not touch output terminals while this machine is operating. - Turn power off before servicing.

P/N M9520100503

	⚠ WARNING
	ELECTRIC SHOCK HAZARD - Do not touch internal wiring or connections while this machine is operating. - Turn power off before servicing.

M92010000

P/N M9520100004

Figure 3. Generator Decals (Cont inued)




Figure 4. Typical Generator Grounding Application

Outdoor Installation

Install the generator in a area that is free of debris, bystanders, and overhead obstructions. Make sure the generator is on secure level ground so that it cannot slide or shift around. Also install the generator in a manner so that the exhaust will not be discharged in the direction of nearby homes.

The installation site must be relatively free from moisture and dust. All electrical equipment should be protected from excessive moisture. Failure to do will result in deterioration of the insulation and will result in short circuits and grounding.

Foreign materials such as dust, sand, lint and abrasive materials have a tendency to cause excessive wear to engine and alternator parts.



CAUTION - EXHAUST HAZARD

Pay close attention to ventilation when operating the generator inside tunnels and caves. The engine exhaust contains noxious elements. Engine exhaust must be routed to a ventilated area.

Indoor Installation

Exhaust gases from diesel engines are extremely poisonous. Whenever an engine is installed indoors the exhaust fumes must be vented to the outside. The engine should be installed at least two feet from any outside wall. Using an exhaust pipe which is too long or too small can cause excessive back pressure which will cause the engine to heat excessively and possibly burn the valves.

Mounting

The generator must be mounted on a solid foundation (such as concrete) and set firmly on the foundation to isolate vibration of the generator when it is running. The generator must set at least 6 inches above the floor or grade level (in accordance to NFPA 110, Chapter 5-4.1). **DO NOT** remove the metal skids on the bottom of the generator. They are to resist damage to the bottom of the generator and to maintain alignment.



Generator Grounding

To guard against electrical shock and possible damage to the equipment, it is important to provide a good **EARTH** ground.

Article 250 (Grounding) of the National Electrical Code (NEC) provides guide lines for proper grounding and specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

NEC articles 250-64(b) and 250-66 set the following grounding requirements:

1. Use one of the following wire types to connect the generator to earth ground.
 - a. Copper - 10 AWG (5.3 mm²) or larger.
 - b. Aluminum - 8 AWG (8.4 mm²) or larger.
2. When grounding the generator (Figure 4) connect the ground cable between the lock washer and the nut on the generator and tighten the nut fully. Connect the other end of the ground cable to earth ground.
3. NEC article 250-52(c) specifies that the earth ground rod should be buried a minimum of 8 ft. into the ground.



When connecting the generator to any buildings electrical system **ALWAYS** consult with a licensed electrician.

DCA-45USI (50/60 Hz) FAMILIARIZATION

Generator

The MQ Power Model DCA-45USI (50/60 Hz) generator can provide 29.6 kW for 50 Hz operation and 36 kW for 60 Hz operation. This generator (Figure 5) is designed as a high quality portable (requires a trailer for transport) power source for telecom sites, lighting facilities, power tools, submersible pumps and other industrial and construction machinery.

Engine Operating Panel

The "Engine Operating Panel" is provided with the following:

- Tachometer
- Emergency Stop Button
- Water Temperature Gauge/ Alarm Lamp
- Oil Pressure Gauge/ Alarm Lamp
- Charging Ammeter Gauge
- Pre-Heat Lamp
- Panel Light
- Panel Light Switch
- Ignition/Preheat Switch
- Fuel Gauge
- Fuel Filter Water Level Alarm Lamp

Generator Control Panel

The "Generator Control Panel" is provided with the following:

- Output Voltage Adjustment Knob
- Frequency Meter (Hz)
- AC Ammeter (Amps)
- AC Voltmeter (Volts)
- Ammeter Change-Over Switch
- Voltmeter Change-Over Switch
- Voltage Regulator
- 3-Pole, 110 amp Main Circuit Breaker

Output Terminal Panel

The "Output Terminal Panel" is provided with the following:

- Three auxilliary output receptacles (CS-6369), 50 amps
- Three auxilliary circuit breakers, @50 amps
- Two GFCI output receptacles, 20 amps
- Two GFCI circuit breakers @ 20amps
- Five output terminal lugs (3Ø power)

Control Box

The "Control Box" is provided with the following:

- Automatic Voltage Regulator (AVR)
- Current Transformer
- Emergency Relay
- Over-Current Relay
- 50 Hz Rheostat (1500 rpm engine speed adjust)
- 60 Hz Rheostat (1800 rpm engine speed adjust)
- Frequency Select Switch (50/60 Hz)

Open Delta Excitation System

The DCA-45USI (50/60 Hz) generator is equipped with the state of the art "**Open-Delta**" excitation system. The open delta system consist of an electrically independent winding wound among stationary windings of the AC output section.

There are four connections of the open delta A, B, C and D. During steady state loads, the power from the voltage regulator is supplied from the parallel connections of A to B, A to D, and C to D. These three phases of the voltage input to the voltage regulator are then rectified and are the excitation current for the exciter section.

When a heavy load, such as a motor starting or a short circuit occurs, the automatic voltage regulator (AVR) switches the configuration of the open delta to the series connection of B to C. This has the effect of adding the voltages of each phase to provide higher excitation to the exciter section and thus better voltage response during the application of heavy loads.

The connections of the AVR to the AC output windings are for sensing only. No power is required from these windings.

The open-delta design provides virtually unlimited excitation current, offering maximum motor starting capabilities. The excitation does not have a "**fixed ceiling**" and responds according the demands of the required load.

Engine

The **DCA-45USI** (50/60 Hz) is powered by a 4 cycle, water cooled, turbocharged **ISUZU Model BB-4JG1T Diesel Engine**. This engine is designed to meet every performance requirement for the generator. Reference Table 1 for engine specifications.

In keeping with MQ Power's policy of constantly improving its products, the specifications quoted herein are subject to change without prior notice.

Mechanical Governor System

The mechanical governor system control the RPM of the engine. When the engine demands increase or decrease, the mechanical governor system regulates the frequency variation to within $\pm 5\%$. The electronic governor option decreases the frequency variation to within $\pm 0.25\%$.

Extension Cables

When electric power is to be provided to various tools or loads at some distance from the generator, extension cords are normally used. Cables should be sized to allow for distance in length and amperage so that the voltage drop between the generator and point of use (load) is held to a minimum. Use the cable selection chart (Table 6) as a guide for selecting proper extension cable size.

DCA-45USI (50/60 Hz)— MAJOR COMPONENTS





Figure 5. Major Components

Table 4. Generator Major Components

ITEM NO.	DESCRIPTION
1	Muffler Assembly
2	Engine Assembly
3	Air Cleaner Assembly
4	Generator Assembly
5	Output Terminal Assembly
6	Fuel Tank Assembly
7	Battery Assembly
8	Generator Control Panel Assembly
9	Engine Operating Panel Assembly

DCA-45USI (50/60 Hz)— GENERATOR CONTROL PANEL




Figure 6. Generator Control Panel


The definitions below describe the controls and functions of the DCA-45USI (50/60 Hz) **Generator Control Panel** (Figure 6).

1. **Main Circuit Breaker** – This three-pole, 110 amp main breaker is provided to protect the **U, V, and W Output Terminal Lugs** from overload.
2. **AC Ammeter** – Indicates the amount of current the load is drawing from the generator per leg selected by the ammeter phase-selector switch.
3. **Ammeter Change-Over Switch** – This switch allows the AC ammeter to indicate the current flowing to the load connected to any phase of the output terminals, or to be switched off. This switch does not effect the generator output in any fashion, it is for current reading only.
4. **Voltmeter Change-Over Switch** – This switch allows the AC voltmeter to indicate phase to phase voltage between any two phases of the output terminals or to be switched off.
5. **Voltage Regulator Control** – Allows $\pm 15\%$ manual adjustment of the generator's output voltage.
6. **Frequency Meter** – Indicates the output frequency in hertz (Hz). Normally 50 or 60 Hz.
7. **AC Voltmeter** – Indicates the output voltage present at the **U, V, and W Output Terminal Lugs**.

Located behind the generator control panel is the **Generator Control Box**. This box contains some of the necessary electronic components required to make the generator function.

The **Control Box** is equipped with the following major components:

- Over-Current Relay
- Automatic Voltage Rectifier (AVR)
- Starter Relay
- Engine Controller (Computer Controlled)
- Current Transformer
- Voltage Selector Switch
- 50 Hz Engine Speed Rheostat (1500 RPM's)
- 60 Hz Engine Speed Rheostat (1800 RPM's)



Remember the **overcurrent relay** monitors the current flowing from the **U, V, and W Output Terminal Lugs** to the load.

In the event of a short circuit or over current condition, it will automatically trip the 110 amp main breaker.

To restore power to the **Output Terminal Panel**, press the **reset** button on the overcurrent relay and place the **main** circuit breaker in the **closed** position (ON).

DCA-45USI (50/60 Hz)— ENGINE OPERATING PANEL

The definitions below describe the controls and functions of the DCA-45USI (50/60 Hz) "**Engine Operating Panel**" (Figure 7).

1. **Panel Light** - Normally used in dark places or at night. When activated, panel will luminate. When the generator is not in use, turn the panel light switch to the **OFF** position.
2. **Panel Light Switch**- When activated, will turn on control panel light.
3. **Oil Pressure Lamp** - Indicates that the oil pressure is too low and will shut down the engine.
4. **Water Temperature Lamp** - Indicates that the water temperature is too hot and will shut down the engine.
5. **Fuel Filter Water Level Alarm Lamp** - This lamp turns on when water in the filter is detected. Drain the water in the fuel filter strainer to correct the problem.
6. **Pre-heat Lamp** - This indicates when the engine has been preheated and is ready for starting. In cold weather conditions, it may be several minutes before the lamp illuminates.
7. **Fuel Leak Detected Alarm** - This indicates that liquid is present in the fuel tank containment basin. Drain the containment basin and repair any leaks.
8. **Tachometer** - Indicates engine speed in RPM's. For 1500 rpm's the meter should indicate 50 Hz and 1800 rpm's for 60 Hz operation when the rated load is applied. In addition a built in hour meter will record the number of operational hours that the generator has been in use.
9. **Fuel Gauge** - Indicates amount of diesel fuel available.
10. **Charging Ammeter Gauge** - Indicates the current being supplied by the engine's alternator which provides current for generator's control circuits and battery charging system.
11. **Water Temperature Gauge** - During normal operation this gauge should read between 165° F to 203° F.
12. **Oil Pressure Gauge** - Normal operation should be about 28 to 71 psi. When starting the generator the oil pressure may read a bit higher, but after the engine warms up the oil pressure should return to normal.
13. **Starter Switch** - Three position switch, stop, preheat/run and start. Insert ignition key to start and stop engine.
14. **Emergency Stop Button** - In the event of an emergency, press this button to shutdown the generator. Pull button outward when re-starting the generator.





Figure 7. Engine Operating Panel

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL PANEL FAMILIARIZATION

Output Terminal Panel

The **Output Terminal Panel** (Figure 8) shown below is located on the right-hand side (left from control panel) of the generator. Lift up on the cover to gain access to receptacles and terminal lugs.



Terminal legs “O” and “Ground” are considered **bonded grounds**.

Output Terminal Familiarization

The “**Output Terminal Panel**” (Figure 8) is provided with the following:

- Three 100/200V output receptacles, 50 amp @ 50 Hz
- Three 120/240V output receptacles 50 amp @ 60 Hz
- Three Circuit Breakers @ 50 amps
- Two 100V GFCI receptacles, 20 amp @ 50 Hz
- Two 120V GFCI receptacles, 20 amp @ 60 Hz
- Two GFCI Circuit Breakers @ 20 amps
- Five Output Terminal Lugs (U, V, W, O, Ground)




Figure 8. Output Terminal Panel

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL PANEL FAMILIARIZATION

GFCI Receptacles

There are two 20 amp GFCI (Duplex Nema 5-20R) receptacles (Figure 9) provided on the output terminal panel. These receptacles can be accessed in **any voltage selector switch** position. Each receptacle is protected by a 20 amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) of both GFCI receptacles is dependent on the load requirements of the U, V, and W output terminal lugs.

Pressing the **reset** button resets the GFCI receptacle after being tripped. Pressing the **Test Button** (See Figure 9) in the center of the receptacle will check the GFCI function. Both receptacles should be tested at least once a month.

100 VAC @ 50 Hz
120 VAC @ 60 Hz
G.F.C.I.

RECEPTACLE




Figure 9. G.F.C.I. Receptacle

Twist Lock Dual Voltage Auxilliary Receptacles

There are three 50 amp auxilliary twist-lock (CS-6369) receptacles (Figure 10) provided on the output terminal panel. These receptacles can **only** be accessed when the voltage selector switch is placed in the **single-phase 240/120 position**.




Figure 10. Twist-LockAuxiliary Receptacles

Each auxilliary receptacle is protected by a 50 amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) on all three receptacles is dependent on the load requirements of the **Output Terminal Lugs**.

Turn the **voltage regulator control knob** (Figure 11) on the control panel to obtain the desired voltage. Turning the knob clockwise will **increase** the voltage, turning the knob counter-clockwise will **decrease** the voltage.



Figure 11. Voltage Regulator Control Knob

Removing the Plastic Face Plate (Output Terminal Lugs)

The **Output Terminal Lugs** are protected by a plastic face plate cover (Figure 12). Un-screw the securing bolts and lift the plastic terminal cover to gain access to the terminal enclosure.

After the load wires have been securely attached to the **Output Terminal Lugs**, reinstall the plastic face plate.




Figure 12. Plastic Face Plate (UVWO Terminals)

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL PANEL FAMILIARIZATION

Connecting Loads

Loads can be connected to the generator by using the **Output Terminal Lugs** or the convenience receptacles (See Figure 13). Make sure to read the operation manual before attempting to connect a load to the generator.

To protect the **Output Terminal Lugs** from overload, a 3-pole, 110 amp, **main** circuit breaker is provided. Make sure to switch **ALL** circuit breakers to the **OFF** position prior to starting the engine.




Figure 13. Connecting Loads

Over Current Relay

An **over current relay** (Figure 14) is connected to the main circuit breaker. In the event of an overload, both the circuit breaker and the over current relay may trip. If the circuit breaker can not be reset, the **reset button** on the over current relay must be pressed. The over current relay is located in the control box.




Figure 14. Over Current Relay

Blower Fan

This unit has an intake fan located at the rear of the machine to draw outside air into the cabinet to cool the engine. The fan has a 10 amp AC fuse located beneath the **Voltage Selector Switch** (Figure 15).




Figure 15. Blower Fan Fuse

DANGER - ELECTROCUTION HAZARDS

This fuse has current running through it any time the engine is running. This fuse is **NOT** connected to the main circuit breaker of the generator. Attempting to replace the fuse with the engine and/or generator operating could result in **electrocution** and **severe bodily harm**. **ALWAYS** turn the unit completely off before attempting to replace or handle this fuse.





DCA-45USI (50/60 Hz)— LOAD APPLICATION

Single Phase Load

Always be sure to check the nameplate on the generator and equipment to insure the wattage, amperage, frequency, and voltage requirements are satisfactorily supplied by the generator for operating the equipment.

Generally, the wattage listed on the nameplate of the equipment is its rated output. Equipment may require 130—150% more wattage than the rating on the nameplate, as the wattage is influenced by the efficiency, power factor and starting system of the equipment.



If wattage is not given on the equipment's name plate, approximate wattage may be determined by multiplying nameplate voltage by the nameplate amperage.

$$\text{WATTS} = \text{VOLTAGE} \times \text{AMPERAGE}$$

The power factor of this generator is 0.8. See Table 5 below when connecting loads.

Table 5. Power Factor By Load

Type Of Load	Power Factor
Single-phase induction motors	0.4 - 0.75
Electric heaters, incandescent lamps	1.0
Fluorescent lamps, mercury lamps	0.4 - 0.9
Electronic devices, communication equipment	1.0
Common power tools	0.8

Table 6. Cable Selection (60 Hz, Single Phase Operation)



Current in Amperes	Load In Watts		Maximum Allowable Cable Length			
	At 100 Volts	At 200 Volts	#10 Wire	#12 Wire	#14 Wire	#16 Wire
2.5	300	600	1000 ft.	600 ft.	375 ft.	250 ft.
5	600	1200	500 ft.	300 ft.	200 ft.	125 ft.
7.5	900	1800	350 ft.	200 ft.	125 ft.	100 ft.
10	1200	2400	250 ft.	150 ft.	100 ft.	
15	1800	3600	150 ft.	100 ft.	65 ft.	
20	2400	4800	125 ft.	75 ft.	50 ft.	

CAUTION: Equipment damage can result from low voltage.



Three Phase Load

When calculating the power requirements for 3-phase power use the following equation:

$$\text{KVA} = \frac{\text{VOLTAGE} \times \text{AMPERAGE} \times 1.732}{1000}$$



If 3Ø load (kVA) is not given on the equipment nameplate, approximate 3Ø load output maybe determined by multiplying voltage by amperage by 1.732.



Motors and motor-driven equipment draw much greater current for starting than during operation.

An inadequate size connecting cable which cannot carry the required load can cause a voltage drop which can burn out the appliance or tool and overheat the cable. See Table 6.

- When connecting a resistance load such as an incandescent lamp or electric heater, a capacity of up to the generating set's rated output (kW) can be used.
- When connecting a fluorescent or mercury lamp, a capacity of up to the generating set's rated output (kW) multiplied by 0.6 can be used.
- When connecting an electric drill or other power tools, pay close attention to the required starting current capacity.

When connecting ordinary power tools, a capacity of up to the generating set's rated output (kW) multiplied by 0.8 can be used.



DANGER - ELECTRICAL SYSTEM HAZARDS

Before connecting this generator to any building's electrical system, a **licensed electrician** must install an **isolation (transfer) switch**. Serious damage to the building's electrical system may occur without this transfer switch.

DCA-45USI (50/60 Hz)— GENERATOR OUTPUTS

Voltage Selector Switch

The **voltage selector** switch (Figure 16) is located above the UVWO Hard Wire Hook-up Panel. It has been provided for ease of voltage selection.




Figure 16. Voltage Selector Switch

Voltage Selector Switch Locking Button

The voltage selector switch has a locking button to protect the generator and load from being switched while the engine is running. To lock the voltage selector switch, **press** and **hold** the **red button** located at the bottom of the switch.

CAUTION - CHANGING VOLTAGES

NEVER change the position of the **voltage selector switch** while the engine is running. **ALWAYS** place circuit breaker in the open position before selecting voltage.

Generator Output Voltages

A wide range of voltages are available to supply voltage for many different applications. Voltages are selected by using the **voltage selector switch** (Figure 16). To obtain some of the voltages as listed in Table 7 (see below) will require a fine adjustment using the **voltage regulator (VR) control knob** located on the control panel.

Table 7. Voltages Available						
Three Phase (Switchable) 50Hz	200V	220V	N/A	416V	440V	N/A
Single Phase (Switchable) 50 Hz	115V	127V	N/A	240V	254V	N/A
Three Phase (Switchable) 60Hz	208V	220V	240V	416V	440V	480V
Single Phase (Switchable) 60 Hz	120V	127V	139V	240V	254V	277V

Generator Amperage

Table 8 describes the generator's current output capability for both 1Ø-phase and 3Ø phase applications.

Table 8. Generator Ampere Ratings						
DCA-45USI	kW	kVA	100/120V	200V	220/240V	440/480V
Single Phase (50 Hz)	21.0	N/A	95A x 2	N/A	95A	N/A
Three Phase* (50 Hz)	29.6	37	N/A	106A	97A	48A
Single Phase (60 Hz)	26	N/A	108A x 2	N/A	108A	N/A
Three Phase* (60 Hz)	36	45	N/A	N/A	108A	54A
* Power Factor = 0.8						

GFCI Receptacle Load Capability

The load capability of the GFCI receptacles is directly related to the voltage being supplied at either the output terminal lugs or the 3 twist lock auxilliary receptacles.

Tables 9 and 10 show what amount of current is available at the GFCI receptacles when the output terminals and twist lock receptacles are in use. Be careful that your load does not to exceed the available current capability at the receptacles. The values listed in Tables 9 and 10 are for a 60 Hz generator. The available current for a 50 Hz generator will be somewhat less.

Table 9. 1Ø GFCI Receptacle Load Capability	
KW in Use Twist-Lock (CS6369)	Available Load Current (Amps)
1Ø 200/100V @ 50 Hz 1Ø 240/120V @ 60 Hz	GFCI Duplex NEMA 5-20R 120V
26	0
24.8	5 amps per receptacle
23.6	10 amps per receptacle
22.4	15 amps per receptacle
21.2	20 amps per receptacle



Table 10. 3Ø GFCI Receptacle Load Capability	
KVA in Use (UVWO Terminals)	Available Load Current (Amps)
3Ø 220/440V @ 50 Hz 3Ø 240/480V @ 60 Hz	GFCI Duplex NEMA 5-20R 120V
45	0
40.9	5 amps per receptacle
36.7	10 amps per receptacle
32.6	15 amps per receptacle
28.4	20 amps per receptacle

How to Read the Output Terminal Gauges.

The gauges and selector switches on the control panel **DO NOT** effect the generator output. They are provided to help observe how much power is being supplied at the **Output Terminal Lugs**.

Before taking a reading off either gauge, set the **Voltage Selector Switch** (Figure 17) to the position which produces the required voltage (For example, for 3Ø 240V, choose the center 3Ø 240/139V position on the voltage selector switch.)

Figure 17. Voltage Selector Switch 240/139V Three Phase Position



For 3Ø 200V/1Ø,100V 50Hz or 3 Ø 208V/1Ø,120V 60Hz, place the Voltage Selector Switch in the 3-Phase 240/139 position.

Reading Voltage

To determine the voltage between two terminal lugs, set the **AC Voltmeter Change-Over Switch** to the appropriate setting (Figure 18) to activate the **AC Voltmeter Gauge** (Figure 19) and read the available voltage between the two lugs.

For example, to measure the voltage between the W and U terminal lugs, set the **AC Voltmeter Change-Over Switch** to W-U and read the **AC Voltmeter Gauge**.




Figure 18. AC Voltmeter Change-Over Switch




Figure 19. AC Voltmeter Gauge (Volt reading on W-U Lug)

Reading Amperage

To determine the amperage at a terminal lug, set the **AC Ammeter Change-Over Switch** to the appropriate setting (Figure 20) to activate the **AC Ammeter Gauge** (Figure 21) and read the available amperage at the terminal lug.

For example, to measure the amperage at the U terminal lug, set the **AC Ammeter Change-Over Switch** to U and read the **AC Ammeter Gauge**.




Figure 20. AC Ammeter Change-Over Switch





Figure 21. AC Ammeter (Amp reading on U lug)



The **ammeter** gauge will only show a reading when the **Output Terminal Lugs** are connected to a load and in use.

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL PANEL CONNECTIONS


UVWO Terminal Output Voltages

Various output voltages can be obtained using the **Output Terminal Lugs**. The voltages at the terminals are dependent on the position of the **Voltage Selector Switch** and the adjustment of the **Voltage Regulator Control Knob**.

Remember the voltage selector switch determines the **range** of the output voltage. The voltage regulator (VR) allows the user to increase or decrease the selected voltage.

3Ø 220/240V (50/60 Hz), 1Ø 127/139V (50/60Hz) Output Terminal Lug Voltages

1. Place the voltage selector switch in the 3Ø 240/139 position as shown in Figure 22.



Use this position for:
 3Ø-220V @ 50 Hz
 1Ø-127V @ 50 Hz
 3Ø-240V @ 60 Hz
 1Ø-139V @ 60 Hz

Figure 22. Voltage Selector Switch 240/139V Three-Phase Position

2. Connect the load wires to the **Output Terminal Lugs** as shown in Figure 23.





Figure 23. Output Terminal Lugs 3Ø 220/240V (50/60 Hz) Connections

3. Turn the voltage regulator knob (Figure 24) clockwise to increase voltage output, turn counterclockwise to decrease voltage output.



Figure 24. Voltage Regulator Knob 3Ø 200/208V (50/60 Hz), 1Ø 115/120V (50/60Hz) Output Terminal Lug Voltages

1. Place the voltage selector switch in the 3Ø 240/139 position as shown in Figure 25.



Use this position for:
 3Ø-200V @ 50 Hz
 1Ø-115V @ 50 Hz
 3Ø-208V @ 60 Hz
 1Ø-120V @ 60 Hz

Figure 25. Voltage Selector Switch 240/139V Three-Phase Position

2. Connect the load wires to the **Output Terminal Lugs** as shown in Figure 26.





Figure 26. Output Terminal Lugs 3Ø 200/208V (50/60 Hz) Connections

3. Turn the voltage regulator knob (Figure 24) clockwise to increase voltage output, turn counterclockwise to decrease voltage output.

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL PANEL CONNECTIONS

3Ø 440/480V (50/60 Hz), 1Ø 254/277V (50/60Hz) Output Terminal Lug Voltages

1. Place the voltage selector switch in the 3Ø 480/277 position as shown in Figure 27.




Use this position for:

3Ø-440V@50 Hz
1Ø-254V@50 Hz
3Ø-480V@60 Hz
1Ø-277V@60 Hz

Figure 27. Voltage Selector Switch 480/277V Three-Phase Position

1Ø 200/100V (50 Hz), 1Ø 240/120V (60 Hz) Output Terminal Lug Voltages

1. Place the voltage selector switch in the 1Ø 240/120 position as shown in Figure 29.



Use this position for:

1Ø-200V@50 Hz
1Ø-100V@50 Hz
1Ø-240V@60 Hz
1Ø-120V@60 Hz

Figure 29. Voltage Selector Switch 240/120V Single-Phase Position

2. Connect the load wires to the **Output Terminal Lugs** as shown in Figure 28.




Figure 28. Output Terminal Lugs 3Ø 440/480V (50/60 Hz) Connections

2. Connect the load wires to the **Output Terminal Lugs** as shown in Figure 30.




Figure 30. Output Terminal Lugs Single-Phase (50/60 Hz) Connections

3. Turn the voltage regulator knob (Figure 24) clockwise to increase voltage output, turn counterclockwise to decrease voltage output.

Circuit Breakers

To protect the generator from an overload, a 3-pole, 110 amp, **main** circuit breaker is provided to protect the UVW output terminals from overload. In addition two single-pole, 20 amp **GFCI** circuit breakers are provided to protect the GFCI receptacles from overload. Three 50 amp **load** circuit breakers have also been provided to protect the auxiliary receptacles from overload. Make sure to switch **ALL** circuit breakers to the **OFF** position prior to starting the engine.

Lubrication Oil

Fill the engine crankcase with lubricating oil through the filler hole, but **DO NOT** overfill. Make sure the generator is level. and verify that the oil level is maintained between the two notches (Figure 31) on the dipstick. See Table 11 for proper selection of engine oil.




Figure 31. Engine Oil Dipstick

When checking the engine oil, be sure to check if the oil is clean. If the oil is not clean, drain the oil by removing the oil drain plug, and refill with the specified amount of oil as outlined in the **Isuzu Engine Owner's Manual**. Oil should be warm before draining.

Other types of motor oils may be substituted if they meet the following requirements:

- API Service Classification CH-4
- API Service Classification CG-4
- API Service Classification CF-4
- ACEA Specification E3
- ACEA Specification E2

Table 11. Recommended Motor Oil		
°F	°C	OIL: SAE
122	50	10W/40
104	40	30
86	30	10W/40
68	20	15W/30
50	10	10W/30
32	0	10W
14	-10	5W/30
-4	-20	ARCTIC OIL
-22	-30	
-40	-40	

Fuel Check

! DANGER - EXPLOSION/FIRE HAZARDS

Fuel spillage on a **hot** engine can cause a **fire** or **explosion**. If fuel spillage occurs, wipe up the spilled fuel completely to prevent fire hazards. **NEVER** smoke around or near the generator.



Refilling the Fuel System

! CAUTION - REFUELING THE GENERATOR

ONLY properly trained personnel who have read and understand this section should refill the fuel tank system.

The generator unit has an internal fuel tank located at the bottom of the cabinet (Figure 32). **ALWAYS** fill the fuel tank with clean and fresh **#2 diesel fuel**. **DO NOT** fill the fuel tanks beyond their capacities.

Pay attention to the fuel tank capacity when replenishing fuel. The fuel tank cap must be closed tightly after filling. Handle fuel in a safety container. If the container does not have a spout, use a funnel. Wipe up any spilled fuel immediately.




Figure 32. Internal Fuel Tank System

Refueling Procedure:

WARNING - RESPIRATORY HAZARDS

Diesel fuel and its vapors are dangerous to your health and the surrounding environment. Avoid skin contact and/or inhaling fumes.

1. **Level Tanks** – make sure fuel cells are level with the ground. Failure to do so will cause fuel to spill from the tank before reaching full capacity (Figure 33).

WARNING:

ALWAYS! place trailer on firm level ground before refueling.





Figure 33. Only Fill on Level Ground



ONLY! use #2 diesel fuel when refueling.

2. Open cabinet doors on the generator. Locate and remove the fuel tank cap and fill tank (Figure 34).




Figure 34. Fueling the Generator

3. **NEVER overfill fuel tank** – It is important to read the fuel gauge when filling trailer fuel tank. **DO NOT** wait for fuel to rise in filler neck (See Figure 35).

FUEL GAUGE LOCATED ON CONTROL PANEL




Figure 35. Full Fuel Tank

CAUTION - REFUELING THE GENERATOR

DO NOT OVER-FILL fuel system. Leave room for fuel expansion. Fuel expands when heated (Figure 36).




Figure 36. Fuel Expansion

Coolant (ISUZU Antifreeze/Summer Coolant/Water)

ISUZU recommends ISUZU Antifreeze/Summer Coolant for use in thier engines, which can be purchased in concentrate (and mixed with 50% demineralized water) or pre-diluted. See the **ISUZU Engine Owner's Manual** for further details.

WARNING - BURN HAZARDS

If adding coolant/antifreeze mix to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. The possibility of **hot!** coolant exists which can cause severe burns.



Day-to-day addition of coolant is done from the recovery tank. When adding coolant to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. See Table 12 for engine, radiator, and recovery tank coolant capacities. Make sure the coolant level in the recovery tank is always between the "H" and the "L" markings.

Table 12. Coolant Capacity

Engine and Radiator	5.3 Gal. (20 L)
Reserve Tank	0.26 Gal. (1L)


Operation Freezing Weather

When operating in freezing weather, be certain the proper amount of antifreeze (Table 13) has been added.

Table 13. Anti-Freeze Operating Temperatures

Vol % Anti-Freeze	Freezing Point	
	°C	°F
50	-37	-34

NOTE



When the antifreeze is mixed with water, the antifreeze mixing ratio **must be** less than 50%.

Cleaning the Radiator

The engine may overheat if the radiator fins become overloaded with dust or debris. Periodically clean the radiator fins with compressed air. Cleaning inside the machine is dangerous, so clean only with the engine turned off and the **negative** battery terminal disconnected.

Air Cleaner

Periodic cleaning/replacement is necessary. Inspect it in accordance with the **Isusu Engine Owner's Manual**.

Fan Belt Tension

A slack fan belt may contribute to overheating, or to insufficient charging of the battery. Inspect the fan belt for damage and wear and adjust it in accordance with the **Isuzu Engine Owner's Manual**.

The fan belt tension is proper if the fan belt bends 10 to 15 mm (Figure 37) when depressed with the thumb as shown below.




Figure 37. Fan Belt Tension

CAUTION - ROTATING PARTS



NEVER place hands near the belts or fan while the generator set is running.



Battery

This unit is of negative ground **DO NOT** connect in reverse. Always maintain battery fluid level between the specified marks. Battery life will be shortened, if the fluid level are not properly maintained. Add only distilled water when replenishment is necessary.

DO NOT over fill. Check to see whether the battery cables are loose. Poor contact may result in poor starting or malfunctions. **Always** keep the terminals firmly tightened. Coating the terminals with an approved battery terminal treatment compound. Replace battery with only recommended type battery. The battery type used in this generator is BCI Group 27.

The battery is sufficiently charged if the specific gravity of the battery fluid is 1.28 (at 68° F). If the specific gravity should fall to 1.245 or lower, it indicates that the battery is dead and needs to be recharged or replaced.

Battery Cable Installation

ALWAYS be sure the battery cables (Figure 38) are properly connected to the battery terminals as shown below. The **RED** cable is connected to the positive terminal of the battery, and the **BLACK** cable is connected to the negative terminal of the battery.

**CAUTION - BATTERY SERVICING SAFETY**

ALWAYS disconnect the negative terminal **FIRST** and reconnect negative terminal **LAST**.





Figure 38. Battery Connections

When connecting battery do the following:

1. **NEVER** connect the battery cables to the battery terminals when the **ignition** switch is in the **PRE-HEAT/RUN** position. **ALWAYS** make sure that the ignition switch is in the **STOP** position when connecting the battery.
2. Place a small amount of battery terminal treatment compound around both battery terminals. This will ensure a good connection and will help prevent corrosion around the battery terminals.



If the battery cable is connected incorrectly, electrical damage to the generator will occur. Pay close attention to the polarity of the battery when connecting the battery.

**CAUTION - BATTERY SERVICING SAFETY**

Inadequate battery connections may cause poor starting of the generator, and create other malfunctions.

Alternator

The polarity of the alternator is negative grounding type. When an inverted circuit connection takes place, the circuit will be in short circuit instantaneously resulting the alternator failure.

DO NOT put water directly on the alternator. Entry of water into the alternator leads an electrolyte corrosion causing an alternator failure.

Before charging the battery with an external electric source, be sure to disconnect the battery cables.

Wiring

Inspect the entire generator for bad or worn electrical wiring or connections. If any wiring or connections are exposed (insulation missing) replace wiring immediately.

Piping and Hose Connection

Inspect all piping, oil hose, and fuel hose connections for wear and tightness. Tighten all hose clamps and check hoses for leaks.

If any hose (**fuel** or **oil**) lines are defective replace them immediately.

DCA-45USI (50/60 Hz)— GENERATOR START-UP PROCEDURE

Before Starting

CAUTION - LETHAL EXHAUST HAZARD

The engine's exhaust contains harmful emissions. **ALWAYS have adequate ventilation when operating.** Direct exhaust away from nearby personnel.

WARNING - STARTING THE GENERATOR

NEVER! manually start the engine with the **main, GFCI** or **auxiliary** circuit breakers in the **ON** (closed) position.

1. Place the **main, G.F.C.I.,** and **aux.** circuit breakers (Figure 39) in the **OFF** position prior to starting the engine.






Figure 39. Main, Aux. and GFCI Circuit Breakers (OFF)

2. Connect the load to the **receptacles** or the **Output Terminal Lugs** as shown in Figure 13. These load connection points can be found on the output terminal panel and the output terminal panel's hard wire hookup panel.
3. The output terminal lugs are protected by a plastic cover. Remove this cover to gain access to the terminals. Tighten terminal nuts securely to prevent load wires from slipping out.
4. Close all engine enclosure doors (Figure 40).



CORRECT



INCORRECT

Figure 40. Engine Enclosure Doors

5. Place the **voltage selector switch** in the desired voltage position (Figure 41).




Figure 41. Voltage Selector Switch

6. Place the **frequency selector switch** in either the 50 or 60 Hz position (Figure 42). This toggle switch can be located on the side of the control box opposite the voltage selector switch.




Figure 42. Frequency Selector Switch

DANGER - FREQUENCY SELECTOR SWITCH

NEVER! change the position of the **frequency selector switch** when the generator is in use. Always shutdown the generator (off) before attempting to change the switch position. Changing the switch position when the generator is running, will **severely damage the equipment and void all warranties.**

7. Press and hold the **pre-heat button** (Figure 43) for at least 5 seconds to warm the engine glow plugs. (manual mode only).




Figure 43. Pre-Heat Button

DCA-45USI (50/60 Hz)— GENERATOR START-UP PROCEDURE

8. Verify that the **pre-heat lamp** (Figure 44) is lit. The lamp will turn off when the engine has started. (manual mode only).




Figure 44. Pre-Heat Lamp

6. Turn the ignition key to the **START** position (Figure 45). Once the engine starts, release the ignition key and allow it to return to the **PRE-HEAT/RUN** position. If the engine fails to start after 10 seconds, wait approximately 30 seconds and repeat steps 1-8.




Figure 45. Ignition Switch (Start Position)

7. Let the engine run for 3-5 minutes and listen and check for any abnormal sounds or smells. Check for fuel leaks, and noises that would associate with a loose cover or hardware.

Check the electric motor fan cooling the radiator for abnormal speed, sound or vibration conditions.

If any of the above mentioned conditions exists, shut-down the engine and correct the problem before operating the generator.

12. Depending on the position of the frequency selector switch (Figure 42), the generator's frequency meter (Figure 46) should be displaying either a 50 or 60 cycle output frequency expressed in **HERTZ**.




Figure 46. Frequency Meter (Hz)

13. There are two engine speed control rheostat's (Figure 47), that are mounted on the side of the control box. One is used for 50 Hz operation the other is for 60 Hz. Under normal conditions these controls should not have to be used. In the event the engine speed needs to be adjusted, use the appropriate control to fine tune the engine speed.




Figure 47. Engine Speed Rheostat's (50/60 Hz)

14. When adjusting the engine speed for the selected frequency, monitor the engine tachometer (Figure 48) until the desired engine speed has been reached. Using a flat bade screw driver, turn the appropriate engine speed rheostat clockwise to increase engine speed and counterclockwise to decrease.





Figure 48. Engine Tachometer Gauge



The **tachometer gauge** (Figure 48) will indicate the speed of the engine when the generator is operating. Under normal operating conditions this speed is approximately 1500 RPM's for 50 Hz operation and 1800 RPM's for 60 Hz operation.

DCA-45USI (50/60 Hz)— GENERATOR START-UP PROCEDURE

9. The generator's voltage meter (Figure 49) displays the output voltage in **VOLTS**.




Figure 49. AC Voltmeter

10. If the voltage is not reading at the specified level, use the voltage adjustment control knob (Figure 50) to increase or decrease the voltage until you reach the desired voltage.




Figure 50. Voltage Adjust Control Knob

11. The ammeter (Figure 51) will indicate zero amps with no load applied. When a load is applied, this meter will indicate the amount of current that the load is drawing from the generator.




Figure 51. Ammeter (No Load)

12. The engine oil pressure gauge (Figure 52) will indicate the oil pressure of the engine. Under normal operating conditions the oil pressure is approximately




Figure 52. Oil Pressure Gauge

13. The coolant temperature gauge (Figure 53) will indicate the coolant temperature. Under normal operating conditions the coolant temperature is between 165 and 203° degrees Fahrenheit.




Figure 53. Coolant Temperature Gauge

14. Turn the **main**, **GFCI**, and **aux.** circuit breakers to the **ON** position (Figure 54).




Figure 54. Main, AUX. and GFCI Circuit Breakers (ON)

15. Observe the generator's ammeter (Figure 55) and verify it reads the anticipated amount of current with respect to the load. The ammeter will only display a current reading if the load is in use.




Figure 55. Ammeter (Load)

16. The generator will run until manually stopped or an abnormal condition occurs.

DCA-45USI (50/60 Hz)— GENERATOR SHUT-DOWN PROCEDURE

Normal Shut-down Procedure

To shutdown the generator, use the following procedure:

1. Switch the **MAIN**, **AUX** and **GFCI** circuit breakers (Figure 56) to the **OFF** position (no load).




Figure 56. Main, AUX. and GFCI Circuit Breakers (OFF)

3. Let the engine cool by running it for 3-5 minutes with no load applied (circuit breakers in the **OFF** position).
4. Place the ignition switch (Figure 57) in the **STOP** position, remove the key and store in a safe place.




Figure 57. Ignition Switch (Off Position)

5. Remove all loads from the generator.
6. Allow for sufficient time for cooling and then inspect the complete unit for any damage or loosening that may have occurred during operation.
7. Check the engine oil, coolant and fuel levels. Replenish as necessary.

Emergency Shut-down Procedure

1. Press the "**RED**" **emergency stop button** (Figure 58)



Figure 58 . Emergency Stop Button



WARNING - SHUTTING DOWN THE GENERATOR

NEVER stop the engine suddenly except in an emergency. **DO NOT** use the emergency stop switch as a method of shutting down the generator. This switch is **ONLY** to be used in the event of an emergency.

Automatic Shut-down System



This unit is equipped with safety devices to automatically stop the engine in the event of low oil pressure (approx. 14 PSI.), or high water temperature (approx. 221° F). The alarm lamps on the Engine Operating Panel (Figure 7) illuminate to signify the reason for the shut-down.



WARNING - AUTOMATIC SHUTDOWN

After automatic shut-down, **ALWAYS** inspect the unit and eliminate any problems before attempting to restart. Failure to do so can damage the unit.

Before inspecting, turn the **starter switch** to the **STOP** position, place all generator **circuit breakers** in the **OFF** position and allow sufficient time for adequate cooling. When ready to restart, complete all steps in the Generator Startup Procedure section of this manual.



Engine protection is furnished during operation, but cannot replace normal preventive maintenance.

Regularly maintain the unit as specified in the Maintenance section of this manual to prevent damage.

DCA-45USI (50/60 Hz) — MAINTENANCE (ENGINE)

TABLE 14. INSPECTION/MAINTENANCE		10 Hrs DAILY	250 Hrs	500 Hrs	1000 Hrs
ENGINE	Check Engine Fluid Levels	X			
	Check Air Cleaner	X			
	Check Battery Acid Level	X			
	Check Fan Belt Condition	X			
	Check for Leaks	X			
	Check Fluid Levels for Containment	X			
	Check for Loosening of Parts	X			
	Replace Engine Oil and Filter * 1		X		
	Drain Bottom of Fuel Tank		X		
	Check Fuel Filter/Water Separator Bowl		X		
	Clean Unit, Inside and Outside		X		
	Check Blowby Hose * 2		X		
	Clean Air Filter		X		
	Replace Air Filter Element * 3			X	
	Change Fuel Filter * 4			X	
	Clean Radiator and Check Coolant Protection Level			X	
	Check all Hoses and Clamps				X
	Clean Inside of Fuel Tank				X
GENERATOR	Measure Insulation Resistance		X		
	Check Rotor Rear Support Bearing			X	

*1 Replace engine oil and filter at 50 hours, first time only.

*2 If blowby hose needs to be replaced, ensure that the slope of the blowby hose is at least a 1/2 inch per foot, with no sags or dips that could collect moisture and/or oil.

*3 Replace primary air filter element when restriction indicator shows a vacuum of 625 mm. (25 in.) H₂O

*4 Push priming pump on fuel filter when air bleeding. It is not necessary to loosen any plugs.

General Inspection

Prior to each use, the generator should be cleaned and inspected for deficiencies. Check for loose, missing or damaged nuts, bolts or other fasteners. Also check for fuel, oil, and coolant leaks. Use Table 14 as a general maintenance guideline **Engine Side** (Refer to the Engine Instruction Manual).

Engine Side (Refer to the Engine Instruction Manual)

Air Cleaner

Every 250 hours: Remove air cleaner element and clean the heavy duty paper element with light spray of compressed air. Replace the air cleaner as needed.

Air Cleaner with Dust Indicator

This indicator is attached to the air cleaner. When the air cleaner element is clogged, air intake restriction becomes greater and the dust indicator signal shows **RED** meaning the element needs changing. After changing the air element, press the dust indicator button to reset the indicator.

Service Daily

If the engine is operating in very **dusty** or **dry grass** conditions, a clogged air cleaner will result. This can lead to a loss of power, excessive carbon buildup in the combustion chamber and high fuel consumption. Change air cleaner more **frequently** if these conditions exist.

Fuel Addition

Add diesel fuel (the grade may vary according to season and locations). Always pour through the mesh filter.

Removing Water from the Fuel Tank

After prolonged use, water and other impurities accumulate in the bottom of the tank. Occasionally inspect the fuel tank for water contamination and drain the contents if required.

During cold weather, the more empty volume inside the tank, the easier it is for water to condense. This can be reduced by keeping the tank full with diesel fuel.

Air Removal

If air enters the fuel injection system of a diesel engine, starting becomes impossible. After running out of fuel, or after disassembling the fuel system, bleed the system according to the following procedure.

To restart after running out of fuel, turn the switch to the **ON** position for 15-30 seconds. Try again, if needed. This unit is equipped with an automatic air bleeding system.

Check Oil Level

Check the crankcase oil level prior to each use, or when the fuel tank is filled. Insufficient oil may cause severe damage to the engine. Make sure the generator is level. The oil level must be between the two notches on the dipstick as shown in Figure 31.

Replacing Oil Filter

- Remove the old oil filter.
- Apply a film of oil to the gasket on the new oil filter.
- Install the new oil filter.
- After the oil cartridge has been replaced, the engine oil will drop slightly. Run the engine for a while and check for leaks before adding more oil if needed. Clean excessive oil from engine.

Replacing Fuel Filter

- Replace the fuel filter cartridge with new one every 500 hours or so.
- Loosen the drain plug at the lower top of the fuel filter. Drain the fuel in the fuel body together with the mixed water. **DO NOT** spill the fuel during disassembly.
- Vent any air.



WARNING - BURN HAZARDS

Allow engine to **cool** when flushing out radiator. Flushing the radiator while hot could cause serious burns from water or steam.



Flushing Out Radiator and Replacing Coolant

- Open both cocks located at the crankcase side and at the lower part of the radiator and drain coolant. Open the radiator cap while draining. Remove the overflow tank and drain.
- Check hoses for softening and kinks. Check clamps for signs of leakage.
- Flush the radiator by running clean tap water through radiator until signs of rust and dirt are removed. **DO NOT** clean radiator core with any objects, such as a screwdriver.
- Tighten both cocks and replace the overflow tank.
- Replace with coolant as recommended by the engine manufacturer. See Table 13 for correct mixture.
- Close radiator cap tightly.

Generator Storage

For long term storage of the generator the following is recommended:

- Fill the fuel tank completely. Treat with a fuel stabilizer if necessary.
- Completely drain the oil from the crankcase and refill if necessary with fresh oil.
- Clean the entire generator, internal and external.
- Cover the generating set and store in a clean, dry place.
- Disconnect the battery.
- Make sure engine coolant is at proper level.
- If generator is mounted on a trailer, jack trailer up and place on blocks so tires do not touch the ground or block and completely remove the tires.

Trailer Maintenance

This section is intended to provide the user with generic trailer service and maintenance information. The service and maintenance guidelines referenced in this section refer to a wide range of trailers.

Remember periodic inspection of the trailer will ensure safe towing of the generator and will prevent personal injury and damage to the equipment.

The definitions below describe some of the major components of a typical trailer that would be used with the DCA-45USI Ultra Silent™ Generator.

1. **Fuel Cell** - Provides an adequate amount of fuel for the equipment in use. Fuel cells must be empty when transporting equipment.
2. **Braking System** - System employed in stopping the trailer. Typical braking systems are electric, surge, hydraulic, hydraulic-surge and air.
3. **GVWR**- Gross Vehicle Weight Rating (GVWR) is the maximum number of pounds the trailer can carry, including the fuel cell (empty).
4. **Frame Length** - Measurement is from the ball hitch to the rear bumper (reflector).
5. **Frame Width** - Measurement is from fender to fender
6. **Jack Stand** - Trailer support device with maximum pound requirement from the tongue of the trailer.
7. **Coupler** - Type of hitch used on the trailer for towing.
7. **Coupler** - Type of hitch used on the trailer for towing.
8. **Tire Size** - Indicates the diameter of the tire in inches (10,12,14, etc.), and the width in millimeters (175,185,205, etc.). The tire diameter must match the diameter of the tire rim.
9. **Tire Ply** - The tire ply (layers) number is rated in letters; 2-ply,4-ply,6-ply, etc.
10. **Wheel Hub** - The wheel hub is connected to the trailer's axle.
11. **Tire Rim** - Tires mounted on a tire rim. The tire rim must match the size of the tire.
12. **Lug Nuts** - Used to secure the wheel to the wheel hub. Always use a torque wrench to tighten down the lug nuts. See Table 16 and Figure 59 for lug nut tightening and sequence.
13. **Axle** - Indicates the maximum weight the axle can support in pounds, and the diameter of the axle expressed in inches. Please note that some trailers have a double axle. This will be shown as 2-6000 lbs., meaning two axles with a total weight capacity of 6000 pounds.
14. **Suspension** - Protects the trailer chassis from shocks transmitted through the wheels. Types of suspension used are leaf, Q-flex, and air ride.
15. **Electrical** - Electrical connectors (looms) are provided with the trailer so the brake lights and turn signals can be connected to the towing vehicle.
16. **Application** - Indicates which units can be employed on a particular trailer.

DCA-45USI (50/60 Hz) — TRAILER BRAKES MAINTENANCE

Brakes

Trailer brakes should be inspected the **first 200 miles** of operation. This will allow the brake shoes and drums to seat properly. After the first 200 mile interval, inspect the brakes **every 3,000 miles**. If driving over rough terrain, inspect the brakes more frequently.

Figure 59 displays the major hydraulic surge brake components that will require inspection and maintenance. Please inspect these components as required using steps 1 through 8 and Table 15 as listed below:

Brake Adjustment

1. Place the trailer on jack stands. Make sure the jack stands are placed on secure level ground.
2. Check the wheel and drum for free rotation.
3. Remove the adjusting hole cover from the adjusting slot at the bottom brake backing plate.
4. With a screwdriver or standard adjusting tool, rotate the star wheel of the adjuster assembly to expand the brake shoes.
5. Adjust the brake shoes outward until the pressure of the lining against the wheel drum makes the wheel difficult to turn.
6. Adjust, rotate the star wheel in the opposite direction until the wheel rotates freely with slight lining drag.
7. Replace the adjusting hole cover and lower the trailer to the ground.
8. Repeat steps 1 through 7 on the remaining brakes.

Hydraulic Surge Brakes

Hydraulic surge brakes (Figure 59) should not require any special attention with the exception of routine maintenance such as shoe and lining replacement. Brake lines should be periodically checked for cracks, kinks, or blockage.




Figure 59. Hydraulic Brake Components

Actuator

Hydraulic surge braking requires the installation of an actuator at the tongue of the trailer. Remember the **surge** or **push** of the trailer toward the tow vehicle automatically synchronizes the trailer brakes with the tow vehicle brakes. As the trailer pushes against the tow vehicle the actuator telescopes together and applies force to the master cylinder, supplying hydraulic pressure to the trailer brakes.

Periodically check and test the surge “**actuator**” to make sure that it is functioning correctly. Never use an undersize actuator.

Table 15. Hydraulic Brake Troubleshooting

Symptom	Possible Cause	Solution
No Brakes	Brake line broken or kinked?	Repair or replace.
Weak Brakes or Brakes Pull to One Side	Brake lining glazed?	Reburnish or replace.
	Trailer overloaded?	Correct weight.
	Brake drums scored or grooved?	Machine or replace.
	Tire pressure correct?	Inflate all tires equally.
	Tires unmatched on the same axle?	Match tires.
Locking Brakes	Brake components loose, bent or broken?	Replace components.
	Brake drums out-of-round?	Replace.
Noisy Brakes	System lubricated?	Lubricate.
	Brake components correct?	Replace and correct.
Dragging Brakes	Brake lining thickness incorrect or not adjusted correctly?	Install new shoes and linings.
	Enough brake fluid or correct fluid?	Replace rubber parts fill with dot 4 fluid.


DCA-45USI (50/60 Hz) — TRAILER MAINTENANCE

Tires/Wheels/Lug Nuts

Tires and wheels are a very important and critical components of the trailer. When specifying or replacing the trailer wheels it is important the wheels, tires, and axle are properly matched.


CAUTION - EYESIGHT HAZARD

ALWAYS wear safety glasses when removing or installing force fitted parts. Failure to comply may result in serious injury.



CAUTION - REPAIRING TRAILER WHEELS

DO NOT attempt to repair or modify a wheel. **DO NOT** install in inner tube to correct a leak through the rim. If the rim is cracked, the air pressure in the inner tube may cause pieces of the rim to explode (break off) with great force and cause serious eye or bodily injury.



Tire Wear/Inflation

Tire inflation pressure is the most important factor in tire life. Pressure should be checked cold before operation **DO NOT** bleed air from tires when they are **hot!** Check inflation pressure weekly during use to insure the maximum tire life and tread wear.

Table 16 (Tire Wear Troubleshooting) will help pinpoint the causes and solutions of tire wear problems.

TABLE 16 TIRE WEAR TROUBLESHOOTING

WEAR PATTERN	CAUSE	SOLUTION
Center Wear	Over Inflation.	Adjust pressure to particular load per tire manufacturer.
Edge Wear	Under Inflation.	Adjust pressure to particular load per tire manufacturer.
Side Wear	Loss of camber or overloading.	Make sure load does not exceed axle rating. Align wheels.
Toe Wear	Incorrect toe-in.	Align wheels.
Cupping	Out-of-balance.	Check bearing adjustment and balance tires.
Flat Spots	Wheel lockup & tire skidding.	Avoid sudden stops when possible and adjust brakes.

Suspension

The **leaf suspension** springs and associated components (Figure 60) should be visually inspected every 6,000 miles for signs of excessive wear, elongation of bolt holes, and loosening of fasteners. Replace all damaged parts (suspension) immediately. Torqued suspension components as detailed in Table 17.




Figure 60. Major Suspension Components

Table 17. Suspension Torque Requirements

Item	Torque (Ft.-Lbs.)
3/8" U-BOLT	MIN-30 MAX-35
7/16" U-BOLT	MIN-45 MAX-60
1/2" U-BOLT	MIN-45 MAX-60
SHACKLE BOLT SPRING EYE BOLT	SNUG FIT ONLY. PARTS MUST ROTATE FREELY. LOCKING NUTS OR COTTER PINS ARE PROVIDED TO RETAIN NUT-BOLT ASSEMBLY.
SHOULDER TYPE SHACKLE BOLT	MIN-30 MAX-50



Lug Nut Torque Requirements

It is extremely important to apply and maintain proper wheel mounting torque on the trailer. Be sure to use only the fasteners matched to the cone angle of the wheel. Proper procedure for attachment of the wheels is as follows:


1. Start all wheel lug nuts by hand.
2. Torque all lug nuts in sequence. See Figure 61. **DO NOT** torque the wheel lug nuts all the way down. Tighten each lug nut in 3 separate passes as defined by Table 18.
3. After first road use, retorque all lug nuts in sequence. Check all wheel lug nuts periodically.

Table 18. Tire Torque Requirements

Wheel Size	First Pass FT-LBS	Second Pass FT-LBS	Third Pass FT-LBS
12"	20-25	35-40	50-65
13"	20-25	35-40	50-65
14"	20-25	50-60	90-120
15"	20-25	50-60	90-120
16"	20-25	50-60	90-120




NEVER use an pneumatic air gun to tighten wheel lug nuts.



4-LUG NUTS

6-LUG NUTS



5-LUG NUTS

8-LUG NUTS




Figure 61. Wheel Lug Nuts Tightening Sequence

DCA-45USI (50/60 Hz)—TRAILER WIRING DIAGRAM





Figure 62. Trailer/Towing Vehicle Wiring Diagram

DCA-45USI (50/60 Hz)— ENGINE WIRING DIAGRAM



WIRE SIZE	
60	: 50mm ²
5	: 5 mm ²
No	: 1.25mm ²

COLOR CODE			
SYM.	WIRE COLOR	SYM.	WIRE COLOR
B	BLACK	R	RED
L	BLUE	W	WHITE
BR	BROWN	Y	YELLOW
G	GREEN	LB	LIGHT BLUE
GR	GRAY	LG	LIGHT GREEN
V	VIOLET	O	ORANGE
P	PINK		




Figure 63. Engine Wiring Diagram

DCA-45USI (50/60 Hz)— ENGINE WIRING DIAGRAM





Figure 63A. Engine Wiring Diagram(Continued)

DCA-45USI (50/60 Hz)— GENERATOR WIRING DIAGRAM



DCA-45USI (50/60 Hz)—TROUBLESHOOTING (GENERATOR)

Practically all breakdowns can be prevented by proper handling and maintenance inspections, but in the event of a breakdown, use the table (Table 19) shown below for basic Generator Troubleshooting. If the problem cannot be remedied, consult our company's business office or service plant.

TABLE 19. GENERATOR TROUBLESHOOTING

SYMPTOM	POSSIBLE PROBLEM	SOLUTION
No Voltage Output	AC Voltmeter defective?	Check output voltage using a voltmeter.
	Is wiring connection loose?	Check wiring and repair.
	Is AVR defective?	Replace if necessary.
	Defective Rotating Rectifier?	Check and replace.
	Defective Exciter Field?	Check for 17.6 ohms across J and K on CN5
Low Voltage Output	Is engine speed correct?	Check engine speed and adjust to the correct speed
	Is wiring connections loose?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
High Voltage Output	Is wiring connections loose?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
Circuit Breaker Tripped	Short Circuit in load?	Check load and repair.
	Over current?	Confirm load requirements and reduce.
	Defective circuit breaker?	Check and replace.
	Over current Relay actuated?	Confirm load requirement and replace.

[illegible]

DCA-45USI (50/60 Hz) — EXPLANATION OF CODE IN REMARKS COLUMN

The following section explains the different symbols and remarks used in the Parts section of this manual. Use the help numbers found on the back page of the manual if there are any questions.

The contents and part numbers listed in the parts section are subject to change **without notice**. Multiquip does not guarantee the availability of the parts listed.



Sample Parts List:

NO.	PART NO.	PART NAME	QTY.	REMARKS
1	12345	BOLT	1	INCLUDES ITEMS W/*
2*		WASHER, 1/4 IN.		NOT SOLD SEPARATELY
2*	12347	WASHER, 3/8 IN.	1	MQ-45T ONLY
3	12348	HOSE	A/R ..	MAKE LOCALLY
4	12349	BEARING	1	S/N 2345B AND ABOVE

NO. Column

Unique Symbols - All items with same unique symbol (*, #, +, %, or >) in the number column belong to the same assembly or kit, which is indicated by a note in the “Remarks” column.

Duplicate Item Numbers - Duplicate numbers indicate multiple part numbers are in effect for the same general item, such as different size saw blade guards in use or a part that has been updated on newer versions of the same machine.



When ordering a part that has more than one item number listed, check the remarks column for help in determining the proper part to order.

PART NO. Column

Numbers Used - Part numbers can be indicated by a number, a blank entry, or TBD.

TBD (To Be Determined) is generally used to show a part that has not been assigned a formal part number at time of publication.

A blank entry generally indicates that the item is not sold separately or is not sold by Multiquip. Other entries will be clarified in the “Remarks” Column.

QTY. Column

Numbers Used - Item quantity can be indicated by a number, a blank entry, or A/R.

A/R (As Required) is generally used for hoses or other parts that are sold in bulk and cut to length.

A blank entry generally indicates that the item is not sold separately. Other entries will be clarified in the “Remarks” Column.

REMARKS Column

Some of the most common notes found in the “Remarks” Column are listed below. Other additional notes needed to describe the item can also be shown.

Assembly/Kit - All items on the parts list with the same unique symbol will be included when this item is purchased.

Indicated by:

“INCLUDES ITEMS W/(unique symbol)”

Serial Number Break - Used to list an effective serial number range where a particular part is used.

Indicated by:

“S/N XXXXX AND BELOW”

“S/N XXXX AND ABOVE”

“S/N XXXX TO S/N XXX”

Specific Model Number Use - Indicates that the part is used only with the specific model number or model number variant listed. It can also be used to show a part is NOT used on a specific model or model number variant.

Indicated by:

“XXXXX ONLY”

“NOT USED ON XXXX”


“Make/Obtain Locally” - Indicates that the part can be purchased at any hardware shop or made out of available items. Examples include battery cables, shims, and certain washers and nuts.

“Not Sold Separately” - Indicates that an item cannot be purchased as a separate item and is either part of an assembly/kit that can be purchased, or is not available for sale through Multiquip.

DCA-45USI (50/60 Hz)— SUGGESTED SPARE PARTS

DCA-45USI (50/60 Hz) w/ ISUZU BB-4JG1T 1 TO 3 UNITS


<u>Qty.</u>	<u>P/N</u>	<u>Description</u>
3	8970497081	OIL FILTER
3	8943692993	FUEL FILTER
3	0602046681	AIR ELEMENT
1	0602122272	UNIT, OIL PRESSURE
1	0602123260	UNIT WATER TEMPERATURE
1	8972606490	FAN BELT
3	8944024980	KEY, STARTER SWITCH
1	0605505070	CAP, FUEL TANK
1	9827200690	SENDER, OIL PRESSURE (ENGINE SIDE)
1	8970785920	SENDER, WATER TEMPERATURE (ENGINE SIDE)
2	0601802149	FUSE, 10A



Part number on this Suggested Spare Parts list may supercede/replace the P/N shown in the text pages of this book.

DCA-45USI (50/60 Hz)— GENERATOR ASSY.

GENERATOR ASSY.




DCA-45USI (50/60 Hz)— GENERATOR ASSY.

GENERATOR ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	B3110100202	ROTOR ASSY.	1	
1-1		FIELD ASSY.	1	
1-2	8051070003	FAN	1	
1-3	0010310035	HEX, HEAD BOLT	8	
1-4	0042510000	SPRING WASHER	8	
1-5	8041611004	COUPLING DISK	4	
1-6	8041015003	BALANCING PLATE	1	PURCHASE SET OF 1-16
1-7	0010310025	HEX, HEAD BOLT	6	
1-8	0042510000	SPRING WASHER	6	
1-9	8001026013	SET PLATE, RECTIFIER BALANCING PLATE ...1	1	PURCHASE SET OF 1-16
1-10	0601821349	RECTIFIER	2	PT3610
1-11	0601822601	SURGE ABSORBER	1	ERZ-M14JK621A
1-12	8001020004	INSULATOR WASHER	1	
1-13	8001020504	INSULATOR WASHER	1	
1-14	0010108020	HEX, HEAD BOLT	4	
1-15	0040008000	SPRING WASHER	4	
1-16	0601000209	BALANCING WEIGHT KIT	1	
1-17	0071906310	BEARING	1	6310DDU C3
2	M1164400003	COUPLING RING	1	
3	0012808030	HEX, HEAD BOLT	6	
4	B3130100103	STATOR ASSY.	1	
4-1	0845041904	GROMMET	2	
5	M1164600003	COUPLING ADAPTER	1	
6	0012810030	HEX, HEAD BOLT	8	
7	8041315202	END BRACKET	1	
8	8041350013	FIELD ASSY. EXCITER	1	
9	0010308065	HEX, HEAD BOLT	4	
10	0042608000	SPRING WASHER	4	
11	0041208000	PLAIN WASHER	4	
12	0017108030	HEX, HEAD BOLT	6	
13	8041310024	COVER, BEARING	1	
14	8041312014	GASKET, BEARING	1	
15	0017106012	HEX, HEAD BOLT	4	
16	8041331014	COVER, END BRACKET	1	
17	0017106012	HEX, HEAD BOLT	4	
18	8001333003	COVER, END BRACKET	1	
19	0340406040	HEX, HEAD BOLT	2	
20	0041206000	PLAIN WASHER	2	
21	0012810030	HEX, HEAD BOLT	6	
22	8051332014	COVER, FAN	1	
23	0600815000	NUT	1	
24	0605000055	RUBBER SUSPENSION	2	
25	0030012000	HEX, NUT	2	
25A	0040012000	SPRING WASHER	2	
25B	0041212000	PLAIN WASHER	2	

DCA-45USI (50/60 Hz)— CONTROL BOX ASSY.

CONTROL BOX ASSY.




DCA-45USI (50/60 Hz)— CONTROL BOX ASSY.

CONTROL BOX ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1214000102	CONTROL BOX	1	
2	S3N125TW	CIRCUIT BREAKER, 3-POLE, 110A	1	KAF361101039
2-1	K5S9	SHUNT TRIP	1	
2-2	K6CSU	CONNECTOR	1	
3	0021005080	MACHINE SCREW	4	
4	0601823863	RELAY UNIT	2	MSA9013A
5	0027104016	MACHINE SCREW	4	
6	0601820671	AUTOMATIC VOLTAGE REGULATOR	1	NTA-5A-2DB
7	0027105016	MACHINE SCREW	4	
8	0601806116	CURRENT TRANSFORMER	3	812-943 75/5A
9	0027106016	MACHINE SCREW	6	
10	0601820845	OVER CURRENT RELAY	1	LR2D1308
11	0601820846	OVER CURRENT RELAY	1	LA7D1064
12	0027104016	MACHINE SCREW	2	
12A	0207004000	HEX, NUT	2	
13	M1213500303	CONTROL BOX COVER	1	
14	0016906016	HEX, HEAD BOLT	4	
15	M1201000004	SELECTOR SWITCH	1	VY-40
15A	TBD	KNOB, SELECTOR	1	
16	M1215601204	SWITCH BRACKET	1	
17	0027103010	MACHINE SCREW	4	
18	0016906016	HEX, HEAD BOLT	4	
19	0330000530	EDGING	1	
20	M1215601104	SWITCH COVER	1	
21	0016906016	HEX, HEAD BOLT	3	
22	0016906016	HEX, HEAD BOLT	8	
22A	0040506000	TOOTHED WASHER	1	
23	M1224000003	CONTROL PANEL	1	
24	0601807641	FREQUENCY METER	1	FCF-6 45~65Hz 240V
25	0601808986	AC AMMETER	1	ACF-6 0~75A/150A:5A
26	0601801040	CHANGE-OVER SWITCH, AMMETER	1	SL-2 AS
27	0601806859	AC VOLTMETER	1	SCF-6 0~600V
28	0601801041	CHANGE-OVER SWITCH, VOLTMETER	1	SL-2 VS
29	EE22LLBC	EMERGENCY STOP BUTTON	1	
29-1	EE25642	NAMEPLATE EMERGENCY STOP BUTTON	1	
29-2	EE1687	GUARD, EMERGENCY STOP BUTTON	1	
29	0601840073	RHEOSTAT(VOLTAGE REGULATOR)	1	RA20A2SE102BJ 2W 1K OHM
30	0601840121	KNOB	1	
31	0602100009	STARTER SWITCH	1	ISUZU 897044-4180
31A	8944024980	IGNITION KEY	1	
32	0602103092	PREHEAT LAMP	1	PL-05
32A	0601810245	BULB, E-10 T-10 DC18V	1	

DCA-45USI (50/60 Hz)— CONTROL BOX ASSY.

CONTROL BOX ASSY.




DCA-45USI (50/60 Hz)— CONTROL BOX ASSY.

CONTROL BOX ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
33	0602120095	TACHOMETER	1	103680
34	0602122093	OIL PRESSURE GAUGE	1	100174
35	0602123090	WATER TEMPERATURE GAUGE	1	100683
36	0602121080	CHARGING AMMETER	1	100158
37	0602125090	FUEL GAUGE	1	100176
38	0602103092	ALARM LAMP, PL-05	3	
38	0602103092	ALARM LAMP, PL05	4	S/N 8200081~
38A	0601810245	BULB, E-10 T-10 DC18V	3	
38A	0601810245	BULB, E-10 T-10 DC18V	4	S/N 8200081~
39	0601810141	PANEL LIGHT	1	98268-O0370
40	0601831330	SWITCH, PANEL LIGHT	1	
41	M1224100104	STOPPER	1	
42	0027105010	MACHINE SCREW	2	
43	0027105010	MACHINE SCREW	4	
44	M9220100004	SET SCREW	2	
45	0080200007	SNAP RING	2	
46	0602200432	EMERGENCY RELAY	1	897111-9621
47	0602202506	PREHEAT CONTROLLER	1	897246-5100
48	0016906020	HEX, HEAD BOLT	3	
49	0602200305	SAFETY RELAY	1	182553-0430
50	0602201400	RELAY	1	582550-0290
51	0016906016	HEX, HEAD BOLT	3	
52	0606503062	FUEL LEAK DETECTED SWITCH	1	
53	M1414800104	BRACKET	1	
54	0016908020	HEX, HEAD BOLT	2	
55	M1247700114	WIRE HARNESS, GENERATOR	1	
56	M1358200112	WIRE HARNESS, ENGINE	1	
57	M3357200304	WIRE, HARNESS, FUEL LEAK	1	S/N 8200081~
58	0601823223	RECTIFIER	2	S/N 8200001 TO 8200080
58	0601823245	RECTIFIER	2	S/N 8200001 TO 8200080
59	0601802149	FUSE, 10A	2	S/N 8200081~
60	0602103092	ALARM LAMP, PL05	4	S/N 8200081~
60A	0601810245	BULB, E-10 T-10 DC18V	4	S/N 8200081~
61	0602122272	UNIT, OIL PRESSURE	1	108497
62	M9200100004	ADAPTER	1	
63	0602123260	UNIT, WATER TEMPERATURE	1	02094-00
64	0602021109	PACKING	1	909572-0140
65	0602202546	CONTROLLER (EGS) DYN1	1	
66	34473	RHEOSTAT, 50/60 Hz	2	
67	EE2761	TOGGLE SWITCH, 50/60 Hz	2	
67-1	M194001108Q	NAMEPLATE TOGGLE SWITCH, 50/60 Hz	1	

DCA-45USI (50/60 Hz)— ENGINE AND RADIATOR ASSY.

ENGINE AND RADIATOR ASSY.




DCA-45USI (50/60 Hz)— ENGINE AND RADIATOR ASSY.

ENGINE AND RADIATOR ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1924200014	ENGINE	1	ISUZU BB-4JG1T
1-1	897049-7081	CARTRIDGE, OIL FILTER	1	REPLACES 0602041214
2	0605000048	RUBBER SUSPENSION	2	
3	0030010000	HEX, NUT	2	
4	0040010000	SPRING WASHER	2	
5	0041210000	PLAIN WASHER	2	
6	M1923200084	RADIATOR	1	2951-293-0000
6A	0602011079	CAP, RADIATOR	1	6713-092-0901
7	M9312200104	MOUNT RUBBER	2	
8	0016908040	HEX, HEAD BOLT	2	
9	0207008000	HEX, NUT	2	
10	M1311500003	RADIATOR HOSE	1	
11	M1311500103	RADIATOR HOSE	1	
12	0605515201	HOSE BAND	4	
13	M1424700104	FAN GUARD	1	
14	M1424700004	FAN GUARD	1	
15	0016906016	HEX, HEAD BOLT	7	
16	0602046582	AIR CLEANER	1	FPG08-2527
16A	0602046681	ELEMENT, AIR CLEANER	1	P82-8889
17	0602040651	INDICATOR, AIR CLEANER	1	RBX00-2352
18	M1374200104	BRACKET, AIR CLEANER	1	
19	0602040556	BAND, AIR CLEANER	1	
20	0016908020	HEX, HEAD BOLT	2	
21	0207008000	HEX, NUT	2	
22	0016910025	HEX, HEAD BOLT	2	
23	M1374100003	HOSE, AIR CLEANER	1	
24	M1374100103	HOSE, AIR CLEANER	1	
25	0605515148	HOSE BAND	1	
26	0605515200	HOSE BAND	2	
27	0602022560	ADAPTER	1	
28	M1320300304	PACKING	1	
29	0602022561	90 DEG. ELBOW	1	
30	0603306590	CONNECTOR	1	

DCA-45USI (50/60 Hz)— ENGINE AND RADIATOR ASSY.

ENGINE & RADIATOR ASSY.



DCA-45USI (50/60 Hz)— ENGINE AND RADIATOR ASSY.

ENGINE & RADIATOR ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
31	0603300285	ROCKNUT	1	
32	0605511395	VALVE	1	
33	0603306395	HOSE JOINT	1	
34	0602021070	CAP	1	
35	0269200310	DRAIN HOSE	1	
36	M2320300103	DRAIN JOINT	1	
37	M920020004	PLUG	1	
38	0150000018	O-RING	1	
39	0016906016	HEX, HEAD BOLT	2	
40	0199100850	DRAIN HOSE	1	
41	0605515106	HOSE BAND	2	
42	M9300000003	RESERVE TANK	1	
43	M9300100003	CAP, RESERVE TANK	1	
44	0199100215	HOSE	1	
45	M1317100004	BRACKET, RESERVE TANK	1	
46	0016908020	HEX, HEAD BOLT	1	
47	0199101700	HOSE	1	
48	0193601200	HOSE	1	
49	0605515106	HOSE BAND	2	
50	0199800730	HOSE	1	
51	0269200480	BLOWBY HOSE	1	
52	0605515198	HOSE BAND	2	
53	0602120465	PICK UP, TACHOMETER	1	
58	M1358300104	HARNESS CLAMP	1	
59	M1358300004	HARNESS CLAMP	1	
60	0016908020	HEX, HEAD BOLT	5	
61	M1358300204	HARNESS CLAMP	1	
62	0017110020	HEX, HEAD BOLT	2	
63	M1924200004	MOTOR FAN	1	
64	0016910025	HEX, HEAD BOLT	4	
65	0602210810	ENGINE STOPPER.....	1	181900-1902
66	0027106016	MACHINE SCREW	3	
67	9827200690	SENDER, OIL PRESSURE	1	
68	8970785920	SENDER, WATER TEMPERATURE	1	
69	8971882810	V-BELT	1	
70	DYNC10502000012	ACTUATOR	1	


ADD THE FOLLOWING DIGITS AFTER THE PART NUMBER WHEN ORDERING ANY PAINTED PANEL TO INDICATE COLOR OF UNIT:

1-ORANGE	5-BLACK
2-WHITE	6-CATERPILLAR YELLOW
3-SPECTRUM GREY	7-CATO GOLD
4-SUNBELT GREEN	8-RED

THE SERIAL NUMBER MAY BE REQUIRED.

DCA-45USI (50/60 Hz)— OUTPUT TERMINAL ASSY.

OUTPUT TERMINAL ASSY.



DCA-45USI (50/60 Hz)— OUTPUT TERMINAL ASSY.

OUTPUT TERMINAL ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1230700103	TERMINAL PANEL	1	
2	M9220100204	OUTPUT TERMINAL BOLT	5	
3	M9220100104	TIE SCREW	5	
4	0039310000	HEX, NUT	10	
5	0040010000	SPRING WASHER	15	
6	0041410000	PLAIN WASHER	20	
7	0016908025	HEX, HEAD BOLT	5	
8	M1236100613	TERMINAL COVER	1	
9	M1236100704	OUTPUT WINDOW	1	
10	0605010040	HINGE	2	
11	0027103010	MACHINE SCREW	4	
11A	0030003000	HEX, NUT	8	
11B	0041203000	PLAIN WASHER	4	
12	0016906020	HEX, HEAD BOLT	2	
13	0016906016	HEX, HEAD BOLT	4	
14	M1236400004	CABLE OUTLET COVER	1	
15	M1236300004	SUPPORTER, CABLE OUTLET COVER	1	
16	0016906020	HEX, HEAD BOLT	6	
17	0601808803	CIRCUIT BREAKER, 1-POLE, 20A	2	QOU 120B
18	0601808804	CIRCUIT BREAKER, 2-POLE, 50A	3	QOU 250B
19	M1260700304	BREAKER FITTING COVER	1	
19A	0222100150	CUSHION RUBBER	1	
20	0016906020	HEX, HEAD BOLT	2	
21	0601812598	RECEPTACLE	2	GF-530EM 125V 20A X 2
22	0601812538	RECEPTACLE	3	CS6369 250V 50A
23	0027104016	MACHINE SCREW	10	
23A	0207004000	HEX, NUT	10	
24	M1236100803	TERMINAL COVER	1	
25	0010112045	HEX, HEAD BOLT	2	
26	0041212000	PLAIN WASHER	2	
27	M9310200004	STAY RUBBER	2	
28	0030012000	HEX, NUT	2	
29	0027103010	MACHINE SCREW	4	


ADD THE FOLLOWING DIGITS AFTER THE PART NUMBER WHEN ORDERING ANY PAINTED PANEL TO INDICATE COLOR OF UNIT:

1-ORANGE	5-BLACK
2-WHITE	6-CATERPILLAR YELLOW
3-SPECTRUM GREY	7-CATO GOLD
4-SUNBELT GREEN	8-RED

THE SERIAL NUMBER MAY BE REQUIRED.

DCA-45USI (50/60 Hz)— BATTERY ASSY.

BATTERY ASSY.




DCA-45USI (50/60 Hz)— BATTERY ASSY.

BATTERY ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	0602220187	BATTERY	1	627MFD
2	M9210500014	BATTERY SHEET	1	
3	M9103000304	BATTERY BAND	1	
4	0602220920	BATTERY BOLT SET	2	BHL-10J 1/4-L10
5	M2346900404	BATTERY CABLE	1	
6	M2346900104	BATTERY CABLE	1	
7		CABLE	1	MAKE LOCALLY
8	0017112025	HEX, HEAD BOLT	1	
8A	0040512000	TOOTHED WASHER	1	
9	0040520000	TOOTHED WASHER	1	
10	74103	BATTERY DISCONNECT SWITCH	1	MOROSO

DCA-45USI (50/60 Hz)— MUFFLER ASSY.

MUFFLER ASSY.




DCA-45USI (50/60 Hz)— MUFFLER ASSY.

MUFFLER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1331100102	MUFFLER	1	
2	0017112030	HEX, HEAD BOLT	4	
3	M1334000003	EXHAUST PIPE	1	
4	0602320101	GASKET	1	894369-0210
5	0039308000	HEX, NUT	6	
6	0602325088	SEAL CLAMP	1	

DCA-45USI (50/60 Hz)— FUEL TANK ASSY.

FUEL TANK ASSY.




DCA-45USI (50/60 Hz)— FUEL TANK ASSY.

FUEL TANK ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1364000102	FUEL TANK	1	
1A	0605505070	FUEL TANK CAP	1	
1B	0605501072	FUEL SENDER UNIT	1	
1C	0605516090	GASKET	1	
2	M1364200004	TANK BAND	4	
3	M9310500104	SUPPORTER SHEET	4	
4	0016908020	HEX, HEAD BOLT	4	
5	0016908065	HEX, HEAD BOLT	2	
5A	0207008000	HEX, NUT	6	
6	0191301300	VENT HOSE	1	
7	0605515109	HOSE BAND	2	
8	897211-2730	FUEL FILTER	1	REPLACES 0602042203
8A	897213-4720	CARTRIDGE, FUEL FILTER	1	REPLACES 0602042701
9	M1367700004	BRACKET, FUEL FILTER	1	
10	0016908020	HEX, HEAD BOLT	4	
11	0191200550	SUCTION HOSE	1	
12	0191201600	SUCTION HOSE	1	
13	0605515108	HOSE BAND	4	
14	0191300750	RETURN HOSE	1	
15	0605515109	HOSE BAND	2	
15	0222100700	TANK SHEET	5	

DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.



DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1414000202	BASE	1	
1A	M1494000004	ACOUSTIC SHEET	1	
2	M1414800003	ENVIRONMENTAL TANK	1	
3	0603306797	PLUG, 1-1/2	1	
4	0017110040	HEX, HEAD BOLT	8	
5	M1424000012	FRONT FRAME	1	
5A	M1494100004	ACOUSTIC SHEET	1	S/N 8200001 TO 8200080
5A	M1493104804	ACOUSTIC SHEET	1	S/N 8200081~
6	M1311600004	RADIATOR COVER	1	
7	0016908020	HEX, HEAD BOLT	2	
8	M1424000302	FRONT FRAME	1	S/N 8200001 TO 8200080
8	M1424000402	FRONT FRAME	1	S/N 8200081~
8A	0314502100	SEAL	1	
8B	M1494100004	ACOUSTIC SHEET	1	S/N 8200001 TO 8200080
8B	M1493104804	ACOUSTIC SHEET	1	S/N 8200081~
9	0601851756	GROMMET, C30-SG-70A	1	S/N 8200001 TO 8200080
10	0601851736	GROMMET, C30-SG-60A	2	
11	0601850266	GROMMET, C30-SG-28A	4	
12	M1424500204	BLOWBY COVER	1	
13	0016906016	HEX, HEAD BOLT	6	
14	M1424500104	GUARD	1	
15	0016906016	HEX, HEAD BOLT	4	
16	0016908020	HEX, HEAD BOLT	8	
17	0016908020	HEX, HEAD BOLT	4	
18	M1424200504	DUCT COVER	2	
19	0016906016	HEX, HEAD BOLT	16	
20	M1311600104	HOSE COVER	1	S/N 8200001 TO 8200080
20	M1484400004	HOSE COVER	1	S/N 8200081~
20	M1484400103	HOSE COVER	1	S/N 8200081~
21	0016906018	HEX, HEAD BOLT	4	
22	M1424200303	COVER, FRONT FRAME	1	S/N 8200001 TO 8200080
22	M1424200313	COVER, FRONT FRAME	1	S/N 8200081~
22A	M1494100104	ACOUSTIC SHEET	1	
23	0016908020	HEX, HEAD BOLT	3	
24	M1434300203	CENTER FRAME	1	
25	M1434300303	CENTER FRAME	1	
26	0010116040	HEX, HEAD BOLT	6	


ADD THE FOLLOWING DIGITS AFTER THE PART NUMBER
WHEN ORDERING ANY PAINTED PANEL TO INDICATE
COLOR OF UNIT:

1-ORANGE	5-BLACK
2-WHITE	6-CATERPILLAR YELLOW
3-SPECTRUM GREY	7-CATO GOLD
4-SUNBELT GREEN	8-RED

THE SERIAL NUMBER MAY BE REQUIRED.

DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.



DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
26A	0040016000	SPRING WASHER	6	
26B	0041216000	PLAIN WASHER	6	
27	0010116040	HEX, HEAD BOLT	4	
27A	0040016000	SPRING WASHER	4	
27B	0041216000	PLAIN WASHER	4	
28	M1444000102	REAR FRAME	1	
28A	M1494300003	ACOUSTIC SHEET	1	
29	M1444800004	DUCT	2	
29A	M1494300204	ACOUSTIC SHEET	1	
30	0207006000	HEX, NUT	12	
31	0016908020	HEX, HEAD BOLT	4	
32	M1444300003	REAR COVER	1	
32A	M1494300104	ACOUSTIC SHEET	1	
33	0016908020	HEX, HEAD BOLT	6	S/N 8200001 TO 8200080
33	0019208020	HEX, HEAD BOLT	6	S/N 8200081~
34	M1444200003	REAR DOOR	1	
35	M1444600004	WINDOW PLATE	1	
36	0207306000	HEX, NUT	8	
36A	0041206000	PLAIN WASHER	8	
37	M9113000002	DOOR HANDLE ASSY.	1	
38	0021806016	MACHINE SCREW	4	
38A	0030006000	HEX, NUT	4	
39	M9112100404	HINGE	2	
40	M9112100604	HINGE	2	
41	0016908020	HEX, HEAD BOLT	8	
42	M1464000002	ROOF PANEL	1	
42A	M1494500004	ACOUSTIC SHEET	1	
43	0016908020	HEX, HEAD BOLT	18	S/N 8200001 TO 8200080
43	0019208020	HEX, HEAD BOLT	18	S/N 8200081~
44	M1465400104	COVER	1	
45	0016908020	HEX, HEAD BOLT	2	S/N 8200001 TO 8200080
45	0019208020	HEX, HEAD BOLT	2	S/N 8200081~
46	M1454200002	SPLASHER PANEL	1	
47	0016908020	HEX, HEAD BOLT	3	
48	0016908065	HEX, HEAD BOLT	1	S/N 8200001 TO 8200080
48	0019208065	HEX, HEAD BOLT	1	S/N 8200081~
49	M1454000403	SIDE DOOR	1	


ADD THE FOLLOWING DIGITS AFTER THE PART NUMBER
WHEN ORDERING ANY PAINTED PANEL TO INDICATE
COLOR OF UNIT:

1-ORANGE	5-BLACK
2-WHITE	6-CATERPILLAR YELLOW
3-SPECTRUM GREY	7-CATO GOLD
4-SUNBELT GREEN	8-RED

THE SERIAL NUMBER MAY BE REQUIRED.

DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.



DCA-45USI (50/60 Hz)— ENCLOSURE ASSY.

ENCLOSURE ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
49A	M1494400404	ACOUSTIC SHEET	1	
50	M1454000103	SIDE DOOR	1	
50A	M1494400104	ACOUSTIC SHEET	1	
51	M1454000503	SIDE DOOR	1	
51A	M1494400504	ACOUSTIC SHEET	1	
52	M1454000303	SIDE DOOR	1	
52A	M1494400304	ACOUSTIC SHEET	1	
53	M9113000002	DOOR HANDLE ASSY.	2	
53A	C9312500004	SEAL RUBBER	2	
54	0021806016	MACHINE SCREW	8	
54A	0030006000	HEX, NUT	8	
55	M9112100404	HINGE	4	
56	M9112100504	HINGE	4	
57	M9112100604	HINGE	8	
58	0016908020	HEX, HEAD BOLT	32	
59	0016908020	HEX, HEAD BOLT	2	
60	0601850097	STOPPER	5	
61	0027208025	MACHINE SCREW	5	
62	0605503062	FUEL LEAK DETECTION SWITCH	1	S/N 8200081~
63	M1414800104	BRACKET	1	S/N 8200081~
64	0017108020	HEX HEAD BOLT	2	S/N 8200081~


ADD THE FOLLOWING DIGITS AFTER THE PART NUMBER
WHEN ORDERING ANY PAINTED PANEL TO INDICATE
COLOR OF UNIT:

1-ORANGE	5-BLACK
2-WHITE	6-CATERPILLAR YELLOW
3-SPECTRUM GREY	7-CATO GOLD
4-SUNBELT GREEN	8-RED

THE SERIAL NUMBER MAY BE REQUIRED.

DCA-45USI (50/60 Hz)— RUBBER SEALS ASSY.

RUBBER SEALS ASSY.




DCA-45USI (50/60 Hz)— RUBBER SEALS ASSY.

RUBBER SEALS ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	0229200950	SEAL RUBBER	1	
2	0228901385	SEAL RUBBER	3	
3	0228900900	SEAL RUBBER	3	
4	0229400900	SEAL RUBBER	1	
5	0228900795	SEAL RUBBER	1	
6	0028900590	SEAL RUBBER	1	
7	0229400445	SEAL RUBBER	1	
8	0228800455	SEAL RUBBER	1	
9	0228900445	SEAL RUBBER	1	
10	0229200455	SEAL RUBBER	1	
11	0228100870	SEAL RUBBER	2	
12	0229200840	SEAL RUBBER	1	
13	0229200560	SEAL RUBBER	2	
14	0229200790	SEAL RUBBER	1	
15	0228800800	SEAL RUBBER	1	S/N 8200001 TO 8200080
15	0228800800	SEAL RUBBER	2	S/N 8200081~
16	0228900475	SEAL RUBBER	1	S/N 8200001 TO 8200080
16	0228900470	SEAL RUBBER	1	S/N 8200081~
17	0228800475	SEAL RUBBER	1	S/N 8200001 TO 8200080
17	0228800470	SEAL RUBBER	1	S/N 8200081~
18	0228100420	SEAL RUBBER	2	
19	0228100325	SEAL RUBBER	2	
20	0314500700	SEAL	1	
22	0330000460	EDGING	1	
23	0330000180	EDGING	1	

DCA-45USI (50/60 Hz)— NAMEPLATE AND DECALS ASSY.

NAME PLATE ASSY.



DCA-45USI (50/60 Hz)— NAMEPLATE AND DECALS ASSY.

NAME PLATE ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	M1511400002	DECAL, GENERATOR CONTROL	1	M11140000A
2	M1511400102	DECAL, ENGINE OPERATING	1	M11140010A
3	M1550000204	DECAL, NOTE	1	M15000020
4	M1550000703	DECAL, AUXILIARY OUTPUT	1	M15000070
5	M1550000804	DECAL, NOTE	1	M15000080
6	M9500000004	DECAL, OIL DRAIN PLUG	1	M90000000
7	M9500100004	DECAL, WATER	1	M90010000
8	M9500300004	DECAL, -	1	M90030000
9	M9500300104	DECAL, +	1	M90030010
10	M9500500004	DECAL, DIESEL FUEL	1	M90050000
11	M9503000004	DECAL, WARNING MOVING PARTS	2	M90300000
12	M9503000103	DECAL, WATER - OIL CHECK	1	M90300010
13	M9503100004	DECAL, WARNING HOT COOLANT	1	M90310000
14	M9503200004	DECAL, WARNING ENGINE EXHAUST	1	M90320000
15	M9510000004	DECAL, FLUID DRAIN	1	M91000000
16	M9510100004	DECAL, CAUTION HOT PARTS	1	M91010000
17	M9512200004	DECAL, MQ	1	M91220000
18	M9520000004	DECAL, GROUND	1	M92000000
19	M9520000104	DECAL, AMMETER CHANGE-OVER SW.	1	M92000010
20	M9520000204	DECAL, VOLTMETER CHANGE-OVER SW.	1	M92000020
21	M9520100004	DECAL, WARNING ELECTRIC SHOCK HAZARD	2	M92010000
22	M9520100204	DECAL, CAUTION	1	M92010020A
23	M9520100304	DECAL, SAFETY INSTRUCTION	1	M92010030
24	M9520100404	DECAL, DANGER HIGH VOLTAGE	1	M92010040
25	M9520100503	DECAL, WARNING	1	M92010050
26	M9520200003	DECAL, CONNECTION OF OUTPUT CABLE	1	M92020000
27	M9520200104	DECAL, OVER CURRENT RELAY	1	C92020010
28	M1561000004	DECAL, MQ POWER	3	S/N 8200001 TO 8200080
28	M1561000004	DECAL, MQ POWER	2	S/N 8200081~
29	M1561100004	STRIPE	2	
30	M1561100103	STRIPE, WHISPERWATT	2	
31	M1561100204	STRIPE, 45	1	
32	M1561100304	STRIPE, 45	1	
33	M1561100404	STRIPE	2	
34	M9510100304	DECAL, ENVIRONMENTAL WARNING	1	S/N 8200081~
35	M9520000304	DECAL, FUEL LEAK DETECTED	1	S/N 8200081~
36	0600500092	PLATE, MQ POWER	1	S/N 8200081~
37	0021106016	MACHINE SCREW	4	S/N 8200081~

PAYMENT TERMS

Terms of payment for parts are net 10 days.

FREIGHT POLICY

All parts orders will be shipped collect or prepaid with the charges added to the invoice. All shipments are F.O.B. point of origin. Multiquip's responsibility ceases when a signed manifest has been obtained from the carrier, and any claim for shortage or damage must be settled between the consignee and the carrier.

MINIMUM ORDER

The minimum charge for orders from Multiquip is \$15.00 net. Customers will be asked for instructions regarding handling of orders not meeting this requirement.

RETURNED GOODS POLICY

Return shipments will be accepted and credit will be allowed, subject to the following provisions:

1. A Returned Material Authorization must be approved by Multiquip prior to shipment.
2. To obtain a Return Material Authorization, a list must be provided to Multiquip Parts Sales that defines item numbers, quantities, and descriptions of the items to be returned.
 - a. The parts numbers and descriptions must match the current parts price list.
 - b. The list must be typed or computer generated.
 - c. The list must state the reason(s) for the return.
 - d. The list must reference the sales order(s) or invoice(s) under which the items were originally purchased.
 - e. The list must include the name and phone number of the person requesting the RMA.
3. A copy of the Return Material Authorization must accompany the return shipment.
4. Freight is at the sender's expense. All parts must be returned freight prepaid to Multiquip's designated receiving point.

5. Parts must be in new and resalable condition, in the original Multiquip package (if any), and with Multiquip part numbers clearly marked.
6. The following items are not returnable:
 - a. Obsolete parts. (If an item is in the price book and shows as being replaced by another item, it is obsolete.)
 - b. Any parts with a limited shelf life (such as gaskets, seals, "O" rings, and other rubber parts) that were purchased more than six months prior to the return date.
 - c. Anyline item with an extended dealer net price of less than \$5.00.
 - d. Special order items.
 - e. Electrical components.
 - f. Paint, chemicals, and lubricants.
 - g. Decals and paper products.
 - h. Items purchased in kits.
7. The sender will be notified of any material received that is not acceptable.
8. Such material will be held for five working days from notification, pending instructions. If a reply is not received within five days, the material will be returned to the sender at his expense.
9. Credit on returned parts will be issued at dealer net price at time of the original purchase, less a 15% restocking charge.
10. In cases where an item is accepted, for which the original purchase document can not be determined, the price will be based on the list price that was effective twelve months prior to the RMA date.
11. Credit issued will be applied to future purchases only.

PRICING AND REBATES

Prices are subject to change without prior notice. Price changes are effective on a specific date and all orders received on or after that date will be billed at the revised price.

Rebates for price declines and added charges for price increases will not be made for stock on hand at the time of any price change.

Multiquip reserves the right to quote and sell direct to Government agencies, and to Original Equipment Manufacturer accounts who use our products as integral parts of their own products.

SPECIAL EXPEDITING SERVICE

A \$35.00 surcharge will be added to the invoice for special handling including bus shipments, insured parcel post or in cases where Multiquip must personally deliver the parts to the carrier.

LIMITATIONS OF SELLER'S LIABILITY

Multiquip shall not be liable here under for damages in excess of the purchase price of the item with respect to which damages are claimed, and in no event shall Multiquip be liable for loss of profit or good will or for any other special, consequential or incidental damages.

LIMITATION OF WARRANTIES

No warranties, express or implied, are made in connection with the sale of parts or trade accessories nor as to any engine not manufactured by Multiquip. Such warranties made in connection with the sale of new, complete units are made exclusively by a statement of warranty packaged with such units, and Multiquip neither assumes nor authorizes any person to assume for it any other obligation or liability whatever in connection with the sale of its products. Apart from such written statement of warranty, there are no warranties, express, implied or statutory, which extend beyond the description of the products on the face hereof.

[illegible]

OPERATION AND PARTS MANUAL

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL
NUMBER *ON-HAND* WHEN CALLING

MQ POWER CORPORATE OFFICE

18910 Wilmington Ave. 800-421-1244
Carson, CA 90746 FAX: 310-632-2656
Email: mqpower@multiquip.com
Internet: www.mqpower.com

PARTS DEPARTMENT

800-427-1244 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

SERVICE DEPARTMENT

800-835-2551 FAX: 310-638-8046
310-537-3700

TECHNICAL ASSISTANCE

800-478-1244 FAX: 310-631-5032

WARRANTY DEPARTMENT

800-835-2551, EXT. 279 FAX: 310-638-8046
310-537-3700, EXT. 279

Your Local Dealer is:

Manufactured for Multiquip Inc.
by
DENYO CO., LTD, JAPAN



MQ POWER

A Division of Multiquip Inc.

POST OFFICE BOX 6254

CARSON, CA 90749

310-537-3700 • 800-421-1244

FAX: 310-632-2656

E-mail: mqpower@multiquip.com

Internet: www.mqpower.com