

**Disabling generator set. Accidental starting can cause severe injury or death.** Turn generator set master switch to OFF position, disconnect power to battery charger, and remove battery cables (remove negative lead first and reconnect it last) to disable generator set before working on the generator set or connected equipment. The generator set can be started by an automatic transfer switch or remote start/stop switch unless these precautions are followed.

# Installation

1. Place the generator set master switch in the OFF position.
2. Disconnect the generator set engine starting battery(ies), negative (–) lead first. Disconnect power to the battery charger, if equipped.
3. Remove controller cover.
4. Mount the dry-contact box in one of the areas listed below. Use the contact assembly as a template and drill the necessary mounting holes.
  - Inside the junction box.
  - On top of the junction box. Limited by the size of the controller and the size of the junction box.
  - On top of the generator skid. Limited by the clearance and housing options.
  - In an area as near to the generator set controller as practical.
5. Attach the contact assembly with customer supplied hardware. Place four spacers (X-400-28) between the dry-contact box bottom and the mounting surface.

## NOTE

Location of lead connections on controller terminal strip vary depending on controller.

6. Connect the contact assembly to the controller or connection box, if used, using the 5 ft. (1.5 m) wiring harness provided. Connect controller/junction box terminals 2 (ground) and 42A (battery voltage) to the alarm contact terminal strip providing an electrical source to operate the K1-K10 relays.

To determine which accessory connection wiring diagram to use, identify the type of generator set controller by the number of terminal strips on the controller circuit board. See Figure 2.

Terminal Strip Qty.	Wiring Diagram
TB1	Figure 4
TB1 and TB2	Figure 5
TB1, TB2, TB3, and TB4	Figure 6

**Figure 2. Generator Set Controller Identification**


Choose up to ten functions to activate the alarm. When a generator fault condition occurs, the relay (K1-K10) tied to that function energizes.

Select normally open or normally closed contacts from each relay depending upon application requirements. Relay-contact closure corresponds to the activated controller light.

7. Verify that the electrical supply meets the requirements of the customer-provided devices connected to the dry-contact kit.
8. Reinstall the controller cover.
9. Reconnect the generator set engine starting battery, negative (–) lead last.

## Ten-Relay Dry-Contact Kit

Parts List		
Kits: PA-273913 and PA-273913-SD		
Qty.	Description	Part Number
4	Spacer	X-400-28
1	Contact assembly (includes*)	A-273936
6	*Washer, shakeproof #8	X-22-12
1	*Board assembly, circuit	D-294303
4	*Screw, hex	X-6216-1
6	*Nut, hex	X-70-12
1	*Grommet	243319
1	*Cover, dry contact	273934
1	*Harness, wiring	273935
6	*Mount, vibro	282829
1	*Box, dry contact	336394



**Figure 3. Ten-Relay Dry-Contact Kit**

### TB1 Terminal Strip

- 1 Ground—emergency stop relay (K4)—Connect emergency stop across terminals TB1-1 and 1A†
- 1A Emergency Stop Relay (K4) coil; negative side—Connect emergency stop across terminals TB1-1 and 1A†
- 2 Ground terminal
- 3 Remote start ground—Connect transfer switch or remote start switch to TB1-3 and TB1-4
- 4 Remote start—Connect transfer switch or remote start switch to TB1-3 and TB1-4
- 9 Crank mode selection (open—cyclic crank; ground—continuous crank).  
Connect TB1-2 to TB1-9 for continuous cranking; leave TB1-9 open cyclic cranking—see Starting
- 12 Overcrank (OC) signal\*
- 26 Auxiliary (AUX) signal\*
- 32 Common Fault/Prealarm Line—A/V alarm or common fault relay  
activated by OC, 12; AUX, 26; LWT, 35; HET, 36; LOP, 38; OS, 39; AHET, 40; ALOP, 41; and LF, 63 faults
- 35 Low water temperature (LWT) signal
- 36 High engine temperature (HET) signal\*
- 38 Low oil pressure (LOP) signal\*
- 39 Overspeed (OS) signal\*
- 40 Anticipatory high engine temperature (AHET) signal\*
- 41 Anticipatory low oil pressure (ALOP) signal\*
- 42A Battery voltage (fuse #1 protected)—Accessory power supply;  
Customer may also provide separate accessory power source
- 48 Emergency stop (ES) signal\*
- 56 Air damper (AD) switch, if equipped. Standard on all 200-2000 kW Detroit Diesel powered models
- 60 System ready signal\*
- 61 Battery charger fault—Connect battery charger alarm contact to TB1-61 to activate fault lamp (active low), if used
- 62 Low battery volts—Connect battery charger alarm contact to TB1-62 to activate fault lamp (active low), if used
- 63 Low fuel (LF) fault—Connect fuel level sensor to TB1-63 to activate fault lamp (active low), if used
- 80 Not in auto signal\*

NOTE: Not all terminals are used for all generator sets; see appropriate wiring diagrams for specific generator set model  
† Connect jumper across terminals 1 and 1A if emergency stop switch is not used.

\* Use a remote annunciator and/or A/V alarm kit as an indicator with a dry contact kit connected to controller terminal strip TB1.




Figure 4. Controller with TB1 Terminal Strip

### TB1 Terminal Strip

- 1 Ground—emergency stop relay (K4)—Connect emergency stop across terminals TB1-1 and 1A†
- 1A Emergency Stop Relay (K4) coil; negative side—Connect emergency stop across terminals TB1-1 and 1A†
- 2 Ground terminal
- 12 Overcrank (OC) signal\*
- 26 Auxiliary (AUX) signal\*
- 32 Common Fault/Prealarm Line 1—A/V alarm or common fault relay activated by OC, 12; AUX, 26; LWT, 35; HET, 36; LOP, 38; OS, 39; AHET, 40; ALOP, 41; and LF, 63 faults
- 32A Common Fault/Prealarm Line 2—A/V alarm or common fault relay activated by AUX, 26; HET, 36; LOP, 38; OS, 39; and ES, 48 faults
- 35 Low water temperature (LWT) signal
- 36 High engine temperature (HET) signal\*
- 38 Low oil pressure (LOP) signal\*
- 39 Overspeed (OS) signal\*
- 40 Anticipatory high engine temperature (AHET) signal\*
- 41 Anticipatory low oil pressure (ALOP) signal\*
- 42A Battery voltage (fuse #1 protected)—Accessory power supply; Customer may also provide separate accessory power source
- 48 Emergency stop (ES) signal\*
- 56 Air damper (AD) switch, if equipped. Standard on all 200-2000 kW Detroit Diesel powered models
- 60 System ready signal\*
- 61 Battery charger fault—Connect battery charger alarm contact to TB1-61 to activate fault lamp (active low), if used
- 62 Low battery volts—Connect battery charger alarm contact to TB1-62 to activate fault lamp (active low), if used
- 63 Low fuel (LF) fault—Connect fuel level sensor to TB1-63 to activate fault lamp (active low), if used
- 70C Generator in cool down mode signal
- 70R Generator in running mode signal
- 80 Not in auto signal\*

NOTE: Not all terminals are used for all generator sets; see appropriate wiring diagrams for specific generator set model


† Connect jumper across terminals 1 and 1A if emergency stop switch is not used.

\* Use a remote annunciator and/or A/V alarm kit as an indicator with a dry contact kit connected to controller terminal strip TB1.

### TB2 Terminal Strip

- 1P Prime power operation
- 2P Prime power operation
- 3 Remote start ground—Connect transfer switch or remote start switch to TB2-3 and TB2-4
- 3P Prime power operation
- 4 Remote start—Connect transfer switch or remote start switch to TB2-3 and TB2-4
- 4P Prime power operation
- 9 Crank mode selection (open—cyclic crank; ground—continuous crank).  
Connect TB2-9 to TB2-9A for continuous cranking; leave TB2-9 open cyclic cranking—see Starting
- 9A Crank mode ground

NOTE: To use prime power mode—place jumpers across TB2-1P to TB2-2P, TB2-3P to TB2-4P, and TB2-3 to TB2-4. To deactivate prime power mode—remove jumpers across TB2-1P to TB2-2P, TB2-3P to TB2-4P, and TB2-3 to TB2-4.



328912A-C

Figure 5. Controller with TB1 and TB2 Terminal Strips

### TB1 Terminal Strip—Output Connections

1	Engine ground	18	42A battery voltage—accessory power supply
2	Engine ground	19	42A battery voltage—accessory power supply
3	Engine ground	20	42A battery voltage—accessory power supply
4	Engine ground	21	Digital voltage regulator (DVR) adjustment down
5	Panel lamp layout	22	Digital voltage regulator (DVR) adjustment common
6	Relay driver output (RDO)—10	23	Digital voltage regulator (DVR) adjustment up
7	Relay driver output (RDO)—9	24	Relay driver output (RDO)—8
8	Relay driver output (RDO)—7	25	Relay driver output (RDO)—6
9	Relay driver output (RDO)—5	26	Relay driver output (RDO)—4
10	Not in auto relay output (80)	27	Relay driver output (RDO)—3
11	Overcrank relay output (12)	28	Relay driver output (RDO)—2
12	Low battery voltage relay output	29	Relay driver output (RDO)—1
13	Low coolant temperature relay output (35)	30	System ready output (60)
14	Low oil pressure relay output (38)	31	Emergency stop relay output (48)
15	High coolant temperature relay output (36)	32	Battery charger fault relay output (61)
16	Low oil pressure warning relay output (41)	33	Low fuel relay output
17	High coolant temperature warning relay output (40)	34	Overspeed relay output (39)

NOTE: Not all terminals are used for all generator sets (see appropriate wiring diagrams for specific generator set model).  
Use a remote annunciator and/or A/V alarm kit as an indicator with a dry contact kit connected to controller terminal strip TB1.  
RDO outputs are active low (—).

### TB2 Terminal Strip—Input Connections

RMT RST	Remote reset*
GND FLT	Ground fault*
SP1	Not used
SP2	Not used
BCF	Battery charger fault*
LF	Low fuel*
PP	Prime power mode*
GND	Engine ground
GND	Engine ground
GND	Engine ground

\* Connect to ground to activate

### TB3 Terminal Strip—Input Connections

1	Emergency stop ground
1A	Emergency stop
3	Remote start
4	Remote start
AX1	Auxiliary 1*
AX2	Auxiliary 2*
AX3	Auxiliary 3*
AX4	Auxiliary 4*
7C	Oil pressure
5	Coolant temperature

\* Connect to ground to activate

### TB4 Terminal Strip—AC Input Connections

L0	L0 (V0)
L1	L1 (V7)
L2	L2 (V8)
L3	L3 (V9)
-	Not used
C3	C3
C2	C2
C1	C1
C0	C0




Figure 6. Controller with TB1, TB2, TB3, and TB4 Terminal Strips