

Service and Parts



Automatic Transfer Switches

Models:

R120

Electrical Controls:
Solid-State

Power Switching Device
Contactors:
100 and 200 Amperes

Table of Contents

Safety Precautions and Instructions	I	4.8 Controller Operation	35
Introduction	i	4.9 Emergency Source Sensing	36
List of Related Materials	i	4.10 Normal Source Sensing	37
Service Assistance	ii	Section 5 Diagrams	39
Service Information	ii	Section 6 Service Part Replacement	43
Product Information	ii	6.1 Before and After Servicing Components	44
Section 1 Specifications	1	6.2 Contactor Assembly	45
1.1 Purpose	1	6.2.1 Contactor Assembly Removal	45
1.2 Components	1	6.2.2 Contactor Assembly Installation	45
1.3 Nameplate	2	6.3 Solenoid Assembly	46
1.4 Model Number	2	6.3.1 Solenoid Assembly Removal	46
1.5 Specifications	4	6.3.2 Solenoid Assembly Installation	46
1.6 Ratings	4	6.4 Controller PCB Assembly	47
1.7 Application Data	5	6.4.1 Controller PCB Removal	47
Section 2 Operation	7	6.4.2 Controller PCB Installation	47
2.1 Startup	7	6.5 Other Service Parts	48
2.2 Automatic Operation	8	6.5.1 Other Service Part Removal	48
2.2.1 Failure of Normal Power	8	6.5.2 Other Service Part Installation	48
2.2.2 Restoration of Normal Power	9	Section 7 Service Parts	49
2.3 Exerciser Function	10	7.1 General Information	49
2.3.1 Exerciser Switch	10	7.1.1 Finding Parts Information	49
2.3.2 Exerciser Power Requirements	10	7.1.2 Leads	49
2.4 Manual Operation	11	7.1.3 Common Hardware	49
2.5 External Test Switch	13	7.2 Contactor	50
Section 3 Scheduled Maintenance	15	7.3 Controls	51
3.1 Inspection and Service	16	7.4 Decals	52
3.1.1 General Inspection	16	7.5 Enclosure	53
3.1.2 Internal Inspections, Procedures, and Tests	17	7.6 Neutral Lug	55
3.2 Testing	19	Appendix A Abbreviations	A-1
3.2.1 Weekly Generator Set Exercise	19	Appendix B Common Hardware Application Guidelines	A-3
3.2.2 Monthly Automatic Operation Test	19	Appendix C General Torque Specifications	A-4
3.2.3 Other Tests	19	Appendix D Common Hardware Identification	A-5
3.3 Service Schedule	21	Appendix E Common Hardware List	A-6
Section 4 Troubleshooting	23		
4.3 General Notes on Connections	27		
4.4 Power to the System	27		
4.4.1 AC System Voltages	27		
4.4.2 DC Controller Voltages	27		
4.5 Engine Start Circuit	28		
4.6 Exerciser Circuits	29		
4.7 Contactor Operation	30		
4.7.1 Mechanical Check	30		
4.7.2 Initial Solenoid and Rectifier Troubleshooting	30		
4.7.3 Solenoid Test	30		
4.7.4 Rectifier Test	30		
4.7.5 After Solenoid Replacement	31		
4.7.6 Coil-Clearing Contacts	31		
4.7.7 NR/ER Relays and Controller Circuitry	32		

Safety Precautions and Instructions

Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**


NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

Battery acid. Sulfuric acid in batteries can cause severe injury or death. Sulfuric acid in the battery can cause blindness and burn skin. Always wear splashproof safety goggles when working near the battery. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.


⚠ WARNING 
Explosion. Can cause severe injury or death. Relays in the battery charger cause arcs or sparks. Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove wristwatch, rings, and other jewelry before handling the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together. Sparks could ignite the battery gases or fuel vapors. Ventilate the compartments containing batteries to prevent accumulation of explosive gases. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Hazardous Voltage/ Electrical Shock

⚠ WARNING 
Hazardous voltage. Can cause severe injury or death. Disconnect all power sources before opening the enclosure.

(600 volts and under)

⚠ WARNING 
Hazardous voltage. Moving rotor. Can cause severe injury or death. Operate the generator set only when all guards and electrical enclosures are in place.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Making line or auxiliary connections. Hazardous voltage can cause severe injury or death. To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

⚠ WARNING 
Hazardous voltage. Can cause severe injury or death. Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

(600 volts and under)

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

Servicing the transfer switch controls and accessories within the enclosure. Hazardous voltage can cause severe injury or death. Disconnect the transfer switch controls at the inline connector to deenergize the circuit boards and logic circuitry but allow the transfer switch to continue to supply power to the load. Disconnect all power sources to accessories that are mounted within the enclosure but are not wired through the controls and deenergized by inline connector separation. Test circuits with a voltmeter to verify that they are deenergized before servicing.

⚠ WARNING

Hazardous voltage. Can cause severe injury or death. Only authorized personnel should open the enclosure.

(600 volts and under)

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.

(600 volts and under)

Heavy Equipment

⚠ WARNING

Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage. Use adequate lifting capacity. Never leave the transfer switch standing upright unless it is securely bolted in place or stabilized.

Moving Parts

⚠ WARNING
 
Hazardous voltage. Moving rotor. Can cause severe injury or death. Operate the generator set only when all guards and electrical enclosures are in place.

Notice

NOTICE

Hardware damage. The transfer switch may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

When replacing hardware, do not substitute with inferior grade hardware. Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings, and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

NOTICE

Improper operator handle usage. Use the manual operator handle on the transfer switch for maintenance purposes only. Return the transfer switch to the normal position. Remove the manual operator handle, if used, and store it in the place provided on the transfer switch when service is completed.

NOTICE

Foreign material contamination. Cover the transfer switch during installation to keep dirt, grit, metal drill chips, and other debris out of the components. Cover the solenoid mechanism during installation. After installation, use the manual operating handle to cycle the contactor to verify that it operates freely. Do not use a screwdriver to force the contactor mechanism.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

Notes

This manual provides service and parts information for DDC/MTU Power Generation Model R120 transfer switches with solid-state electrical controls and 100 and 200 ampere contactor power switching devices. This manual includes operation, troubleshooting, repair, and maintenance procedures for the transfer switch including the power switching device and electrical controls. This manual is intended for the use only by persons trained and qualified to work on electrical equipment.

Information in this publication represents data available at the time of print. The manufacturer of DDC/MTU Power Generation products reserves the right to change this literature and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are very important to safe and efficient operation. Inspect parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/dealer to keep equipment in top condition.

List of Related Materials

A separate operation and installation manual contains operation and installation information not provided in this manual. The following table lists the available manual part numbers.

Model	Operation/ Installation Manual
Model R120 (100 and 200 ampere contactor power switching device and solid-state electrical controls)	MP-5990

Service Assistance

Service Information

For professional advice on generator power requirements and conscientious service, please contact your nearest DDC/MTU Power Generation distributor.

- Consult the Yellow Pages under the heading Generators—Electric
- Visit the DDC/MTU Power Generation website at ddcmtupowergeneration.com
- Look at the labels and stickers on your DDC/MTU Power Generation product or review the appropriate literature or documents included with the product

Product Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Transfer Switch Identification Numbers

Record the product identification numbers from the transfer switch nameplate.

Model Number _____

Serial Number _____

Accessory Number	Accessory Description
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Section 1 Specifications


1.1 Purpose

An automatic transfer switch (ATS) transfers electrical loads from a normal (preferred or utility) source of electrical power to an emergency (standby or replacement) source when the normal source fails to maintain a minimum power quality level.

When the normal source fails, the ATS signals the emergency source generator set to start. When the emergency source reaches a minimum quality level, the ATS transfers the load from the normal source to the emergency source. The ATS continuously monitors the normal source and transfers the load back to the normal source when the normal source returns. After transferring the load back to the normal source, the ATS removes the generator start signal, allowing the generator set to shut down.

1.2 Components

The ATS documented in this manual contains several components. See Figure 1-1. The contactor power switching device connects the load to the normal or emergency sources of power. The electrical controls monitor power sources, control the contactor, and signal the generator to start when needed. The exerciser switch controls the operation of the exerciser function.



1. Power switching device (contactor)
2. Enclosure
3. Electrical controls (solid-state)
4. Enclosure cover
5. Exerciser switch

Figure 1-1. ATS Components

The contactor power switching device transfers power from the normal or emergency power sources to the load. The electrical controls electrically actuate the contactor to select a power source, and the contactor mechanically latches in the selected position. The contactor also includes a provision for manual operation in emergency nonpowered conditions.

The contactor power switching device uses two sets of multipole contacts. See Figure 1-2. One set of contacts connects the load to the normal source and the other set connects the load to the emergency source. The double-throw, inherently interlocked design of the contactor prevents simultaneous closing of both sets of contacts and cross-coupling of power sources.





Figure 1-2. Typical ATS Block Diagram

1.3 Nameplate

A nameplate attached to the inside of the enclosure door or cover includes a model number, a serial number, ratings, and other information that may be needed for operation, installation, service, or to order parts. See Figure 1-3 or Figure 1-4.


Copy the model number, serial number, and accessory information from the nameplate into the spaces provided in the Service Assistance section in this manual for use when requesting service or parts. Copy the model number into the blank spaces in Figure 1-6 and use the figure to interpret the model number code.

Copy the model number and serial number from the nameplate into the spaces provided in the Service Assistance section of this manual for use when requesting service or parts.



1. Model number
2. Factory-installed accessory numbers
3. Serial number

**Figure 1-3. Typical Transfer Switch Nameplate
(used before April 8, 1999)**



1. Model number
2. Serial number
3. Factory-installed accessory numbers

**Figure 1-4. Typical Transfer Switch Nameplate
(used on or after April 8, 1999)**

1.4 Model Number

Some Model R120 ATSSs have a model number beginning with R120 that directly encodes the transfer switch properties. See Figure 1-6 to interpret this type of transfer switch model number.

Model R120 transfer switches manufactured before April 8, 1999 used voltage and frequency codes beginning with 2 to indicate a contactor voltage rating of 250 volt maximum. Model R120 transfer switches manufactured on or after April 8, 1999 use voltage and frequency codes beginning with 6, but the maximum voltage remains 250 volts. See Figure 1-5 to determine the voltage and frequency of a switch that uses a voltage and frequency code beginning with 2.

Old Code	New Code	Voltage and Frequency
23	63	220 Volt, 50 Hz
24	64	240 Volt, 60 Hz
28	68	208 Volt, 60 Hz

Figure 1-5. Voltage and Frequency Code Conversion

Record the transfer switch model number in the boxes below. The transfer switch model number defines characteristics and ratings as explained in the accompanying chart.

Model	Controls	Voltage and Frequency	Poles	Wires	Enclosure	Current Rating

DDC/MTU Power Generation Model Number Key

This chart explains the DDC/MTU Power Generation transfer switch model number code. The sample model number shown is for a Model R120 automatic transfer switch that uses a 250-volt maximum contactor power switching device with solid-state electrical controls rated at 240 volts, 60 hertz, 1 phase, 2 pole, and 3 wires in a NEMA Type 1 enclosure with a current rating of 200 amperes. Not all possible combinations are available.

SAMPLE MODEL NUMBER

R120-164231-0200

Model

R120: Model R120 transfer switch, 250-volt maximum contactor

Electrical Controls

1: Solid-state

Voltage and Frequency

63: 220 Volt, 50 Hz

64: 240 Volt, 60 Hz

68: 208 Volt, 60 Hz

Number of Poles and Phases

2: 2 Pole, 1 Phase

3: 3 Pole, 3 Phase

Number of Wires

3: 3 Wire

4: 4 Wire

Enclosure

1 = NEMA type 1

3 = NEMA type 3R

Current Rating

Numbers indicate the current rating of the switch in amperes.

Figure 1-6. Transfer Switch Model Number Code

1.5 Specifications

The following specifications apply to the Model R120 ATS.

- UL 1008 listed and CSA certified
- Contactors rated 250 VAC maximum, 50 or 60 Hz
- ATS available with ratings of 100 and 200 amperes, 2 or 3 poles, single- or three-phase
- NEMA type 1 and 3R enclosures available
- Integrated solid-state electrical controls with conformally coated printed circuit board for protection against harsh environments
- Emergency source voltage sensing one phase: dropout fixed at 160 VAC and pickup fixed at 190 VAC
- Single-phase switches: normal source dropout fixed at 160 VAC and pickup fixed at 190 VAC
- Three-phase switches: normal source dropout fixed at approximately 80% of nominal for single-phase failure and pickup fixed at approximately 90% of nominal
- Time delay engine start (TDES) fixed at 3 seconds
- Time delay normal-to-emergency (TDNE) fixed at 2 seconds
- Time delay emergency-to-normal (TDEN) fixed at 12 seconds
- Time delay engine cooldown (TDEC) fixed at 2 minutes
- User-enabled generator exerciser: starts and runs the generator unloaded for a 20-minute period once a week
- Transfer time 50 milliseconds maximum
- Contactor electrically and mechanically interlocked
- Contactor manually operable, no load, for maintenance purposes
- Provision for test switch
- Ambient operating temperature range
-4° to 140°F (-20° to 60°C)
- Ambient storage temperature range
-22° to 158°F (-30° to 70°C)
- Humidity range 5 to 85% noncondensing

1.6 Ratings

The following tables provide contactor withstand and closing current ratings (WCR) per UL 1008 standards. Figure 1-7 provides WCR when used with given types of fuses and circuit breakers. Figure 1-8 provides WCR for 100 and 200 ampere switch sizes when coordinated with specific manufacturer's circuit breakers. Figure 1-8 has ratings for 240 V maximum and applies to both UL and CSA listings.

Switch Rating (amps)	Withstand and Closing Ratings* per UL 1008 and CSA, Maximum Current (amps)		
	When Used With 400 Amps Maximum Class J, RK5, or RK1 Fuse	When Coordinated With Molded-Case Circuit Breakers	
		Any, 400 Amps Maximum	Specific Manufacturer's (see Figure 1-8)
100	200,000	10,000	22,000
200	200,000	10,000	22,000

* UL 1008 listed and CSA certified at 240 VAC maximum.

Figure 1-7. Withstand and Closing Current Ratings

WCR, RMS Symmetrical Amperes	Specific Manufacturer's Molded-Case Circuit Breakers		
	Manufacturer	Type or Class	Maximum Size (amps)
22,000	Cutler-Hammer/ Westinghouse	FCL, FB Tripac	100
		FD, FDC, HFD	150
		HJD, JD, JDB, JDC	250
		HKD, KD, KDB, KDC, LA Tripac, LCL, DK	400
	Square D	FC, FH, FI	100
		KA, KC, KH, KI	250
		LA, LC, LE, LH, LI, LX, LXI	400
	ITE/Siemens	CED6, ED6, HED4, HED6, ED4	125
		CFD6, FD6, FXD6, HFD6	250
		CJD6, HJD6, HHJD6, HHJXD6, JD6, JXD6, SCJD6, SHJD6, SJD6	400
	GE	TB1	100
		SEL, SEP, TEL, THED, THLC1	150
		TFK, TFL, THFK, THLC2	225
		SFL, SFP, TFJ	250
		SGL4, SGP4, TB4, THJK4, THLC4, TJJ, TJK4, TLB4	400

* UL 1008 listed and CSA certified at 240 VAC maximum.

Figure 1-8. Withstand and Closing Current Ratings (WCR) With Coordinated Circuit Breakers, 240 V Maximum, UL and CSA Listings


1.7 Application Data

See Figure 1-9 for application data including the range of wire sizes for transfer switch power terminals.

UL-Listed Solderless Screw-Type Terminals for External Power Connections		
Switch Rating (amps)	Normal, Emergency, and Load Terminals	
	Cables per Pole	Range of Wire Sizes
100	1	#8 to 3/0 (copper or aluminum)
200	1	#8 to 3/0 (copper only)

Figure 1-9. Application Data

Notes



(600 volts and under)

Have preventive maintenance performed on the transfer switch at regular intervals after installation. See Section 4 for instructions.

Contact an authorized distributor/dealer to inspect and service the transfer switch when any wear, damage, deterioration, or malfunction of the transfer switch or its components is evident or suspected; *do not energize the switch*.

2.1 Startup

Perform the following powerup procedure after maintenance or service of the standby system that requires disconnection of power sources from the transfer switch, *not for initial startup*.

For initial startup, follow the instructions in the Installation section in the operation and installation manual for the transfer switch. See List of Related Materials in the Introduction section of this manual for the manual part number.

Read and understand documentation provided with the switch and labels affixed to the switch. Review the operation of installed accessories.

Follow the steps below to power up the transfer switch and prepare it for automatic operation.

Powerup Procedure

1. Place the generator set master switch in the OFF position to prevent starting the generator set.
2. Disconnect *both* the normal and emergency power sources by opening circuit breakers or switches leading to the transfer switch.
3. Open the enclosure and check that the contactor wiring harness is connected to the electrical controls at connector P1. See Figure 4-1.
4. Follow the manual operation procedure to prepare the transfer switch for automatic operation. See Section 2.4 for instructions.

5. Replace the transfer switch enclosure cover. Lock NEMA type 3R enclosures with a padlock. Replace and tighten the fastening screws on the enclosure cover.
6. Prepare the standby generator set for operation. Check the oil level, coolant level, fuel supply, batteries, and items specified by the generator set Prestart Checklist or similar instructions in the operation manual.
7. Place the generator set master switch in the AUTO position. The generator set should start.
8. When loads are ready to be energized, close circuit breakers or switches leading to the transfer switch.

NOTE

When applying power to the transfer switch whose electrical controls have lost power, the engine-start contact remains closed and the engine start LED stays off, signaling the generator to run at least until the ATS's time delay engine cooldown (TDEC) ends.

9. Perform an automatic operation test. With normal power present, disconnect the normal power source and verify that the system responds as described in Section 2.2.1, starting the generator set automatically and transferring the load to the emergency power source. When the transfer switch has transferred the load to the emergency source, reconnect the normal power source and verify that the system operates as described in Section 2.2.2, retransferring the load to the normal source and shutting down the generator set after TDEC.

2.2 Automatic Operation

The ATS controller monitors the normal and emergency power sources and determines when a power source has failed or is acceptable and controls the system accordingly. See Figure 4-1. Failure of a power source occurs when its voltage on one or more phases falls below the dropout voltage level. A power source is acceptable when its voltage on sensed phases rise above the pickup voltage level and stay above the dropout voltage level. A power source is restored when it becomes acceptable again after failure. See Section 1.5 for voltage sensing and pickup and dropout voltage specifications. Typical ATS operation occurs in two separate automatic sequences.

- **Failure of normal power** and the resulting transfer to emergency power.
- **Restoration of normal power** and the resulting transfer back to normal power.

2.2.1 Failure of Normal Power

The main controller circuit board monitors phase A-C of the normal power source. The normal available (NA) LED on the main controller circuit board lights when the normal power source is acceptable.

On single-phase switches the jumper JP3 connects terminals GND and 3PH on the main controller circuit board. See Figure 2-1. The controller considers the normal source unacceptable when the normal source voltage on phase A-C drops below the single-phase dropout specification and acceptable when it rises above the single-phase pickup specification.




Figure 2-1. Single-phase Configuration

On three-phase switches a contact on a separate three-phase module VS is connected across terminals 3PH and GND, and jumper JP3 is cut at the factory. See Figure 2-2. When the contact on the three-phase module is closed, single-phase sensing determines source acceptability. When the contact is open, the controller considers the normal source to have failed.




Figure 2-2. Three-phase Configuration

The three-phase module considers all three phases for source acceptability and opens a contact when the voltage on any phase drops below the three-phase dropout specification, or the phase sequence is not A-B-C. The contact does not close until all three phases are above the three-phase pickup specification and the phase sequence is A-B-C.

When the normal power source fails, the normal relay (NR) on the main controller circuit board is no longer held, the NA LED turns off, and the controller starts a time delay called time delay engine start (TDES). TDES prevents unnecessary generator startup during short utility power interruptions. The controller maintains internal control circuits including the plant exerciser setting for up to 90 seconds without the normal or emergency power source. If the normal power source is restored before TDES ends, the controller resets the time delay. If the normal power failure persists and TDES ends, the controller issues a signal to start the standby (emergency) generator to produce the emergency power source by closing the engine-start contact between terminals ES3 and ES4 and the engine start (ES) LED on the main controller circuit board turns off.

After signalling the generator to start, the controller monitors the voltage on phase A-C of the emergency source. The emergency acceptable (EA) LED on the main controller circuit board lights when the voltage rises above the emergency source pickup specification. The controller considers the emergency source acceptable and the EA LED remains lit when the emergency source voltage remains above the emergency source dropout level specification. When the emergency source becomes available, the controller starts a time delay called time delay normal-to-emergency (TDNE). TDNE allows emergency power source stabilization before load connection. When TDNE ends, the controller lights the ER LED and energizes the emergency relay (ER). The emergency relay signals the contactor to connect the load to the emergency source operating the contactor solenoid TS through a bridge rectifier BR and coil-clearing contact SCE. When the contactor moves away from the normal position, coil-clearing contact SCE opens to remove power from the solenoid. The contactor mechanism's inertia carries it through the top of the cycle and into the emergency position. A contactor mechanically latches in the emergency position until normal power source restoration and stabilization.

2.2.2 Restoration of Normal Power

When the normal power source is restored, the controller lights the NA LED and starts a time delay called time delay emergency-to-normal (TDEN). If the normal source fails before TDEN ends, the NA LED turns off and the time delay resets. TDEN ensures normal power source stabilization before load reconnection.


When the controller determines that the normal power source has maintained an acceptable level and TDEN ends, the controller signals the contactor to reconnect the load to the normal source. It does this by lighting the NR LED and energizing the NR relay to operate the contactor solenoid TS through bridge rectifier BR and coil-clearing contact SCN. When the contactor moves away from the emergency position, coil-clearing contact SCN opens to remove power from the solenoid. The contactor mechanism's inertia carries it through the top of the cycle and into the normal position. The contactor is mechanically latched in the normal position until the next normal power source failure. The controller starts a time delay called time delay engine cooldown (TDEC). TDEC allows the engine and generator to run unloaded and cool down before shutdown. When TDEC ends, the controller signals the generator set to shut down by opening the engine-start contact between terminals ES3 and ES4 and the ES LED on the main controller circuit board lights. When the generator set shuts down, the EA LED turns off.

2.3 Exerciser Function

The exerciser function, when enabled, automatically starts and runs the generator set unloaded (the ATS does not transfer the load to the emergency source) for 20 minutes once a week. Exercising the generator set helps to ensure that the generator set starts when emergency power is needed. An exerciser switch selects exerciser functions. Automatic operation overrides the exerciser function. The loss of all power sources for more than 90 seconds will result in the loss of the exerciser set time. See Section 2.3.2.


2.3.1 Exerciser Switch

An exerciser switch is located inside the ATS enclosure. See Figure 1-1 and Figure 2-3.



1. Exerciser switch
2. Set position (momentary, up)
3. Disable position (down)
4. Enable position (middle)

Figure 2-3. Exerciser Switch



(600 volts and under)

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

NOTE

The exerciser switch is set during installation and normally does not require adjustment. Line voltage is present on some components inside the ATS enclosure when power sources are applied. Only trained and qualified personnel should open the ATS enclosure when power is present. Read and follow all safety decals inside the enclosure and avoid contact with line voltage.

The exerciser switch selects the following exerciser functions when power is available. See Section 2.3.2.

- **Set (⤴⤵).** Placing the switch in the momentary (spring-loaded) set position and releasing the switch to the run position sets the exerciser: the exerciser's internal one-week timer is set and the exerciser starts and runs the generator set for a 20-minute period. Subsequent weekly 20-minute exercise periods start at the same day and time the exerciser was released from the set position.
- **Enable (⚡).** Placing the switch in the enable position causes the exerciser to start and run the generator set unloaded for 20 minutes on the same day and time each week the exerciser was last set.
- **Disable (⊘).** Placing the switch in the disable position prevents the exerciser from starting and running the generator. The exerciser's internal one-week timer continues to run and the exerciser's set day and time are not lost. The ATS, however, starts the generator automatically when the normal power source fails.

Replace the enclosure cover on the ATS enclosure and tighten the screws that hold it in place after viewing or making changes to the exerciser switch setting.


2.3.2 Exerciser Power Requirements

An internal one-week timer for the exerciser function maintains its setting for up to 90 seconds after power loss of both the normal and emergency sources. When the normal power source fails, the generator must start and run to provide emergency power within approximately 90 seconds or the system loses the previously set day and time and the exerciser is set to the day and time that either power source returns. Then, if the exerciser switch is in the Enable (⚡) position, the controller starts and runs the generator set unloaded for 20 minutes one week from the day and time of power source return and on subsequent weeks at the same day and time.

2.4 Manual Operation

To test or troubleshoot the transfer switch, manually operate the contactor using the procedure described below.

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

WARNING



Hazardous voltage. Can cause severe injury or death.

Disconnect all power sources before opening the enclosure.

(600 volts and under)

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

Manual Operation Procedure

1. Prevent the generator set from starting by:
(1) placing the generator set master switch in the OFF position; (2) disconnecting power to the generator engine start battery charger, if installed; and (3) disconnecting all generator engine start batteries, negative (-) leads first.
2. Disconnect or turn off *both* the normal and emergency power sources by opening upstream circuit breakers or switches to the transfer switch.
3. Remove the cover on the front of the transfer switch enclosure.
4. Insert a #2 Phillips screwdriver or similar tool with an electrically insulated handle into the hole located on the flywheel at the left of the contactor. See Figure 2-4 and Figure 2-5. A marking on the outer part of the flywheel shows the switch position when viewed from the front of the enclosure. The letter E is visible if the switch is in the emergency position [load is connected to the emergency (standby) power source]. The letter N is visible if the switch is in the normal position [load is connected to the normal (utility) power source].

NOTE


A contactor in serviceable condition transfers smoothly without binding when operated manually. Do not place the transfer switch into service if the contactor does not manually operate smoothly without binding; contact an authorized distributor/dealer to service the contactor.

5. Move the tool's handle up to rotate the flywheel to manually operate the switch into the emergency position. Move the tool's handle down to rotate the flywheel to manually operate the switch into the normal position. See Figure 2-5.
6. Manually operate the switch to select the normal position for automatic operation.
7. Remove the tool used to manually operate the switch.
8. Replace the cover on the transfer switch enclosure and tighten the screws that hold it in place.
9. Reconnect the power supplies to the transfer switch.

NOTE


When applying power to the transfer switch whose electrical controls have lost power, the engine-start contact remains closed and the engine start LED stays off, signaling the generator to run at least until the ATS's time delay engine cooldown (TDEC) ends.

10. Reconnect the generator engine start battery cables, negative (-) leads last; reconnect power to the generator engine start battery charger, if installed; and place the generator set master switch in the AUTO (automatic) position. The generator may start and run for a while (see NOTE above).



1. Flywheel

Figure 2-4. Typical Contactor



1. Flywheel
2. Marking shows switch in the normal position
3. Tool inserted into hole in flywheel
4. Move down to select the normal position
5. Marking shows switch in the emergency position
6. Move up to select the emergency position

Figure 2-5. Manual Operation of Contactor

2.5 External Test Switch

A provision on the main controller circuit board allows the connection of a customer-supplied, normally closed external test switch. This test switch connects between the TEST and GND terminals after cutting the jumper JP2 on the controller circuit board. See Figure 2-6. When the test switch contact is open, normal-source single-phase power is disconnected from the controller, and the controller follows the same sequence of operation as when the normal source fails.




Figure 2-6. External Test Switch

Notes

Section 3 Scheduled Maintenance

Scheduled preventive maintenance ensures safe and reliable operation and extends the life of the transfer switch. Preventive maintenance includes periodic testing, cleaning, inspecting, and replacing of worn or missing components.


A local authorized distributor/dealer can provide complete preventive maintenance and services to keep the transfer switch in top condition. Contact a local distributor/dealer for additional information. See the Service Assistance section in the Introduction for how to locate a local distributor/dealer.

Read this entire section carefully before attempting any maintenance or service. Unless otherwise specified, have maintenance or service performed by an authorized distributor/dealer that has trained and qualified personnel who follow all applicable codes and standards.

Keep records of all maintenance or service.

Replace all barriers and close and lock the enclosure door after maintenance or service and before reapplying power.

⚠ WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

⚠ WARNING




Hazardous voltage.
Can cause severe injury or death.

Disconnect all power sources before opening the enclosure.

(600 volts and under)


⚠ WARNING



Hazardous voltage. Moving rotor.
Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.



(600 volts and under)

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.
(600 volts and under)

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

Servicing the transfer switch controls and accessories within the enclosure. Hazardous voltage can cause severe injury or death. Disconnect the transfer switch controls at the inline connector to deenergize the circuit boards and logic circuitry but allow the transfer switch to continue to supply power to the load. Disconnect all power sources to accessories that are mounted within the enclosure but are not wired through the controls and deenergized by inline connector separation. Test circuits with a voltmeter to verify that they are deenergized before servicing.

NOTICE

Hardware damage. The transfer switch may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

When replacing hardware, do not substitute with inferior grade hardware. Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings, and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

3.1 Inspection and Service

Contact an authorized distributor/dealer to inspect and service the transfer switch when any wear, damage, deterioration, or malfunction of the transfer switch or its components is evident or suspected.

3.1.1 General Inspection

External Inspection. Keep the transfer switch clean and in good condition by performing a weekly general external inspection of the transfer switch for any condition of vibration, leakage, noise, temperature, contamination, or deterioration. Remove accumulations of dirt, dust, and other contaminants from the transfer switch's exterior with a vacuum cleaner or by wiping with a dry cloth or brush. *Do not use compressed air to clean the switch because it can cause debris to lodge in and damage the components.* Replace any worn, missing, or broken external components with manufacturer-recommended replacement parts. Contact a local authorized distributor/dealer for part information and part ordering. Tighten loose external hardware.

3.1.2 Internal Inspections, Procedures, and Tests

Internal Inspection. Disconnect all power sources, remove the transfer switch enclosure cover, and inspect internal components every six months (more frequently in dusty or dirty areas) or when any condition noticed during an external inspection may have affected internal components. Inspect for:

- Accumulations of dirt, dust, moisture, or other contaminants
- Signs of corrosion
- Worn, missing, or broken components
- Loose hardware
- Wire or cable insulation deterioration, cuts, or abrasion
- Signs of overheating or loose connections: discoloration of metal, melted plastic, or a burning odor
- Other evidence of wear, damage, deterioration, or malfunction of the transfer switch or its components.

Cleaning. Remove contaminants from internal components with a vacuum cleaner or by wiping with a dry cloth or brush if possible. *Do not use compressed air to clean the switch because it can cause debris to lodge in and damage the components.*

Lubrication. The outer mechanism of the contactor is lubricated for the life of the contactor and requires no further lubrication under normal use. If the outer mechanism is contaminated, clean it with a soft cloth and relubricate it with Lubriplate 105 lubricant.

Manually operate the contactor mechanism to be sure that it operates smoothly without binding. If applying lubricant to the outer mechanism of the contactor does not eliminate binding, replace the contactor assembly.

Periodically oil the screws that secure covers in place. Apply a thin layer of grease to the top edge of a NEMA type 3R enclosure cover to aid in positioning it. Periodically oil the padlock clasp on a NEMA type 3R enclosure.

Part Replacement and Tightening. Replace worn, missing, broken, deteriorated, or corroded internal components with manufacturer-recommended replacement parts. Contact a local authorized distributor/dealer for part information and part ordering. Tighten loose internal hardware.

Wire Repair or Replacement. Have damage to power circuit wiring evaluated and repaired or replaced by a qualified electrician. Replace wiring when there is any doubt about its condition. Tape minor control circuit wire insulation cuts or abrasions less than 0.04 in. (1 mm) across by wrapping the section tightly with three layers of UL-listed 3/4 in. (19 mm) wide electrical tape. Repair moderately damaged leads, where conductors are cut or insulation is damaged over sections shorter than about 4 in. (100 mm) or less than about 25% of the length of the wire by cutting out the damaged section and splicing in wire of the same type using UL-listed insulated (250 V minimum) connectors and follow the connector manufacturer's instructions. Replace extensively damaged or deteriorated leads completely. If the leads are part of a wiring harness, replace the entire wiring harness. Fabricate new leads using the same type of wire and UL-listed insulated (250 V minimum) connectors and follow the connector manufacturer's instructions.

Terminal Tightening. Loose connections on the power circuits can lead to overheating or explosion. Tighten all contactor terminal lugs to 200 in. lbs. (16.7 ft. lbs. or 22.6 Nm) of torque. Tighten the neutral lugs to the torque values shown in Figure 3-1.

Wire Size (AWG or MCM)	Torque		
	In. Lbs.	Ft. Lbs.	Nm
8	75	6.2	8.5
6	110	9.2	12
4	110	9.2	12
2	150	13	17
1	150	13	17
1/0	180	15	20
2/0	180	15	20
3/0	250	21	28
4/0	250	21	28
250	325	27	37

Figure 3-1. Tightening Torque for Neutral Terminal Lugs


Tighten the ground screw terminal to the torque values shown in Figure 3-2.

Wire Size (AWG or MCM)	Torque		
	In. Lbs.	Ft. Lbs.	Nm
14	35	2.9	4.0
12	35	2.9	4.0
10	35	2.9	4.0
8	40	3.3	4.5
6	45	3.8	5.1
4	45	3.8	5.1

Figure 3-2. Tightening Torque for Ground Screw Terminal


Tighten the terminal strip terminals on the controller assembly including the engine-start connections on terminals ES3 and ES4 on terminal strip TB3 to 9 in. lbs. (1.0 Nm) of torque.

Contactor Inspection. Remove the screws that secure the covers (100 amp units) or arc chute assemblies (200 amp units) at the front of the contactor and inspect the main contacts inside the contactor. See Figure 3-3 and Figure 3-4. Remove surface deposits with a clean cloth. *Do not use emery cloth or a file.* If the contacts are pitted, show signs of overheating, or are worn, replace the contactor assembly. See Figure 3-4 for how each pole of the main contacts should appear when closed. The contacts are worn if the contact surface material, a layer of silvery-colored metal, is removed. See Figure 3-4. On 200 amp units check the condition of the arc chutes. If the arc chutes show signs of disintegration, replace the arc chute assembly.



1. Cover/arc chute assembly screws.

Figure 3-3. Screw Removal for Contactor Inspection



1. Stationary contact surface material (normal and emergency)
2. Moving (center) contact surface material

Figure 3-4. Main Contacts

Signs of Overheating. Replace components damaged by overheating and locate the cause of the overheating. Overheating could be caused by loose power connections, overloading, or a short circuit in the system. After tightening power terminals perform a millivolt drop test to locate areas with high contact resistance. See Section 3.2.3. Check the line circuit breakers in the system to be sure that they do not allow the load to exceed the switch rating. Use the controller troubleshooting and schematics to locate a control circuit short.

3.2 Testing

Periodic testing is important in any transfer switch application. It helps to ensure that the generator will start and the transfer switch mechanisms and control circuits will operate when needed.

3.2.1 Weekly Generator Set Exercise

Use the plant exerciser to start and run the generator set once a week to maximize the reliability of the emergency power system. See Section 2.

3.2.2 Monthly Automatic Operation Test

Test the transfer switch's automatic control system monthly. See Section 2. Verify that the expected sequence of operations occurs as the switch transfers the load to the emergency source when a normal source failure occurs or is simulated. When the switch transfers the load to the emergency source, end the test and verify that the expected sequence of operations occurs as the transfer switch retransfers to the available normal source and signals the generator set to shut down after a cooldown period.

3.2.3 Other Tests

Every Year

Use a millivolt drop test to help locate high-resistance contacts in the ATS under a moderate and balanced load. The objective is to locate a contact that is of significantly higher-resistance than others. This manual cannot give an exact value to look for because the value is a function of the physical condition of the contactor and the loading of the unit, which is impossible to predict.

Millivolt Drop Test Procedure


1. Carefully measure the voltage on each phase from the source lugs to the load lugs when a balanced load of at least 10% of the switch rating is connected to each source. To obtain accurate readings, keep the meter as far as possible from current-carrying conductors and the meter leads as short, direct, and at right angles to current-carrying conductors as possible. This minimizes the effect of induced voltages (transformer effect) in the vicinity of the current-carrying conductors. The reading may be erratic because of the small voltage measured, load fluctuations, and meter circuit contact resistances, so take several readings to ensure accuracy. Look for approximately 0.1 mV per ampere of load current.
2. The highest voltage on a phase should be within 1.5 times the lowest voltage measured on other phases of the same source. This factor is high because all lines may not be exactly balanced, the construction of each contactor circuit may be slightly different, and there may be residual heating from prior load conditions. If an unusually high voltage is found, disconnect power, check the connections and lug torques, and repeat the test. If the problem cannot be found, replace the contactor assembly.

Every Three Years

Perform a wire insulation breakdown test.

Wire Insulation Breakdown Test Procedure

1. Disconnect all power sources by opening upstream circuit breakers or switches to the transfer switch. Disconnect the load from the transfer switch by opening circuit breakers or switches leading from the transfer switch. Disconnect the contactor wiring harness from the controller at connector P1. See Figure 4-1.



(600 volts and under)

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.

(600 volts and under)

2. Use a hi-pot tester or meggar to check the insulation resistance phase-to-phase and phase-to-neutral, and phase-to-ground if neutral and ground are isolated. If using a hi-pot tester, the maximum potential is 500 VAC and the maximum test time is 1 second. The insulation resistance must exceed 1.24 MΩ. If the hi-pot tester indicates wire insulation breakdown or if the measured resistance is less than the minimum, use an instrument designed for this purpose to isolate the leakage current and replace the faulty components with voltage breakdown. It may require disconnecting power conductors from the lugs to isolate the problem. If the power conductors are disconnected from the lugs, see Section 6.2.2 for reconnection instructions.

Every Five Years

Check normal and emergency source setpoint calibration according to the procedures in Section 4.9 and 4.10.

3.3 Service Schedule

Follow the service schedule below for the recommended service intervals. Have all service performed by an authorized distributor/dealer except for items designated by an X.

System Component or Procedure	See Section	Visually Inspect	Check	Change	Clean	Test	Interval
ELECTRICAL SYSTEM							
Check for signs of overheating or loose connections: discoloration of metal, melted plastic, or a burning odor	3.1.2	X	X				S
Check the contactor's external operating mechanism for cleanliness. Clean and relubricate if dirty *	3.1.2	X		D, R (lubricant)	D		Y
Check wiring insulation for deterioration, cuts, or abrasion and repair or replace wiring to regain the properties of the original wiring	3.1.2	X		D, R (wiring)			S
	3.1.2	D	D				Y
Check the transfer switch's main power switching mechanisms' mechanical operation and integrity	3.1.2	D	D			D	Y
Tighten control and power wiring connections to specifications	3.1.2		D			D	Y
Check the transfer switch's main power switching contacts' condition. Clean or replace the main contacts or replace the contactor assembly as necessary	3.1.2	D		D, R	D		Y
Perform a millivolt drop test to check for high contact resistances on power circuits. Tighten connections, clean main contacts, adjust or replace main contacts or contactor assembly to eliminate high contact resistances	3.2.3		D	D, R	D	D	Y
Test wire and cable insulation for electrical breakdown	3.2.3					D	Every 3 Years
Check calibration of voltage-sensing circuitry and setpoints, and recalibrate circuitry as necessary	4.9, 4.10		D			D	Every 5 Years
CONTROL SYSTEM							
Exercise the generator set unloaded	3.2.1					X	W
Test the transfer switch's automatic control system	2, 3.2.2, 4.8	X				X	M
Test all LED indicators, time delays, and remote control systems for operation	2, 4.8	D	D	D, R		D	Y
GENERAL EQUIPMENT CONDITION							
Inspect the outside of the transfer switch for any condition of vibration, leakage, noise, temperature, contamination, or deterioration to keep the transfer switch clean and in good condition *	3.1.1	X			X		W
Check that all external hardware is in place, tightened, and not badly worn	3.1.1	X	X	R			W
Inspect the inside of transfer switch for any condition of vibration, leakage, noise, temperature, contamination, or deterioration to keep the inside of the transfer switch clean, dry, and in good condition *	3.1.2	D	D		D		S or Y
Check that all internal hardware is in place, tightened, and not badly worn	3.1.2	D	D				S or Y
* Service more frequently if operated in dusty or dirty areas. See Section Read these sections carefully for additional information before attempting maintenance or service. Visually Inspect Examine these items visually. Check Requires physical contact with or movement of system components, or the use of nonvisual indications. Change May require replacement of components depending upon the severity of the problem. Clean Remove accumulations of dirt and contaminants from external transfer switch's components or enclosure with a vacuum cleaner or by wiping with a dry cloth or brush. <i>Do not use compressed air to clean the switch because it can cause debris to lodge in the components and cause damage.</i> Test May require tools, equipment, or training available only through an authorized distributor/dealer. D Have service performed by an authorized distributor/dealer. X Operator action. R May require replacement of components.							W=Week M=Month Q=Quarter S=Six Months Y=Year

Notes


Section 4 Troubleshooting

This section contains transfer switch troubleshooting information. Only trained qualified personnel following all applicable codes and standards should attempt to service the transfer switch covered by this manual. Improper repairs can be hazardous and lead to additional repairs.

Refer first to the troubleshooting chart in Figure 4-2. Possible causes of problems are listed generally in the order of likelihood. See Figure 4-1 for the location of LEDs and connection terminals referred to in Figure 4-2. See Section 1.5 for specifications on controller operation. See the schematic and interconnection diagrams in Section 5, the parts drawings in Section 7, and the labeling on system components to identify and troubleshoot system components.

Use the sections after the troubleshooting chart and the theory of operation to methodically test and troubleshoot the system. The sections are presented in a recommended sequence. Read and be familiar with all sections as some are interdependent.

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.


WARNING



Hazardous voltage. Can cause severe injury or death.

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

(600 volts and under)




Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

Servicing the transfer switch controls and accessories within the enclosure. Hazardous voltage can cause severe injury or death. Disconnect the transfer switch controls at the inline connector to deenergize the circuit boards and logic circuitry but allow the transfer switch to continue to supply power to the load. Disconnect all power sources to accessories that are mounted within the enclosure but are not wired through the controls and deenergized by inline connector separation. Test circuits with a voltmeter to verify that they are deenergized before servicing.



(600 volts and under)

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.
(600 volts and under)

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

Problem	Possible Cause	Corrective Action
ATS fails to operate and no LEDs are lit	No power to the transfer switch/controller.	Close circuit breakers leading from power sources to the transfer switch. Troubleshoot power to the system. See Section 4.4.
Generator set does not start when the normal source fails	Generator set master switch is in the OFF position or the batteries are not charged or connected.	Place the generator set master switch in the AUTO position. Check that the generator set batteries are charged and connected.
	Engine start circuit is malfunctioning.	Troubleshoot. See Section 4.5.
	Generator set is malfunctioning.	See the generator set operation or service manual.
Generator set does not start with the exerciser	Exerciser switch is in the Disable position.	Place the exerciser switch in the Enable position to enable normal exerciser operation. Move the exerciser switch to the Set position to test the exerciser and reset the exerciser timer. See Section 2.3 for exerciser operation.
	Generator set master switch is in the OFF position or the batteries are not charged or connected.	Place the generator set master switch in the AUTO position. Check that the generator set batteries are charged and connected.
	Engine start or exerciser circuit is malfunctioning.	See Section 4.5 first to troubleshoot the engine start circuit, then see Section 4.6 to troubleshoot the exerciser.
	Generator set is malfunctioning.	See the generator set operation or service manual.
Generator set does not shut down	Generator set master switch is in the RUN position.	Place the generator set master switch in the AUTO position.
	The engine start circuit is malfunctioning, the exerciser is operating, or the exerciser circuit is malfunctioning.	If the exerciser has recently been in the Set position or is in the Enable position, wait for the exerciser period of 20 minutes to end. If the generator set continues to run, see Section 4.5 first to troubleshoot the engine start circuit, then see Section 4.6 to troubleshoot the exerciser.
	Time delay engine cooldown (TDEC) has not timed out. (after retransferring the load to the normal source)	Check operation. Enough time must pass for the time delay engine cooldown (TDEC, 2 minutes) timer to time out.
	Generator set is malfunctioning.	See the generator set operation or service manual.
ATS starts the generator when normal fails but fails to transfer the load to the emergency source	Generator set circuit breaker is open.	Close circuit breakers leading from the generator set to the ATS.
	Time delay normal-to-emergency (TDNE) has not timed out.	Check operation. Enough time must pass for the time delay normal-to-emergency (TDNE, 2 seconds) to time out.
	Generator voltage is out of range or emergency source sensing circuits are malfunctioning.	Check the emergency source voltage. Repair or adjust generator set if the output voltage is it is out of range, otherwise see Section 4.9.
	Contactors operation problems.	Troubleshoot. See Section 4.1.
ATS fails to retransfer the load to the normal source after the normal source returns	Normal source circuit breaker is open.	Close circuit breakers leading from the normal source to the transfer switch.
	Time delay emergency-to-normal (TDEN) has not timed out.	Check operation. Enough time must elapse for the time delay emergency-to-normal (TDEN, 12 seconds) timer to time out.
	Normal source voltage levels are out of range or the normal source sensing circuits are malfunctioning.	Check the normal source voltage. If the normal source voltage is within range see Section 4.10.
	Contactors operation problems.	Troubleshoot. See Section 4.2.
Contactors mechanism is binding	Debris is in the contactor mechanism.	Clean the contactor assembly. See Section 3.1.2.
	Outer mechanism needs lubrication.	Lubricate the outer mechanism. See Section 3.1.2.
	Contactors mechanism is damaged.	Replace the contactor assembly.
ATS operates erratically or operates out of specifications	Power supply problems/loose connections, incorrect transfer switch controller operation/calibration.	For erratic operation, check wiring for loose connections especially those that supply power to the controller or in the affected circuit. Check the power supply. See Section 4.4. See Section 4.8 for problems related to time delays in the operating sequence except for the exerciser. See Section 4.6 for problems related to exerciser time delays. For problems related to dropout and pickup specifications see Section 4.9 for the emergency source or Section 4.10 for the normal source.

Figure 4-2. Troubleshooting Chart

4.3 General Notes on Connections

Many service problems are caused by faulty connections due to corrosion, loose terminals, and damaged wiring or connectors. With all power supplies disconnected, perform the following general checks while troubleshooting.

- Unplug connectors and check terminals and leads for corrosion. Remove corrosion from terminals and leads.
- Tighten loose terminals.
- Carefully wiggle the wires in wiring harnesses near sockets or plugs while making continuity measurements at terminals that should be connected through the wiring harness. Replace wiring harnesses with breaks in continuity.
- Recrimp or replace loosely connected lead terminals. See Section 3.1.2 for instructions on wiring repair and replacement.

4.4 Power to the System

Follow this section when the normal source is available and the transfer switch

- None of the LEDs on the controller lights and the relays or contactor do not operate.
- Operates erratically.

Return to this section after making repairs that have restored operation to verify that controller DC voltages are within specifications.

4.4.1 AC System Voltages

1. Disconnect all power sources and check that the controller is connected to the contactor assembly wiring harness at connector P1.
2. Check that the circuit breakers leading to the transfer switch from the normal and emergency sources are closed.
3. The transfer switch needs at least one source present to transfer the load to an available source. If the normal source is available, check for nominal line voltage between lugs NA and NC (also NB-NC for three-phase switches) on the contactor assembly. If the emergency source is available, check for line voltage between lugs EA and EC on the contactor assembly. If not all phases are present on the corresponding source, the problem lies upstream of the transfer switch.

4. If all phases are present on the normal source lugs, check for nominal line voltage between terminals J1-12 and J1-15 (and J1-9 and J1-15 for three-phase switches) on the contactor wiring harness connector on the controller assembly. If all phases are present, check for nominal line voltage between terminals NA and NC (and NB-NC for three-phase switches) on TB1 on the controller assembly. If voltage is present on J1 but not on TB1, replace the controller assembly.
5. If all phases are present on the emergency source lugs, check for nominal line voltage between terminals J1-3 and J1-6 on the contactor wiring harness connector on the controller assembly.
6. If the voltage on any phase at the controller is not steady and correct, the problem could lie in the connection between the contactor and the controller. Check the contactor wiring harness and connections.

4.4.2 DC Controller Voltages

1. If AC voltage is present at terminals NA-NC on TB1 on the controller assembly, check the DC voltage between terminals GND and the +12UF on TB5 on the controller assembly. A good controller assembly should have between 12.0 and 14.0 VDC between these terminals. If the voltage is higher or zero, replace the controller assembly.
2. If the voltage on terminal +12UF is low, disconnect any customer load connected to terminal +12UF on TB5 and remeasure. If voltage is restored the problem is an excessive load on +12UF. If voltage is not restored, replace the controller assembly.
3. If the +12UF terminal voltage is within specifications, check the voltage between terminal GND on TB5 and the +5VDC (right-most) terminal on voltage regulator VR1 located near the center of the controller circuit board. It may be necessary to scrape the +5VDC terminal slightly with the test probe due to the conformal coating on the circuit board to make good contact. A good controller should have $5 \pm 5\%$ VDC at the +5VDC terminal, otherwise replace the controller assembly.
4. If the +5VDC terminal voltage is within specifications, disconnect customer loads connected to terminal +12UF on TB5 on the controller assembly, and disconnect all power sources to the transfer switch. The 5 VDC supply should stay within specifications for at least 90 seconds. If this voltage is not held, replace the controller assembly, otherwise reconnect customer loads to terminal +12UF.

4.5 Engine Start Circuit

Follow this section first when the transfer switch does not start the generator set engine when it should or the generator set engine is signalled to run when it should not.

This procedure will also verify that the ES LED on the controller assembly correctly reflects the engine start circuit status. The ES LED should be off when the engine start circuit between terminals ES3 and ES4 on the controller assembly is closed to signal the engine to start. See Figure 4-3. The ES LED should light when the engine start circuit is open to signal the engine to shut down.

Engine Start Circuit Troubleshooting

1. Disconnect all power sources and wait at least five minutes.
2. Manually operate the contactor to the normal position.
3. Disconnect the exerciser switch wiring harness from connector P2 on the controller assembly.
4. Remove the engine start wires from engine start terminals ES3 and ES4 on TB3 on the controller assembly. The engine should shut down after the generator set's time delay engine cooldown (TDEC, if equipped) ends.
5. If the engine continues to run when it is not supposed to, check for continuity on the engine start wires. If there is continuity, a short in the wiring leading to the generator set controller or a short on the generator set controller or other generator set problem could be causing the engine to run.
6. If the engine would not start when it was supposed to, connect the engine start wires together. This should signal the engine to start. If this doesn't, there could be an open circuit in the wiring leading to the generator set controller, loose wires on the generator set controller, or other generator set problem.
7. Tape the ends of the engine start wires.
8. Check for continuity between terminals ES3 and ES4 on TB3 on the controller assembly. The ES LED should be off and the engine-start contact should be closed. If not, check that jumper JP4 is installed on the circuit board by checking for continuity between terminals ES3 and ES3D on TB3 on the controller assembly. If the jumper is not in place, install a jumper wire between terminals ES3 and ES3D on TB3. If the jumper is in place and there is no continuity between terminals ES3 and ES4, replace the controller assembly.

9. Apply the normal power source and wait for TDEC. If the NA LED does not light, see Section 4.10. If the NA LED lights and the ES LED does not light, or the engine-start contact does not open within $\pm 10\%$ of the TDEC specification, replace the controller assembly.

NOTE

After completing troubleshooting in this section and the ES LED correctly reflects the engine start circuit status.

- See Section 4.6 to troubleshoot engine starting problems with the exerciser.
- See Section 4.8 to troubleshoot engine starting problems in the automatic operation sequence.

When engine start circuit troubleshooting is complete, disconnect all power sources and reconnect the exerciser switch wiring harness to connector P2, and the engine start wires to terminals ES3 and ES4 on TB3 on the controller assembly.




Figure 4-3. Engine Start Circuit

4.6 Exerciser Circuits

Follow this section when

- The plant exerciser does not start the engine at the appropriate time when the exerciser switch is in the Set or Enable position.
- The engine does not shut off when the exerciser switch is in the Enable position after the exerciser period ends.
- The engine does not shut off when the exerciser switch is in the Disable position.

Within the exerciser switch there are two normally open contacts which are both open when in the maintained Enable position. When the switch is in the momentary Set position, the contact from terminal COM to SET on the main controller circuit board is closed. When the switch is in the maintained Disable position, the contact from terminal COM to DISABLE on the main controller circuit board is closed. See Figure 4-4.

Exerciser Circuit Troubleshooting

1. Disconnect all power sources.
2. Disconnect the exerciser switch from connector P2 on the controller assembly.
3. Check the exerciser switch wiring harness for loose, dirty, or corroded connections.
4. Check that connector J2 is wired to the correct terminals on the exerciser switch according to Figure 4-4.
5. Check the exerciser switch continuity. If any of these continuity readings is wrong, replace the damaged exerciser switch.
 - a. Place the exerciser switch in the Enable position and check for open circuits between terminals J2-2 to J2-1 and J2-3.
 - b. Toggle the exerciser switch to the momentary Set position and check that terminals J2-1 and J2-2 are connected and terminals J2-2 to J2-3 are not connected.
 - c. Toggle the exerciser switch to the Disable position and check that terminals J2-2 and J2-3 are connected and the terminals J2-1 to J2-2 is are not connected.
6. See Sections 4.5 and 4.8 first, to verify that the transfer switch is starting the generator set and the ES LED correctly reflects the engine-start contact status in the automatic operation sequence.
7. If the switch is correctly wired, and the switch operates correctly, reconnect J2 to P2.
8. Review the instructions for exerciser operation. If the exerciser is still not operating properly, replace the controller assembly.




Figure 4-4. Exercise Circuit

4.7 Contactor Operation

Follow this section when the switch fails to transfer or transfers improperly when one source fails and the other source is available and is indicated by the corresponding source-available LED.

There may be both mechanical and electrical causes of contactor operation problems. If the contactor is binding, the contactor solenoid TS and other components could be damaged.

4.7.1 Mechanical Check

Manually operate the contactor to check that it operates smoothly without binding. If it does not, clean and relubricate the contactor. See Section 3.1.2. Replace the contactor assembly if cleaning or relubrication does not solve the binding problem. If the contactor assembly was replaced, check the solenoid on the damaged contactor assembly before reapplying power. See Section 4.7.3. If the solenoid was damaged, follow the instructions in Section 4.7.5 to check other system components not replaced with the contactor assembly for damage.

4.7.2 Initial Solenoid and Rectifier Troubleshooting

The contactor solenoid TS should energize and operate the contactor when nominal AC voltage is applied to the bridge rectifier assembly BR terminals AC1 and AC2 from wires 103 and 104. See Figure 4-9 or Figure 4-10.

Initial Solenoid and Rectifier Troubleshooting

1. If the switch fails to transfer or transfers improperly, check for nominal voltage on AC1 and AC2 of BR during the time at which the switch is supposed to transfer.
2. If nominal voltage is not present, the problem is most likely in the coil-clearing contacts or the controller, so go to Section 4.7.6. If voltage is present and the switch fails to transfer or transfers improperly, either the rectifier or solenoid could be damaged.

4.7.3 Solenoid Test


Disconnect all power sources and disconnect the solenoid leads from the bridge rectifier. Allow the solenoid to cool to room temperature. Measure the solenoid's resistance and compare the measured value with the specifications in Figure 4-5. If the measured resistance is not within $\pm 10\%$ of specifications, replace the damaged solenoid. If the solenoid is damaged, return to Section 4.7.5 before reapplying power.

Nominal Line-line Voltage (VAC)	Cold Resistance (Ω)
190-208	18.1
220-240	28.8

Figure 4-5. Solenoid Coil Resistance

4.7.4 Rectifier Test

Disconnect all leads to the bridge rectifier BR and test each rectifier (diode) in the bridge individually using an ohmmeter (R $\times$ 1 scale) or diode checker. See Figure 4-6. The diodes should exhibit a reverse resistance of at least 100 times the forward resistance. If the reverse resistance is low, replace the damaged rectifier assembly.



1. Forward-biased diode—current flows from the positive terminal of the meter to the negative terminal in the same direction as the diode arrow, low resistance
2. Reverse-biased diode—current flows from the positive terminal of the meter to the negative terminal in the opposite direction of the diode arrow, high resistance

Figure 4-6. Testing Diodes

4.7.5 After Solenoid Replacement

A contactor solenoid is not designed to operate continuously. When operated continuously the solenoid coil windings first tend to short circuit, then eventually burn up, and the solenoid becomes an open circuit. Therefore, a damaged solenoid most likely indicates that the contactor was mechanically binding or that something in the control circuit failed and allowed the solenoid to operate over a longer period than it should.

After Solenoid Replacement

1. Check that the contactor operates freely without binding.
2. Check the coil-clearing contacts. See Section 4.7.6.
3. Visually check other components for evidence of overheating (discolored metal, burning odor or melted plastic) and replace damaged components. Check the wiring, coil-clearing contacts, bridge rectifier BR, NR and ER relay contacts, and the controller assembly.

4.7.6 Coil-Clearing Contacts

Coil-clearing contact SCE should be closed when the main shaft of the contactor is within approximately 30 degrees of the normal position and open otherwise. See Figure 4-7. Coil-clearing contact SCN should be closed when the main shaft of the contactor is within approximately 30 degrees of the emergency position and open otherwise. See Figure 4-8.

Coil-Clearing Contact Test

1. Disconnect the leads to the contact from the wiring harness.
2. Manually operate the contactor and observe the contact continuity with main shaft rotation. Replace coil-clearing contacts that do not operate correctly—the contact mounting is not adjustable.
3. Reconnect leads to the coil-clearing contact.

4.7.7 NR/ER Relays and Controller Circuitry

Use the following steps to troubleshoot controller circuits when voltage is not appearing on terminals AC1 and AC2 of the bridge rectifier BR to energize the solenoid when a transfer is supposed to occur. See Figure 4-9 or Figure 4-10.

NR/ER Relay and Controller Circuit Troubleshooting

1. Check for voltage across terminals J1-14 and J1-10 when the switch is supposed to transfer. If voltage is present, check the contactor wiring harness and connections to terminals AC1 and AC2 on the bridge rectifier BR.
2. Disconnect all power sources.
3. Check that the jumper on terminals CRB and CRBD (TB4-1 and TB4-2) is installed. If not, reinstall a permanent jumper wire between these terminals and test the system.
4. Manually operate the contactor to the normal position and check for continuity between terminals J1-7 and J1-10 and between terminals J1-13 and J1-14 on the controller assembly. There should be no connection, replace the NR relay if there is. See Figure 4-7.
5. Coil-clearing contact SCE should be closed. Check for continuity across contact SCE between terminals J1-4 and J1-6. Check the contactor wiring harness and connections or replace coil-clearing contact SCE if there is no continuity. See Figure 4-7.
6. Manually operate the contactor to the emergency position. Coil-clearing contact SCN should be closed. Check for continuity across SCN between terminals J1-12 and J1-13. Check the contactor wiring harness and connections or replace coil-clearing contact SCN if there is no continuity. See Figure 4-8.
7. Apply the normal power source. The NA LED should light. If the NA LED does not light, see Section 4.10.
8. When the NA LED lights, wait for TDEN, listen to the NR relay energize, and observe the NR LED. If voltage is not applied to terminals J1-10 and J1-14 and the contactor does not transfer to the normal source, check the following. See Figure 4-9.
 - a. If the NR LED does not light, replace the controller assembly.
 - b. If the NR LED lights but the NR relay does not energize, replace the NR relay. If the replacement NR relay does not cause voltage to be applied to terminals J1-10 and J1-14, replace the controller assembly.
9. If voltage appears across terminals J1-14 and J1-10 but the contactor does not transfer to the normal position, check the contactor wiring harness and connections to terminals AC1 and AC2 on the bridge rectifier BR.
10. When the contactor transfers the load to the normal power source, disconnect the normal source and allow the generator set to start.
11. When the generator starts the EA LED should light. If the EA LED does not light, see Section 4.9.
12. When the EA LED lights, wait for TDNE, listen to the ER relay energize, and observe the ER LED. If voltage is not applied to terminals J1-10 and J1-14 and the contactor does not transfer to the emergency source, check the following. See Figure 4-10.
 - a. If the ER LED does not light, replace the controller assembly.
 - b. If the ER LED lights but the ER relay does not energize, or if the ER relay energizes and the NR relay was replaced, replace the ER relay.
 - c. Replace the NR or ER relay if it has not been replaced already. It is difficult to access the contacts located between terminals J1-4 and J1-10, and J1-1 and J1-14 to determine the faulty relay in-circuit.
13. If voltage appears across terminals J1-14 and J1-10 but the contactor does not transfer to the emergency position, check the contactor wiring harness and connections to terminals AC1 and AC2 on the bridge rectifier BR.




Figure 4-7. Contactor in Normal Position, No Power Present




Figure 4-8. Contactor in Emergency Position, No Power Present




Figure 4-9. Contactor in the Emergency Position, Emergency Present, Normal Returns, TDEN Ends, Transferring to the Normal Position




Figure 4-10. Contactor in the Normal Position, Normal Fails, Emergency Available, TDNE Ends, Transferring to the Emergency Position

4.8 Controller Operation

Follow this section to check the controller's automatic operation sequence including engine starting, time delays, contactor operation, and LEDs.

Controller Operation Test

1. Disconnect all power sources for at least five minutes.
2. Manually operate the contactor to the normal position.
3. Disconnect the exerciser switch wiring harness from connector P2 on the controller assembly.
4. Apply the normal power source and wait for TDEC. If the NA LED does not light, see Section 4.10. If the NA LED lights and the ES LED does not light or the engine-start contact does not open within $\pm 10\%$ of the TDEC specification, replace the controller assembly.
5. Disconnect the normal power source and wait for TDES. If the ES LED does not turn off and the engine-start contact does not close within $\pm 10\%$ of the TDES specification, replace the controller assembly.
6. Reconnect the emergency source and check the EA LED. If the EA LED does not light, see Section 4.9. Wait for TDNE and the switch to transfer to the emergency source. If the switch fails to transfer, see Section 4.7. If the switch transfers but not within $\pm 10\%$ of the TDNE specification, replace the controller assembly.
7. Reconnect the normal power source and wait for TDEN and for the switch to transfer back to the normal source. If the switch fails to transfer, see Section 4.7. If the switch transfers but not within $\pm 10\%$ of the TDEN specification, replace the controller assembly.
8. Wait for TDEC. If the ES LED does not light and the engine-start contact does not open within $\pm 10\%$ of the TDEC specification after transfer to normal, replace the controller assembly.
9. Reconnect the exerciser switch wiring harness to connector P2 on the controller assembly.

4.9 Emergency Source Sensing

Follow this section when the transfer switch starts the generator set but does not recognize the emergency source as available by lighting the EA LED, or it fails to recognize emergency power source failure.

This section requires a voltmeter with a minimum accuracy of $\pm 1\%$ on the scale being measured.

Initial Emergency Source Sensing Troubleshooting

Use this section to initially troubleshoot emergency source sensing. This procedure requires emergency source availability. See Section 4.5 if the generator set does not start.

1. Disconnect the emergency source. If the EA LED remains lit more than a few seconds, replace the controller assembly.
2. Reconnect the emergency source and check for nominal line voltage on phase EA-EC between terminals P1-3 and P1-6 on the controller assembly.
 - a. If voltage is not present at the controller, check for voltage on lugs EA and EC on the contactor assembly. If voltage is not present at the lugs, check the emergency source and the emergency source wiring and circuit breaker. If voltage is present at the lugs, check the contactor wiring harness connections from the lugs to the controller.
 - b. If the voltage on phase EA-EC on P1 on the controller exceeds the single-phase pickup voltage specification in Figure 4-11 then the EA LED on the controller assembly should light; replace the controller assembly if the LED does not light.

Dropout Voltage (VAC)	Pickup Voltage (VAC)
160	190

Figure 4-11. Single-Phase Emergency Source Undervoltage Specifications

Use the following procedure to test emergency source sensing operation and calibration.

Emergency Source Single-Phase Sensing Test

Follow the next steps to check single-phase sensing of the emergency source on both single- and three-phase switches.

1. Disconnect the normal and emergency power sources and the load from the transfer switch.
2. Connect a variable voltage source that ranges from about 5% below the dropout specification to about 5% above the pickup specification to lugs EA-EC on the contactor assembly.
3. Increase the voltage until the EA LED lights or the voltage is 5% above the pickup voltage specification. If the EA LED does not light, replace the controller assembly. Otherwise, reduce the voltage until the EA LED turns off or the voltage is 5% below the dropout voltage specification.
4. If the EA LED remains lit, replace the controller assembly. If the LED turns off, check the voltage. If the voltage is not within $\pm 5\%$ of the dropout voltage specification, replace the controller assembly.
5. Increase the voltage until the EA LED lights. If the voltage is not within $\pm 5\%$ of the pickup voltage specification, replace the controller assembly.

4.10 Normal Source Sensing

Follow this section when the system fails to recognize the normal power source as available by lighting the NA LED, or when it fails to recognize normal power source failure.

This section requires a voltmeter with a minimum accuracy of $\pm 1\%$ on the scale being measured.

Initial Normal Source Sensing Troubleshooting

Use this section to initially troubleshoot normal source sensing. This procedure requires normal source availability.

1. Disconnect all power sources.
2. On single-phase switches, check for continuity between terminals GND and 3PH on TB2 on the controller assembly. If the circuit is open, install a permanent jumper between these terminals, then reapply power and test the system.
3. On three-phase switches, disconnect the three-phase module from terminals GND and 3PH on TB2 on the controller assembly and install a temporary jumper between these terminals on the controller assembly. Remove the temporary jumper and reconnect the three-phase module when normal source sensing troubleshooting and testing is complete.
4. Disconnect the normal source. If the NA LED remains lit for more than a few seconds, replace the controller assembly.
5. Reconnect the normal source and check for nominal line voltage on phase NA-NC on terminals P1-12 and P1-15 on the controller assembly.
 - a. If voltage is not present on phase NA-NC on P1 on the controller, check for voltage on lugs NA and NC on the contactor assembly. If voltage is not present on the lugs, check the normal source and the normal source wiring and circuit breaker. If voltage is present on the lugs, check the contactor wiring harness connections from the lugs to the controller assembly.
 - b. If the voltage on phase NA-NC on P1 on the controller exceeds the single-phase pickup voltage specification in Figure 4-12 then the NA LED on the controller assembly should light; replace the controller assembly if the LED does not light.
6. On three-phase switches, measure the voltages on all three phases A-B-C on terminals J1-12, J1-9, and J1-15 respectively on the controller assembly.
 - a. If voltage is present on all phases on P1 on the controller assembly, check for nominal line voltage between terminals NA, NB, and NC on TB1 on the controller assembly. If any phase is missing on TB1, replace the controller assembly.
 - b. If voltage is not present for any phase or if the phase sequence is not A-B-C on P1 on the controller assembly, check the voltage on lugs NA, NB, and NC on the contactor assembly. If voltage is not present at the lugs or the phase sequence is not A-B-C, check the normal source and the normal source power circuit wiring and circuit breaker. If voltage is present at the lugs and is in the correct phase sequence, check the contactor wiring harness connections from the lugs to the controller.
 - c. If the voltage on all three phases on TB1 on the controller assembly exceeds the minimum pickup specification in Figure 4-13 and the phase sequence is A-B-C, check for continuity between the leads that were disconnected from terminals GND and 3PH of TB2 on the controller assembly coming from the three-phase module contact C-C1. If the contact is open, check the wiring of the three-phase module to TB1 on the controller assembly. If the three-phase module is wired correctly, replace the three-phase module.

Dropout Voltage (VAC)	Pickup Voltage (VAC)
160	190

Figure 4-12. Single-Phase Normal Source Undervoltage Specifications

Nominal Line-line Voltage (VAC)	Dropout Voltage (VAC)	Pickup Voltage (VAC)
208	173	187
220	183	198
240	199	216

Figure 4-13. Three-Phase Normal Source Undervoltage Specifications

Use the following procedures to test normal source sensing operation and calibration.

Normal Source Single-Phase Sensing Test

Follow the next steps to check single-phase sensing of the normal source on both single- and three-phase switches.

1. Disconnect the normal and emergency power sources and the load from the transfer switch.
2. Connect a variable voltage source that ranges from about 5% below the dropout specification to about 5% above the pickup specification to lugs NA-NC on the contactor assembly. Increase the voltage until the NA LED lights or the voltage is 5% above the pickup voltage specification in Figure 4-12
3. If the NA LED does not light, replace the controller assembly.
4. If the NA LED lights, reduce the voltage until the NA LED turns off or is 5% below the dropout voltage specification. If the NA LED remains lit, replace the controller assembly. If the LED turns off, check the voltage. If the voltage is not within $\pm 5\%$ of the dropout voltage specification, replace the controller assembly.
5. Increase the voltage until the NA LED lights. If the voltage is not within $\pm 5\%$ of the pickup specification, replace the controller assembly.

Normal Source Three-Phase Sensing Test


Follow the next steps to check the three-phase sensing module (three-phase sensing of the normal source) on three-phase switches.

1. Disconnect the normal and emergency power sources and the load from the transfer switch.
2. Connect three variable-voltage, three-phase sources that range from about 5% below the dropout specification to about 5% above the pickup specification to lugs NA, NB, and NC respectively on the contactor assembly in phase sequence A-B-C. Maintain a similar voltage level on all phases and increase the voltages until all exceed the three-phase pickup specification in Figure 4-13.
3. Check the output of the three-phase module contact that was disconnected from terminals GND and 3PH on TB3 on the controller assembly. The contact from the three-phase module should close when all of the voltages rise above the pickup settings. If the contact stays open, replace the three-phase module.
4. If the contact closes, lower the voltage on each phase one at a time and verify that the contact opens when a single phase falls below the dropout setting and remains open until the voltage is increased above the pickup setting. If the contact does not operate properly, replace the three-phase module.
5. Connect the voltage sources out of phase sequence (A-C-B, B-A-C, B-C-A, C-A-B, and C-B-A) to lugs NA, NB, and NC. The contact should remain open despite all three voltages being above the pickup specification. If the contact does not operate properly, replace the three-phase module.

Section 5 Diagrams

Diagram or Drawing	Drawing Number	Page
Interconnection Diagram		
Model R120 100–200 Amperes and Solid-State Controls	362139-S-B	41
Schematic Diagram		
Model R120 100–200 Amperes and Solid-State Controls	362140-S-B	42

Notes




Schematic Diagram, 362140-S-B

Section 6 Service Part Replacement

Use the instructions in this section for transfer switch service part replacement. See Section 7 for service parts.

WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

WARNING



Hazardous voltage.
Can cause severe injury or death.

Disconnect all power sources before opening the enclosure.

(600 volts and under)

WARNING



Hazardous voltage.
Can cause severe injury or death.

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

(600 volts and under)

WARNING



Hazardous voltage.
Can cause severe injury or death.

Only authorized personnel should open the enclosure.


(600 volts and under)

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.
(600 volts and under)

Making line or auxiliary connections. Hazardous voltage can cause severe injury or death. To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

Servicing the transfer switch controls and accessories within the enclosure. Hazardous voltage can cause severe injury or death. Disconnect the transfer switch controls at the inline connector to deenergize the circuit boards and logic circuitry but allow the transfer switch to continue to supply power to the load. Disconnect all power sources to accessories that are mounted within the enclosure but are not wired through the controls and deenergized by inline connector separation. Test circuits with a voltmeter to verify that they are deenergized before servicing.



NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

NOTICE

Hardware damage. The transfer switch may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

When replacing hardware, do not substitute with inferior grade hardware. Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings, and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

6.1 Before and After Servicing Components

Before Service. Follow these instructions before opening the enclosure and servicing the transfer switch.

1. Prevent the emergency power source generator set from starting by placing the generator set master switch in the OFF position; disconnecting power to the generator set battery charger, if installed; and removing the generator set engine start battery cables, negative (-) lead first.
2. Disconnect or turn off *both* the normal and emergency power sources before opening the enclosure door. Check circuits with a voltmeter to verify that the power is off before servicing components inside the enclosure.

After Service Follow these instructions after servicing the transfer switch.

1. Reinstall barriers.
2. Remove debris from the enclosure.
3. See Section 2.1 for startup instructions.

6.2 Contactor Assembly

NOTE

Serviceable contactor assembly parts can be replaced without removing the contactor assembly from the enclosure.

6.2.1 Contactor Assembly Removal

1. Disable the generator set and disconnect all power sources as described in Section 6.1 before opening the transfer switch enclosure.
2. Loosen the power terminal lugs and disconnect the normal, emergency, and load power conductors, and label and tape the ends of the conductors.
3. Disconnect the contactor wiring harness from the controller at connector P1.
4. Remove the nuts and lock washers located at the four corners of the contactor's back plate that secure the contactor assembly to the back wall of the enclosure. See Section 7.2.
5. Lift and pull the contactor assembly from the enclosure.

6.2.2 Contactor Assembly Installation

1. Position the contactor assembly on the mounting studs inside the transfer switch enclosure.
 2. Reinstall the nuts and lock washers that secure the contactor assembly.
 3. Reconnect the power source and load conductors to the lugs. Tighten the connections to the torques shown in Section 3.1.2 of this manual.
-

NOTE

Connect the source and load phases as indicated by the markings and drawings. Improper connections may cause short circuits or cause phase-sensitive load devices to malfunction or operate in reverse.

4. Reconnect the contactor wiring harness to the controller at connector P1.
5. Follow the instructions under **After Service** in Section 6.1.

6.3 Solenoid Assembly

6.3.1 Solenoid Assembly Removal

1. Note the solenoid connections to the rectifier assembly and disconnect the leads. See Section 7.2.
2. Loosen the two screws on the solenoid clamp. Hold the solenoid assembly firmly and remove the screw at the front of the contactor. See Figure 6-1.


NOTE

The solenoid spring pressure will push the solenoid assembly up when the solenoid clamp is loosened.

3. Slide the solenoid coil assembly off the core mechanism. Be prepared to catch the solenoid spring as the mechanism slides apart. Do not wipe off the lubricant.

6.3.2 Solenoid Assembly Installation

1. If the solenoid core mechanism is dirty, wipe it with a soft, clean cloth and relubricate it with Lubriplate 105.
2. Insert the solenoid spring into the new solenoid and slide the new solenoid over the core.
3. Hold the solenoid assembly in position on the contactor and reinstall the solenoid clamp and screw. Tighten the solenoid clamp screws.
4. Operate the contactor using the manual operating handle to verify that the mechanism operates smoothly without binding.
5. Test the operation of the coil-clearing contacts using the procedure in Section 4.7.6.
6. Follow the instructions under **After Service** in Section 6.1.



1. Solenoid clamp
2. Solenoid screws
3. Core mechanism
4. solenoid spring is inside solenoid, not shown

Figure 6-1. Solenoid Assembly (side view)

6.4 Controller PCB Assembly

Electronic printed circuit boards (PCBs) are sensitive to a variety of elements and can be damaged during removal, installation, transportation, or storage. Observe the following when working with circuit boards.

Circuit Board Handling

- Store circuit boards in the anti-static, cushioned packaging provided by the factory in a clean environment away from moisture, vibration, static electricity, corrosive chemicals, solvents, or fumes until installation.
- Wear an approved grounding, anti-static wrist strap when handling circuit boards or components.
- Carefully hold the circuit board only by its edges, not by any of its components.
- Don't bend or drop the circuit board or any of its components.
- Don't strike the circuit board or any of its components with a hard object.
- Clean dusty or dirty circuit boards only with a vacuum cleaner or dry brush.
- Never attempt component-level circuit repairs.
- Never remove or install a circuit board with power connected.
- Label wiring when disconnecting it for reconnection later.

6.4.1 Controller PCB Removal

1. Disable the generator set and disconnect all power sources as described in Section 6.1 before opening the transfer switch enclosure.
1. Remove the four screws located at the four corners of the main controller circuit board assembly.
2. Five push-on PCB standoffs at various locations on the mounting plate also holds the circuit board. Carefully pry the circuit board away from each standoff at the locations shown by the arrows in Figure 6-2. Pry near the standoff located below terminal strip TB2 first and work clockwise.

6.4.2 Controller PCB Installation

1. Position the circuit board over the push-on PCB standoffs on the mounting plate.
2. Gently push the circuit board onto the standoffs.
3. Replace and tighten the four screws at the corners of the circuit board.
4. Follow the instructions under **After Service** in Section 6.1.




Figure 6-2. PCB Removal

6.5 Other Service Parts

The removal and installation of other service parts listed in Section 7, such as plug-in relays, auxiliary switches, brackets, and other hardware, for which removal and installation instructions are not previously given is covered by the following generic procedures.

6.5.1 Other Service Part Removal

1. Disable the generator set and disconnect all power sources as described in section 6.1 before opening the transfer switch enclosure.
2. Disconnect wiring from the part(s), noting the locations from which wiring was removed for later reconnection. Tape and label the wires.
3. Note the position of the part(s) and loosen or remove hardware that holds the part(s) in place. Note the location, type, and condition of hardware removed and compare it with the parts list. Replace damaged or missing hardware.
4. Carefully remove the part(s) from the unit. Gently rock plug-in parts, such as relays, from side to side while pulling straight out to remove them without bending circuit boards.

6.5.2 Other Service Part Installation

1. Position the part(s) in place in the same manner that the old part was installed. Support the back of circuit boards when installing plug-in parts, such as relays, to avoid bending the circuit board.
2. Tighten or reinstall hardware that holds the part(s) in place to the general torque specifications in the appendix unless otherwise noted.
3. Reconnect wiring to the same locations from which they were removed, torquing terminals to the specifications given in the maintenance section of this manual.
4. Follow the instructions under **After Service** in Section 6.1.

Use this section to locate and identify serviceable parts for the transfer switch model covered by this manual.

7.1 General Information

7.1.1 Finding Parts Information

1. Decode the transfer switch model number from the nameplate to determine the transfer switch's electrical controls, voltage and frequency, poles and phases, wires, enclosure type, and current rating. See Section 1.4.
2. Locate the section that illustrates the part(s) that are needed.
3. Locate the part(s) in the illustration.
4. When there are multiple possibilities for parts, use the transfer switch characteristics determined in step 1 to locate the part number and quantity required. The quantity is shown either at the end of the description in parentheses, or in a separate column when there are alternatives.


7.1.2 Leads

Fabricate replacement leads using the same type of wire as the old leads. Add terminals and lead markers at each end of the new lead. See Section 3.1.2 for instructions on wiring repair and replacement.

7.1.3 Common Hardware


Common hardware such as nuts, bolts, screws, and washers are Grade 2 unless otherwise noted and can be obtained locally if the same type and grade is available. Refer to Appendices B through E for general torque specifications and to help to identify parts that may not be shown in the parts lists.

7.2 Contactor



Item	Part Number	Description	All	Quantity by Characteristic					
				100 Amps			200 Amps		
				208 V	220/240 V	208 V	220/240 V		
				Poles					
				3	2	3	3	2	3
1	A-353602	Contactory assembly, 3 pole, 208 V, 100 amps		1					
	A-353600	Contactory assembly, 2 pole, 220/240 V, 100 amps			1				
	A-353603	Contactory assembly, 3 pole, 220/240 V, 100 amps				1			
	A-353676	Contactory assembly, 3 pole, 208 V, 200 amps					1		
	A-353674	Contactory assembly, 2 pole, . 220/240 V., 200 amps						1	
	A-353677	Contactory assembly, 3 pole, 220/240 V, 200 amps							1
2	362087	Solenoid, 208 VAC, 18.1 Ω		1			1		
	362135	Solenoid, 220/240 VAC, 28.8 Ω			1	1		1	1
3	362080	Rectifier assembly, full wave bridge	1						
4	362079	Screw, rectifier retaining	1						
5	362084	Arc chute assembly (3)					3	2	3
6	362086	Cover, arc chute		1	1	1			
7	GM10920	Wiring harness, contactor	1						
8	297949	Tag, hang	1						
9	X-22-11	Washer, lock, .262 ID x .469 in. OD	4						
10	X-81-10	Nut, hex, 1/4-20	4						
11	362081	Switch, coil-clearing, SCN/SCE	2						
12	362077	Clamp, solenoid retaining	1						
13	362076	Screw, solenoid retaining	2						
14	362083	Screw, coil clearing switch retaining	2						


7.3 Controls



DP-295000


Item	Part Number	Description	Quantity by Characteristic			
			All	3 Phase		
				208 V	220 V	240 V
1	362107	Three-phase module, 208 V		1		
	362138	Three-phase module, 220 V			1	
	362108	Three-phase module, 240 V				1
2	X-71-2	Nut, hex machine screw, 6-32		2	2	2
3	—	Washer, #6		2	2	2
4	282831	Stud, blind self-clinching, 6-32 x .500	2			
5	A-353529	PCB assembly, solid-state ATS controls. Includes relays 295253 (2)	1			
6	X-22-6	Washer, lock, .146 ID x .285 in. OD	4			
7	X-49-2	Screw, cross recess pan head machine, #6-32 x .375	4			
8	353619	Standoff, blind self-clinching, 6-32 x 0.500	4			
9	362143	Wiring harness, exerciser	1			
10	362141	Switch, toggle, SPDT pole, exerciser	1			
11	353618	Panel, mounting	1			
12	X-6048-2	Jumper, term block 2 pos	1			
13	295253	Relay, 10 A, NR/ER, 120 Ω coil	2			
14	337441	Standoff, PCB push-on, .146 Dia., 0.5 tall	5			

7.4 Decals



Item	Part Number	Description	Quantity by NEMA Enclosure Type		
			All	1	3R
1	362112	Decal, ATS rating	1		
2	297556	Decal, torque	1		
3	362129	Decal, engine start	1		
4	X-6303-3	Decal, "TRANSFER SWITCH"	1		
5	362176	Decal, danger	1		
6	X-6301-8	Decal, logo	1		
7	362145	Decal, exerciser ATS	1		
8	298777	Envelope, manual	1		
9	362144	Decal, logic ATS	1		
10	362130	Decal, NEMA 3R rating ATS			1
	362131	Decal, NEMA 1 rating ATS		1	
11	224233	Decal, 1-800 number	1		
12	345211	Decal, ground	1		


7.5 Enclosure NEMA Type 1



DP-295000

Item	Part Number	Description
1	X-67-52	Screw, hex washer, thread-forming (16)
2	353617	Panel, ATS, top and bottom (2)
3	353616	Box, ATS
4	—	Nut, hex, 10-32 (4)
5	353615	Cover, ATS
6	362126	Lug, terminal, copper
7	X-22-11	Washer, lock, .262 ID x .469 in. OD
8	X-81-8	Nut, hex, 1/4-20

Enclosure
NEMA Type 3R




DP-295000

Item	Part Number	Description
1	362441	Enclosure (includes 353613, 353614, and 353708)
2	353613	Box
3	—	Nut, hex, 10-32 (4)
4	X-67-52	Screw, hex washer, thread-forming, 10-32 x 0.500 (2)
5	353614	Cover
6	353708	Hasp
7	362126	Lug, terminal, copper
8	X-81-8	Nut, hex, 1/4-20
9	X-22-11	Washer, lock, .262 ID x .469 in. OD

7.6 Neutral Lug


100 Amp



Item	Part Number	Description
1	233269	Insulator, panel (2)
2	295304	Bracket, mounting
3	—	Washer, 1/4 (2)
4	X-22-11	Washer, lock, .262 ID x .469 in. OD (2)
5	X-465-6	Bolt, 1/4-20 x .50 (2)
6	295303	Lug, terminal, aluminum (3)
7	X-22-9	Washer, lock, .20 ID x .373 in. OD (3)
8	X-97-11	Screw, slotted hex head machine, 10-32 x 0.500 (3)

Neutral Lug

200 Amp



Item	Part Number	Description
1	233269	Insulator, panel (2)
2	297713	Bracket, mounting
3	—	Washer, 1/4 (2)
4	X-22-11	Washer, lock, .262 ID x .469 in. OD (7)
5	297712	Lug, terminal (3)
6	X-465-6	Bolt, 1/4-20 x .50 (5)

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	CG	center of gravity	F	Fahrenheit, female
ABDC	after bottom dead center	CID	cubic inch displacement	fglass.	fiberglass
AC	alternating current	CL	centerline	FHM	flat head machine (screw)
A/D	analog to digital	cm	centimeter	fl. oz.	fluid ounce
ADC	analog to digital converter	cmm	cubic meters per minute	flex.	flexible
adj.	adjust, adjustment	CMOS	complementary metal oxide substrate (semiconductor)	freq.	frequency
ADV	advertising dimensional drawing	cogen.	cogeneration	FS	full scale
AHWT	anticipatory high water temperature	COM	communications (port)	ft.	foot, feet
AISI	American Iron and Steel Institute	conn.	connection	ft. lbs.	foot pounds (torque)
ALOP	anticipatory low oil pressure	cont.	continued	ft./min.	feet per minute
alt.	alternator	CPVC	chlorinated polyvinyl chloride	g	gram
Al	aluminum	crit.	critical	ga.	gauge (meters, wire size)
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CRT	cathode ray tube	gal.	gallon
		CSA	Canadian Standards Association	gen.	generator
AO	anticipatory only	CT	current transformer	genset	generator set
API	American Petroleum Institute	Cu	copper	GFI	ground fault interrupter
approx.	approximate, approximately	cu. in.	cubic inch	gnd.	ground
AR	as required, as requested	cw.	clockwise	gov.	governor
AS	as supplied, as stated, as suggested	CWC	city water-cooled	gph	gallons per hour
ASE	American Society of Engineers	cyl.	cylinder	gpm	gallons per minute
ASME	American Society of Mechanical Engineers	D/A	digital to analog	gr.	grade, gross
assy.	assembly	DAC	digital to analog converter	gr. wt.	gross weight
ASTM	American Society for Testing Materials	dB	decibel	H x W x D	height by width by depth
ATDC	after top dead center	dBA	decibel (A weighted)	HC	hex cap
ATS	automatic transfer switch	DC	direct current	HCHT	high cylinder head temperature
auto.	automatic	DCR	direct current resistance	HD	heavy duty
aux.	auxiliary	deg., °	degree	HET	high exhaust temperature
A/V	audio/visual	dept.	department	hex	hexagon
avg.	average	dia.	diameter	Hg	mercury (element)
AVR	automatic voltage regulator	DI/EO	dual inlet/end outlet	HH	hex head
AWG	American Wire Gauge	DIN	Deutsches Institut fur Normung e. V. (also Deutsche Industrie Normenausschuss)	HHC	hex head cap
AWM	appliance wiring material	DIP	dual inline package	HP	horsepower
bat.	battery	DPDT	double-pole, double-throw	hr.	hour
BBDC	before bottom dead center	DPST	double-pole, single-throw	HS	heat shrink
BC	battery charger, battery charging	DS	disconnect switch	hsg.	housing
BCA	battery charging alternator	DVR	digital voltage regulator	HVAC	heating, ventilation, and air conditioning
BCI	Battery Council International	E, emer.	emergency (power source)	HWT	high water temperature
BDC	before dead center	EDI	electronic data interchange	Hz	hertz (cycles per second)
BHP	brake horsepower	EFR	emergency frequency relay	IC	integrated circuit
blk.	black (paint color), block (engine)	e.g.	for example (<i>exempli gratia</i>)	ID	inside diameter, identification
blk. htr.	block heater	EG	electronic governor	IEC	International Electrotechnical Commission
BMEP	brake mean effective pressure	EGSA	Electrical Generating Systems Association	IEEE	Institute of Electrical and Electronics Engineers
bps	bits per second	EIA	Electronic Industries Association	IMS	improved motor starting
br.	brass	EI/EO	end inlet/end outlet	in.	inch
BTDC	before top dead center	EMI	electromagnetic interference	in. H ₂ O	inches of water
Btu	British thermal unit	emiss.	emission	in. Hg	inches of mercury
Btu/min.	British thermal units per minute	eng.	engine	in. lbs.	inch pounds
C	Celsius, centigrade	EPA	Environmental Protection Agency	Inc.	incorporated
cal.	calorie	EPS	emergency power system	ind.	industrial
CARB	California Air Resources Board	ER	emergency relay	int.	internal
CB	circuit breaker	ES	engineering special, engineered special	int./ext.	internal/external
cc	cubic centimeter	ESD	electrostatic discharge	I/O	input/output
CCA	cold cranking amps	est.	estimated	IP	iron pipe
ccw.	counterclockwise	E-Stop	emergency stop	ISO	International Organization for Standardization
CEC	Canadian Electrical Code	etc.	et cetera (and so forth)	J	joule
cfh	cubic feet per hour	exh.	exhaust	JIS	Japanese Industry Standard
cfm	cubic feet per minute	ext.	external	k	kilo (1000)
				K	kelvin
				kA	kiloampere
				KB	kilobyte (2 ¹⁰ bytes)
				kg	kilogram

kg/cm ²	kilograms per square centimeter	mW	milliwatt	rnd.	round
kgm	kilogram-meter	μF	microfarad	ROM	read only memory
kg/m ³	kilograms per cubic meter	N, norm.	normal (power source)	rot.	rotate, rotating
kHz	kilohertz	NA	not available, not applicable	rpm	revolutions per minute
kJ	kilojoule	nat. gas	natural gas	RS	right side
km	kilometer	NBS	National Bureau of Standards	RTV	room temperature vulcanization
kOhm, kΩ	kilo-ohm	NC	normally closed	SAE	Society of Automotive Engineers
kPa	kilopascal	NEC	National Electrical Code	scfm	standard cubic feet per minute
kph	kilometers per hour	NEMA	National Electrical Manufacturers Association	SCR	silicon controlled rectifier
kV	kilovolt	NFPA	National Fire Protection Association	s, sec.	second
kVA	kilovolt ampere	Nm	newton meter	SI	<i>Système international d'unités</i> , International System of Units
kVAR	kilovolt ampere reactive	NO	normally open	SI/EO	side in/end out
kW	kilowatt	no., nos.	number, numbers	sil.	silencer
kWh	kilowatt-hour	NPS	National Pipe, Straight	SN	serial number
kWm	kilowatt mechanical	NPSC	National Pipe, Straight-coupling	SPDT	single-pole, double-throw
L	liter	NPT	National Standard taper pipe thread per general use	SPST	single-pole, single-throw
LAN	local area network	NPTF	National Pipe, Taper-Fine	spec, specs	specification(s)
L x W x H	length by width by height	NR	not required, normal relay	sq.	square
lb.	pound	ns	nanosecond	sq. cm	square centimeter
lbm/ft ³	pounds mass per cubic feet	O/C	overcrank	sq. in.	square inch
LCB	line circuit breaker	OD	outside diameter	SS	stainless steel
LCD	liquid crystal display	OEM	original equipment manufacturer	std.	standard
ld. shd.	load shed	O/F	overfrequency	stl.	steel
LED	light emitting diode	opt.	option, optional	tach.	tachometer
Lph	liters per hour	O/S	oversize, overspeed	TD	time delay
Lpm	liters per minute	OSHA	Occupational Safety and Health Administration	TDC	top dead center
LOP	low oil pressure	O/V	overvoltage	TDEC	time delay engine cooldown
LP	liquefied petroleum	oz.	ounce	TDEN	time delay emergency to normal
LPG	liquefied petroleum gas	p., pp.	page, pages	TDES	time delay engine start
LS	left side	PA	packed accessory	TDNE	time delay normal to emergency
L _{wa}	sound power level, A weighted	PC	personal computer	TDOE	time delay off to emergency
LWL	low water level	PCB	printed circuit board	TDON	time delay off to normal
LWT	low water temperature	pF	picofarad	temp.	temperature
m	meter, milli (1/1000)	PF	power factor	term.	terminal
M	mega (10 ⁶ when used with SI units), male	ph.	phase	TIF	telephone influence factor
m ³	cubic meter	PHC	Phillips head crimplite (screw)	TIR	total indicator reading
m ³ /min.	cubic meters per minute	PHH	Phillips hex head (screw)	tol.	tolerance
mA	milliampere	PHM	pan head machine (screw)	turbo.	turbocharger
man.	manual	PLC	programmable logic control	typ.	typical (same in multiple locations)
max.	maximum	PMG	permanent magnet generator	U/F	underfrequency
MB	megabyte (2 ²⁰ bytes)	pot	potentiometer, potential	UHF	ultrahigh frequency
MCM	one thousand circular mils	ppm	parts per million	UL	Underwriter's Laboratories, Inc.
meggar	megohmmeter	PROM	programmable read only memory	UNC	unified coarse thread (was NC)
MHz	megahertz	psi	pounds per square inch	UNF	unified fine thread (was NF)
mi.	mile	pt.	pint	univ.	universal
mil	one one-thousandth of an inch	PTC	positive temperature coefficient	U/S	undersize, underspeed
min.	minimum, minute	PTO	power takeoff	UV	ultraviolet
misc.	miscellaneous	PVC	polyvinyl chloride	U/V	undervoltage
MJ	megajoule	qt.	quart	V	volt
mJ	millijoule	qty.	quantity	VAC	volts alternating current
mm	millimeter	R	replacement (emergency) power source	VAR	voltampere reactive
mOhm, mΩ	milliohm	rad.	radiator, radius	VDC	volts direct current
MOhm, MΩ	megohm	RAM	random access memory	VFD	vacuum fluorescent display
MOV	metal oxide varistor	RDO	relay driver output	VGA	video graphics adapter
MPa	megapascal	ref.	reference	VHF	very high frequency
mpg	miles per gallon	rem.	remote	W	watt
mph	miles per hour	RFI	radio frequency interference	WCR	withstand and closing rating
MS	military standard	RH	round head	w/	with
m/sec.	meters per second	RHM	round head machine (screw)	w/o	without
MTBF	mean time between failure	rly.	relay	wt.	weight
MTBO	mean time between overhauls	rms	root mean square	xfmr	transformer
mtg.	mounting				
MW	megawatt				


Appendix B Common Hardware Application Guidelines

Use the information below and on the following pages to identify proper fastening techniques when no specific reference for reassembly is made.

Bolt/Screw Length: When bolt/screw length is not given, use Figure 1 as a guide. As a general rule, a minimum length of one thread beyond the nut and a maximum length of 1/2 the bolt/screw diameter beyond the nut is the preferred method.

Washers and Nuts: Use split lock washers as a bolt locking device where specified. Use SAE flat washers with whiz nuts, spirallock nuts, or standard nuts and preloading (torque) of the bolt in all other applications.

See General Torque Specifications and other torque specifications in the service literature.



1. 1/2 of Bolt Diameter
2. Min. 1 Full Thread Beyond Top of Nut
3. Below Top of Nut


Figure 1. Acceptable Bolt Lengths

Steps for common hardware application:

1. Determine entry hole type: round or slotted.
2. Determine exit hole type: fixed female thread (weld nut), round, or slotted.

For round and slotted exit holes, determine if hardware is greater than 1/2 inch in diameter, or 1/2 inch in diameter or less. Hardware that is *greater than 1/2 inch* in diameter takes a standard nut and SAE washer. Hardware *1/2 inch or less* in diameter can take a properly torqued whiz nut or spirallock nut. See the diagram below.

3. Follow these SAE washer rules after determining exit hole type:
 - a. Always use a washer between hardware and a slot.
 - b. Always use a washer under a nut (see 2 above for exception).
 - c. Use a washer under a bolt when the female thread is fixed (weld nut).
4. Refer to the diagram below, which depicts the preceding hardware configuration possibilities.



1. Cap screw
2. Entry hole types
3. Standard nut and SAE washer
4. Whiz nut or spirallock: up to 1/2" dia. hardware
5. Weld nuts: above 1/2" dia. hardware
6. Exit hole types

Figure 2. Acceptable Hardware Combinations

Appendix C General Torque Specifications

Use the following torque specifications when service literature instructions give no specific torque values. The charts list values for new plated, zinc phosphate, or

oiled threads. Increase values by 15% for nonplated threads. All torque values are +0%/-10%.

American Standard Fasteners Torque Specifications

Size	Torque Measurement	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 2 or 5
		Grade 2	Grade 5	Grade 8	
8-32	in. lbs. (Nm)	16 (1.8)	20 (2.3)	—	16 (1.8)
10-24	in. lbs. (Nm)	26 (2.9)	32 (3.6)	—	26 (2.9)
10-32	in. lbs. (Nm)	26 (2.9)	32 (3.6)	—	26 (2.9)
1/4-20	in. lbs. (Nm)	60 (6.8)	96 (10.8)	132 (14.9)	60 (6.8)
1/4-28	in. lbs. (Nm)	72 (8.1)	108 (12.2)	144 (16.3)	72 (8.1)
5/16-18	in. lbs. (Nm)	120 (13.6)	192 (21.7)	264 (29.8)	120 (13.6)
5/16-24	in. lbs. (Nm)	132 (14.9)	204 (23.1)	288 (32.5)	132 (14.9)
3/8-16	ft. lbs. (Nm)	18 (24)	28 (38)	39 (53)	18 (24)
3/8-24	ft. lbs. (Nm)	20 (27)	31 (42)	44 (60)	20 (27)
7/16-14	ft. lbs. (Nm)	29 (39)	44 (60)	63 (85)	—
7/16-20	ft. lbs. (Nm)	32 (43)	50 (68)	70 (95)	—
1/2-13	ft. lbs. (Nm)	44 (60)	68 (92)	96 (130)	—
1/2-20	ft. lbs. (Nm)	49 (66)	76 (103)	108 (146)	—
9/16-12	ft. lbs. (Nm)	60 (81)	98 (133)	138 (187)	—
9/16-18	ft. lbs. (Nm)	67 (91)	109 (148)	154 (209)	—
5/8-11	ft. lbs. (Nm)	83 (113)	135 (183)	191 (259)	—
5/8-18	ft. lbs. (Nm)	94 (128)	153 (208)	216 (293)	—
3/4-10	ft. lbs. (Nm)	147 (199)	240 (325)	338 (458)	—
3/4-16	ft. lbs. (Nm)	164 (222)	268 (363)	378 (513)	—
1-8	ft. lbs. (Nm)	191 (259)	532 (721)	818 (1109)	—
1-12	ft. lbs. (Nm)	209 (283)	582 (789)	895 (1214)	—

Metric Fasteners Torque Specifications, Measured in ft. lbs. (Nm)

Size (mm)	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 5.8 or 8.8
	Grade 5.8	Grade 8.8	Grade 10.9	
M6 x 1.00	4 (5.6)	7 (9.9)	10 (14)	4 (5.6)
M8 x 1.25	10 (13.6)	18 (25)	26 (35)	10 (13.6)
M8 x 1.00	16 (21)	18 (25)	26 (35)	16 (21)
M10 x 1.50	20 (27)	35 (49)	50 (68)	20 (27)
M10 x 1.25	29 (39)	35 (49)	50 (68)	29 (39)
M12 x 1.75	35 (47)	61 (83)	86 (117)	—
M12 x 1.50	48 (65)	65 (88)	92 (125)	—
M14 x 2.00	55 (74)	97 (132)	136 (185)	—
M14 x 1.50	74 (100)	103 (140)	142 (192)	—
M16 x 2.00	85 (115)	148 (200)	210 (285)	—
M16 x 1.50	104 (141)	155 (210)	218 (295)	—
M18 x 2.50	114 (155)	203 (275)	288 (390)	—
M18 x 1.50	145 (196)	225 (305)	315 (425)	—

Appendix D Common Hardware Identification

Screw/Bolts/Studs	
Head Styles	
Hex Head or Machine Head	
Hex Head or Machine Head with Washer	
Flat Head (FHM)	
Round Head (RHM)	
Pan Head	
Hex Socket Head Cap or Allen™ Head Cap	
Hex Socket Head or Allen™ Head Shoulder Bolt	
Sheet Metal Screw	
Stud	
Drive Styles	
Hex	
Hex and Slotted	
Phillips®	
Slotted	
Hex Socket	

Nuts	
Nut Styles	
Hex Head	
Lock or Elastic	
Square	
Cap or Acorn	
Wing	
Washers	
Washer Styles	
Plain	
Split Lock or Spring	
Spring or Wave	
External Tooth Lock	
Internal Tooth Lock	
Internal-External Tooth Lock	


Hardness Grades	
American Standard	
Grade 2	
Grade 5	
Grade 8	
Grade 8/9 (Hex Socket Head)	
Metric	
Number stamped on hardware; 5.8 shown	

Allen™ head screw is a trademark of Holo-Krome Co.


Phillips® screw is a registered trademark of Phillips Screw Company.

Sample Dimensions


American Standard (Screws, Bolts, Studs, and Nuts)



Metric (Screws, Bolts, Studs, and Nuts)



Plain Washers



Lock Washers



Appendix E Common Hardware List

The Common Hardware List lists part numbers and dimensions for common hardware items.

American Standard

Part No.	Dimensions	Part No.	Dimensions	Part No.	Dimensions	Type
Hex Head Bolts (Grade 5)		Hex Head Bolts, cont.		Hex Nuts		
X-465-17	1/4-20 x .38	X-6238-14	3/8-24 x .75	X-6009-1	1-8	Standard
X-465-6	1/4-20 x .50	X-6238-16	3/8-24 x 1.25	X-6210-3	6-32	Whiz
X-465-2	1/4-20 x .62	X-6238-21	3/8-24 x 4.00	X-6210-4	8-32	Whiz
X-465-16	1/4-20 x .75	X-6238-22	3/8-24 x 4.50	X-6210-5	10-24	Whiz
X-465-18	1/4-20 x .88	X-6024-5	7/16-14 x .75	X-6210-1	10-32	Whiz
X-465-7	1/4-20 x 1.00	X-6024-2	7/16-14 x 1.00	X-6210-2	1/4-20	Spiralock
X-465-8	1/4-20 x 1.25	X-6024-8	7/16-14 x 1.25	X-6210-6	1/4-28	Spiralock
X-465-9	1/4-20 x 1.50	X-6024-3	7/16-14 x 1.50	X-6210-7	5/16-18	Spiralock
X-465-10	1/4-20 x 1.75	X-6024-4	7/16-14 x 2.00	X-6210-8	5/16-24	Spiralock
X-465-11	1/4-20 x 2.00	X-6024-11	7/16-14 x 2.75	X-6210-9	3/8-16	Spiralock
X-465-12	1/4-20 x 2.25	X-6024-12	7/16-14 x 6.50	X-6210-10	3/8-24	Spiralock
X-465-14	1/4-20 x 2.75	X-129-15	1/2-13 x .75	X-6210-11	7/16-14	Spiralock
X-465-21	1/4-20 x 5.00	X-129-17	1/2-13 x 1.00	X-6210-12	1/2-13	Spiralock
X-465-25	1/4-28 x .38	X-129-18	1/2-13 x 1.25	X-6210-15	7/16-20	Spiralock
X-465-20	1/4-28 x 1.00	X-129-19	1/2-13 x 1.50	X-6210-14		Spiralock
X-125-33	5/16-18 x .50	X-129-20	1/2-13 x 1.75	X-85-3	5/8-11	Standard
X-125-23	5/16-18 x .62	X-129-21	1/2-13 x 2.00	X-88-12	3/4-10	Standard
X-125-3	5/16-18 x .75	X-129-22	1/2-13 x 2.25	X-89-2	1/2-20	Standard
X-125-31	5/16-18 x .88	X-129-23	1/2-13 x 2.50			
X-125-5	5/16-18 x 1.00	X-129-24	1/2-13 x 2.75	Washers		
X-125-24	5/16-18 x 1.25	X-129-25	1/2-13 x 3.00	Part No.	ID	OD
X-125-34	5/16-18 x 1.50	X-129-27	1/2-13 x 3.50			Thick.
X-125-25	5/16-18 x 1.75	X-129-29	1/2-13 x 4.00			Bolt/
X-125-26	5/16-18 x 2.00	X-129-30	1/2-13 x 4.50			Screw
230578	5/16-18 x 2.25	X-463-9	1/2-13 x 5.50	X-25-46	.125	.250
X-125-29	5/16-18 x 2.50	X-129-44	1/2-13 x 6.00	X-25-9	.156	.375
X-125-27	5/16-18 x 2.75	X-129-51	1/2-20 x .75	X-25-48	.188	.438
X-125-28	5/16-18 x 3.00	X-129-45	1/2-20 x 1.25	X-25-36	.219	.500
X-125-22	5/16-18 x 4.50	X-129-52	1/2-20 x 1.50	X-25-40	.281	.625
X-125-32	5/16-18 x 5.00	X-6021-3	5/8-11 x 1.00	X-25-85	.344	.687
X-125-35	5/16-18 x 5.50	X-6021-4	5/8-11 x 1.25	X-25-37	.406	.812
X-125-36	5/16-18 x 6.00	X-6021-2	5/8-11 x 1.50	X-25-34	.469	.922
X-125-40	5/16-18 x 6.50	X-6021-1	5/8-11 x 1.75	X-25-26	.531	1.062
X-125-43	5/16-24 x 1.75	273049	5/8-11 x 2.00	X-25-15	.656	1.312
X-125-44	5/16-24 x 2.50	X-6021-5	5/8-11 x 2.25	X-25-29	.812	1.469
X-125-30	5/16-24 x .75	X-6021-6	5/8-11 x 2.50	X-25-127	1.062	2.000
X-125-39	5/16-24 x 2.00	X-6021-7	5/8-11 x 2.75			
X-125-38	5/16-24 x 2.75	X-6021-12	5/8-11 x 3.75			
X-6238-2	3/8-16 x .62	X-6021-11	5/8-11 x 4.50			
X-6238-10	3/8-16 x .75	X-6021-10	5/8-11 x 6.00			
X-6238-3	3/8-16 x .88	X-6021-9	5/8-18 x 2.50			
X-6238-11	3/8-16 x 1.00	X-6239-1	3/4-10 x 1.00			
X-6238-4	3/8-16 x 1.25	X-6239-8	3/4-10 x 1.25			
X-6238-5	3/8-16 x 1.50	X-6239-2	3/4-10 x 1.50			
X-6238-1	3/8-16 x 1.75	X-6239-3	3/4-10 x 2.00			
X-6238-6	3/8-16 x 2.00	X-6239-4	3/4-10 x 2.50			
X-6238-17	3/8-16 x 2.25	X-6239-5	3/4-10 x 3.00			
X-6238-7	3/8-16 x 2.50	X-6239-6	3/4-10 x 3.50			
X-6238-8	3/8-16 x 2.75	X-792-1	1-8 x 2.25			
X-6238-9	3/8-16 x 3.00	X-792-5	1-8 x 3.00			
X-6238-19	3/8-16 x 3.25	X-792-8	1-8 x 5.00			
X-6238-12	3/8-16 x 3.50					
X-6238-20	3/8-16 x 3.75					
X-6238-13	3/8-16 x 4.50					
X-6238-18	3/8-16 x 5.50					
X-6238-25	3/8-16 x 6.50					

Metric

Hex head bolts are hardness grade 8.8 unless noted.

Part No.	Dimensions	Part No.	Dimensions	Part No.	Dimensions	Type
Hex Head Bolts (partial thread)		Hex Head Bolts (full thread)		Hex Nuts		
M931-06040-60	M6-1.00 x 40	M933-04006-60	M4-0.70 x 6	M934-03-50	M3-0.50	Standard
M931-06055-60	M6-1.00 x 55	M933-05050-60	M5-0.80 x 50	M934-04-50	M4-0.70	Standard
M931-06060-60	M6-1.00 x 60	M933-06010-60	M6-1.00 x 10	M934-05-50	M5-0.80	Standard
M931-06070-60	M6-1.00 x 70	M933-06014-60	M6-1.00 x 14	M982-05-80	M5-0.80	Elastic Stop
M931-06075-60	M6-1.00 x 75	M933-06016-60	M6-1.00 x 16	M6923-06-80	M6-1.00	Spiralock
M931-06090-60	M6-1.00 x 90	M933-06020-60	M6-1.00 x 20	M934-06-64	M6-1.00	Std. (green)
M931-08035-60	M8-1.25 x 35	M933-06025-60	M6-1.00 x 25	M982-06-80	M6-1.00	Elastic Stop
M931-08040-60	M8-1.25 x 40	M933-06040-60	M6-1.00 x 40	M6923-08-80	M8-1.25	Spiralock
M931-08040-82	M8-1.25 x 40*	M933-06050-60	M6-1.00 x 50	M934-08-60	M8-1.25	Standard
M931-08045-60	M8-1.25 x 45	M933-08016-60	M8-1.25 x 16	M982-08-80	M8-1.25	Elastic Stop
M931-08050-60	M8-1.25 x 50	M933-08020-60	M8-1.25 x 20	M6923-10-80	M10-1.50	Spiralock
M931-08055-82	M8-1.25 x 55*	M933-08025-60	M8-1.25 x 25	M982-10-80	M10-1.50	Elastic Stop
M931-08060-60	M8-1.25 x 60	M933-08030-60	M8-1.25 x 30	M6923-12-80	M12-1.75	Spiralock
M931-08070-60	M8-1.25 x 70	M933-10012-60	M10-1.50 x 12	M982-12-80	M12-1.75	Elastic Stop
M931-08070-82	M8-1.25 x 70*	M961-10020-60	M10-1.25 x 20	M982-14-80	M14-2.00	Elastic Stop
M931-08075-60	M8-1.25 x 75	M933-10020-60	M10-1.50 x 20	M6923-16-80	M16-2.00	Spiralock
M931-08080-60	M8-1.25 x 80	M933-10025-60	M10-1.50 x 25	M982-16-80	M16-2.00	Elastic Stop
M931-08090-60	M8-1.25 x 90	M933-10030-60	M10-1.50 x 30	M982-18-80	M18-2.50	Elastic Stop
M931-08095-60	M8-1.25 x 95	M933-10030-82	M10-1.50 x 30*	M6923-22-80	M22-2.50	Spiralock
M931-08100-60	M8-1.25 x 100	M961-10035-60	M10-1.25 x 35	M982-22-80	M22-2.50	Elastic Stop
M931-10040-60	M10-1.50 x 40	M933-10035-60	M10-1.50 x 35	M934-24-80	M24-3.00	Standard
M931-10045-60	M10-1.50 x 45	M933-12016-60	M12-1.75 x 16	M982-24-80	M24-3.00	Elastic Stop
M931-10050-60	M10-1.50 x 50	M933-12020-60	M12-1.75 x 20	Washers		
M931-10055-60	M10-1.50 x 55	M933-12025-60	M12-1.75 x 25	Part No.	ID OD	Bolt/ Thick. Screw
M931-10060-60	M10-1.50 x 60	M933-12025-82	M12-1.75 x 25*			
M931-10065-60	M10-1.50 x 65	M933-12030-60	M12-1.75 x 30	M125A-03-80	3.2 7.0	0.5 M3
M931-10070-60	M10-1.50 x 70	M933-12040-60	M12-1.75 x 40	M125A-04-80	4.3 9.0	0.8 M4
M931-10080-60	M10-1.50 x 80	M933-12040-82	M12-1.75 x 40*	M125A-05-80	5.3 10.0	1.0 M5
M931-10090-60	M10-1.50 x 90	M961-14025-60	M14-1.50 x 25	M125A-06-80	6.4 12.0	1.6 M6
M931-10100-60	M10-1.50 x 100	M933-14025-60	M14-2.00 x 25	M125A-08-80	8.4 16.0	1.6 M8
M931-12045-60	M12-1.75 x 45	M961-16025-60	M16-1.50 x 25	M125A-10-80	10.5 20.0	2.0 M10
M931-12050-60	M12-1.75 x 50	M933-16025-60	M16-2.00 x 25	M125A-12-80	13.0 24.0	2.5 M12
M931-12055-60	M12-1.75 x 55	M933-16030-82	M16-2.00 x 30*	M125A-14-80	15.0 28.0	2.5 M14
M931-12060-60	M12-1.75 x 60	M933-16035-60	M16-2.00 x 35	M125A-16-80	17.0 30.0	3.0 M16
M931-12065-60	M12-1.75 x 65	M933-16040-60	M16-2.00 x 40	M125A-18-80	19.0 34.0	3.0 M18
M931-12080-60	M12-1.75 x 80	M933-16050-60	M16-2.00 x 50	M125A-20-80	21.0 37.0	3.0 M20
M931-12090-60	M12-1.75 x 90	M933-16050-82	M16-2.00 x 50*	M125A-24-80	25.0 44.0	4.0 M24
M931-12100-60	M12-1.75 x 100	M933-16060-60	M16-2.00 x 60			
M931-12110-60	M12-1.75 x 110	M933-18050-60	M18-2.50 x 50			
M931-16090-60	M16-2.00 x 90	M933-18060-60	M18-2.50 x 60			
M931-20065-60	M20-2.50 x 65	Pan Head Machine Screws				
M931-20120-60	M20-2.50 x 120	M7985A-03010-20	M3-0.50 x 10			
M931-20160-60	M20-2.50 x 160	M7985A-03012-20	M3-0.50 x 12			
M931-22090-60	M22-2.50 x 90	M7985A-04020-20	M4-0.70 x 20			
M931-22120-60	M22-2.50 x 120	M7985A-05010-20	M5-0.80 x 10			
M931-22160-60	M22-2.50 x 160	M7985A-05012-20	M5-0.80 x 12			
M931-24090-60	M24-3.00 x 90	Flat Head Machine Screws				
M931-24120-60	M24-3.00 x 120	M965A-05016-20	M5-0.80 x 16			
M931-24160-60	M24-3.00 x 160					

* This metric hex bolt's hardness is grade 10.9.



DDC/MTU Power Generation
605 North 8th Street, Suite 501
Sheboygan, Wisconsin 53081 USA
Phone 920-451-0846, Fax 920-451-0843
ddcmtupowergeneration.com