

VOLVO

- ① Click UDDIA
- ② Password - KATOLIT 1 Click OK
- ③ HIT IDENTIFY = JobCard = Job # Click OK
- ④ Click GenSet then OK (Then Communicates)
- ⑤ Click Service and Maintenance
- ⑥ Click Programmer Programming (Then Communicates)
- ⑦ Go to Coolant Temp
- ⑧ Hit play button
- ⑨ Hit coolant temp 205 F.S.O. - Hit OK
- ⑩ Change 205 to 217 Hit OK
- then asks if you want to change parameter = Yes
- ⑪ Scroll down to ~~PER~~ ECR Piston cool change to NO or make sure its on NO!
- ⑫ Hit back button then asks you to turn Battery power off then asks to turn it back on
- ⑬ Then should be done Hit File then Exit
- ⑭ Don't EVER Finalize when they ask

