

Atlas Copco Generator Trailer

Series 4600 (for QAS 186-246)

Parts list

1310 3011 17 Ed. 3 2003-06

“Copyright 1998, Atlas Copco Compressors, Inc. Holyoke, Massachusetts
Any unauthorized use or copying of the contents or any part of this book is prohibited.
This applies in particular to trademarks, model denominations, part numbers and
drawings.”

No. 1310 3011 17 Ed. 3
2003-06



OWNERSHIP DATA

Unit model: _____ Owner's machine no.: _____

Electric motor type: _____ Unit service no.: _____

Delivery date: _____ Motor serial no.: _____

Service plan: _____ First start-up date: _____

Selected Lubricants

Compressor: _____ Capacity: _____

Bearing grease type, electric motor: _____

Printed Matter Nos.

Atlas Copco instruction book: _____ Atlas Copco logbook: _____

Atlas Copco parts list: _____ Motor parts list: _____

Local Atlas Copco Representative

Name: _____

Address: _____

Telephone: _____ Contact persons: _____ Service: _____

Telefax: _____ Parts: _____

Example parts list

Ref.	Part number	Qty	Name	Remarks
1	1310 0332 64	158	Screw - Round Head	
2	1310 0326 91	2	Hinge	
3	1310 0326 79	2	Fender	

Explanation of columns:

Ref. - Reference number. Relates a part in list and drawing. "x" means that the part is not shown on the drawing. "-" indicates the beginning of a new list item.

Part number. "---" directs to consult another list of which the heading mostly has the same designation. "****" means that the part is not available as spare part. Parts followed by one dot are comprised in the assembly(ies) listed above the first dot.

Qty - A number indicating the quantity of parts. The quantity is only related to its corresponding reference number ("Ref") and may differ from the total quantity of this part for the entire unit. For parts of an assembly the quantity mentioned is for one assembly. "AR" means "as required" : bulk material or quantity to be determined.

Name - Mostly part names. When machine types, Classification Societies, dimensions, etc. are mentioned under the same "Designation", look carefully for the part number for your specific equipment. When a selection is to be made, the various selections are indented and preceded by a dash.

Remarks - A number followed by a bracket, e.g. 1), refers to a footnote.


A number in bold, e.g. 1, refers to a "Service Kit". For the "Service Kit" number, see below list. Parts of one "Service Kit" may be spread over several pages.

ORDERING PARTS

Always quote the part number, "Designation" and quantity of the desired parts as well as type designation and serial number of the unit.


Table of Contents

1.	Trailer Assembly	4
2.	Fuel Tank Assembly.....	5
3.	Hub And Drum Components.....	6
4.	Brake Assembly	7
5.	Hydraulic Brake Assembly	8
6.	Electrical Components.....	9



1. Trailer Assembly


Ref	Part number	Qty	Name	Remarks	Ref	Part number	Qty	Name	Remarks
1	1310 0347 12	1	Tongue Jack			1310 0345 92		Electric Brake Only	
2	1310 0348 43	1	Toolbox		12	1310 0348 29	1	Folding Step	
3	1310 3107 84	2	Safety Chain (3/8")	2	13	1310 3107 80	1	Inner Slide Tube Assembly	1
4	1310 0347 65	2	Atlas Copco Mud Flap		14	1310 0346 35	1	3/32" Cable with hooks (both ends)	1
5	1310 0346 72	1	Towing Eye (2-1/2", gloss black)		15	1310 0347 13	1	Master Cyl. Repair Kit w/gasket	1
6	1310 0329 64	1	Ball Coupler (2-5/16"- gloss black)						
7	1310 0348 44	1	Tow Bar (EB only)		1	Not shown			
8	1310 0346 11	4	Light Bracket, Fender		2	Includes hook and safety chain anchor			
9	1310 0345 81	1	Actuator Kit						
10	1310 0348 55	4	Tire & Wheel Assembly						
11	---	2	Axle Assy., 6000Lb., Torflex			1310 9042 94	Rev. 01		
	1310 0345 93		Hydraulic Brake Only						



2. Fuel Tank Assembly

Ref	Part number	Qty	Name	Remarks	Ref	Part number	Qty	Name	Remarks
1	1310 0348 37	1	Tank, 200 Gal, Double wall		7	1310 0347 31	1	Suction and Return Kit	1
2	1310 0346 86	1	Fuel gauge		8	1310 0347 14	1	Interconnection Kit	1
3	1310 0346 75	2	Suction and Return Tube		9	1310 3106 30	1	Spillage-Free Interconnection Kit	2
4	1310 0346 74	2	Compression Fitting		10	1310 0346 27	1	Low Fuel Shut Down Switch	2
5	1310 0355 33	1	Fill Pipe Kit	3	1	Not shown			
5a	1310 0346 38	1	Prevent cap		2	Optional			
5b	1310 0346 62	1	Coupling, 2"		3	Including prevent cap and 2" coupling			
5c	1310 0347 93	1	Pipe asy, 2" x 27"						
6	1310 0347 93	1	Vent pipe kit	3					
6a	1310 0346 38	1	Prevent cap						
6b	1310 0346 62	1	Coupling						
6c	1310 0347 93	1	Pipe asy, 2" x 27"						


1310 9042 95 Rev. 01



3. Hub And Drum Components

Ref	Part number	Qty	Name	Remarks	Ref	Part number	Qty	Name	Remarks
1	1310 3107 72	1	Bearing Kit including:		G		1	Cotter Pin	
A		1	Grease seal		H		1	Grease Cap	
B		1	Inner Bearing Cone 25580		J		1	Spindle Washer	
C		1	Inner Bearing Cup 25520		2	1310 0347 08	1	Hub & Drum Assembly, 1/2" studs	
D		1	Outer Bearing Cup 14276						
E		1	Outer Bearing Cone 14125A						
F		1	Spindle Nut						


1310 9042 97 Rev. 01



4. Brake Assembly

Ref	Part number	Qty	Name	Remarks	Ref	Part number	Qty	Name	Remarks
1	1310 0347 94	1	Backing Plate Assembly		10	1310 0348 49	1	Anchor Post Washer	
2	---	1	Actuating Lever Arm	1	11	1310 0347 56	5	Lock washer	
	1310 3107 74		Left Hand		12	1310 0347 66	5	Brake Mounting Nut	
	1310 3107 76		Right Hand						
3	1310 0348 28	2	Retractor Spring		1	Includes (2) Wire clips			
4	1310 0347 25	1	Shoe & Lining Kit	2	2	Includes: Primary shoe & lining, Secondary shoe and lining,			
5	1310 0345 84	1	Adjuster Assembly		3	Includes: Magnet (white wire), Magnet clip, Magnet spring			
6	1310 0348 19	1	Adjusting Screw Spring						
7	1310 0347 17	1	Magnet Kit	3					
8	1310 0348 03	1	Plug						
9	1310 0346 90	1	Wire Grommet						

1310 9042 98 Rev. 00



6. Electrical Components

Ref	Part number	Qty	Name	Remarks	Ref	Part number	Qty	Name	Remarks
1	1310 0347 33	1	License Plate Lamp		11	1310 0347 01	1	Wire Harness, HB Only	1
2	1310 0347 42	4	Marker Light, red		12	1310 0346 97	1	Wire Harness, EB Only	1
3	1310 0347 43	4	Marker Light, yellow		13	1310 0348 30	1	Breakaway Switch, EB Only	1
4	1310 0346 89	8	Marker light Grommet		14	1310 0348 57	1	Emergency Brake Wire, EB Only	1
5	1310 0347 45	2	Tail Light Assembly, sealed						
6	1310 0347 44	3	Rear ID Light		1	Not shown			
7	1310 0346 88	3	ID Light Grommet						
8	1310 0346 09	20	Conspicuity Tape						
9	1310 0346 56	1	Connector, 6 way trailer end	1					
10	1310 0347 74	8	Pigtail	1	1310 9043 01	Rev. 00			