



1. Download and install

IL-NT-Install-Suite-2.1r1
 IL-NT-SNMP-2.1.iwe
 IB-Lite1.8.zip

2. Open LiteEdit and import IL-NT-SNMP-2.1.iwe



3. Open archive with SNMP support



4. Generate MIB table

