



Power. Passion. Partnership.

# Up-To-Date

## Service Information

SI-2012-MB-01/00

Minidiag SCR Commissioning password for Mercedes-Benz Tier 4i

<input checked="" type="checkbox"/> Action Required		<input type="checkbox"/> Information Only			Effective: Immediately
<input type="checkbox"/> Global	OR	<input checked="" type="checkbox"/> North America	<input type="checkbox"/> Eastern Europe / CIS	<input type="checkbox"/> China	
		<input type="checkbox"/> Latin America	<input type="checkbox"/> Mediterranean	<input type="checkbox"/> North East Asia	
			<input type="checkbox"/> Northern / Central Europe	<input type="checkbox"/> South East Asia	
			<input type="checkbox"/> Turkey, Middle East, Africa	<input type="checkbox"/> Australia / Pacific	
<input checked="" type="checkbox"/> Principals	<input type="checkbox"/> Sales	<input type="checkbox"/> Parts	<input checked="" type="checkbox"/> Service	<input checked="" type="checkbox"/> Warranty	<input type="checkbox"/> <i>Special Distribution List: Specify</i>

Due to EPA regulations, Tier 4i Mercedes-Benz Engines may enter a state of low power operation (inducement) if there is any issue with the SCR system or its components. If an engine is run for enough time to enter final inducement, a password is required to clear the fault codes (by going through the SCR commissioning routine from the password routines list). Each password is Minidiag serial number specific and therefore must be requested for each and every Minidiag in the field.

### Action Required:

Each distributor must collect the serial numbers of all the Minidiag tools within the organization (including all branches). Once all of the serial numbers are in a list, send an email to [minidiag@daimler.com](mailto:minidiag@daimler.com) with the subject line titled: "SCR commissioning password". In the email, state that the SCR passwords are needed for all of the following Minidiag serial numbers (then list the serial numbers of the tools). You can expect to receive a response within 2-3 business days. Create a label or write the password directly on the correct corresponding Minidiag as the password will never change. The SCR codes cannot be cleared without a commissioning password.

Please address any questions regarding this communication to [MTUdistributorsupport@tognum.com](mailto:MTUdistributorsupport@tognum.com). This communication will be posted on the web within 24 hours.

This communication was issued by department VCNI on January 6, 2012.