



Select primary throttle if you want to control the speed of the engine if not enable digital throttle and 3 stage

production) is interrupted, or ICE is used to pump water in the case of fire or flood, etc.. An ICE used to supply power to an electric grid or that supply power as part of a financial arrangement with another entity are not considered emergency engines. If you are unsure or not able to certify emergency usage of this engine, you should not check this box. Failure to comply could adversely impact engine emissions and be a violation of the applicable emission regulations. Questions should be directed to your JDPS Sales Engineer.

I CERTIFY THAT THIS ENGINE IS BEING USED IN AN EMERGENCY APPLICATION AS DEFINED ABOVE. I understand that by checking this box I need to keep accurate records of final customer installation to ensure it meets the emergency application criteria. These records may be subject to audit and provided to EPA.

<p>Standard Shutdowns</p> <p><input checked="" type="checkbox"/> Enable Coolant Temperature Shutdown</p> <p><input checked="" type="checkbox"/> Enable Fuel Temperature Shutdown</p> <p><input checked="" type="checkbox"/> Enable Intake Manifold Air Temperature Shutdown</p> <p><input checked="" type="checkbox"/> Enable Oil Pressure Shutdown</p> <p><input checked="" type="checkbox"/> Enable Water-in-Fuel Shutdown</p> <p><input checked="" type="checkbox"/> Enable Coolant Level Shutdown (refer to the Loss of Coolant Switch section to enable or disable this shutdown)</p> <p>Shutdown Timer <input type="text" value="Immediate"/></p>	<p>J1939 Enable/Disable Shutdowns</p> <p><input type="checkbox"/> Allow Enable/Disable of Shutdowns by J1939 CAN Message</p> <p><input type="text" value="5"/> Shutdown Message Source Address</p>
--	---

External Shutdown

External Shutdown Enable

External Shutdown Switch Input Type

External Shutdown Timer

Deselect all of the standard shutdowns if you are using a controller that has shutdowns and the external shutdown.

External Shutdown

External Shutdown Enable

External Shutdown Switch Input Type

External Shutdown Timer

Override External Shutdown at Engine Start

Override External Shutdown Time

Fuel Filter Pressure Sensor

Fuel Filter Pressure Sensor Enable

Tachometer Output

Enable Tachometer Output

Pulses per Revolution

Air Filter Restriction Switch

Air Filter Restriction Switch

Help

Read ONLY if Oil Temp is enabled: Enabling Air Filter Restriction Switch while Oil Temp is enabled via this input, will disable the Oil Temperature

Air Filter Restriction Switch Enable

Air Filter Restriction Switch Type

Loss of Coolant Switch

Help

Coolant Level Switch Enable

Coolant Level Switch Type

Enable Coolant Level Shutdown

Start Aids

Help

Electric Start Aid Control

Enable Glow Plugs/Intake Air Heaters

Oil Temperature Sensor

Print...

Program...

Cancel